
SQD Tape Pin Rack - Build Sheet

Visuals

Rack Assembly



Materials & Cuts

• Carbin: 36" length (double saddled)

Long Rods: (4) pieces @ 31"

• Short Rods: (20) pieces @ 3 3/4"

• Mid Rods: (4) pieces @ 8 1/2"

Center washer and bolt

Instructions

- 1 Assemble Frame: Weld the horizontal and vertical rods together to create the grid frame.
- Attach to Carbin: Weld the assembled frame to the 36" carbin spine.
- Center Bolt: Add the center washer and bolt everything into the squares as indicated.

Spacing Notes

Refer to the original diagram for specific weld points and spacing measurements (e.g., 3 1/2", 8 3/8", 15", 21 3/4", etc.).