
Auto 1 Sleeve Rack (20 station) - Build Sheet

Visuals

Rack Assembly



Materials & Cuts

- Carbin: 43 1/4" length
- Tips (20 total): 3/16" rod, 16" long

Instructions

- Cut Carbin: Cut the main carbin spine to its 43 1/4" length.
- Bend & Weld Tips: Bend the 3/16" rod for the 20 tips using the blue bending machine. Weld them onto the spine according to the spacing notes.

Hook Spacing

First tip starts 3" in from the side. Then, there is 4" spacing between each subsequent tip.

```
3", 7", 11", 15", 19", 23", 27", 31", 35", 39", ...
```