
# **SQD Vertical Halfmoon - Build Sheet**

### **Visuals**

#### **Rack Assembly**



#### **Materials & Cuts**

- Carbin: 44" length
- Copper Hook: 4ft length, bent @ 2 1/2" with a twist
- Tips (21 total): 1/4" or 3/16" rod, 12" long

#### **Instructions**

- **Form Hook:** Take the 4ft copper piece, make the J-bend at 2 1/2", and add the twist.
- Assemble: Bolt the copper hook to the top of the 44" carbin spine.
- Bend & Weld Tips: Bend the 21 tips in a press with a jig. Weld them onto the spine according to the spacing measurements.

## **Tip Spacing (From Top)**

First tip starts 2 1/4" down from the top. Then, there is 2" spacing between each subsequent tip.