
# **SQD Jewell Rack - Build Sheet**

## **Visuals**

#### **Rack Assembly**



## **Materials & Cuts**

• Carbin: 36" length

• **Tips:** 1/4" rod, 12" long

## Instructions

- Prepare Carbin: Start with the 36" carbin spine.
- Bend Tips: Cut the 12" tips. Bend each tip into a J-hook as shown in the detail diagram.
- Weld Tips: Weld the finished J-hooks onto the carbin spine according to the spacing measurements.

# **Tip Spacing (From Top)**

3, 6, 9, 12, 15, 18, 21, 24, 27, 30, 33

#### **Tip Bending Detail**

