
Auto 1 Tube Rack (ID) - Build Sheet

Visuals

Rack Assembly



Materials & Cuts

• Carbin: 39 1/2" length

• Copper Hook: 46" length, bent @ 2 1/2" with a twist

• **Tips:** 1/4" rod, 9" long

Instructions

- Form Hook: Take the 46" copper piece, make the J-bend at 2 1/2", and add the twist.
- Assemble: Bolt the copper hook to the top of the 39 1/2" carbin spine.
- 3 Bend & Weld Tips: Bend the 1/4" rod for the tips in a bending machine. Weld them onto the spine according to the spacing measurements.

Tip Spacing (From Top)

First tip starts 3 1/2" down from the top. Then, there is 2" spacing between each subsequent tip.