
Auto 1 Double Sided Pin Rack - Build Sheet

Visuals

Rack Assembly



Materials & Cuts

• Carbin: 41 1/2" length

• Copper Hook: 15" length, bent @ 2 1/2"

Tips: 12" long

• Stops: 5 1/2" long

• Full Length: 46 1/2"

Instructions

- **Form Hook:** Take the 15" copper piece and make the J-bend at 2 1/2".
- Assemble: Bolt the copper hook to the top of the 41 1/2" carbin spine.
- Bend & Weld Tips/Stops: Bend the tips and stops using the appropriate benders. Weld them onto the spine according to the spacing measurements.

Tip Spacing (From Bottom)

Front:

2", 6", 10", 15", 19 1/2", 24", 28 1/2", 32 1/2"

Back:

4 1/2", 9", 13 1/4", 17 1/2", 22", 26 1/2", 31", 35"