SAP Configuration Details

Step 1: Define Notification Type

Path:

SPRO → Quality Management → Quality Notification → Notification Creation → Notification Types

Example:

Notification Type	Description
Q1	Internal Defect
Q2	Vendor Complaint
Q3	Customer Complaint

Step 2: Define Catalogs & Code Groups

Path:

SPRO → QM → Quality Notification → Notification Processing → Catalogs

- Create: Catalog Type = 9 (Defect Type)

Code Group	Defect Code	Description
RAW_DEF	DAMAGED	Material damaged
RAW_DEF	SCRATCH	Surface scratch
RAW_DEF	WRONG_DIM	Dimension issue
RAW_DEF	CONTAMINATION	Contamination

Step 3: Automatic Notification Creation

Path:

SPRO → QM → Quality Inspection → Inspection Lot Creation

Activate:

✓ Automatic defect recording
✓ Automatic QM Notification at UD

Step 4: Task Determination

Path:

SPRO → QM → Quality Notification → Define Tasks

Example Tasks:

Task Code	Description
T01	Root Cause Analysis
T02	Vendor Communication
T03	Corrective Action
T04	Effectiveness Check

Step 5: Status Profile

Create Status Profile:

- CRTD – Created
- INPR – In Process
- RCA – Root Cause Identified
- CAPA – Corrective Action Implemented
- CLSD – Closed