

Master Data & Configuration Details

1. Define Inspection Severity

Path:

SPRO → QM → Quality Inspection → Dynamic Modification → Define Inspection Severity

Severity	Description
N	Normal
R	Reduced
T	Tightened
S	Skip

2. Define Dynamic Modification Rule

Path:

SPRO → QM → Quality Inspection → Dynamic Modification → Define Rules

Example Rule: DMR_01

Stage	From → To	Criteria
1	Normal → Reduced	After 5 accepted lots
2	Reduced → Skip	After 3 accepted lots
3	Any → Tightened	After 1 rejection

3. Define Sampling Procedure

Path:

SPRO → QM → Sampling → Sampling Procedure

Inspection Level	Sampling
Reduced	10%
Normal	50%
Tightened	100%

4. Assign DMR to Inspection Type

Path:

SPRO → QM → Inspection Lot Creation → Assign DMR

Assign to Inspection Type (01 / 04)

5. Material Master Configuration

Transaction: MM02 (QM View)

Maintain:

- Inspection Type (01)
- Dynamic Modification Rule (DMR_01)
- Sampling Procedure

6. Inspection Plan

Transaction: QP01

- Assign MIC (Master Inspection Characteristics)
- Link Sampling Procedure