Start

↓

Material Master → Activate Inspection Type 03 (MM02)

↓

Create MICs (QS21)

↓

Create Routing + Assign MICs (CA01)

↓

Create Production Order (CO01)

↓

Release Order → Inspection Lot Generated

↓

Record Results (QE51N)

↓

Usage Decision (QA11)

↓

Accepted / Rejected

↓

End