1. Energy Bands in Solids & Types of Materials

Definition: In a solid, the energy levels of closely packed atoms merge to form continuous bands of energy called Energy Bands. The gap between the highest occupied band and the lowest empty band determines the electrical properties of the material.

According to the Band Theory of Solids, there are three main energy regions in a solid:

- **Valence Band (VB):** The energy band formed by the valence (outermost) electrons. It is completely or partially filled but never completely empty.
- **Conduction Band (CB):** The energy band above the valence band. Electrons here are free to move and conduct electricity. It can be empty or partially filled.
- **Forbidden Energy Gap (E_g):** The energy gap between the valence band and the conduction band where no electrons can exist.

Types of Materials Based on Band Gap:

1. **Insulators:** Materials that do not conduct electricity. The Forbidden Energy Gap is very large ($E_g > 3$ eV). Electrons in the VB cannot gain enough energy to jump to the CB. Example: Wood, Glass, Diamond.
2. **Conductors:** Materials that easily conduct electricity. The Valence Band and Conduction Band **overlap** each other ($E_g = 0$). Free electrons are always available for conduction. Example: Copper, Silver, Aluminum.
3. **Semiconductors:** Materials with conductivity between insulators and conductors. The Forbidden Energy Gap is very small ($E_g \approx 1$ eV). At absolute zero (0 K), they act as insulators, but at room temperature, some electrons jump to the CB, making them partially conductive. Example: Silicon (1.1 eV), Germanium (0.7 eV).

```
ENERGY BANDS DIAGRAM:

     INSULATOR             SEMICONDUCTOR            CONDUCTOR
  +-------------+         +-------------+         +-------------+
  | Conduction  |         | Conduction  |         | Conduction  |
  | Band (Empty)|         | Band (CB)   |         | Band (CB)   |
  +-------------+         +-------------+         |=============| <-- Overlap
  |             |         |   Small Eg  |         |=============|
  | Large Eg    |         +-------------+         | Valence     |
  | (> 3 eV)    |         | Valence     |         | Band (VB)   |
  +-------------+         | Band (VB)   |         +-------------+
  | Valence     |         +-------------+
  | Band (Full) |
  +-------------+
```

👉 **Hinglish Explanation:** Atoms ke paas aane se solid me energy "Bands" bante hain. Niche wala Valence Band (VB) aur upar wala Conduction Band (CB). Agar inke beech ka gap (Forbidden Gap) bahut bada hai to electron CB me nahi ja payega, use **Insulator** kahenge. Agar gap zero hai (overlap karte hain), to wo **Conductor** hai. Aur agar gap bahut chota (~1 eV) hai, to use **Semiconductor** kehte hain jo garam hone par current flow karta hai.

2. Intrinsic and Extrinsic Semiconductors

Definition: An intrinsic semiconductor is an extremely pure semiconductor, whereas an extrinsic semiconductor is one in which a small amount of impurity is added (doping) to increase its electrical conductivity.

Intrinsic Semiconductors:

These are pure forms of Silicon (Si) or Germanium (Ge). In these materials, every atom forms four covalent bonds with its neighbors. At absolute zero, they are insulators. At room temperature, some bonds break due to thermal energy, creating an equal number of free electrons and "holes" (vacancies left by electrons that act as positive charges).
Rule: Number of electrons (n_e) = Number of holes (n_h). Conductivity is very low.

Extrinsic Semiconductors & Doping:

To make semiconductors useful for electronics, we add impurities. This process is called **Doping**. Depending on the impurity, they are divided into two types:

1. **N-Type Semiconductor:**
   Created by doping with a **Pentavalent** impurity (like Phosphorus, Arsenic, Antimony - having 5 valence electrons).
   Four electrons form bonds, and the 5th electron becomes free.
   Majority Charge Carriers: Electrons. **Minority:** Holes.
2. **P-Type Semiconductor:**
   Created by doping with a **Trivalent** impurity (like Boron, Aluminum, Gallium - having 3 valence electrons).
   Three electrons form bonds, leaving one vacancy called a "hole" which acts as a positive charge.
   Majority Charge Carriers: Holes. **Minority:** Electrons.

👉 **Hinglish Explanation: Intrinsic** matlab ekdum pure Silicon/Germanium (ispe electronics nahi chal sakti kyuki conductivity low hai). **Extrinsic** banane ke liye hum isme thodi milawat (Doping) karte hain. Agar 5 electron wali impurity milayi (Pentavalent), toh ek electron extra bachega aur wo **N-type** ban jayega (N matlab Negative, electrons zyada). Agar 3 electron wali milayi (Trivalent), toh ek jagah khali reh jayegi jise Hole kehte hain, aur wo **P-type** ban jayega (P matlab Positive, Holes zyada).

3. P-N Junction, Junction Diode & V-I Characteristics

Definition: A P-N junction is formed when a P-type semiconductor is suitably joined to an N-type semiconductor. A device containing a single P-N junction is called a P-N Junction Diode, which allows current to flow in only one direction.

Formation of Depletion Layer & Potential Barrier:

The moment a P-N junction is formed, electrons from the N-side diffuse into the P-side, and holes from the P-side diffuse into the N-side. They recombine and neutralize each other near the junction. This creates a region free of mobile charge carriers called the **Depletion Layer**. The accumulation of static ions creates an electric field that opposes further diffusion. This opposing voltage is called the **Potential Barrier** (~0.7V for Si, ~0.3V for Ge).

Biasing of P-N Junction Diode:

- **Forward Bias:** P-side is connected to the Positive terminal, N-side to Negative. The applied voltage pushes majority carriers towards the junction, reducing the depletion layer width. Current flows easily. (Low resistance).
- **Reverse Bias:** P-side to Negative, N-side to Positive. The applied voltage pulls majority carriers away from the junction, widening the depletion layer. Almost no current flows, except a tiny leakage current due to minority carriers. (High resistance).

V-I Characteristics:

The graph showing the relation between applied Voltage (V) and flowing Current (I) is the V-I characteristic.

- **Knee Voltage:** The forward voltage at which current starts increasing rapidly (e.g., 0.7V for Silicon).
- **Breakdown Voltage:** In reverse bias, if the reverse voltage is increased too much, the covalent bonds break, causing a sudden huge reverse current. This destroys a normal diode.

Types of Junction Diodes:

- **Zener Diode:** Heavily doped diode designed to operate in the reverse breakdown region. Used as a Voltage Regulator.
- **LED (Light Emitting Diode):** Emits light when forward biased.
- **Photodiode:** Operated in reverse bias, conducts when light falls on its junction.

```
DIODE SYMBOL:
      P (Anode)      N (Cathode)
      ----|>|----
          |

V-I CHARACTERISTICS GRAPH:
         I (mA)
          |     / Forward Bias
          |   /   (Current increases after Knee Voltage)
          | /
----------+------------ V (Volts)
          |
Reverse   |
Breakdown |
          |
```

👉 **Hinglish Explanation:** Jab P-type (Holes) aur N-type (Electrons) ko jodte hain to P-N junction banta hai. Inke beech ek diwaar ban jati hai jise 'Depletion layer' kehte hain. Agar battery ka Plus P se aur Minus N se jodein (Forward Bias), toh current flow karta hai. Agar ulta jodein (Reverse Bias) to current nahi flow karta. Diode ek "One-way valve" ki tarah kaam karta hai. Knee voltage ke baad hi diode on hota hai (0.7V for Si).

4. Diode as a Rectifier (Half Wave & Full Wave)

Definition: A rectifier is an electronic device that converts Alternating Current (AC) into Direct Current (DC). This process is called rectification. Diodes are used as rectifiers because they allow current to flow in only one direction.

1. Half Wave Rectifier:

It uses a single P-N junction diode connected in series with a load resistor.

- **Working:** During the positive half-cycle of the AC input, the diode is forward-biased and conducts current. During the negative half-cycle, the diode is reverse-biased and blocks the current.
- **Output:** The output contains only positive pulses. The negative half is completely cut off.
- **Disadvantage:** Highly inefficient (maximum efficiency is ~40.6%). Half of the input power is wasted. Output is highly pulsating.

2. Full Wave Rectifier (Centre-Tapped):

It uses two diodes (D_1 and D_2) and a centre-tapped transformer. The load resistor is connected between the center tap and the common point of both diodes.

- **Working:** During the positive half-cycle, D_1 is forward-biased (conducts) and D_2 is reverse-biased (blocked). Current flows through the load. During the negative half-cycle, D_2 becomes forward-biased and D_1 becomes reverse-biased. Current again flows through the load *in the same direction*.
- **Output:** Both half-cycles of AC are converted into DC. The output is a continuous series of positive pulses.
- **Advantage:** Much higher efficiency (~81.2%). Less ripple compared to half-wave. No power is wasted.

```
INPUT AC WAVEFORM:
    /\      /\      /\
___/  \____/  \____/  \___
       \  /    \  /
        \/      \/

HALF WAVE RECTIFIER OUTPUT (1 Diode):
    /\              /\
___/  \____________/  \___   (Only positive half passes)


FULL WAVE RECTIFIER OUTPUT (2 Diodes):
    /\      /\      /\
___/  \____/  \____/  \___   (Both halves become positive)
```

👉 **Hinglish Explanation:** AC (Ghar ki light) ko DC (Battery wali light) me badalne wale device ko **Rectifier** kehte hain (Jaise mobile ka charger). **Half wave** me 1 diode lagta hai, ye aadhi light (negative cycle) ko waste kar deta hai. **Full wave centre-tapped** me 2 diode lagte hain, ye puri light (dono cycle) ko use karke continuous DC banata hai. Isliye Full Wave ki efficiency double hoti hai.

5. Transistor: Description, Terminals & Types

Definition: A Transistor (Transfer + Resistor) is a three-terminal solid-state semiconductor device used to amplify or switch electrical signals and power. It consists of two P-N junctions back-to-back.

Three Terminals of a Transistor:

A Bipolar Junction Transistor (BJT) consists of three doped regions forming three terminals:

1. **Emitter (E):** Heavily doped to supply a large number of majority charge carriers into the base. Moderate size.
2. **Base (B):** Very thin and lightly doped. It passes most of the carriers from the emitter to the collector, controlling their flow.
3. **Collector (C):** Moderately doped but has the largest size/area. Its function is to collect the charge carriers coming from the emitter. It is large because it has to dissipate the most heat.

Types of Transistors:

- **NPN Transistor:** A thin layer of P-type semiconductor is sandwiched between two thick N-type layers. Electrons are the majority carriers. (Arrow points *outward* from Base to Emitter). Most widely used because electrons are faster than holes.
- **PNP Transistor:** A thin layer of N-type semiconductor is sandwiched between two thick P-type layers. Holes are the majority carriers. (Arrow points *inward* from Emitter to Base).

Electronic Applications (List):

Transistors are the building blocks of modern electronics (processors, computers, mobiles). Key applications include:

- As an **Amplifier** (increases the strength of a weak signal - Audio amplifiers).
- As a **Switch** (turns ON/OFF in digital logic circuits and computer memory).
- As an **Oscillator** (generates continuous AC signals of high frequency).
- As a **Modulator / Demodulator** (in communication systems like radio).

```
TRANSISTOR SYMBOLS:

      NPN Transistor                PNP Transistor
            C                             C
           /                             /
          /                             /
   B ----|                       B ----|
          \                             \
           \ v (Arrow Out)               \ ^ (Arrow In)
            E                             E
```

👉 **Hinglish Explanation:** Transistor electronics ka dil hai. Isme 3 pahiye (terminals) hote hain: **Emitter** (carriers ko bhejta hai, heavy doped), **Base** (control karta hai, sabse patla), aur **Collector** (carriers jama karta hai, sabse bada). NPN me arrow bahar ki taraf hota hai aur PNP me andar ki taraf. Ye as a Switch (computers me) aur as an Amplifier (Speakers me awaaz badi karne ke liye) use hota hai.

6. Photocells & Solar Cells

Definition: Both are optoelectronic devices. A Photocell works on the photoelectric effect (light

changing resistance/current), while a Solar Cell is a specially designed P-N junction that converts solar energy directly into electrical energy (Photovoltaic effect).

Photocells:

A photocell (or photo-resistor/LDR) is a device whose electrical resistance decreases when light falls on it. It is used to detect light.

- **Applications of Photocells:** Automatic street light switching, burglar alarms, automatic doors, and light meters in cameras.

Solar Cells (Photovoltaic Cells):

A solar cell is essentially a large-area P-N junction diode designed to capture solar energy. The top layer (usually N-type) is made very thin so that sunlight can penetrate to the junction.

Working Principle:

1. **Generation:** When sunlight (photons with energy > E_g) falls on the P-N junction, the energy is absorbed by the semiconductor atoms, breaking covalent bonds and generating Electron-Hole Pairs (EHP).
2. **Separation:** The built-in electric field of the depletion layer immediately sweeps the electrons to the N-side and the holes to the P-side, preventing them from recombining.
3. **Collection:** The N-side becomes negatively charged and the P-side becomes positively charged. This generates a photo-EMF (voltage). When an external load is connected, current starts flowing.

Engineering Applications of Solar Cells:

- Power supply for **Artificial Satellites** and Space Vehicles (where conventional batteries can't be replaced).
- Off-grid power generation (Solar panels on rooftops, remote villages).
- Small electronic devices (Calculators, digital watches).
- Solar-powered street lights and water pumping systems for irrigation.

👉 **Hinglish Explanation: Photocell** ka kaam light detect karna hai (jaise raat hote hi street light apne aap on ho jati hai). **Solar cell** dhup (sunlight) ko seedha bijli (electricity) me badalta hai. Jab dhup cell ke junction par girti hai, to electron aur holes alag ho jate hain, jisse voltage ban jati hai aur current milne lagta hai. Space satellites me solar panels hi power ka ek matra source hote hain.

🔁 Quick Revision Notes (Exam Saver)

- **Bands:** Insulators have large E_g (>3eV). Conductors overlap. Semiconductors have small E_g (~1eV).
- **Doping:** Pure = Intrinsic. Doped = Extrinsic. Add Pentavalent (5) = N-type (e- majority). Add Trivalent (3) = P-type (Hole majority).
- **P-N Junction:** Forward bias = Conducts. Reverse bias = Blocks. Depletion layer stops current naturally.
- **Rectifier:** AC to DC. Half-wave uses 1 diode (40.6% eff). Full-wave center-tapped uses 2 diodes (81.2% eff).
- **Transistor:** Emitter (heavily doped), Base (thin, light doped), Collector (largest area). NPN is faster/better than PNP. Main uses: Amplifier & Switch.
- **Solar Cell:** Converts light into electricity using P-N junction (Photovoltaic effect). Used in satellites and solar panels.

Powered & Inspired by: Rgpvnotes.tech