
SERVICING FIXTURES & TOOLS

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.		Part No.	Part No. Part Name & Description
		DV ALIGNMENT TAPE (COLOR BAR)		NTSC MODEL ONLY				
	VFM3110EDS VFM3000EDS	DV ALIGNMENT TAPE (COLOR BAR) DV ALIGNMENT TAPE (LINEARITY)	1	PAL MODEL ONLY	 	\vdash		
	VFK1217	TAPE END/BEG DET CASSETTE	1					
		MEASURING BOARD	1					
		EVR CONNECTOR BOARD	1					
		EVR EXTENDER BOARD	1					
		DC CABLE	2	K2GY2DZ00003	-			
	VFK1317 VFK1809	30PIN FLAT CABLE 72MM ATTACHMENT RING	1					
		43MM ATTACHMENT RING	1				-	
	VFK1164TCM01	COLLIMATOR SET	1	(INFINITY LENS)			-	1
16	VFK1345	CC FILTER HOLDER	1					
	VFK1346	STEP DOWN RING	1					
	VFK1659	STEP-UP RING					-	
	VFK1660	STEP-UP RING		(49MM-62MM)	<u> </u>			
		CC FILTER (LB40) CC FILTER (LB80)		NTSC MODEL ONLY PAL MODEL ONLY				
	VFK1342 VFK1347	CC FILTER (LB80) CC FILTER (LB120)	1	TAL MODEL ONLY	 		ĺ	
	VFK1347 VFK1884	CC FILTER (LBA2)	1				ı	
	VFK1888	CC FILTER (LBB6)	1				۱	
	VFK1885	CC FILTER (LBB2)		NTSC MODEL ONLY			ı	
	VFK1886	CC FILTER (CC C10)		PAL MODEL ONLY			l	
27	VFK1887	CC FILTER (CC C20)	1	PAL MODEL ONLY			İ	
		MEASURING BOARD	1				ĺ	
		MECH. NEUTRAL PLATE	1				l	
	VFK1266	GEAR DRIVER	1				l	
	VFK1149B	POST DRIVER	1		<u> </u>		ŀ	
	VFK1151A VFK1810	NUT DRIVER (2.5MM) LISTA MEASURING BOARD	1				ŀ	
	VFK1810 VFK1186	LISTA MEASURING BOARD	1				ŀ	
		MORLYTONE GREASE	1		-		ŀ	
		A/D CONVERTER BOARD	1				I	
							١	
-							ĺ	
							ſ	
							l	
					<u> </u>			
					<u> </u>		۱	
							ŀ	
							۱	
							l	
							ľ	
							L	
							Ĺ	
							ļ	
							ŀ	
							ŀ	
							ŀ	
							ŀ	
							۱	
							H	
							f	
							ľ	
							ĺ	
							l	
							۱	
					<u> </u>			
							ı	
							I	
							I	
							Ĺ	
							L	
					ļ		L	
							ŀ	


MECHANICAL CHASSIS ASSEMBLY (1)



MECHANICAL CHASSIS ASSEMBLY (1)

Ref.No.	Part No.	Part Name & Description	Pos	Remarks	Ref.No.	Part No.	Part Name & Description	Pas	Remarks
Ker.MO.	I di C NO.	1 21 5 Name & Description		Kemalka	WGT : NO.	Tale No.	1 22 5 Name & Deptilption	_ 08	Nomalka
1	VEG1573	CYLINDER UNIT	1	(M)					
3	VSC4639	SHIELD CASE	1						
4	VES0928	FLEXIBLE CABLE	1						
5	VMA0D82	CAPSTAN COVER	1						
7	VMA9179 VMD2373	RADON PLATE	1						
8	VMD2373 VSC4640	SHIELD CASE	1						
9	VSR0114	MODE SW	_	(M)					
10	VXA5407	CAM GEAR	_	(M)					
11	VXL3242	S BOAT ASS'Y		(M)					
12	VXL3243	T BOAR ASS'Y	1	(M)					
13	VXA5417	GEAR BOX		(M)					
14	VXA5612	RADON ARM ASS'Y	1						
15	VXL2461	T2 ARM ASS'Y	1						
15-1	VMB2789 VXL3103	T2 ARM SPRING CLEANING ARM ASS'Y	1	(M)					
17	VXL2470	S1 ARM ASS'Y	1	(H)					
18	VXL2471	T1 ARM ASS'Y	1						
19	VMA0P25	CYLINDER HOLD ANGLE	1						
21	VXA5387	GARAGE ASS'Y	1						
22	EYHS77Y7	DEW SENSOR ASS'Y	1						
23	VMD4706	FLEX HOLDER	1						
24	VMB3518	CLEANING SPRING	1						
25	VMP7361	CASSETTE BLINDER PLATE	1						
			_						-
			-						
101	VHD0878	SCREW	1						
102	VHD0989	SCREW	2						
103	XQN14+B4	SCREW	2						
104	VXQ0439	SCREW	3						
105	XQN14+B35	SCREW	2						
106	XQN14+BQ4	SCREW	2						
107	XQN14+B15	SCREW	7						
108	XQN14+B2	SCREW	2						
109	VHD0882	SCREW	4						
111	VMX2027 XQN2+CF3	CUT WASHER SCREW	1						
113	VHD1285	SCREW	2						
114	XQN2+B2FZ	SCREW	2						
E5	VEP05395A	H/R AMP C.B.A.	1						
					1				
			-						-
									-
			L			-			
			_						
			-						-
-					-				1
									-
			Т						
									<u> </u>
			_						
-			-		<u> </u>				
					-				1
			\vdash						
			L						
						•		_	•

MECHANICAL CHASSIS ASSEMBLY (2)




MECHANICAL CHASSIS ASSEMBLY (2)

P-5 **-	Damt **-	Bart Name & Bassaisti	D.~ :	Pamanha	Pof **-	Darri V-	Dart Name & Descripti	D	Domank -
Ref.No.	Part No.	Part Name & Description	PCS	Remarks	Ref.No.	Part No.	Part Name & Description	PCS	Remarks
1	VDG1445	DRIVE PULLEY	1						
	VDG1031	CENTER PULLEY	1						
	VDG1032	SENSOR GEAR	1						
	VDV0265 VMA9178	TIMING BELT PINCH PRESSURE PLATE	1						
	VMA9178	BRAKE ROD SUPPORT (T)	1						
	VMB2776	SPRING	1						
9	VSH0067	MIC SWITCH	1	K0MZ55000001					
	VSJ0114	SOLENOID	1						
		BRAKE ROD ASS'Y	1						
	VXA5408 VXA5411	T3 ROD ASS'Y LED HOLDER ASS'Y	1						
	VXA6576	COVER PLATE ASS'Y	1						
25	VXL2454	P IDLER ARM ASS'Y	1						
	VXL2455	FR IDLER ARM ASS'Y	1						
	VXL2462	T3 ARM ASS'Y	1						
	VXL2732	PAD ARM ASS'Y	_	(M)					
	VMB2788 VMB2787	TENSION SPRING PAD ARM SPRING	1						
	VXL3244	TENSION ARM ASS'Y		(M)					
	VXL3161	PINCH ARM ASS'Y		(M)					
	VXL2466	EJECT ARM ASS'Y	1						
	VXR0355	SUPPLY REEL TABLE	_	(M)					
	VXR0356	TAKE UP REEL TABLE		(M)					
	VXZ0319	TAKE UP MAIN BRAKE	1						
	VMB2782	T MAIN BRAKE SPRING	1	(M)	-				
	VXZ0321 VMB2783	SUPPLY MAIN BRAKE S MAIN BRAKE SPRING	1	(M)					
	VXZ0322	FF BRAKE ASS'Y		(M)					
	VMB2784	FF BRAKE SPRING	1						
37	VXZ0441	REV BRAKE ASS'Y	1						
37-1	VMB3388	REV SPRING	1						
37-2	VMB3389	REV BRAKE SPRING	1						
101	VHD0884	SCREW	1						
	XQN14+B15	SCREW	2						
103	VHD0883	SCREW	5						
104	XQN14+B35	SCREW	3						
	VMX2503	C PULLEY WASHER	1						
	VMX3122	WASHER	1						
	VMX2504 VMX2027	WASHER CUT WASHER	1						
	VMX2027	WASHER	1						
	VMX2394	WASHER	1						
					<u> </u>				
<u> </u>	ļ								
					-				
	ļ								
					-				
					<u> </u>				
1	1	ļ l							


FRAME & CASING PARTS ASSEMBLY (1)

Components identified with the mark \triangle have the special characteristics for safety. When replacing any of these components, use only the same type.




Components identified with the mark Δ have the special characterisitics for safety. When replacing any of these components, use only the same type.

				1					
Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	_	Remarks
1	VWJ1583	SIDE JACK FLEX.	1		79 <u>/</u> 1 80	VMZ3341 VMG1514	SHIELD INSULATION PLATE 2 POWER HEAT SINK SHEET 1	1	1
2	VWJ10E5050L0	FLAT CABLE	1		//\ 80 /\ 81	VSC5471	POWER HEAT SINK SHEET I	1	
3	VML3710	CLUTCH SLIDE PLATE	1		<u> </u>	VMG1515	POWER HEAT SINK SHEET 2	1	
4	VMP7341	CLUTH ANGLE	1		83	VGQ6923	VF CASE (L)	1	
5	VGH4612	JACK NAME PLATE B	1		83	VGQ7346	VF CASE (L)	_	AG-DVX100AE/EN/DVC180AMC
6	VGH4615	JACK NAME PLATE A	1		84	K4ZZ04000026	BATTERY CATHER	1	
8	VJF1470 VKM5983	SIDE JACK CAP CENTER FRAME	1		85 86	VWJ10E5050L0 VMG1520	FLAT CABLE TOGGLE SW CUSHION	1	
9		AWB COVER HOLDER SHEET	1		87	VJF1468	XLR CAP	2	
10		AWB WINDOW	1		88	VMG1517	LENS HEAT SINK SHEET (2)	1	
11	VMD3345	TRIPOD FRAME	1		89	VMZ3356	FPC PROTECT SHEET	1	
12	VMZ3323	EVR INSULATION SHEET	1		90	VMZ3357	FPC LOCK SHEET	1	
14	VGQ6902	MIC SWITCHING KNOB HOLDER	1		91	VMZ3345	LED INSULATION PLATE	1	
15	VGU9246 VGU9194	ZOOM CLUTCH KNOB MIC SWITCHING KNOB	2		92	VMZ3376 VSC5519	JACK GUIDE SHEET EARTH PLATE	1	
17	VMG1460	SLIDE SW RUBBER COVER	6		94	VSC5525	EARTH SHEET	1	
18	VGU9214	SLIDE KNOB	4		95	VYK1A28	BACK CASE ASS'Y	1	AG-DVX100AP
19	VGU9200	CAMERA OP BUTTON	1		95	VYK0Y43	BACK CASE ASS'Y	1	AG-DVX100AAN
20	VGQ6896	FOCUS KNOB HOLDER	1		95	VYK1A17	BACK CASE ASS'Y	1	AG-DVX100AE/EN
21	VGU9213	FOCUS SLIDE KNOB	1		95	VYK1A18	BACK CASE ASS'Y	1	AG-DVC180AMC
22	VGU9211	FOCUS BUTTON	1		96	J0ZZZ0000042	SHEET	1	AG-DVX100AE/EN/DVC180AMC
23	VGQ6894	ND SWITCHING PIECE	1						
24	-2	HOLDER BLIND SHEET ND SWITCHING KNOB	1					_	
25	VGU9222 VMB3681	ND SWITCHING KNOB FOCUS KNOB SPRING	1		100	XON2+B4FN	SCREW	35	
26	VGQ6905	ND FILTER HOLDER	1		100	XQN2+B4FN XQN16+B4FZ	SCREW	35	
28	VGU9228	IRIS BUTTON	1		102	XYN26+A6FZ	SCREW	4	
29	VGQ6897	SPEAKER HOLDER	1		103	XYN2+C4	SCREW	5	i
30	VEK9842	SPEAKER ASS'Y	1		104	XQN16+BJ4FZ	SCREW	2	1
31	VMP7330	SPEAKER HOLDER ANGLE	1		105	XQN2+C5	SCREW	6	
32	VMT1347	SPEAKER HOLDER CUSHION	1		106	XWG2	WASHER	1	
33	VMT1367	P.C.B. HOLDER CUSHION	1		107	XQN16+BJ3FZ	SCREW	1	
34		RUBBER BUTTON 2	1		108	XQN2+B35FN	SCREW	2	
35		RUBBER BUTTON 3 RUBBER BUTTON 1	1		109	XYN2+F5 XYN2+C6	SCREW SCREW	2	
<u>∧</u> 37	VSC5460	SIDE (R) SHIELD PLATE	1		111	XQN2+BJ6	SCREW	2	
<u>₩</u> 38		P.C.B. PROTECT SHEET	1		112	XQN2+B3FZ	SCREW	2	
39	VGQ7175	ND KNOB SHEET	2		113	XQN2+BJ4FZ	SCREW	6	
40	VGQ7637	HINGE COVER	1		<u> 114</u>	VMX3286	WASHER	1	
41	VGU9212	AUDIO ROTATING KNOG	2		115	XQN2+B4FZ	SCREW	20	
42	VGU9197	MONITOR LOCK KNOB	1		116	XQN2+BJ4	SCREW	3	1
43	VGP5997	SIDE CASE (R) LCD LOCK SHAFT	1		117	XQN2+B6FZ	SCREW	1	•
44	VMS7187 VMP7331	OPENER HOLDER ANGLE	1						
46	VMB3661	POP UP SPRING	1						
47	VGQ6901	MONITOR KNOB	1		E2	VEP23597A	CAMERA C.B.A.	1	AG-DVX100AP/AN
48	VMB3659	MONITOR OPENER SPRING	1		E2	VEP23597B	CAMERA C.B.A.	1	AG-DVX100AE/EN/DVC180AMC
49	VKN0169	SPEAKER NET	1		E3	VEP01914B	POWER C.B.A.	1	
50		W.BAL KNOB (LOWER)	1		E4	VEP01922A	POWER 2 C.B.A.	1	
51		W.BAL KNOB (UPPER)	1		E6	VEP04817A	R SIDE C.B.A.	_	AG-DVX100AP/AN
52		RAIN COVER RUBBER (B)	1		E6	VEP04817B	R SIDE C.B.A.	_	AG-DVX100AE/EN/DVC180AMC
54	VMG1286	CUSHION RUBBER	1		E7	VEP06E92A	CAMERA OP1 C.B.A.	1	:
55 56	VMZ3316 VGQ4088	MONITOR FPC PROTECT SHEET 3CCD BADGE TAPE	1		E8 E11	VEP06E93A VEP001E7A	CAMERA OP2 C.B.A. MENU C.B.A.	1	1
57	VGB0322	3CCD BADGE TAPE	1		E16	VEP000Y2A	EVR CONNECT C.B.A.	1	
59	VGP6006	BACK PANEL	1		E18	VEP000Y4A	LCD OPEN SW C.B.A.	1	
60	VGU8582	BATTERY LOCK BUTTON	1		E25	VEP22351A	GYRO C.B.A.	1	
61	VMB3210	BATTERY LOCK SPRING	1		E26	VEP04858A	SIDE JACK C.B.A.	1	
62		MODE SELECT KNOB	1		E27	VEP04815A	EXT MIC CH2 C.B.A.	1	
63		DCIN ANGLE	1		E28	VEP04865A	EXT MIC CH1 C.B.A.	1	
64		MODE PANEL LIGHT	2		E29	VEP06E89B	MODE SW C.B.A.	1	
65	VGU9219 VGU9209	CAMERA/VCR BUTTON JOY STICK BUTTON	2		E30	VEP01923A	DC IN C.B.A.	1	
66	VGU9209 VGU9199	JOY STICK BUTTON MENU BUTTON	1		E31	VEP01915B	BATTERY C.B.A.	1	1
68	VGQ6924	VF CASE (R)	1	AG-DVX100AP/AN					
68	VGQ7347	VF CASE (R)		AG-DVX100AE/EN/DVC180AMC					
<u>/</u> 69	VMZ3315	BATTERY BLIND SHEET	1						
<u>^</u> 71	VMG1516	CCD HEAT SINK SHEET	1						
72	VGQ6886	EVR COVER	1						
73	VWJ13E5085L0	FLEX. CABLE	1						
74		R SIDE FPC	1						
75		P.C.B HOLDER ANGLE	1						
77	VMZ3340	SHIELD INSULATION PLATE 1	1					-	
78	VSC5478	CAMERA P.C.B. SHIELD	2						
					-				1



Components identified with the mark Δ have the special characterisitics for safety. When replacing any of these components, use only the same type.


	ı	1		1		ſ	1		
Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	PC	Remarks
					74	VXP2356	ZOOM RING	1	
1	VMS7186	ROTATING SHAFT	2		75	VEE0T93	MIK IO	1	
<u></u>	VMZ3371	POWER INSULATION SHEET C	1		76	VXY1738S	MECHA CHASSIS ASS'Y	1	(M)
3	VMX0531	CLATCH SPACER	1		77	L6DABBHC0001	ZOOM MOTOR ASS'Y	1	
4	VGU9203	REC CHECK RUBBER BUTTON	1		78	EVAJGGUA3B14	ZOOM ENCODER	1	
5	VGQ6903	ZOON LEVER CASE (R)	1		80	VXQ1193	PRISM ASS'Y	1	
6	VGQ6904	ZOON LEVER CASE (L)	1		82	VYK1A07	GRIP COVER ASS'Y		AG-DVX100AP/AN
7	VGQ6996	ZOOM HOLDER (R)	1		82	VYK1A08	GRIP COVER ASS'Y	_	AG-DVX100AE/EN/DVC180AMC
9	VGQ6997 VGQ6928	ZOOM SPRING HOLDER PIECE	1		83	VMP7739 VMZ3406	ANGLE	1	
10	VMB3663	ZOOM SW HOLDER COIL SPRING ZOOM	1		84	VMZ3406	SHEET		
11	VGU9215	ZOOM LEVER	1		-				
12	VEE0U25	EJECT 1	1						
13	VMT1350	CASSETTE COVER GASKET	1		100	XUC15FX	E-RING	3	3
14	VGP5801	SIDE CASE (L)	1		101	XQN2+B3FN	SCREW	7	
15	VGU9206	EJECT KNOB	1		102	XQN16+BJ3FZ	SCREW	4	
16	VGU9216	EJECT LOCK BUTTON	1		103	XQN2+BJ4FZ	SCREW	19	,
17	VMB3662	EJECT LOCK BUTTON SPRING	1		104	VHN0194	SPACER	1	
18	VGQ6899	EJECT KNOB FIX PIECE	1		105	XQN16+B4FZ	SCREW	2	:
19	VJF1469	H.P CAP	1		106	XQN16+BJ4FZ	SCREW	٤	1
20	VGU9204	POWER BUTTON	1		107	XTB26+6GFZ	SCREW	2	1
21	VGU9205	S/S BUTTON	1		108	XYN2+C6	SCREW	2	:
22	VGU9201	POWER LOCK BUTTON	1		109	VMX2535	WASHER	1	
23	VGQ6998	S/S BUTTON HOLDER	1		110	XQN2+B35FN	SCREW	4	
24	VGQ6884	S/S HOLDER PIECE	1		111	XQN2+B4FZ	SCREW	11	
25	VMP7337	LOCK LEVER HOLDER ANGLE	1		112	VHD1546	SCREW	1	
26	VMS7211	PIN	2		113	XQN2+BJ5FZ	SCREW	4	
27	VMP7339	CASSETTE LOCK LEVER	1		114	XQN2+C6FZ	SCREW	1	
28	VMS7203	EJECT LOCK PIN	2		115	VHD1100	SCREW	3	
29	VMB3680	EJECT LOCK BUTTON SPRING	1		116	XQN2+B4FN	SCREW	16	
30	VGH4733	GRIP COVER WINDOW		AG-DVX100AP/AN	117	VHD1538	SCREW	1	
30	VGH4734	GLIP COVER WINDOW		AG-DVX100AE/EN/DVC180AMC	118	VHD0866	SCREW	2	
31	VGP5804	CASSETTE COVER	1		119	XYN2+C6	SCREW	1	
32	VGF0952	SHIELD PLATE	1		120	XQN14+CJ4Z	SCREW	2	
33	VMP7338	CASSETTE COVER FIX ANGLE	1						
34	VMP6741	BELT HOLDER ANGLE	1						
35	VFB0215 VMP7325	GLIP BELT GLIP BELT ANGLE (FRONT)	1		E1	VEP03G55A	VTR C.B.A.	_	AG-DVX100AP/AN
37	VMP7525 VMP7501	HOLDER ANGLE	1		E1	VEP03G55A VEP03G55B	VTR C.B.A.		AG-DVX100AF/AN AG-DVX100AE/EN/DVC180AMC
38	VMC1092	CASSETTE DOWN SPRING	1		E17	VEP000Y3B	VC CONNECT C.B.A.	1	
39	VMC1835	LINK DUMPER SPRING	1		E19	VEP000Y6A	R JACK CONNECT C.B.A.		
40	VMA9219	OPEN ANGLE (A)	1		E20	VEP000Y7A	EJECT C.B.A.	1	
41	VMS5748	LINK PIN (B)	1		E21	VEP04819A	REAR JACK C.B.A.	1	
42	VMA9220	OPEN LINK (B)	1		E22	VEP06E96A	POWER SW C.B.A.	1	
43	VMA0P91	LINK ANGLE	1		E23	VEP06E90A	ZOOM SW C.B.A.	1	
44	VMX2397	ARM STAND ROLLER	1		E24	VEP000Y9A	TOP OP C.B.A.	1	
45	VMS7293	ARM STAND PIN	1						
46	VMS5747	RINK PIN (A)	1						
47	VDP1653	ROTATION ROLLER	1						
48	VGP5998	TOP PANEL	1						
49	VGU9195	REC BUTTON	1						
50	VGU9210	REC/DUB BUTTON	2						
51	VGU9249	AUDIO MONITOR BUTTON (-)	1						
52	VGU9196	AUDIO MONITOR BUTTON (+)	1						
53	VMG1478	TOP SW BUTTON RUBBER	1						
54	VMP7432	TOP SUPPORT ANGLE	1						
55	VYK0Z96	LENS CAP ASS'Y	1		-				
56	VGH4614	LENS NAME PLATE	1		-				
58	VMG1463	DUSTPROOF RUBBER MECHA HOLDER ANGLE	1						
60	VMP7336 VMZ3295	MECHA HOLDER ANGLE MECHA BARRIER	1		-				
61	VGQ6885	BOTTOM COVER	1						+
62	VKA0340	GLIP DUSTPROOF RUBBER	1		-				
63	VGU9255	HOOD FIX PIECE	1						
64	VYF2861	LENS HOOD ASS'Y	1						
65	VMP7605	LENS HOOD WINDOW	1						
66	VGQ7077	MECHA DUSTPROOF COVER	1						<u> </u>
67	VMT1348	CASSETTE COVER GASKET (U)	1						1
68		FOCUS RING ASS'Y	1						
69	VDW0855	FIX RING ASS'Y	1						
70	VJF1472	FLEX. HOLDER	1						
71	VXW0635	CAMERA LENS ASS'Y	1	AG-DVX100AP/AN					
71	VXW0636	CAMERA LENS ASS'Y	1	AG-DVX100AE/EN/DVC180AMC					
72	VGQ7078	RUBBER CAP	1						
	VEE0T92	INT MIC	1]			
73			_						
73									



HANDLE & EVF PARTS ASSEMBLY

	ı	1				1		_	
Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	s Remarks
1	VMP7328	HANDLE SLIDE ANGLE	1					Ĺ	
2	VGU9214	SLIDE KNOB	1						
3	VMG1460	SLIDE SW RUBBER COVER	1						
4	VKH0410	HANDLE	1						
5	VGQ6888	HANDLE FRONT COVER	1		-				1
6	VJF1421	SHU	1						
7	VMC1697	SPRING	1						
8	VYF2863	REAR TALLY COVER ASS'Y	1						
		HANDLE S/S BUTTON RUBBER	1						+
10	VMG1479		1						
11	VGU9207	HANDLE S/S BUTTON	1						
12		MIC CASE ASS'Y							
20		DUMPER HOLDER PIECE	1						
21	VGQ6891	MIC P.C.B. HOLDER	1						
22	VGQ6878	MIC RUBBER FIX PIECE	1						
23	VMG1459	MIC RUBBER HOLDER	1						
24	VMP7329	MIC HOLDER ANGLE	1						
25	VGQ7862	HANDLE COVER	1	AG-DVX100AP/AN					
25	VGQ6873	HANDLE COVER	1	AG-DVX100AE/EN/DVC180AMC					
26	VGQ6887	MIC CASE (LOWER)	1						
27	VYQ2773	HELICOID ASS'Y	1					Ī	
29	VGQ6890	EVF FILTER HOLDER	1						
30	VWJ1586	EVF FPC	1						
31	VMX2967	PB SPACER	1		-				
32		ACTIVE MATRIX LCD PANEL	1		 			-	+
33		LCD MASK	1					-	-
	VGQ7088								
34	VGQ6926	LCD CASE	1		 			<u> </u>	1
35	VMC1612	EVF EARTH SPRING	1						
36	VMP7360	EVF COVER ANGLE	1						
37	VMC1808	EVF EARTH SPRING	1						
38	VGQ6927	EVF COVER	1						
39	VGP5799	EVF CASE	1						
40	VGQ3855	DIOPTER ADJUST BRACKET	1						
41	VGU6944	EYE SIGHT ADJ. DIAL	1						
42	VMG1286	CUSHION RUBBER	2						
43	VXW0567	EVF LENS ASS'Y	1						
44	VYK0K51	EVF EYE CAP HOLDER ASS'Y	1		-				1
46	VYQ2548	EVF ASS'Y	1						
49	VGQ6892	EVF HINGE COVER	1						
52	VMZ3361	SHEET	1						+
<u>∧</u> 54	VMS7303	EYE SIGHT KNOB SHAFT	1						+
			1						-
55	VKC0594	VF HINGE	1		-				
100	XQN2+C4	SCREW	6						
101	XQN2+B4FZ	SCREW	9						
102	XSN2+4FC	SCREW	1						
103	XSS2+4FZ	SCREW	4						
104	XQN2+BJ3FZ	SCREW	1						
105	XYN2+J4	SCREW	1						
106	XQN2+BJ4	SCREW	4						
107	XWG2	WASHER	2						
108	XQN2+BJ5FZ	SCREW	3						
109	XQN2+BJ4FZ	SCREW	12						
110	XQN16+C25FZ	SCREW	1		 			-	+
111	XQN16+C25FZ XQN2+CJ6FZ	SCREW	3		 			-	+
	XQN2+CJ6FZ XQN16+C3		4		-				
112	AUNIO+U3	SCREW	4		 			-	1
					 			<u> </u>	1
									<u> </u>
E9		EVF A C.B.A.	1						
E10	VEP28275B	EVF B C.B.A.	1						
E12	VEP06F70A	HANDLE 1 C.B.A.	1					L	
E13	VEP06F04A	HANDLE 2 C.B.A.	1						
E14	VEP04828A	MIC C.B.A.	1						
E15	VEP06E94A	F TALLY C.B.A.	1						
									1
					 			-	+
					-			-	1
					 			<u> </u>	1
					ļ				
									1
								L	
								l	
								_	

LCD PARTS ASSEMBLY




LCD PARTS ASSEMBLY

Ref.No.	Part No.	Part Name & Description P	cs	Remarks	Ref.N	ю.	No. Part No.	No. Part No. Part Name & Description
						Ī		
1		LCD ASS'Y		AG-DVX100AP/AN/E/EN				
1		LCD ASS'Y		AG-DVC180AMC		Ļ		
2		LCD CASE (LOWER)	1			-		
9		BLIND SHEET (A) LCD HINGE (2)	1			\vdash		
10		HINGE COVER (LOWER)	1					
11		HINGE COVER (UPPER)	1					
14		BARRIER (LCD)	1					
15		BARRIER (LCD-B)	1					
16		LCD CASE (UPPER) ASS'Y		AG-DVX100AP/AN/E/EN				
16	VYK1A14	LCD CASE (UPPER) ASS'Y	1	AG-DVC180AMC				
							_	
					<u> </u>	-	-	
100	XQN16+B2FN	SCREW	1					
100		SCREW	5					
102		SCREW	4					
			•					
-							l	
							I	
E32	VEP26257A	MONITOR C.B.A.	1				ı	
E32-1	VEP06E29A	HALL SENSOR FLEX CARD	1				J	
				-			Į	
							I	
							ļ	
							ļ	
					<u> </u>		l	
		+					ł	
							l	
							l	
							١	
							ı	
							ĺ	
							ļ	
							ļ	
							1	
		1			 	1		
							١	
							t	
							Į	
							ĺ	
							ļ	
					ļ		ļ	
							ļ	
					-		ł	
					<u> </u>		۱	
							l	
							ł	
							ł	
							j	
							Į	
							I	
							١	
							١	
					<u> </u>			
		+						
							I	
							Į	
·							ſ	
							Ĺ	
							L	
					<u> </u>		ļ	

PACKING PARTS ASSEMBLY

Components identified with the mark \triangle have the special characteristics for safety. When replacing any of these components, use only the same type.



PACKING PARTS ASSEMBLY

Dof No	Dont No.	Dank Name C Desamination	0.00	Remarks	Dof No	Domb No.	Dont Name & Description	D==	Remarks
Ref.No.	Part No.	Part Name & Description	PCS	Remarks	Ref.No.	Part No.	Part Name & Description	PCS	Remarks
1	VPG0V37	PACKING CASE	1	AG-DVX100AP					
1	VPG0U36	PACKING CASE	1	AG-DVX100AAN					
	VPG0V38	PACKING CASE		AG-DVX100AE					
	VPG0Y22	PACKING CASE		AG-DVX100AEN					
	VPG0T56	PACKING CASE		AG-DVC180AMC					
	VPN5826 VPN5825	CUSHION (LOWER) CUSHION (UPPER)	1						
	VPF0884	POLYETHYLENE BAG	1		-				
	VPN5930	PARTITION PLATE	1						
	VFA0402	WIRELESS REMOTE CONTROL	1						
		SHOULDER BELT	1						
8	VMG1458	EYE CAP	1						
9	VPF0179	POLYETHYLENE BAG	1						
10	VYC0890	MIC HOLDER ADAPTOR	1						
	XSB4+6FZ	SCREW	2						
	VPF1016	POLYETHYLENE BAG	_	PCS:3 AG-DVX100AE/EN/DVC180AMC					
	XSB4+12FXKS VYC0870	SCREW	1						
	VPK0825	MIC HOLDER ASS'Y ACCESSORY BOX	1						
	VEK8722	DC CABLE ASS'Y	1		-				
	K2CB2CB00006	POWER CODE		AG-DVX100AP					
	K2CA2DA00030	POWER CODE		AG-DVC180AMC					
	VQT0F36	OPERATING INSTRUCTIONS		AG-DVX100AP					
∱ 18	VQT0E17	OPERATING INSTRUCTIONS	1	AG-DVX100AAN					
	VQT0F37	OPERATING INSTRUCTIONS		AG-DVX100AE					
	VQT0J59	OPERATING INSTRUCTIONS		AG-DVX100AEN					
	VQT0F38	OPERATING INSTRUCTIONS		AG-DVC180AMC					
	VPG0V39	PACKING CASE		AG-DVC180AMC					
	K2CP2DA00001 K2CT3DA00001	POWER CODE		AG-DVX100AAN AG-DVX100AE/EN					
		POWER CODE AC CORD		AG-DVX100AE/EN AG-DVX100AE/EN	-				
	J0KG00000013	FERRITE CORE		AG-DVX100AE/EN/DVC180AMC					
	DE-852DB	AC ADAPTOR		AG-DVX100AP/AN					
	DE-811DB	AC ADAPTOR	1	AG-DVX100AE/EN					
1 24	DE-811FB	AC ADAPTOR	1	AG-DVC180AMC					
					-				
					-				
					<u> </u>				
					-				
					 				
						-			
					<u> </u>				
					 				
								_	