In the name of Allah

Computer Architecture Midterm Overview

Zohre Soorani Mahdi Haghverdi Husseini Husseini Hosna Rajaei



November 14, 2023

Content

Computer Abstraction and Technology

Operations of the Computer Hardware

Operands of the Computer Hardware

Memory Operands Constant or Immedidate Operands

Representing Instructions

Logical Operations

Instuctions for Making Decisions

Suporting Precedures in Computer Hardware

MIPS Addressing for 32-Bit Immediates and Addresses

A C Sort Example to Put It All Together

Computer Abstraction and Technology

Computer Abstraction and Technology

Operations of the Computer Hardware

Operations of the Computer Hardware

Figure: Arithmatic Instructions in MIPS

Category	Instruction	Example	Meaning	Comments
	add	add \$s1,\$s2,\$s3	\$s1 = \$s2 + \$s3	Three register operands
Arithmetic	subtract	sub \$s1,\$s2,\$s3	\$s1 = \$s2 - \$s3	Three register operands
	add immediate	addi \$s1,\$s2,20	\$s1 = \$s2 + 20	Used to add constants

load word	lw \$s1, 20(\$s2)	\$s1 = Memory[\$s2 + 20]	Word from memory to register
store word	sw \$s1, 20(\$s2)	Memory[\$s2 + 20] = \$s1	Word from register to memory
load byte	lb \$s1, 20(\$s2)	\$s1 = Memory[\$s2 + 20]	Byte from memory to register
load byte unsigned	lbu \$s1, 20(\$s2)	\$s1 = Memory[\$s2 + 20]	Byte from memory to register
store byte	sb \$s1, 20(\$s2)	Memory[\$s2 + 20] = \$s1	Byte from register to memory
load upper immed	lui \$s1, 20	\$s1 = 20 * 2 ¹⁶	Loads constant in upper 16 bits

Table: Data Transfer Instructions in MIPS

Figure: Logical Instructions in MIPS

	and	and	\$s1,\$s2,\$s3	\$s1 = \$s2 & \$s3	Three reg. operands; bit-by-bit AND
	or	or	\$s1,\$s2,\$s3	\$s1 = \$s2 \$s3	Three reg. operands; bit-by-bit OR
	nor	nor	\$s1,\$s2,\$s3	\$s1 = ~ (\$s2 \$s3)	Three reg. operands; bit-by-bit NOR
Logical	and immediate	andi	\$s1,\$s2,20	\$s1 = \$s2 & 20	Bit-by-bit AND reg with constant
	or immediate	ori	\$s1,\$s2,20	\$s1 = \$s2 20	Bit-by-bit OR reg with constant
	shift left logical	s11	\$s1,\$s2,10	\$s1 = \$s2 << 10	Shift left by constant
	shift right logical	srl	\$s1,\$s2,10	\$s1 = \$s2 >> 10	Shift right by constant

Figure: Conditional Branch Instructions in MIPS

Conditional branch	branch on equal	beq	\$s1,\$s2,25	if (\$s1 == \$s2) go to PC + 4 + 100	Equal test; PC-relative branch
	branch on not equal	bne	\$s1,\$s2,25	if (\$s1!= \$s2) go to PC + 4 + 100	Not equal test; PC-relative
	set on less than slt \$		\$s1,\$s2,\$s3	if (\$s2 < \$s3) \$s1 = 1; else \$s1 = 0	Compare less than; for beq, bne
	set on less than unsigned	sltu	\$s1,\$s2,\$s3	if (\$s2 < \$s3) \$s1 = 1; else \$s1 = 0	Compare less than unsigned
	set less than immediate	slti	\$s1,\$s2,20	if (\$s2 < 20) \$s1 = 1; else \$s1 = 0	Compare less than constant
	set less than immediate unsigned	sltiu	\$s1,\$s2,20	if (\$s2 < 20) \$s1 = 1; else \$s1 = 0	Compare less than constant unsigned

Figure: Unconditional Jump Instructions in MIPS

iumn	jump	j 2500		go to 10000	Jump to target address
	jump register jr \$ra		\$ra	go to \$ra	For switch, procedure return
	jump and link	jal	2500	pa = PC + 4; go to 10000	For procedure call

Example - Compiling a Complex C Assignment into MIPS

A somewhat complex statement contains the five variables f, g, h, i, and j: f = (g + h) - (i + j); What might a C compiler produce?

Answer

- add t0, g, h # temporary variable t0 contains g + h
- add t1, i, j # temporary variable t1 contains i + j $\,$
- sub f, t0, t1 # f gets t0 t1, which is (g + h) (i + j)

Operands of the Computer Hardware

Example - Compiling a C Assignment Using Registers

It is the compiler's job to associate program variables with registers.

Take, for instance, the assignment statement from our earlier example:

$$f = (g + h) - (i + j);$$

The variables f, g, h, i, and j are assigned to the registers s0, s1, s2, s3, and s4, respectively.

What is the compiled MIPS code?

Answer

- add \$t0, \$s1, \$s2 # register \$t0 contains g + h
- add \$t1, \$s3, \$s4 # register \$t1 contains i + j
- sub \$s0, \$t0, \$t1 # f gets <math>\$t0 \$t1, which is (g + h) (i + j)

Example - Compiling Using Load and Store

Assume variable h is associated with register \$s2 and the base address of the array A is in \$s3.

What is the MIPS assembly code for the C assignment state ment below?

A[12] = h + A[8];

Answer

- lw \$t0, 32(\$s3) # Temporary reg \$t0 gets A[8]
- add \$t0, \$s2, \$t0 # Temporary reg \$t0 gets h + A[8]
- sw \$t0, 48(\$s3) # Stores h + A[8] back into A[12]

Constant or Immedidate Operands

- addi \$s3, \$s3, 4 # \$s3 = \$s3 + 4

Representing Instructions

Instructions Big Picture

Name	Format	Example						Comments
Field Size		6 bit	5 bit	5 bit	5 bit	5 bit	6 bit	All MIPS instructions are 32 bits long
R-format	R	op	rs	rt	$_{\mathrm{rd}}$	shamt	funct	Arithmetic instruction format
add	R	0	18	19	17	0	32	add \$s1,\$s2,\$s3
I-format	I	op	rs	rt	address			Data transfer format
lw	I	35	18	17	100			lw \$s1,100(\$s2)
J-format	J	op	address			s		Unconditional Branch
j	J	8	300					jump to address

Logical Operations

Instuctions for Making Decisions

Suporting Precedures in Computer Hardware

MIPS Addressing for 32-Bit Immediates and Addresses

A C Sort Example to Put It All Together