



## Software Safety Requirements and Architecture Lane Assistance

**Document Version: [Version]** 

Template Version 1.0, Released on 2017-06-21



## **Document history**

Date	Version	Editor	Description
08/13/2017	1.0	Yuesong Xie	First Draft

### **Table of Contents**

#### Contents

Document history	2
Table of Contents	
Purpose	2
Inputs to the Software Requirements and Architecture Document	
Technical safety requirements	3
Refined Architecture Diagram from the Technical Safety Concept	
Software Requirements	
Refined Architecture Diagram	

## Purpose

Covers implementation details of functions that enable the system to reach a safe state as well as detection, indication and handling of faults in both hardware and software.

# Inputs to the Software Requirements and Architecture Document


### Technical safety requirements

Technical Safety Requirements related to Functional Safety Requirement 01-01 are:

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Architecture Allocation	Safe State
Technical Safety Requirement 01	The LDW safety component shall ensure that the amplitude of the 'LDW_Torque_Request' sent to the 'Final electronic power steering Torque' component is below 'Max_Torque_Amplitude.	С	50ms	LDW Safety Functionality	Off
Technical Safety Requirement 02	As soon as the LDW function deactivates the LDW feature, the 'LDW Safety' software block shall send a signal to the car display ECU to turn on a warning light.	С	50ms	LDW Safety Functionality	Off
Technical Safety Requirement 03	As soon as a failure is detected by the LDW function, it shall deactivate the LDW feature and the 'LDW_Torque_Request' shall be set to zero.	С	50ms	LDW Safety Functionality	Off
Technical Safety Requirement 04	The validity and integrity of the data transmission for 'LDW_Torque_Request' signal shall be ensured	С	50ms	Data Transmission Integrity Check	Off
Technical Safety Requirement 05	Memory test shall be conducted at startup of the EPS ECU to check for any	А	Ignition cycle	Safety Startup	Off

faults in memory.	faults in memory.				
-------------------	-------------------	--	--	--	--

### Refined Architecture Diagram from the Technical Safety Concept



## Software Requirements

Lane Departure Warning (LDW) Amplitude Malfunction Software Requirements:

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Allocation to Architecture	Safe State
Technical Safety Requirement 01	The LDW safety component shall ensure that the amplitude of the LDW_Torque_Request sent to the Final Electronic Power Steering Torque component is below Max_Torque_Amplitude	С	50ms	LDW Safety	Off

ID	Software Safety Requirement	A S I L	Allocation Software Elements	Safe State
Software Safety Requirement 01-01	The input signal "Primary_LDW_Torq_Req" shall be read and pre-processed to determine the torque request coming from the "Basic/Main LA Functionality" SW Component. Signal "processed_LDW_Torq_Req" shall be generated at the end of the processing	С	LDW_SAFETY_INPUT_P RO CESSING	N/A
Software Safety Requirement 01-02	In case the  "processed_LDW_Torq_Req" signal has a value greater than "Max_Torque_Ampltide_LD W"( maximum allowed safe torque), the torque signal "limited_LDW_Torq_Req" shall be set to 0, else "limited_LDW_Torq_Req" shall take the value of "processed_LDW_Torq_Req"	С	TORQUE_LIMITER	limited_LDW_To rq _Req = 0(Nm)
Software Safety Requirement 01-03	The  "limited_LDW_Torq_Req"shall be transformed into a signal "LDW_Torq_Req" which is suitable to be transmitted outside of the LDW Safety component ("LDW Safety") to the "Final EPS Torque"component. Also see SofSafReq02-01 and SofSafReq02-02	С	LDW_SAFETY_OUTPUT _G ENERATOR	LDW_Torq_Req = 0 (Nm)

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Allocation to Architecture	Safe State
Technical Safety Requirement 02	The validity and integrity of the data transmission for LDW_Torque_Request signal shall be ensured	С	50ms	Data Transmission Integrity Check	Off

ID	Software Safety Requirement	A S I L		Safe State
Software Safety Requirement 02-01	Any data to be transmitted outside of the LDW Safety component ("LDW Safety")including "LDW_Torque_Req"and "activation_status" (seeSofSafReq03-02) shall be protected by an End2End(E2E)protection mechanism	O	E2ECalc	LDW_Torq_Re q = 0 (Nm)
Software Safety Requirement 02-02	The E2E protection protocol shall contain and attach the control data: alive counter (SQC) and CRC to the data to be transmitted.	С	E2ECalc	LDW_Torq_Re q = 0 (Nm)

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Allocation to Architecture	Safe State
Technical Safety Requirement 03	As soon as a failure is detected by the LDW function, it shall deactivate the LDW feature and the LDW_Torque_Request shall be set to zero	С	50ms	LDW Safety Functionality	Off

ID	Software Safety Requirement	ASLL	Allocation Software Elements	Safe State
Software Safety Requirement 03-01	Each of the SW elements shall output a signal to indicate any error which is detected by the element. Error signal = error_status_input(LDW_SAFET Y_I NPUT_PROCESSING), error_status_torque_limiter(TOR QU E_LIMITER), error_status_output_gen(LDW_SAF ETY_OUTPUT_GENERATOR)	С	All	N/A
Software Safety Requirement 03-02	A software element shall evaluate the error status of all the other software elements and in case any 1 of them indicates an error, it shall deactivate the LDW feature("activation_status"=0)	С	LDW_SAFETY _A CTIVATION	Activation_status = 0 (LDW function deactivated)
Software Safety Requirement 03-03	In case of no errors from the software elements, the status of the LDW feature shall be set to activated ("activation_status"=1)	С	LDW_SAFETY _A CTIVATION	N/A
Software Safety Requirement 03-04	In case an error is detected by any of the software elements, it shall set the value of its corresponding torque to 0 so that "LDW_Torq_Req" is set to 0	С	All	LDW_Torq_Req = 0

Software Safety Requirement 03-05	Once the LDW functionality has been deactivated, it shall stay deactivated until the time the ignition is switched from off to on again.	С	LDW_SAFETY _A CTIVATION	Activation_status = 0 (LDW function deactivated)
--	--	---	----------------------------	--

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Allocation to Architecture	Safe State
Technical Safety Requirement 04	As soon as the LDW function deactivates the LDW feature, the LDW Safety software block shall send a signal to the car display ECU to turn on a warning light	С	50ms	LDW Safety Functionality	Off

ID	Software Safety Requirement	A S I L	Allocation Software Elements	Safe State
Software Safety Requirement 04-01	When the LDW function is deactivated (activation_status set to 0), the activation_status shall be sent to the car display ECU.	С	LDW_SAFET Y_ ACTIVATION, CarDisplay ECU	N/A

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Allocation to Architecture	Safe State
Technical Safety Requirement 05	Memory test shall be conducted at start up of the EPS ECU to check for any faults in memory	Α	Ignition cycle	Safety Startup	Off

ID	Software Safety Requirement	A S I L	Allocation Software Elements	Safe State
Software Safety Requirement 05-01	A CRC verification check over the software code in the Flash memory shall be done every time the ignition is switched from off to on to check for any corruption of content	Α	MEMORYTES T	Activation_status = 0
Software Safety Requirement 05-02	Standard RAM tests to check the data bus, address bus and device integrity shall be done every time the ignition is switched from off to on (E.g.walking 1s test, RAM pattern test. Refer RAM and processor vendor recommendations)	A	MEMORYTES T	Activation_status = 0
Software Safety Requirement 05-03	The test result of the RAM or Flash memory shall be indicated to the LDW_Safety component via the "test_status" signal	Α	MEMORYTES T	Activation_status = 0
Software Safety Requirement 05-04	In case any fault is indicated via the "test_status" signal the INPUT_LDW_PROCESSING shall set an error on error_status_input (=1) so that the LDW functionality is deactivated and the LDW Torque is set to 0	Α	LDW_SAFET Y_ INPUT_PROC E SSING	Activation_status = 0

## Refined Architecture Diagram

