

1- ORGANISMES CHARGES DES SERVICES DE LA CIRCULATION

AERIENNES: CASABLANCA ACC et MARRAKECH-Ménara APP assurent la fourniture des services de la circulation aérienne dans la TMA de MARRAKECH.

2- ESPACES DELEGUES A MARRAKECH-Ménara APP :

a-Limites laterales et verticales (cf. ENR 2.1)

b- Calage altimétrique :

L'altitude de transition pour la TMA de MARRAKECH-Ménara est de 6000 ft. Le niveau de transition est calculé par MARRAKECH-Ménara APP.

3- PROCEDURES:

a- Limitation de vitesse

- Sauf clairance particulière de MARRAKECH-Ménara APP la vitesse indiquée (IAS) ne devra pas excéder 250 kt en dessous du FL100.

b- Itinéraires normalisés d'arrivées aux instruments (STARs):

- Les itinéraires IFR à l'interieur de la TMA sont ceux définie à la page AD2 GMMX - 34_1_a.
- Sauf autorisation contraire de l'approche, les aéronefs devront se conformer aux spécifications fixées pour chaque itinéraire normalisé aux instruments.
- Les points d'entrées de la TMA doivent figurer au plan de vol pour les aéronefs en rigime IFR

1.RELEVANT AIR TRAFFIC SERVICES:

Casablanca ACC and Marrakech Mènara APP provide air traffic control services in Marrakech Mènara TMA.

007°

30' W

2.AIRSPACE ALLOCATED TO MARRAKECH MÈNARA APP :

a-Lateral and Vertical limits (cf ENR 2.1)

b-Altimeter setting:

008° 00'W

The transition altitude in Marrakech Mènara TMA is 6000 ft. The transition level will be calculated by Marrakech Menara APP.

3.PROCEDURES:

a-Speed restriction:

-Except special clearance from Marrakech Mènara APP, the indicated airspeed (IAS) shall not exceed 250kts below FL 100

- b-Standard arrival routes (STAR): -IFR routes inside the TMA, are those defined in AD2 GMMX 34_1_a Except with other clearances, the aircraft shall comply with
- specifications set on each standard route.
- Entry points of the TMA should be included in the flight plan for ACFT under IFR rules

MARRAKECH-Ménara STARs(GNSS) RWY 10

(Protégés pour CAT A, B, C, D)

ITINERAIRES:

KUDAX 3A

KDX 3A: KUDAX et suivre 275° (272.73°T) direct jusqu'à LANBA. virer à gauche 205° (203.79°T) direct jusqu'à ODALO.

OBOGA 3A

BGA 3A: OBOGA et suivre 273° (269.96°T) direct jusqu'à LANBA. virer à gauche 205° (203.79°T) direct jusqu'à ODALO

MABAP 3A

MBP 3A: MABAP et suivre 213° (210.32°T) direct jusqu'à LANBA. virer à gauche 205° (203.79°T) direct jusqu'à ODALO

BNV 3A: BENOV et suivre 171° (168.64°T) direct jusqu'à LANBA. virer à droite 205° (203.79°T) direct jusqu'à ODALO

MAGAV 3A

MGV 3A: MAGAV et suivre 066° (063.71°T) direct jusqu'à ODALO.

GSN 3A: GOSNO et suivre 015° (012.34°T) direct jusqu'à ODALO.

LISRA 3A

LSR 3A: LISRA et suivre 002° (359.16°T) direct jusqu'à ODALO.

MKR 3A: MOKIR et suivre 284° (281.60°T) direct jusqu'à SIVSO. virer à droite 327° (324.34°T) direct jusqu'à ODALO.

PANNE DE COM:

En sus des dispositions des paragraphes 7 (ENR 1.2.3) et 4 (ENR 1.3.2), l'aéronef doit:

- Afficher code 7600
- Suivre la STAR PLN ou autorisée. En cas de guidage radar rejoindre la STAR initiale.
- Respecter les contraintes de niveau et de vitesse publiés.
- Se présenter à l'IAF au dernier niveau de vol assigné pour lequel il y a eu accusé de réception s'il est utilisable dans l'attente, à défaut le niveau le plus élevé de l'attente.
- Attendre à ce niveau jusqu'à la plus tardive des heures suivantes :
- . HAP.
- . Heure d'entrée dans l'attente plus 10 minutes. Puis descendre dans le circuit d'attente jusqu'au FL 060.
- Quitter l'IAF à ce niveau pour entreprendre la procédure d'approche connue ou estimée jusqu'à l'atterrissage.

OUTGOING ROUTES:

KUDAX 3A

KDX 3A: KUDAX and track 275 ° (272.73 ° T) direct to LANBA. turn left 205 ° (203.79 ° T) direct to ODALO.

OBOGA 3A

BGA 3A: OBOGA and track 273° (269.96°T) direct to LANBA. turn left 205° (203.79°T) direct to ODALO.

MABAP 3A

MBP 3A: MABAP and track 213° (210.32°T) direct to LANBA. turn left 205 ° (203.79 ° T) direct to ODALO.

BENOV 3A

BNV 3A: BENOV and track 171° (168.64°T) direct to LANBA. turn right 205 ° (203.79 ° T) direct to ODALO.

MAGAV 3A

MGV 3A: MAGAV and track 066° (063.71°T) direct to ODALO.

GOSNO 3A

GSN 3A: GOSNO and track 015° (012.34°T) direct to ODALO.

LISRA 3A

LSR 3A: LISRA and track 002° (359.16°T) direct to ODALO.

MOKIR 3A

MKR 3A: MOKIR and track 284° (281.60°T) direct to SIVSO. turn right 327° (324.34°T) direct to ODALO.

RADIO FAILURE:

In addition to the provisions of the paragraphs 7 (ENR 1.2.3) and 4 (ENR 1.3.2), the aircraft must:

- Squawk code 7600
- Follow the authorized or PLN STAR. In case of radar guidance, proceed to the initial STAR.
- Observe the published flight level and speed requirements.
- Proceed to the IAF at the last assigned level that was acknowledged, if this level is available in the holding pattern, otherwise at the highest level in the holding pattern.
- stay in the holding pattern at this level until the latest time as follow: EAT,
- Arrival time in the holding pattern plus 10 minutes.
- Affival unite in the holding pattern to FL 060.

 Leave the IAF at this level to perform the known or estimated approach. procedure until landing.

Identificateur de point de cheminement	Coordonnées	
KUDAX	N 31°48'30,86"	W 007°40'18,96"
OBOGA	N 31°50'15,53"	W 007°48'51,29"
MABAP	N 32°07'27,36"	W 008°11'49,62"
BENOV	N 32°05'38,77"	W 008°27'16,64"
LANBA	N 31°50'09,45"	W 008°23'37,76"
ODALO	N 31°38'46.97"	W 008°29'29.32"
MAGAV	N 31°31'31.05"	W 008°46'40.15"
GOSNO	N 31°19'04.79"	W 008°34'31.54"
LISRA	N 31°14'00.44"	W 008°29'03.92"
MOKIR	N 31°20'24.67"	W 007°36'46.01"
SIVSO	N 31°27'55.89"	W 008°20'23.00"
NAPOV	N 31°24'00.65"	W 007°57'22.12"
VABOL	N 31°22'44.97"	W 008°29'13.67"