

STANDARDIZED BRIEFINGS – DA42-VI

▪ LOCAL FLIGHT:

○ Departure safety briefing:

- T/O nature, T/O weight and rotation speed.
- Failure or warning before V_R RTO.
- Failure or warning after V_R : clean up, acknowledge, memory items, recover RWY HDG until TSA.
- Engine-out trajectory after TSA and ATC advisory.
- First altitude, heading and working area.

○ End of work briefing:

▪ Both engines operative:

- Joining the pattern.
- Altitude restriction.
- Traffic information and conflicts.
- Landing type and configuration choice.
- Intentions.

▪ One engine inoperative:

- Joining the pattern.
- Altitude restriction.
- Traffic information and conflicts.
- Landing type and configuration choice.
- One engine inop G/A procedure.

STANDARDIZED BRIEFINGS – DA42-VI

▪ CROSS-COUNTRY FLIGHT:

○ Departure safety briefing:

- T/O nature, T/O weight and rotation speed.
- Failure or warning before V_R : RTO.
- Failure or warning after V_R : clean up, acknowledge, memory items, recover RWY HDG until TSA.
- Engine-out trajectory after TSA and ATC advisory.
- First altitude, heading and WPT.
- Frequency changes and airspace boundaries.

○ Cruise briefing items:

- Final cruise level,
- Highest safe altitude and obstacle clearance,
- Potential alternates in case of problem, NOTAMs and WX,
- Cruise speed, LOAD and FF,
- Mandatory position reports,
- Frequency changes and airspace boundaries.

○ Descent and Approach briefing items:

- WX and NOTAMs: ATIS, SIGWX, ARPT equipment,
- Potential holds due to traffic,
- Transition LVL and airfield elevation,
- Joining the pattern,
- Landing configuration and G/A procedure,
- Airport diagram: Runway vacation and taxi itinerary.
- Threats: SIGWX, terrain and obstacles, traffic, bird hazard, hot spots, etc.