

1 Power On Display

Connect 5V power to scoreboard. The status LED will blink red/orange while scanning.

2 Wake Up Remote


Click either button once. The remote wakes from deep sleep and advertises BLE.

3 Auto-Pair & Ready

Display flashes **CONN** in green. MAC is saved in flash memory.

Remote Layout

Xiaomi XYLY01 BLE Clicker



Wear on wrist lanyard or clip via 3D printed holder

⏮ Padel Scoreboard Controls (Default Mode)

TRIGGER	BUTTON	ACTION & DISPLAY REACTION
Single Click	• Big Button	+ 1 Point Team 1 (Left / Blue) Advances 0 → 15 → 30 → 40 → Game / Tiebreak
Single Click	■ Small Button	+ 1 Point Team 2 (Right / Red) Advances 0 → 15 → 30 → 40 → Game / Tiebreak
Double Click Within 380ms	Either Button	UNDO Last Point Reverts point instantly; games module flashes
Long Press Hold ≥ 1.5s (at 0-0)	Either Button	Swap Court Sides Swaps Team 1 ↔ Team 2 sides & colors before start
Long Press Hold ≥ 1.5s (during match)	Either Button	Clock Mode Toggle Displays current real-time clock (HH:MM)
Any Click While in Clock Mode	Either Button	Wake back to Scoreboard Restores match score intact (does NOT score point)

🕒 Gym / Timer Mode Controls

- **Single Timer (Up / Down):**
 - **Big** Toggle Start / Pause
 - **Small** Step value (+1 / -1)
 - **Double Click** Reset to zero / target
- **Dual Timers (Left & Right Clocks):**
 - **Big** Click = Start/Pause Left | Double Click = Reset Left
 - **Small** Click = Start/Pause Right | Double Click = Reset Right

🔋 Battery & Pro Tips

- **Coin Battery:** Uses a standard **CR1632** 3V cell (lasts ~6–12 months). Twist open rear cap using a coin to replace.
- **Deep Sleep:** Remote enters sleep when unused. One click wakes it back up and re-links automatically.
- **Undo Window:** Double-click has a **380ms** threshold. Keep deliberate pace when scoring consecutive points.
- **Score Persistence:** Scores and paired remote MAC are preserved in NVS flash memory across power cycles.