
## Robot Introduction







#### Questions:

alexander.hirsch@student.uibk.ac.at

Alex Hirsch 1 / 32

## Content

- The Robot (internals + components)
- Communication (USB OTG / Bluetooth)
- Setup everything
- Example App
- Details:
   I2C, H-Bridge, PWM, Sensors

Alex Hirsch 2 / 32

# My Experiance (last year)




Alex Hirsch 3 / 32

# Now Better (hopefully)

- Improved communications
- Code examples
- Knowledge about firmware / interior setup
- Not multithreaded (better debugging)
- Easy to use interface

Alex Hirsch 4 / 32

## The Robot



Alex Hirsch 5 / 32

## 2 Layers

#### Interior

- DC Motors (movement)
- IR Sensors (range detection)
- Control Board
- Battery


#### On Top

Comm Board

<u> → new ←</u>


 Servo Motor (Catching Balls)

## Interior




Alex Hirsch 7 / 32

# On Top




Alex Hirsch 8 / 32

# Component Interaction



Alex Hirsch 9 / 32

## Component Interaction (detail)



Alex Hirsch 10 / 32

# Communication (wired)

#### **Benefits of Serial Connection:**

- very easy compared to USB
- device / platform independent

Comm Board

Serial

USB ↔ Serial Converter (FTDI 232)

USB OTG

Code Examples


Provided, scroll down





Phone powers Converter + Comm Board

# USB OTG (on the go)






Alex Hirsch 12 / 32

# Communication (wireless)

Comm Board Powers Bluetooth module






Pair w/ Phone

Secret code: 1234

Ground +5V (only for bluetooth)

I2C Control Board I2C Control Board



+5V Serial Convert
Ground /
RXD Bluetooth
TxD

NC Servo


NC ... not connected

Alex Hirsch 14 / 32

# Setup everything up

- Make sure Comm Board is connected propperly
- Connect serial converter / Bluetooth module to Comm Board
- 3) Check if battery is connected
- 4) Push button on the <u>underside</u> of the Robot
- 5) Connect Phone

Sneaky Button: On / Off




Alex Hirsch 16 / 32

### How does Serial Work

#### **Detail:**


Same as RS232 but with 0V 5V

It's character based!



Alex Hirsch 17 / 32

## WASD example App



W	Move forward	
S	Stop	
Α	Turn left	
D	Turn right	
X	Move backward	
-	Lower bar a few degree	
+	Rise bar a few degree	
Down	Fixed position for bar (low)	
Up	Fixed position for bar (high)	

Debug Output + Sensor Data Below

Application needs FTDriver library https://github.com/ksksue/FTDriver

Alex Hirsch 18 / 32

## WASD Code FTDriver instance

```
@Override
protected void onCreate(Bundle savedInstanceState) {
    super.onCreate(savedInstanceState);
    setContentView(R.layout.activity_main);

    textLog = (TextView) findViewById(R.id.textLog);

    com = new FTDriver((UsbManager) getSystemService(USB_SERVICE));
    connect();
}
```

Alex Hirsch 19 / 32

### WASD Code Write Data

```
private FTDriver com;

public void comWrite(byte[] data) {
    if (com.isConnected()) {
        com.write(data);
    } else {
        textLog.append("not connected\n");
    }
}
```

Alex Hirsch 20 / 32

### WASD Code Read Data

```
private FTDriver com;

public String comRead() {
    String s = "";
    int i = 0;
    int n = 0;
    while (i < 3 || n > 0) {
        byte[] buffer = new byte[256];
        n = com.read(buffer);
        s += new String(buffer, 0, n);
        i++;
    }
    return s;
}
```



Strange android tripple buffering

Alex Hirsch 21 / 32

### WASD Code ReadWrite Data

```
private FTDriver com;

public String comReadWrite(byte[] data) {
    com.write(data);
    try {
        Thread.sleep(100);
    } catch (InterruptedException e) {
        // ignore
    }
    return comRead();
}
```

Alex Hirsch 22 / 32

## WASD Code Commands

#### Commands without parameter

W	Move forward
S	Stop
а	Turn left
d	Turn right
X	Move backward
-	Lower bar a few degree
+	Rise bar a few degree
r	LEDs on
е	LEDs off
q	Read sensors

#### Commands with parameter

```
public void robotSetLeds(byte red, byte blue)
      ComReadWrite(
            new byte[] { 'u', red, blue, '\r', '\n' }
public void robotSetVelocity(byte left, byte
right) {
      ComReadWrite(
            new byte[] { 'i', left, right, '\r', '\n' }
public void robotSetBar(byte value) {
      ComReadWrite(
            new byte[] { 'o', value, '\r', '\n' }
```

Example: new byte[] {'w', '\r', '\n'};

\r is ignored anyway, \n is used as lineending

## Android USB Permission (simple)

```
<?xml version="1.0" encoding="utf-8"?>
<manifest ...>
  <uses-feature android:name="android.hardware.usb.host" />
  <application ...>
    <activity ...>
       <intent-filter>
         <action android:name="android.intent.action.MAIN" />
         <category android:name="android.intent.category.LAUNCHER" />
         <action
android:name="android.hardware.usb.action.USB_DEVICE_ATTACHED" />
       </intent-filter>
       <meta-data
         android:name="android.hardware.usb.action.USB_DEVICE_ATTACHED"
         android:resource="@xml/device_filter" />
    </activity>
  </application>
</manifest>
```

Alex Hirsch 24 / 32

## Android USB Permission (better)

Use intent filter

+

Implement Permission request

see https://developer.android.com/guide/topics/connectivity/usb/host.html

Alex Hirsch 25 / 32


### Bluetooth

- see http://luugiathuy.com/2011/02/android-java-bluetooth/
- see http://english.cxem.net/arduino/arduino5.php



Alex Hirsch 26 / 32


## **I2C Communication**



Master / Slave
Each slave has a 7 Bit address
+ 1 bit to state read or write access


Src: ATmega32 datasheet

## I2C Communication (example)



Alex Hirsch 28 / 32


# LEDs (PWM)



PWM... Pulse Width Modulation

Alex Hirsch 29 / 32

# DC Motors (H - Bridge)




Alex Hirsch 30 / 32

## IR Sensor



GP2Y0A21YK0F
According to Datasheet from 10 to 80 cm



Sensor Output Voltage will be provided via the Comm Board in hexadecimal notation (0x00 – 0xFF) per sensor.

Example: "sensor: 0x00 0xa2 0xef 0x12 0xf3 0x01 0x00 0x17"

Alex Hirsch 31 / 32

## Comm Board Code

File	Content
main.c	entry point + command execution
uart.c	serial communication (low level)
twi.c	i2c communication
timer1.c	PWM servo output
log.h	debug macro
command.c	handle received data (available commands listed here)
robot.c	robot control (high level)

Alex Hirsch 32 / 32