
CROSS SECTION PROFILE

CROSS SECTION PROFILE								
	LENGTH	ELEV.	SLOPE	ROUGHNESS				
1	-147.0	-28.8	.00	1.00				
2	-115.0	-20.9						
3	-114.0	-20.7	5.00	1.00				
4	-87.9	-12.1	3.03	1.00				
5	-86.9	-12.0	10.00	1.00				
6	-82.9	-11.9	40.00	1.00				
7	-79.9	-11.9	FLAT	1.00				
8	3.1	.5	6.72	1.00				
9			3.45	1.00				
	4.1	.8	4.35	1.00				
10	8.1	1.7	3.95	1.00				
11	11.1	2.4	5.88	1.00				
12	13.1	2.8	1.75	1.00				
13	16.1	4.5	1.45	1.00				
14	24.1	10.0	2.33	1.00				
15	26.1	10.9						
16	28.1	11.8	2.06	1.00				
17	31.1	12.5	4.55	1.00				
18	37.1	14.0	4.05	1.00				
19	40.1	14.3	10.34	1.00				
20	45.1	15.0	6.33	1.00				
20		T SLOPE	8.00	I ACT DOMOUNDES	1.00			
	LAS	T STORE	0.00	LAST ROUGHNESS	1.00			

OUTPUT TABLE

INPUT PARAMETERS RUNUP RESULTS

WATER LEVEL ABOVE DATUM (FT.)	DEEP WATER WAVE HEIGHT (FT.)	WAVE PERIOD (SEC.)	BREAKING SLOPE NUMBER	RUNUP SLOPE NUMBER	RUNUP ABOVE WATER LEVEL (FT.)	BREAKER DEPTH (FT.)
9.00	1.88	5.06	11	19	5.33	2.56
9.00	1.88	5.32	11	19	5.49	2.60
9.00	1.88	5.59	11	19	5.66	2.64
9.00	1.98	5.06	11	19	5.66	2.68
9.00	1.98	5.32	11	19	5.85	2.72
9.00	1.98	5.59	11	19	6.01	2.76
9.00	2.08	5.06	11	19	5.96	2.79
9.00	2.08	5.32	11	20	6.14	2.83
9.00	2.08	5.59	11	20	6.34	2.87