\*

## CROSS SECTION PROFILE

	011000	02011011	11101 1111	
	LENGTH	ELEV.	SLOPE	ROUGHNESS
1	-399.0	-16.9	.00	1.00
2	-363.0	-16.9	20.00	
3	-355.0	-16.5		1.00
4	-291.0	-13.2	19.39	1.00
5	-270.0	-11.2	10.50	1.00
6	-222.9	-6.5	9.98	1.00
7	-221.9	-6.4	25.00	1.00
			FLAT	1.00
8	-137.9	-6.4	22.62	1.00
9	-118.9	-5.6	500.00	1.00
10	-108.9	-5.6	22.27	1.00
11	-8.9	-1.1	8.59	1.00
12	8.1	.9	12.50	1.00
13	14.1	1.4		
14	26.1	2.6	9.52	1.00
15	27.1	2.9	4.55	1.00
16	37.1	7.6	2.11	1.00
17	45.1	7.6	FLAT	1.00
			3.33	1.00
18	46.1	7.9	1.49	1.00
19	52.1	11.9	16.67	1.00
20	53.1	12.0		

LAST SLOPE 31.00 LAST ROUGHNESS 1.00

\*

## OUTPUT TABLE

## INPUT PARAMETERS RUNUP RESULTS

WATER LEVEL ABOVE DATUM (FT.)	DEEP WATER WAVE HEIGHT (FT.)	WAVE PERIOD (SEC.)	BREAKING SLOPE NUMBER	RUNUP SLOPE NUMBER	RUNUP ABOVE WATER LEVEL (FT.)	BREAKER DEPTH (FT.)
9.00	2.78	7.76	11	20	11.91 1.25 SOLUTION DOES NOT	5.03 CONVERGE
9.00	2.78	8.17	11	20	12.38 1.28 SOLUTION DOES NOT	5.13 CONVERGE
9.00	2.78	8.58	11	20	12.76 1.33 SOLUTION DOES NOT	5.23 CONVERGE
9.00	2.92	7.76	11	20	12.11 1.28 SOLUTION DOES NOT	5.23 CONVERGE
9.00	2.92	8.17	11	20	12.57 1.31 SOLUTION DOES NOT	5.34 CONVERGE
9.00	2.92	8.58	11	20	13.00 1.34 SOLUTION DOES NOT	5.44 CONVERGE
9.00	3.07	7.76	11	20	12.35 1.32 SOLUTION DOES NOT	5.45 CONVERGE
9.00	3.07	8.17	11	20	12.80 1.35 SOLUTION DOES NOT	
9.00	3.07	8.58	11	20	13.30 1.38 SOLUTION DOES NOT	5.66 CONVERGE