IoT: Client Devices

An Example Startup Script

Particular Script Format

```
#!/bin/sh
<stuff that always happens>
<start function>
<stop function>
<case handling args>
exit $?
```

```
3 DAEMON_NAME="DAEMON NAME"
13 }
15 restart() {
     start
     start)
     start
     stop)
     stop
     restart reload)
     restart
```

```
Usage: ./sample_framed {start|stop|restart}
[cclamb@ubuntu:~ $ ./sample_framed start
Starting DAEMON NAME: OK
[cclamb@ubuntu:~ $ ./sample_framed stop
Stopping DAEMON NAME: OK
[cclamb@ubuntu:~ $ ./sample_framed restart
Stopping DAEMON NAME: OK
Starting DAEMON NAME: OK
cclamb@ubuntu:~ $
```

Running the Frame

Filling Out the Frame

Let's use our sample daemon

```
3 DAEMON_NAME="sampled"
5 start() {
     /usr/sbin/$DAEMON_NAME
    touch /var/lock/$DAEMON_NAME
     echo "OK"
11
    killall $DAEMON_NAME
    rm -f /var/lock/$DAEMON_NAME
     echo "OK"
17 }
19 restart() {
     stop
21
     start
22 }
23
24 case "$1" in
    start)
    start
    ;;
     stop)
    stop
31 restart | reload)
32 restart
36 exit 1
```

Move sampled to image

Move sampled to device

scp -P 2222 sampled <username>@localhost:~/

Move it to /usr/sbin

...this is the location pointed to in start script

Move Start Script to Device

- place in /etc/init.d
- I called S80sampled
- Reboot, login, and check out /var/log/messages