





#### I2C BUS 0 SHARED WITH FUNCTION BOARD 12C0{12C}♦-I2C0.SCL 12CO.SCL I2CO.SDA I2CO.SDA JST\_SH\_4\_RA JST\_SH\_4\_RA +3.3V **←** +3.3V **<** GND GND P1 PAD\_SOLDER\_2mm +3.3V Ī2C\_INT< $\Lambda$


### I2C BUS 1






# SPI1 BREAKOUT


Most MicroMod Processors don't connect SPI1. These pads allow for expansion/bodge wires.



## SPARE 10



## **EXPANSION MOUNTS**



Intended for mounting and connection of Sparkfun Qwiic sensors

Spare IO broken out as pads.

Check processor support before use!

Sheet: /Expansion IO/ File: expansion.kicad\_sch

		Tit	le:	Ex	pa	ns	ion	10
--	--	-----	-----	----	----	----	-----	----

Size: A4	Date: 2023-08-09	Rev: V1.0
KiCad E.D.A. ki	cad 7.0.6	ld: 5/6

