# **MRI** Procedure Information

For Abbott Medical MR Conditional Neurostimulation Systems

Clinician's Manual



# **Contents**

1
1
1 1 1
2
2
3 3
5
6 6 
12 12
13 14 15 16
18
18 18 19
20 20 21
21
22

### Introduction

Read the information in this manual before conducting an MRI scan on a patient with an implanted Abbott Medical neurostimulation system. This manual contains information about the components that comprise the MR Conditional system, applicable warnings and precautions related to the MR Conditional system, and the requirements that you must follow in order for the implanted neurostimulation system to be conditionally safe for MRI scans

Refer to the appropriate clinician's manual or user's guide for non-MRI related information. If you have any questions, contact Technical Support. See "Technical Support" (page 21).

NOTE: Before conducting an MRI scan, always ensure that you are using the most recent version of these MRI procedures. Contact Technical Support or get the most recent version online at **medical.abbott/manuals**. For more information about MR Conditional products, visit the Abbott Medical product information page at neuromodulation.abbott/MRI-ready.

## **Symbols and Definitions**

The following symbols may be used in this document and on some of the products and packaging:

Table 1. Symbols and definitions

Symbol	Definition
$\triangle$	Caution, consult accompanying documents
MR	Magnetic Resonance (MR) Conditional, an item with demonstrated safety in the MR environment within the defined conditions. At a minimum, address the conditions of the static magnetic field, the switched gradient magnetic field, and the radiofrequency fields. Additional conditions, including specific configurations of the item, may be required.
MR	Magnetic Resonance (MR) Unsafe, an item poses unacceptable risks to the patient, medical staff, or other persons within an MR environment

## **Warnings and Precautions**

Read this section for warnings and precautions related to an MR Conditional neurostimulation system.

### Warnings

**Unapproved components.** Do not perform an MRI scan on patients who have any components of a neurostimulation system that are unapproved for use in an MR environment.

**Abandoned devices.** Do not perform an MRI scan on patients who have any abandoned neurostimulation devices, such as an IPG, lead, extension, or lead adapter.

**Nonfunctional leads.** Do not perform an MRI scan on patients with broken or intermittent MR Conditional leads, or lead impedance measurements not within the lead impedance limits. MRI scans of patients with nonfunctional leads may result in higher than normal heating occurring at the location of the implanted lead electrodes.

**Location of implanted system.** To meet the MR Conditional requirements, components must be implanted according to the approved locations specified by the MRI labeling. Implant location can be confirmed with X-ray imaging or by referring to the patient records. The MR Conditional leads must be implanted in the epidural space and routed subcutaneously to the IPG pocket. Multiple MR Conditional leads should be routed in close proximity. Nonadjacent leads can possibly result in increased unintended stimulation or heating at the lead electrodes.

**Location of RF transmit-receive coils.** Head or extremity MRI scans can be conducted safely using a Detachable Head or Extremity RF transmit-receive coil when no parts of the implanted neurostimulation system are within the transmit-receive coil according to the conditions specified for each system in the MRI labeling. This can be confirmed with X-ray imaging of the neck, head, and extremity regions or by referring to the patient records. This warning is not applicable to IPG Model 3660 or 3662 with lead Model 3186.

**Skin erosion.** Do not perform an MRI scan on patients who have any portion of their implanted system exposed due to skin erosion. The MRI scan may cause heating of the system, which could result in serious patient injury.

**Neurostimulation trial systems.** Do not perform an MRI scan on patients who have a neurostimulation trial system or any components that are not fully implanted because these devices have not been tested in an MR environment.

**Multiple neurostimulation systems.** MRI has not been tested with multiple MR Conditional neurostimulation systems (multiple IPGs) and may cause heating of the lead electrodes, which could result in serious patient injury.

Other implanted medical devices. Scanning patients who have other MR Conditional devices is acceptable as long as all the MR Conditional requirements for each of the implanted devices are met. Do not conduct an MRI scan if any conditions or implants prohibit it. If you are unclear what implants are present, perform an X ray to determine the implant type and location.

Imaging with atoms other than hydrogen. Imaging with atoms other than hydrogen has not been tested and could result in serious patient injury.

### **Precautions**

**External devices.** Do not allow external control devices into the scanner magnet room, such as a programmer, controller, or charging system. Because these devices contain ferromagnetic material, they can be affected by the MRI magnet, may present a projectile hazard, and are considered MR Unsafe.

**Electromagnetic interference (EMI).** Some electrical equipment, such as an MRI machine, may generate enough EMI to interfere with the operation of the internal or external electronic components of a neurostimulation system if the equipment is too close to the system component. To mitigate the effects of possible EMI, increase the distance between the electrical equipment and the system component that is affected, and try performing the operation again.

### **Potential Adverse Events**

The Abbott Medical MR Conditional neurostimulation system has been designed to minimize the potential adverse events that may cause patient harm. The following potential adverse events may occur in the MRI environment:

- Lead electrode heating resulting in patient discomfort, tissue damage, or serious patient injury
- IPG heating resulting in tissue damage in the implant pocket or patient discomfort or both
- Induced currents on leads resulting in overstimulation or shocking sensations
- Damage to the IPG or leads causing the system to fail to deliver stimulation or causing the system to deliver overstimulation
- Damage to the functionality or mechanical integrity of the IPG resulting in the inability to communicate with the IPG
- Movement or vibration of the IPG or leads

## **Preparing a Patient for an MRI Scan**

Before conducting an MRI scan, you must perform the following steps:

- 1. Confirm the MR Conditional components and location of the system.
- 2. Confirm that no adverse conditions to MR scanning are present.
- 3. Ensure the patient's neurostimulation system is in MRI mode.
- 4. Review the general scan requirements.
- 5. Confirm implant locations and scan requirements for the patient's system.

The following sections provide more information about each of these steps. You can also use the form in the appendix of this manual as a quick-reference checklist to help you determine a patient's eligibility for an MRI scan.

NOTE: Before the MRI procedure, inform patients to set their IPG to MRI mode within a day of their procedure. Also inform patients to bring their patient ID card, their patient controller or programmer, and their charger (if applicable). Remind patients with a patient controller to recharge it before the MRI procedure.

## Step 1: Confirm the MR Conditional Components and Location of the System

Before performing a scan, confirm the patient's neurostimulation system components are MR Conditional and implanted in approved locations. When a neurostimulation system is implanted, a patient receives an identification card and patient controller (if applicable) that identifies the model numbers of the implanted components to help you identify them as MR Conditional. To confirm that the patient's implanted system contains only MR Conditional components, review the patient's identification card or use the patient controller for his or her system. Use the following table to determine if the components are implanted in approved locations.

NOTE: If a patient does not have his or her identification card or patient controller, consider other means of confirming the MR Conditional system, such as referencing the patient's medical history or contacting Technical Support. See "Technical Support" (page 21).

### Using a Patient Identification Card to Confirm the Implanted System Components

To confirm that the patient's system contains only MR Conditional components and that those components are implanted in approved locations, follow these steps:

- 1. Request the identification card from the patient.
- 2. Using the following table, check the IPG and lead model numbers on the card are MR Conditional components.
- 3. Using the following table, check the IPG and lead model numbers on the card are implanted in approved locations.

WARNING: For a neurostimulation system to be MR Conditional, all implanted components must be approved MR Conditional models and implanted in approved locations according to the following table. If the implanted system contains components or models not listed in the following table, then the system is considered untested for an MRI environment. In addition, a component must be implanted in its approved location as listed in the following table or the entire implanted system is considered untested for an MRI environment.


Table 2. Approved models and implant locations for an MR Conditional neurostimulation system

MR Conditional System Components		Approved Component Locations (as shown in Figure 1)
IPG*	Lead**	
3660 Proclaim™ XR 5 IPG	3186 Octrode™ lead, 60 cm	• IPG in upper buttock, low back, flank, abdomen, or midline
3662 Proclaim™ XR 7 IPG		• Lead tip in the epidural space between the C1 and S2 vertebrae
	3228 Penta™ lead, 60 cm	IPG in upper buttock, low back, flank, abdomen, or midline
		• Lead tip in the epidural space between the T7 and T12 vertebrae
3664 Proclaim™ DRG IPG	MN10450-50 lead, 50 cm	IPG in upper buttock, low back, flank, or abdomen
	MN10450-50A lead, 50 cm	• Lead tip in the epidural space between the T10 and S2 vertebrae
3771 Protégé MRI™ IPG	3186 Octrode™ lead, 60 cm	IPG in upper buttock, low back, flank, abdomen, or midline
3772 Prodigy MRI™ IPG	3228 Penta™ lead, 60 cm	• Lead tip in the epidural space between the T7 and T12 vertebrae

 $<sup>{}^{*}\</sup>text{The IPG}$  port plug associated with these models is an MR Conditional component.

NOTE: Extensions are untested and are therefore considered MR Unsafe.

Figure 1. Anatomical locations for implanted components of MR Conditional neurostimulation systems



### IPG Implant Locations\*

- 1. Abdomen
- 2. Midline
- 3. Upper buttock, low back, flank

#### Lead Tip Locations\*

- 4. C1-S2
- 5. T7-T12
- 6. T10-S2
- \* Refer to the table above for approved locations for each IPG and lead configuration.

<sup>\*\*</sup>The anchors associated with these models are MR Conditional components. Multiple MR conditional leads and anchors may be implanted.

### Using a Patient Controller to Confirm the System Components

To confirm that the patient's system contains only MR Conditional components using the patient controller, follow these steps:

- 1. Turn on the patient controller by pressing the power button.
- 2. Tap the patient controller app icon on the Home screen to launch the app. The patient controller app automatically connects to the IPG. While the app starts up, you will see the following Start-up screen.

NOTE: In some cases, use of Bluetooth® wireless technology media devices (such as headphones or speakers) may prevent the patient controller from connecting to the IPG. Abbott Medical recommends disconnecting these accessories before you attempt to set the IPG mode using the patient controller.

NOTE: The patient controller app times out after 3 minutes of inactivity.

Figure 2. Start-up screen



3. After you connect to the IPG, you should see a screen similar to the following Therapy screen.

Figure 3. Therapy screen



- 4. Tap the information icon in the upper-right corner of the screen. A system screen opens showing information about the generator, including the model number.
  - If the patient is implanted with only MR Conditional components, the top of the screen displays the message "System is MR Conditional" (see the following figure).
  - If the system contains components other than approved MR Conditional models, the screen displays "MRI is Not Permitted."

Figure 4. System screen showing MR Conditional components



- 5. To view information about the implanted leads, such as model numbers, tap the Leads/Extensions icon at the bottom of the screen.
- 6. Confirm the IPG and lead model numbers on the controller screens are MR Conditional components listed in "Table 2. Approved models and implant locations for an MR Conditional neurostimulation system" (page 3).
- 7. When you are finished reviewing the system information, tap **Done**.

## **Step 2: Confirm No Adverse Conditions to Scanning Are Present**


If any conditions exist that could make an MRI scan unsafe, do not perform the MRI scan. Such conditions include any of the following:

- The presence of implanted neurostimulation components that are not listed as MR Conditional. See "Table 2. Approved models and implant locations for an MR Conditional neurostimulation system" (page 3).
- The location of MR Conditional components in an area other than what is listed in the previous table. See "Table 2. Approved models and implant locations for an MR Conditional neurostimulation system" (page 3).
- The presence of abandoned neurostimulation devices, such as an IPG, lead, extension, or lead adapter
- The presence of broken or intermittently functioning MR Conditional leads
- The presence of more than one IPG
- Any exposed portions of MR Conditional neurostimulation system components due to skin erosion
- The presence of any other implanted devices (active or passive implanted devices) that prohibit safe scanning
- The presence of a fever in the patient on the day of the scan (only applicable to IPG Models 3660, 3662, and 3664)

## Step 3: Ensure the Neurostimulation System Is in MRI Mode

MRI mode is a special configuration of the implanted neurostimulation system that allows a patient to safely receive an MRI scan according to the conditions and requirements in this document. Before conducting an MRI scan, ensure that the patient's neurostimulation system is in MRI mode. Before you begin, you need to identify the type of handheld device the patient has: a patient controller or a patient programmer. The following figure shows the differences between a patient controller and a patient programmer.

Figure 5. Patient controller (left) versus patient programmer (right)



- To ensure the system is set to MRI mode using a patient controller, refer to the instructions in the following section.
- To ensure the system is set to MRI mode using a patient programmer, refer to the instructions in "Using the Patient Programmer to Confirm MRI Mode" (page 9).

CAUTION: Do not bring any external control devices, such as a programmer, controller, or charger (if applicable) into the scanner magnet room (Zone IV). Because these devices contain ferromagnetic material, they can be affected by the MRI magnet, may present a projectile hazard, and are considered MR Unsafe.

NOTE: If the patient did not bring the patient controller on the day of the MRI procedure, a clinician programmer can also be used. After connecting to the IPG using the clinician programmer, an authorized representative can place the IPG in MRI mode.

#### Using the Patient Controller to Confirm MRI Mode

To ensure that the patient's neurostimulation system is in MRI mode using a patient controller, follow these steps.

- 1. Turn on the patient controller by pressing the power button.
- 2. Tap the patient controller app icon on the Home screen to launch the app. The patient controller app automatically connects to the IPG. While the app starts up, you will see the following Start-up screen.

NOTE: In some cases, use of Bluetooth® wireless technology media devices (such as headphones or speakers) may prevent the patient controller from connecting to the IPG. Abbott Medical recommends disconnecting these accessories before you attempt to set the IPG mode using the patient controller.

NOTE: The patient controller app times out after 3 minutes of inactivity.

Figure 6. Start-up screen



3. After the app connects with the IPG, the following screen appears if the IPG is in MRI mode. If you do not see this screen, the IPG will need to be set to MRI mode. See "Setting the IPG to MRI Mode Using a Patient Controller" (page 7).

Figure 7. MRI mode screen on a patient controller



### Setting the IPG to MRI Mode Using a Patient Controller

To set the IPG to MRI mode, follow these steps.

NOTE: Before patients arrive for the MRI procedure, consider reminding them to recharge their patient controller and bring it with them in order to use it to confirm that the IPG is set to MRI mode. Also advise patients to set their IPG to MRI mode within a day of their procedure.

1. Ensure that the patient controller is connected with the IPG. If MRI mode is not enabled, you should see a screen similar to the following Therapy screen.

Figure 8. Therapy screen



1. Mode

2. Tap **Mode** to display the Mode screen.

Figure 9. Mode screen



3. Tap MRI Mode to view the MRI Mode screen.

Figure 10. MRI Mode screen



- 4. Tap the **MRI Mode** switch.
- 5. When the "Set Generator to MRI Mode" message appears, tap **Continue**. Stimulation stops, and the patient controller app checks the system for any issues. If the checks are successful, the "Proceed with MRI" message appears and the MRI mode is on (see the following figure).

NOTE: If a warning screen appears instead of the "Proceed with MRI" message, you cannot set the IPG to MRI mode and cannot perform an MRI scan. Refer to "Troubleshooting" (page 20) for more information. After troubleshooting, if you continue to receive a warning screen, do not perform the MRI scan.

6. Tap **OK** and proceed with the MRI scan.

Figure 11. Proceed with MRI message




### Using the Patient Programmer to Confirm MRI Mode

To ensure that the patient's neurostimulation system is in MRI mode using a patient programmer, follow these steps:


- 1. Ensure that the programmer is off. (It turns itself off after one minute of non-use.)
- 2. Plug the communication wand into the wand port on the bottom of the programmer.

Figure 12. Plug the wand into the programmer




- 3. Press the Power key to turn on the programmer. The Diagnostic Test screen appears.
- 4. Place the flat, circular end of the wand over the IPG site.

Figure 13. Place the wand over the IPG site  $\,$ 



5. Wait for the LOCATING IPG screen to appear and hold the wand in place. The programmer beeps while it is trying to locate the IPG.

Figure 14. LOCATING IPG screen




NOTE: The programmer will try to locate the IPG for about 5 seconds before a screen appears to retry communication. If the programmer does not establish communication, move the wand slowly over the IPG site in small circular movements until you achieve communication.

NOTE: After you have established communication with the IPG, keep the wand in place. If you move the wand from over the IPG site, you may lose communication with the IPG.

6. Check the programmer's screen to verify that the programmer has established communication with the IPG. When the programmer finds the IPG, the beeping stops and the following screen appears.

Figure 15. IPG FOUND screen




7. Next, an IPG information screen appears. If the IPG is part of an MR Conditional system, the patient programmer will show an MR icon in the upper right corner of the screen.

Figure 16. MR icon on the IPG information screen



8. If the IPG is set to MRI mode, the following screen appears. If you do not see this screen, the IPG will need to be set to MRI mode. See the following section.

Figure 17. MRI mode screen




## Setting the IPG to MRI Mode Using a Patient Programmer

To set the IPG to MRI mode, follow these steps.

NOTE: Before patients arrive for the MRI procedure, consider reminding them to fully recharge their IPG in order be able to set the IPG to MRI mode. Also advise patients to set their IPG to MRI mode within a day of their procedure.

The following image shows the different parts of the patient programmer.

Figure 18. Parts of the patient programmer



- 1. Amplitude Decrease key
- 2. Amplitude Increase key
- 3. Display screen
- 4. Power key
- 5. Balance key
- 6. Previous Screen key
- 7. Scroll keys (left and right)
- 8. Select key
- 9. Battery pack
- 10. Battery release latch
- 11. Wand port
- 12. Communication wand connector


1. Ensure that you have established communication with the patient programmer by following the steps in "Using the Patient Programmer to Confirm MRI Mode" (page 9). The following screen appears.

Figure 19. Operational Display screen



2. Press either one of the Scroll keys on the programmer until the MRI mode icon (MR) appears in the user option window on the bottom left corner of the screen.

Figure 20. Scroll to the MRI mode icon



3. Press the Select key on the programmer. The following screen appears.


Figure 21. Enter MRI mode screen



4. Press the Select key. The programmer stops stimulation, checks the impedance on the lead electrodes, and checks the remaining battery capacity of the IPG. If the checks are successful, the following screen appears indicating that the IPG is in MRI mode.

NOTE: If you see a warning screen instead of the following MRI mode screen, refer to "Troubleshooting" (page 20) for guidelines on how to proceed. After troubleshooting, if you continue to receive a warning screen, do not perform the MRI scan. Contact Technical Support to resolve the issue.

Figure 22. MRI mode screen



## **Step 4: Review the General Scan Requirements**

After you have confirmed that the patient's IPG is set to MRI mode, set up the MRI equipment. Refer to the following tables for MRI equipment and scanning requirements.

### **MRI Equipment and Scanning Requirements**

Patients implanted with MR Conditional components of an Abbott Medical neurostimulation system must be scanned using a 1.5-T system according to the following requirements.

CAUTION: Before reviewing the following requirements, use the information in Table 2 to confirm the implanted neurostimulation system components are MR Conditional and are within the indicated implant locations. Use the following information to review the scanning requirements and restrictions for the various IPG and lead configurations.

NOTE: For information about the MRI equipment that will be used to scan the patient, including important safety information, equipment features, and instructions for use, refer to the manual for the MRI equipment.

The following tables indicate general scan requirements.

Table 3. General scan requirements

General Scan Requirements				
MRI system type	1.5-T cylindrical-bore magnet, horizontal field orientation	WARNING: Only use 1.5-T cylindrical-bore magnet, horizontal field orientation MRI systems. Other MRI systems, such as 1.0-T and 3.0-T machines or vertical field orientation machines, have not been tested and could cause device damage and excessive heating of implanted components, which could result in serious patient injury.		
Gradient slew rate	Maximum gradient slew rate of ≤ 200 T/m/s per axis	WARNING: Do not use gradient slew rates greater than 200 T/m/s because they have not been tested and could increase the risk of induced stimulation or heating of the neurostimulator.		
Spatial field gradient	Maximum spatial field gradient of 30 T/m (3000 G/cm)			
Patient position	Supine, patient's arms must be at his or her sides	WARNING: Any prone patient positions or "superman" positions (where the patient's arm is raised above his or her head) are excluded and have not been tested.		
Total active scan time (RF on-time)	30 minutes total of active scan time per session	WARNING: Exceeding the active scan time limit increases the risk of excessive heating, which could result in serious patient injury.		
	<ul> <li>30-minute wait between sessions</li> </ul>	NOTE: During the MRI scan, visually and audibly monitor the patient, including verbal communication. Instruct the patient to notify MR		

vibration is experienced.

personnel immediately if any discomfort, pain, heating, stimulation, or

## Step 5: Confirm Implant Locations and Scan Requirements for the Patient's System

Find the patient's IPG and lead configuration in the list below. The list directs you to the information for implant locations and scan requirements for that system. Click the link or go to the page listed for the appropriate system.

- "Proclaim™ XR IPG with Octrode™ Lead" (page 14)
- "Proclaim™ XR IPG with Penta™ Lead" (page 15)
- "Proclaim™ DRG IPG with MN10450-50 or MN10450-50A Lead" (page 16)
- "Protégé™ MRI or Prodigy™ MRI with Octrode™ or Penta™ Lead" (page 17)

### Proclaim™ XR IPG with Octrode™ Lead

Table 4.

Implant Locations for Proclaim XR IPG with Octrode Lead		
IPG*	Lead**	Approved Implant Locations
3660 Proclaim XR 5	3186 Octrode, 60 cm	IPG in upper buttock, low back, flank, abdomen, or midline
3662 Proclaim XR 7		<ul> <li>Lead tip in the epidural space between the C1 and S2 vertebrae</li> </ul>

<sup>\*</sup>The IPG port plug associated with these models is an MR Conditional component.

NOTE: Extensions are untested and are therefore considered MR Unsafe.

Table 5.

IPG Model	Lead Model	Scan Region	RF Coil	RF Power	Notes and Warnings
Proclaim XR 3660 3662	Octrode 3186	Any body part	Integrated Whole body transmit coil (Circularly Polarized only) with any receive coil	Normal operating mode	1, 2, 3, 6
Caution:		Head scans	Integrated Whole body transmit coil (Circularly Polarized only) with any receive coil -OR-	Normal operating mode	1, 2, 3, 6
Confirm the ead and IPG ocations are			Detachable Head transmit-receive coil (Circularly Polarized only)	Normal operating mode	1, 2, 3, 4, 6
approved per		Extremity scans			
Table 4 above.		<ul> <li>All including hip and shoulder</li> </ul>	Integrated Whole body transmit coil (Circularly Polarized only) with any receive coil	Normal operating mode	1, 2, 3, 6
		<ul> <li>All except hip and shoulder</li> </ul>	Detachable Extremity transmit- receive coil (Circularly Polarized only)	Normal operating mode	1, 2, 3, 4, 5, 6

- 1. NOTE: The SAR requirements will be met if the scanner is in normal operating mode.
- 2. NOTE: To allow the MRI scanner to estimate the SAR, ensure that you enter the patient's body weight accurately into the scanner.
- 3. WARNING: Do not conduct MRI scans in first-level controlled or second-level controlled operating mode. These modes allow higher levels of RF energy and may cause excessive heating of implanted components, which could result in serious patient injury.
- 4. WARNING: Only Circularly Polarized, birdcage designs of Detachable Head and Extremity RF transmit-receive coils have been tested. Do not use other transmit coil designs (e.g., linear, phased-array, or saddle) because these have not been tested and could result in serious patient injury.
- 5. WARNING: Scans of the hips and shoulders have not been tested using Detachable Extremity RF transmit-receive coils. For hip and shoulder scans, use an Integrated Whole body RF transmit coil (Circularly Polarized only) with any receive coil according to RF power requirements listed above.
- 6. WARNING: Before an MRI scan, determine the patient's body temperature. If the patient has a fever, you should not perform an MRI scan.

<sup>\*\*</sup>The anchors associated with these models are MR Conditional components. Multiple MR conditional leads and anchors may be implanted.

### Proclaim™ XR IPG with Penta™ Lead

Table 6.

Implant Locations for Proclaim XR IPG with Penta Lead		
IPG*	Lead**	Approved Implant Locations
3660 Proclaim XR 5	3228 Penta, 60 cm	IPG in upper buttock, low back, flank, abdomen, or midline
3662 Proclaim XR 7		<ul> <li>Lead tip in the epidural space between the T7 and T12 vertebrae</li> </ul>

<sup>\*</sup>The IPG port plug associated with these models is an MR Conditional component.

NOTE: Extensions are untested and are therefore considered MR Unsafe.

Table 7.

RF Field Requirements for Proclaim XR IPG with Penta Lead					
IPG Model	Lead Model	Scan Region	RF Coil	RF Power	Notes and Warnings
Proclaim XR 3660 3662	Penta 3228	Any body part	Integrated Whole body transmit coil (Circularly Polarized only) with any receive coil	Whole body SAR ≤ 0.1 W/kg	2, 3, 4, 8
$\triangle$		Head scans	Integrated Whole body transmit coil (Circularly Polarized only) with any receive coil	Whole body SAR ≤ 0.1 W/kg	2, 3, 4, 8
Caution:			-OR-		
Confirm the lead and IPG			Detachable Head transmit-receive coil (Circularly Polarized only)	Normal operating mode	1, 2, 3, 4, 5, 7
locations are approved per		Extremity scans			
Table 6 above.		<ul> <li>All including hip and shoulder</li> </ul>	Integrated Whole body transmit coil (Circularly Polarized only) with any receive coil	Whole body SAR ≤ 0.1 W/kg	2, 3, 4, 8
		<ul> <li>All except hip and shoulder</li> </ul>	Detachable Extremity transmit- receive coil (Circularly Polarized only)	Normal operating mode	1, 2, 3, 4, 5, 6

- 1. NOTE: The SAR requirements will be met if the scanner is in normal operating mode.
- 2. NOTE: To allow the MRI scanner to estimate the SAR, ensure that you enter the patient's body weight accurately into the scanner.
- 3. WARNING: Do not conduct MRI scans in first-level controlled or second-level controlled operating mode. These modes allow higher levels of RF energy and may cause excessive heating of implanted components, which could result in serious patient injury.
- 4. WARNING: Before an MRI scan, determine the patient's body temperature. If the patient has a fever, you should not perform an MRI scan.
- 5. WARNING: Only Circularly Polarized, birdcage designs of Detachable Head and Extremity RF transmit-receive coils have been tested. Do not use other transmit coil designs (e.g., linear, phased-array, or saddle) because these have not been tested and could result in serious patient injury.
- 6. WARNING: Scans of the hips and shoulders have not been tested using Detachable Extremity RF transmit-receive coils. For hip and shoulder scans, use an Integrated Whole body RF transmit coil (Circularly Polarized only) with any receive coil according to RF power requirements listed above.
- 7. WARNING: To avoid excessive heating that could cause serious patient injury, do not place any part of the Detachable Head RF transmit-receive coil over any implanted neurostimulation system component.
- 8. WARNING: Personnel knowledgeable in MR safety should be involved to optimally plan the scan and actively monitor specific absorption rate (SAR) levels during the scan. Ensure the scanner displays SAR prospectively. Exceeding these SAR limits could increase the risk of excessive heating of implanted components.

<sup>\*\*</sup>The anchors associated with these models are MR Conditional components. Multiple MR conditional leads and anchors may be implanted.

### Proclaim™ DRG IPG with MN10450-50 or MN10450-50A Lead

Table 8.

Implant Locations for Proclaim DRG IPG with MN10450-50 or MN10450-50A Lead		
IPG* Lead** Approved Implant Locations		Approved Implant Locations
3664 Proclaim DRG	MN10450-50, 50 cm	IPG in upper buttock, low back, flank, or abdomen
	MN10450-50A, 50 cm	<ul> <li>Lead tip in the epidural space between the T10 and S2 vertebrae</li> </ul>

<sup>\*</sup>The IPG port plug associated with these models is an MR Conditional component.

Table 9.

IPG Model	Lead Model	Scan Region	RF Coil	RF Power	Notes and Warnings
Proclaim DRG 3664	MN10450-50 -or- MN10450-50A	Head scans	Detachable Head transmit-receive coil (Circularly Polarized only)	Normal operating mode	1, 2, 3, 4, 6, 7, 8
٨	Extremity scans Detachable Extremity transmit-	Detachable Extremity transmit-	Normal operating	1, 2, 3, 4, 5, 6, 8	
<u> </u>		<ul> <li>All except hip and shoulder</li> </ul>	receive coil (Circularly Polarized only)	mode	
Caution:					
Confirm the					
lead and IPG locations are					
approved per					
Table 8 above.					

- 1. NOTE: The SAR requirements will be met if the scanner is in normal operating mode.
- 2. NOTE: To allow the MRI scanner to estimate the SAR, ensure that you enter the patient's body weight accurately into the scanner.
- 3. WARNING: Do not conduct MRI scans in first-level controlled or second-level controlled operating mode. These modes allow higher levels of RF energy and may cause excessive heating of implanted components, which could result in serious patient injury.
- 4. WARNING: Only Circularly Polarized, birdcage designs of Detachable Head and Extremity RF transmit-receive coils have been tested. Do not use other transmit coil designs (e.g., linear, phased-array, or saddle) because these have not been tested and could result in serious patient injury.
- 5. WARNING: Scans of the hips and shoulders have not been tested using Detachable Extremity RF transmit-receive coils.
- 6. WARNING: Before an MRI scan, determine the patient's body temperature. If the patient has a fever, you should not perform an MRI scan.
- 7. WARNING: To avoid excessive heating that could cause serious patient injury, do not place any part of the Detachable Head RF transmit-receive coil over any implanted neurostimulation system component.
- 8. WARNING: To avoid excessive heating that could cause serious patient injury, do not use the Integrated Whole body RF transmit coil.

<sup>\*\*</sup>The anchors associated with these models are MR Conditional components. Multiple MR conditional leads and anchors may be implanted.

NOTE: Extensions are untested and are therefore considered MR Unsafe.

### Protégé™ MRI or Prodigy™ MRI IPG with Octrode™ or Penta™ Lead

Table 10.

Implant Locations for Protégé MRI or Prodigy MRI IPG with Octrode or Penta Lead		
IPG* Lead** Approved Implant Locations		Approved Implant Locations
3771 Protégé MRI	3186 Octrode, 60 cm	IPG in upper buttock, low back, flank, abdomen, or midline
3772 Prodigy MRI	3228 Penta, 60 cm	<ul> <li>Lead tip in the epidural space between the T7 and T12 vertebrae</li> </ul>

<sup>\*</sup>The IPG port plug associated with these models is an MR Conditional component.

Table 11.

IPG Model	Lead Model	Scan Region	RF Coil	RF Power	Notes and Warnings
Protégé MRI 3771 -or- Prodigy MRI 3772	Octrode 3186 -or- Penta 3228	Head scans	Detachable Head transmit-receive coil (Circularly Polarized only)	Normal operating mode	1, 2, 3, 4, 6, 7
$\triangle$		Extremity scans  • All except hip and shoulder	Detachable Extremity transmit- receive coil (Circularly Polarized only)	Normal operating mode	1, 2, 3, 4, 5, 7
Caution: Confirm the lead and IPG locations are approved per Table 10 above.					

- ${\bf 1.} \qquad {\bf NOTE: The \ SAR \ requirements \ will \ be \ met \ if \ the \ scanner \ is \ in \ normal \ operating \ mode.}$
- 2. NOTE: To allow the MRI scanner to estimate the SAR, ensure that you enter the patient's body weight accurately into the scanner.
- 3. WARNING: Do not conduct MRI scans in first-level controlled or second-level controlled operating mode. These modes allow higher levels of RF energy and may cause excessive heating of implanted components, which could result in serious patient injury.
- 4. WARNING: Only Circularly Polarized, birdcage designs of Detachable Head and Extremity RF transmit-receive coils have been tested. Do not use other transmit coil designs (e.g., linear, phased-array, or saddle) because these have not been tested and could result in serious patient injury.
- 5. WARNING: Scans of the hips and shoulders have not been tested using Detachable Extremity RF transmit-receive coils.
- 6. WARNING: To avoid excessive heating that could cause serious patient injury, do not place any part of the Detachable Head RF transmit-receive coil over any implanted neurostimulation system component.
- 7. WARNING: To avoid excessive heating that could cause serious patient injury, do not use the Integrated Whole body RF transmit coil.

<sup>\*\*</sup>The anchors associated with these models are MR Conditional components. Multiple MR conditional leads and anchors may be implanted.

NOTE: Extensions are untested and are therefore considered MR Unsafe.

## **Performing the Scan and Monitoring the Patient**

Before performing the scan, ensure that you have consulted the general and specific requirements for IPG and lead configurations.

While performing the scan, follow these guidelines:

- Leave any external control devices, such as a programmer or charger, out of the scanner magnet room (Zone IV).
- For head or extremity scans using the Detachable Head or Extremity RF transmit-receive coil, ensure that the transmit-receive coil does not cover any part of the implanted MR Conditional system (not applicable to IPG Model 3660 or 3662 with lead Model 3186).
- For scans using the Whole body RF transmit coil, involve personnel knowledgeable in MR safety to actively monitor the SAR levels during the scan (not applicable to IPG Model 3660 or 3662 with lead Model 3186).
- Keep the duration of the total active scanning time to 30 minutes or less per session. Wait at least 30 minutes between scanning sessions.
- Instruct the patient to notify MR personnel immediately if any discomfort, pain, heating, stimulation, or vibration is experienced.
- During the MRI scan, visually and audibly monitor the patient, including verbal communication.
- When selecting the field of view and imaging parameters, consider that image distortion may occur around an implanted lead or IPG. Also, consider these factors when interpreting the MRI images.

### **Disabling MRI Mode**

After you have finished scanning the patient and the patient is outside of the MRI environment, you can disable the MRI mode.

- To disable MRI mode using a patient controller, refer to the instructions in the following section, "Using the Patient Controller to Disable MRI Mode" (page 18).
- To disable MRI mode using a patient programmer, refer to the instructions in the following section, "Using the Patient Programmer to Disable MRI Mode" (page 19).

NOTE: To identify which handheld device you are using, see the figure in "Step 3: Ensure the Neurostimulation System Is in MRI Mode" (page 6).

NOTE: If the patient did not bring the patient controller the day of the MRI procedure, a clinician programmer that has been paired with the IPG can also be used. After connecting to the IPG using the clinician programmer, an authorized representative can disable MRI mode by following steps similar to those for the patient controller.

### Using the Patient Controller to Disable MRI Mode

To disable MRI mode using a patient controller, follow these steps:

- 1. Turn on the patient controller.
- 2. On the Home screen, tap the patient controller app icon to launch the app. The patient controller app automatically connects to the IPG. While the app starts up, you will see the Start-up screen.
- 3. After the app connects with the IPG, you should see a screen indicating that the IPG is in MRI mode.
- 4. Tap **Exit MRI Mode**. The patient controller app disables MRI mode, and a screen similar to the following Therapy screen appears, showing that stimulation therapy is off.

Figure 23. Therapy screen showing stimulation off




5. To start stimulation, tap Therapy is OFF.

### Using the Patient Programmer to Disable MRI Mode

After you have finished scanning the patient, you can use the patient's programmer to disable the MRI mode. To disable the MRI mode, follow these steps:

1. Establish communication with the patient's IPG. See the steps in "Setting the IPG to MRI Mode Using a Patient Programmer" (page 10). You should see the following screen indicating that the IPG is in MRI mode.

Figure 24. MRI mode screen




2. Press the Select key. The following screen appears.

Figure 25. Exit MRI mode screen



3. Press the Select key. The programmer disables MRI mode, and a screen appears similar to the following Operational Display screen showing that stimulation is off.

Figure 26. Operational Display screen showing stimulation off



 ${\bf 4.} \qquad {\bf To \ start \ stimulation, \ press \ the \ Amplitude \ Increase \ key \ on \ the \ top \ of \ the \ programmer.}$ 

Figure 27. Operational Display screen showing stimulation on



## **Troubleshooting**

This section provides information about troubleshooting issues you may encounter with the patient's handheld device.

- To troubleshoot issues with a patient controller, refer to the instructions in the following section.
- To troubleshoot issues with a patient programmer, refer to the instructions in "Troubleshooting Using a Patient Programmer" (page 21).

  NOTE: To identify which handheld device you are using, see the figure in "Step 3: Ensure the Neurostimulation System Is in MRI Mode" (page 6).

### **Troubleshooting Using a Patient Controller**

The following tables show issues you may encounter using the patient controller. The first table identifies possible issues that you may encounter on the System screen while trying to access the MRI Mode screen. The second table shows patient controller messages or screens that you may see while setting MRI mode before a scan. Follow the guidelines to help troubleshoot the issue.

NOTE: If you experience a situation other than one listed in the following table, contact the patient's physician or Technical Support. See "Technical Support" (page 21).

NOTE: The clinician programmer displays messages similar to the patient controller. If an authorized representative is using the clinician programmer to help confirm or enable MRI mode, the information in the following tables provides possible solutions to these issues.

Table 12. Possible causes and solutions for potential issues with accessing the MRI Mode screen from the Mode screen

Problem	Possible Cause	Solution
MRI is Not Permitted is displayed instead of the MRI Mode option on the Mode screen.	Patient has a system component that is not MR Conditional.	Do not perform the MRI scan. Check the patient's identification card to identify implanted models.
Cannot access the <b>Mode</b> screen.	The IPG is not connected to the patient controller.	Try connecting to the IPG again.

Table 13. Troubleshooting messages for MRI mode using a patient controller

Message	Solution			
Turn On Bluetooth to Access Generator	Turn on Bluetooth® wireless technology on the patient controller if communication is disabled.			
	1. Return to the patient controller Home screen and tap <b>Settings</b> .			
	2. Tap <b>Bluetooth</b> , then tap the Bluetooth wireless technology toggle button.			
System Problem	Try the action again. If you continue to encounter this problem, conta Technical Support.			
The system encountered a problem. Contact Abbott if this problem persists.				
Generator Unavailable	Make sure the generator is in range and has enough battery power; the			
Make sure the generator is in range and has enough battery power.	try connecting to the IPG again.			
Generator Not Connected	The connection has timed out. Reconnect to the IPG.			
Connect to the generator to adjust your therapy.				
Connection Problem with the Generator	Try connecting to the IPG again. If you continue to encounter this problem, contact Technical Support.			
Connection Lost	Try connecting to the IPG again.			
A magnet was used to place the generator in the Bluetooth pairing mode.	If you continue to encounter this problem, contact Technical Support.			
Connection Not Ready	Try connecting to the IPG again. If you continue to encounter this			
This device was not ready to find the generator.	problem, contact Technical Support.			
MRI is Not Advised	Do not perform the MRI scan. The IPG is not in MRI mode.			
There may be a problem with the implanted lead(s).				
MRI is Not Advised	Do not perform the MRI scan. The IPG is not in MRI mode.			
The generator battery voltage is too low.				

## **Troubleshooting Using a Patient Programmer**

The following table shows patient programmer screens that you may see while setting MRI mode before a scan. If you see any of these screens, follow the guidelines to help troubleshoot the issue.

NOTE: If you experience a situation other than one listed in the following table, contact the patient's physician or Technical Support. See "Technical Support" (page 21).

Table 14. Troubleshooting screens for MRI mode

Screen	Description	Guideline		
A CONNECT WAND  ⊕> ⊖ +- ⊚  ✓ CONTINUE	The communication wand is not properly connected to the programmer.	Disconnect the communication wand from the programmer and reinsert it fully. Then press the Select key.		
△IPG not found AdJust wand #5000 ✔Retry	The programmer did not locate the IPG when trying to establish communication with it.	Reposition the communication wand over the IPG site and press the Select key to try to establish communication with the IPG again.		
A WARNING A IPG COMM ERROR #8000 ✔Retry	The programmer encountered a problem communicating with the IPG (when entering or exiting MRI mode).	Ensure the communication wand is positioned over the IPG site and press the Select key to try to communicate with the IPG again.		
Δ WARNING Δ IPG battery is	The battery capacity of the IPG is too low.	Press the Previous Screen key on the programmer.		
too low for MRI Cancel		• Instruct the patient to fully recharge the IPG battery.		
⚠ WARNING ⚠ MRI NOT advised!	The check of the lead impedance failed, likely because	Check the patient's identification card.		
See manual-ID:P1 ✔MRI →Cancel	no lead is inserted in port 1 of the IPG header.	<ul> <li>If the patient only has one MR Conditional lead implanted, then consider pressing the Select key to proceed to MRI mode.</li> </ul>		
		<ul> <li>If the patient has two leads, do not perform the MRI scan. Press the Previous Screen key on the programmer and contact Technical Support.</li> </ul>		
Δ WARNING Δ MRI NOT advised	The check of the lead impedance failed, likely because no lead is inserted in port 2 of the IPG header.	Check the patient's identification card.		
See manual-ID:P2 ✔MRI ⊅Cancel		<ul> <li>If the patient only has one MR Conditional lead implanted, then consider pressing the Select key to proceed to MRI mode.</li> </ul>		
		<ul> <li>If the patient has two leads, do not perform the MRI scan. Press the Previous Screen key on the programmer and contact Technical Support.</li> </ul>		
A WARNING A MRI NOT advised! See manual-ID:AX Cancel	The check of the lead impedance failed, likely because one or both ports of the IPG header contain a 4-electrode lead, which is not MR Conditional. (The actual screen shows a number in place of the "X," ranging from 1 to 5.)	Do not perform the MRI scan.		
Δ WARNING Δ MRT NOT advised!	The check of the lead impedance failed for another reason unrelated to the lead configuration.	Do not perform the MRI scan.		
MRI NOT advised! See manual-ID:CF DCancel		Contact Technical Support.		
A WARNING A MRI NOT advised! See manual-ID:IC \$\forall \text{Cancel}\$	The check of the lead impedance did not complete.	Press the Previous Screen key on the programmer and try entering MRI mode again.		
Δ WARNING Δ MRI NOT advised!	The system check failed because of a problem with the	Do not perform the MRI scan.		
See manual-ID:VL  Cancel	G.	Contact Technical Support.		

# **Technical Support**

For technical questions and support for your product, use the following information:

- +1 855 478 5833 (toll-free within North America)
- +1 651 756 5833

For additional assistance, call your local Abbott Medical representative.

## Appendix A: Patient Eligibility Form for an MRI Scan

Patient name

Physician name and contact

Is only one IPG implanted?

Is the IPG set to MRI mode?

Complete this form to help you determine the eligibility of a patient with an implanted neurostimulation system for an MRI scan. If the answers to all of the following questions are "Yes," consult the MRI procedures manual for complete information on conducting an MRI scan. If the answer to any of the questions is "No," do not perform the scan. If "Unsure," contact the patient's physician or Technical Support for help

WARNING: Scanning patients who have other MR Conditional devices is acceptable as long as all the MR Conditional requirements for each of the implanted devices are met. Do not conduct an MRI scan if any conditions or implants prohibit it. If you are unclear what implants are present, perform an X-ray to determine the implant type and location.

NOTE: Before conducting an MRI scan, always ensure that you are using the most recent version of the MRI procedures manual. Contact Technical Support or get the most recent version online at **medical.abbott/manuals**. For more information about MR Conditional products, visit the Abbott Medical product information page at neuromodulation.abbott/MRI-ready.

	dress, phone number)					
Da	te of eligibility assessment					
IPG	IPG model IPG location					
Lea	Lead model or models Lead location or locations					
Elig	gibility Factors for an MRI Scar	n		Yes	No	Unsure
1.	Does the patient have IPG an models.)	nd lead models that are MR Condition	nal? (See the patient's ID card for IPG and lead			
2.	. Are the MR Conditional components the only neurostimulation components implanted?					
3. Does the location of the implanted components (including lead tips) meet the approved conditions of use? See						

"Step 1: Confirm the MR Conditional Components and Location of the System" (page 3).

Does the intended scan region meet the conditions of use for the RF coil that will be used? See "Step 5: Confirm

Did you confirm the patient does not have a fever? (only applicable to IPG Models 3660, 3662, and 3664)

Is the patient free of broken or abandoned neurostimulation devices?

Implant Locations and Scan Requirements for the Patient's System" (page 13).

Abbott Medical 6901 Preston Road Plano, Texas 75024 USA +1 855 478 5833 +1 651 756 5833 Abbott Medical The Corporate Village Da Vincilaan 11 Box F1 1935 Zaventem Belgium +32 2 774 68 11

2021-11 ARTEN600190677 A



