

SPARCstation MAC address 08:00:20:HOSTID

MAC address = 08:00:20:10:7e:3a

press stop + a

ok set-defaults \To reset all settings in defaults

ok 01 00 mkp \ Byte 0: Format/version number

ok 80 01 mkp \ Byte 1: Machine type (IPX = 0x80)

ok 08 02 mkp \ Byte 2: MAC address

ok 00 03 mkp

ok 20 04 mkp

ok 10 05 mkp

ok 7e 06 mkp

ok 3a 07 mkp \ Byte 7

ok 00 08 mkp \ Bytes 8-b: date of manufacture (usually zeroed)

ok 00 09 mkp

ok 00 0a mkp

ok 00 0b mkp

ok 10 0c mkp \ Byte c: 2nd byte of hostid

ok 7e 0d mkp \ Byte d: 3rd byte of hostid

ok 3a 0e mkp \ Byte e: 4th byte of hostid

ok 0 f 0 do i idprom@ xor loop f mkp \ Byte f: checksum (XOR of bytes 0 through e)

reset