

Setup Zebra Printer ZT410-203dpi ZPL

- 1) Make sure the sticker in the correct position



- 2) Do the calibration to make sure accurate label printing, proper media feeding and consistent output




3) Find the IP address the Zebra Printer



4) Setting the Print Method as Direct Thermal



5) Add the Zebra Printer Driver in the PC



6) Add the printer as network

Printer Installation Wizard

Select Port
Select port to which the printer is attached.



→ Network Port
Ethernet (LAN) or Wireless (WiFi) installation.

→ USB Port
Installation of USB Plug and play device.

→ Bluetooth Port
Installation of Bluetooth device.

→ Other
Installation on Serial (COM) or Parallel (LPT) ports.

Exit < Previous Next >

Printer Installation Wizard

Detect Network Printer
Please select the printer found on the local network.



The listed printers were found on the network. Please select the desired printer and press the Add button. Press Manual button if your printer is not listed.

ZT410-203dpi ZPL

ZDesigner Windows Printer Driver Version 10.6.26.28275 - In...

Select Destination



Setup will install files into the folder displayed below.

c:\ZD10-6-26-28275 Browse...

Install Folder

Required Disk Space:	84,479 KB
Remaining Disk Space:	882,552 MB

< Back Next > Cancel

Printer Installation Wizard

Summary

Operation completed. Please read the summary below.



Installed printers:

- ZDesigner ZT410-203dpi ZPL - **succeeded**
 - Version: 10.6.26.28275
 - Port: LAN_ZDesigner_ZT410-203dpi_ZPL


Added ports:

- LAN_ZDesigner_ZT410-203dpi_ZPL - **succeeded**


[Open printing preferences](#)

[Install another printer](#)

[Exit](#)



7) Edit the printer preferences based on size sticker label



8) Printer able to print in the correct size sticker

