

RYLR999

RYLR999_OTA_Update_Firmware



1. Download and install the burning tool:

[1]Simplicity Connect App iOS®:

<https://apps.apple.com/tw/app/simplicity-connect/id1030932759>

[2] Simplicity Connect App Android®:

https://play.google.com/store/apps/details?id=com.siliconlabs.bledemo&hl=zh_TW


[3]Firmware update file from <https://reyax.com//products/RYLR999>

[4]UART/RS-232 COMFORT software :

https://reyax.com/products/COMFORT_Software

2. Hardware connection

Connect RYLR999 to the computer via the RYLS135 USB to UART bridge tool.




3.Appicaiton software operation


1.Execute COMFORT and follow the steps below to complete the setup.

[i]Set com port and Baud rate 115200.

[ii]Enter “AT+VER?” and click “Connect”.





[iii]After pressing Button '1', a message window will display the current firmware version.





2. Execute the Simplicity Connect App on your mobile phone.



[i] then search for the device “REYAX_BLE_RYL999” and click “Connect”





[ii] Click “OTA Firmware”.



[iii] Then click “Choose file” to navigate to the firmware update file location. And click “Upload”.




[iv] During the update, the screen will display as shown below. Please do not close the app until the update is complete.




[v] after the update is complete, the following screen will be displayed. Click “Done” and the module will automatically reset."


iOS®



Android®



[vi] You can return to COMFORT to check the firmware version.



REYAX
TECHNOLOGY CORPORATION, LTD

E-mail : sales@reyax.com
Website : <http://reyax.com>