Update instruction

To update the software for the T-Bone, please do the following steps

- 1. Download the Arduino IDE (http://arduino.cc/en/Main/Software)
- 2. Download the latest T-Bone Software (https://github.com/trinamic/T-Bone/tree/master/Software/ArduinoClient)
- 3. Download all libraries (https://github.com/trinamic/T-Bone/tree/master/Software/ArduinoLibraries)
- 4. Copy libraries to: C:\Users\Username\Documents\Arduino\libraries
 - a. If folder does not exist, create it
- 5. Open Arduino IDE
- 6. Open "ArduinoClient.ino"
- 7. Power up T-Bone
- 8. Connect T-Bone via USB to computer
- 9. Select the right Serial Port
- 10. Upload the Code
- 11. Done

To update the Beagle Bone Black software, please do these steps:

- 1. Connect Beagle Bone Black (BBB) with power
- 2. Connect BBB with Internet
- 3. Connect to BBB via SSH, e.g. with putty (http://www.putty.org/)
- 4. Username: root Password: none (just hit ENTER)
- 5. Go to directory "/home/root/trinamic3d/"
- 6. Type in: "git pull"
- 7. Wait until download complete
- 8. Done