

# **Real Mode**

**Real Mode** is a simplistic 16-bit mode that is present on all x86 processors. Real Mode was the first x86 mode design and was used by many early operating systems before the birth of <u>Protected</u> Mode. For compatibility purposes, all x86 processors begin execution in Real Mode.

## **Contents**

### Information

Cons

Pros

**Common Misconception** 

### **Memory Addressing**

The Stack

High Memory Area

Addressing Modes

### **Switching from Protected Mode to Real Mode**

### x86 Assembly Example

See Also

**Articles** 

**External Links** 

References

## Information

All modern operating systems (Windows, Linux, ...) run in <u>Protected Mode</u>, due to the many limitations and problems that Real Mode presents (see below, and the <u>Real Mode OS Warning page</u>). Older operating systems (such as DOS) and programs ran in Real Mode because it was the only mode available at the time. For information on how to switch from Real Mode to <u>Protected Mode</u>, see the corresponding article.

Note: There is a mode called <u>Virtual 8086 Mode</u> which allows operating systems running in Protected mode to emulate the <u>Real Mode segmented model</u> for individual applications. This can be used to allow a <u>Protected Mode</u> operating system to still have access to e.g. BIOS functions, whenever needed.

Below you'll find a list of cons and pros. These are mostly 'in comparison to Protected Mode'.

#### Cons

- Less than 1 MB of RAM is available for use.
- There is no hardware-based memory protection (GDT), nor virtual memory.

- There are no built in security mechanisms to protect against buggy or malicious applications.
- The default CPU operand length is only 16 bits.
- The memory addressing modes provided are more restrictive than other CPU modes.
- Accessing more than 64k requires the use of segment registers that are difficult to work with.

### **Pros**

- The BIOS installs device drivers to control devices and handle interrupts.
- BIOS functions provide operating systems with an advanced collection of low level API functions.
- Memory access is faster due to the lack of descriptor tables to check combined with smaller registers.

### **Common Misconception**

Programmers often think that since Real Mode defaults to 16 bits, that the 32 bit registers are not accessible. This is not true.

All of the 32-bit registers (EAX, ...) are still usable, by simply adding the "Operand Size Override Prefix" (0x66) to the beginning of any instruction. Your assembler is likely to do this for you, if you simply try to use a 32-bit register.

## **Memory Addressing**

In Real Mode, there is a little over 1 MB of "addressable" memory (including the <u>High Memory Area</u>). See <u>Detecting Memory (x86)</u> and <u>Memory Map (x86)</u> to determine how much is actually **usable**. The usable amount will be much less than 1 MB. Memory access is done using Segmentation via a segment:offset system.

There are six 16-bit segment registers: CS, DS, ES, FS, GS, and SS. When using segment registers, addresses are given with the following notation (where 'Segment' is a value in a segment register and 'Offset' is a value in an address register):

```
12F3 : 4B27
^ ^
Segment Offset
```

Segments and Offsets are related to physical addresses by the equation:

```
PhysicalAddress = Segment * 16 + Offset
```

Thus, 12F3:4B27 corresponds to the physical address 0x17A57. Any physical address can be represented in multiple ways, with different segments and offsets. For example, physical address 0x210 can be 0020:0010, 0000:0210, or 0021:0000.

#### The Stack

SS and SP are 16-bit segment:offset registers that specify a 20-bit physical address (described above), which is the current "top" of the stack. The stack stores 16-bit words and grows downwards. It is used every time a program does a PUSH, POP, CALL, INT, or RET opcode and

also when the BIOS handles any hardware interrupt.

### **High Memory Area**

If you set DS (or any segment register) to a value of oxFFFF, it points to an address that is 16 bytes below 1 MB. If you then use that segment register as a base, with an offset of 0x10 to 0xFFFF, you can access physical memory addresses from 0x100000 to 0x10FFEF. This (almost 64 kB) area above 1 MB is called the "High Memory Area" in Real Mode. Note that you have to have the A20 address line activated for this to work.

### **Addressing Modes**

Real Mode uses 16-bit addressing mode by default. Assembly programmers are typically familiar with the more common 32-bit addressing modes, and may want to make adjustments -- because the registers that are available in 16-bit addressing mode for use as "pointers" are much more limited. The typical programs that run in Real Mode are often limited in the number of bytes available, and it takes one extra byte in each opcode to use 32-bit addressing instead.

Note that you can still use 32-bit addressing modes in Real Mode, simply by adding the "Address Size Override Prefix" (0x67) to the beginning of any instruction. Your assembler is likely to do this for you, if you simply try to use a 32-bit addressing mode. But you are still constrained by the current "limit" for the segment that you use in each memory access (always 64K in Real Mode -- Unreal Mode can be bigger).

- [BX + val]
- [SI + val]
- [DI + val]
- [BP + val]
- [BX + SI + val]
- [BX + DI + val]
- [BP + SI + val]
- [BP + DI + val]
- [address]

## Switching from Protected Mode to Real Mode

As noted above, it is possible for a Protected mode operating system to use <u>Virtual 8086 Mode</u> mode to access BIOS functions. However, VM86 mode has its own complications and difficulties. Some OS designers think that it is simpler and cleaner to temporarily return to Real Mode on those occasions when it is necessary to access a BIOS function. This requires creating a special Ring o program, and placing it in a physical memory address that can be accessed in Real Mode.

The OS usually needs to pass an information packet about which BIOS function to execute.

The program needs to go through the following steps:

- 1. Disable the interrupts:
  - Turn off maskable interrupts using CLI.
  - Disable NMI (optional).
- 2. Turn off paging:

- Transfer control to a 1:1 page.
- Ensure that the GDT and IDT are in a 1:1 page.
- Clear the PG-flag in the zeroth control register.
- Set the third control register to 0.
- 3. Use GDT with 16-bit tables (skip this step if one is already available):
  - Create a new GDT with a 16-bit data and code segment:
    - Limit: 0xFFFFF
    - Base: 0x0
    - 16-bit
    - Privilege level: 0
    - Granularity: 0
    - Read and Write: 1
  - Load new GDT ensuring that the currently used selectors will remain the same (index in cs/ds/ss will be copy of original segment in new GDT)
- 4. Far jump to 16-bit protected mode:
  - Far jump to 16-bit protected mode with a 16-bit segment index.
- 5. Load data segment selectors with 16-bit indexes:
  - Load ds, es, fs, gs, ss with a 16-bit data segment.
- 6. Load real mode IDT:
  - Limit: 0x3FF
  - Base 0x0
  - Use lidt
- 7. Disable protected mode:
  - Set PE bit in CR0 to false.
- 8. Far jump to real mode:
  - Far jump to real mode with real mode segment selector (usually 0).
- 9. Reload data segment registers with real mode values:
  - Load ds, es, fs, gs, ss with appropriate real mode values (usually 0).
- 10. Set stack pointer to appropriate value:
  - Set sp to stack value that will not interfere with real mode program.
- 11. Enable interrupts:
  - Enable maskable interrupts with STI.
- 12. Continue on in real mode with all bios interrupts.

## **x86 Assembly Example**

```
; We are already in 16-bit mode here!
             ; Disable interrupts.
   ; Need 16-bit Protected Mode GDT entries!
   mov eax, DATASEL16 ; 16-bit Protected Mode data selector.
   mov ds, eax
   mov es, eax
   mov fs, eax
   mov gs, eax
   mov ss, eax
   ; Disable paging (we need everything to be 1:1 mapped).
   mov [savcr0], eax ; save pmode CR0
   and eax, 0x7FFFFFFe; Disable paging bit & disable 16-bit pmode.
   mov cr0, eax
   jmp 0:GoRMode
                   ; Perform Far jump to set CS.
GoRMode:
   mov sp, 0x8000
                   ; pick a stack pointer.
               ; Reset segment registers to 0.
   mov ax, 0
   mov ds, ax
   mov es, ax
   mov fs, ax
   mov gs, ax
   mov ss, ax
   lidt [idt_real]
             ; Restore interrupts -- be careful, unhandled int's will kill it.
  ______
```

### See Also

#### **Articles**

- BIOS
- System Initialization (x86)
- Protected Mode

### **External Links**

- The Workings of: x86-16/32 Real Mode Addressing (https://web.archive.org/web/20130609073 242/http://www.osdever.net/tutorials/rm\_addressing.php?the\_id=50) (2003)
- The workings of IA32 real mode addressing and the A20 line (http://therx.sourceforge.net/osde v/files/ia32 rm addr.pdf) (2004)

#### References

- Intel® 64 and IA-32 Architectures Software Developer's Manual (http://www.intel.com/products/processor/manuals/) (2011)
  - Volume 3A: System Programming Guide, Part 1, Chapter 20:8086 EMULATION, which is a
    detailed reference about real mode using 32-bit addressing mode

Retrieved from "https://osdev.wiki/wiki/Real\_Mode"