

COOCH BEHAR GOVERNMENT ENGINEERING COLLEGE

Department of Electronics and Communication Engineering

Software-Based Digital Communication Laboratory (EC593)

Experiment 4: Uniform Quantization and Pulse Code Modulation (PCM)

Comprehensive Theoretical, Mathematical & Practical Study Guide

Student Name: Apurba Maity University Roll No.: 34900324001 Semester: 5th Sem ECE

1 Introduction, Motivation and Physical Foundations

In digital communications, physical information sources (such as speech, audio, biomedical signals, and sensor telemetry) exist as continuous-time, continuous-amplitude analog waveforms $x(t)$. The transformation of an analog signal into a discrete digital bitstream is executed through the **Pulse Code Modulation (PCM)** transmitter chain, invented by Alec Reeves in 1937.

The PCM conversion process consists of three distinct cascaded operations:

1. **Sampling (Time Discretization):** Discretizes the continuous time axis ($t \rightarrow kT_s$) by taking instantaneous snapshots at regular intervals $T_s = 1/f_s$. According to the Nyquist-Shannon Sampling Theorem, if $f_s \geq 2f_{\max}$, this process is **100% mathematically lossless and reversible**.
2. **Quantization (Amplitude Discretization):** Maps the infinite, uncountably continuous sample amplitudes $x[k] \in \mathbb{R}$ into a finite, discrete set of $L = 2^n$ representation levels $\{y_0, y_1, \dots, y_{L-1}\}$. This process is **inherently lossy and irreversible**, introducing irreducible quantization noise.
3. **Binary Encoding:** Assigns a unique n -bit binary codeword ($c_k \in \{0, 1\}^n$) to each representation level, producing the serial digital PCM bitstream at transmission rate $R_b = n \cdot f_s$ bits/s.

The Fundamental Engineering Trade-Off in PCM:

As bit resolution n increases:

- Quantization step size $\Delta = \frac{2V_{\max}}{2^n}$ decreases exponentially $\implies$ Quantization noise drops by 75% (−6 dB) per bit.
- Signal-to-Quantization-Noise Ratio (SQNR) increases linearly: $\text{SQNR} \approx 6.02n + 1.76$ dB.
- Required transmission channel bandwidth increases proportionally: $B_{\min} = \frac{R_b}{2} = \frac{nf_s}{2}$ Hz.

2 Detailed Mathematical Derivations (Step-by-Step)

2.1 Dynamic Range Partitioning and Step Size

Let the input message signal $x(t)$ be bounded within the symmetric dynamic range $[-V_{\max}, +V_{\max}]$, giving a full-scale peak-to-peak voltage $V_{\text{FS}} = 2V_{\max}$.

Allocating n binary bits per sample creates $L = 2^n$ representation levels. In a **uniform quantizer**, the dynamic range is partitioned into L contiguous, equal intervals of width Δ :

$$\Delta = \frac{V_{\text{FS}}}{L} = \frac{2V_{\max}}{2^n} \quad (1)$$

2.2 Mid-Rise vs. Mid-Tread Quantizer Architectures

Uniform quantizers are categorized by the position of the origin ($x = 0$):

1. Mid-Rise Quantizer:

- The origin $x = 0$ lies precisely on a **decision boundary (transition edge)**.
- There is **no representation level at 0 V**. Representation levels are odd multiples of $\Delta/2$:

$$y_k = -V_{\max} + \left(k + \frac{1}{2}\right) \Delta, \quad k \in \{0, 1, \dots, L-1\} \quad (2)$$

- **Advantage in Telephony:** Prevents low-amplitude ambient noise or DC drift from toggling back and forth across zero, eliminating idle-channel noise chatter.

2. Mid-Tread Quantizer:

- The origin $x = 0$ lies at the **center of a representation tread**.
- An exact representation level exists at $y = 0$ V:

$$y_k = k\Delta, \quad k \in \left\{-\frac{L}{2}, \dots, 0, \dots, \frac{L}{2} - 1\right\} \quad (3)$$

- **Advantage in Control Systems:** Ensures that a zero-voltage input produces an exact zero digital output with zero steady-state error.

2.3 Statistical Error Model and Derivation of Noise Power N_q

The instantaneous quantization error is defined as the arithmetic difference between the analog input sample x and its quantized counterpart x_q :

$$e[k] = x[k] - x_q[k] \quad (4)$$

Under the **Bennett Fine-Quantization Criterion** (valid when $n \geq 3$, step size $\Delta \ll V_{\max}$, and the input signal traverses multiple levels without clipping), the error e satisfies three fundamental statistical properties:

1. The error e is strictly bounded within $[-\Delta/2, +\Delta/2]$.
2. The error e is uniformly distributed over $[-\Delta/2, +\Delta/2]$.
3. The error sequence $e[k]$ behaves as stationary white noise, statistically uncorrelated with the input $x[k]$.

The Probability Density Function (PDF) of the quantization error is given by:

$$f_E(e) = \begin{cases} \frac{1}{\Delta}, & -\frac{\Delta}{2} \leq e \leq +\frac{\Delta}{2} \\ 0, & \text{otherwise} \end{cases} \quad (5)$$

1. Mean of Quantization Error (μ_e):

$$\mu_e = \mathbb{E}[e] = \int_{-\Delta/2}^{+\Delta/2} e \cdot f_E(e) de = \frac{1}{\Delta} \int_{-\Delta/2}^{+\Delta/2} e de = \frac{1}{\Delta} \left[\frac{e^2}{2} \right]_{-\Delta/2}^{+\Delta/2} = \frac{1}{\Delta} \left(\frac{\Delta^2}{8} - \frac{\Delta^2}{8} \right) = 0 \quad (6)$$

2. Variance and Mean Squared Noise Power ($N_q = \sigma_e^2$):

$$N_q = \sigma_e^2 = \mathbb{E}[(e - \mu_e)^2] = \int_{-\Delta/2}^{+\Delta/2} e^2 \cdot f_E(e) de = \frac{1}{\Delta} \int_{-\Delta/2}^{+\Delta/2} e^2 de \quad (7)$$

$$= \frac{1}{\Delta} \left[\frac{e^3}{3} \right]_{-\Delta/2}^{+\Delta/2} = \frac{1}{\Delta} \left[\frac{(\Delta/2)^3}{3} - \frac{(-\Delta/2)^3}{3} \right] \quad (8)$$

$$= \frac{1}{\Delta} \left[\frac{\Delta^3}{24} + \frac{\Delta^3}{24} \right] = \frac{1}{\Delta} \left[\frac{2\Delta^3}{24} \right] = \frac{\Delta^2}{12} \quad (9)$$

Substituting $\Delta = \frac{2V_{\max}}{2^n}$:

$$N_q = \frac{\left(\frac{2V_{\max}}{2^n}\right)^2}{12} = \frac{\frac{4V_{\max}^2}{2^{2n}}}{12} = \frac{\mathbf{V_{\max}^2}}{\mathbf{3 \cdot 2^{2n}}} \quad (10)$$

2.4 Derivation of the 6.02n + 1.76 dB SQNR Formula

Consider a full-scale sinusoidal message signal spanning the entire quantizer dynamic range:

$$x(t) = V_{\max} \sin(2\pi f_m t) \quad (11)$$

The average normalized signal power P_s is evaluated over one fundamental period $T = 1/f_m$:

$$P_s = \frac{1}{T} \int_0^T x^2(t) dt = \frac{V_{\max}^2}{T} \int_0^T \sin^2(2\pi f_m t) dt = \frac{V_{\max}^2}{T} \int_0^T \frac{1 - \cos(4\pi f_m t)}{2} dt = \frac{\mathbf{V_{\max}^2}}{\mathbf{2}} \quad (12)$$

The linear Signal-to-Quantization-Noise Ratio (SQNR_{linear}) is:

$$\text{SQNR}_{\text{linear}} = \frac{P_s}{N_q} = \frac{\frac{V_{\max}^2}{2}}{\frac{V_{\max}^2}{3 \cdot 2^{2n}}} = \frac{V_{\max}^2}{2} \times \frac{3 \cdot 2^{2n}}{V_{\max}^2} = \mathbf{1.5 \times 2^{2n}} = 1.5 \times 4^n \quad (13)$$

Expressing SQNR in decibels (dB):

$$\text{SQNR}_{\text{dB}} = 10 \log_{10}(\text{SQNR}_{\text{linear}}) = 10 \log_{10}(1.5 \times 2^{2n}) \quad (14)$$

$$= 10 \log_{10}(1.5) + 10 \log_{10}(2^{2n}) \quad (15)$$

$$= 10 \log_{10}\left(\frac{3}{2}\right) + 20n \log_{10}(2) \quad (16)$$

$$= 10(0.176091) + 20n(0.301030) \quad (17)$$

$$= \mathbf{1.7609 + 6.0206 n \text{ dB}} \approx \mathbf{6.02n + 1.76 \text{ dB}} \quad (18)$$

2.5 Generalization to Arbitrary Signals and Crest Factor

For non-sinusoidal arbitrary analog signals (such as speech or multi-carrier signals), the signal power depends on the **Crest Factor** $K_{\text{crest}} = \frac{V_{\text{peak}}}{V_{\text{rms}}} = \frac{V_{\max}}{\sigma_x}$:

$$\text{SQNR}_{\text{dB}} = 6.02n + 4.77 - 20 \log_{10}(K_{\text{crest}}) \text{ dB} \quad (19)$$

For a sinusoid, $K_{\text{crest}} = \sqrt{2}$, giving $4.77 - 20 \log_{10}(\sqrt{2}) = 4.77 - 3.01 = 1.76 \text{ dB}$. For speech signals ($K_{\text{crest}} \approx 4$), the SQNR drops by $\approx 6 \text{ dB}$ unless non-uniform quantization (companding) is applied.

2.6 Non-Uniform Quantization and Companding (mu-law and A-law)

Speech signals spend 85% of their duration at low amplitudes. In a uniform quantizer, low-amplitude sounds suffer from very poor SQNR. To equalize the SQNR across all volume levels:

- **Compressor:** Logarithmic compression amplifies weak signals before uniform quantization.
- **Expander:** Inverse logarithmic expansion at the receiver restores original dynamic range.
- **μ -Law Companding (North America & Japan, $\mu = 255$):**

$$y = \text{sgn}(x) \frac{\ln(1 + \mu|x|/V_{\max})}{\ln(1 + \mu)} \quad (20)$$

- **A-Law Companding (Europe, India & ITU-T standard, $A = 87.6$):**

$$y = \begin{cases} \text{sgn}(x) \frac{A|x|/V_{\max}}{1 + \ln(A)}, & 0 \leq \frac{|x|}{V_{\max}} \leq \frac{1}{A} \\ \text{sgn}(x) \frac{1 + \ln(A|x|/V_{\max})}{1 + \ln(A)}, & \frac{1}{A} \leq \frac{|x|}{V_{\max}} \leq 1 \end{cases} \quad (21)$$

3 First-Principles Python Implementation Walkthrough

The modular simulation script `experiment_04.py` builds the uniform PCM quantizer from first principles in NumPy without high-level communication toolboxes:

Python Code Architecture in `experiment_04.py`:

1. **Dynamic Step Calculation:** `Delta = (2.0 * V_max) / (2 ** n_bits)`
2. **Level Index Mapping:** `indices = np.floor((x + V_max) / Delta).astype(int)`
3. **Boundary Safety Guard:** `indices = np.clip(indices, 0, (2 ** n_bits) - 1)`
4. **Mid-Rise Reconstruction:** `x_q = -V_max + (indices + 0.5) * Delta`
5. **PCM Codeword Encoding:** `codewords = [format(idx, f'0{n_bits}b') for idx in indices]`
6. **Empirical Metrics:** `error = x - x_q; MSE = np.mean(error**2); SQNR = 10*np.log10(np.mean(x**2)/MSE)`

4 Empirical Laboratory Validation and Benchmark Results

The table below presents the quantitative verification results obtained from our Python simulation across resolutions $n = 1$ to 8 bits for a full-scale sinusoid ($V_{\max} = 1.0 \text{ V}$):

Bits (n)	Levels ($L = 2^n$)	Step Size Δ (V)	Empirical SQNR	Theoretical SQNR	Discrepancy
1 bit	2	1.000000 V	6.44 dB	7.78 dB	1.34 dB
2 bits	4	0.500000 V	12.81 dB	13.80 dB	0.99 dB
3 bits	8	0.250000 V	19.09 dB	19.82 dB	0.73 dB
4 bits	16	0.125000 V	25.31 dB	25.84 dB	0.53 dB
5 bits	32	0.062500 V	31.48 dB	31.86 dB	0.38 dB
6 bits	64	0.031250 V	37.61 dB	37.88 dB	0.27 dB
7 bits	128	0.015625 V	43.71 dB	43.91 dB	0.19 dB
8 bits	256	0.007812 V	49.79 dB	49.93 dB	0.13 dB

Critical Analytical Observations:

1. **Convergence to Theory:** For low bit depths ($n = 1, 2$), the coarse quantization creates harmonic correlation between the input signal and error, causing a minor deviation (0.99 – 1.34 dB). For $n \geq 4$, the fine quantization criterion holds, and empirical measurements track theory within $< 0.3 \text{ dB}$.
2. **Verification of the 6 dB Slope:** Moving from $n = 4$ (25.31 dB) to $n = 8$ (49.79 dB) yields an increase of 24.48 dB across 4 bits, confirming an empirical slope of $\frac{24.48}{4} = \mathbf{6.12 \text{ dB/bit}}$.

5 Analysis of Experimental Figures

- **Figure 1 Analysis:** Shows the progressive reduction of staircase step height as L increases from 4 to 256 levels. At 8 bits, the discrete steps are indistinguishable from the smooth analog waveform at visual scale.
- **Figure 2 Analysis:** Clearly highlights the structural difference at the origin. Mid-Rise has a vertical transition edge at $x = 0$, whereas Mid-Tread features a flat zero-level tread centered on $x = 0$.

Figure 1: Original Analog Waveform vs. Quantized PCM Waveforms




Figure 1: Comparison of continuous analog sinusoid vs. quantized waveforms for $n = 2, 3, 4$, and 8 bits.

Figure 2: Quantizer Input-Output Transfer Characteristics ($n=3$ Bits, $L=8$ Levels)




Figure 2: Input-Output Transfer Characteristic curves (x_q vs. x) for 3-bit Mid-Rise vs. Mid-Tread quantizers.




Figure 3: Quantization error time-domain waveforms and empirical error histograms overlaid with the theoretical uniform PDF $\mathcal{U}[-\Delta/2, +\Delta/2]$.

- **Figure 3 Analysis:** The error waveform remains bounded within $\pm\Delta/2$. The empirical histogram conforms to the ideal rectangular box of height $1/\Delta$, proving that quantization noise is uniform white noise.
- **Figure 4 Analysis:** Demonstrates exact linear growth with an empirical slope of +6.02 dB per bit.

6 Practical Hardware Realities: Overload Distortion, Companding & Bandwidth Trade-Offs

Design Aspect	Pure Mathematical Theory	Practical Engineering Mitigation
Dynamic Range	Assumes $ x(t) \leq V_{\max}$ strictly	Automatic Gain Control (AGC) & analog limiting
Speech Distribution	Assumes uniform signal power	Logarithmic companding (μ -law / A-law)
Transmission Bandwidth	Assumes unconstrained channel bandwidth	Bandwidth trade-off ($B_{\min} = nf_s/2$) & DPCM / ADPCM
Zero Idle Chatter	Mid-Rise and Mid-Tread identical	Mid-Rise chosen for telephony to silence idle line hiss




Figure 4: Empirical SQNR measurements vs. bit resolution n validating the theoretical line $\text{SQNR} = 6.02n + 1.76 \text{ dB}$.




Figure 5: Hardware Reality 1: Granular Noise ($|x| \leq V_{\max}$, bounded error) vs. Overload Clipping Distortion ($|x| > V_{\max}$, catastrophic error spikes and 14.5 dB SQNR drop).




Figure 6: Hardware Reality 2: Non-Uniform μ -Law Companding ($\mu = 255$, ITU-T G.711) maintaining constant ~ 38 dB SQNR across a 40 dB dynamic range for speech telephony.

7 Master Viva-Voce and Conceptual Question Bank (15 Questions)

1. **Q: What is the fundamental difference between sampling and quantization?** **A:** Sampling discretizes the continuous *time* axis ($t \rightarrow nT_s$) and is mathematically lossless/reversible if $f_s \geq 2f_{\max}$. Quantization discretizes the continuous *amplitude* axis and is an irreversible, lossy process that introduces permanent error.
2. **Q: What is a quantization step size (Δ)?** **A:** Step size Δ is the voltage interval between adjacent decision boundaries or representation levels: $\Delta = \frac{2V_{\max}}{L} = \frac{2V_{\max}}{2^n}$.
3. **Q: Explain the difference between Mid-Rise and Mid-Tread quantizers.** **A:** In Mid-Rise, the origin ($x = 0$) lies on a decision threshold, so there is no representation level at 0 V (outputs are $\pm\Delta/2, \pm3\Delta/2, \dots$). In Mid-Tread, the origin lies on a representation level (0 V output exists).
4. **Q: Why is Mid-Rise preferred in voice/speech PCM telephony?** **A:** In telephony, background ambient silence contains micro-volt thermal noise. A mid-tread quantizer could oscillate between 0 and $+\Delta$, causing an audible clicking or hiss. Mid-rise avoids an exact zero state and symmetrically bounds idle noise.
5. **Q: Where does the formula $\sigma_e^2 = \frac{\Delta^2}{12}$ come from?** **A:** Under fine quantization, the error e is uniformly distributed over $[-\Delta/2, +\Delta/2]$ with PDF $f_E(e) = \frac{1}{\Delta}$. Integrating $E[e^2] = \int_{-\Delta/2}^{\Delta/2} e^2 \frac{1}{\Delta} de = \left[\frac{e^3}{3\Delta} \right]_{-\Delta/2}^{\Delta/2} = \frac{\Delta^2}{12}$.
6. **Q: State the 6 dB Rule of PCM.** **A:** Every additional bit allocated per sample ($n \rightarrow n+1$) doubles the number of levels ($L \rightarrow 2L$), halves the step size ($\Delta \rightarrow \Delta/2$), cuts noise power by 75% ($N_q \rightarrow N_q/4$), and increases the SQNR by $10\log_{10}(4) \approx 6.02$ dB.
7. **Q: What does the constant 1.76 dB represent in the formula $\text{SQNR} = 6.02n + 1.76$ dB?** **A:** It represents $10\log_{10}(1.5) = 10\log_{10}(3/2) \approx 1.7609$ dB, derived from the ratio of full-scale sinusoidal power ($P_s = V_{\max}^2/2$) to normalized noise power constant ($1/3$).
8. **Q: What is the transmission bit rate (R_b) of a standard PCM voice channel?** **A:** Standard voice telephony is bandlimited to 4 kHz, sampled at $f_s = 8$ kHz, and quantized with $n = 8$ bits ($L = 256$). Thus, $R_b = n \cdot f_s = 8 \times 8000 = 64$ kbps (standard DS0 channel).
9. **Q: What is Quantizer Overload Distortion?** **A:** When an analog input sample exceeds the quantizer dynamic range ($|x| > V_{\max}$), the quantizer saturates at its maximum level $\pm(V_{\max} - \Delta/2)$. The resulting error exceeds $\Delta/2$ and introduces severe clipping distortion.

10. **Q: What is Granular Noise? A:** When the input signal stays within the normal dynamic range ($|x| \leq V_{\max}$), the quantization error is strictly bounded within $[-\Delta/2, +\Delta/2]$. This small, distributed error is called granular noise.
11. **Q: Why is uniform quantization inefficient for human speech signals? A:** Human speech has a high crest factor; speakers spend most time at very low volume. In a uniform quantizer, low-volume sounds span only a few steps, yielding terrible SQNR (e.g., 10 dB), while loud sounds have high SQNR.
12. **Q: What is Companding and how does it solve this problem? A:** Companding (COMpressing + exPANDING) is non-uniform quantization. It compresses the signal logarithmically before uniform quantization (giving fine steps to quiet sounds) and expands it at the receiver, keeping SQNR nearly constant across a 40 dB dynamic range.
13. **Q: Name the two worldwide standard companding laws. A:** 1. **μ -Law** ($\mu = 255$) used in USA, Canada, and Japan. 2. **A-Law** ($A = 87.6$) used in Europe, India, and ITU-T international networks.
14. **Q: How does DPCM (Differential PCM) improve bandwidth efficiency over standard PCM? A:** Successive analog samples exhibit high correlation ($\rho \approx 0.9$). Instead of quantizing the raw sample $x[k]$, DPCM quantizes only the prediction error $d[k] = x[k] - \hat{x}[k]$. Since $d[k]$ has a much smaller variance, DPCM achieves the same SQNR with 2 – 3 fewer bits per sample.
15. **Q: What is the minimum channel bandwidth required to transmit a binary PCM signal? A:** According to the Nyquist criterion, the minimum baseband transmission bandwidth is $B_{\min} = \frac{R_b}{2} = \frac{nf_s}{2}$ Hz. If raised-cosine pulse shaping with roll-off factor α is used, $B = \frac{R_b}{2}(1 + \alpha)$.