# Attack PICO SWAES using CW

# ChipWhisperer Setup


- CW Clock: 4Mhz
- CW ADC Sampling rate : 16Mhz
- Samples per trace : 24400
- # of traces : 40k
- Time per traces to capture : 3 sec

# **Attack Region and Time**

- Trigger = 11st round sboxTrigger = 0
- Attack time per byte: 20 mins


## Communication between PICO SWAES and CW


Command order




#### 0-48800 samples


0	1	2	3
4	5	6	7
8	9	10	11
12	13	14	15






### 48800-73200 samples







#### 73200-97600 samples

0	1	2	3
4	5	6	7
8	9	10	11
12	13	14	15

0.02

0.01

0.00


5000


10000

15000


20000

25000






## 97600-12200 samples





0.00




0.000

#### 12200-146400 samples







146400-170800 samples<sub>...s</sub>. Byte 3, 7



0.010


0.005

5000

10000

15000

20000



0.010

0.005

0.000

5000

10000

15000

20000

25000

25000

Subkey 7, Correlation 0.054492 at sample point 5275

SWAES PICO CW Power Traces Plot 146400-170800