
Mr.Loop Android Miracast User Guide


Note:

- Support Android 5.1 above.
- · On Android Mobile or Tablet, please with USB OTG cable.


1. Install Android APK – "ml_miracast_android_5.1.apk"




2. Plugin WiGig USB3.0 Dongle on Android platform, then click Yes button.



3. Wait for connection




If connect fail, you can see:



Windows Setup
 Please install Application – MrLoopApp_1.0.3.24

5. Plugin WiGig USB3.0 Dongle on Windows PC, the open application Enter Miracast button -> Share Screen



6. Share Screen to Android devices

