

## CS301 Embedded System and Microcomputer Principle


Lecture 3: C for Embedded System


2024 Fall

This PowerPoint is for internal use only at Southern University of Science and Technology. Please do not repost it on other platforms without permission from the instructor.



Recap





ALU



# **Embedded vs Desktop Programming**

- Main characteristics of embedded programming environments:
  - Cost sensitive
  - Limited ROM, RAM, stack space
  - Limited power
  - Limited computing capability
  - Event-driven by multiple events
  - Real-time responses and controls
  - Reliability
  - Hardware-oriented programming



## **Embedded Programming**

- Basically, optimize the use of resources:
  - Execution time
  - Memory
  - Energy/power
  - Development/maintenance time
- Time-critical sections of program should run fast
  - Processor and memory-sensitive instructions may be written in assembly
  - Most of the codes are written in a high level language (HLL): e.g. C, C++, or Java




## **Outline**

- Operations
- Data Types
- Storage Classes



## **Arithmetic**

- Integer arithmetic → Fastest
- Floating-point arithmetic in hardware → Slower
- Floating-point arithmetic in software → Very slow



- Try to use integer addition/subtraction
- Avoid multiplication unless you have hardware
- Avoid division
- Avoid floating-point, unless you have hardware
- Really avoid math library functions




## **Bit Manipulation**

- C has many bit-manipulation operators:
  - & Bit-wise AND
  - Bit-wise OR
  - A Bit-wise XOR
  - Negate (one's complement)
  - >> Right-shift
  - << Left-shift
- Plus assignment versions of each: &=, |=, etc
- Often used in embedded systems



## **Bit Manipulation**





## Bit Manipulation in STM32

use | operator to set a bit of a byte to 1

```
GPIOA->ODR =(1<<8); //set bit 8 (9th bit) of GPIOA->ODR
```

use & operator to clear a bit in a byte to 0

```
GPIOB->ODR &= \sim(1<<8); //clear bit 8 (9th bit) of GPIOB->ODR
```

• use & operator to see if a bit in a byte is 1 or 0

```
if( ((GPIOC->IDR & (1<5)) != 0) //check bit 5 (6th bit)
```

A mask indicates which bit positions we are interested in



# Faking Multiplication/Division

- Addition, subtraction, and shifting are fast
  - Can sometimes supplant multiplication
- Like floating-point, not all processors have a dedicated hardware multiplier
  - Multiplication is realized by addition and subtraction
  - Multiplication to a power of two is just a shift
- Division is a much more complicated algorithm that generally involves decisions
  - Division by a power of two is just a shift:

$$a/2 = a >> 1$$

$$a/4 = a >> 2$$



## **Lazy Logical Operators**

"Short circuit" tests save time

if 
$$(a == 3 \&\& b == 4 \&\& c == 5) \{ ... \}$$

equivalent to

if 
$$(a == 3) \{ if (b == 4) \{ if (c == 5) \} \}$$

Strict left-to-right evaluation order provides safety



## **Multi-way branches**

Which one is faster? Shorter?

```
if (a == 1)
                                  switch (a) {
   foo();
                                  case 1:
else if (a == 2)
                                      foo(); break;
    bar();
                                  case 2:
else if (a == 3)
                                       bar(); break;
    baz();
                                  case 3:
else if (a == 4)
                                       baz(); break;
    qux();
                                  case 4:
else if (a == 5)
                                      qux(); break;
    quux();
                                  case 5:
                                       quux(); break;
else if (a == 6)
    corge();
                                  case 6:
                                       corge(); break;
                       baiyh@sustech.edu.cn
```

# Code for if-then-else

```
if (a == 1)
    foo();
else if (a == 2)
    bar();
else if (a == 3)
    baz();
else if (a == 4)
    qux();
else if (a == 5)
    quux();
else if (a == 6)
    corge();
```

```
20: void test(int a) {
0x080004DC B500
                      PUSH
                                {lr}
    21:
                 if (a == 1)
0x080004DE 2801
                               r0, #0x01
                      CMP
0x080004E0 D102
                                0x080004E8
                      BNE
     22:
                 foo();
0x080004E2 F7FFFFCF BL.W
                               foo (0x08000484)
0x080004E6 E017
                               0x08000518
    23: else if (a == 2)
0x080004E8 2802
                               r0, #0x02
                      CMP
0x080004EA D102
                               0x080004F2
                      BNE
                 bar();
     24:
0x080004EC F7FFFF89 BL.W
                               bar (0x08000402)
0x080004F0 E012
                                0x08000518
    25: else if (a == 3)
0x080004F2 2803
                               r0, #0x03
                      CMP
0x080004F4 D102
                      BNE
                               0x080004FC
     26:
                 baz();
0x080004F6 F7FFFF85 BL.W
                               baz (0x08000404)
0x080004FA E00D
                               0x08000518
    27: else if (a == 4)
0x080004FC 2804
                               r0, #0x04
                      CMP
0x080004FE D102
                               0x08000506
                      BNE
     28:
                 qux();
0x08000500 F7FFFFEB BL.W
                               qux (0x080004DA)
0x08000504 E008
                               0x08000518
    29: else if (a == 5)
0x08000506 2805
                      CMP
                               r0, #0x05
0x08000508 D102
                      BNE
                                0x08000510
    30:
                 quux();
0x0800050A F7FFFFE5 BL.W
                               quux (0x080004D8)
0x0800050E E003
                                0x08000518
    31: else if (a == 6)
0x08000510 2806
                               r0, #0x06
                      CMP
                               0x08000518
0x08000512 D101
                      BNE
     32:
                 corge();
0x beigh@sustachedworff77 BL.W
                               corge (0x08000406)
    33: }
```



# Code for Switch

```
switch (a) {
case 1:
    foo(); break;
case 2:
    bar(); break;
case 3:
    baz(); break;
case 4:
    qux(); break;
case 5:
    quux(); break;
case 6:
    corge(); break;
  BCS: Branch if Carry Set
  TBB: Table Branch Byte
  DCW: allocates a half-word
```

```
35: void testswitch(int a) {
□ 0x080004DC B500
                       PUSH
                                {lr}
     36:
                  switch(a){
     37:
                 case 1:
 0x080004DE 2807
                       CMP
                                r0,#0x07
 0x080004E0 D217
                       BCS
                                0x08000512
 0x080004E2 E8DFF000
                      TBB
                                [pc, r0]
 0x080004E6 0416
                       DCW
                                0x0416
                      DCW
 0x080004E8 0A07
                                0x0A07
                      DCW
 0x080004EA 100D
                                0x100D
 0x080004EC 0013
                       DCW
                                0x0013
     38:
                          foo(); break;
     39:
                 case 2:
 0x080004EE F7FFFFC9 BL.W
                             foo (0x08000484)
 0x080004F2 E00E
                                0x08000512
                          bar(); break;
     40:
                 case 3:
     41:
 0x080004F4 F7FFFF85 BL.W
                               bar (0x08000402)
 0x080004F8 E00B
                                0x08000512
                       В
     42:
                          baz(); break;
     43:
                  case 4:
 0x080004FA F7FFFF83 BL.W
                               baz (0x08000404)
 0x080004FE E008
                                0x08000512
                       В
                          qux(); break;
     44:
     45:
                 case 5:
 0x08000500 F7FFFEB BL.W
                              qux (0x080004DA)
 0x08000504 E005
                                0x08000512
     46:
                          quux(); break;
     47:
                 case 6:
 0x08000506 F7FFFFE7 BL.W
                                quux (0x080004D8)
 0x0800050A E002
                                0x08000512
     48:
                          corge(); break;
 0x09al/0@sustech.For FFF7B
                      BL.W
                                corge (0x08000406)
 0x08000510 BF00
                       NOP
```





# Computing Function x=f(a)

 There are many ways to compute a "random" function of one variable, especially for sparse domain:

 Better for large, dense domains, switch cases use a jump table

Best: constant time lookup table

```
int f[] = {0, 4, 7, 2, 8, 9};
x = f[a]; /* assumes 0 <= a <= 5 */</pre>
```


```
if (a == 0) x = 0;
else if (a == 1) x = 4;
else if (a == 2) x = 7;
else if (a == 3) x = 2;
else if (a == 4) x = 8;
else if (a == 5) x = 9;
...
```

```
switch (a) {
    case 0: x = 0; break;
    case 1: x = 4; break;
    case 2: x = 7; break;
    case 3: x = 2; break;
    case 4: x = 8; break;
    case 5: x = 9; break;
...
}
```



## **Preprocessor and Macro**

- The preprocessor is executed before the compilation. Main usages:
  - File inclusion
  - Macro substitution
  - Conditional compilation
  - preprocessing instruction: #include, #ifdef, #ifndef, #if, #else, #define, etc
- Macro is a fragment of code that is given a name and can be used as a replacement for that code in the source code





## **Function vs Macro**

#### A named collection of codes

- A function is compiled only once. On calling that function, the processor has to save the context, and on return restore the context
- Preprocessor puts macro code at every place where the macro-name appears. The compiler compiles the codes at every place where they appear.

#### Function versus macro:

- Time: use function when  $T_{\text{overheads}} << T_{\text{exec}}$ , and macro when  $T_{\text{overheads}} \sim= \text{or} > T_{\text{exec}}$ , where  $T_{\text{overheads}}$  is function overheads (context saving and return) and  $T_{\text{exec}}$  is execution time of codes within a function
- Space: similar argument



## **Outline**

- Operations
- Data Types
- Storage Classes



# **Data Type**

stdint.h stm32f10x.h


		Stairit.11	SIIII32110X.II
# bit	Range	Stdint type	ST type
8	-128 ~ 127	int8_t	s8
8	0 ~ 255	uint8_t	u8
16	-32768 ~ 32767	int16_t	s16
16	0 ~ 65535	uint16_t	u16
32	-2147483648 ~ 2147483647	int32_t	s32
32	0 ~ 4294967295	uint32_t	u32
32	-2147483648 ~ 2147483647		
32	0 ~ 4294967295		
64	-(2^64)/2 ~ (2^64)/2-1	int64_t	
64	0 ~ (2^64)-1	uint64_t	
32	-3.4e38 ~ 3.4e38		
64	-1.7e308 ~ 1.7e308		
	8 8 16 16 32 32 32 32 64 64 64	8	# bit Range Stdint type  8



## **Pointers**

- A pointer is the memory address of a data object
- e.g.

```
int x = 42;
int *xp = &x;
```



- The pointer xp holds the address of x
- The data x is accessed by dereferencing the pointer xp using \*xp.
- Pointer's data size is usually 4 or 8 byte
- Dangling pointer = danger!

```
1&2
         Add
         600
         602
         604
                p1
                    600
                                p1
                                     600
                                                 p1
                                                     600
                                                                     600
p1
         606
p2
                                    602
                                                     602
                                                                     600
                p2
```

```
void main ( ) {
   int i, j;
   int *p1, *p2;

1   i = 4;
2   j = 3;
3   p1 = &i;
4   p2 = &j;
5   *p1 = *p1+*p2;
6   p2 = p1;
}
```



## **Pointer vs Array**

- Incrementing and decrementing pointers to array elements
  - Increment operator ++ makes pointer advance to next element
  - Decrement operator -- makes pointer move to previous element
  - These use the size of the variable's base type (e.g. int, char, float) to determine what to add
    - p++ (Equivalent to p=p+1) increments the pointer p by the size of the data type it points to, for example sizeof(int)
    - size of is C operator which returns size of type in bytes

```
int a[18];
int * p;
p = &a[5];
*p = 5; /* a[5]=5 */
p++;
*p = 7; /* a[6]=7 */
p--;
*p = 3; /* a[5]=3 */
```



## **Pointer vs String**

- There is no "string" type in C.
- Instead, an array of characters is used: char a[44];
- The string is terminated by a NULL character (value of 0, represented in C by \0).
- Need an extra array element to store this null
  Example
  char str[10] = "testing";
  char str[30];

```
char str[30];
int a = 30;
float b = 3.14;

sprintf(str, "a=%d, b=%f\n", a, b);

sprintf(str, "a=0x%X, b=%.1f\n", a, b);

str

a=30, b=3.140000
str

a=0x1E, b=3.1
```



#### Structure

• a structure is an aggregate data type composed of several distinct members.

```
struct PERSON {
    char gender;
    int age;
};

struct PERSON sue;

typedef struct {
    char gender;
    int age;
} PERSON;

PERSON sue;
```


- GPIOC->CRL
  - GPIOC\_BASE: base address of GPIOC registers
  - GPIOC: pointer to a GPIO\_TypeDef structure
  - GPIOC->CRL: access the CRL register of GPIOC

```
/** @brief General
  *Purpose I/O
  */
typedef struct
{
    __IO uint32_t CRL;
    __IO uint32_t CRH;
    __IO uint32_t IDR;
    __IO uint32_t ODR;
    __IO uint32_t BSRR;
    __IO uint32_t BRR;
    __IO uint32_t LCKR;
} GPIO_TypeDef;
```



## **Memory Alignment**

- Modern processors have byte-addressable memory
  - But, many data types (integers, addresses, floating-point) are wider than a byte
  - In 32-bit system, data are transferred in 32-bit chunks
- Structures member are stored in order, but memory aligned





#### **Structure Bit Fields**

- Aggressively packs data to save memory
  - Compiler will pack these fields into words
  - Implementation-dependent packing, ordering, ...
  - Usually not very efficient in terms of execution time: requires masking, shifting, readmodify-write
    - → a tradeoff between space and time!



## **C** Unions

 Like structs, but shares the same storage space and only stores the mostrecently-written field

```
union {
    char ival;
    short fval;
    char *sval;
} u;
```

- but occupy same memory space
- can hold different types at different times
- overall size is largest of elements
- Potentially very dangerous: not type-safe



## **Data Type Selection**

- Mind the architecture
  - Same C source code could be efficient or inefficient
  - Should keep in mind the architecture's typical instruction size and choose the appropriate data type accordingly
- 3 rules for data type selection:
  - Use the smallest possible type to get the job done
  - Use unsigned type if possible
  - Use casts within expressions to reduce data types to the minimum required
- Use typedefs to get fixed size
  - Change according to compiler and system
  - Code is invariant across machines

```
/* Fixed-size types */
typedef unsigned char uint8_t;
typedef short int16_t;
typedef unsigned int uint32_t;
```



## **Strength Reduction**

- Why multiply when you can add?
- Use [] istead of ->

```
struct {
    int a;
    char b;
    int c;
} foo[10];
int i;
for (i = 0; i < 10; ++i) {
    foo[i].a = 77;
    foo[i].b = 88;
    foo[i].c = 99;
}</pre>
```

```
struct {
    int a;
    char b;
    int c;
} *fp, *fe, foo[10];
fe = foo + 10;
for (fp = foo; fp != fe; ++fp) {
    fp->a = 77;
    fp->b = 88;
    fp->c = 99;
}
```

Good optimizing compilers automatically do this



## **Outline**

- Operations
- Data Types
- Storage class



## Storage class in C

- keywords related to storage class provide information on
  - scope: visibility or accessibility
  - **lifetime**: existence of a variable

```
/* fixed address: visible to other files */
extern int global static;
/* fixed address: visible within file */
static int file static;
/* parameters always stacked */
int foo(int auto param)
    /* fixed address: only visible to func */
    static int func static;
    /* stacked: only visible to function */
    int auto i, auto a[10];
    /* array explicitly allocated on heap */
    double *auto_d = malloc(sizeof(double) * 5);
    /* return value in register or stacked */
    return auto i;
```



## Storage class in C

#### auto:

- Default storage class for variables declared inside a function.
- Accessible only within the function's scope.

#### • register:

- Stores variables in CPU registers to speed up access.
- Same scope and accessibility as auto; allocation depends on the compiler.

#### • static:

- Variable lifetime matches the program's duration.
- Retains its value between function calls; initialized to zero by default.
- Accessibility depends on declaration context.

#### extern:

- Makes variables accessible across multiple functions and files.
- Can be modified by any function within its scope.



## **Static**

- Static variable inside function is initialized only once.
- What's the value of y?

```
int foo();
                                 int foo();
int main(void) {
                                 int main(void) {
  int y;
                                    int y;
  y = foo(); // y = ?
                                    y = foo(); // y = ?
  y = foo(); // y = ?
                        y = foo(); // y = ?
                               y = foo(); // y = ?
  y = foo(); // y = ?
                                    while(1);
  while(1);
int foo() {
                                 int foo() {
  int x = 5;
                                    static int x = 5;
  x = x + 1;
                                    X = X + 1;
  return(x)
                                    return(x)
```



#### **Extern**

 See how extern allows access to the global variable count across different files



## **Volatile**

- A volatile variable is one whose value may be change outside the normal program flow. In embedded systems, there are two ways this can happen:
  - Via an interrupt service routine
  - As a consequence of hardware action
- It is considered to be very good practice to declare all peripheral registers in embedded devices as volatile
  - Modify the variable with the volatile keyword so that the value of the variable is re-read every time instead of using the backup value stored in the register



# malloc() and free()

- Flexible than (stacked) automatic variables
- More costly in time and space
- Use non-constant-time algorithms
- Two-word overhead for each allocated block:
  - Pointer to next empty block
  - Size of this block
- Common source of errors:

Using uninitialized memory Using freed memory

Not allocating enough Indexing past block

Neglecting to free disused blocks (memory leaks)

Good or bad for embedded applications?



## **Storage Compared**

- On most processors, access to automatic (stacked) data and globals is equally fast
  - Automatic usually preferable since the memory is reused when function terminates
  - Danger of exhausting stack space with recursive algorithms. Not used in most embedded systems.
- The heap (malloc) should be avoided if possible:
  - Allocation/deallocation is unpredictably slow
  - Danger of exhausting memory
  - Danger of fragmentation
  - Best used sparingly in embedded systems



## **Summary**

- 1. Integer arithmetic
- 2. Pointer access
- 3. Simple conditionals and loops
- 4. Static and automatic variable access
- 5. Array access
- 6. Floating-point with hardware support
- 7. Switch statements
- 8. Function calls
- 9. Floating-point emulation in software
- 10. Malloc() and free()
- 11. Library functions (e.g. sin, log, etc)
- 12. Operating system calls (e.g. open)