

Section B - Panel Components

[Topics](#) [Send Feedback](#)

Description

Insert Panel layout footprint and annotate.

Topics

Name	Description
c:ace_get_footprint_fname	Query footprint_lookup.mdb for footprint file name.
c:ace_ins_dinrail	Insert parametrically build DIN rail, no dialog box, no prompts
c:wd_adjust_pnlays	Move attributes found on panel footprint block insert "ben" to the appropriate layer categories defined on the drawing's WD_PNLM insert.
c:wd_dinrl	Insert parametrically built DIN rail. User prompted for insertion point, length, direction, and so on.
c:wd_do_psym_in	Triggers panel footprint icon menu display for component selection. User selects insertion point and rotation.
c:wd_edsym2	Trigger EDIT component dialog box for panel footprint entity "ben". The component can also be a PLC module, schematic symbol, a voltage signal source or destination arrow, or footprint. AcadE pops open appropriate dialog box based upon selected component type.
c:wd_ins_np	User entry point for inserting a smart nameplate.
c:wd_insymp	Insert panel footprint block. Footprint can be totally "dumb" with prepositioned AcadE attributes (ex: footprints straight from a vendor) or AcadE-aware with attributes. If no attributes, AcadE adds annotation data to the block on -the-fly in the form of AutoCAD extended entity data (XDATA).
c:wd_insymp_r	Simple footprint insert, with rotate prompt.
c:wd_is_it_pnl	Check entity type. Determine if given entity is a panel footprint, terminal, nameplate symbol, or item balloon.
c:wd_pnl_asmb2	For inserting assy of one or more panel footprints, terminal footprints, nameplates, and/or balloons.
c:wd_pnl_ed	Obsolete. Use wd_psymed instead.
c:wd_pnl_lout	Find and insert footprint. Select component from AcadE Schematic extract list (.wd1 file), find and insert matching footprint (based on schematic component's MFG and catalog number, then start the footprint dialog box.
c:wd_pnlb_doedit	This function has been renamed, use wd_psymed instead.
c:wd_psymed	Select a panel footprint to edit. Prompts user to select a panel footprint.

Links

[Topics](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:ace_get_footprint_fnam

[Section B - Panel Components](#) [Send Feedback](#)

Description

Query footprint_lookup.mdb for footprint file name.

AutoLISP

```
(c:ace_get_footprint_fnam param_lst)
```

Parameters

Parameters	Description
param_lst	(list mfg cat assycode flag) (nth 0) = MFG (nth 1) = CAT (nth 2) = ASSYCODE (nil or "" = none) (nth 3) = "ins_mode" flag: "0" = use normal lookup (mech footprints), "1" = use wiring diagram tables (+ "_WD" table names), "2" = look for AcadE table fi then normal mech table if no match found, "16" = = quiet mode, display file search message in commanc window.

Returns

(list recval fullblknam) where "recval" = block name pulled from footprint_lookup.mdb file, "fullblknam" = full path/name (if found). If the first character of recval is an asterisk (*), then this flags that the returned block is marked t exploded upon insert.

Module

[Section B - Panel Components](#)

Links

[Section B - Panel Components](#)

[Example](#) [Section B - Panel Components](#) [Send Feedback](#)

Description

Insert parametrically build DIN rail, no dialog box, no prompts

AutoLISP

```
(c:ace_ins_dinrail param_lst)
```

Parameters

Parameters	Description
param_lst	("mfg", "cat", "asmb" = catalog manufacturer, catalog assycode (if required)) (nth 0) : xyz - insertion point (nth 1) : len - length (nth 2) : horv - horiz or vertical insert "H" or "V" (nth 3) : scale, nil = 1.0 (nth 4) : pnl_mounting 1 = holes, 2 = stand-offs, 3 none (nth 5) : options (1's bit set = show the EDIT dialog after insertion)

Example

```
(setq params (list (list 150.0 10.0 0.0) 50.0 "V" 1.0 2))  
(c:ace_ins_dinrail "AB" "199-DR1" "" params)
```

Module

[Section B - Panel Components](#)

Links

[Example](#), [Section B - Panel Components](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_adjust_pnlays

[Example](#) [Section B - Panel Components](#) [Send Feedback](#)

Description

Move attributes found on panel footprint block insert "ben" to the appropriate layer categories defined on the drawing
WD_PNL_M block insert

Parameters

Parameters	Description
ben	AutoCAD entity name of footprint block.

Returns

List of changes made, or nil if no change. Format:

Example

User prompt to pick footprint to process.

```
(c:wd_adjust_pnlays (car (entsel "Pick footprint to process:")))
```

Module

[Section B - Panel Components](#)

Links

[Example](#), [Section B - Panel Components](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_dinrl

[Section B - Panel Components](#) [Send Feedback](#)

Description

Insert parametrically built DIN rail. User prompted for insertion point, length, direction, and so on.

AutoLISP

```
(c:wd_dinrl)
```

Module

[Section B - Panel Components](#)

Links

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_do_psym_in

[Example 1](#) [Example 2](#) [Example 3](#) [Example 4](#) [Section B - Panel Components](#) [Send Feedback](#)

Description

Triggers panel footprint icon menu display for component selection. User selects insertion point and rotation.

AutoLISP

```
(c:wd_do_psym_in)
```

Example 1

Pops open the current/default panel icon menu.

```
(c:wd_do_psym_in)
```

Example 2

Pop open a specific panel icon menu (one time).

```
(c:wd_use_menu "c:/my_custom/my_special_pnlmenu.dat")  
(c:wd_do_psym_in)
```

Example 3

Make a specific panel icon menu persist during the current AcadE session.

```
(setq GBL_wd_pnl_menu_override "c:/my_custom/my_special_pnlmenu.dat")
```

Example 4

Flip back to the default panel icon menu.

```
(setq GBL_wd_pnl_menu_override nil)
```

Module

[Section B - Panel Components](#)

Links

[Example 1](#), [Example 2](#), [Example 3](#), [Example 4](#), [Section B - Panel Components](#)

Description

Trigger EDIT component dialog box for panel footprint entity "ben". The component can also be a PLC module, sche symbol, a wire signal source or destination arrow, or footprint. AcadE pops open the appropriate dialog box based u selected component type.

AutoLISP

```
(c:wd_edsym2 ben)
```

Parameters

Parameters	Description
ben	AutoCAD entity name of selected AcadE component.

Example

User prompt to pick footprint to edit.

```
(setq ben (car (entsel "Select footprint to edit:")))  
(if ben (c:wd_edsym2 ben))
```

Module

[Section B - Panel Components](#)

Links

[Example](#), [Section B - Panel Components](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_ins_np

[Example](#) [Section B - Panel Components](#) [Send Feedback](#)

Description

User entry point for inserting a smart nameplate.

AutoLISP

```
(c:wd_ins_np fpben npblk xy rot scl xgrp noprompts anno_dat)
```

fpben	Footprint block ent name to tie nameplate to (nil = insert as stand-alone nameplate).
npblk	Nameplate block name (nil = figure out from mfg/cat/asmb lookup).
xy	Nameplate insertion point (nil = prompt user for pick if fpben = nil and noprompts = nil). If fpben given, insert at its origin.
rot	rotation angle, nil = prompt user if noprompts = nil, 0.0 if noprompts = 1.
scl	scale, nil=insert at current symbol setting scale, or optional x and y scale passed as a list: (list xscl yscl)
mfg	manufacturer code assignment (optional)
cat	catalog code assignment (optional)
asmb	assemble code assignment (optional)
xgrp	1 to explode and GROUP (For example, a nameplate nested inside a stretchable border. Nil = insert as not exploded block.
noprompts	1 to suppress all user prompts and no edit dialog box; also return quietly from the routine if any needed data missing or invalid.
anno_dat	annotation data list (any entry can have a value or be nil or "").

Returns

nil if failed to run, otherwise return ent name list of lists in this order: (list footprints nameplates balloons term_footprints).

Example

User prompt to pick footprint to add nameplate to.

```
(c:wd_ins_np (car (entsel)) (wd_fio_does_pnlblock_exist "ab/np-name plates/npab8ta") nil nil nil
nil nil nil nil
nil)
```

Module

[Section B - Panel Components](#)

Links

[Example](#), [Section B - Panel Components](#)

[Example 1](#), [Example 2](#), [Section B - Panel Components](#), [Send Feedback](#)

Description

Insert panel footprint block. Footprint can be totally "dumb" with no prepositioned AcadE attributes (ex: footprints s from a vendor) or AcadE-aware with attributes. If no attributes, AcadE adds annotation data to the block on -the-fly form of AutoCAD extended entity data (XDATA).

AutoLISP

```
(c:wd_insymp fpblk xy rot scl anno_dat)
```

Parameters

Parameters	Description
fpblk	Panel footprint block to insert (searches normal Acac paths).
xy	Insertion point (nil = user prompted).
rot	Rotation (in degrees), nil = 0.0 degrees.
scl	scale (default = 1.0), optional (list xscl yscl) allowed
anno_dat	future/optional list of annotation data, pass "nil" for

Returns

Entity name of new block insert.

Example 1

```
(c:wd_insymp "ab/pb-pushbuttons/abpb3r" nil 0.0 1.0 nil)
```

Example 2

```
(c:wd_insymp "ab/pb-pushbuttons/abpb3r" (list 5.5 4.0) 0.0 (list 2.0 -2.0) nil)
```

Module

[Section B - Panel Components](#)

Links

[Example 1](#), [Example 2](#), [Section B - Panel Components](#)

[Example](#) [Section B - Panel Components](#) [Send Feedback](#)

Description

Simple footprint insert, with rotate prompt.

AutoLISP

```
(c:wd_insymp_r footprint)
```

Parameters

Parameters	Description
footprint	footprint block/file name to insert.

Returns

nil if failure or ent name of inserted block insert.

Example

Insert Allen-Bradley pilot light representation.

```
(c:wd_insymp_r "AB/LT-PILOT LIGHTS/ABLT3R")
```

Module

[Section B - Panel Components](#)

Links

[Example](#), [Section B - Panel Components](#)

Description

Check entity type. Determine if given entity is a panel footprint, panel terminal, nameplate symbol, or item balloon.

AutoLISP

Parameters	Description
ben	name of entity to query.

Returns

nil = not panel symbol, "FP" = footprint, "FPT" = panel terminal, "NP" = panel nameplate, "BAL" = item balloon.

Example

Simple user prompted pick.

```
(c:wd_is_it_pnl (car (entsel "Pick block to query:")))
```

Module

[Section B - Panel Components](#)

Links

[Example](#), [Section B - Panel Components](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_pnl_asmb2

[Section B - Panel Components](#) [Send Feedback](#)

Description

For inserting assy of one or more panel footprints, terminal footprints, nameplates, and/or balloons.

AutoLISP

```
(c:wd_pnl_asmb2 symname xy scl rot flgbits)
```

Parameters

Parameters	Description
symname	wblocked dwg to insert exploded (nil=user promptec choose).
xy	Insertion point (nil=user prompt).
scl	Scale (nil=GBL_wd_symscl value if exist or 1.0 if not

1's bit AND 2's bit set = add in attribute template for converted footprints.
Set flgbits = nil or 0 to leave any dumb blocks as dumb blocks.

Returns

nil if failed to run, otherwise return ent name list of lists in this order: (list footprints nameplates balloons term_footprints).

Module

[Section B - Panel Components](#)

Links

[Section B - Panel Components](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_pnl_ed

[Section B - Panel Components](#) [Send Feedback](#)

Description

Obsolete. Use wd_psymed instead.

AutoLISP

```
(c:wd_pnl_ed)
```

Module

[Section B - Panel Components](#)

Links

[Section B - Panel Components](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_pnl_lout

[Section B - Panel Components](#) [Send Feedback](#)

Find and insert footprint. Select component from AcadE Schematic extract list (.wd1 file), find and insert matching footprint (based upon schematic component's MFG and catalog number, then start the EDIT footprint dialog box.

AutoLISP

```
(c:wd_pnl_lout fnam)
```

Parameters

Parameters	Description
fnam	Panel extract csv file ("nil" = access project's databa file).

Module

[Section B - Panel Components](#)

Links

[Section B - Panel Components](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_pnlb_doedit

[Section B - Panel Components](#) [Send Feedback](#)

Description

This function has been renamed, use wd_psymed instead.

AutoLISP

```
(c:wd_pnlb_doedit)
```

Module

[Section B - Panel Components](#)

Links

[Section B - Panel Components](#)

Description

Select a panel footprint to edit. Prompts user to select a panel footprint to edit, then starts EDIT footprint dialog bo:

AutoLISP

```
(c:wd_psymed)
```

Module

[Section B - Panel Components](#)

Links

[Section B - Panel Components](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_ptrm_lout

[Section B - Panel Components](#) [Send Feedback](#)

Description

Insert panel terminal footprint symbols. Symbols picked from schematic terminal extract list.

AutoLISP

```
(c:wd_ptrm_lout fnam)
```

Parameters

Parameters	Description
fnam	panel extract csv file ("nil" = access project's databa file).

Module

[Section B - Panel Components](#)

Links

[Section B - Panel Components](#)