

Section H - Reports

[Topics](#) [Send Feedback](#)

Description

Report generation.

Topics

Name	Description
c:ace_auto_rpt	Initiate automatic report generation.
c:ace_dwglst_rpt_dbx	Execute and display the Drawing List report.
c:ace_termplan_r	Cause schematic "terminal plan" connection report generation with any user prompts.
c:wd_bompnlr	Cause panel BOM report generation without any user prompts.
c:wd_bomr	This function is obsolete - use wd_bomschr instead.
c:wd_bomschr	Cause schematic BOM report generation without any user prompts.
c:wd_chkpwr_r	Cause generation of Power source/load data report without any user prompts.
c:wd_compconn_r	Cause schematic component connection report generation without any user prompts.
c:wd_compr_pnlr	Cause panel component report generation without any user prompts.
c:wd_compr_sch	Cause schematic component report generation without any user prompts.
c:wd_connpin_rpt1	Cause "Connector pin - Summary" report generation without any prompts.
c:wd_connpin_rpt2	Cause "Connector pin - Details" report generation without any user prompts.
c:wd_frm2_r	Cause wire or cable from/to report generation without any user prompts.
c:wd_get_schem_tags_in_use	Each returned value is a sublist consisting of Tag-ID, INST, LOC, DESC1-3 values. Returned list is sorted by Tag-ID and then by INST.
c:wd_getlocs	For the active drawing only, this routine extracts directly from the entities currently in the drawing. For a project-wide list, this routine queries the active project's database file, tables "COMP", "PLCIO", "TERM" for schematic and "PNLCOMP", "PNLTERM" for panel. This routine does NOT refresh the database before doing the query. You may want to call (c:wd_mdb_freshen nil) if you're not sure whether the database file is fully in synch with the drawing set.

c:wd_piconn_r	Cause schematic plug-jack connection report generation without user prompts.
c:wd_term_nums_rpt	Cause schematic terminal numbers report generation without an prompts.

Links

[Topics](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_auto_rpt
[Section H - Reports](#) [Send Feedback](#)

Description

Initiate automatic report generation.

AutoLISP

```
(c:ace_auto_rpt rgfnam firstdnam templatenam)
```

Parameters

Parameters	Description
rgfnam	Report Grouping file name as created in Automatic R dialog box.
firstdnam	Name of first drawing name if table output is an opti and new drawing(s) will be created, can be nil if no r drawings will be created.
templatenam	Template name if table output is an option and new drawing(s) will be created, nil for no template.

Module

[Section H - Reports](#)

Links

[Section H - Reports](#)

Description

Execute and display the Drawing List report.

AutoLISP

```
(c:ace_dwglst_rpt_dbx dist set_file T)
```

Parameters

Parameters	Description
dist	List of drawings from active project.
set_file	Format file (.set) name or nil for none.
T	This should always be set to T.

Module

[Section H - Reports](#)

Links

[Section H - Reports](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:ace_termplan_r
[Example 1](#) [Example 2](#) [Example 3](#) [Section H - Reports](#) [Send Feedback](#)

Description

Cause schematic "terminal plan" connection report generation without any user prompts.

AutoLISP

```
(c:ace_termplan_r param_lst)
```

Parameters

Parameters	Description
param_lst	Parameter list for the terminal plan report generation.

"doloc" parameter.

doloc = location code to include (if `todo_locs = 3`). I have wild cards per AutoCAD standards (for example `"*JBOX"` means any location with "JBOX" substring).

incl = (not used, set to "nil").

dlist = (ignore if `doall = nil`). `nil` = do all drawings in project, otherwise do this list of dwgs in the current project (list "dwg1" "dwg2" ...). Full path not needed.

format = output file format "ASC" for ascii, "XLS" for Excel, "MDB" for Access, "CSV" for comma delimited "CSV+P" for comma delimited with project information first line of data.

fields = 0 to output all fields; 1 = output only fields defined in default ".set" report settings file; = specify settings file to use ("set" extension is not required, double backslashes if path is given).

outfilename = output file name, use single forward double backslashes in path.

scriptfilename = optional script file name (execute report extraction is complete). The "outfilename" can be accessed from within the script file through the following AutoLISP expression: `(vl-bb-ref 'FNAM)`.

Example 1

Extract terminal plan report, project-wide, output all fields in Excel format to a file named "terms.xls":

```
(c:ace_termplan_r (list 1 1 nil nil nil "XLS" 0 "terms.xls" nil))
```

Example 2

Extract terminal plan report, project-wide, but for terminals that have a LOC location assignment containing the word "SPLIT", output only fields defined in the default settings file to ASCII report file "terms.rpt":

```
(c:ace_termplan_r (list 1 3 "*SPLIT*" nil nil "ASC" 1 "terms.rpt" nil))
```

Example 3

Same as above but show those that have an INST value of "LINE2":

```
(c:ace_termplan_r (list 1 (list 3 3) (list "LINE2" "*SPLIT*") nil nil "ASC" 1 "terms.rpt" nil))
```

Module

[Section H - Reports](#)

Links

[Example 1](#), [Example 2](#), [Example 3](#), [Section H - Reports](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

Description

Cause panel BOM report generation without any user prompts.

AutoLISP

```
(c:wd_bompnlr param_lst)
```

Parameters

Parameters	Description
param_lst	A "list" of ten elements: doall = 1 to process all dwgs in active project; nil to process only active dwg only. todolocs = 1 to process all components; 2 process components that have a blank location code; 3 process components that "wild card match with "doloc" parameters below. doloc = location code to include (if todolocs=3). Can be wild cards per AutoCAD stds (for example, "*CAB*" for any location with "CAB" substring). incl = what to include (0 = pnl comps only, 2 = incl connectors, 4 = incl pnl terms, 8 = incl nameplates, 16 = incl unreferenced schematic comps, 31 = include all Electrical comps, 64 = include Inventor comps, 127 = include all, 1024 = list terminal numbers). purch = tally in purchase order format; 1=purchase order format, 0=normal BOM format, 2 = "By TAG" BOM format. format = output file format "ASC" for ASCII, "XLS" for Excel, "MDB" for Access, "XML," "CSV" for comma-delimited ASCII, "CSV+P" for comma-delimited ASCII with project info as first line of data. fields = 0 to output all fields; 1= output only fields defined in default ".set" report settings file; = specify settings file to use (".set" extension is not required, double backslashes if path is given). outfilename = output file name, use single forward slashes for single backslashes in path. scriptfilename = optional script file name (execute report extraction is complete). The "outfilename" can be accessed from within the script file through the following AutoLISP expression: (vl-bb-ref &C~FNAM). category = WDTYPE filter (nil or "" = schematic, "1" = one-line, etc.). Optional.

Example 1

```
(c:wd_bompnlr (list 1 1 "" 31 1 "ASC" 1 "c:\\purchase.txt" nil))
```

Example 2

```
(c:wd_bomplnr (list 1 3 "*" 127 nil "ASC" 1 "c:\\purchase.txt" nil))
```

Module

[Section H - Reports](#)

Links

[Example 1](#), [Example 2](#), [Example 3](#), [Section H - Reports](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_bomr

[Section H - Reports](#) [Send Feedback](#)

Description

This function is obsolete - use wd_bomschr instead.

AutoLISP

```
(c:wd_bomr)
```

Module

[Section H - Reports](#)

Links

[Section H - Reports](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_bomschr

[Example 1](#) [Example 2](#) [Example 3](#) [Section H - Reports](#) [Send Feedback](#)

Description

Cause schematic BOM report generation without any user prompts.

AutoLISP

Parameters	Description
param_lst	A "list" of ten elements: doall = 1 to process all dwgs in active project; nil to process only active dwg only. todolocs = 1 to process all components; 2 process components that have a blank location code; 3 process components that "wild card match with "doloc" parameter below. doloc = location code to include (if todolocs=3). Can use wild cards per AutoCAD stds (for example, "*CAB*" will include any location with "CAB" substring). incl = what to include (0 = sch comps only, 1 = include cables, 2 = include connectors, 3 = include all Electrical components, 64 = include Inventor comps, 127 = include all 1024 = list terminal numbers). purch = 1 = like subitems combined, nil = normal BOM, 2 = "By TAG" BOM, 3=normal tallied BOM grouped by Inst/Loc. format = output file format "ASC" for ASCII, "XLS" for Microsoft Excel format, "MDB" for Microsoft Access format, "CSV" for comma-delimited ASCII, "CSV+P" for comma-delimited ASCII with project info as first line of data. fields = 0 to output all fields; 1 = output only fields defined in default ".set" report settings file; = specify settings file to use (".set" extension is not required; double backslashes if path is given). outfilename = output file name, use single forward slashes in path. scriptfilename = optional script file name (execute report extraction is complete). The "outfilename" can be accessed from within the script file through the following AutoLISP variables: for AutoCAD Release 14 it is simply FNAM, for AutoCAD 2000 the report file name can be retrieved via the following AutoLISP expression: (vl-get 'FNAM). category = WDTYPE filter (nil or "" = schematic, "1-line", etc.). Optional.

Example 1

```
(c:wd_bomschr (list 1 3 "CAB1" 3 nil "XLS" 1 "report.xls" nil))
```

Example 2

```
(c:wd_bomschr (list 1 3 "CAB1" 3 nil "XLS" 1 "report.xls" nil "1-"))
```

Example 3

```
(c:wd_bomschr (list 1 3 "*" 127 nil "XLS" 1 "report.xls" nil))
```

Module

[Section H - Reports](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_chkpwr_r

[Example](#) [Section H - Reports](#) [Send Feedback](#)

Description

Cause generation of Power source/load data report without any user prompts.

AutoLISP

```
(c:wd_chkpwr_r param_lst)
```

Parameters

Parameters	Description
param_lst	A "list" of elements: dosingle = 1 to do active dwg only. todolocs = 1 to process all components; 2 process components that have a blank location code; 3 process components that "wild card match with "doloc" parameter below. doloc = location code to include (if todolocs = 3). Can have wild cards per AutoCAD stds (for example, "*CAB" means any location with "CAB" substring). format = output file format "XLS" for Excel, "MDB" for Microsoft Access format, "CSV" for comma delimited future = 0 outfilename = output file name (use double backslashes or single forward slashes) future = nil

Example

```
(c:wd_chkpwr_r (list 1 1 nil nil "XLS" 0 "c:/rep/powerdump.xls" nil))
```

Module

[Section H - Reports](#)

Links

[Example](#), [Section H - Reports](#)

Description

Cause schematic component connection report generation without any user prompts.

AutoLISP

```
(c:wd_compconn_r param_lst)
```

Parameters

Parameters	Description
param_lst	A "list" of nine elements: doall = nil to do active drawing only, 1 = process all project (see dlist parameter element). todo_locs = 1 to process all schematic connector symbols; 2 process only those that have a blank loc code; 3 process those subject to wild card match with "doloc" parameter. doloc = location code to include (if todo_locs = 3). Have wild cards per AutoCAD standards (for example "*JBOX*" means any location with "JBOX" substring). incl = (not used, set to "nil"). dlist = (ignore if doall = nil). nil = do all drawings in project, otherwise do this list of dwgs in the current project (list "dwg1" "dwg2" ...). Full path not needed. format = output file format "ASC" for ascii, "XLS" for Excel, "MDB" for Access, "CSV" for comma delimited "CSV+P" for comma delimited with project information first line of data. fields = 0 to output all fields; 1 = output only fields defined in default ".set" report settings file; = specify settings file to use (".set" extension is not required, double backslashes if path is given). outfilename = output file name, use single forward double backslashes in path. scriptfilename = optional script file name (execute report extraction is complete). The "outfilename" can be accessed from within the script file through the following AutoLISP expression: (vl-bb-ref 'FNAM).

Example

```
(c:wd_compconn_r (list 1 1 "" 3 nil "XLS" 0 "c:\temp\compconn.xls" nil))
```

Module

[Section H - Reports](#)

Links

[Example](#), [Section H - Reports](#)

c:wd_compr_pnlr

[Example 1](#) [Example 2](#) [Section H - Reports](#) [Send Feedback](#)

Description

Cause panel component report generation without any user prompts.

AutoLISP

```
(c:wd_compr_pnlr param_lst)
```

Parameters

Parameters	Description
param_lst	A "list" of nine elements: doall = 1 to process all dwgs in active project; nil to process active dwg only. todoloc = 1 to process all components; 2 process components that have a blank location code; 3 process components subject to wild card match with "doloc" parameter. doloc = location code to include (if todoloc = 3). Can have wild cards per AutoCAD standards (for example "*CAB*" means any location with "CAB" substring). incl = what to include (0 = components, 1's bit = panels, 2's bit = connectors, 4's bit = panel terminal). suprs = suppress blank entries (0 = extract all, 1 = suppress blank TAG items, 2 = suppress blank MFG/items, 3 = suppress both 1 and 2). format = output file format "ASC" for ascii, "XLS" for Excel, "MDB" for Access, "CSV" for comma delimited "CSV+P" for comma delimited with project information first line of data. fields = 0 to output all fields; 1 = output only fields defined in default ".set" report settings file; = specify settings file to use (".set" extension is not required, double backslashes if path is given). outfilename = output file name, use single forward double backslashes in path. scriptfilename = optional script file name (execute report extraction is complete). The "outfilename" can be accessed from within the script file through the following AutoLISP expression: (vl-bb-ref 'FNAM).

Example 1

```
(c:wd_compr_pnlr (list 1 1 nil 3 0 "csv" 0 "report.csv" nil))
```

Example 2

```
(c:wd_compr_pnlr (list 1 1 nil 3 0 "asc" "d:\spcl\pnlcomp.set" "dat.out" nil))
```

Links

[Example 1](#), [Example 2](#), [Section H - Reports](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_compr_sch

[Example 1](#) [Example 2](#) [Example 3](#) [Section H - Reports](#) [Send Feedback](#)

Description

Cause schematic component report generation without any user prompts.

AutoLISP

(c:wd_compr_sch param_lst)

Parameters

Parameters	Description
param_lst	A "list" of ten elements: doall = 1 to process all dwgs in current project; nil to process current dwg only. todolocs = 1 to process all components; 2 process components that have a blank location code; 3 process components subject to wild card match with "doloc" parameter. doloc = location code to include (if todolocs=3). Can use wild cards per AutoCAD standard (for example, "*CAB" means any location with "CAB" substring). incl = what to include (nil = all, 1's bit = parent components, 2's bit = parent and child components, 4's bit = cable marker symbols, 8's bit = connector symbols). suprs = suppress blank entries (0 = extract all, 1 = suppress blank TAG items, 2 = suppress blank MFG/ITEM items, 3 = suppress both 1 and 2). format = output file format "ASC" for ascii, "XLS" for Excel, "MDB" for Access, "CSV" for comma delimited, "CSV+P" for comma delimited with project information first line of data. fields = 0 to output all fields; 1 = output only fields defined in default ".set" report settings file; = specify settings file to use (".set" extension is not required, double backslashes if path is given). outfilename = output file name, use single forward slashes in path. scriptfilename = optional script file name (execute report extraction is complete). The "outfilename" can be accessed from within the script file through the following AutoLISP expression: (vl-bb-ref 'FNAM). category = WDTYPE filter (nil or "" = schematic, "1-

Extract all parent/child components, cable markers, and connector symbols:

```
(command "_QSAVE")
(c:wd_compr_sch (list 1 1 nil nil 0 "csv" 0 "report.csv" nil))
```

Example 2

Extract parent components in locs "PNL1 thru PNL9" and output to ss format:

```
(c:wd_compr_sch (list 1 3 "PNL#" 1 0 "xls" 0 "dat.xls" nil))
```

Example 3

Extract parent schematic and one line components in locs "PNL1 thru PNL9" and output to ss format:

```
(c:wd_compr_sch (list 1 3 "PNL#" 1 0 "xls" 0 "dat.xls" nil "1-;\\""))
```

Module

[Section H - Reports](#)

Links

[Example 1](#), [Example 2](#), [Example 3](#), [Section H - Reports](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_connpin_rpt1
[Example 1](#) [Example 2](#) [Example 3](#) [Example 4](#) [Section H - Reports](#) [Send Feedback](#)

Description

Cause "Connector pin - Summary" report generation without any user prompts.

AutoLISP

```
(c:wd_connpin_rpt1 param_lst)
```

Parameters

Parameters	Description
param_lst	a "list" of ten elements: doall = nil to do active dwg only, 1 = process active project (see dlst parameter element). todo_locs = 1 to process all schematic connectors; 2

"*JBOX*" means any location with "JBOX" substring;
incl = (not used, set to "nil")
dlist = (ignore if doall = nil). nil = process all drawing project, otherwise do this list of drawings in the current project: (list "dwg1" "dwg2" ...). Full path not needed
format = output file format "ASC" for ascii, "XLS" for Excel, "MDB" for Access, "CSV" for comma delimited "CSV+P" for comma delimited with project information first line of data.
fields = 0 to output all fields; 1 = output only fields defined in default ".set" report settings file; = specify settings file to use ("set" extension is not required, double backslashes if path is given).
outfilename = output file name, use single forward double backslashes in path.
scriptfilename = optional script file name (execute report extraction is complete). The "outfilename" can be accessed from within the script file through the following AutoLISP expression: (vl-bb-ref 'FNAM).
category = WDTYPE filter (nil or "" = schematic, "1-line", etc.). Optional.

Example 1

```
(c:wd_connpin_rpt1 (list 1 3 "P-*" nil nil "csv" 0 "report.csv" nil))
```

Example 2

```
(c:wd_connpin_rpt1 (list 1 1 nil nil nil "asc" "d:\\spcl\\qts.set" "dat.out" nil))
```

Example 3

```
(c:wd_connpin_rpt1 (list 1 1 nil nil nil "asc" "d:\\spcl\\qts.set" "dat.out" nil "1-"))
```

Example 4

```
(c:wd_connpin_rpt1 (list 1 1 nil nil nil "asc" "d:\\spcl\\qts.set" "dat.out" nil "1-;\\\""))
```

Module

[Section H - Reports](#)

Links

[Example 1](#), [Example 2](#), [Example 3](#), [Example 4](#), [Section H - Reports](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

Description

Cause "Connector pin - Details" report generation without any user prompts.

AutoLISP

```
(c:wd_connpin_rpt2 param_lst)
```

Parameters

Parameters	Description
param_lst	a "list" of ten elements: doall = nil to do active dwg only, 1 = process active project (see dlst parameter element). todo_locs = 1 to process all schematic connector symbols; 2 process only those that have a blank loc code; 3 process those subject to wild card match with "doloc" parameter. doloc = location code to include (if todo_locs = 3). Have wild cards per AutoCAD standards (for example "*JBOX*" means any location with "JBOX" substring). incl = (not used, set to "nil") dlst = (ignore if doall = nil). nil = process all drawing project, otherwise do this list of drawings in the current project: (list "dwg1" "dwg2" ...). Full path not needed. format = output file format "ASC" for ascii, "XLS" for Excel, "MDB" for Access, "CSV" for comma delimited "CSV+P" for comma delimited with project information first line of data. fields = 0 to output all fields; 1 = output only fields defined in default ".set" report settings file; = specify settings file to use (".set" extension is not required, double backslashes if path is given). outfilename = output file name, use single forward double backslashes in path. scriptfilename = optional script file name (execute report extraction is complete). The "outfilename" can be accessed from within the script file through the following AutoLISP expression: (vl-bb-ref 'FNAM). category = WDTYPE filter (nil or "" = schematic, "1-line", etc.). Optional.

Example 1

```
(c:wd_connpin_rpt2 (list 1 3 "P-*" nil nil "csv" 0 "report.csv" nil))
```

Example 2

```
(c:wd_connpin_rpt2 (list 1 1 nil nil nil "asc" "d:\\spcl\\qts.set" "dat.out" nil))
```

Example 3

```
(c:wd_connpin_rpt2 (list 1 1 nil nil nil "asc" "d:\\spcl\\qts.set" "dat.out" nil "1-;\\\""))
```

Module

[Section H - Reports](#)

Links

[Example 1](#), [Example 2](#), [Example 3](#), [Example 4](#), [Section H - Reports](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_frm2_r

[Example 1](#) [Example 2](#) [Example 3](#) [Example 4](#) [Section H - Reports](#) [Send Feedback](#)

Description

Cause wire or cable from/to report generation without any user prompts.

AutoLISP

```
(c:wd_frm2_r param_lst)
```

Parameters

Parameters	Description
param_lst	A "list" of twelve elements: xtr = 1 to force a fresh extract of wire information, 0 to reuse wire extract data from the last run. when xtr = 0 then type and doall values are ignored type = 0 = Wire from/to, 1 = Cable conductor from/to options = nil if none, 1's bit set = Include reverse sequences in the output when use of "wire sequencing" results in a from/to wire connection that is the reverse of what is given in "frmlst" and "tolst". doall = nil to do current drawing only, 1 = all in project or (list "path/dwg1" "path/dwg2" ...) to process a specified list of drawings. frmlst = "list" of "from" location codes; for example "PNL1" "PNL2"). Wild cards are permitted. To enable location codes, use (list "*"). tolst = same as frmlst but "to" location codes. fut2 = (future) set to nil. format = output file format "ASC" for ascii, "CSV" for comma delimited ascii, "CSV+P" for comma delimited project information as first line of data, "XLS" for Excel, "MDB" for Microsoft Access. fields = 0 to output all fields; 1 = output only fields defined in default "set" report settings file.

report extraction is complete). The "outfilename" can be accessed from within the script file through the following AutoLISP variables: for AutoCAD Release 14 it is simply FNAM, for AutoCAD 2000 the report file name can be retrieved via the AutoLISP expression (vl-bb-ref 'FN/ **category** = WDTYPE filter (nil or "" = schematic, "1" = one-line, etc.). Optional.

Example 1

Fresh extract, wire from/to, proj-wide, from = PNL1, to = all locs, CSV ascii out, output all fields, output file "report.csv", no script file

```
(c:wd_frm2_r (list 1 0 nil 1 (list "PNL1") (list "") nil "csv" 0 "c:\\report.csv" nil))
```

Example 2

As above but from=CAB1 or CAB2, to = all locs, CSV ascii out, output fields in ".set", out file "report.csv", no script

```
(c:wd_frm2_r (list 1 0 nil 1 (list "CAB1" "CAB2") (list "") nil "csv" 1 "report.csv" nil))
```

Example 3

Fresh extract, wire from/to, proj-wide, from=P1, to=E01, include reverse sequences (i.e. from E01 to P1), CSV ascii out, output all fields, output file "report.csv", no script file

```
(c:wd_frm2_r (list 1 0 1 1 (list "P1") (list "E01") nil "csv" 0 "c:\\report.csv" nil))
```

Example 4

Fresh extract, wire from/to, proj-wide, from=PNL1, to=all locs, CSV ascii out, output all fields, output file "report.csv", script file, report on one line components

```
(c:wd_frm2_r (list 1 0 nil 1 (list "PNL1") (list "") nil "csv" 0 "c:\\report.csv" nil "1-"))
```

Module

[Section H - Reports](#)

Links

[Example 1](#), [Example 2](#), [Example 3](#), [Example 4](#), [Section H - Reports](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

c:wd_get_schem_tags_in_use

[Section H - Reports](#) [Send Feedback](#)

AutoLISP

```
(c:wd_get_schem_tags_in_use options)
```

Parameters

Parameters	Description
options	1 to process current dwg only, 2 = project-wide, 3 = wide with "Freshen".

Returns

(list (list tagname inst loc d1 d2 d3)(list tagname inst loc d1 d2 d3)(...))

Module

[Section H - Reports](#)

Links

[Section H - Reports](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

c:wd_getlocs
[Section H - Reports](#) [Send Feedback](#)

Description

For the active drawing only, this routine extracts directly from the entities currently in the drawing. For a project-wide this routine queries the active project's database file, tables "COMP", "PLCIO", and "TERM" for schematic and "PNLC" "PNLTERM" for panel. This routine does NOT refresh the database before doing the query. You may want to call (c:wd_mdb_freshen nil) if you're not sure whether the database file is fully in synch with the drawing set.

AutoLISP

```
(c:wd_getlocs param_lst)
```

Parameters

Parameters	Description
param lst	A list of four elements: doall = 1 to process all drawi

to a file.

Returns

List of codes.

Module

[Section H - Reports](#)

Links

[Section H - Reports](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_mark_get_initials
[Section H - Reports](#) [Send Feedback](#)

Description

Prompt for user initials and comments to be used in wd_mark_get_initials function parameters.

AutoLISP

```
(c:wd_mark_get_initials)
```

Returns

"cancel_flag" = nil if user DIDN'T cancel, = 1 if user did cancel.

Module

[Section H - Reports](#)

Links

[Section H - Reports](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
c:wd_mark_get_initials

Cause project-wide mark/verify with/without user prompts.

AutoLISP

```
(c:wd_mark_proj param_lst)
```

Parameters

Parameters	Description
param_lst	A "list" of seven elements: dowhat = 0 for MARK mode, 1 for VERIFY mode, 2 REMOVE mark info. mark_log = log file name, ""=defaults to "wdmark" initials = MARK mode: user initials to be saved and reported on VERIFY. comment1 = MARK mode: user comment1 reporter VERIFY. comment2 = MARK mode: user comment1 reporter VERIFY. comment3 = MARK mode: user comment1 reporter VERIFY. options = 1's bit do all proj dwgs set without prompt user to select dwgs, 2's bit set for MARK mode mark AutoCAD Electrical block inserts, 4's bit set for MARK mode: mark line wire entities, 8's bit set for VERIFY mode: suppress display of report at end.

Example

```
(c:wd_mark_proj (list 0 "" "NEH" "Sending to customer" "" "" 7))
```

Module

[Section H - Reports](#)

Links

[Example](#), [Section H - Reports](#)

Description

Cause schematic plug-in connection report generation without any user prompts.

Parameters

Parameters	Description
param_lst	A "list" of ten elements: doall = nil to do active drawing only, 1 = process ac project (see dlst parameter element). todo_locs = 1 to process all schematic connector symbols; 2 process only those that have a blank loca code; 3 process those subject to wild card match wit "doloc" parameter. doloc = location code to include (if todo_locs = 3). (have wild cards per AutoCAD standards (for example "*JBOX*" means any location with "JBOX" substring) incl = (not used, set to "nil"). dlst = (ignore if doall = nil). nil = do all drawings in project, otherwise do this list of dwgs in the current project (list "dwg1" "dwg2" ...). Full path not needed format = output file format "ASC" for ascii, "XLS" fo Excel, "MDB" for Access, "CSV" for comma delimited "CSV+P" for comma delimited with project informati first line of data. fields = 0 to output all fields; 1 = output only fields defined in default ".set" report settings file; = specifi settings file to use (".set" extension is not required, double backslashes if path is given). outfilename = output file name, use single forward double backslashes in path. scriptfilename = optional script file name (execute: report extraction is complete). The "outfilename" car accessed from within the script file through the follow AutoLISP expression: (vl-bb-ref 'FNAM). category = WDTYPE filter (nil or "" = schematic, "1-one-line, etc.). Optional.

Example 1

```
(c:wd_pjconn_r (list 1 1 "" nil nil "CSV" 0 "c:\\temp\\pj.csv" nil))
```

Example 2

```
(c:wd_pjconn_r (list 1 1 "" nil nil "CSV" 0 "c:\\temp\\pj.csv" nil "1-"))
```

Module

[Section H - Reports](#)

Links

[Example 1](#), [Example 2](#), [Section H - Reports](#)

Description

Cause schematic terminal numbers report generation without any user prompts.

AutoLISP

```
(c:wd_term_nums_rpt param_lst)
```

Parameters

Parameters	Description
param_lst	a "list" of nine elements: doall = nil to do active dwg only, 1 = process active project (see dlst parameter element). todo_locs = 1 to process all schematic terminal syn 2 process only those that have a blank location code process those subject to wild card match with "doloc parameter. doloc = location code to include (if todo_locs = 3). (have wild cards per AutoCAD standards (for example "*JBOX*" means any location with "JBOX" substring). incl = (not used, set to "nil") dlst = (ignore if doall = nil). nil = process all drawin project, otherwise do this list of drawings in the curr project: (list "dwg1" "dwg2" ...). Full path not neede format = output file format "ASC" for ascii, "XLS" fc Excel, "MDB" for Access, "CSV" for comma delimited "CSV+P" for comma delimited with project informati first line of data. fields = 0 to output all fields; 1 = output only fields defined in default ".set" report settings file; = specif settings file to use (".set" extension is not required, double backslashes if path is given). outfilename = output file name, use single forward double backslashes in path. scriptfilename = optional script file name (execute report extraction is complete). The "outfilename" car accessed from within the script file through the follow AutoLISP expression: (vl-bb-ref 'FNAM).

Example 1

```
(c:wd_term_nums_rpt (list 1 3 "JBOX2" nil nil "csv" 0 "report.csv" nil))
```

Example 2

```
(c:wd_term_nums_rpt (list 1 1 nil nil nil "asc" "d:\spcl\term.set" "dat.out" nil))
```

Module

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)