

AutoCAD Electrical 2025: AutoLISP Reference

Section K - XLS and MDB Tools

[Topics](#) [Send Feedback](#)

Description

Microsoft Access/Excel file read/write tools.

Remarks

AutoCAD Electrical includes some read/write/query API calls related to Microsoft Access database files and a limited capability to read/write Microsoft Excel format files.

Topics

Name	Description
wd_mdb_AddRecs	Add records to given table.
wd_mdb_Close	Close opened file.
wd_mdb_CloseAll	Close all opened mdb files.
wd_mdb_Create	Create new mdb file, overwrite any existing file.
wd_mdb_CreateTable	Create new table in opened or newly created mdb file, overwriting existing.
wd_mdb_DeleteRecs	Delete target records.
wd_mdb_GetFieldSpecs	Return list of field names, field type, field width values of specific table name.
wd_mdb_GetHandle	Get MS Access/Excel file handle.
wd_mdb_GetRecCount	Return number of records in table.
wd_mdb_GetRecs	Query target table and return matching records.
wd_mdb_GetTabNames	Return table names found in opened file.
wd_mdb_ModifyFieldData	Modify contents of one or more fields in the target record.
wd_mdb_Open	Open Excel or Access file for read/modify.
wd_oledb_command	Perform an SQL-type command on database file.
wd_oledb_delete	Delete selected records from table in database file.
wd_oledb_select	Perform an SQL-type query on database file.

Links

wd_mdb_AddRecs

Description

Add records to given table.

AutoLISP

```
(wd mdb AddRecs hdl tabnam reclst)
```

Parameters

Parameters	Description
hdl	File handle of opened file.
tabnam	Table name (for Excel, use "Sheet1\$").
reclst	(list (list (list fieldname1 fieldval)(list fieldname2 fieldval)...) (list fieldnameN fieldval))

Returns

T = success, nil = failure.

Example

This snippet of code creates a new file in Access format and adds records to a table.

```
(if (setq fname (getstring "Select MDB file to create: "))
  (progn
    (setq hdl (wd\_mdb\_GetHandle 1)) ; get next handle, MDB format
    (if hdl
      (progn
        (setq x (wd_dbase_CreateDatabase hdl fname 1))
        (princ x)
        (if x
          (progn
            (setq x nil)
            (setq tablename (getstring T "nTable name to create: "))
            (if (AND tablename (/= tablename ""))
              (progn
                (setq x (wd\_mdb\_CreateTable hdl tablename
                  (list
                    (list "FIELD_ONE" "S" 20) ; type = char string, field width = 20
                    (list "FIELD_TWO" "S" 40)
                    (list "FIELD_THREE" "S" 40)
                    (list "FIELD_FOUR" "S" 40)
                    (list "AUTONUM" "A" 0)) ; type = autonumber
                    1 ; overwrite
                  )
                )
              )
            (princ "\n table created = ")
          )
        )
      )
    )
  )
```

```
(list
  (list "FIELD_ONE" "APPLE") (list "FIELD_THREE" "BANANNA"))
(list
  (list "FIELD_ONE" "GRAPES") (list "FIELD_TWO" "TOMATO"))))
)
(princ "n records added = ")
(princ x) ; "T" if success
)
)
(wd_mdb_Close hdl)
(setq hdl nil)
)
)
)
```

Module

[Section K - XLS and MDB Tools](#)

Links

[Example](#), [Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference

wd_mdb_Close
[Section K - XLS and MDB Tools](#) [Send Feedback](#)

Description

Close opened file.

AutoLISP

```
(wd_mdb_Close hdl)
```

Parameters

Parameters	Description
hdl	File handle of opened file.

Returns

T = file closed, nil = failure or file was not open or invalid handle.

Module

[Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

wd_mdb_CloseAll

[Section K - XLS and MDB Tools](#) [Send Feedback](#)

Description

Close all opened mdb files.

AutoLISP

```
(wd_mdb_CloseAll)
```

Returns

T = success, nil = failure or no files open.

Module

[Section K - XLS and MDB Tools](#)

Links

[Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

wd_mdb_Create

[Section K - XLS and MDB Tools](#) [Send Feedback](#)

Description

Create new mdb file, overwrite any existing file.

AutoLISP

```
(wd_mdb_Create hdl fnam)
```

Parameters

fnam

mdb filename to create.

Returns

T = success, nil = failure.

Module

[Section K - XLS and MDB Tools](#)

Links

[Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
wd_mdb_CreateTable
[Section K - XLS and MDB Tools](#) [Send Feedback](#)

Description

Create new table in opened or newly created mdb file, overwriting existing.

AutoLISP

```
(wd_mdb_CreateTable hdl tabnam field_lst x)
```

Parameters

Parameters	Description
hdl	File handle returned by (wd_mdb_GetHandle 1).
tabnam	Table name to create.
field_lst	Table's field definition (list (list name typ width))(list where: name = field name. typ = "S" for character, "A" for autonumber. width = character width (use 0 for type "A").
x	1

Returns

T = success, nil = failure.

Links

[Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

wd_mdb_DeleteRecs

[Section K - XLS and MDB Tools](#) [Send Feedback](#)

Description

Delete target records.

AutoLISP

```
(wd_mdb_DeleteRecs hdl tabnam query)
```

Parameters

Parameters	Description
hdl	File handle of opened file.
tabnam	Table name (for Excel, use "Sheet1\$").
query	Query to specify target records.

Returns

T = success, nil = failure.

Module

[Section K - XLS and MDB Tools](#)

Links

[Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

wd_mdb_GetFieldSpecs

[Section K - XLS and MDB Tools](#) [Send Feedback](#)

Return list of field names, field type, field width values of specified table name.

AutoLISP

(wd_mdb_GetFieldSpecs hdl tabnam)

Parameters

Parameters	Description
hdl	File handle of opened file.
tabnam	Name of table to query.

Returns

(list (list fieldnam1 typ width)(fieldnam2 typ width)â€¦)

Module

[Section K - XLS and MDB Tools](#)

Links

[Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
wd_mdb_GetHandle
[Section K - XLS and MDB Tools](#) [Send Feedback](#)

Description

Get MS Access/Excel file handle.

AutoLISP

(wd_mdb_GetHandle typ)

Parameters

Parameters	Description
typ	1 for Access format (mdb). 2 for Excel format (xls).

Module

[Section K - XLS and MDB Tools](#)

Links

[Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

wd_mdb_GetRecCount

[Section K - XLS and MDB Tools](#) [Send Feedback](#)

Description

Return number of records in table.

AutoLISP

```
(wd_mdb_GetRecCount hdl tabnam)
```

Parameters

Parameters	Description
hdl	File handle of opened file.
tabnam	Name of table.

Module

[Section K - XLS and MDB Tools](#)

Links

[Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

wd_mdb_GetRecs

[Section K - XLS and MDB Tools](#) [Send Feedback](#)

AutoLISP

```
(wd_mdb_GetRecs hdl tabnam fields2rtrn query sortorder)
```

Parameters

Parameters	Description
hdl	File handle of opened mdb file.
tabnam	Name of table to query.
fields2rtrn	"" to return all fields or "fieldnam1,fieldnam2..." to r specific fields.
query	"" to return all records, non-blank to return records matching specific query.
sortorder	"" to return records in natural order or "fieldnam1,fieldnam2..." to return records sorted by given fields, left to right.

Returns

(list (list rec_data) (list rec_data) ...)

Module

[Section K - XLS and MDB Tools](#)

Links

[Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
wd_mdb_GetTabNames
[Example](#) [Section K - XLS and MDB Tools](#) [Send Feedback](#)

Description

Return table names found in opened file.

AutoLISP

```
(wd_mdb_GetTabNames hdl)
```

Parameters	Description
hdl	File handle of opened mdb file.

Returns

(list tablename1 tablename2â€¦) or nil if failure.

Example

This snippet of code shows opening a file in Access format and displaying the table names found in the file and ther dumping the table contents to the command window.

```
(defun c:mdb_read ( / ff hdl x lst tabnam fnam)
  (if (AND (mdb_chk_if_arx_loaded)
    (setq fnam (getfiled "Select MDB file to open and read" "" "MDB" 0)))
    (progn
      (setq hdl (wd\_mdb\_GetHandle 1)) ; get next handle, MDB format
      (if hdl
        (progn
          (if (wd\_mdb\_Open hdl fnam) ; open mdb file
            (progn
              (setq lst (wd\_mdb\_GetTabNames hdl)) ; get list of table names
              (princ "nTables found:")
              (princ lst)
              ; prompt to select table to query
              (setq tabnam (getstring T "nSelect table to query="))
              (if (AND tabnam (/= tabnam ""))
                (progn ; Dump list of fields in table
                  (setq lst (wd\_mdb\_GetFieldSpecs hdl tabnam)) ; get list of fields
                  (princ "nFields defined in table:")
                  (princ tabnam)
                  (princ "=")
                  (foreach x (car lst) (princ x) (princ ", "))
                  ; Get all records
                  (princ "nnRecord dump")
                  (setq lst (wd\_mdb\_GetRecs hdl tabnam "" "" ""))
                  (foreach rec lst
                    (princ "nn===RECORD===")
                    (foreach field rec
                      (princ "nfield=")
                      (princ (car field))
                      (Princ " value=")
                      (princ (cdr field))
                    )
                  )
                )
              )
            )
          )
          (princ)
        )
      )
    )
  )
)
```

Module

[Section K - XLS and MDB Tools](#)

Links

[Section K - XLS and MDB Tools](#)

Description

Modify contents of one or more fields in the target record.

AutoLISP

```
(wd_mdb_ModifyFieldData hdl tabnam query recdata)
```

Parameters

Parameters	Description
hdl	File handle of opened file.
tabnam	Table name (for Excel, use "Sheet1\$").
query	Query to specify target record (for example, use stri "CATALOG = '010344' AND STYLE = 'RED'" to specif target record with catalog field value '010344' and si field value 'RED').
recdata	(list (list fieldname1 fieldval)(list fieldname2 fieldval)

Returns

T = success, nil = failure.

Module

[Section K - XLS and MDB Tools](#)

Links

[Section K - XLS and MDB Tools](#)

Description

```
(wd_mdb_Open hdl fnam mode)
```

Parameters

Parameters	Description
hdl	File handle returned by (wd_mdb_GetHandle 1).
fnam	xls or mdb filename to open.
mode	(Excel only, not required for Access) Example: Excel 5.0;HDR=YES

Returns

1 = success, nil = failure.

Example

This example code opens a file in Excel format.

```
(if (setq fnam (readfile "Select XLS file to open and get" "" "XLS" 0))
(progn
  (setq hdl (wd\_mdb\_GetHandle 2)) ; get next handle, XLS format
  (if hdl
    (progn
      (setq x (wd_mdb_Open hdl fnam "Excel 5.0;HDR=YES"))
      (princ x)
      (if x
        (progn
          (setq lst (wd\_mdb\_GetTabNames hdl))
          (princ lst)
          (setq tabnam (getstring T "nSelect table to query (some might be empty)=") )
          (if (AND tabnam (/= tabnam ""))
            (progn ; Dump list of fields in table
              (setq lst (wd\_mdb\_GetFieldSpecs hdl tabnam))
              (if (not lst)
                (progn ; sometimes seems to take a $ suffix (?)
                  (setq tabnam (strcat tabnam "$"))
                  (setq lst (wd\_mdb\_GetFieldSpecs hdl tabnam))
                ))
              (princ "nFields defined in table ")
              (princ tabnam)
              (princ "n")
              (foreach x (car lst) (princ x)(princ "n"))
              ; Get all records
              (princ "nnRecord dump")
              (setq lst (wd\_mdb\_GetRecs hdl tabnam "" "" ""))
              (foreach x lst
                (princ "n***n")
                (princ "rec=")
                (princ x)
              )
            )))
      )))
  (wd\_mdb\_Close hdl)
  (setq hdl nil)
))))
```

Model 1

[Example](#), [Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

wd_oledb_command

[Example](#) [Section K - XLS and MDB Tools](#) [Send Feedback](#)

Description

Perform an SQL-type command on database file.

AutoLISP

```
(wd_oledb_command fnam query_str)
```

Parameters

Parameters	Description
fnam	Name of database file.
query_str	SQL command.

Example

Update field "CAT" in table "CR" for record number "x".

```
(if (setq cat_fnam GBL_wd_catmdb_fnam)
    (wd_oledb_command cat_fnam (strcat
    "UPDATE [CR] SET [CAT]='700AX' WHERE [RECNUM] ="
    (itoa x))))
```

Module

[Section K - XLS and MDB Tools](#)

Links

[Example](#), [Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)

AutoCAD Electrical 2025: AutoLISP Reference

wd_oledb_delete

Delete selected records from table in database file.

AutoLISP

```
(wd_oledb_delete fnam table query_str)
```

Parameters

Parameters	Description
fnam	Name of database file.
table	Name of table from which to delete records.
query_str	SQL select to identify records to delete. NOTE! If this argument is omitted, then ALL records are deleted.

Module

[Section K - XLS and MDB Tools](#)

Links

[Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.
What do you think about this topic? [Send feedback!](#)
AutoCAD Electrical 2025: AutoLISP Reference
wd_oledb_select
[Example](#) [Section K - XLS and MDB Tools](#) [Send Feedback](#)

Description

Perform an SQL-type query on database file.

AutoLISP

```
(wd_oledb_select fnam query_str)
```

Parameters

Parameters	Description
fnam	Name of database file.
querv str	SQL querv.

```
(setq fnam (c:wd_mdb_get_proj_scratch_dbnam nil)) ; nil=active project
(setq lst (wd_oledb_select fnam (strcat
  "SELECT TAGNAME,MFG,CAT,ASSYCODE FROM [COMP]"
  " WHERE PAR1_CHLD2='1' AND CAT <> ' ' AND"
  " FAMILY IN (\"CR\", \"TD\")"
  " ORDER BY MFG,CAT,ASSYCODE"))))
```

Module

[Section K - XLS and MDB Tools](#)

Links

[Example](#), [Section K - XLS and MDB Tools](#)

Copyright (c) Autodesk 2024. All rights reserved.

What do you think about this topic? [Send feedback!](#)