



Constant current driver AC class II wiring driver: constant current driver, 350mA




INSTALLATION SHEET

SLOT square

recessed LED steplight



IMPORTANT INSTRUCTIONS





location

- this product is suitable for
- **DRY INDOOR LOCATIONS ONLY**
- make sure this product is NOT on the same circuit as inductive loads, (e.g. fluorescent bulbs, discharge bulbs, ventilation fans, etc...)

safety

- Do not switch on line voltage until all wiring has been complete
- Incorrect wiring will result in irreparable damage to the LED and power supply
- This product should only be installed by a licensed electrician
- DO NOT CONNECT DIRECTLY TO LINE VOLTAGE

INSTALLATION

switch off the line voltage supply

- A Cut a hole according to dimension
- B Connect the LED to driver, driver to line voltage according to the drawing
- Flip the springs, put the fixture in place

WARRANTY

- This product must be installed in accordance with all applicable installation codes and ordinance
- Limited two (2) years warranty
- Warranty is void in the eventuality of unauthorized modifications and/or improper use

