#### **ASSEMBLIES**

## PART LIST


	QTY	DESCRIPTION	PART NO
A1	1	led module with bracket	see page 2

#### **PARTS**

Γ	A C		QTY	DESCRIPTION	PART NO
\ 	A2	P1	1	mounting cross arm (include for installation)	0117 TRIPAR
		P2	1	canopy	0395-20 TRIPAR
		P2a	2	Screws (for mounting cross arm to canopy) M4 10mm flat head	425-022 SPAENAUR B67
		P3	1	canopy plate	0162 TRIPAR
		P3	1	swivel 16x35mm	2065-1635-0101-3102 BENDLER
		P4	1	driver casing top plate	666-03-058-XX
		P5	1	driver bracket	666-02-067-00 or 666-02-067-02
		P6	1	driver	TBD
		P7	1	driver casing body	666-03-054-XX
		P8	1	driver casing bottom plate	666-03-053-XX
		P9	1	screws for cover #6-32 UNC 3/8"	HK358-359 SPAENAUR
	Р	10	2	nut M10	1110-0143-0101-2104 BENDLER
	Р	11	3	tooth lock washer	1345-0082-4444-2104 BENDLER
	Р	12	1	brass nipple (need to trim off 5mm from 20mm)	1732-1215-0101-3102 15mm

# LETO 16 canopy version page 1 of 2





www.sensolighting.com info@sensolighting.com T 403.216.7043 F 403.216.7045




#### **PARTS**

## PART LIST

)	PART N	DESCRIPTION	QTY	
2	XSA-21: B or C	heatsink	1	P13
	908002923 SPAENAU	set screw M3	1	P14
X	666-03-057-X	LED body	1	P15
_	2063-1636-0101-310 BENDLE	rotating joint	1	P16
	XSI XICAT	LED module	1	P17
7	388-25 SPAENAU B6	LED module mounting screw M3x0.5x20mm	3	P18
C	TB	reflector	1	P19
X	666-03-036-X	ring	1	P20
Ν	666-02-055-0 7340-01 BARO	(not shown) Tether Clip	1 1 1	P21
J5	2485-0102-1529-21			

LE1		16
	canopy v	ersion
	pag	ge 2 of 2

#### For XTM **DESCRIPTION PART NO** QTY XTM spacer XSA-271 1 XSA-244 1 ring adaptor LED module 388-252 3 mounting screws (without spacer) **SPAENAUR** M3x0.5x14mm **TBD** 1 reflector



### **MISCELLANEOUS**

DESCRIPTIO	QTY	
heat pas	2gr	
locktio	2gr	

P20