
# GPSS II User Guide

*2025. 06* 




## CONTENTS

User-Interface & Usage	3
Login System	3
Materials Menu	5
Materials Setup Page	5
Materials Registration Page	9
Materials Specification Page	11
Orders Menu	13
Cutting Plan Menu	16
Default Parameters Page	17
Reorganize Groups Page	19
Generate Plan Page	21



#### User-Interface & Usage

## **Login System**



The GPSS II system is web-based and can be accessed by entering its web address into a web browser. The recommended web browsers are Google Chrome and Microsoft Edge.


Upon accessing the GPSS II system, you will see the following login window. The initial account information is as follows:

Username: YOUR\_EMAIL

Password: YOUR PASS



#### **Navigation Pane**



Once you've logged in, you can navigate between pages using the menus in the navigation bar at the top. The system features three main menus, each with its own set of sub-menus:

#### Materials

- Materials Setup
- o Materials Registration
- o Materials Specification

#### Orders

o Orders Management


#### • Cutting Plan

- Default Parameters
- Reorganize Groups
- Generate Plan




#### **Materials Menu**

This page allows you to manage the materials required for generating cutting plans.



#### **Materials Setup Page**






On the **left table (Material List)**, you can generate **Material IDs**. These IDs are automatically assigned based on **Material Type** and **Length**.

You can then combine two Material IDs from the left table to create a **Spec ID** on the **right table** (Manufacturing-Spec. List). A Spec ID includes:


- The Material ID designated as the **Bearing-Bar**
- The Material ID designated as the Cross-Bar
- Bearing Bar Pitch
- Cross-Bar Pitch
- Saw Blade Thickness

To create a **Material ID** or generate a **Spec ID**, click the + **button** located at the bottom of each respective table.






You can input the necessary values by pressing the Enter key to move to the next field. Creation is automatic when you either click the Add button or press Enter after inputting the final value.




Similarly, when creating a **Spec ID**, you can define the necessary fields using the following modal window.

A Spec ID is generated based on the format: 'MS – {Bearing-Bar Material Type} – {Unique Identifier}'. The unique identifier is a 3-digit integer (e.g., '001'). This identifier increases each time you create a new Spec ID that shares the same Bearing-Bar but has at least one different value for the Cross-Bar, B-Pitch, C-Pitch, or Blade.





You can search for Material IDs or locate them manually to add them.




Just like creating, you can modify or delete a Material ID or Spec ID by clicking its




corresponding row. However, please note that modification and deletion are not possible if the Material ID or Spec ID is already registered in an order list or has been used to generate a cutting plan.

# **Materials Registration Page**




This page helps you manage the quantity and weight of each Material ID.






Similarly, you can add new items by clicking the + **button** at the bottom.





If you want to **modify or delete** a created item, you can do so by clicking its corresponding row, as shown in the image.

## **Materials Specification Page**



This page allows you to create Item Names, which are the standard for materials.



Here's an explanation of each button:




- Apply Changes: This button applies the changes made to your Item list. Your
  modifications won't be saved to the server until you click this button. It will only become
  active if there's at least one change.
- Add: Clicking this button adds a new cell to the table. Initially, the cell will be blank, and you can either type directly into it or import from a list.
- **Delete**: This button deletes the selected cell. It's disabled by default if no cell is selected.




When adding an item, fields with a **red border** (Material ID, End-bar, Item Type) can be selected from the modal window, while the remaining fields allow for direct input.





#### **Orders Menu**




This page allows you to manage your order list.






You can create, modify, or delete orders directly within the Orders list table.






The Task Number is automatically generated. It follows the format 'YYYMMDD-T-{2-digit integer}'. The 2-digit integer increments by one for each order were created on the same day.





If you want to modify or delete an order, simply click on its row to proceed with the changes or removal. However, please note that modification and deletion are not possible if a cutting plan has already been generated for that order.


## **Cutting Plan Menu**




This page allows you to add and group item lists to orders for cutting plan generation. You can also create cutting plans and view work orders here.



#### **Default Parameters Page**




This page features two lists. The **Order List** (top table) displays the orders you've created. From here, you can also generate a **BOM File** for bulk upload or download the currently saved BOM as an Excel file. The **Item List** (bottom table), identified by its Task Number, allows you to add or delete detailed items for the selected order.





- Create BOM: You can create an **Excel template for bulk uploads**. This template allows you to specify the **Spec ID** and **EndBar type**.
- BOM Export : You can download the **currently generated orders** in an Excel format.




After downloading the Excel file, you can input your desired data into it and then **bulk upload** it using the bottom table.



- Apply: Applies all changes.



- Upload BOM: Uploads the Bill of Materials you previously created.
- Add: Adds a single item.
- Delete: Deletes the selected item.
- Delete All: Deletes all items within the current order.




If you want to modify an item, you can either double-click the cell or press Enter.

# **Reorganize Groups Page**

This page allows you to merge or split items within an order based on their Drawing Number.





You can select multiple items with the same **Drawing Number** by holding **Ctrl** and clicking.


When selected, the rows will alternate between green and yellow.



- Bulk Change All: Changes the Spec ID for all items in the current order.
- Bulk Change Group: Changes the Spec ID for the selected groups.
- Merge: Combines the selected groups into a single group.
- **Split**: Restores merged groups back to their original, individual states.



### **Generate Plan Page**




This page allows you to generate cutting plans for orders.





The top-left table displays your current orders.


- **Generate Plan**: This creates a cutting plan for the currently selected order. This process will take longer with a higher number of assigned items and generated groups.
- View Past Plan: You can view previously created cutting plans here.
- Change Settings: This allows you to modify the options for generating cutting plans.





	Group Number	Even Percentage(%)	Item Name	SpecID	Compression Setting	Base Length	+L Adjustment	-l Adjust
1	G-20250410-02-001	63.6	Steel Grating	MS-SE0320050-004	2-Optimized	50	3	-3
2	G-20250410-02-002	64.3	Steel Grating	MS-SE0320050-004	2-Optimized	50	3	-3
3	G-20250410-02-003	70.9	Steel Grating	MS-SE0320050-004	2-Optimized	50	3	-3
4	G-20250410-02-004	71.7	Steel Grating	MS-SE0320050-004	2-Optimized	50	3	-3
5	G-20250410-02-005	86.7	Steel Grating	MS-SE0320050-004	2-Optimized	50	3	-3
6	G-20250410-02-006	91.7	Steel Grating	MS-SE0320050-004	2-Optimized	50	3	-3
7	G-20250410-02-007	94.1	Steel Grating	MS-SE0320050-004	2-Optimized	50	3	-3

The top-right table allows you to **change the Spec ID by group**. This enables you to compare with **Past Plans** to see which Spec ID results in less material loss.






The **Spec IDs** you can select here must share the same **BB code** and **CB code**, but can have different lengths.



The bottom table displays the **generated cutting plan**. When you click on a group, two buttons will become active:

• View Item Placement (Work Order Form): This opens the work order form for the selected group in a new window.



• View Details: This allows you to view the layout of the selected group in 3D.



Plate No.: P001




Plate No.: P002



Plate No.: P003



