

## Wireless Security

Prof. Marco Mellia Dr. Andrea Nardin

### Course Outline

- Course Outline
  - ► Review of basic concepts for digital communications
  - Security at the physical layer
  - ► Global Navigation Satellite Systems (GNSS) and positioning
  - Security in WiFi Networks
  - ► Bluetooth security
  - ► Security of Cellular Networks 3G/4G/5G Network Structure and Architectures
  - Security of Near Field Communications (NFCs) and RFIDs

# Basic Concepts for Digital Communications

Andrea Nardin


### Contents

- Review of basic concepts for digital communications
  - ► Introduction
  - Digital Communications Overview
  - Signals Representation and Processing
    - ► Signal representation
    - ▶ Frequency domain, filters, modulation
    - ▶ Sampling Theorem and Discrete Time Signals
  - Signals Transmission and Reception
    - ► Digital Modulations
    - ► AWGN channel and equalization
    - Received symbols and decision regions
    - ► Link Budget
    - ► Multiplexing / Multiple Access schemes (FDM/A, TDM/A, CDM/A)
    - Source and channel coding


### Contents

- Review of basic concepts for digital communications
  - **▶** Introduction
  - Digital Communications Overview
  - Signals Representation and Processing
    - ► Signal representation
    - ▶ Frequency domain, filters, modulation
    - ▶ Sampling Theorem and Discrete Time Signals
  - ► Signals Transmission and Reception
    - ► Digital Modulations
    - ► AWGN channel and equalization
    - Received symbols and decision regions
    - ► Link Budget
    - ► Multiplexing / Multiple Access schemes (FDM/A, TDM/A, CDM/A)
    - Source and channel coding


- The main study area of this part of the course is **security** at the **physical layer**
- ► The physical layer defines the means of transmitting a stream of raw bits over a physical data link connecting network nodes
- The bitstream may be grouped into code words or symbols and converted to a physical signal that is transmitted over a transmission medium
- When signals are transmitted over the wireless channel, security is more of a concern




- When signals are transmitted over the wireless channel, security is more of a concern
- ► Why?
  - ▶ No inherent physical protection
    - physical connections between devices are replaced by logical associations
    - sending and receiving messages do not need physical access to the network infrastructure (cables, hubs, routers, etc.)




- When signals are transmitted over the wireless channel, security is more of a concern
- ► Why?
  - Broadcast communications
    - wireless usually means radio, which has a broadcast nature
    - transmissions can be overheard by anyone in range
    - ▶ anyone can generate transmissions
      - received by other devices in range
      - interfere with other nearby transmissions and may prevent their correct reception (jamming)



- When signals are transmitted over the wireless channel, security is more of a concern
- As a result:
  - eavesdropping is easy
  - injecting bogus messages into the network is easy
  - replaying previously recorded messages is easy (e.g. meaconing)
  - illegitimate access to the network and its services is easy
  - denial of service is easily achieved by jamming



- When signals are transmitted over the wireless channel, security is more of a concern
- ► To understand threats and identify countermeasures we must first dwell on the working principles of digital communications




This will be our «reference map»

### Contents


- Review of basic concepts for digital communications
  - ► Introduction
  - Digital Communications Overview
  - ► Signals Representation and Processing
    - ► Signal representation
    - ▶ Frequency domain, filters, modulation
    - ▶ Sampling Theorem and Discrete Time Signals
  - ► Signals Transmission and Reception
    - ► Digital Modulations
    - ► AWGN channel and equalization
    - Received symbols and decision regions
    - ► Link Budget
    - ► Multiplexing / Multiple Access schemes (FDM/A, TDM/A, CDM/A)
    - Source and channel coding

### Digital Communication System: Overview

- ► To avoid getting lost on the working principles of **digital communications**, it is useful to characterize the general model of a digital communication system
- The model can be divided into three sections:
  - ▶ The user section
  - The interface section
  - The channel section




### Digital Communication System: Overview



### Digital Communication System: TX chain

- Encoder
  - ► Implements source encoding to limit the amount of transmitted data
  - Implements channel encoding to limit the effects of channel disturbances
- Modulator
  - ► Converts the digital signal into an analog signal to be transmitted over the channel




user section

### Digital Communication System: Channel

### Channel

- ► The channel transfers an analog signal from the transmitter to the receiver.
- Its operation is affected by different types of disturbances such as:
  - ► frequency-domain distortion
  - wireless fading
  - additive noise
  - impulsive noise
  - ▶ interference from other frequency channels (interchannel interference)
  - ▶ interference from the same frequency channel (cochannel interference)
  - ▶ Intentional interference



interface section

channel section

user section


### Digital Communication System: RX chain

#### Demodulator

Converts the received analog signal into a sequence of samples to be processed by the decoder

### Decoder

- Implements channel decoding to limit the effect of channel errors and extract the information data
- ► Implements **source decoding** to expand the compressed data back to their original form




### Contents

- Review of basic concepts for digital communications
  - ► Introduction
  - Digital Communications Overview
  - Signals Representation and Processing
    - ► <u>Signal representation</u>
    - ▶ Frequency domain, filters, modulation
    - ▶ Sampling Theorem and Discrete Time Signals
  - ► Signals Transmission and Reception
    - Digital Modulations
    - ► AWGN channel and equalization
    - Received symbols and decision regions
    - ► Link Budget
    - ► Multiplexing / Multiple Access schemes (FDM/A, TDM/A, CDM/A)
    - Source and channel coding

### Signal Representation and Processing

- A signal is a function that conveys information about a phenomenon [1]
- Any quantity that can vary over space or time can be used as a signal to share messages between observers [2]




<sup>[1]</sup> Roland Priemer (1991). Introductory Signal Processing. World Scientific. p. 1. ISBN 978-9971509194

<sup>[2]</sup> Chakravorty, Pragnan (2018). "What Is a Signal? [Lecture Notes]". IEEE Signal Processing Magazine. 35 (5): 175-177. doi:10.1109/MSP.2018.2832195.

### What is a Signal?


- ► A signal describes the evolution of physical quantities over **time** (voltages, currents, temperatures, etc.)
- ► Its mathematical representation is therefore a **function of real variable** (time) taking **real** or **complex** values



## What is a Signal?

► We will be mostly focused on **Electromagnetic Signals** (e.g. voltage), but the general concepts can be applied to any kind of signal






### Energy of a Signal

▶ The energy of a signal is the integral of the squared modulus of the signal itself

$$E(x) \triangleq \int_{-\infty}^{\infty} |x(t)|^2 dt$$



### Power of a Signal

- Instantaneous power
  - ▶ It is a function of time that coincides with the squared module of the signal

$$P_{ist}(t) = \left| x(t) \right|^2$$

- Power (average)
  - ► Time average of the instantaneous power
  - ▶ We refer to this when we talk about power


$$P(x) \triangleq \lim_{a \to \infty} \frac{1}{2a} \int_{-a}^{a} |x(t)|^{2} dt$$

Remark: Eenrgy and Average Power are associated with a real scalar number

### Physical interpretation: resistor

- ► These concepts are related to the dual concepts seen in electronics classes
- Aside from a proportionality constant R, the previous definitions coincide with the physical definitions of power and energy

## Voltage f(t) = v(t) $R = 1\Omega$ $P_{ist}(t) = \frac{v^2(t)}{R}$



### Signals Representation

- To analyze and process the signals, it is necessary to adequately represent them
- The definition of signals as "time functions" is NOT effective for many applications
- A signal can be represented as a sum of elementary signals
  - ▶ Thanks to the *scalar product* between signals

$$\langle \mathbf{x}, \mathbf{y} \rangle = \langle x(t), y(t) \rangle \triangleq \int_{-\infty}^{\infty} x(t) y^*(t) dt$$

Given a complete orthonormal basis for the signal x(t)

$$w_1(t)$$
  $w_2(t)$   $\cdots$   $w_M(t)$ 

We can write the signal as a linear combination of basis functions


$$x(t) = \sum_{i=1}^{M} \alpha_i w_i(t) \quad where: \quad \alpha_i = \langle x(t), w_i(t) \rangle = \int_{-\infty}^{+\infty} x(t) \cdot w_i^*(t) dt$$

- This concept can be used
  - To associate signals with **vectors coefficients** (basis, modulations)  $\mathbf{x} = (\alpha_1, \alpha_2, ..., \alpha_M)$
  - To associate signals with **frequency components** (spectral analysis)

- The scalar product associates a (complex)
- It is a measure of "similarity" among signals
- Two signals with zero scalar product are said to be orthogonal

### Signals Representation: I/Q Representation

- ► To associate signals with **vectors coefficients** (basis, modulations)
- Some basis are more important than others in practical applications:
  - $w_1(t) = \cos(2\pi f_0 t)$  or In-phase
  - $w_2(t) = \sin(2\pi f_0 t)$  or Quadrature phase



### Contents

- Review of basic concepts for digital communications
  - ► Introduction
  - Digital Communications Overview
  - Signals Representation and Processing
    - ► Signal representation
    - ► Frequency domain, filters, modulation
    - ▶ Sampling Theorem and Discrete Time Signals
  - ► Signals Transmission and Reception
    - Digital Modulations
    - ► AWGN channel and equalization
    - Received symbols and decision regions
    - ► Link Budget
    - Multiplexing / Multiple Access schemes (FDM/A, TDM/A, CDM/A)
    - Source and channel coding

### The Fourier Analysis

#### Euler's formula

- $e^{j2\pi\frac{n}{T}t} = \cos 2\pi\frac{n}{T}t + j\sin 2\pi\frac{n}{T}t$ Let's consider the complex exponential
  - ▶ Made by complex sinusoidal signals with frequency  $f_n = n/T$ .
- It can be shown that this infinite set of functions


$$w_n(t) = \frac{1}{\sqrt{T}} e^{j\frac{2\pi}{T}nt} - T/2 \le t \le T/2$$

Is a complete basis for all the signals limited in [-T/2,T/2] or periodic, i.e.


$$x(t) = \frac{1}{\sqrt{T}} \sum_{n=-\infty}^{\infty} c_n e^{j\frac{2\pi}{T}nt}$$

$$c_n = \frac{1}{\sqrt{T}} \int_{-T/2}^{T/2} x(t) e^{-j\frac{2\pi}{T}nt} dt = \left\langle x(t), w_n(t) \right\rangle \qquad -\frac{T}{2} \le t \le \frac{T}{2}$$

Each coefficient  $c_n$  tells, for each frequency  $f_n$  of the n-th sinusoid, how much it "counts" in the signal x(t)







### The Fourier Analysis (cont'd)


 $\blacktriangleright$  Extending the concept to **any signal** we get the *Fourier transform* of x(t)


$$X(f) = \int_{-\infty}^{\infty} x(t)e^{-j2\pi ft} dt$$

And its inverse

$$x(t) = \int_{-\infty}^{\infty} X(f)e^{j2\pi ft} df$$


- X(f) indicates the "weight" (complex) of the **sinusoidal component** (complex) at frequency f for the generic signal x(t)
- The inverse F.t. tells us that we can decompose any signal into sinusoidal components at a given frequency *f*
- Important observations:
  - For each signal, we have a «*spectral*» representation (spectral analysis)
  - For each operation over a signal, there are equivalent **effects in the frequency domain**
  - Finite duration signals have infinite support in the frequency domain






### Bandwidth

- ▶ The bandwidth (or simply band) is the interval of frequencies occupied by a signal
- ► The definition of bandwidth as the support of the Fourier Transform of the signal is too restrictive.
  - Signals have often infinite support in frequency domain
  - ▶ But many systems are characterized by quasi-null frequency spectrum out of the main lobes
- ▶ Different definitions can be used but the most popular are related to the square of the modulus  $|X(f)|^2$ 
  - ► E.g. 3dB Bandwidth




One-sided 3dB Bandwidth



Two-sided 3dB Bandwidth


### Bandwidth in Linear Systems


- ► The relationship between the bandwidth of the input signal and the bandwidth of a system is usually very important
- A set of operations applied to signals can be modeled as a *system* 
  - ▶ When a system is used to pass/remove particular frequencies of a signal, it can be regarded as a *filter*




- Linear time-invariant systems (LTI) are modeled by a frequency response H(f)
  - And we have that Y(f) = X(f)H(f)

Input bandwidth is narrower than system bandwidth






Input bandwidth is wider than system bandwidth




### **Filters**

- > Systems/filters can be used to model desired and undesired effects over signals
  - Process the signals to obtain desired features
  - Model channel effects




## An example from the GPS world


► A GPS satellite generates, approximately, the following timedomain waveform to be broadcasted



- ► Thanks to the Fourier transform and its properties, we know which are the strongest **frequency components** of the signal
- We get, approximately, this equivalent representation




**Time-domain representation** 



Frequency-domain representation


### An important property: Signal Modulation


Multiplying a signal by a sinusoidal function, results in a frequency shift



$$y(t) = x(t)\cos(2\pi f_0 t)$$


$$\mathcal{F}(x(t)\cos(2\pi f_0 t)) = \frac{1}{2} [X(f - f_0) + X(f + f_0)]$$






### Signal Modulation: Example

Sine wave modulated by a GPS signal




$$y(t) = x(t)\cos(2\pi f_0 t)$$

$$\mathcal{F}(x(t)\cos(2\pi f_0 t)) = \frac{1}{2}[X(f - f_0) + X(f + f_0)]$$




This result is FUNDAMENTAL for most wireless modulations to move the spectral content of the original signal to the most appropriate frequency band





How to go back to the original signal?

### Signal Demodulation

- ▶ When received, the signal can be recovered by
  - multiplying it for a sinusoid at the same frequency
  - Low pass filtering










### Signal Demodulation

- ▶ When received, the signal can be recovered by
  - multiplying it for a sinusoid at the same frequency
  - Low pass filtering








### Frequency multiplexing (FDM)

- Different signals with overlapping bandwidths can be **frequency-modulated** in different portions of the spectrum.
- Once they are received they can be de-multiplexed withouth distortions.



## 0-300 GHz Spectrum Allocation

https://upload.wikimedia.org/wikipedia/commons/c/c7/United\_States Frequency
Allocations Chart 2016 - The Radio Spectrum.pdf



### Contents


- Review of basic concepts for digital communications
  - ► Introduction
  - Digital Communications Overview
  - Signals Representation and Processing
    - ► Signal representation
    - ▶ Frequency domain, filters, modulation
    - Sampling Theorem and Discrete Time Signals
  - ► Signals Transmission and Reception
    - Digital Modulations
    - AWGN channel and equalization
    - ► Received symbols and decision regions
    - ► Link Budget
    - Multiplexing / Multiple Access schemes (FDM/A, TDM/A, CDM/A)
    - Source and channel coding

### Source of information

- ▶ We have now acquired some tools to deal with signals. How do we use them?
- Which kind of information do we need to transmit?
  - Analog
  - Digital
- Digital signals allow for more sophisticated processing methods

user section

- error detection and correction, data compression, etc.
- How to convert an analog signal in a numerical signal?



interface section


**Bits** 

channel section

...001101010100...


42

### **Analog-to-Digital Conversion**



### Sampling theorem

Nyquist Theorem: A continuous time signal can be sampled and perfectly reconstructed from its samples if the sampling frequency is greater than twice the "band" of the signal.



### Sampling theorem

Nyquist Theorem: A continuous time signal can be sampled and perfectly reconstructed from its samples if the sampling frequency is greater than twice the "band" of the signal.

$$f_c \triangleq \frac{1}{T_c} > 2B \rightarrow T_c < \frac{1}{2B}$$

 $\boldsymbol{B}$  is the one-side bandwidth of the analog signal.

