# Neuromorphic Engineering I INI-404 227-1033-00

Material courtesy of Elisabetta Chicca Bielefeld University, Germany

> Institute of Neuroinformatics University of Zurich and ETH Zurich

Zurich, 2013/2014 Fall Semester

Giacomo Indiveri (INI)

institute of neuroinformatics

University of Signal State

# Solids

**Energy bands** 

In a solid the forces of attraction and repulsion between atoms affect the electron energy levels.

An energetic balance is found at the proper inter-atomic spacing for the crystal.


The electronic energy levels form continuous bands of energies.

#### Isolated atoms



Hydrogen Energy Levels

#### Electron in atoms have quantized energy levels




Source: http://hyperphysics.phy-astr.gsu.edu/hbase/hyde.html

Giacomo Indiveri (INI)

institute of neuroinformatics



# Metals, semiconductors and insulators Energy bands



Giacomo Indiveri (INI)

institute of neuroinformatics

Giacomo Indiveri (INI)

institute of neuroinformatics

#### Metals, semiconductors and insulators

Energy bands





Energy bands



At 0 K the electrons occupy the lowest energy states available, every state in the valence band is filled and the conduction band is empty.

Current flow in solids: an applied electric field can generate current flow only if electrons can move into new energy states. There must be empty states available to the electrons.

Giacomo Indiveri (INI)

**Insulators**: at 0 K the valence band is completely filled and the conductance band is completely empty. No charge transport can take place in either bands.

**Semiconductors**: at 0 K semiconductors are equivalent to insulators. The size of the band gap  $E_q$  is much smaller in semiconductors (e.g. 1.1 eV for silicon (Si), 5 eV for diamond (C)).

Metals: the energy bands overlap, thus electrons and empty energy states are intermixed. At 0 K an applied electric field can generate current flow (electrons can move freely).

Giacomo Indiveri (INI)

institute of neuroinformatics

### Metals, semiconductors and insulators

Energy bands



# Electrons and holes


University of Zurichuzh

thermal energy allows electrons in the valence band to be excited across the band gap to the Room temperature conduction band.

These electrons leave unoccupied states in the valence band (called holes).

In semiconductors, at room temperature,

This process generates the so called Electron-Hole Pairs (EHPs).



In semiconductors (materials with small band gap  $E_a$ ) the number of electrons available for conduction is significantly increased by thermal energy. This number is negligible in insulators (materials with big band gap  $E_a$ ).

Giacomo Indiveri (INI)


Giacomo Indiveri (INI)

# Electrons and holes (free charges)





Electrons in the conduction band are surrounded by a large number of unoccupied energy states (e.g.: pure Si at room temperature: 10<sup>10</sup> EHP/cm<sup>3</sup>, 10<sup>22</sup> atoms/cm<sup>3</sup>). These unoccupied energy states allow the few electrons in the conductance band to move freely. Similarly, holes in the valence band can move and generate a current flow of positive charges.



Giacomo Indiveri (INI)

Neuromorphic Engineering


institute of neuroinformatics

11 / 62

# Intrinsic semiconductors








The free electron and the hole are spread out over several lattice spacing (not as depicted in the figure), as predicted by quantum mechanics.

Electrons concentration in the conductance band

n = electrons per cm<sup>3</sup> Holes concentration in the valence band p = holes per cm<sup>3</sup> Intrinsic carrier concentration

$$n_i = n = p$$




#### Intrinsic semiconductors





Intrinsic semiconductor: perfect crystal of semiconductor material with no impurities or defects.

At 0 K there are no free electron-hole pairs, therefore no charge carriers are available. Si valence electrons are constrained in covalent bonds<sup>1</sup> of the crystal lattice. The energy required to break a covalent bond is the band gap energy  $E_g$ .



<sup>1</sup> Chemical bond formed by the sharing of one or more electrons, especially pairs of electrons, between atoms.

Giacomo Indiveri (INI)

Neuromorphic Engineering

institute of neuroinformatics

10 / 0

#### Extrinsic semiconductors





Extrinsic or *doped* materials are created by purposely introducing impurities into the crystal. Impurities can generate extrinsic negative or positive charge carriers.

Donor impurities: atoms with more valence electrons than intrinsic atoms. The extra electrons require very little thermal energy to be excited to the conductance band.

Acceptor impurities: atoms with less valence electrons than intrinsic atoms.


The missing electrons are recruited from the valence band of intrinsic atoms, creating holes in the intrinsic semiconductor.

#### Extrinsic semiconductors

University of Sopreticine

*n*-type materials

Donor atoms for Silicon and Germanium (4 electrons) are Phosphorus and Arsenic (5 electrons).



#### Distribution of electrons





Fermi-Dirac distribution function

The distribution of electrons at thermal equilibrium is

$$f(E) = \frac{1}{1 + e^{(E - E_F)/kT}}$$


f(E) is the probability that an energy state with energy E is occupied by an electron at absolute temperature T. k is the Boltzmann's constant  $(k = 8.62 \times 10^{-5} eV/K)$  and  $E_F$  is the Fermi level. Independently of the absolute temperature, the probability of occupancy of an energy state at the Fermi level is 1/2.

#### Extrinsic semiconductors



p-type materials

Acceptor atoms for Silicon and Germanium (4 electrons) are Boron and Aluminium (3 electrons).



#### Concentration of electrons



The electrons concentration in the conduction band is given by the integral, over the range of energies accessible by electrons, of the density of states at energy E, weighted by the probability f(E) for an electron to have this given energy:

$$n_0 = \int_{E_C}^{\infty} f(E) N(E) dE$$

N(E)dE ( $cm^{-3}$ ) is the density of states in the energy range dE.

The density of states in the conduction band can be derived using the three dimensional Schrödinger equation for a free electron, with the addition of a set of periodic boundary conditions representing the crystal lattice (see Streetman 1995, appendix IV). The subscript 0 in  $n_0$  is used to indicate equilibrium conditions.

Given that f(E) tends to zero for large energies, f(E)N(E) decreases rapidally above  $E_C$ .

Giacomo Indiveri (INI)

institute of neuroinformatics





Derivation

$$f(E) \approx \mathrm{e}^{(E_F - E)/kT} \; \; \text{for} \; (E - E_F) > 3kT, \; \; N_C(E) = \frac{1}{2\pi^2} \left(\frac{2m_c}{\hbar^2}\right)^{3/2} \sqrt{E - E_C}$$

where  $m_c$  is the effective mass of the electron in the crystal and  $\hbar = h/2\pi$  is the normalized Plank constant ( $h = 6.626 \cdot 10^{-34} Js$ ).

$$n_0 = \int_{E_C}^{\infty} N_C(E) f(E) dE = \int_{E_C}^{\infty} N_C(E) \cdot e^{\frac{E_F - E}{kT}} dE = \int_{E_C}^{\infty} N_C(E) \cdot e^{-\frac{E - E_C}{kT}} e^{-\frac{E_C - E_F}{kT}} dE$$


$$n_0 = N_C \cdot e^{-\frac{E_C - E_F}{kT}}$$

where  $N_C = \int_{E_C}^{\infty} N_C(E) \cdot e^{-\frac{E-E_C}{kT}} dE$  is the *effective densities of states*.

Giacomo Indiveri (INI)

# The product $n_0 p_0$





$$n_0 p_0 = N_C \cdot e^{-\frac{E_C - E_F}{kT}} N_V \cdot e^{\frac{E_V - E_F}{kT}} = N_C N_V e^{-\frac{E_C - E_V}{kT}} = N_C N_V e^{-\frac{E_G}{kT}}$$

Intrinsic carriers are created in pairs (by thermal energy), so their concentrations  $n_i = N_C e^{-(E_C - E_i)/kT}$  and  $p_i = N_V e^{(E_V - E_i)/kT}$  (where  $E_i$  is the intrinsic Fermi level) are equal. Given that  $n_i p_i = N_C N_V e^{-E_g/kT}$ , we can write the intrinsic concentration as

$$n_i = \sqrt{N_C N_V} e^{-\frac{E_g}{2kT}}$$

which leads to

$$n_0 p_0 = n_i^2, n_0 = n_i \cdot e^{\frac{E_f - E_i}{kT}}, p_0 = n_i \cdot e^{\frac{E_i - E_f}{kT}}$$

#### Concentration of holes



# Derivation

$$1 - f(E) \approx e^{-(E_F - E)/kT} \text{ for } (E_F - E) > 3kT, \ \ N_V(E) = \frac{1}{2\pi^2} \left(\frac{2m_c}{\hbar^2}\right)^{3/2} \sqrt{E_V - E}$$

where  $m_V$  is the effective mass of the hole in the crystal and  $\hbar = h/2\pi$  is the normalized Plank constant ( $h = 6.626 \cdot 10^{-34} Js$ ).

$$p_0 = \int_{-\infty}^{E_V} N_V(E) (1 - F(E)) dE = \int_{-\infty}^{E_V} N_V(E) \cdot e^{-\frac{E_F - E}{kT}} e^{\frac{E_V - E_V}{kT}}$$

$$p_0 = N_V \cdot e^{\frac{E_V - E_F}{kT}}$$

where  $N_V = \int_{-\infty}^{E_V} N_V(E) \cdot e^{\frac{E-E_V}{kT}} dE$  is the effective densities of states.

Giacomo Indiveri (INI)

Giacomo Indiveri (INI)


#### Extrinsic semiconductors






Fermi level and carrier concentrations

For 
$$N_d\gg n_i$$
 and  $N_a=0$ ,  $n_0\simeq N_d$  and  $p_0\simeq rac{p_i^2}{N_d}$ 



For  $N_a \gg p_i$  and  $N_d = 0$ ,  $p_0 \simeq N_a$  and  $n_0 \simeq \frac{n_i^2}{N_i}$ 



#### Extrinsic semiconductors






Compensation

Example:  $N_a > N_d > 0$ , this is a p-type material (more holes than electrons. Fermi level in the lower part of the band gap). All free electrons created by donors recombine with holes created by acceptors. The resultant holes concentration is therefore  $N_a - N_d$ . This process is called *compensation*.

Space charge neutrality:  $p_0 + N_d^+ = n_0 + N_a^-$ 

 $p_0 = n_0 + (N_a^- - N_d^+) \simeq N_a - N_d$ , if the material is p-doped  $(N_a > N_d)$  and all impurities are ionized  $(N_a^- = N_a \text{ and } N_d^+ = N_d).$ 



Giacomo Indiveri (INI)

#### Drift of carriers in electric field





Collisions' effect on momentum and equilibrium

At steady state, the acceleration provided by the electric field is balanced by decelerations due to collisions. The differential change in momentum due to collisions is

$$dp_x = -p_x \frac{dt}{\overline{t}} \rightarrow \frac{dp_x}{dt} = -\frac{p_x}{\overline{t}}$$

where  $\bar{t}$  is the *mean free time* (mean time between two collisions).

At steady state the changes of momentum due to the electric field and collisions must balance:

$$-nq\mathscr{E}_{x}-\frac{p_{x}}{\overline{t}}=0$$

We can therefore express the average momentum per electron  $\langle p_x \rangle$  as

$$\langle p_{x} \rangle = \frac{p_{x}}{n} = -q\bar{t}\mathscr{E}_{x}$$

#### Drift of carriers in electric field



Electric field's effect on momentum

When an electric field is applied to a semiconductor a *drift* of carriers is generated, thus producing a current flow. Two important quantities are needed to calculate the current flow: carrier concentrations and mobilities.

Free charges in semiconductors are subject to collisions with the lattice and the impurities. These processes are temperature dependent (thermal motion of the lattice atoms and carriers' velocity) and affect carrier mobilities.

An electric field  $\mathscr{E}_x$  applied in the x-direction produces a force  $-q\mathscr{E}_x$  on each electron. This force produces, on average a net motion of electrons in the x-direction, affecting the total x-component momentum  $p_x$  as follows:

$$-nq\mathscr{E}_{x} = \frac{dp_{x}}{dt}$$

Giacomo Indiveri (INI)

#### Drift of carriers in electric field



University of | ETH

Electron average velocity and current density

We can therefore write the electrons average net velocity  $\langle v_x \rangle$  produced by the electric field  $\mathcal{E}_x$  as

$$\langle v_{x} \rangle = \frac{\langle p_{x} \rangle}{m_{n}^{*}} = -\frac{q\bar{t}}{m_{n}^{*}}\mathscr{E}_{x}$$

where  $m_n^*$  is the electron effective mass (which is a property of the material band structure).

The electron current density produced by the electric field  $\mathscr{E}_{\nu}$  is given by the electron charge -q multiplied by the number of electron crossing a unit area per unit time  $n < v_x >$ 

$$J_X = \frac{nq^2\overline{t}}{m_n^*}\mathscr{E}_X$$

#### Drift of carriers in electric field





Ohm's law

Ohm's law states that the current density is directly proportional to the electric field:

$$J_x = \sigma_n \mathscr{E}_x, \;\; ext{where} \; \sigma_n \equiv rac{nq^2 \overline{t}}{m_n^*} \; ext{is the conductivity}$$

The electron *mobility* is defined as

$$\mu_n \equiv rac{q ar t}{m_n^*}$$

therefore, the conductivity can be rewritten as  $\sigma_n = qn\mu_n$ .

The current density can be rewritten as

$$\int_{\mathcal{X}} = q(n\mu_n + p\mu_p)\mathscr{E}_{\mathcal{X}} = \sigma\mathscr{E}_{\mathcal{X}}$$

Giacomo Indiveri (INI)

#### Diffusion of carriers





Given that  $\overline{I}$  is a small distance, we can write

$$n_1 - n_2 = \frac{n(x) - n(x + \Delta x)}{\Delta x} \overline{I}$$

with  $x = x_1 + \overline{l}$  and  $\Delta x = \overline{l}$ . In the limit of small free path we can rewrite the electron flux density as follows:

$$\Phi_n(x_0) = \frac{7^2}{2\overline{t}} \lim_{\Delta x \to 0} \frac{n(x) - n(x + \Delta x)}{\Delta x} = -\frac{7^2}{2\overline{t}} \frac{dn(x)}{dx} = -D_n \frac{dn(x)}{dx}$$

where  $D_n = \overline{I}^2/2\overline{t}$  is the electron diffusion coefficient.

#### Diffusion of carriers





Diffusion of carriers is generated by the presence of a carrier concentration gradient (as for gas molecules). The gradient in carrier concentration generates a net motion from regions with high concentration to regions with low concentration. Let us consider an arbitrary function n(x) describing the electron distribution in the x-direction.

The electron flux density (rate of electron flow per unit area) from  $x_1$  to  $x_2 = x_1 + 2\bar{l}$  is

$$\Phi_n(x_0) = \frac{\overline{I}}{2\overline{t}}(n_1 - n_2)$$

where  $\bar{l}$  is the mean free path between collisions,  $\bar{t}$  is the mean free time between collisions,  $n_1 = n(x_1)$  and  $n_2 = n(x_2)$  are the electron concentrations at  $x_1$  and  $x_2$  respectively.

Giacomo Indiveri (INI)

# **Current density**





$$J_n^{diff} = +qD_n \frac{dn(x)}{dx}$$
 $J_p^{diff} = -qD_p \frac{dp(x)}{dx}$ 

where  $J_n^{diff}$  and  $J_p^{diff}$  are the diffusion currents crossing a unit area due to electrons and holes respectively.

Both electrons and holes move in the direction of decreasing carrier concentration. Because of their opposite charge (-a) for electrons, +a for holes) the currents they generate are in opposite directions (given the same concentration gradient).

# Total current density





The total current density is the sum of the electron and holes current densities.

$$J(x) = J_n(x) + J_p(x)$$

In presence of an electric field, each of these current densities have a drift and a diffusion component:

$$J_{n}(x) = q\mu_{n}n(x)\mathscr{E}_{x} + qD_{n}\frac{dn(x)}{dx}$$
$$J_{p}(x) = q\mu_{p}p(x)\mathscr{E}_{x} - qD_{p}\frac{dp(x)}{dx}$$

Giacomo Indiveri (INI)

Neuromorphic Engineering

institute of neuroinformatics

33 / 62

# Diffusion equation





For negligible drift current, we can replace the current density by the diffusion current  $(J_p = -qD_p \frac{\partial \delta p}{\partial x}, J_n = qD_n \frac{\partial \delta n}{\partial x})$  and obtain the *diffusion equation* for holes and electrons:

$$\frac{\partial \delta p}{\partial t} = D_p \frac{\partial^2 \delta p}{\partial x^2} - \frac{\delta p}{\tau_p}$$
$$\frac{\partial \delta n}{\partial t} = D_n \frac{\partial^2 \delta n}{\partial x^2} - \frac{\delta n}{\tau_p}$$

#### Diffusion and recombination





Recombination of charge carriers should be considered when dealing with diffusion processes. Recombination can alter the carrier distribution, thus affecting diffusion. Let us consider the number of carriers entering a volume  $\Delta xA$  (where  $\Delta x$  is a differential length of a semiconductor sample with area A in the plan orthogonal to x) per unit time:

$$\left. \frac{\partial p}{\partial t} \right|_{x \to x + \Delta x} = \frac{1}{q} \frac{J_p(x) - J_p(x + \Delta x)}{\Delta x} - \frac{\delta p}{\tau_p}$$

where  $J_p(x)$  is the hole current density and  $\delta p/\tau_p$  is the recombination rate. For  $\Delta x \to 0$ , we can use the derivative form to write the *continuity equation* for holes and electrons

$$\frac{\partial \delta p}{\partial t} = -\frac{1}{q} \frac{\partial J_p}{\partial x} - \frac{\delta p}{\tau_p}$$
$$\frac{\partial \delta n}{\partial t} = \frac{1}{q} \frac{\partial J_n}{\partial x} - \frac{\delta n}{\tau_n}$$

Giacomo Indiveri (INI)

Neuromorphic Engineering

institute of neuroinformatics

24 / 60

# Diffusion equation





ETH Eldgeelssische Technische Hachschule Zürich Sevina Federal Institute of Technology Zurich

Steady state

When a steady state distribution of excess carriers is maintained, all time derivatives in the diffusion equation are zero. The diffusion equation for the steady state condition becomes:

$$\frac{d^2 \delta p}{dx^2} = \frac{\delta p}{D_p \tau_p} \equiv \frac{\delta p}{L_p^2}$$
$$\frac{d^2 \delta n}{dx^2} = \frac{\delta n}{D_n \tau_n} \equiv \frac{\delta n}{L_n^2}$$

where  $L \equiv \sqrt{D\tau}$  is the diffusion length.

Giacomo Indiveri (INI)

### The origins of the p-n junction





Russel Ohl and colleagues
Bell Telephone Laboratories, March 1940.

Before and during World War II ultrashort-wave radio communication research was pushed by the need for radar applications. George Southworth unsuccessfully tried to detect ultrashort radio waves with specially designed vacuum tubes and copper oxide rectifiers. He then bought a few old "cat's whisker" crystal detectors from a tiny second-hand radio shop and got promising results. Southworth asked Ohl to make a comprehensive study of crystal detectors to determine the best material. Ohl had already worked extensively with crystal detectors, trying to remove odd behaviors by reducing impurities. Ohl tested a rod of silicon and he wrote in his lab notebook that "near one end of the rod there is a change in the crystal structure indicated by a crack." He also noticed that the amount of current that could flow through the crystal was strongly affected by light. The crack was the point of contact between highly purified silicon and impurities rich silicon (resulting from slowly cooling the ingot from which the rod was cut). The two types of silicon were called p-type (producing a positive voltage under light exposure) and n-type (producing a negative voltage under light exposure). The barrier between the two types of silicon was named **p-n junction**.

Giacomo Indiveri (INI)

Neuromorphic Engineering I

institute of neuroinformatics

38 / 62

# Invariance of the Fermi level at equilibrium





Let us consider two different materials (e.g.: a metal and a semiconductor, two differently doped semiconductors, etc.) in contact with each other, such that charge carriers can move from one to the other. At thermal equilibrium the net current and the net transfer of energy have to be null  $\rightarrow$  the net transfer of electrons between the two material has to be null.

The rate of transfer of electrons from one material to the other is proportional to the number of filled state in the first material and the number of empty states in the second material:


$$1 \to 2 \propto N_1(E) f_1(E) \cdot N_2(E) [1 - f_2(E)] 2 \to 1 \propto N_2(E) f_2(E) \cdot N_1(E) [1 - f_1(E)]$$

where  $N_1(E)$  and  $N_2(E)$  are the density of states for material 1 and 2 respectively,  $f_1(E)$  and  $f_2(E)$  are the Fermi distributions for material 1 and 2 respectively.

# The origins of the p-n junction







# Invariance of the Fermi level at equilibrium



institute of neuroinformatics



At equilibrium

$$N_1(E)f_1(E) \cdot N_2(E)[1 - f_2(E)] = N_2(E)f_2(E) \cdot N_1(E)[1 - f_1(E)]$$

Neuromorphic Engineering

which leads to

$$N_1 N_2 f_1 - N_1 N_2 f_1 f_2 = N_1 N_2 f_2 - N_1 N_2 f_1 f_2 \to f_1(E) = f_2(E)$$

$$\frac{1}{1 + e^{(E - E_{F1})/kT}} = \frac{1}{1 + e^{(E - E_{F2})/kT}} \to E_{F1} = E_{F2}$$

At equilibrium the Fermi level throughout materials in intimate contact is constant:

 $\frac{dE_F}{dx} = 0 \ \forall x$ 

# The contact potential



ETH Edgeelseische Technische Hachschafe Zürlich Swiss Federal Institute of Technology Zurich

Let us imagine to put together two pieces of semiconductor: an *n*-type and a *p*-type semiconductor. Once the two pieces are joint, concentration gradients of electrons and holes are created. Because of that holes diffuse to the *n*-type material and electrons diffuse to the *p*-type material.

Holes diffusing away from the p-type material create uncompensated acceptor ions  $N_a^-$  and electrons diffusing away from the n-type material create uncompensated donor ions  $N_d^+$ . These charges generate an electric field directed from the n to the p-type material. This field gives rise to a drift current from the n-type to the p-type material, opposite to the diffusion current.

Giacomo Indiveri (INI)

Neuromorphic Engineering I

institute of neuroinformatics

42 / 6

### Equilibrium





At equilibrium the following conditions have to be met:

- No net current can flow: the drift currents exactly compensate the diffusion currents.
- No accumulation of carrier can occur: for each type of carrier, the drift current exactly compensate the diffusion current

$$J_n(diff) - J_n(drift) = 0$$

$$J_p(diff) - J_p(drift) = 0$$

# The contact potential






p in

 $V_0 = \text{contact potential}$  $qV_0 = \text{bands separation}$ 

 $E_F = Fermi level$ 



Giacomo Indiveri (INI)

Neuromorphic Engineering

institute of neuroinformatics

40.10

#### **Electron current**





Assuming that the x direction is from p to n, we can write the electron current as follows:

$$J_n(x) = q \left[ D_n \frac{dn(x)}{dx} + \mu_n n(x) \mathscr{E}(x) \right] = 0$$

Rearranging terms, we can write:

$$\frac{\mu_n}{D_n}\mathscr{E}(x) = -\frac{1}{n(x)}\frac{dn(x)}{dx}$$

Using the Einstein relation  $(D/\mu = kT/q)$  and writing the electric field as a function of the potential gradient ( $\mathscr{E} = -dV(x)/dx$ ), we obtain:

$$\frac{q}{kT}\frac{dV(x)}{dx} = \frac{1}{n(x)}\frac{dn(x)}{dx}$$

# Contact potential and carrier concentrations University of | ETH





We can solve this equation by integrating it over the appropriate limits:

$$\frac{q}{kT} \int_{V_p}^{V_n} dV = \int_{n_p}^{n_n} \frac{dn}{n}$$

This integration gives:

$$\frac{q}{kT}(V_n - V_p) = \ln n_n - \ln n_p = \ln \frac{n_n}{n_p}$$

Given that the contact potential  $V_0$  is the difference  $V_p - V_n$ , we can write it as a function of the equilibrium hole concentration on the two sides of the junction:

$$V_0 = \frac{kT}{q} \ln \frac{n_n}{n_p} \rightarrow \frac{n_n}{n_p} = e^{qV_0/kT}$$

Given that  $p_p n_p = p_n n_n = n_i^2$ , we can write:

$$\boxed{\frac{n_n}{n_p} = \frac{p_p}{p_n} = e^{\frac{qV_0}{kT}}}$$

Giacomo Indiveri (INI)

# Contact potential and carrier concentrations





We can solve this equation by integrating it over the appropriate limits:

$$-\frac{q}{kT}\int_{V_p}^{V_n}dV=\int_{p_p}^{p_n}\frac{dp}{p}$$

This integration gives:

$$-\frac{q}{kT}(V_n - V_p) = \ln p_n - \ln p_p = \ln \frac{p_n}{p_p}$$

Given that the contact potential  $V_0$  is the difference  $V_n - V_p$ , we can write it as a function of the equilibrium hole concentration on the two sides of the junction:

$$V_0 = rac{kT}{q} \ln rac{p_p}{p_n} 
ightarrow rac{p_p}{p_n} = e^{qV_0/kT}$$

Given that  $p_p n_p = p_n n_n = n_i^2$ , we can write:

$$\boxed{\frac{p_p}{p_n} = \frac{n_n}{n_p} = e^{\frac{qV_0}{kT}}}$$

#### Hole current





Assuming that the x direction is from p to n, we can write the hole current as follows:

 $J_p(x) = q \left[ -D_p \frac{dp(x)}{dx} + \mu_p p(x) \mathscr{E}(x) \right] = 0$ 

Rearranging terms, we can write:

$$\frac{\mu_p}{D_p}\mathscr{E}(x) = \frac{1}{p(x)}\frac{dp(x)}{dx}$$

Using the Einstein relation  $(D/\mu = kT/q)$  and writing the electric field as a function of the potential gradient ( $\mathscr{E} = -dV(x)/dx$ ), we obtain:

$$-\frac{q}{kT}\frac{dV(x)}{dx} = \frac{1}{p(x)}\frac{dp(x)}{dx}$$

Giacomo Indiveri (INI)

# Contact potential and donor/acceptor concentrations



If we assume that in each side of the junction the majority carrier concentration is equal to the impurity concentration, we can express the contact potential as follows:

$$V_0 = \frac{kT}{q} \ln \frac{N_a N_d}{n_i^2} \tag{1}$$


where  $N_a$  is the acceptor concentration in the p-type material,  $N_d$  is the donor concentration in the *n*-type material and  $n_i$  is the intrinsic electron concentration.

### The p-n junction is a rectifier, and more ...



EITH
Eldgreissische Technische Hachschale Zürich
Serins Federal Institate of Technology Zurich

Forward bias



When an external voltage is applied to the p-n junction, its current flow strongly depend on the sign of the voltage:

- Forward bias: the p region as a positive external voltage bias relative to the n region. Current can freely flow from the p to the n region.
- Reverse bias: the p region as a negative external voltage bias relative to the n region. No current can flow in the p-n junction.

p-n junctions can also be used as photocells (see p-n junction history), light emitters (LEDs), voltage variable capacitor. Junctions can be used as "building blocks" for constructing TRANSISTORS.

Giacomo Indiveri (INI)

Neuromorphic Engineering I

institute of neuroinformatics

50 / 62

Giacomo Indiveri (INI)

Neuromorphic Engineering I

institute of neuroinformatics

51 / 62


#### Forward bias




We can assume that the applied voltage  $V_f$  appears entirely across the depletion region. The forward bias raises the potential on the p-type material relative to the n-type material. The electric field decreases (applied field opposite to built-in field), therefore decreasing the width of the depletion region. Given the lowered energy barrier majority carriers can easily diffuse from one side to the other (holes from p to n and electrons from n to p).

The diffusion current can be large for forward bias.


The drift current is independent of the energy barrier.






#### Reverse bias







#### Reverse bias






The reverse bias lowers the potential on the p-type material relative to the *n*-type material. The electric field increases (applied field in the same direction as the built-in field), therefore increasing the width of the depletion region. Given the increased energy barrier virtually no majority carriers can diffuse from one side to the other.

The diffusion current is negligible for reverse bias.

The drift current is independent of the energy barrier.




Giacomo Indiveri (INI)

University of Lidge of State of Lidge of State of Lidge o


# **Diode equation**



Diffusion of majority carriers across the depletion region varies the minority carrier concentrations in the opposite side. In presence of an external voltage bias the equilibrium ratio of hole concentration  $(p_p/p_n = e^{qV_0/kT})$  becomes



where the external voltage bias V is positive for forward bias and negative for reverse bias.



Neglecting changes in majority carrier concentrations, we can write:

$$\frac{p_p}{p(x_{n0})} = \frac{p_p}{p_n} e^{\frac{-qV}{kT}} \rightarrow \frac{p(x_{n0})}{p_n} = e^{\frac{qV}{kT}}$$

### **Diode** equation




University of Zurich

Equilibrium ratio of electron concentration

Diffusion of majority carriers across the depletion region varies the minority carrier concentrations in the opposite side. In presence of an external voltage bias the equilibrium ratio of hole concentration  $(n_n/n_p = e^{qV_0/kT})$  becomes

$$\frac{n(x_{n0})}{n(-x_{n0})}=e^{q\frac{V_0-V}{kT}}$$



where the external voltage bias V is positive for forward bias and negative for reverse bias.

Neglecting changes in majority carrier concentrations, we can write:


$$rac{n_n}{n(-x_{p0})} = rac{n_n}{n_p} e^{rac{-qV}{kT}} o rac{n(-x_{p0})}{n_p} = e^{rac{qV}{kT}}$$

Giacomo Indiveri (INI)

University of | ETH

# **Diode** equation

Minority carrier distribution




$$\Delta n_p = n(-x_{p0}) - n_p = n_p e^{\frac{qV}{kT}} - n_p = n_p (e^{\frac{qV}{kT}} - 1)$$

$$\Delta p_n = p(x_{n0}) - p_n = p_n e^{\frac{qV}{kT}} - p_n = p_n (e^{\frac{qV}{kT}} - 1)$$

As minority carriers diffuse into the material (away from the depletion region) they recombine with majority carriers. The resulting excess of minority carrier distribution can be derived as a solution of the steady state diffusion equation (see slide 32):

$$\delta p(x_n) = \Delta p_n e^{-\frac{x_n}{L_p}} = p_n (e^{\frac{qV}{kl}} - 1) e^{-\frac{x_n}{L_p}}$$
$$\delta n(x_n) = \Delta n_n e^{-\frac{x_n}{L_n}} = n_n (e^{\frac{qV}{kl}} - 1) e^{-\frac{x_n}{L_n}}$$



where  $x_0$  is the distance from the edge of depletion region in the p-type material  $(-x_{00})$  and  $x_{0}$  is the distance from the edge of depletion region in the *n*-type material  $(x_{n0})$ .

#### Diode equation






Current

The hole and electron diffusion currents can be easily calculated:

$$I_{p}(x_{n}) = -qAD_{p}\frac{d\delta p(x_{n})}{dx_{n}} = qA\frac{D_{p}}{L_{p}}\Delta p_{n}e^{-\frac{x_{n}}{L_{p}}}$$

$$I_{n}(x_{p}) = qAD_{n}\frac{d\delta p(x_{p})}{dx_{p}} = -qA\frac{D_{n}}{L_{n}}\Delta n_{p}e^{-\frac{x_{p}}{L_{n}}}$$



The total diffusion current injected into the material at the junction is obtained for  $x_p = 0$  and  $x_n = 0$  respectively in the p and n diffusion currents:

$$I_p(x_n=0) = qA\frac{D_p}{L_p}\Delta p_n = qA\frac{D_p}{L_p}p_n(e^{\frac{qV}{kT}}-1)$$

$$I_n(x_p=0) = -qA\frac{D_n}{L_n}\Delta n_p = -qA\frac{D_n}{L_n}n_p(e^{\frac{qV}{kT}}-1)$$

where  $I_n$  is opposite to the  $x_n$  direction.

Giacomo Indiveri (INI)

institute of neuroinformatics



#### Next week





Metal-Oxide-Semiconductor Transistor

# **Diode** equation





Current

Taking the x-direction as reference, we can write the total current as follows:

$$I = qA\left(\frac{D_p}{L_p}p_n + \frac{D_n}{L_n}n_p\right)\left(e^{\frac{qV}{kT}} - 1\right) = I_0\left(e^{\frac{qV}{kT}} - 1\right)$$

For reverse bias  $V_r > 3kT/q$  the exponential term is negligible compared to the unity term and the diode equation becomes  $I = -I_0$ .

Giacomo Indiveri (INI)

Giacomo Indiveri (INI)

Neuromorphic Engineering I

institute of neuroinformatics

#### Momentum





The momentum p of a particle is the product of its mass m and velocity v:

$$p = mv$$

A force F applied to a particle for a time interval  $\Delta t$  produces a change in the particle's momentum given by:

$$\Delta p = F \Delta t$$

This equation can be expressed in a differential form (Newton's second law) stating that the rate of change in momentum is equal to the force applied to the particle:

$$F = \frac{dp}{dt}$$
.

# Second order differential equation



Diffusion equation  $\frac{d^2\delta p}{dx^2} = \frac{\delta p}{L_p^2}$ 

$$ay'' + by' + cy = 0$$

If  $b^2 - 4ac > 0$  then the general solution of the differential equation is:

$$y = c_1 e^{r_1 x} + c_2 e^{r_2 x}$$
 with  $r_{1,2} = \frac{-b \pm \sqrt{b^2 - 4ac}}{2a}$ 

We have a = 1, b = 0 and  $c = -1/L^2$  so the general solution is:

$$y = c_1 e^{x/L} + c_2 e^{-x/L}$$

 $c_1$  and  $c_2$  can be determined by imposing boundary conditions.

Giacomo Indiveri (IN

Neuromorphic Engineering I

institute of neuroinformation

62 / 6

