Dynamic Controllers, Filters Control Theory, Lecture 10

by Sergei Savin

Spring 2025

CONTENT

- Systems static, dynamic
- Dynaic Controller
- PID
- Filters

Systems

A system is characterized by how it relates its input to its output.

- Controller $\mathbf{u} = \mathbf{K}\mathbf{x}$ is a system that relates \mathbf{x} its input to \mathbf{u} , its output.
- Plant (in state-space representation) $\begin{cases} \dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} \\ \mathbf{y} = \mathbf{C}\mathbf{x} \end{cases}$ relates its input \mathbf{u} to its output \mathbf{y} .
- Plant (in Laplace representation) Y(s) = W(s)U(s) with a transfer function W(s) is a system relating its input signal U(s) to its output signal Y(s).

LINEAR SYSTEMS, STATIC

For some systems, the relation between input and output is proportional. Such system we can call *static*.

Examples of static systems:

- \blacksquare (State-Space) controller $\mathbf{u} = \mathbf{K}\mathbf{x}$.
- (Laplace) gain function Y(s) = 10U(s).

LINEAR SYSTEMS, DYNAMIC

Alternatively, there are linear systems for which relation between input and output depends on derivatives of the input and the output. Such system we can call dynamic.

Examples of dynamic systems:

$$\qquad \qquad \textbf{(State-Space) plant } \begin{cases} \dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} \\ \mathbf{y} = \mathbf{C}\mathbf{x} \end{cases}.$$

■ (Laplace) plant
$$Y(s) = \frac{1}{s^2 + 2s + 7}U(s)$$
.

STATIC VS DYNAMIC

We can think of static systems as a form of linear algebraic equations, while dynamic systems are linear differential equations.

The distinguishing quality of dynamic systems is that they have a *state*. We can think of the state as an internal variable which changes with time, affecting the relation between the input and the output of the system.

CONTROLLER+OBSERVER

Controller + Luenberger observer is also a dynamic system with input \mathbf{y} , output \mathbf{u} and state $\hat{\mathbf{x}}$:

$$\begin{cases} \hat{\dot{\mathbf{x}}} = \mathbf{A}\hat{\mathbf{x}} + \mathbf{B}\mathbf{u} + \mathbf{L}(\mathbf{y} - \mathbf{C}\hat{\mathbf{x}}) \\ \mathbf{u} = -\mathbf{K}\hat{\mathbf{x}} \end{cases}$$
(1)

The form of this system resebles the plant with output equation.

We can think of this system as a *dynamic controller* (rather then separating it into a dynamic observer and a static controller).

DYNAMIC CONTROLLER

A generic form of dynamic controller is:

$$\begin{cases} \hat{\mathbf{x}} = \mathbf{A}_k \hat{\mathbf{x}} + \mathbf{B}_k \mathbf{y} \\ \mathbf{u} = \mathbf{C}_k \hat{\mathbf{x}} + \mathbf{D}_k \mathbf{y} \end{cases}$$
 (2)

where matrices \mathbf{A}_k , \mathbf{B}_k , \mathbf{C}_k and \mathbf{D}_k can be tuned to achieve better performance.

A Luenberger observer + static controller is a particular instance of dynamic controller.

PID, 1

One of the better known examples of dynamic controllers is a proportional-integral-derivative controller (PID). Scaler case:

$$u(t) = k_p e(t) + k_d \frac{d}{dt} e(t) + k_i \int_0^t e(\tau) d\tau$$
 (3)

Vector case:

$$\mathbf{u}(t) = \mathbf{K}_p \mathbf{e}(t) + \mathbf{K}_d \frac{d}{dt} \mathbf{e}(t) + \mathbf{K}_i \int_0^t \mathbf{e}(\tau) d\tau$$
 (4)

This controller works for second-order systems (in $\mathbf{e}(t)$) where \mathbf{e} and $\dot{\mathbf{e}}$ form the state of the system (or control error).

This controller is equivalent to the linear controllers we studied in the course (e.g. LQR) but with integral part allowing for robustness - the ability to compensate for static additive disturbance in the model.

PID, 2

We can re-write PID in Laplace space:

$$U(s) = \left(k_p + k_d s + k_i \frac{1}{s}\right) E(s) \tag{5}$$

$$U(s) = \frac{k_d s^2 + k_p s + k_i}{s} E(s) \tag{6}$$

It is not instantly obvious that the controller has state.

PID, 3

To re-write it in the state-space form, we introduce input to the controller (output to the plant) $\mathbf{y} = \begin{bmatrix} \mathbf{e} \\ \dot{\mathbf{e}} \end{bmatrix}$. We define a state $\mathbf{z} = \int_0^t \mathbf{e}(\tau) d\tau$, giving us the following state-space form of the controller:

$$\begin{cases} \dot{\mathbf{z}} = \begin{bmatrix} \mathbf{I} & 0 \end{bmatrix} \mathbf{y} \\ \mathbf{u} = \mathbf{K}_i \mathbf{z} + \begin{bmatrix} \mathbf{K}_p & \mathbf{K}_d \end{bmatrix} \mathbf{y} \end{cases}$$
 (7)

STATIC DISTURBANCE, 1

Consider a system with a static disturbance d:

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} + \mathbf{d} \tag{8}$$

Applying a stabilizing linear control law $\mathbf{u} = -\mathbf{K}\mathbf{x}$ we find that the closed-loop system $\dot{\mathbf{x}} = (\mathbf{A} - \mathbf{B}\mathbf{K})\mathbf{x} + \mathbf{d}$ has a steady-state solution \mathbf{x}_s :

$$(\mathbf{A} - \mathbf{B}\mathbf{K})\mathbf{x}_s + \mathbf{d} = 0 \tag{9}$$

$$\mathbf{x}_s = -(\mathbf{A} - \mathbf{B}\mathbf{K})^{-1}\mathbf{d} \tag{10}$$

STATIC DISTURBANCE, 2

We can achieve the same result using Laplace representation:

$$\begin{cases} s\mathbf{X} = \mathbf{A}\mathbf{X} + \mathbf{B}\mathbf{U} + \mathbf{D} \\ \mathbf{U} = -\mathbf{K}\mathbf{X} \end{cases}$$
(11)

$$s\mathbf{X} - (\mathbf{A} - \mathbf{B}\mathbf{K})\mathbf{X} = \mathbf{D} \tag{12}$$

$$\mathbf{X} = (s\mathbf{I} - (\mathbf{A} - \mathbf{B}\mathbf{K}))^{-1}\mathbf{D}$$
 (13)

With a steady-state gain $-(\mathbf{A} - \mathbf{B}\mathbf{K}))^{-1}$, same as above.

STATIC DISTURBANCE COMPENSATION, 1

If we know static disturbance \mathbf{d} , we could chose a control law $\mathbf{u} = -\mathbf{K}\mathbf{x} - \mathbf{B}^{+}\mathbf{d}$ which will cancel the disturbance (if it lies in the range of the control matrix \mathbf{B}).

But if we don't know \mathbf{d} , we can use an *integral* component in a control law to compensate the disturbance:

$$\mathbf{u} = -\mathbf{K}_p \mathbf{x} - \mathbf{K}_i \int_0^t \mathbf{x} d\tau \tag{14}$$

In the Laplace domain it can be represented as:

$$\begin{cases} s\mathbf{X} = \mathbf{A}\mathbf{X} + \mathbf{B}\mathbf{U} + \mathbf{D} \\ \mathbf{U} = -\mathbf{K}_{p}\mathbf{X} - \frac{1}{s}\mathbf{K}_{i}\mathbf{X} \end{cases}$$
 (15)

STATIC DISTURBANCE COMPENSATION, 2

$$\begin{cases} s\mathbf{X} = \mathbf{A}\mathbf{X} + \mathbf{B}\mathbf{U} + \mathbf{D} \\ \mathbf{U} = -\mathbf{K}_{p}\mathbf{X} - \frac{1}{s}\mathbf{K}_{i}\mathbf{X} \end{cases}$$
 (16)

We can write it as a transfer function:

$$s\mathbf{X} = \mathbf{A}\mathbf{X} - \mathbf{B}\mathbf{K}_{p}\mathbf{X} - \frac{1}{s}\mathbf{B}\mathbf{K}_{i}\mathbf{X} + \mathbf{D}$$
 (17)

$$s^{2}\mathbf{X} = s\mathbf{A}\mathbf{X} - s\mathbf{B}\mathbf{K}_{p}\mathbf{X} - \mathbf{B}\mathbf{K}_{i}\mathbf{X} + s\mathbf{D}$$
 (18)

$$\mathbf{X} = s \left(s^2 \mathbf{I} - s(\mathbf{A} - \mathbf{B} \mathbf{K}_p) + \mathbf{B} \mathbf{K}_i \right)^{-1} \mathbf{D}$$
 (19)

Its static-state gain is equal to 0.

FILTERS, 1

Consider a system:

$$\begin{cases} \dot{x} = ax + bu \\ y = cx + d\sin(wt) \end{cases}$$
 (20)

where w >> 0 is a frequency of the external disturbance and d is it amplitute.

We can first pass the measurement y through a system that attenuates high-frequency component of a signal; such system is called a *low-pass filter* and then pass it through the controller:

$$\begin{cases} \dot{z} = -z + y \\ u = kz \end{cases} \tag{21}$$

FILTERS, 2

The filter $\dot{z} = -z + y$ has a Laplace form:

$$Z(s) = \frac{1}{s+1}Y(s) \tag{22}$$

Frequency response of this transfer function is:

$$W(\omega) = \frac{1}{\sqrt{\omega^2 + 1}} Y(s) \tag{23}$$

As frequency increases, the signal is attenuated more. For frequencies close to zero, the signal passes nearly unchanged.

Lecture slides are available via Github:

github.com/SergeiSa/Control-Theory-2025

