# Data Process - Wedge/Store, Enter Key, Extend Key

Wedge Only	Wedge & Store Always
82000	82001
Store Only  82002	Save if Sent  82003
Save if Not Sent	
Enable Enter Key (KDC350L/D Only)	Disable Enter Key (KDC350L/D Only)
8E001	8E000
Enable Extend Key (KDC350L/D Only)	Disable Extend Key (KDC350L/D Only)
8X001	8X000

#### Data Process - Data Edit

Start Prefix Enter	Start Suffix Enter
83000	83001
Finish Prefix/Suffix Enter	Cancel Prefix/Suffix Enter
83002	83003
Delete Prefix	Delete Suffix
83004	83005
Display Prefix	Display Suffix
83006	83007
AIM ID None	AIM ID In Prefix
8B000	8B001
AIM ID In Suffix	
8B002	

#### Data Process - Data Format and Handshake

Data format = Barcode only	Data format = Packet data
84001	84010
Enable Handshake	Disable Handshake
86001	86010

## Data Process - Termination Character & Duplicate Check

Termination Character = None	Termination Character = CR
88000	88001
Termination Character = LF	Termination Character = CR+LF
88002	88003
Termination Character = Tab	
88004	
Enable Duplicate Check	Disable Duplicate Check
89001	89010


### Data Process - Termination Character & Duplicate Check

Enable Bluetooth Power	Disable Bluetooth Power
60001	60010
Enter Pairing Mode	
61001	
Enable Discovering	Disable Discovering
61101	61110
Connect To Last	Connecting to
61201	61301
Disconnect	
6D000	
HID Sync	SPP Sync
6E000	6E001
Bluetooth Profile = SPP	Bluetooth Profile = HID iOS
6A000	6A001

Bluetooth Profile = MFi	Bluetooth Profile = SPP2.0
Bluetooth Frome = MFi	bluetooth Ffoille = 3FF2.0
6A002	6A003
Bluetooth Profile = HID Normal	
6A004	
Enable Auto Connect	Disable Auto Connect
62001	62010
Enable Auto Reconnect	Disable Auto Reconnect
6R001	6R010
Enable Auto Power On	Disable Auto Power On
66001	66010
Enable Auto Power Off	Disable Auto Power Off
64001	64010
Enable Beep Warning	Disable Beep Warning
68001	68010

Enable Power Off Msg	Disable Power Off Msg
63001	63010
Display BT MAC Address	Display BT FW Version
63100	63200
Enable Wakeup Nulls	Disable Wakeup Nulls
63401	63410
Enable BT Toggle	Disable BT Toggle
6B001	6B010
Enable BT Disconnect Button	Disable BT Disconnect Button
6B101	6B110
Enable Auto Pairing	Disable Auto Pairing
6N001	6N010

### Bluetooth Auto Power On Time



Auto Power On Time = 2sec	Auto Power On Time = 3sec
67002	67003
Auto Power On Time = 4sec	Auto Power On Time = 5sec
67004	67005
Auto Power On Time = 6sec	Auto Power On Time = 7sec
67006	67007
Auto Power On Time = 8sec	Auto Power On Time = 9sec
67008	67009
Auto Power On Time = 10sec	
6700A	