






Debug LED



PIR

Note: Make sure the signal is 3v3 or less. Otherwise, use a resistor divider.



NOTE: TV is controlled via CEC over HDMI

ID_SD and ID_SC PINS:
These pins are reserved for HAT ID EEPROM.

At boot time this I2C interface will be interrogated to look for an EEPROM that identifies the attached board and allows automatic setup of the GPIOs (and optionally, Linux drivers).

Bridging JP1 enables write protection.

DO NOT USE these pins for anything other than attaching an I2C ID EEPROM. Leave unconnected if ID EEPROM not required.

Additional pin functions:
<https://pinout.xyz/>

Sheet: /
File: Kiosk.kicad_sch

Title:

Size: A4 Date: 2026-10-06

KiCad E.D.A. 10.0.1

Rev: 1

Id: 1/1