
MySensor small PCB board MD-MS


Revision 1 — 16.04.2015



Components:

Chip ATMega328P QFP32 Capacitor 4,7mf Resistor SMD 0805 10k





NRF24L01+ inserted into MD-MS after the firmware boot loader



Assembly

- 1. Solder processor
- 2. Solder the resistor
- 3. Write boot loader
- 4. Solder the wires to the contacts D5-D8
- 5. Solder the remaining wires (You can later, but uncomfortable)
- 6. Solder NRF24L01+
- 7. Solder the capacitor
- 8. Write Sketch

Write boot can be after assembly, but there may be conflicts SPI NRF24L01+

If you do not cut the connectors NRF24L01 + then they can connect to flash

Warning For Reset working. Between the programmer and the board Reset must be 0.1uf capacitor