★TOPIC:- HARDWARE

Module_2-Day_3:

❖ Tasks:

1. **List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.**

⇨

❖ Common USB Keyboard and Mouse Issues:

No.	Common Issue	Possible Solution
1	Keyboard or mouse is not working.	Unplug the USB connector and plug it into another USB port.
2	Keyboard keys are not responding.	Clean the keyboard and check whether any keys are stuck.
3	Mouse cursor is moving slowly or irregularly.	Clean the mouse sensor and use it on a flat surface.
4	USB device connects and disconnects repeatedly.	Check the USB cable for damage and reconnect it securely.
5	Laptop does not detect the keyboard or mouse.	Restart the laptop or update the USB drivers using Device Manager.

2. **Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.**

⇨

❖ Troubleshooting: Bluetooth Headphones Not Connecting to a Phone

★ **Step-by-step actions to diagnose and fix the issue:**

1. **Check the Headphones' Battery:** Make sure the headphones are charged. Check the LED indicator or battery level if available.
2. **Turn Bluetooth On:** Open the phone's Settings → Bluetooth and ensure Bluetooth is switched on.
3. **Enable Pairing Mode:** Turn on the headphones and press and hold the Bluetooth or power button until the LED flashes (usually blue and red or blue and white).
4. **Check Available Devices:** Under the phone's Bluetooth settings, look for the headphone name in the available devices list.
5. **Connect the Headphones:** Tap the headphone name and wait for the status to show Connected.
6. **Disconnect Other Devices:** If the headphones are connected to another phone or laptop, disconnect them from that device and try pairing again.
7. **Forget and Re-pair:** If the headphones appear but do not connect, tap the settings icon beside their name, select Forget/Unpair, then search for them and pair again.
8. **Restart Both Devices:** Turn the headphones off and on. Restart the phone, enable Bluetooth again, and retry the connection.
9. **Check Audio Output:** Play music and check the phone's audio output settings to ensure the headphones are selected for media audio.
10. **Test the Headphones:** Try connecting them to another phone. If they work, the problem may be with the original phone's Bluetooth settings. If they do not, check the headphone manual for a reset procedure.

3. **A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem.

Hint: Consider device manager, privacy settings, and app permissions.**

⇨

❖ Fix External Webcam Not Detected on Windows 10:

(1) Check USB Connection: Unplug the webcam and reconnect it. Try another USB port.
(2) Check Device Manager: Open Device Manager and expand Cameras. If the webcam is disabled, right-click it and select Enable device.
(3) Check Privacy Settings: Go to Settings → Privacy → Camera and enable camera access.
(4) Check Zoom Settings: Open Zoom → Settings → Video and select the correct webcam.
(5) Close Other Apps: Close other applications that may be using the webcam, then restart Zoom.
(6) Update the Driver: Open Device Manager, right-click the webcam, and select Update driver.

4. **You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.**

⇨

❖ Steps to Fix a Printer Showing "Offline" Using Windows Troubleshooter:

(1) Open Settings: Press Windows + I to open Windows Settings.
(2) Go to Troubleshoot: Select System → Troubleshoot → other troubleshooters in Windows 11. In Windows 10, go to Settings → Update & Security → Troubleshoot → Additional troubleshooters.
(3) Select Printer: Find the Printer troubleshooter and click Run.
(4) Select the Printer: Choose the printer showing offline status and follow the on-screen instructions.
(5) Check for Problems: Allow Windows to detect issues such as connection problems, incorrect printer settings, or driver errors.
(6) Apply Fixes: If Windows suggests a solution, apply it and follow any additional instructions.
(7) Test the Printer: Print a test page to confirm that the printer is online and working correctly.

❖ What Information Does the Troubleshooter Provide?

★ **Detected problems:** Identifies possible issues with the printer or its connection.
★ **Diagnostic results:** Shows which problems were found during the scan.
★ **Suggested solutions:** Recommends actions to fix detected issues.
★ **Repair status:** Indicates whether Windows successfully applied a fix or whether further action is required.