Voice Commands

Basic...

Voice Commands	Functionality
Halt the programme.	Stops taking voice and video input.
Start the process	Starts taking voice and video input.
Move mouse cursor	Cursor moves with the middle point of two eyes.
Freeze	Cursor stops moving.
Click/Open	Performs double click.
Go back	Go to previous page.
Hide the application	Application interface goes to background.
Show the application	Application interface comes to foreground.
Minimize current window	Minimize current focused window.
Maximize current window	Maximize current focused window.
Close current window	Close current focused window.
Close the programme.	Application exits.

For cursor control mode...

Voice Command	Functionality
Activate cursor control mode	Switch to cursor control mode.
Halt the programme.	System stops taking video and voice input.
Start the process	System starts taking voice and video input.
Move mouse cursor	Cursor starts moving with the focused point between the eyes.
Freeze	Mouse cursor stops moving.
Stop moving cursor	Mouse cursor stops moving.
Single Click	Performs single click
Click / Open	Performs double click.
Right click	Performs right click.

Go back	Goes to previous window.
Activate blink control	Performs click events with eye blink
Deactivate blink control	Deactivate the eye blink control.
Hide the application	Application interface goes to background.
Show the application	Application interface comes to foreground.
Increase pointer movement	Pointer sensitivity increases(relative to head movement)
Decrease pointer movement	Pointer sensitivity decreases(relative to head movement)
Increase pointer speed	Pointer speed increases.
Decrease pointer speed	Pointer speed decreases.
Show cursor coordinate	Cursor coordinate is displayed.
Hide cursor coordinate	Cursor coordinate is hidden.
Check cursor frame	The relative position of the cursor according to screen is shown in a rectangle.
Uncheck cursor frame	Hide the cursor frame.
Check processed image	Shows the detected face and eyes.
Uncheck processed image	Hide the processed image.
Minimize current window	Minimize current focused window.
Maximize current window	Maximize current focused window.
Close current window	Close current focused window.
Close the programme	Application exits

For Multimode...

Voice Command	Functionality
Activate multimode	Switch to Multimode.
Move mouse cursor	Cursor starts moving.
Slide	Scrolling mode is activated.(Please use
	"Move mouse cursor" command before
	using this command)
Stop	Scrolling mode is disabled.

Picture view	Activating fast forwarding and rewarding
Tietare view	using head gesture.
Describerto distance di con	
Deactivate picture view	Deactivating fast forwarding and rewarding
	using head gesture.
Next frame	Show next image (in Picasa & windows
	photo viewer).
Previous frame	Show previous image (in Picasa & windows
	photo viewer).
Zoom in	Zooms in the picture (in Picasa & windows
	photo viewer).
Zoom out	Zooms out of the image (in Picasa &
	windows photo viewer).
Enter	Full Screen (in KMPlayer)
Escape	Close (in KMPlayer).
Start the video	Starts the video playback.
Pause the video	Pauses the video.
Upper stroke	Increases volume (in KMPlayer)
Lower stroke	Decreases volume(in KMPlayer)
Minimize current window	Minimize current focused window.
Maximize current window	Maximize current focused window.
Close current window	Close current focused window.
Close the programme	Application exits

For Security Access mode...

Voice Command	Functionality
Activate security access mode	Switch to security mode after giving the
	voice password.
Terminate security access mode	Deactivates the security access mode after
	giving the voice password.

VOICE PASSWORD: EYE POINTER