

Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
1	02.001.04.0.00	SPECIAL WASHER - M14 BOLT	Spare Part	31	15%
2	02.001.13.0.00	DISC PLUG	Spare Part	114	15%
3	02.001.14.0.00	SPLIT BUSH	Spare Part	34	15%
4	02.001.16.0.00	COUPLING DISC KG 42.3, SAE 11.5"	Spare Part	5800	15%
5	02.002.05.0.00	SPRING WASHER(M8)	Spare Part	15	15%
6	02.002.10.0.00	OIL SPRAY NOZZLE ASSLY	Spare Part	172	15%
7	02.005.04.0.00	HARD WASHER 13 X21 X1.5	Spare Part	22	15%
8	02.014.09.0.PR	SCRAPER RING	Spare Part	422	15%
9	02.015.04.0.00	INLINE FIP: HA294 G1 20.5 HP @ 1500 RPM CPCB-II	Spare Part	70224	15%
10	02.019.03.0.00	SHIM RING: CYL LINER 0.2THK	Spare Part	43	15%
11	02.019.04.0.00	CYLINDER LINER	Spare Part	5874	15%
12	02.019.08.0.PR	LINER FOR SCRAPER RING	Spare Part	6289	15%
13	02.020.02.0.00	PISTON PIN	Spare Part	837	15%
14	02.020.40.0.00	PISTON RING SET	Spare Part	1920	15%
	02.020.50.0.00	PISTON ASSEMBLY	· · · · · · · · · · · · · · · · · · ·	7668	15%
15		PISTON RING SET ALCAN3R	Spare Part	1686	15%
16	02.020.60.0.00	CONNECTING ROD BOLT	Spare Part		15%
17			Spare Part	151	
18	02.022.03.0.00	CYLINDER HEAD BOLT 12X211	Spare Part	1000	15%
19	02.022.04.0.00	WASHER	Spare Part	58	15%
20	02.022.06.0.00	WASHER	Spare Part	31	15%
21	02.022.07.0.00	BUTTON FOR INJECTOR YOKE	Spare Part	28	15%
22	02.022.09.0.00	LOCKING SCREW	Spare Part	203	15%
23	02.022.11.0.00	VALVE CUP	Spare Part	262	15%
24	02.022.12.0.00	VALVE COLLET	Spare Part	58	15%
25	02.022.13.0.00	VALVE SPRING	Spare Part	163	15%
26	02.022.15.0.00	VALVE SEAT INSERT -INLET	Spare Part	572	15%
27	02.022.16.0.00	VALVE SEAT INSERT -EXHAUST	Spare Part	502	15%
28	02.022.17.0.00	VALVE GUIDE	Spare Part	228	15%
29	02.022.18.0.00	WIRE SNAP RING	Spare Part	28	15%
30	02.022.21.0.00	SPRING CUP	Spare Part	157	15%
31	02.022.24.0.00	NUT M8 (BRASS)	Spare Part	77	15%
32	02.022.25.0.00	COPPER WASHER	Spare Part	58	15%
33	02.022.28.0.00	VALVE COLLET-3-GROOVE	Spare Part	46	15%
34	02.022.31.0.00	VALVE SEAT INSERT (EXHAUST)	Spare Part	397	15%
35	02.022.31.7.00	VALVE SEAT INSERT: EXHAUST	Spare Part	397	15%
36	02.022.50.0.00	CYLINDER HEAD RECONDITIONING KIT HA ENGINE (BS II)	Spare Part	4151	15%
37	02.022.60.0.00	CYLINDER HEAD RECONDITIONING KIT HA ENGINES (INDL BSIII & PG CPCB) NEW MODEL (POST	Spare Part	4117	15%
38	02.024.01.0.00	VALVE TAPPET	Spare Part	465	15%
39	02.024.02.0.00	SEALING RING BOTTOM	Spare Part	71	15%
40	02.024.03.0.00	SEALING RING CAP	Spare Part	22	15%
41	02.024.04.0.00	SPRING	Spare Part	58	15%
42	02.024.05.0.00	O RING: TOP P.R. TUBE 5.3X17 21507	Spare Part	65	15%
43	02.024.09.0.00	WASHER	Spare Part	22	15%
44	02.024.13.0.00	ROCKER ARM: ADJ SCREW	Spare Part	83	15%
45	02.024.14.0.00	OIL METERING SCREW	Spare Part	34	15%
46	02.024.15.0.00	V.R.TOE	Spare Part	108	15%
47	02.024.13.0.00	VALVE ROCKER ASSLY	Spare Part	1388	15%
	1	BUSH FOR SUPPORT	Spare Part	65	15%
48	02.024.25.0.00		· · · · · · · · · · · · · · · · · · ·		
49	02.024.27.0.00	NUT: ROCKER ADJ SCREW	Spare Part	31	15%
50	02.024.32.0.00	ROCKER COVER	Spare Part	1117	15%
51	02.024.33.0.00	PUSH ROD TUBE COVER: HA	Spare Part	178	15%
52	02.024.38.0.00	WASHER(ROCKER LEVER)	Spare Part	43	15%
53	02.024.41.0.00	ROCKER COVER GASKET	Spare Part	271	15%
54	02.024.48.0.00	PUSH ROD: WELDED	Spare Part	289	15%
55	02.024.50.0.00	ROCKER LEVER ASSEMBLY	Spare Part	2837	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
56	02.024.70.0.00	PUSH ROD: WELDED	Spare Part	292	15%
57	02.024.97.0.00	ROCKER COVER GASKET	Spare Part	520	15%
58	02.025.01.0.00	NOZZLE WASHER (THICKNESS - 3MM)	Spare Part	31	15%
59	02.026.10.0.PR	EXPANSION MODULE FOR KG645	Spare Part	46119	15%
60	02.026.11.0.PR	SEDEMAC GENSET CONTROL UNIT GC2111	Spare Part	65073	15%
61	02.026.13.0.00	KG934 FRONT FACIA	Spare Part	2028	15%
62	02.026.14.0.PR	GC2112 CONTROLLER UNIT	Spare Part	67956	15%
63	02.026.26.0.PR	KG645 C CONTROLLER UNIT SP 3 HARDWARE 12V	Spare Part	38196	15%
64	02.026.28.0.PR	KG640I CONTROLLER UNIT	Spare Part	30230	15%
65	02.026.31.0.PR	KG640 CONTROLLER UNIT (SP-3 HARDWARE 12V)	Spare Part	33932	15%
66	02.026.32.0.PR	KG645 CONTROLLER UNIT WITH 4-20MA	Spare Part	39295	15%
67	02.026.34.0.PR	KG645E CONTROLLER UNIT SP 3 HARDWARE 12V	Spare Part	31504	15%
68	02.026.36.0.PR	KG640C CONTROLLER UNIT FOR CPCB4 ENGINE	Spare Part	39036	15%
69	02.026.61.0.PR	SEDEMAC GENSET CONTROL UNIT GC2111	Spare Part	61291	15%
70	02.027.05.0.00	BALL BEARING (20X47X14)	Spare Part	831	15%
71	02.029.04.0.00	RUBBER GROMMET	Spare Part	25	15%
72	02.030.03.0.00	INJECTOR WITH CONICAL SAC 'S' TYPE NOZZLE	Spare Part	5621	15%
73	02.030.08.0.00	INJECTOR	Spare Part	9209	15%
74	02.035.08.0.00	BUSH FOR INJECTOR	Spare Part	138	15%
75	02.036.03.0.00	RUBBER SLEEVE	Spare Part	25	15%
76	02.037.04.0.00	DIPSTICK GUIDE	Spare Part	43	15%
77	02.037.06.0.00	DUAL BANJO BOLT-M8	Spare Part	92	15%
78	02.045.08.0.00	JOINT : EXH INLET	Spare Part	43	15%
79	02.050.10.0.SP	SET OF JOINTS	Spare Part	2105	15%
80	02.051.10.0.00	SET OF O RINGS: HA294	Spare Part	1098	15%
81	02.052.04.0.00	CYLINDRICAL DOWEL BETWEEN CR.CASE AND F.W.HSG.	Spare Part	74	15%
82	02.053.02.0.00	COUNTER WEIGHT	Spare Part	997	15%
83	02.053.10.0.00	CRANKSHAFT ASSLY WITH GEAR	Spare Part	52138	15%
84	02.055.10.0.00	HA2 FUEL PUMP ASSLY	Spare Part	58199	15%
85	02.056.50.0.00	LUBE OIL PUMP ASSLY WITH DRVG GEAR	Spare Part	6840	15%
86	02.058.01.0.00	AIR INLET M'FOLD: HA2 FINISH	Spare Part	3381	15%
87	02.058.07.0.00	JOINT: AIR INLET MANIFOLD	Spare Part	65	15%
88	02.059.01.0.00	EXHAUST M'FOLD: HA2	Spare Part	2545	15%
89	02.060.20.0.00	SET OF JOINTS	Spare Part	2923	15%
90	02.061.01.0.00	LOWER COWLING	Spare Part	1040	15%
91	02.062.01.0.00	TOP AIR BAFFLE	Spare Part	415	15%
92	02.063.01.0.00	REAR COWLING	Spare Part	1388	15%
93	02.064.10.0.00	EXHAUST AIR BAFFLE	Spare Part	769	15%
94	02.067.20.0.00	COOLING AIR BLOWER ASSLY	Spare Part	17231	15%
95	02.068.10.0.00	UPPER COWLING ASSLY	Spare Part	1492	15%
96	02.069.01.0.00	BREATHER TUBE	Spare Part	458	15%
97	02.069.03.0.00	STOPPER FOR BREATHER TUBE	Spare Part	37	15%
98	02.071.01.0.00	V BELT: A46	Spare Part	529	15%
99	02.074.02.0.00	LUBE OIL PIPE	Spare Part	994	15%
100	02.078.05.0.00	FRONT COVER	Spare Part	15009	15%
101	02.081.01.0.00	DELIVERY TUBE	Spare Part	794	15%
102	02.083.02.0.00	SEALING RING - LUBE OIL COOLER	Spare Part	191	15%
103	02.083.04.0.00	LUBE OIL COOLER- ALUMINIUM	Spare Part	13923	15%
104	02.083.56.0.00	RS485 HIGH VOLTAGE 300V AC OR 250 DC PROTECTION KIT	Spare Part	1046	15%
105	02.088.20.0.00	SUB ASSLY LEAK OFF PIPE	Spare Part	437	15%
106	02.091.01.0.00	EXHAUST M'FOLD CUM SILENCER WITH CLIP	Spare Part	6031	15%
107	02.102.02.0.00	FUEL PIPE: 7.5 14X14B- 700 WB	Spare Part	2095	15%
108	02.102.13.0.00	FUEL PIPE RETURN FIP TO TANK	Spare Part	4640	15%
109	02.1031.01.0.00	FRONT COVER	Spare Part	8834	15%
110	02.1033.06.0.00	HEADER (TOP) FOR SPIN ON FILTER FINISH	Spare Part	8449	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
111	02.1033.09.0.00	JOINT: CRANKCASE & HEADER	Spare Part	46	15%
112	02.1033.20.0.00	HEADER ASSEMBLY	Spare Part	9264	15%
113	02.1035.01.0.00	BRACKET: ALTERNATOR	Spare Part	886	15%
114	02.104.02.0.00	SAE 1 FLYWHEEL HOUSING SUITABLE FOR DOWEL MTG	Spare Part	18126	15%
115	02.1046.01.0.00	EXHAUST MANIFOLD	Spare Part	2345	15%
116	02.1047.01.0.00	CRANK PULLEY	Spare Part	3406	15%
117	02.112.01.0.00	PLATE FOR FUEL FILTER MTG	Spare Part	972	15%
118	02.116.10.0.00	FLYWHEEL ASSEMBLY	Spare Part	45738	15%
119	02.118.01.0.00	LEVER FOR ENGINE STOPPING	Spare Part	89	15%
120	02.120.04.0.00	SLEEVE: NOZZLE	Spare Part	154	15%
121	02.120.30.0.00	CYLINDER HEAD ASSLY	Spare Part	25677	15%
122	02.121.01.0.00	BELT GUARD : FRP	Spare Part	3609	15%
123	02.1216.01.0.00	WIRING HARNESS TIE 200MM LENGTH IN BLACK COLOUR	Spare Part	15	15%
124	02.124.01.0.00	BEARING HOUSING	Spare Part	6437	15%
125	02.1263.10.0.00	CRANKCASE ASSEMBLY	Spare Part	79556	15%
126	02.1263.20.0.00	CRANKCASE ASSEMBLY	Spare Part	81996	15%
127	02.1266.01.0.00	BELT (AVX 10 1500)	Spare Part	837	15%
128	02.1266.03.0.00	BELT: AVX 10 1545 SPZ	Spare Part	738	15%
129	02.1268.01.0.00	ALTERNATOR MTG BRACKET	Spare Part	2169	15%
130	02.182.10.0.00	PISTON ASSEMBLY	Spare Part	8711	15%
131	02.182.30.0.00	PISTON RING SET (TC)	Spare Part	2089	15%
132	02.183.01.0.00	CYLINDER LINER	Spare Part	5628	15%
133	02.238.01.0.00	ADAPTOR PEPPER POT SILENCER	Spare Part	1406	15%
134	02.240.40.0.PR	POWER PANEL ASSEMBLY FOR APU 3 5 KW	Spare Part	397192	15%
135	02.243.49.0.PR	7 5KW APU FUEL LEVEL SENSOR	Spare Part	12892	15%
136	02.298.90.0.00	SET HIGH PRESS PIPE HA294	Spare Part	1745	15%
137	02.302.01.0.00	ADAPTOR: LONG EXTENSION SHAFT BELT	Spare Part	1357	15%
138	02.320.02.0.00	SPINON LUBE FILTER CTG HA294	Filter	1061	20%
139	02.322.01.0.00	EXHAUST SILENCER	Spare Part	7437	15%
140	02.322.03.0.00	RAIN CAP	Spare Part	1049	15%
141	02.342.05.0.00	FUEL PIPE: NOZZLE OVERFLOW TO FUEL TANK	Spare Part	529	15%
142	02.347.03.0.00	RUBBER PAD FOR FUEL TANK MOUNTING	Spare Part	215	15%
143	02.347.04.0.00	SPECIAL STUD FOR FUEL TANK	Spare Part	145	15%
144	02.365.20.0.00	WIRING HARNESS: HA294 WITH ALT	Spare Part	2618	15%
145	02.401.10.0.00	DIPSTICK ASSLY	Spare Part	123	15%
146	02.408.05.0.00	FUEL PIPE RETURN WITH UNION NUT	Spare Part	920	15%
147	02.408.06.0.00	FUEL PIPE INLET M14X15 BANJO ONE SIDE M16X15 UNION	Spare Part	923	15%
148	02.410.03.0.PR	AUTOLEC STARTER 12V STMRVH-1106 NEW	Spare Part	22492	15%
149	02.411.02.0.00	FUEL LEVEL GAUGE MECH:DIAL 95 MM	Spare Part		15%
150	02.422.40.0.00	VALVE PAIR: HA CROME PLATED	Spare Part		15%
151	02.424.02.0.00	ENGINE SAFETY UNIT 12/24V 6 LED	Spare Part		15%
152	02.424.05.0.00	ESU 6LPD TYPE: V BELT & HOOTER O/P 12VDC	Spare Part		15%
153	02.438.23.0.00	HARD WASHER 11 I D X 19 O D X 1 5 TH	Spare Part		15%
154	02.443.35.0.00	PISTON ASSEMBLY	Spare Part	6471	15%
155	02.443.50.0.00	PISTON ASSEMBLY COMPLETE	Spare Part		15%
156	02.445.04.0.00	VALVE SEAT INSERT-INLET	Spare Part		15%
157	02.445.05.0.00	VALVE SEAT INSERT -EXHAUST	Spare Part		15%
158	02.445.10.0.00	VALVE PAIR INLET & EXHAUST	Spare Part		15%
159	02.447.08.0.00	INJECTOR	Spare Part		15%
160	02.448.10.0.00	CAMSHAFT AND GEAR ASSEMBLY	Spare Part		15%
161	02.466.20.0.00	PISTON ASSEMBLY	Spare Part		15%
162	02.468.80.0.PR	CONTROL PANEL SCHEMATIC FOR 15KVA 3PH WITH KG640 IP A	Spare Part		15%
163	02.468.90.0.PR	CONTROL PANEL SCHEMATIC FOR 15KVA 3FR WITH R6040 IP A CONTROL PANEL SCHEMATIC FOR 15KVA 1PH WITH K6640 IP A	Spare Part		15%
164	02.469.80.0.PR	CONTROL PANEL SCHEMATIC FOR 15KVA 1PH WITH KG640 IP A CONTROL PANELSCHEMATIC FOR 15KVA 3PH HA2 WITH KG640, IP+B	Spare Part	78402	15%
		L GONTINGE FAMELOGIEIVIATIG FOR TORVA OFFI TIAZ WITH NG040, IPTD	i Suare Part	/ 041//	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
166	02.477.01.0.00	STOP SOLENOID WITH 12V 10A 75MM	Spare Part	11655	15%
167	02.478.20.0.00	SUB ASSEMBLY OF ENGINE STOPPING LEVER	Spare Part	895	15%
168	02.480.04.0.00	ADAPTOR: LUBE OIL SUPPLY TO FP& PR GAUGE SENDOR	Spare Part	138	15%
169	02.480.10.0.00	FUEL PUMP: HA294 LLA-LLR	Spare Part	97460	15%
170	02.481.01.0.00	INJECTOR	Spare Part	10184	15%
171	02.486.42.0.PR	FUEL RETURN PIPE M12X1 5 ADAPTOR AND M14X1 5 UNION NUT	Spare Part	1498	15%
172	02.492.01.0.00	ANTI VIBRATION MOUNTS	Spare Part	1480	15%
173	02.494.01.0.00	BUTTON FOR INECTOR YOKE	Spare Part	108	15%
174	02.500.08.0.00	HOSE CLAMP -CONST PRESS SPR BAND	Spare Part	52	15%
175	02.500.30.0.00	NOZZLE LEAK OFF PIPE	Spare Part	523	15%
176	02.508.38.0.PR	DIGITAL LINE VOLTAGE MONITOR MODEL VMRD MSP PROTON MAKE 3PH 1PH 2 C O	Spare Part	7065	15%
177	02.519.06.0.00	DEFLECTOR PLATE (HA - LIGHT WEIGHT C'CASE)	Spare Part	487	20%
178	02.520.02.0.00	JOINT: FRONT COVER	Spare Part	443	15%
179	02.523.10.0.00	FLYWHEEL ASSEMBLY	Spare Part	31206	15%
180	02.523.20.0.00	FLYWHEEL: SUB ASSLY	Spare Part	20166	15%
181	02.525.06.0.00	FUEL HOSE 5.1 D X11.5 X12.7 O	Spare Part	52	15%
182	02.525.10.0.00	COMBINED LEAK OFF PIPE NOZZLE TO FIP	Spare Part	797	15%
183	02.525.12.0.00	FUEL HOSE HP LEAKOFF PIPE TO TANK PIPE	Spare Part	200	15%
184	02.525.20.0.00	COMB LEAKOFF PIPE NOZZLE TO FIP	Spare Part	911	15%
185	02.525.50.0.00	COMBINED LEAK OFF PIPE: HA2	Spare Part	923	15%
186	02.526.07.0.00	FUEL FILLING HOSE 'S' TYPE	Spare Part	1951	15%
187	02.528.03.0.00	FLYWHEEL HOUSING	Spare Part	16455	15%
188	02.532.01.0.00	ENGINE MOUNTING FOOT G.E.(F.P. SIDE)	Spare Part	2612	15%
189	02.532.02.0.00	ENGINE MOUNTING FOOT GE (FP SIDE)	Spare Part	2769	15%
190	02.532.03.0.00	ENGINE MOUNTING FOOT FOR FWE STARTER SIDE	Spare Part	711	15%
191	02.532.04.0.00	ENGINE MOUNTING FOOT FOR FWE FUEL PUMP SIDE	Spare Part	711	15%
192	02.534.10.0.00	CAM SHAFT ASSEMBLY (WITH 18 MM CAM GEAR)	Spare Part	18378	15%
193	02.535.01.0.00	FUEL PUMP GEAR	Spare Part	3003	15%
194	02.536.03.0.00	INTERMEDIATE GEAR SUPPORT	Spare Part	1098	15%
195	02.536.10.0.00	INTERMEDIATE GEAR ASSEMBLY	Spare Part	2289	15%
196	02.537.01.0.00	CRANKSHAFT GEAR (18MM WIDTH)	Spare Part	3095	15%
197	02.537.10.0.00	CRANKSHAFT ASSLY WITH GEAR	Spare Part	61510	15%
198	02.538.04.0.00	EXPANSION BELLOW	Spare Part	7169	15%
199	02.538.10.0.00	RESIDENTIAL SILENCER	Spare Part	15501	15%
200	02.538.12.0.00	RAIN CAP	Spare Part	1726	15%
201	02.538.50.0.00	SILENCER	Spare Part	14329	15%
202	02.538.70.0.00	SILENCER: HA2 9" DIA BODY	Spare Part	14818	15%
203	02.538.81.0.PR	SILENCER ASSEMBLY	Spare Part	18871	15%
204	02.539.30.0.00	LUBE OIL SUMP	Spare Part	3335	15%
205	02.541.02.0.00	AIR CLEANER ELEMENT	Filter	1606	20%
206	02.542.02.0.00	BELT (AX60)	Spare Part	1065	15%
207	02.542.05.0.00	AIR CLEANER ELEMENT	Filter	613	20%
208	02.542.06.0.00	BRACKET: AIR FILTER	Spare Part	732	15%
209	02.542.10.0.00	AIR CLEANER ASSLY: DRY TYPE	Spare Part	2586	20%
210	02.542.13.0.00	AIR INLET HOSE	Spare Part	495	15%
211	02.542.18.0.00	AIR INLET HOSE	Spare Part	1665	15%
212	02.542.21.0.PR	HOSE FOR AIR CLEANER	Spare Part	2422	15%
213	02.542.30.0.00	DRY TYPE AIR CLEANER ASSLY FOR HA2	Spare Part	2878	20%
214	02.544.04.0.00	FUEL FILLING HOSE	Spare Part	1938	15%
215	02.544.05.0.00	DRAIN PIPE: LUBE OIL SUMP- HA294	Spare Part	2372	15%
216	02.545.06.0.00	EXPANSION BELLOW 2.5": 2PLY	Spare Part	4585	15%
217	02.556.10.0.00	SUCTION TUBE ASSLY	Spare Part	658	15%
218	02.567.10.0.00	WIRING HARNESS ASSLY	Spare Part	5083	15%
219	02.568.01.0.00	SPACER (DIA 20 O.D x DIA.11 I.D & 70 mm LENGTH)	Spare Part	148	15%
220	02.570.10.0.00	ENGINE WIRING HARNESS	Spare Part	4548	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
221	02.571.05.0.00	FRONT COWLING	Spare Part	837	15%
222	02.571.06.0.00	REAR COWLING	Spare Part	1138	15%
223	02.571.20.0.00	HOT AIR DUCTING	Spare Part	5181	15%
224	02.571.30.0.00	HOT AIR DUCTING: COM SIDE OPEN	Spare Part	3111	15%
225	02.571.50.0.00	HOT AIR DUCTING	Spare Part	5585	15%
226	02.583.10.0.00	COMBINED LEAK OFF PIPE NOZZLE TO PUMP (M12 BANJO)	Spare Part	563	15%
227	02.585.03.0.00	DOUBLE ROW ANGULAR CONTACT BALL BEARING	Spare Part	11348	15%
228	02.585.12.0.00	GEAR: 21 T AUX HYD PUMP	Spare Part	3169	15%
229	02.589.01.0.00	FAN: 12" 11 BLADES S/F	Spare Part	3839	20%
230	02.589.04.0.00	ADAPTOR ON CRANK PULLEY FOR FAN MOUNTING CI	Spare Part	2760	15%
231	02.594.01.0.SP	FLYWHEEL HSG MACHINING SAE 1 S F COST REDUCTION	Spare Part	34076	15%
232	02.595.10.0.00	FLYWHEEL ASSLY	Spare Part	51276	15%
233	02.618.100.0.PR	PISTON ASSEMBLY COMPLETE HA294 CPCB II	Spare Part	7231	15%
234	02.618.30.0.00	PISTON ASSEMBLY	Spare Part	5591	15%
235	02.618.80.0.00	PISTON ASSEMBLY	Spare Part	5865	15%
236	02.619.90.0.00	SET OF HIGH PRESSURE PIPE: HA294	Spare Part	1923	15%
237	02.637.01.0.00	BELT: SPZ AVX10 X 1564	Spare Part	982	15%
238	02.650.01.0.00	ANTI VIBRATION MOUNTS	Spare Part	1348	15%
239	02.650.02.0.00	ANTI VIBRN MTG -ALTERNATOR	Spare Part	1403	15%
240	02.650.03.0.00	ANTI VIBRATION MOUNTS	Spare Part	1366	15%
241	02.663.10.0.00	FUEL PUMP MOUNTED STOP SOLEND	Spare Part	7169	15%
241	02.665.10.0.00	KIT GROUP ASSEMBLY FOR CONVERSION OF HORIZONTAL STOP SOLENOID TO VERTICAL PUM	Spare Part	15600	15%
243	02.687.01.0.00	FUEL PUMP: HA294 CMVR STAGE I	Spare Part	42030	15%
243	02.689.30.0.00	PISTON ASSLY 3 RING CMVR-II		8188	15%
			Spare Part		15%
245	02.692.01.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	966 1151	15%
246	02.692.02.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part		
247	02.692.06.0.00	FUEL PIPE FUELFILTER TO FUEL PUMP	Spare Part	1114	15%
248	02.692.07.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	763	15%
249	02.701.02.0.00	12 V DC RELAY BOARD TWO RELAY	Spare Part	4495	15%
250	02.709.05.0.00	GENSET CONTROL UNIT EMS 927V3/V4	Spare Part	59341	15%
251	02.709.22.0.00	GLASS FUSE 1AMP 20 MM	Spare Part	28	15%
252	02.709.23.0.00	12V DC, 88Ah, Lead Acid Kirloskar Green Battery	Battery	15558	15%
253	02.709.24.0.PR	12V DC, 75Ah, Lead Acid Kirloskar Green Battery	Battery	14361	15%
254	02.709.25.0.00	12V DC, 65Ah, Lead Acid Kirloskar Green Battery	Battery	13873	15%
255	02.712.06.0.00	FUEL PIPE PRE-FILTER TO TANK	Spare Part	683	15%
256	02.731.08.0.00	12V DC, 130Ah, Lead Acid Kirloskar Green Battery	Battery	23994	15%
257	02.731.33.0.00	12V DC, 180Ah, Lead Acid Kirloskar Green Battery	Battery	34408	15%
258	02.731.40.0.00	12V DC 110AH SMF BATTERY MODEL SMF N100 SEBANG GLOBAL BATTERY	Spare Part		15%
259	02.751.12.0.00	FUEL INLET PIPE	Spare Part	1052	15%
260	02.751.21.0.PR	FUEL INLET PIPE M14X1 5 BANJO AND M16X1 5 UNION NUT	Spare Part	1855	15%
261	02.752.41.0.00	PLASTIC FUEL SPOUT AND CAP	Spare Part		15%
262	02.759.14.0.PR	EMERGENCY PUSH BUTTON WITH NO CONTACT NON LACHABLE TEKNIC MAKE P2AM4 S1	Spare Part		15%
263	02.759.21.0.PR	LEFT HAND LOCK WITH CATCHER PADLOCK ARRANGEMENT UPTO 10 KVA	Spare Part		15%
264	02.759.22.0.PR	RIGHT HAND LOCK WITH CATCHER PADLOCK ARRANGEMENT UPTO 10 KVA	Spare Part	2314	15%
265	02.759.23.0.PR	LEVER LOCK FOR CANOPY	Spare Part		15%
266	02.759.31.0.PR	LEFT HAND LOCK WITH CATCHER PADLOCK ARRANGEMENT RELIENCE INFRA	Spare Part		15%
267	02.759.32.0.PR	RIGHT HAND LOCK WITH CATCHER PADLOCK ARRANGEMENT RELIENCE INFRA	Spare Part	2366	15%
268	02.771.39.0.00	FUSE TERMINAL	Spare Part		15%
269	02.804.12.0.00	DIODE FORWORD BAIS FOR KG15ST TO KG30ST ALTERNATOR TYPE	Spare Part	942	15%
270	02.804.13.0.00	DIODE REVERSE BAIS FOR KG15ST TO KG30ST ALTERNATOR TYPE	Spare Part	942	15%
271	02.804.15.0.00	EXCITER ROTOR	Spare Part	10068	15%
272	02.804.21.0.00	TERMINAL BLOCK: KG15ST-30ST	Spare Part	1194	15%
273	02.811.01.0.ASP	RRA Condenser Diode, Varistor	Spare Part	15351	15%
274	02.811.03.0.ASP	" SAE 3, DE BRKT- PROT. SCREEN ASLY ? KG28. KVA Rating:- (15-20, 1Ph & 20-30, 3Ph). Meccalte	Spare Part	21729	15%
275	02.811.05.0.ASP	EXCITOR STATOR KG28 KG32 S H 45mm 6P KVA Rating 15 20 1Ph 20 30 3Ph 25 1Ph	Spare Part	25953	15%



				Duine to	
				Price to Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
				NPR	
276	02.811.06.0.ASP	EXCITOR ROTOR WITH RRA KG28 KG32 S H 45 6P KVA Rating 15 20 1Ph	Spare Part	33941	15%
277	02.811.09.0.ASP	COUPLING DISC SET WITH HARDWARE- 15/20 KVA 1 PHASE	Spare Part	9649	15%
278	02.840.50.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	11452	15%
279	02.840.60.0.00	ENGINE WIRING HARNESS ASSLY WITH FUEL LEVEL GEMS SENSOR	Spare Part	10584	15%
280	02.846.11.0.00	LUBE OIL PRESSURE SWITCH FOR HONEYWELL MAKE	Spare Part	3668	15%
281	02.846.12.0.PR	LUBE OIL PRESSURE SWITCH HONEYWELL PART NO 76068 29	Spare Part	5465	15%
282	02.846.60.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	7769	15%
283	02.847.30.0.PR	ENGINE WIRING HARNESS FOR 15KVA HA2 EMERALD	Spare Part	7058	15%
284	02.854.57.0.00	12V RELAY BOARD 1A-70A	Spare Part	1342	15%
285	02.859.06.0.00	3 Phase 12V Rear Mounting w/o Display	Spare Part	7760	15%
286	02.870.05.0.00	12 VDC RELAY BOARD THREE CHANNEL	Spare Part	4271	15%
287	02.872.18.0.00	BATTERY CHARGER 10A 12 VDC	Spare Part	8077	15%
288	02.872.22.0.PR	BATTERY CHARGER 10A NHP MAKE 12VDC TYPE-R5H17-12V-10A	Spare Part	7849	15%
289	02.887.03.0.00	4 POLE 50 AMP MCB	Spare Part	9600	15%
290	02.901.01.0.PR	KOEL GREEN Alternator, KG 15 S S Frame: L KG 42.3 A, SAE-2 11.5",230V, 50 Hz, 0.8 PF	Spare Part	200687	15%
291	02.901.03.0.PR	KOEL GREEN Alternator, KG 15 S T Frame: L KG 40 E, SAE-2 11.5", 415V, 50 Hz, 0.8 PF	Spare Part	156564	15%
292	02.910.10.0.00	WIRING HARNESS WITH SOCKET	Spare Part	3523	15%
293	02.920.20.0.00	WIRING HARNESS: 15KVA	Spare Part	6923	15%
294	02.930.10.0.00	ASSEMBLY OF AIR GUIDE RING & BRUSH	Spare Part	2705	15%
295	02.935.10.0.00	WIRING HARNESS ASSLY S/F HA2	Spare Part	4889	15%
296	02.938.20.0.00	WIRING HARNESS ASSLY WITH CLD	Spare Part	4975	15%
297	02.938.70.0.00	WIRING HARNESS ASSLY	Spare Part	5834	15%
298	02.944.11.0.00	DOUBLE POLE MCB 6A	Spare Part	2502	15%
299	02.944.12.0.00	DOUBLE POLE MCB 16A	Spare Part	2548	15%
300	02.944.76.0.00	POWER TERMINAL	Spare Part	243	15%
301	02.944.78.0.00	POWER TERMINAL	Spare Part	1517	15%
302	02.945.08.0.00	GLASS FUSE LINK 15A 20 MM	Spare Part	25	15%
303	02.950.10.0.00	BATTERY CABLE ASSEMBLY 21 SQ.MM	Spare Part	3880	15%
304	02.958.10.0.PR	CONTROL PANEL ASSEMBLY HA VE VE	Spare Part	31889	15%
305	02.958.30.0.00	WIRING HARNESS: HA294 INDUSTRIAL VA/VE	Spare Part	4255	15%
306	02.959.10.0.PR	CONTROL PANEL ASSEMBLY HA VA/VE OEM BASED	Spare Part	46052	15%
307	02.959.30.0.00	WIRING HARNESS ASSEMBLY HA294 VA VE OEM BASED	Spare Part	5621	15%
308	02.961.14.0.00	4 PIN POWERMATE MALE HOUSING	Spare Part	65	15%
309	02.961.15.0.00	6 PIN MALE HOUSING	Spare Part	89	15%
310	02.961.16.0.00	6 PIN CONNECTOR	Spare Part	108	15%
311	02.961.17.0.00	10 PIN CONNECTOR	Spare Part	138	15%
312	02.961.60.0.00	CONNECTOR ASSEMBLY FOR CONTROL PANEL WITH L0 CONTROLLER	Spare Part	582	15%
313	02.974.37.0.00	SINGLE POLE MCB 10A A9N1P10C SCHNEIDER MAKE	Spare Part	1212	15%
314	02.991.33.0.00	DSE2157 DSENet OUTPUT EXPANSION MODULE	Spare Part	53412	15%
315	02.999.11.0.00	B KIT OVERHAUL HA294 - KTL	Spare Part	32240	15%
316	02.999.13.0.00	PUSH ROD KIT: HA2	Spare Part	483	15%
317	02.999.17.0.00	ONE TIME FILTER KIT 0.5 LTR	Filter	548	20%
318	02.999.35.0.00	HA 294 (PG) SERVICE KIT - B CHECK	Filter	588	20%
319	02.999.36.0.00	HA294 SR II/394 PG SERV KIT B CHK	Filter	1863	20%
320	02.999.37.0.00	HA294 (PG) SERVICE KIT WITH AIR FILTER C CHK	Filter	2020	20%
321	02.999.38.0.00	HA294 SR II PG SERVICE KIT WITH AIR FILTER -C CHECK	Filter	2410	20%
322	02.999.60.0.00	HALF OVERHAUL KIT FOR HA494	Spare Part	45633	15%
323	02.999.80.0.00	MAJOR OVERHAUL KIT	Spare Part	58021	15%
324	02.999.91.0.SP	CONVERSION KIT FROM KG 934 TO KG 645	Spare Part	47202	15%
325	02.999.92.0.SP	CONVERSION KIT FROM KG 541 TO KG 645 FOR DC CARD	Spare Part	39384	15%
326	02.999.93.0.SP	CONVERSION KIT FROM KG 541 TO KG 645 FOR AC+DC CARD	Spare Part	44719	15%
327	02.999.94.0.SP	CONVERSION KIT FROM KG 541 TO KG 640 FOR DC CARD	Spare Part	35403	15%
328	02.999.95.0.SP	CONVERSION KIT FROM KG 541 TO KG 640 FOR AC+DC CARD	Spare Part	43578	15%
329	02.999.96.0.SP	CONVERSION KIT FROM KG 541 TO KG 640 FOR CHHOTA CHILLI	Spare Part	34052	15%
330	02.M801.09.0.00	NEGATIVE INSULATED STARTER 12 VDC 2 WIRE 2 7KW	Spare Part	47507	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
331	02.M801.10.0.00	CYL HEAD TEMP SWITCH 2 WIRE MAKE RICO	Spare Part	4566	15%
332	03.001.04.0.00	CAM BUSH	Spare Part	382	15%
333	03.001.06.0.00	SCREW PLUG	Spare Part	145	15%
334	03.001.07.0.00	SLOTTED PIN	Spare Part	28	15%
335	03.001.08.0.00	DEFLECTOR PLATE	Spare Part	255	15%
336	03.001.12.0.00	PRECOATED STUD (FOR FUEL PUMP MOUNTING)	Spare Part	68	15%
337	03.001.22.0.00	BOLT : MB CAP HEX HEAD M14X2X128	Spare Part	255	15%
338	03.001.25.0.00	WASHERFOR FUEL PUMP MOUNTING	Spare Part	18	15%
339	03.001.50.0.00	CRANKCASE ASSEMBLY	Spare Part	117257	15%
340	03.003.11.0.00	GASKET: FUEL PUMP	Spare Part	31	15%
341	03.003.60.0.00	OVERFLOW VALVE ASSLY	Spare Part	446	15%
342	03.005.02.0.00	CRANKSHAFT GEAR	Spare Part	2938	15%
343	03.006.02.0.00	THRUST WASHER FOR CAMSHAFT	Spare Part	228	15%
344	03.006.03.0.00	BUSH FOR TACHOMETER	Spare Part	46	15%
345	03.006.04.0.00	CAMSHAFT GEAR	Spare Part	3218	15%
346	03.006.10.0.00	CAMSHAFT & GEAR ASSLY	Spare Part	21969	15%
347	03.007.01.0.00	OIL SEAL HOUSING: F	Spare Part	1960	15%
348	03.007.04.0.00	JOINT FOR OIL SEAL HSG	Spare Part	58	15%
349	03.007.06.0.00	OIL SEAL(115X140X12)	Spare Part	3058	15%
350	03.007.91.0.00	ROTARY SHAFT SEAL TEFLON	Spare Part	2166	15%
351	03.008.05.0.00	INTERMEDIATE GEAR SUPPORT	Spare Part	1200	15%
352	03.008.06.0.00	SPLIT BUSH : SUPPORT	Spare Part	58	15%
353	03.008.10.0.00	INTERMEDIATE GEAR ASSLY	Spare Part	4741	15%
354	03.010.02.0.00	SCREEN PLATE	Spare Part	65	15%
355	03.010.11.0.00	O RING: L.O. PUMP 1.57X65 - 21508	Spare Part	65	15%
356	03.010.13.0.00	RELIEF VALVE	Spare Part	68	15%
357	03.010.14.0.00	SPRING: RELIEF VALVE	Spare Part	31	15%
358	03.010.50.0.00	LUBE OIL PUMP ASSLY WITH DRVG GEAR	Spare Part	7461	15%
359	03.011.02.0.00	UNION SCREW	Spare Part	182	15%
360	03.011.03.0.00	DOUBLE CONE RING	Spare Part	188	15%
361	03.011.04.0.00	CLIP FOR PIPE	Spare Part	86	15%
362	03.012.02.0.00	O RING: DELIVERY TUBE: 3X14- 21508	Spare Part	49	15%
363	03.012.04.0.00	YOKE SPRING (PIPE CLAMP)	Spare Part	397	15%
364	03.012.11.0.00	DELIVERY TUBE	Spare Part	532	15%
365	03.013.03.0.00	COVER	Spare Part	274	15%
366	03.013.04.0.00	O RING: 3X78 SILICONE	Spare Part	68	15%
367	03.013.05.0.00	JOINT: FRONT COVER	Spare Part	166	15%
368	03.013.06.0.00	OIL SEAL (65X85X13)	Spare Part	1914	15%
369	03.013.11.0.00	O RING (3.2 X 78 SILICON)	Spare Part		15%
370	03.013.12.0.00	JOINT FOR FRONT COVER(ASBESTOSS FREE)	Spare Part	1745	15%
371	03.013.91.0.00	ROTARY SHAFT SEAL(GE) TEFLON	Spare Part	1422	15%
372	03.014.05.0.00	TACHOMETER PLUG	Spare Part	268	15%
373	03.014.06.0.00	SPRING FOR CUP	Spare Part	71	15%
374	03.014.10.0.00	SUB ASSEMBLY OF SPRING TACHODRIVE CUP	Spare Part	138	15%
375	03.016.02.0.00	BOLT: CRANK PULLEY UPDATED 110MM	Spare Part	1388	15%
376	03.016.03.0.00	WASHER: CRANK PULLEY BOLT	Spare Part	31	15%
377	03.017.06.0.00	BREATHER TUBE	Spare Part	720	15%
378	03.019.01.0.00	LOWER COWLING	Spare Part	1738	15%
379	03.019.05.0.00	RUBBER GROMMET	Spare Part	163	15%
380	03.020.02.0.00	UNION SCREW	Spare Part	372	15%
381	03.020.03.0.00	DOUBLE CONE RING	Spare Part		15%
382	03.020.05.0.00	RUBBER BUSH	Spare Part	34	15%
383	03.020.06.0.00	SPACER	Spare Part	95	15%
384	03.020.08.0.00	SEALING RING	Spare Part	194	15%
JU4	03.021.01.0.00	FRONT COWLING	Spare Part		15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
386	03.022.01.0.00	TOP AIR BAFFLE	Spare Part	634	15%
387	03.022.02.0.00	RUBBER GROMMET	Spare Part	28	15%
388	03.022.03.0.00	RUBBER GROMMET	Spare Part	31	15%
389	03.023.01.0.00	REAR COWLING	Spare Part	1145	15%
390	03.023.02.0.00	SPECIAL PLAIN WASHER - M6	Spare Part	25	15%
391	03.024.20.0.00	ASSLY OF EXH AIR BAFFLE & SCREEN PLATE	Spare Part	1243	15%
392	03.025.15.0.00	FAN PULLEY (98 PCD, A SECTION, 2 GROOVES)	Spare Part	1209	15%
393	03.025.40.0.00	ASSLY OF COOLING BLOWER	Spare Part	17431	15%
394	03.027.04.0.00	BANJO BOLT	Spare Part	37	15%
395	03.027.07.0.00	LEAK OFF PIPE	Spare Part	369	15%
396	03.027.10.0.00	LEAK OFF PIPE ASSLY	Spare Part	449	15%
397	03.027.20.0.00	LEAK OFF PIPE SUB ASSLY	Spare Part	769	15%
398	03.029.10.0.00	COWLING ASSLY: WELDED	Spare Part	1991	15%
399	03.030.05.0.00	SPACER(11 X 18 X18 L)	Spare Part	52	15%
400	03.033.10.0.00	SCREEN PLATE ASSEMBLY	Spare Part	289	15%
401	03.034.01.0.00	STARTER 12V	Spare Part	29661	15%
402	03.035.02.0.00	STARTER RING 121T 3.175MOD	Spare Part	3723	15%
403	03.035.03.0.00	BOLT : FLYWHEEL M10X35 LONG	Spare Part	102	15%
404	03.036.01.0.00	O RING: DIPSTICK 2X5 21515	Spare Part	25	15%
405	03.036.10.0.00	DIPSTICK ASSLY	Spare Part	154	15%
406	03.037.01.0.00	INLET MANIFOLD	Spare Part	5043	15%
407	03.037.04.0.00	V BELT A49 1278 LENGTH	Spare Part	28	15%
408	03.040.03.0.00	SEALING RING: BOWL 89X102X3.2T	Spare Part	83	15%
409	03.040.06.0.00	BANJO BOLT	Spare Part	95	15%
410	03.040.07.0.00	JOINT: LUBE FILTER ASBESTOS FREE	Spare Part	37	15%
411	03.040.11.0.00	LUBE OIL FILTER HEADER	Spare Part	2708	15%
412	03.040.19.0.00	LUBE OIL FILTER ELEMENT	Filter	263	20%
413	03.041.10.0.00	MOUNTING ASSLY: LUBE OIL FILTER	Spare Part	4889	15%
414	03.047.01.0.00	BLANKING PLATE	Spare Part	338	15%
415	03.049.07.0.00	MUD SLINGER GE SIDE	Spare Part	154	15%
416	03.050.02.0.00	FLYWHEEL BOLT: M10X50	Spare Part	105	15%
417	03.050.10.0.00	FLYWHEEL ASSEMBLY	Spare Part	46227	15%
418	03.050.75.0.PR	FLYWHEEL ASSEMBLY	Spare Part	43966	15%
419	03.052.03.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	554	15%
420	03.052.06.0.00	BRACKET FOR FUEL FILTER	Spare Part	538	15%
421	03.052.07.0.00	FUEL PIPE FUEL FILTER TO FIP	Spare Part	582	15%
422	03.052.08.0.00	FUEL PIPE: FEED PUMP TO FUEL FILTER INLET	Spare Part	729	15%
423	03.052.11.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	778	15%
424	03.052.12.0.00	FUEL PIPE FUEL FILTER TO FIP	Spare Part	612	15%
425	03.054.01.0.00	V BELT A49 1278 LENGTH	Spare Part	517	15%
426	03.056.01.0.00	GEAR END FOOT	Spare Part	7523	15%
427	03.057.01.0.00	CRANKCASE FOOT	Spare Part	2243	15%
428	03.059.01.0.00	BELT GUARD	Spare Part	4089	15%
429	03.059.03.0.00	SPACER FOR BELT GUARD ON FRONT COVER	Spare Part	108	15%
430	03.059.04.0.00	SPACER FOR BELT GUARD ON BT UNIT	Spare Part	77	15%
431	03.059.05.0.00	HEX SPACER FOR BELT GUARD ON GE FOOT	Spare Part	108	15%
432	03.059.06.0.00	SUPPORT FOR BELT GUARD ON FAN BODY	Spare Part	77	15%
433	03.060.05.0.00	SPACER: BELT GUARD	Spare Part	74	15%
434	03.060.08.0.00	WASHER	Spare Part	12	15%
435	03.060.11.0.00	SUPPORT FOR BELT GUARD ON FAN BODY	Spare Part	255	15%
436	03.061.20.0.00	AIR CLEANER ASSLY	Spare Part	8123	15%
437	03.061.21.0.00	AIR CLEANER CLAMP	Spare Part	1006	15%
438	03.061.22.0.00	BOWL	Spare Part	222	15%
439	03.061.23.0.00	SEALING RING	Spare Part	191	15%
-100	00.001.20.0.00		Opaic rait	131	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer	Custom
				without Vat in NPR	Charge%
441	03.061.40.0.00	PRE CLEANER FOR AIR CLEANER	Spare Part	1794	15%
442	03.061.70.0.00	OIL BATH AIR CLEANER WITH RUBBER SLEEVE	Filter	6182	20%
443	03.063.01.0.00	BRACKET: AIR CLEANER	Spare Part	1711	15%
444	03.063.02.0.00	HOSE FOR AIR CLEANER: 70 IDX 80L	Spare Part	508	15%
445	03.064.05.0.00	BRACKET	Spare Part	335	15%
446	03.064.07.0.00	LINK FOR BALL JOINT	Spare Part	34	15%
447	03.064.09.0.00	BUSH	Spare Part	62	15%
448	03.064.11.0.00	WASHER FOR STOPPING LEVER	Spare Part	52	15%
449	03.064.20.0.00	SUB ASSEMBLY OF ENGINE STOPPING LEVER	Spare Part	655	15%
450	03.065.04.0.00	KNURLED NUT	Spare Part	52	15%
451	03.065.05.0.00	SPHERICAL WASHER	Spare Part	46	15%
452	03.065.30.0.00	ASSLY SPEED ADJUSTMENT UNIT S/F	Spare Part	138	15%
453	03.067.01.0.00	ADAPTOR: TEMP GAUGE	Spare Part	209	15%
454	03.068.10.0.SP	SET OF JOINTS	Spare Part	2458	15%
455	03.068.12.0.00	SET OF WASHERS	Spare Part	754	15%
456	03.069.10.0.00	SET OF O RINGS: HA394	Spare Part	1289	15%
457	03.069.30.0.00	SET OF COPPER WASHER	Spare Part	1071	15%
458	03.071.01.0.00	GEAR END FOOT	Spare Part	2142	15%
459	03.072.01.0.00	FLYWHEEL END FOOT FIL SIDE	Spare Part	812	15%
460	03.075.10.0.00	ADAPTOR: SPIN ON LOF	Spare Part	2975	15%
461	03.076.02.0.00	LIFTING HOOK	Spare Part	615	15%
462	03.080.03.0.00	O RING: B.T. UNIT 4X18-21511	Spare Part	49	15%
463	03.080.90.0.00	B.T. UNIT SUB ASSLY	Spare Part	8077	15%
464	03.080.91.0.00	BELT TENSION UNIT WITH ACTUATOR	Spare Part	8018	15%
465	03.081.10.0.00	LEAK OFF PIPE ASSLY	Spare Part	397	15%
466	03.086.02.0.00	COVER FOR FLYWHEEL HOUSING	Spare Part	151	15%
467	03.086.03.0.00	FLYWHEEL HOUSING	Spare Part	27772	15%
468	03.086.11.0.PR	GAS MIXER	Spare Part	115592	15%
469	03.087.01.0.00	CRANK PULLEY	Spare Part	6351	15%
470	03.088.03.0.00	SPACER (11 X 20 X 9 L)	Spare Part	37	15%
471	03.093.110.0.00	BELT TENSIONING PULLEY ASSEMBLY	Spare Part	5741	15%
472	03.093.90.0.00	B.T. UNIT SUB ASSLY	Spare Part	6901	15%
473	03.093.91.0.00	BELT TENSION UNIT WITH ACTUATOR	Spare Part	5745	15%
474	03.093.92.0.00	BELT TENSION SUB ASSLY WITH ACTUATOR	Spare Part	5052	15%
475	03.093.94.0.00	B.T. UNIT SUB ASSLY & ACTUATOR	Spare Part	6825	15%
476	03.095.01.0.00	ROCKER COVER	Spare Part	1582	15%
477	03.096.01.0.00	ADAPTOR FOR EXTension SHAFT	Spare Part	1431	15%
478	03.105.01.0.00	REAR COWLING	Spare Part	1462	15%
479	03.106.20.0.00	DUCTING & COVER ASSEMBLY FOR HYDRAULIC COOLER	Spare Part	3538	15%
480	03.107.02.0.00	BRACKET: ALTERNATOR	Spare Part	1074	15%
481	03.107.04.0.00	SPACER (11X20X24 L)	Spare Part	62	15%
482	03.107.05.0.00	SPACER (9X20X21L)	Spare Part	68	15%
483	03.108.03.0.00	FLYWHEEL HOUSING	Spare Part	22227	15%
484	03.109.03.0.00	SPECIAL WASHER	Spare Part	34	15%
485	03.113.01.0.00	PLATE FOR FUEL FILTER	Spare Part	760	15%
486	03.113.02.0.00	PLATE FOR FUEL FILTER	Spare Part	803	15%
487	03.114.02.0.00	JOINT: EXHAUST BEND	Spare Part	1397	15%
488	03.117.02.0.00	PIN	Spare Part	83	15%
489	03.117.04.0.00	ADAPTOR FOR TACHODRIVE	Spare Part	172	15%
490	03.119.04.0.00	U CLAMP	Spare Part	178	15%
491	03.119.05.0.00	CLAMPING PLATE (FOR U CLAMP)	Spare Part	185	15%
492	03.119.20.0.00	EXHAUST MANIFOLD: SILENCER WITH CLAMP	Spare Part	13934	20%
493	03.120.20.0.00	RAIN CAP SUB ASSLY	Spare Part	1363	15%
494	03.120.30.0.00	RAIN CAP SUB ASSLY	Spare Part	1898	15%
	03.120.40.0.00	SUB ASSEMBLY OF BEND & RAIN CAP	Spare Part	3218	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
496	03.121.05.0.00	SPACER	Spare Part	34	15%
497	03.121.06.0.00	PLATE FOR STOPPING BAR	Spare Part	194	15%
498	03.121.20.0.00	SUB-ASSEMBLY OF GUIDE PLATE & TORSION SPRING	Spare Part	194	15%
499	03.124.01.0.00	AMMETER -(50-0-50)AMPS	Spare Part	729	15%
500	03.128.01.0.00	ALTERNATOR PULLEY: 24V	Spare Part	1003	15%
501	03.128.02.0.00	BRACKET: ALTERNATOR MTG	Spare Part	1492	15%
502	03.128.03.0.00	DAMPING BUSH	Spare Part	77	15%
503	03.128.06.0.00	TENSION ADJUSTING LEVER	Spare Part	483	15%
504	03.128.08.0.00	BRACKET FOR ALTERNATOR	Spare Part	954	15%
505	03.130.01.0.00	ALTERNATOR: 24V	Spare Part	79737	15%
506	03.135.04.0.00	FAN PULLEY (82 PCD, A SECTION, 2 GROOVES)	Spare Part	1268	15%
507	03.135.40.0.00	ASSLY OF COOLING BLOWER	Spare Part	19187	15%
508	03.135.60.0.00	FAN BODY STATOR & IMPELL SUB ASSLY	Spare Part	18717	15%
509	03.137.06.0.00	EXHAUST FAN, 12", 230VAC, 1400RPM.	Spare Part	9332	15%
510	03.147.16.0.00	START PUSH BUTTON	Spare Part	625	15%
511	03.147.19.0.00	STOP PUSH BUTTON, (XB5 AA42N + 1NO)	Spare Part	800	15%
512	03.148.05.0.00	ALTERNATOR: 12V 35A	Spare Part	19323	15%
513	03.148.70.0.00	F002 G1B 704 CHARGINE ALTERNATOR 12v 35AMP WITH 2 WIRE SYSTEM	Spare Part	32815	15%
514	03.149.01.0.00	ALTERNATOR PULLEY F: 81 PCD	Spare Part	1277	15%
515	03.149.02.0.00	SPACER(11 X 20 X 6.5 L)	Spare Part	58	15%
516	03.149.03.0.00	TENSION ADJUSTING LEVER	Spare Part	252	15%
517	03.180.08.0.00	SPACER	Spare Part	135	15%
518	03.180.12.0.00	SPACER FOR HOT AIR DUCTING	Spare Part	132	15%
519	03.182.02.0.00	SPACER (BAR)	Spare Part	74	15%
520	03.190.10.0.00	ASSEMBLY A V MTG	Spare Part	2391	15%
521	03.199.01.0.00	BRACKET FOR STOPPING BAR	Spare Part	172	15%
522	03.203.01.0.00	BRACKET FOR PRRESSURE GAUGE SENDOR UNIT	Spare Part	98	15%
523	03.203.25.0.00	AIR CLEANER BRACKET	Spare Part	914	15%
524	03.203.29.0.00	HOSE: AIR CLEANER	Spare Part	2720	15%
525	03.203.33.0.00	REDUCER HOSE FOR AIR CLEANER	Spare Part	1351	15%
526	03.203.34.0.00	EXHAUST DIFFUSER	Spare Part	2874	15%
527	03.203.56.0.00	HOSE FOR AIR CLEANER	Spare Part	2052	15%
528	03.208.02.0.00	ADAPTOR FOR INLET CONNECTION	Spare Part	311	15%
529	03.215.83.0.00	ROTEX SOLENOID OPERATED FUEL MAGNET VALVE	Spare Part	38036	15%
530	03.215.98.0.00	RECIPROCATING AIR COMPRESSOR, MODEL: LL2/90T, 1500 RPM, FAD: 80 CUBIC METER/HR, 10.2	Spare Part	1558481	15%
531	03.216.71.0.00	AIR CLEANER FOR HA3 ENGINE	Spare Part	6547	20%
532	03.216.86.0.00	1 2 INCH BSP STRAIGHT MALE ADAPTOR LENGTH 42mm A F 22 25mm ID 14mm	Spare Part	2080	15%
533	03.217.24.0.00	AUTOMATIC VOLTAGE REGULATOR AVR	Spare Part	70624	15%
534	03.217.27.0.00	FUEL HOSE (1/2 INCH BSP X M14 -1500 LENGTH)	Spare Part	3148	15%
535	03.217.28.0.00	FUELTANK FOR 7 5 KW APU	Spare Part	14627	15%
536	03.217.29.0.00	FUEL LEVEL SENSOR CUM SWITCH	Spare Part	7252	15%
537	03.218.87.0.00	VULKAN COUPLING (VULASTIK-COUPLING BETWEEN ALTERNATOR & COMPRESSOR)	Spare Part	90439	15%
538	03.219.21.0.00	ENGINE WIRING HARNESS FOR HHP APU	Spare Part	36353	15%
539	03.219.27.0.00	SOLENOID DRAIN VALVE KIT SPERRE PART NO 57911	Spare Part	265769	15%
540	03.219.49.0.00	VULKAN COUPLING BETWEEN ALTERNATOR COMPRESSOR MEGIFLEX B COUPLING 1040S	Spare Part	75639	15%
541	03.219.57.0.00	1 INCH BSPP SWIVEL ELBOW ONE SIDE MALE ONE SIDE SWIVEL FEMALE MOC FORGED STEE	Spare Part	3200	15%
542	03.219.58.0.00	1 2 INCH BSP 90 DEG ELBOW BOTH SIDE MALE MOC FORGED STEEL 1000PSI	Spare Part	1483	15%
543	03.221.129.0.SP	AIR FILTER INSERT SPERRE PART NO 3720	Spare Part	103900	15%
544	03.221.180.0.SP	OVERHAUL KIT ROUTINE D 7951	Spare Part	2987865	15%
545	03.221.35.0.00	GASKET KIT VALVE LP SPERRE PART NO 3566	Spare Part	166269	15%
546	03.221.39.0.00	AIR FILTER SPERRE PART NO 3672	Spare Part	138887	20%
547	03.221.66.0.00	72V DC COIL FOR 2 2 DIRECT ACTING NORMALLY CLOSED SOLENOID VALVE SOLENOID VALVE	Spare Part	38624	15%
548	03.221.92.0.SP	SPARE KIT VALVE LP SPERRE PART NO 3596	Spare Part	704969	15%
549	03.221.93.0.SP	SPARE KIT VALVE LP SPERRE PART NO 3597	Spare Part	704969	15%
550	03.222.62.0.00	FUEL STRAINER	Spare Part	4348	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
			0 ,	without Vat in NPR	Charge%
551	03.222.95.0.00	VULKAN COUPLING (VULASTIK-COUPLING BETWEEN ALTERNATOR & COMPRESSOR)	Spare Part	87017	15%
552	03.224.01.0.00	EXHAUST FAN (450MM) WITH CONNECTOR	Spare Part	14015	15%
553	03.224.17.0.PR	EXHAUST FAN 15", 230V, 50HZ, FLOW DIRECTION MOTOR TO BLADE	Spare Part	12661	15%
554	03.231.09.0.00	CURRENT TRANSFORMER 30 5 2 5 VA	Spare Part	1858	15%
555	03.236.10.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	22147	15%
556	03.236.20.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	19824	15%
557	03.236.40.0.00	CAMSHAFT & GEAR ASSEMBLY	Spare Part	20363	15%
558	03.238.01.0.00	FLANGE FOR STARTER	Spare Part	1120	15%
559	03.239.01.0.00	METALIC BREATHER PIPE (LONG)	Spare Part	837	15%
560	03.240.82.0.00	MUSHROOM PUSH BUTTON MODEL NO ZB5AC4 WITH NO CONTACT AND COLLAR MODEL NO	Spare Part	5532	15%
561	03.240.83.0.00	AMF65 APU CONTROLLER TYPE APU MASTER 7 5KW	Spare Part	167961	15%
562	03.240.84.0.00	AMF65 APU CONTROLLER TYPE APU SLAVE 7 5KW	Spare Part	161681	15%
563	03.247.10.0.00	FUEL PUMP	Spare Part	83073	15%
564	03.248.02.0.PR	FUEL PIPE FILTER LEAK OFF TO TANK	Spare Part	1043	15%
565	03.248.20.0.00	NOZZLE TO NOZZLE LEAK OFF PIPE	Spare Part	837	15%
566	03.248.60.0.00	LEAK OFF PIPE NOZZLE LEAK OFF TO FILTER LEAK OFF	Spare Part	831	15%
567	03.250.81.0.00	DIODE FOR RECTIFIER UNIT	Spare Part	24037	15%
568	03.250.82.0.00	DIODE FOR RECTIFIER UNIT	Spare Part	24037	15%
569				85402	15%
	03.250.93.0.00	POWER CONTACTOR 3D 70V DO	Spare Part		
570	03.250.94.0.00	POWER CONTACTOR 3P 72V DC	Spare Part	34541 800	15% 15%
571	03.254.07.0.00	DRAIN PIPE FOR LUB OIL SUMP 320 mm	Spare Part	1772	15%
572	03.274.01.0.00	ANTI VIBRATION MOUNTS	Spare Part		
573	03.291.13.0.00	NON RETURN VALVE	Spare Part	2901	15%
574	03.291.16.0.00	ADAPTOR M16x1.5 TO 1/4" BSP	Spare Part	289	15%
575	03.294.01.0.00	PULLEY: ALTERNATOR 24V SPZ	Spare Part	1071	15%
576	03.312.90.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	12698	15%
577	03.313.40.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	9077	15%
578	03.314.50.0.PR	ENGINE WIRING HARNESS HA394 WITH ROTRY PUMP	Spare Part	9511	15%
579	03.340.04.0.00	Rotary FIP for HA394 TCI 40HP@1500rpm (CPCBII) Engine	Spare Part	131374	15%
580	03.340.07.0.00	F 002 A2Z 009 BOSCH INLINE FIP FOR HA394TCI G1 ENGINE 32 HP 1500 RPM CPCB II BOSCH E	Spare Part	72337	15%
581	03.360.10.0.00	ENGINE WIRING HARNESS ASSEMBLY (WITHOUT 'V' BELT)	Spare Part	4406	15%
582	03.360.20.0.00	WIRING HARNESS	Spare Part	5378	15%
583	03.423.51.0.00	SILICON COATED FIBER GLASS CLOTH SIZE AFTER FORMING 18 X 14 X 13 WITH FITTINGS	Spare Part	7181	15%
584	03.485.20.0.00	HOT AIR DUCTING ASSLY: SIDE OPEN	Spare Part	4114	15%
585	03.489.10.0.00	WIRING HARNESS WITH PUMP MOUNTED STOP SOLENOID	Spare Part	5123	15%
586	03.503.10.0.00	FUEL TANK ASSembly	Spare Part	19437	15%
587	03.504.10.0.00	CAM SHAFT GEAR ASSLY	Spare Part	21830	15%
588	03.508.01.0.00	BRACKET FOR VSC UNIT	Spare Part	360	15%
589	03.508.13.0.00	BRACKET: FIXED SPEED HA294	Spare Part	262	15%
590	03.530.01.0.00	EXHAUST M'FOLD: CENTRAL OPEN	Spare Part	4821	15%
591	03.530.10.0.00	SUB ASSEMBLY OF EXHAUST MANIFOLD AND ADAPTOR	Spare Part	7471	15%
592	03.593.01.0.00	LUBE OIL PRESS GAUGE PIPE 1.3M	Spare Part	2169	15%
593	03.608.03.0.00	SUNDERAM CLAYTON COMPRESSOR MODEL SC160 TYPE M 100960	Spare Part	53962	15%
594	03.609.15.0.00	O RING: COMPRESSOR	Spare Part	34	15%
595	03.609.17.0.00	O RING: COVER PLATE	Spare Part	28	15%
596	03.609.19.0.00	COVER PLATE FOR COMPRESSOR	Spare Part	726	15%
597	03.609.60.0.00	LUB OIL SUPPLY PIPE ASSEMBLY CCASE TO COMP	Spare Part	523	15%
598	03.635.16.0.00	FUEL PIPE PRE-FILTER TO TANK	Spare Part	652	15%
599	03.635.17.0.00	FUEL RETURN PIPE	Spare Part	1034	15%
600	03.635.19.0.00	INLET FUEL PIPE FILTER TO FEED PUMP	Spare Part	886	15%
601	03.635.20.0.00	FUEL PIPE PRE FILTER TO TANK UNIT	Spare Part	794	15%
602	03.635.36.0.00	FUEL PIPE FEED PUMP TO TANK UNIT	Spare Part	1166	15%
603	03.648.01.0.00	CLAMP FOR DIP STICK GUIDE	Spare Part	138	15%
604	03.648.50.0.00	RAISED DIPSTICK ASSLY	Spare Part	852	15%
605	03.656.20.0.00	DU FUEL FILTER 1.1 L W/O VALVE	Filter	3574	20%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
606	03.660.07.0.00	SPECIAL BANJO BOLT(LOSUPPLY TO PUMP)	Spare Part	111	15%
607	03.660.10.0.00	FUEL PUMP ASSLY: HA394	Spare Part	77048	15%
608	03.716.01.0.00	HUB FOR FUEL PUMP GEAR	Spare Part	2532	15%
609	03.716.02.0.00	FUEL PUMP GEAR	Spare Part	3975	15%
610	03.716.03.0.00	WASHER FUEL PUMP GEAR	Spare Part	22	15%
611	03.716.07.0.00	ECCENTRIC RING FOR FIP GEAR	Spare Part	1935	15%
612	03.721.10.0.00	LEAK OFF PIPE ASSLY	Spare Part	418	15%
613	03.723.90.0.00	SET OF HIGH PRESS PIPE: DHA394	Spare Part	2055	15%
614	03.731.01.0.00	FRONT COVER	Spare Part	14947	15%
615	03.731.05.0.00	FRONT COVER	Spare Part	10726	15%
616	03.732.01.0.00	INLET CAP FOR OIL BATH AIR CLEANER	Spare Part	1043	15%
617	03.734.03.0.00	EXHAUST MANIFOLD TO SUIT TR 43 TURBO CHARGER	Spare Part	4591	15%
618	03.734.04.0.00	HOSE (COMPRESSOR OUT)	Spare Part	886	15%
619	03.736.04.0.00	LUB OIL DRAIN PIPE FRONT COVER SIDE	Spare Part	412	15%
620	03.736.05.0.00	LUB OIL DRAIN PIPE TURBO SIDE	Spare Part	415	15%
621	03.750.01.0.00	LUBE OIL COOLER- ALUMINIUM	Spare Part	14381	15%
622	03.752.10.0.00	CAC-IN PIPE ASSEMBLY (CAC-SIDE)	Spare Part	4483	15%
623	03.769.02.0.00	ADAPTOR: PRESS GAUGE SENDOR	Spare Part	163	15%
624	03.774.04.0.00	JOINT FOR COVER AUX L O SUMP	Spare Part	172	15%
625	03.793.23.0.00	12V DC, 100Ah, Lead Acid Kirloskar Green Battery	Battery	19625	15%
626	03.793.24.0.00	12V DC, 150Ah, Lead Acid Kirloskar Green Battery	Battery	30074	15%
627	03.829.30.0.00	LUBE OIL SUMP: FLAT FACE	Spare Part	3037	15%
628	03.830.20.0.00	SUCTION TUBE	Spare Part	920	15%
629	03.842.20.0.00	WIRING HARNESS HA394 P.G.ENGINE WITH ALT	Spare Part	2305	15%
630	03.907.20.0.00	WIRING HARNESS: ENGINE TO CONTROL PANEL	Spare Part	5388	15%
631	03.910.01.0.00	ADAPTER RING FOR SAE1 TO SAE2	Spare Part	8280	15%
632	03.913.30.0.00	CRANKSHAFT ASSLY WITH CR GEAR	Spare Part	73331	15%
633	03.913.40.0.00	CRANKSHAFT ASSEMBLY	Spare Part	77344	15%
634	03.918.17.0.00	ENGINE START PUSH BUTTON	Spare Part	643	15%
635	03.918.18.0.00	ENGINE STOP PUSH BUTTON	Spare Part	668	15%
636	03.922.10.0.00	FUEL FILTER 0.5 L WO O-RING	Filter	2079	20%
637	03.922.40.0.00	SPINON FUEL FILTER 0.6L SBOWL	Filter	1689	20%
638	03.922.42.0.00	FUEL FILTER ELEMENT	Filter	1213	20%
639	03.924.01.0.00	ADAPTOR FOR PRICOL LUBE OIL PRESSURE SENSOR	Spare Part	154	15%
640	03.943.20.0.00	WIRING HARNESS ASSEMBLY HA3	Spare Part	2425	15%
641	03.947.01.0.00	FUEL PUMP VARIABLE SPEED HA394 CMVR STAGE I	Spare Part	43824	15%
	03.963.02.0.00	ENGINE SAFETY UNIT (KRB 203A WITH TIMER FOR COLD STARTING AID)	Spare Part	30830	15%
	03.963.19.0.00	OFF/ON SELECTOR SWITCH	Spare Part		15%
644	03.963.22.0.00	SELECTOR SWITCH 2WAY	Spare Part		15%
645	03.963.23.0.00	EMERGENCY SWITCH	Spare Part		15%
		START STOP CARD	Spare Part		15%
	03.963.48.0.00 03.974.01.0.00	FLYWHEEL HOUSING	Spare Part		15%
648	03.974.03.0.00	FLYWHEEL HOUSING SAE3	Spare Part	12661	15%
649	03.999.15.0.00	B KIT OVERHAUL HA394 - KTL	Spare Part	43956	15%
650	03.999.20.0.00	PUSH ROD KIT: HA3	Spare Part		15%
651	03.999.35.0.00	HA394 PG SERVICE KIT WITH AIR FILTER C CHECK	Filter	3369	20%
652	04.001.08.0.00	PRECOATED SCREW PLUG	Spare Part		15%
653	04.001.90.0.00	C'CASE ASSLY W/O BEARING	Spare Part	184499	15%
654	04.005.12.0.00	SOCKET HEAD BOLT: M12X1.75X60 -10.9	Spare Part	111	15%
655	04.006.30.0.00	CAMSHAFT & GEAR ASSEMBLY	Spare Part	26870	15%
656	04.006.40.0.00	CAMSHAFT & GEAR ASSLY CMVR III	Spare Part	30338	15%
657	04.008.01.0.00	COMB LEAK OFF S/F PIPES: HA4	Spare Part		15%
658	04.010.20.0.00	SUB ASSEMBLY LEAK OFF PIPE (INDUSTRIAL)	Spare Part	1114	15%
659	04.011.40.0.00	SUCTION TUBE SUB ASSEMBLY	Spare Part	837	15%
660	04.014.01.0.00	EXHAUST AIR BAFFLE	Spare Part	920	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
661	04.016.01.0.00	INLET MANIFOLD	Spare Part	6938	15%
662	04.019.01.0.00	LOWER COWLING	Spare Part	1406	15%
663	04.019.03.0.00	LOWER COWLING FOR HA494T BS III	Spare Part	1412	15%
664	04.020.01.0.00	LUBE OIL COOLER	Spare Part	14818	15%
665	04.020.02.0.00	O RING: LUBE OIL COOLER 2.5X26 -21502	Spare Part	194	15%
666	04.020.03.0.00	LUBE OIL COOLER: HA494TC	Spare Part	18981	15%
667	04.021.01.0.00	TOP AIR BAFFLE	Spare Part	738	15%
668	04.022.10.0.00	UPPER COWLING WELDED ASSLY	Spare Part	2474	15%
669	04.024.02.0.00	BOLT: FLYWHEEL-M10X45 LG	Spare Part	114	15%
670	04.024.10.0.00	SUBASSEMBLY OF FW&STARTER RING	Spare Part	26387	15%
671	04.024.20.0.00	FLYWHEEL(C-108 PTO,FLEXIBLE COUP.CENTA) MODIFIED FOR WIDTH	Spare Part	25344	15%
672	04.028.02.0.00	SPACER (11X20X13.8L)	Spare Part	58	15%
673	04.030.02.0.00	WASHER (TOP)	Spare Part	129	15%
674	04.030.20.0.00	ANTI VIBRATION MOUNTS ASSLY	Spare Part	2597	15%
675	04.031.02.0.00	TORSIONAL VIBRATION DAMPER	Spare Part	11098	15%
676	04.032.01.0.00	HYDRAULIC PUMP 1P3036	Spare Part	31827	15%
677	04.032.02.0.00	JOINT	Spare Part	25	15%
678	04.032.03.0.00	HYDRAULIC PUMP GEAR	Spare Part	4415	15%
679	04.032.04.0.00	LOCK NUT	Spare Part	34	15%
680	04.032.05.0.00	FLANGE	Spare Part	714	15%
681	04.032.06.0.00	O RING - SUCTION FLANGE	Spare Part	163	15%
682	04.032.07.0.00	FLANGE (SMALL) FOR HYD PUMP	Spare Part	751	15%
683	04.032.08.0.00	O RING - DEL.FLANGE (2.5X19,21507)	Spare Part	194	15%
684	04.032.12.0.00	FERRULE FOR DELIVERY PIPE	Spare Part	215	15%
685	04.032.14.0.00	FLANGE (OUTLET)	Spare Part	1049	15%
686	04.034.10.0.SP	SET OF JOINTS	Spare Part	2803	15%
687	04.034.20.0.SP	SET OF JOINTS	Spare Part	2951	15%
688	04.035.10.0.00	SET OF O RINGS HA494	Spare Part	1569	15%
689	04.037.01.0.00	PLATE FOR A V MOUNTING	Spare Part	5052	15%
690	04.039.10.0.00	FLYWHEEL ASSLY	Spare Part	35384	15%
691	04.040.04.0.00	BRACKET: FUEL FILTER	Spare Part	1206	15%
692	04.051.50.0.00	STOPPING BAR ASSEMBLY	Spare Part	280	15%
693	04.052.30.0.00	EXHAUST M'FOLD CUM SILENCER	Spare Part	19497	20%
694	04.062.01.0.00	V BELT : A48X 1252 LONG	Spare Part	702	15%
695	04.080.01.0.00	SPACER: BOTTOM A V MTG	Spare Part	271	15%
696	04.081.10.0.00	ASSLY OF COOLING BLOWER	Spare Part	18261	15%
697	04.089.01.0.00	FUEL PIPE 80,14X14B,235	Spare Part	563	15%
698	04.091.01.0.00	FLEXIBLE PIPE LOP GAUGE (2.5 M LONG)	Spare Part	4123	15%
699	04.106.01.0.00	V BELT: FAILURE SWITCH KHD-224 5023	Spare Part	1985	15%
700	04.108.10.0.00	HOT AIR DUCTING ASSLY	Spare Part	3563	15%
701	04.110.01.0.00	EXHAUST M'FOLD: HA4 FINISH	Spare Part	6723	15%
702	04.119.01.0.00	TRIANGULAR FLANGE (EXH OUTLET)	Spare Part	563	15%
703	04.135.02.0.00	START KEY SWITCH	Spare Part	2105	15%
704	04.135.10.0.00	FLYWHEEL ASSEMBLY	Spare Part	35544	15%
705	04.140.01.0.00	V BELT: A47 1227 LONG	Spare Part	652	15%
706	04.141.01.0.00	BELT GUARD	Spare Part	3311	15%
707	04.141.03.0.00	SPACER (BAR)	Spare Part	34	15%
708	04.157.01.0.00	BREATHER: BOX TYPE	Spare Part	1834	15%
709	04.195.01.0.00	CRANK PULLEY: NARROW 2GR	Spare Part	4785	15%
710	04.195.05.0.00	CRANK PULLEY FOR MUD SLINGER	Spare Part	5332	15%
711	04.196.02.0.00	BRACKET: V BELT SWITCH	Spare Part	335	15%
712	04.197.01.0.00	PULLEY: FAN 98PCD SPZ 1GR	Spare Part	1686	15%
713	04.198.01.0.00	ALTERNATOR PULLEY	Spare Part	951	15%
714	04.198.04.0.00	SPACER FOR B TENSION LEVER	Spare Part	77	15%
715	04.203.08.0.00	HOSE: AIR CLEANER	Spare Part	1277	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
716	04.203.09.0.PR	HOSE FOR AIR CLEANER	Spare Part	1000	15%
717	04.214.01.0.00	AIR INLET MANIFOLD	Spare Part	9243	15%
718	04.246.30.0.00	OVERHAUL KIT HA494 BSII INDL APPL	Spare Part	90180	15%
719	04.249.01.0.00	V BELT AX51 RAW COG LP1341	Spare Part	932	15%
720	04.249.02.0.00	V BELT COGGED AX49 RAW EDGE LP1279	Spare Part	926	15%
721	04.250.01.0.00	V BELT: LP1131 AX43 RAW EDGE COGGED	Spare Part	825	15%
722	04.266.01.0.00	HUB FOR FUEL PUMP GEAR	Spare Part	2495	15%
723	04.268.01.0.00	FILTER HEADER: LUBE OIL & FUEL FILTER	Spare Part	7560	15%
724	04.268.02.0.00	ADAPTOR FOR PR.GAUGE CONN.	Spare Part	52	15%
725	04.270.01.0.00	SPINON LUBE OIL FILTER	Filter	746	20%
726	04.291.03.0.00	INTERMEDIATE RING(1 MM THK.)	Spare Part	98	15%
727	04.291.06.0.00	INTERMEDIATE RING: 1.3MM	Spare Part	111	15%
728	04.291.11.0.00	INTERMEDIATE RING 1.5MM THK	Spare Part	126	15%
729	04.291.22.0.00	INTERMEDIATE RING(2.0 MM THICK)	Spare Part	185	15%
730	04.291.30.0.00	CYLINDER HEAD ASSLY	Spare Part	26144	15%
731	04.292.04.0.00	SEALING WASHER	Spare Part	31	15%
732	04.295.01.0.00	NOZZLE	Spare Part	4628	15%
733	04.295.03.0.00	WASHER FOR INJ	Spare Part	77	15%
734	04.295.10.0.00	INJECTOR	Spare Part	5886	15%
735	04.296.01.0.00	FUEL FILTER CARTRIDGE	Filter	814	20%
736	04.304.02.0.00	LUBE OIL SUPPLY HOSE	Spare Part	714	15%
737	04.308.01.0.00	INLET MANIFOLD	Spare Part	5840	15%
738	04.329.01.0.00	EXHAUST SILENCER: HA494TC	Spare Part	7781	15%
739	04.329.04.0.00	EXHAUST SILENCER (S/F L&T)	Spare Part	9603	15%
740	04.329.07.0.00	EXHAUST SILENCER	Spare Part	9418	15%
741	04.334.05.0.00	CRANK PULLEY (238 PCD,3 GR,A SECT)	Spare Part	8341	15%
742	04.355.01.0.00	PULL TYPE ACCELARATOR LEVER (INDITAL)	Spare Part	572	15%
743	04.358.90.0.00	SET OF HIGH PRESS PIPE	Spare Part	3068	15%
744	04.362.03.0.00	RUBBER SEALING RING	Spare Part	2425	15%
745	04.362.10.0.00	ASSEMBLY AIR GUIDE RING & BRUSH	Spare Part	5671	15%
746	04.363.02.0.00	HOSE: AIR CLEANER	Spare Part	2252	15%
747	04.364.04.0.00	EXHAUST SILENCER: TRACTOR SHORT	Spare Part	7545	15%
748	04.364.08.0.00	EXHAUST SILENCER	Spare Part	7640	15%
749	04.364.11.0.00	HOSE: AIR CLEANER	Spare Part	3043	15%
750	04.364.20.0.00	SUB ASSLY FLEX EXH PIPE: 2.5"IDX550L	Spare Part	8203	15%
751	04.364.40.0.00	FLEXIBLE PIPE SUB ASSLY	Spare Part	4486	15%
752	04.367.01.0.00	ALTERNATOR: 12V 55A	Spare Part	17901	15%
753	04.375.01.0.00	LUBE OIL SUMP: SIDE DRAIN	Spare Part	17301	15%
754	04.378.05.0.00	ADAPTOR: LUBE FILTER HA2	Spare Part	1677	15%
755	04.387.02.0.00	HOSE: AIR CLEANER S/F 24 V ALT	Spare Part	698	15%
		MAIN ELEMENT FOR AIR CLEANER	Spare Part	9896	20%
756 757	04.403.11.0.00 04.416.06.0.00	FUEL PUMP HA4 CMVR STAGE II	Spare Part	65516	15%
			·		
758	04.416.40.0.00	FUEL PUMP HA494 NON CMVR VARIABLE SPEED	Spare Part	73581	15%
759	04.417.30.0.00	LUBE OIL SUMP: FLAT FACE	Spare Part	4025	15%
760	04.417.31.0.PR	LUB OIL SUMP (FLAT FACE)	Spare Part	6317	15%
761	04.417.50.0.00	LUBE OIL SUMP: FLAT FACE	Spare Part	3994	15%
762	04.444.20.0.00	SUCTION TUBE ASSLY: PRESS SUMP	Spare Part	797	15%
763	04.445.10.0.00	DIPSTICK ASSLY: PRESS SUMP 210-170X25-38	Spare Part	98	15%
764	04.450.20.0.00	WIRING HARNESS WITH ALTERNATOR	Spare Part	2452	15%
765	04.451.20.0.00	SUCTION TUBE	Spare Part	874	15%
766	04.452.01.0.00	DRAIN PIPE FOR LUBE OIL SUMP	Spare Part	705	15%
767	04.452.03.0.00	U-CLAMP FOR SUMP DRAIN PIPE	Spare Part	62	15%
768	04.452.06.0.00	ADAPTOR FOR SUMP DRAIN	Spare Part	243	15%
769	04.465.01.0.00	V BELT COGGED SPZ-LP1280 98 PCD	Spare Part	760	15%
770	04.465.03.0.PR	V BELT (SPZX 1280L) BLOWER FAN PULLEY	Spare Part	1286	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
				without Vat in NPR	Charge%
771	04.474.05.0.00	BANJO BOLT	Spare Part	62	15%
772	04.475.01.0.00	RUBBER HOSE: AIR INLET	Spare Part	486	15%
773	04.493.01.0.00	ACTUATOR ADC225 GS 12V WITH LEVER	Spare Part	120035	15%
774	04.499.01.0.00	SPACER FOR BRACKET	Spare Part	77	15%
775	04.499.04.0.00	SPACER FOR ALTERNATOR MTG BRACKET	Spare Part	95	15%
776	04.508.01.0.PR	BRACKET FOR CABLE TYPE AND LOW IDLE SPEED ADJUSTMENT	Spare Part	314	15%
777	04.513.01.0.00	FUEL PIPE: TANK TO FEED PUMP 1700MM	Spare Part	1538	15%
778	04.529.40.0.00	DIPSTICK ASSLY	Spare Part	1898	15%
779	04.536.02.0.00	FUEL LEVEL MECH GAUGE 160MM	Spare Part	1517	15%
780	04.536.03.0.00	FUEL PIPE FILTER TO FEED PUMP	Spare Part	763	15%
781	04.536.04.0.00	FUEL PIPE PRE-FILTER TO TANK UNIT	Spare Part	674	15%
782	04.536.11.0.00	FUEL PIPE INLET M14 X 1 5 BANJO BOTH SIDES LENGTH 950MM	Spare Part	1631	15%
783	04.536.21.0.PR	FUEL PIPE FROM TANK TO FUEL FILTER	Spare Part	5249	15%
784	04.536.23.0.PR	FUEL PIPE FROM FUEL FILTER TO TANK	Spare Part	3160	15%
785	04.536.26.0.PR	FUEL PIPE FROM PRE FILTER TO FUEL TRANSFER PUMP	Spare Part	3018	15%
786	04.536.27.0.PR	FUEL PIPE FROM PRE FILTER TO FUEL JUNCTION BOX	Spare Part	2905	15%
787	04.536.29.0.PR	FUEL PIPE FROM FUEL TRANSFER PUMP TO FEED PUMP	Spare Part	3191	15%
788	04.540.20.0.00	WIRING HARNESS FOR ENGINE TO CONTROL PANELCPCB PROJECT WITH T	Spare Part	5483	15%
789	04.563.10.0.00	STOP SOLENOID: VERT S/F C LEVER	Spare Part	4901	15%
790	04.564.01.0.00	AIR INLET MANIFOLD	Spare Part	6631	15%
791	04.564.02.0.00	ADAPTOR FOR AIR INLET MANIFOLD	Spare Part	2172	15%
792	04.566.02.0.00	EXHAUST MANIFOLD FINISH WITH EXTERNAL EGR ARRENGMENT FOR HA4T CMVR III	Spare Part	7305	15%
793	04.566.04.0.00	JOINT: EJR PIPE: HA BSIII	Spare Part	83	15%
794	04.568.10.0.00	TURBOCHARGER TEL MAKE K24 2460 GGA 5 11	Spare Part	82504	15%
795	04.574.04.0.00	HOSE: LUBE OIL DRAIN TURBO	Spare Part	868	15%
796	04.574.06.0.00	ADAPTOR FOR LUBE OIL PIPE ON CRANCKCASE	Spare Part	108	15%
797	04.574.07.0.00	CLIP FOR LUBE OIL INLET PIPE	Spare Part	138	15%
798	04.574.08.0.00	BRACKET FOR CLIP MOUNTING	Spare Part	206	15%
799	04.574.09.0.00	RUBBER SLEEVE FOR LUBE OIL PIPE	Spare Part	169	15%
800	04.575.01.0.00	EXHAUST DIFFUSER	Spare Part	1917	15%
801	04.575.04.0.00	JOINT: EXHAUST DIFFUSER	Spare Part	720	15%
802	04.576.02.0.00	SPACER FOR TENSION LEVER	Spare Part	77	15%
803	04.586.03.0.00	PRIMARY AIR CLEANER ELEMENT	Filter	1587	20%
804	04.586.04.0.00	AIR CLEANER SAFETY ELEMENT	Filter	733	20%
805	04.586.30.0.00	AIR CLEANER ASSLY+ STRAINER	Spare Part	6182	20%
806	04.587.10.0.00	AIR CLEANER ASSLY: DRY TYPE	Spare Part	5759	20%
807	04.588.02.0.00	HOSE: AIR CLEANER	Spare Part	382	15%
808	04.588.05.0.00	RESTRICTION INDICATOR	Spare Part	523	15%
809	04.594.20.0.00	SUB ASSEMBLY OF CAM SHAFT (CPCB) WITH CHILLED C.I. CAM SHAFT	Spare Part	27655	15%
810	04.595.10.0.00	F 002 AOZ 395 FUEL PUMP ASSEMBLY LLA LLR MICO	Spare Part	71897	15%
811	04.596.03.0.00	INJECTOR	Spare Part	10735	15%
812	04.599.01.0.00	EXHAUST SILENCER	Spare Part	6495	15%
813	04.599.02.0.00	RAIN CAP: BLACK	Spare Part	1828	15%
814	04.600.01.0.00	BOX TYPE BREATHER	Spare Part	1911	15%
815	04.612.01.0.00	ADAPTER FOR EXHAUST SILENCER	Spare Part	1462	15%
816	04.613.01.0.00	FUEL PIPE (S/F041221)1400 L, 95 ID, 14 BANJO	Spare Part	889	15%
817	04.625.02.0.00	EXPANSION BELLOW	Spare Part	7492	15%
818	04.625.10.0.00	SILENCER	Spare Part	20763	15%
819	04.666.10.0.00	HOT AIR DUCTING ASSLY	Spare Part	5689	15%
820	04.668.01.0.00	V BELT COGGED-AVX10 1265L BLOWER PULLEY	Spare Part	634	15%
821	04.668.02.0.PR	V BELT COGGED SPAX 1260L BLOWER PULLEY	Spare Part	1345	15%
822	04.669.01.0.00	V BELT COGGED 37AX 1200L BLOWER FOLLET V BELT COGGED AVX 10-1136 FOR ALTERNATOR PULLEY	Spare Part	646	15%
823	04.670.10.0.00	ASSEMBLY AIR GUIDE RING	Spare Part	2920	15%
	04.677.01.0.00	STARTER: 12V 2.7KW	Spare Part	28772	15%
824		OTABLES. LA C./ 1889	, opare rait	20112	1070



				Price to	
Cu Na	Daut Neurobau	Don't Description	Catagoni	Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
826	04.684.70.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	NPR 24581	15%
827	04.685.20.0.00	CON ROD ASSLY: WO LE BRG	Spare Part	8775	15%
828	04.690.01.0.00	PULLEY: FAN 79PCD SPZ 1GR	Spare Part	1905	15%
829	04.691.20.0.00	CON ROD ASSLY: MAS BAL WO LE BRG	Spare Part	8609	15%
830	04.692.03.0.00	CONNECTING ROD BOLT	Spare Part	191	15%
831	04.692.10.0.00	CONNECTING ROD ASSLY	Spare Part	8717	15%
832	04.708.01.0.00	BELT: SPZX SECTION ALT24V LP1180	Spare Part	1188	15%
833	04.725.02.0.00	ADAPTOR FOR ROTARY FUEL PUMP MOUNTING	Spare Part	3320	15%
834	04.725.04.0.00	HUB FOR FIP GEAR	Spare Part	2917	15%
835	04.734.03.0.00	EXHAUST MANIFOLD FINISH	Spare Part	5935	15%
836	04.735.02.0.00	TURBOCHARGER	Spare Part	47319	15%
837	04.750.02.0.00	JOINT: TURBO INLET	Spare Part	594	15%
838	04.751.02.0.00	JOINT: LUBE OIL OUTLET FLANGE	Spare Part	49	15%
839	04.751.03.0.00	HOSE: LUBE OIL DRAIN HA494 BS3	Spare Part	289	15%
840	04.751.05.0.00	LUBE OIL DRAIN PIPE: FRONT COVER HA4	Spare Part	378	15%
841	04.751.120.0.00	TURBO OIL INLET PIPE	Spare Part	720	15%
842	04.751.120.0.00	LUBE OIL INLET PIPE ASSLY	Spare Part	926	15%
843	04.752.01.0.00	CAC OUTLET PIPE TO INLET MANIFOLD	Spare Part	3332	15%
844	04.752.03.0.00	HOSE (CAC OUT)	Spare Part	391	15%
845	04.752.08.0.00	HOSE (CAC-IN)	Spare Part	495	15%
846	04.752.08.0.00	INTERCOOLER ASSEMBLY FOR HA4 TCI (CPCB II)	Spare Part	39267	15%
847	04.755.01.0.00	BRACKET FOR FUEL FILTER	Spare Part	418	15%
848	04.755.02.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	658	15%
849	04.755.03.0.00	FUEL PIPE FUEL FILTER TO FIP	Spare Part	572	15%
850	04.755.06.0.00	COMBINE LEAK OFF PIPE INJECTOR TO FUEL FILTER	Spare Part	720	15%
851	04.755.10.0.00	COMB LEAK OFF PIPE: HA BSIII	Spare Part	732	15%
852	04.755.16.0.PR	FUEL PIPE FEED PUMP TO FILTER	Spare Part	1597	15%
853	04.755.18.0.PR	FUEL PIPE FUEL FILTER TO FUEL PUMP	Spare Part	1252	15%
854	04.755.33.0.PR	LEAKOFF PIPE FOR FUEL PUMP TO JUNCTION BOX	Spare Part	4160	15%
855	04.760.01.0.00	PRIMARY FILTER ELEMENT	Filter	5520	20%
856	04.760.02.0.00	SAFETY FILTER ELEMENT	Filter	1655	20%
857	04.760.10.0.00	AIR CLEANER ASSLY: DRY 8M3	Spare Part	27403	20%
858	04.768.03.0.00	FUEL LEVEL GAUGE MECH: DIAL 140 MM	Spare Part	1237	15%
859	04.785.90.0.00	HIGH PRESSURE PIPE ASSLY	Spare Part	4646	15%
860	04.786.60.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	12234	15%
861	04.786.81.0.00	ENGINE WIRING HARNESS WITH SEDEMAC GOVERNOR AND COLD START	Spare Part	16474	15%
862	04.805.15.0.00	EXCITER ROTOR	Spare Part	21058	15%
863	04.805.21.0.00	TERMINAL BLOCK: KG35ST-125ST	Spare Part	1394	15%
864	04.805.38.0.00	TERMINAL BLOCK FOR 225 FRAME (TA3L10)	Spare Part	2268	15%
865	04.805.39.0.00	TERMINAL BLOCK FOR 280 FRAME (TA3T10)	Spare Part	3234	15%
866	04.805.49.0.00	ROTATING RECTIFIER ASSLY FOR KG200/225/280 FRAME KG35 TO KG200 KVA ALTRNATORS INC	Spare Part	11797	15%
867	04.813.10.0.00	F 002 A0Z 365 FUEL PUMP BOSCH	Spare Part	116931	15%
868	04.815.20.0.00	NOZZLE LEAK OFF PIPE	Spare Part	997	15%
869	04.859.40.0.00	ASSEMBLY INSTRUMENT PANEL WITH METERS ALTR HR	Spare Part	12504	15%
870	04.861.01.0.00	4 POLE MCB 63 AMP	Spare Part	8812	15%
871	04.931.11.0.00	EMS 18 COMUNICATION MODULE FOR RS 485 OUT PUT	Spare Part	24360	15%
872	04.942.07.0.00	1 RELAY+BOARD, 12VDC, 5A, 2C/O	Spare Part	1443	15%
873	04.956.40.0.00	CRANKSHAFT ASSLY INTEGRAL	Spare Part	90005	15%
874	04.978.01.0.00	FIP: HA494 TCI CPCB-II	Spare Part	105814	15%
875	04.978.05.0.00	STANDYNE ROTARY FIP FOR HA 494 TCI G1		122300	15%
		HA494 PG SERVICE KIT B CHECK	Spare Part Filter	3472	20%
876 877	04.999.35.0.00 04.999.36.0.00	HA494 PG SERVICE KIT B CHECK HA494 PG SERVICE KIT WITH AIR FILTER -C CHK	Filter	5257	20%
011	04.999.37.0.00	HA494 CPCB II Service Kit - B Check	Filter	3861	20%
878			riilei	30011	∠∪70
878 879	04.999.38.0.00	HA494 CPCB II Service Kit with Air Filter - C Check	Filter	5517	20%



				Price to	
Cu Na	Doub Name hou	Doub Description	Catagony	Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
001	04.999.85.0.00	SERV KIT A: 500 HRS HA494 BSIII INDL CONCRETE PUMP	Filter	NPR 786	20%
881 882	04.999.85.0.00	SERVICE KIT B 500 HRS: HA494 BSIII INDL CONCRETE PUMP	Filter	1433	20%
883	06.001.50.0.00	C'CASE ASSLY W/O BEARING	Spare Part	246292	15%
884	06.004.40.0.00	CRANKSHAFT ASSEMBLY	Spare Part	132109	15%
885	06.005.10.0.00	CAMSHAFT & GEAR ASSLY	Spare Part	41775	15%
886	06.005.20.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	36153	15%
887	06.005.50.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	39215	15%
888	06.006.01.0.00	COMB LEAK OFF PIPE: HA694	Spare Part	806	15%
889	06.008.02.0.00	UNION SCREW	Spare Part	391	15%
890	06.008.03.0.00	DOUBLE CONE RING	Spare Part	178	15%
891	06.008.04.0.00	CLAMPING STRAP	Spare Part	58	15%
892	06.008.20.0.00	SUB ASSEMBLY OF SUCTION TUBE	Spare Part	957	15%
893	06.010.01.0.00	COUNTER SUNK SOCKET HEAD SCREW.	Spare Part	68	15%
894	06.010.130.0.00	LUB OIL PUMP ASSLY	Spare Part	8898	15%
895	06.010.60.0.00	LUBE OIL PUMP ASSLY	Spare Part	8711	15%
896	06.011.07.0.00	JOINT: AIR INLET MANIFOLD TO CAC PIPE	Spare Part	157	15%
897	06.011.08.0.00	JOINT: CAC PIPE	Spare Part	111	15%
898	06.011.16.0.00	CAC INLET PIPE (TURBO SIDE)	Spare Part	2412	15%
899	06.011.18.0.00	CAC-IN PIPE (CAC SIDE)	Spare Part	3649	15%
900	06.011.20.0.00	INTERCOOLER	Spare Part	43541	15%
901	06.017.10.0.00	CRANK PULLEY ASSLY	Spare Part	17815	15%
902	06.017.40.0.00	ASSLY OF CRANK PULLEY (MODIFIED FOR BANDED BELT)	Spare Part	19307	15%
903	06.019.10.0.00	LOWER COWLING SUB ASSLY	Spare Part	3089	15%
904	06.019.40.0.00	LOWER COWLING	Spare Part	3874	15%
905	06.020.01.0.00	LUBE OIL COOLER	Spare Part	20763 252	15% 15%
906	06.020.02.0.00 06.020.07.0.00	SEALING RING LUBE OIL COOLER LUBE OIL COOLER -HA6	Spare Part Spare Part	22274	15%
908	06.021.01.0.00	FRONT COWLING	Spare Part	2037	15%
909	06.021.04.0.00	FRONT COWLING	Spare Part	2572	15%
910	06.022.01.0.00	TOP AIR BAFFLE	Spare Part	1548	15%
911	06.024.10.0.00	EXHAUST AIR BAFFLE	Spare Part	2745	15%
912	06.025.13.0.00	BALL BEARING(25X52X15)	Spare Part	483	15%
913	06.025.14.0.00	FAN PULLEY (119 PCD, A SECTION, 2 GROOVES- MODIFIED FOR	Spare Part	2391	15%
914	06.025.40.0.00	ASSembLY OF COOLING BLOWER	Spare Part	24338	15%
915	06.027.20.0.00	SUB ASSLY LEAK OFF PIPE	Spare Part	1812	15%
916	06.028.01.0.00	AIR INLET MANIFOLD G.E.OPENING	Spare Part	4246	15%
917	06.028.05.0.00	AIR INLET MANIFOLD	Spare Part	8861	15%
918	06.028.06.0.00	AIR INLET MANIFOLD	Spare Part	4249	15%
919	06.029.10.0.00	UPPER COWLING	Spare Part	6692	15%
920	06.031.01.0.00	BANDED WRAPPED BELT 2JA1310Lp (1310 MM EFFECTIVE Pitch)	Spare Part	2606	15%
921	06.031.04.0.00	BANDED COGGED BELT: LP1310 2JAX50	Spare Part	2440	15%
922	06.032.01.0.00	BANDED WRAPPED BELT 2JA 51 -1328mm PITCH LENGTH	Spare Part	3061	15%
923	06.032.02.0.00	BANDED WRAPPED BELT: 2JA 52 1354 LONG	Spare Part	2960	15%
924	06.032.03.0.00	BELT :2JAX51 LP -1326 BANDED COGGED	Spare Part	2517	15%
925	06.032.04.0.00	BELT: LP1352 BANDED COGGED 2JAX52	Spare Part	2458	15%
926	06.033.01.0.00	STARTER MOTOR 12V 3KW	Spare Part	29310	15%
927	06.034.02.0.00	STARTER 12V	Spare Part	34532	15%
928	06.034.06.0.00	STARTER 24V	Spare Part	35430	15%
929	06.037.01.0.00	HOSE: INLET MANIFOLD	Spare Part	397	15%
930	06.037.03.0.00	HOSE: INLET MANIFOLD	Spare Part	612	15%
931	06.040.01.0.00	LUBE OIL FILTER ELEMENT	Filter	263	20%
932	06.040.10.0.00	LUBE OIL FILTER ASSLY	Spare Part	8077	15%
933	06.046.02.0.00	SPECIAL NUT: BRASS	Spare Part	320	15%
934	06.046.10.0.00	EXHAUST M'FOLD GE TOP OPEN	Spare Part	18375	20%
935	06.047.90.0.00	B.T. UNIT SUB ASSLY	Spare Part	7745	159



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
936	06.047.91.0.00	BELT TENSION UNIT WITH ACTUATOR	Spare Part	NPR 7674	15%
937	06.048.01.0.00	AIR CLEANER OIL BATH	Filter	9969	20%
938	06.048.02.0.00	PRE CLEANER	Spare Part	3431	15%
939	06.048.03.0.00	CLAMP FOR PRE CLEANER	Spare Part	200	15%
940	06.048.05.0.00	AIR CLEANER CLAMP	Spare Part	911	15%
941	06.048.10.0.00	AIR CLEANER ASSLY	Spare Part	12788	15%
942	06.049.01.0.00	BRACKET FOR AIR CLEANER	Spare Part	1868	15%
943	06.049.02.0.00	HOSE: AIR CLEANER	Spare Part	834	15%
944	06.050.10.0.SP	SET OF JOINTS	Spare Part	3068	15%
945	06.051.10.0.00	SET OF O RINGS: HA694	Spare Part	2292	15%
946	06.052.01.0.00	V BELT : A 52 1354 LONG	Spare Part	538	15%
947	06.055.90.0.00	SET OF HIGH PRESSURE PIPE	Spare Part	7526	15%
948	06.065.20.0.00	RAIN CAP	Spare Part	4212	15%
949	06.065.30.0.00	SUB ASSEMBLY OF RAIN CAP WITH MODIFIED BEND	Spare Part	4074	15%
950	06.066.20.0.00	SUB ASSEMBLY OF EXHAUST	Spare Part	5105	15%
951	06.069.01.0.00	EXHAUST M'FOLD: 4CYL	Spare Part	6021	15%
952	06.069.02.0.00	EXHAUST M'FOLD: 2CYL	Spare Part	3757	15%
953	06.069.03.0.00	COMPRESSION RING	Spare Part	1723	15%
954	06.069.04.0.00	COMPRESSION RING	Spare Part	1049	15%
955	06.069.20.0.00	EXHAUST MANIFOLD 4 CLY SUB ASSLY WITH ADAPTOR FOR EXHAUST SILENCER	Spare Part	8994	15%
956	06.070.01.0.00	ADAPTOR: EXH SILENCER	Spare Part	1138	15%
957	06.072.03.0.00	SPACER (BAR) FOR ACTUATOR	Spare Part	46	15%
958	06.072.20.0.00	STOPPING BAR	Spare Part	292	15%
959	06.073.01.0.00	CRANKSHAFT GEAR: KNURLED	Spare Part	3138	15%
960	06.073.50.0.00	CRANKSHAFT ASSLY WITH CR GEAR	Spare Part	129272	15%
961	06.074.14.0.00	SPACER PLATE	Spare Part	7160	15%
962	06.074.15.0.00	GASKET: 1.5MM THK	Spare Part	391	15%
963	06.074.16.0.00	WASHER -SHEET METAL L.O.SUMP	Spare Part	22	15%
964	06.074.30.0.00	LUBE OIL SUMP: FLAT FACE	Spare Part	4997	15%
965	06.074.04.0.00	O RING - (2.6X45,21511)	Spare Part	28	15%
966	06.077.05.0.00	ADAPTOR: DIPSTICK ASSLY	Spare Part	218	15%
967	06.081.01.0.00	STOP SOLENOID 12V 20MM FOOT MTG	Spare Part	7212	15%
968	06.082.02.0.00	MOUNTING PLATE (LUBE OIL FILTER SIDE)	Spare Part	529	15%
969	06.082.03.0.00	MOUNTING PLATE (CODE OIL FIETER SIDE)	Spare Part	557	15%
970	06.085.12.0.00	FAN PULLEY (90 PCD A SECTION, 2 GROOVES)	Spare Part	1831	15%
971	06.085.40.0.00	ASSLY COOLING BLOWER HYD OIL COOLER	Spare Part	26224	15%
972	06.085.60.0.00	FAN BODY STATOR & IMPELL SUB ASSLY	Spare Part	29821	15%
973	06.085.70.0.00	FAN BODY: WITH RUBBER	Spare Part	22203	15%
973	06.085.80.0.00	SUB ASSEMBLY OF FAN BODY, STATOR AND IMPELLER (ANGULAR BEARING)	Spare Part	29640	15%
974	06.086.03.0.00	MOUNTING STRAP	Spare Part	1363	15%
975	06.086.04.0.00	VACUATOR VALVE	Spare Part	388	15%
976	06.087.02.0.00	TEMP SWITCH	Spare Part	2246	15%
978	06.087.06.0.00	AMMETER (60-0-60 AMPS)	Spare Part	825	15%
979	06.089.02.0.00	U CLAMP	Spare Part	218	15%
980	06.089.03.0.00	CLAMPING PLATE	Spare Part	382	15%
981	06.089.05.0.00	U CLAMP S F 04 329 04 0 00 SILENCER	Spare Part	249	15%
982	06.089.06.0.00	CLAMPING PLATE	Spare Part	360	15%
983	06.089.07.0.00	U CLAMP	Spare Part	228	15%
984	06.091.01.0.00	END COVER FOR BELL HOUSING	Spare Part	209	15%
985	06.092.10.0.00	SUCTION TUBE	Spare Part	1080	15%
		HUB ON CRANK PULLEY	Spare Part	4563	15%
986 987	06.097.01.0.00 06.098.01.0.00	V BELT: A51 1328 LONG	Spare Part	532	15%
987	06.101.10.0.00	COWLING ASSLY	Spare Part	3018	15%
989	06.101.10.0.00	SPARK ARRESTOR	Spare Part	2363	15%
508	00.103.01.0.00	OF ARRANGOTOR	Spare Part	2303	13%



1010					Price to	
March Marc	C= N=	Doub Normalian	Dauk Dassyinkian	Catagory		Custom
1997 1997	Sr.No.	Part Number	Part Description	Category		Charge%
March Marc	004	00.407.44.0.00	ADADTOD ON FUEL DUMP (DADVIAGO V 45)	On our Book		450/
1988 0.1971-0.00						
Met MIT MET MET		+		· ·		
MIT MIT						
1010				· ·		
907 908 0.0 10 10 20 0.0 905 10 10 10 10 10 10 10	995	06.107.30.0.00		Spare Part		15%
1968 196 03 100 00	996	06.107.40.0.00	FUEL PIPE FIP TO SOLENOID	Spare Part		15%
	997	06.108.02.0.00	SOLENOID VALVE 24V	Spare Part	9957	15%
1900 1818 CZ 10 00	998	06.108.03.0.00	BIMETAL SWITCH 24 V	Spare Part	16249	15%
1901 1902 1903 1905	999	06.158.01.0.00	SPACER 9X20X9THICK	Spare Part	55	15%
1002 8.1724.01.0.00 FPF FOR HABBAT COENGINE CPCBB I 59are Parl 153632 1575 1003 0.2174.2.2.0.00 SPANDYNE ROTARY FPF FOR HA 680 FCI G1 Spare Parl 1533.0 158 1006 0.2110.1.0.00 SPACER FOR FUEL FLITER Spare Parl 159 151 1007 0.2110.1.0.00 ON FIRE SCH MANIFOLD F Spare Parl 159 151 1007 0.219.02.0.00 TVO PIRE SCH MANIFOLD F Spare Parl 1334 151 1008 0.219.02.0.00 TVO PIRE SCH MANIFOLD F Spare Parl 1304 151 1009 0.224.03.0.00 RUBBER HOSE: DRAIN PIRE Spare Parl 1416 158 1010 0.225.00.00 NO "RUBBER HOSE: DRAIN PIRE Spare Parl 759 151 1011 0.224.00.00 NO "RUBBER HOSE: DRAIN PIRE Spare Parl 759 151 1012 0.224.00.00 NO "RUBBER HOSE: DRAIN PIRE Spare Parl 151 151 1012 0.224.00.00 NO "RUBBER HOSE: DRAIN PIRE Spare Parl 151 151	1000	06.158.02.0.00	SPACER(9X18X25THICK)	Spare Part	123	15%
1903 68 1742 22 0.00 STAMDYME POTAMY EP FOR HA 684 TCI GI Spere Part 158330 157 1004 02 11 01 0.00 SPACER FOR FUEL FLTER Spere Part 440 159 1006 02 21 01 0.00 PLASTIC TUBE: BOXMM SAR Spere Part 1169 159 1007 02 21 02 0.00 TVO PIECE EM MANIFOLD F Spere Part 11869 159 1008 02 21 03 0.00 SEALING RING Spere Part 132 159 1009 02 22 11 0.00 RUBBER HOSE: DRAIN PIPE Spere Part 132 159 1010 QUESCO DOLO TVO PIECE EM MANIFOLD Spere Part 132 159 1010 QUESCO DOLO RESPERTIVE LUB OLI NIET PIPE Spere Part 159 159 1011 DE 202 00.00 PRE CLEANER ASSILY Spere Part 1517 1517 1012 DE 202 00.00 PRE CLEANER ASSILY Spere Part 750 1519 1016 DE 260 00.00 SERLINET AND FUEL FUEL FUEL FUEL FUEL FUEL FUEL FUEL	1001	06.1684.06.0.00	FUSE HOLDER WITH 100 AMP FUSE	Spare Part	3975	15%
1904 02:1101.000 SPACER FOR PLEE FILTER Spare Part	1002	06.1724.01.0.00	FIP FOR HA694 TCI ENGINE CPCB II	Spare Part	130432	15%
1005 02.150 10.00 PLASTIC TUBE SOMM BAR Spare Part 1515 1500 15	1003	06.1724.22.0.00	STANDYNE ROTARY FIP FOR HA 694 TCI G1	Spare Part	158330	15%
1000 06.219.01.0.0	1004	06.211.01.0.00	SPACER FOR FUEL FILTER	Spare Part	440	15%
1000 06.219.02.0.00 TWO PIPE EAT HAMIFOLD F Spare Part 1326 155 1008 06.219.03.0.00 SEALING RING Spare Part 1415 151 1	1005	06.216.01.0.00	PLASTIC TUBE: 500MM BAR	Spare Part	191	15%
1007 60:219 02:00 TWO PIPE EAH MANIFOLD F Spare Part 13264 155 1008 62:219 03:00 SEALING RING Spare Part 415 156 1009 62:24 11:00 RUBBER HOSE: DEMAI PIPE Spare Part 415 156 1010 06:224 30:00 ASSEMBLY OF LUB OIL INLET PIPE Spare Part 729 115 1011 06:229 00:00 PRE CLEANER ASSEMBLY Spare Part 151 151 1013 06:229 00:00 PRE CLEANER ASSEMBLY Spare Part 151 151 1014 06:245:220:00 SILCON COATED FIBER GLASS CLOTH (SIZE AFTER FORMING 15" X" X 10" WITH FITTI Spare Part 151 151 1015 06:246:00:20 PRIMARY FILER ELEMENT Filter 1944 203 1016 06:246:00:20 PRIMARY FILER ELEMENT Filter 1944 203 1017 06:246:01:00 DIPSTICK ASSLY Spare Part 158 155 1018 06:246:01:00 ADAPTOR: BET EXH MOLD & TURBO Spare Part 122 151	1006	06.219.01.0.00	ONE PIPE EXH MANIFOLD F	· ·	11689	15%
1008 06.219.03.0.00						15%
1000 06.224.11.0.00 RUBBER HOSE: DRAIN PIPE Spare Part				· · · · · · · · · · · · · · · · · · ·		
1010 06.224.00.00						
1011 06.225.03.0.00 NUT (SPECIAL) Spare Part 154 155 151				· ·		
1012 06.229.0.0.00 PRE CLEANER ASSLY Spare Part 1517 1598 15191				· ·		
1013 06.229.60.0.00 PRE CLEANER ASSEMBLY Spare Part 7901 155 1014 06.249.22.0.00 SILICON COATED FIBER GLASS CLOTH (SIZE AFTER FORMING 15" X.7" X 10" WITH FITTI Spare Part 3108 155 1015 06.246.02.00 PRINARY FILTER ELEMENT Filter 4944 200 1016 06.246.03.0.00 SAFETY AIR FILTER ELEMENT Filter 1974 200 1017 06.248.01.0.00 DIPSTICK ASSLY Spare Part 68 155 1018 06.256.01.0.00 DIPSTICK ASSLY Spare Part 7548 159 1019 06.256.01.0.00 AIR NILET MANIFOLD Spare Part 122 159 1020 06.256.01.0.00 BRACKET FOR TURBOCCHARGER MOUNTING Spare Part 132 159 1021 06.256.01.0.00 BRACKET FOR ALTERNATOR Spare Part 132 159 1022 06.260.03.0.00 HOSE: AIR INLET MANIFOLD Spare Part 136 159 1023 06.260.03.0.00 BRACKET FOR ALTERNATOR Spare Part 202 159 </td <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
1014 06 245 22 0.00				· ·		
1015 06 246 02 0.00 PRIMARY FILTER ELEMENT Filter 4944 201 1016 06 246 03 0.00 SAFETY AIR FILTER ELEMNT Filter 1974 200 1017 06 246 10 0.00 OIDSTICK ASSLY Spare Part 189 159 1018 06 256 01 0.00 AIR INLET MANIFOLD Spare Part 7548 163 1019 06 256 01 0.00 ADAPTOR: BET EXH MOLD & TURBO Spare Part 182 159 1020 06 256 01 0.00 BRACKET FOR TURBO CHARGER MOUNTING Spare Part 132 159 1021 06 256 01 0.00 HOSE: AIR CLEANER Spare Part 115 159 1022 06 260 02 0.00 HOSE: AIR INLET MANIFOLD Spare Part 1815 159 1023 06 260 03 0.00 HOSE: AIR INLET MANIFOLD Spare Part 1805 159 1024 06 260 03 0.00 DOWEL BOLT FOR ALTERNATOR (24 V GAC SR) Spare Part 1805 159 1025 06 260 03 0.00 TENSION LEVER Spare Part 500 159				· ·		
1010 106 246 03 0.00						
1017 06.248.10.0.00 DIPSTICK ASSLY Spare Part 89 1.50	1015	06.246.02.0.00				20%
1019 06.254.01.0.00 AIR INLET MANIFOLD Spare Part 7.548 1.551 1.019 06.255.01.0.00 ADAPTOR: BET EXH MOLD & TURBO Spare Part 1.222 1.591 1.020 06.255.01.0.00 BRACKET FOR TURBOCHARGER MOUNTING Spare Part 3.021 1.020 06.255.03.0.00 JOINT: TURBO EXH OUTLET Spare Part 1.32 1.591 1.020 06.250.03.0.00 HOSE: AIR INLET MANIFOLD Spare Part 3.05 1.591 1.020 06.200.03.0.00 HOSE: AIR INLET MANIFOLD Spare Part 3.05 1.591 1.020 06.200.03.0.00 BRACKET FOR ALTERNATOR (24 V GAC 5R) Spare Part 3.05 1.591 1.020 06.200.03.0.00 DOWEL BOLT FOR ALTERNATOR (24 V GAC 5R) Spare Part 3.020 1.591 1.020 06.200.00 TENSION LEVER Spare Part 3.020 1.591 1.020 06.200.00 TENSION LEVER Spare Part 3.020 1.591 1.591 1.020 06.200.00 TENSION LEVER Spare Part 3.020 1.591 1.591 1.020 06.200.00 TENSION LEVER Spare Part 3.020 1.591 1.591 1.020 06.200.00 TENSION LEVER Spare Part 3.020 1.591 1.	1016	06.246.03.0.00	SAFETY AIR FILTER ELEMNT			20%
1019 06.255.01.0.00 ADAPTOR: BET EXH MOLD & TURBO Spare Part 1222 159 150	1017	06.248.10.0.00	DIPSTICK ASSLY	Spare Part	89	15%
1020 06.256.01.0.00 BRACKET FOR TURBOCHARGER MOUNTING Spare Part 3618 159 1021 06.256.03.0.00 JOINT: TURBO EXH OUTLET Spare Part 132 159 1022 06.260.03.0.00 HOSE: AIR INLET MANIFOLD Spare Part 1815 159 1023 06.260.03.0.00 HOSE: AIR INLET MANIFOLD Spare Part 1862 159 1024 06.265.04.0.00 BRACKET FOR ALTERNATOR (24 V GAC 5R) Spare Part 1862 159 1025 06.265.05.0.00 DOWEL BOLT FOR ALTERNATOR Spare Part 220 159 1026 06.265.05.0.00 TENSION LEVER Spare Part 5008 159 1026 06.265.05.0.00 TENSION LEVER Spare Part 5008 159 1026 06.265.05.0.00 TENSION LEVER Spare Part 5008 159 1026 06.265.05.0.00 INTERMEDIATE RING: 1.1MM Spare Part 5008 159 1026 06.290.02.0.00 INTERMEDIATE RING: 1.1MM Spare Part 5008 159 1029 06.309.02.0.00 RAIN CAP ASSLY Spare Part 1923 159 1030 06.309.02.0.00 BRACKET: ALTERNATOR Spare Part 520 159 1030 06.309.02.0.00 BRACKET: ALTERNATOR Spare Part 520 159 1030 06.309.00.00 BRACKET: ALTERNATOR Spare Part 520 159 159 150	1018	06.254.01.0.00	AIR INLET MANIFOLD	Spare Part	7548	15%
1021 06.256.03.0.00 JOINT: TURBO EXH OUTLET Spare Part 132 159 1022 06.260.02.0.00 HOSE: AIR CLEANER Spare Part 1815 159 1022 06.260.03.0.00 HOSE: AIR INLET MANIFOLD Spare Part 2305 159 1024 06.265.04.0.00 BRACKET FOR ALTERNATOR (24 V GAC SR) Spare Part 1862 169 1025 06.265.05.0.00 DOWLE BOLT FOR ALTERNATOR Spare Part 222 159 1026 06.265.05.0.00 DOWLE BOLT FOR ALTERNATOR Spare Part 222 159 1026 06.265.05.0.00 TENSION LEVER Spare Part 689 159 1027 06.266.01.0.00 EXHAUST SILENCER: HA694 Spare Part 5908 159 1028 06.292.01.0.00 INTERMEDIATE RING: 1.1MM Spare Part 159 1029 06.399.02.0.00 RAIN CAP ASSLY Spare Part 159 1030 06.399.02.0.00 BRACKET: ALTERNATOR Spare Part 203 159 1031 06.309.02.0.00	1019	06.255.01.0.00	ADAPTOR: BET EXH MOLD & TURBO	Spare Part	1222	15%
1022 06.280.02.0.00 HOSE: AIR CLEANER Spare Part 1815 159 1023 06.280.03.0.00 HOSE: AIR INLET MANIFOLD Spare Part 2305 159 1024 06.285.04.0.00 BRACKET FOR ALTERNATOR (24 V GAC SR) Spare Part 1862 159 1025 06.285.06.0.00 DOWEL BOLT FOR ALTERNATOR Spare Part 222 159 1026 06.285.06.0.00 TENSION LEVER Spare Part 689 159 1027 06.286.06.0.00 EXHAUST SILENCER: HA694 Spare Part 5908 159 1028 06.292.01.0.00 INTERMEDIATE RING: 1.1MM Spare Part 74 159 1029 06.309.02.0.00 RAIN CAP ASSLY Spare Part 193 159 1031 06.329.02.0.00 BRACKET: ALTERNATOR Spare Part 203 159 1031 06.326.03.0.00 BRACKET: ALTERNATOR Spare Part 52 159 1032 06.326.03.0.00 BUSH Spare Part 52 159 1033 06.326.03.0	1020	06.256.01.0.00	BRACKET FOR TURBOCHARGER MOUNTING	Spare Part	3618	15%
1023 06.260.03.0.00 HOSE: AIR INLET MANIFOLD Spare Part 2305 159 1024 06.265.04.0.00 BRACKET FOR ALTERNATOR (24 V GAC 5R) Spare Part 1862 159 1025 06.265.05.0.00 DOWEL BOLT FOR ALTERNATOR Spare Part 222 159 1026 06.265.06.0.00 TENSION LEVER Spare Part 689 159 1027 06.266.01.0.00 EXHAUST SILENCER: HA894 Spare Part 590 159 1028 06.292.01.0.00 INTERMEDIATE RING: 1.1MM Spare Part 74 159 1029 06.309.02.0.00 RAIN CAP ASSLY Spare Part 1923 159 1030 06.309.02.0.00 RAIN CAP ASSLY Spare Part 203 159 1031 06.326.09.0.00 BARCKET. ALTERNATOR Spare Part 751 159 1032 06.326.09.0.00 BUSH Spare Part 52 159 1033 06.326.09.0.00 BUSH Spare Part 52 159 1034 06.336.00.00	1021	06.256.03.0.00	JOINT: TURBO EXH OUTLET	Spare Part	132	15%
1024 06.265.04.0.00 BRACKET FOR ALTERNATOR (24 V GAC 5R) Spare Part 1862 159 1025 06.265.05.0.00 DOWEL BOLT FOR ALTERNATOR Spare Part 222 159 1026 06.265.06.0.00 TENSION LEVER Spare Part 689 159 1027 06.266.01.0.00 EXHAUST SILENCER: HA694 Spare Part 5908 159 1028 06.292.01.0.00 INTERMEDIATE RING: 1.1MM Spare Part 74 159 1029 06.309.02.0.00 RAIN CAP ASSLY Spare Part 1923 159 1030 06.309.04.0.00 CLAMP FOR EXHAUST PIPE Spare Part 203 159 1031 06.326.03.0.00 BRACKET: ALTERNATOR Spare Part 751 159 1032 06.326.09.0.00 BUSH Spare Part 52 159 1033 06.326.03.0.00 TENSION LEVER Spare Part 634 159 1034 06.333.02.0.00 FUEL PIPE: FUEL FILTER Spare Part 154 159 1035 06.333.02.0.00	1022	06.260.02.0.00	HOSE: AIR CLEANER	Spare Part	1815	15%
1025 06 265.05.0.00 DOWEL BOLT FOR ALTERNATOR Spare Part 222 159 1026 06 265.06.0.00 TENSION LEVER Spare Part 689 159 1027 06 266.01.00 EXHAUST SILENCER: HA694 Spare Part 5908 159 1028 06 292.01.0.00 INTERMEDIATE RING: 1.1MM Spare Part 74 159 1029 06 309.02.0.00 RAIN CAP ASSLY Spare Part 1923 159 1030 06 309.04.0.00 CLAMP FOR EXHAUST PIPE Spare Part 203 159 1031 06 326.03.0.00 BRACKET: ALTERNATOR Spare Part 751 159 1032 06 326.03.0.00 BUSH Spare Part 52 159 1033 06 326.03.0.00 TENSION LEVER Spare Part 52 159 1034 06 333.00.00 TENSION LEVER Spare Part 634 159 1035 06 333.00.00 FUEL PIPE: FUEL FILTER TO FIP Spare Part 58 159 1036 06 333.00.00 BRACKET </td <td>1023</td> <td>06.260.03.0.00</td> <td>HOSE: AIR INLET MANIFOLD</td> <td>Spare Part</td> <td>2305</td> <td>15%</td>	1023	06.260.03.0.00	HOSE: AIR INLET MANIFOLD	Spare Part	2305	15%
1026 06.265.06.0.00 TENSION LEVER Spare Part 689 159 1027 06.266.01.0.00 EXHAUST SILENCER: HA694 Spare Part 5908 159 1028 06.292.01.0.00 INTERMEDIATE RING: 1.1MM Spare Part 74 159 1029 06.309.02.0.00 RAIN CAP ASSLY Spare Part 1923 159 1030 06.309.04.0.00 CLAMP FOR EXHAUST PIPE Spare Part 203 159 1031 06.326.030.00 BRACKET: ALTERNATOR Spare Part 55 159 1032 06.326.090.00 BUSH Spare Part 52 159 1033 06.326.130.00 TENSION LEVER Spare Part 52 159 1034 06.333.01.0.00 FUEL PIPE FEED PUMP -FUEL FILTER Spare Part 58 159 1035 06.333.01.0.00 FUEL PIPE: FUEL FILTER TO FIP Spare Part 47 159 1036 06.333.01.0.00 BRACKET Spare Part 305 159 1037 06.333.01.0.00 BRACK	1024	06.265.04.0.00	BRACKET FOR ALTERNATOR (24 V GAC 5R)	Spare Part	1862	15%
1027 06.266.01.0.00 EXHAUST SILENCER: HA694 Spare Part 5908 159 1028 06.292.01.0.00 INTERMEDIATE RING: 1.1MM Spare Part 74 159 1029 06.309.02.0.00 RAIN CAP ASSLY Spare Part 1923 159 1030 06.309.04.0.00 CLAMP FOR EXHAUST PIPE Spare Part 203 159 1031 06.326.03.0.00 BRACKET: ALTERNATOR Spare Part 751 159 1032 06.326.03.0.00 BUSH Spare Part 52 159 1033 06.326.13.0.00 TENSION LEVER Spare Part 63 159 1034 06.333.01.0.00 FUEL PIPE FEED PUMP -FUEL FILTER Spare Part 168 159 1035 06.333.01.0.00 FUEL PIPE: FUEL FILTER TO FIP Spare Part 585 159 1036 06.333.01.0.00 BRACKET Spare Part 305 159 1037 06.333.01.0.00 BRACKET FOR FUEL FILTER Spare Part 305 159 1039 06.337.01.0.00	1025	06.265.05.0.00	DOWEL BOLT FOR ALTERNATOR	Spare Part	222	15%
1028 06.292.01.0.00 INTERMEDIATE RING: 1.1MM Spare Part 74 159 1029 06.309.02.0.00 RAIN CAP ASSLY Spare Part 1923 159 1030 06.309.04.0.00 CLAMP FOR EXHAUST PIPE Spare Part 203 159 1031 06.326.03.0.00 BRACKET: ALTERNATOR Spare Part 751 159 1032 06.326.09.0.00 BUSH Spare Part 52 159 1033 06.326.13.0.00 TENSION LEVER Spare Part 634 159 1034 06.333.01.0.00 FUEL PIPE FEED PUMP -FUEL FILTER Spare Part 1268 159 1035 06.333.02.0.00 FUEL PIPE: FUEL FILTER TO FIP Spare Part 585 159 1036 06.333.07.0.00 BRACKET Spare Part 305 159 1037 06.333.07.0.00 BRACKET FOR FUEL FILTER Spare Part 305 159 1038 06.337.01.0.00 V BELT: AX50 LP1303 RAW EDGE COGGED Spare Part 843 159 1040 06.337.01.0.00 V BELT: LP1254 AX48 RAW EDGE COGGED Spare Part 1212 159 <td>1026</td> <td>06.265.06.0.00</td> <td>TENSION LEVER</td> <td>Spare Part</td> <td>689</td> <td>15%</td>	1026	06.265.06.0.00	TENSION LEVER	Spare Part	689	15%
1029 06.309.02.0.00 RAIN CAP ASSLY Spare Part 1923 159 1030 06.309.04.0.00 CLAMP FOR EXHAUST PIPE Spare Part 203 159 1031 06.326.03.0.00 BRACKET: ALTERNATOR Spare Part 751 159 1032 06.326.09.0.00 BUSH Spare Part 52 159 1033 06.326.13.0.00 TENSION LEVER Spare Part 634 159 1034 06.333.01.0.00 FUEL PIPE FEED PUMP -FUEL FILTER Spare Part 1268 159 1035 06.333.02.0.00 FUEL PIPE: FUEL FILTER TO FIP Spare Part 477 159 1036 06.333.07.0.00 BRACKET Spare Part 305 159 1037 06.333.07.0.00 BRACKET FOR FUEL FILTER Spare Part 305 159 1038 06.337.01.0.00 V BELT: AX50 LP1303 RAW EDGE COGGED Spare Part 843 159 1040 06.337.01.0.00 V BELT: LP1254 AX48 RAW EDGE COGGED Spare Part 858 159 1040	1027	06.266.01.0.00	EXHAUST SILENCER: HA694	Spare Part	5908	15%
1029 06.309.02.0.00 RAIN CAP ASSLY Spare Part 1923 159 1030 06.309.04.0.00 CLAMP FOR EXHAUST PIPE Spare Part 203 159 1031 06.326.03.0.00 BRACKET: ALTERNATOR Spare Part 751 159 1032 06.326.09.0.00 BUSH Spare Part 52 159 1033 06.326.13.0.00 TENSION LEVER Spare Part 634 159 1034 06.333.01.0.00 FUEL PIPE FEED PUMP -FUEL FILTER Spare Part 1268 159 1035 06.333.02.0.00 FUEL PIPE: FUEL FILTER TO FIP Spare Part 477 159 1036 06.333.07.0.00 BRACKET Spare Part 305 159 1037 06.333.07.0.00 BRACKET FOR FUEL FILTER Spare Part 305 159 1038 06.337.01.0.00 V BELT: AX50 LP1303 RAW EDGE COGGED Spare Part 843 159 1040 06.337.01.0.00 V BELT: LP1254 AX48 RAW EDGE COGGED Spare Part 858 159 1040	1028	06.292.01.0.00	INTERMEDIATE RING: 1.1MM	Spare Part	74	15%
1030 06.309.04.0.00 CLAMP FOR EXHAUST PIPE Spare Part 203 159 1031 06.326.03.0.00 BRACKET: ALTERNATOR Spare Part 751 159 1032 06.326.09.0.00 BUSH Spare Part 52 159 1033 06.326.13.0.00 TENSION LEVER Spare Part 634 159 1034 06.333.01.0.00 FUEL PIPE FEED PUMP -FUEL FILTER Spare Part 1268 159 1035 06.333.02.0.00 FUEL PIPE: FUEL FILTER TO FIP Spare Part 477 159 1036 06.333.07.0.00 BRACKET Spare Part 477 159 1037 06.333.07.0.00 BRACKET FOR FUEL FILTER Spare Part 305 159 1038 06.337.01.0.00 V BELT: AX50 LP1303 RAW EDGE COGGED Spare Part 843 159 1039 06.338.01.0.00 V BELT: LP1254 AX48 RAW EDGE COGGED Spare Part 1212 159 1040 06.347.03.0.00 RUBBER HOSE: AIR CLEANER 100X100X80L Spare Part 109 159				1		15%
1031 06.326.03.0.00 BRACKET: ALTERNATOR Spare Part 751 159 1032 06.326.09.0.00 BUSH Spare Part 52 159 1033 06.326.13.0.00 TENSION LEVER Spare Part 634 159 1034 06.333.01.0.00 FUEL PIPE FEED PUMP -FUEL FILTER Spare Part 1268 159 1035 06.333.02.0.00 FUEL PIPE: FUEL FILTER TO FIP Spare Part 585 159 1036 06.333.03.0.00 BRACKET Spare Part 477 159 1037 06.333.07.0.00 BRACKET FOR FUEL FILTER Spare Part 305 159 1038 06.337.01.0.00 V BELT: AX50 LP1303 RAW EDGE COGGED Spare Part 843 159 1039 06.338.01.0.00 V BELT: LP1254 AX48 RAW EDGE COGGED Spare Part 858 159 1040 06.347.03.0.00 RUBBER HOSE: AIR CLEANER 100X100X80L Spare Part 1212 159 1042 06.353.01.0.00 V BELT: LP 1362 AX52 RAW EDGE COGGED Spare Part 109 159				· · · · · · · · · · · · · · · · · · ·		15%
1032 06.326.09.0.00 BUSH Spare Part 52 159 1033 06.326.13.0.00 TENSION LEVER Spare Part 634 159 1034 06.333.01.0.00 FUEL PIPE FEED PUMP -FUEL FILTER Spare Part 1268 159 1035 06.333.02.0.00 FUEL PIPE: FUEL FILTER TO FIP Spare Part 585 159 1036 06.333.03.0.00 BRACKET Spare Part 477 159 1037 06.333.07.0.00 BRACKET FOR FUEL FILTER Spare Part 305 159 1038 06.337.01.0.00 V BELT: AX50 LP1303 RAW EDGE COGGED Spare Part 843 159 1039 06.338.01.0.00 V BELT: LP1254 AX48 RAW EDGE COGGED Spare Part 858 159 1040 06.347.03.0.00 RUBBER HOSE: AIR CLEANER 100X100X80L Spare Part 1212 159 1041 06.353.01.0.00 V BELT: LP 1362 AX52 RAW EDGE COGGED Spare Part 1009 159 1042 06.354.01.0.00 V BELT AX46 RAW EDGE COGGED Spare Part 1514 159						
1033 06.326.13.0.00 TENSION LEVER Spare Part 634 159 1034 06.333.01.0.00 FUEL PIPE FEED PUMP -FUEL FILTER Spare Part 1268 159 1035 06.333.02.0.00 FUEL PIPE: FUEL FILTER TO FIP Spare Part 585 159 1036 06.333.07.0.00 BRACKET Spare Part 477 159 1037 06.333.07.0.00 BRACKET FOR FUEL FILTER Spare Part 305 159 1038 06.337.01.0.00 V BELT: AX50 LP1303 RAW EDGE COGGED Spare Part 843 159 1039 06.338.01.0.00 V BELT: LP1254 AX48 RAW EDGE COGGED Spare Part 858 159 1040 06.347.03.0.00 RUBBER HOSE: AIR CLEANER 100X100X80L Spare Part 1212 159 1041 06.353.01.0.00 V BELT: LP 1362 AX52 RAW EDGE COGGED Spare Part 1009 159 1042 06.354.01.0.00 V BELT AX46 RAW EDGE COGGED Spare Part 1514 159 1043 06.357.02.0.00 HYDRAULIC PUMP DOWTY IP 3052 Spare Part 40086 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
1034 06.333.01.0.00 FUEL PIPE FEED PUMP -FUEL FILTER Spare Part 1268 159 1035 06.333.02.0.00 FUEL PIPE: FUEL FILTER TO FIP Spare Part 585 159 1036 06.333.03.0.00 BRACKET Spare Part 477 159 1037 06.333.07.0.00 BRACKET FOR FUEL FILTER Spare Part 305 159 1038 06.337.01.0.00 V BELT: AX50 LP1303 RAW EDGE COGGED Spare Part 843 159 1039 06.338.01.0.00 V BELT: LP1254 AX48 RAW EDGE COGGED Spare Part 858 159 1040 06.347.03.0.00 RUBBER HOSE: AIR CLEANER 100X100X80L Spare Part 1212 159 1041 06.353.01.0.00 V BELT: LP 1362 AX52 RAW EDGE COGGED Spare Part 1009 159 1042 06.354.01.0.00 V BELT AX46 RAW EDGE COGGED Spare Part 1514 159 1043 06.357.02.0.00 HYDRAULIC PUMP DOWTY IP 3052 Spare Part 40086 159 1044 06.358.12.0.00 ADAPTOR ON UNLOADER VALVE Spare Part						
1036 66.333.02.0.00 FUEL PIPE: FUEL FILTER TO FIP Spare Part 585 159 1036 06.333.03.0.00 BRACKET Spare Part 477 159 1037 06.333.07.0.00 BRACKET FOR FUEL FILTER Spare Part 305 159 1038 06.337.01.0.00 V BELT: AX50 LP1303 RAW EDGE COGGED Spare Part 843 159 1039 06.338.01.0.00 V BELT: LP1254 AX48 RAW EDGE COGGED Spare Part 858 159 1040 06.347.03.0.00 RUBBER HOSE: AIR CLEANER 100X100X80L Spare Part 1212 159 1041 06.353.01.0.00 V BELT: LP 1362 AX52 RAW EDGE COGGED Spare Part 1009 159 1042 06.354.01.0.00 V BELT AX46 RAW EDGE COGGED Spare Part 1514 159 1043 06.357.02.0.00 HYDRAULIC PUMP DOWTY IP 3052 Spare Part 40086 159 1044 06.358.12.0.00 ADAPTOR ON UNLOADER VALVE Spare Part 338 159						
1036 06.333.03.0.00 BRACKET Spare Part 477 159 1037 06.333.07.0.00 BRACKET FOR FUEL FILTER Spare Part 305 159 1038 06.337.01.0.00 V BELT: AX50 LP1303 RAW EDGE COGGED Spare Part 843 159 1039 06.338.01.0.00 V BELT: LP1254 AX48 RAW EDGE COGGED Spare Part 858 159 1040 06.347.03.0.00 RUBBER HOSE: AIR CLEANER 100X100X80L Spare Part 1212 159 1041 06.353.01.0.00 V BELT: LP 1362 AX52 RAW EDGE COGGED Spare Part 1009 159 1042 06.354.01.0.00 V BELT AX46 RAW EDGE COGGED Spare Part 1514 159 1043 06.357.02.0.00 HYDRAULIC PUMP DOWTY IP 3052 Spare Part 40086 159 1044 06.358.12.0.00 ADAPTOR ON UNLOADER VALVE Spare Part 338 159				· ·		
1037 06.333.07.0.00 BRACKET FOR FUEL FILTER Spare Part 305 159 1038 06.337.01.0.00 V BELT: AX50 LP1303 RAW EDGE COGGED Spare Part 843 159 1039 06.338.01.0.00 V BELT: LP1254 AX48 RAW EDGE COGGED Spare Part 858 159 1040 06.347.03.0.00 RUBBER HOSE: AIR CLEANER 100X100X80L Spare Part 1212 159 1041 06.353.01.0.00 V BELT: LP 1362 AX52 RAW EDGE COGGED Spare Part 1009 159 1042 06.354.01.0.00 V BELT AX46 RAW EDGE COGGED Spare Part 1514 159 1043 06.357.02.0.00 HYDRAULIC PUMP DOWTY IP 3052 Spare Part 40086 159 1044 06.358.12.0.00 ADAPTOR ON UNLOADER VALVE Spare Part 338 159						
1038 06.337.01.0.00 V BELT: AX50 LP1303 RAW EDGE COGGED Spare Part 843 159 1039 06.338.01.0.00 V BELT: LP1254 AX48 RAW EDGE COGGED Spare Part 858 159 1040 06.347.03.0.00 RUBBER HOSE: AIR CLEANER 100X100X80L Spare Part 1212 159 1041 06.353.01.0.00 V BELT: LP 1362 AX52 RAW EDGE COGGED Spare Part 1009 159 1042 06.354.01.0.00 V BELT AX46 RAW EDGE COGGED Spare Part 1514 159 1043 06.357.02.0.00 HYDRAULIC PUMP DOWTY IP 3052 Spare Part 40086 159 1044 06.358.12.0.00 ADAPTOR ON UNLOADER VALVE Spare Part 338 159						
1039 06.338.01.0.00 V BELT: LP1254 AX48 RAW EDGE COGGED Spare Part 858 159 1040 06.347.03.0.00 RUBBER HOSE: AIR CLEANER 100X100X80L Spare Part 1212 159 1041 06.353.01.0.00 V BELT: LP 1362 AX52 RAW EDGE COGGED Spare Part 1009 159 1042 06.354.01.0.00 V BELT AX46 RAW EDGE COGGED Spare Part 1514 159 1043 06.357.02.0.00 HYDRAULIC PUMP DOWTY IP 3052 Spare Part 40086 159 1044 06.358.12.0.00 ADAPTOR ON UNLOADER VALVE Spare Part 338 159		+		· ·		
1040 06.347.03.0.00 RUBBER HOSE: AIR CLEANER 100X100X80L Spare Part 1212 159 1041 06.353.01.0.00 V BELT: LP 1362 AX52 RAW EDGE COGGED Spare Part 1009 159 1042 06.354.01.0.00 V BELT AX46 RAW EDGE COGGED Spare Part 1514 159 1043 06.357.02.0.00 HYDRAULIC PUMP DOWTY IP 3052 Spare Part 40086 159 1044 06.358.12.0.00 ADAPTOR ON UNLOADER VALVE Spare Part 338 159						15%
1041 06.353.01.0.00 V BELT: LP 1362 AX52 RAW EDGE COGGED Spare Part 1009 159 1042 06.354.01.0.00 V BELT AX46 RAW EDGE COGGED Spare Part 1514 159 1043 06.357.02.0.00 HYDRAULIC PUMP DOWTY IP 3052 Spare Part 40086 159 1044 06.358.12.0.00 ADAPTOR ON UNLOADER VALVE Spare Part 338 159	1039	06.338.01.0.00	V BELT: LP1254 AX48 RAW EDGE COGGED	Spare Part		15%
1042 06.354.01.0.00 V BELT AX46 RAW EDGE COGGED Spare Part 1514 159 1043 06.357.02.0.00 HYDRAULIC PUMP DOWTY IP 3052 Spare Part 40086 159 1044 06.358.12.0.00 ADAPTOR ON UNLOADER VALVE Spare Part 338 159	1040	06.347.03.0.00	RUBBER HOSE: AIR CLEANER 100X100X80L	Spare Part	1212	15%
1043 06.357.02.0.00 HYDRAULIC PUMP DOWTY IP 3052 Spare Part 40086 159 1044 06.358.12.0.00 ADAPTOR ON UNLOADER VALVE Spare Part 338 159	1041	06.353.01.0.00	V BELT: LP 1362 AX52 RAW EDGE COGGED	Spare Part		15%
1044 06.358.12.0.00 ADAPTOR ON UNLOADER VALVE Spare Part 338 159	1042	06.354.01.0.00	V BELT AX46 RAW EDGE COGGED	Spare Part	1514	15%
	1043	06.357.02.0.00	HYDRAULIC PUMP DOWTY IP 3052	Spare Part	40086	15%
1045 06.363.10.0.00 ASSLY.OF CRANK PULLEY AND DAMPER Spare Part 13981 159	1044	06.358.12.0.00	ADAPTOR ON UNLOADER VALVE	Spare Part	338	15%
	1045	06.363.10.0.00	ASSLY.OF CRANK PULLEY AND DAMPER	Spare Part	13981	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
1046	06.376.03.0.00	"T" BOLT CLAMP KLIPCO TB72/JUPITOR (79 TO 87 DIA)	Spare Part	274	15%
1047	06.376.04.0.00	T BOLT CLAMP	Spare Part	302	15%
1048	06.376.05.0.00	T BOLT CLAMP KLIPCO TB64 JUPITOR 50 TO 64 DIA	Spare Part	222	15%
1049	06.376.08.0.00	T BOLT CLAMP JUPITOR RANGE FROM DIA 116 TO 123	Spare Part	228	15%
1050	06.387.05.0.00	CLAMP FOR BATTERY	Spare Part	2631	15%
1051	06.389.10.0.00	SUB ASSLY OF CAM SHAFT	Spare Part	38898	15%
1052	06.398.01.0.00	INLET MANIFOLD	Spare Part	4225	15%
1053	06.403.01.0.00	HOSE: AIR CLEANER	Spare Part	3000	15%
1054	06.420.01.0.00	EXHAUST DIFFUSER (UPWARD OPEN)	Spare Part	3800	15%
1055	06.429.10.0.SP	SET OF JOINTS	Spare Part	2895	15%
1056	06.436.01.0.00	SPINON LUBE OIL FILTER	Filter	1160	20%
1057	06.441.10.0.00	MC NO 9 400 030 622 FUEL PUMP ASSLY MICO 4	Spare Part	64790	15%
1058	06.465.01.0.00	BRACKET FOR AIR CLEANER	Spare Part	2120	15%
1059	06.465.03.0.00	HOSE: AIR CLEANER	Spare Part	545	15%
1060	06.468.02.0.00	FLANGE FOR EXHAUST DIFFUSER DOWN OPEN	Spare Part	529	15%
1061	06.468.03.0.00	JOINT: EXH DIFFUSER	Spare Part	209	15%
1062	06.468.04.0.00	JOINT: EXHAUST	Spare Part	95	15%
1063	06.469.10.0.00	HOT AIR DUCTING: UPWARD OPENING	Spare Part	16006	15%
1064	06.471.03.0.00	RUBBER SEALING RING	Spare Part	2009	15%
1065	06.471.10.0.00	ASSEMBLY AIR GUIDE RING & BRUSH	Spare Part	7289	15%
1066	06.473.90.0.00	SET OF HIGH PRESS PIPE: DHA694	Spare Part	7154	15%
1067	06.474.03.0.00	FUEL PIPE: FEED PUMP TO FUEL FILTER	Spare Part	588	15%
1068	06.474.04.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	526	15%
1069	06.474.05.0.00	FUEL FILTER ELEMENT ASSLY	Filter	3252	20%
1070	06.474.19.0.00	ADAPTOR FOR AIR BLEED FILTER	Spare Part	145	15%
1071	06.474.24.0.00	FUEL PIPE FROM COMBINED LEAK OFF TO TANK	Spare Part	1200	15%
1072	06.474.25.0.00	COMBINED LEAK OFF PIPE FROM NOZZLE LEAK OFF TO FILTER LEAK OFF	Spare Part	622	15%
1073	06.474.50.0.00	FUEL FILTER BSIII HA494 HA694	Filter	8193	20%
1074	06.482.01.0.00	FRONT COVER	Spare Part	12864	15%
1075	06.484.06.0.00	ADAPTOR ON CRANK PULLEY	Spare Part	2228	15%
1076	06.484.11.0.00	FAN: 390MM OD 11 BLADES	Spare Part	4682	20%
1077	06.484.12.0.00	ADAPTOR FOR FAN	Spare Part	1923	15%
1078	06.488.01.0.00	EXHAUST DIFFUSER UPWARD OPEN	Spare Part	3821	15%
1079	06.491.01.0.00	BELT: AX47, LP1227 RAW EDGE COGGED	Spare Part	1145	15%
1080	06.5001.21.0.00	FUEL PIPE (RETURN) M12 X 15 MALE PLUG X M14 X 15 BANJO (900	Spare Part	1363	15%
1081	06.527.30.0.00	FIP ASSLY 9 5 DIA	Spare Part	105525	15%
1082	06.529.20.0.00	FIP ASSLY: 9.5 DIA	Spare Part	79676	15%
1083	06.531.01.0.00	BELT : LP-1150 AX44 RAW EDGE COGGED	Spare Part	1191	15%
1084	06.550.20.0.00	PRE CLEANER ASSLY	Spare Part	3883	15%
1085	06.550.50.0.00	PRE CLEANER FLEETGUARD 8400159	Spare Part	12123	15%
1086	06.555.20.0.00	SUCTION TUBE	Spare Part	991	15%
1087	06.573.50.0.00	ASSEMBLY IINSTUMENT PANEL WITH METERS(ALTR,HR)	Spare Part	15058	15%
1088	06.574.20.0.00	WIRING HARNESS HA694 P.G.ENGINE WITH ALT	Spare Part	1985	15%
1089	06.586.02.0.00	ADAPTER FOR EXHAUST SILENCER	Spare Part	1157	15%
1090	06.597.94.0.00	LEFT HAND LOCK WITH CATCHER (UPTO 82.5 KVA)	Spare Part	2335	15%
1091	06.598.03.0.00	LH LOCK WITH CATCHER 100-600 KV	Spare Part	2308	15%
1092	06.598.04.0.00	RH LOCK WITH CATCHER 100-600 KVA	Spare Part	2308	15%
1093	06.598.05.0.00	RH LOCK WITH CATCHER TO 82.5 KVA	Spare Part	2308	15%
1094	06.602.10.0.00	EXPANSION BELLOW ASSLY 3"	Spare Part	7357	15%
1095	06.610.02.0.00	HOSE TAIL: FUEL LEAK OFF CONN	Spare Part	95	15%
1096	06.610.03.0.00	FUEL PIPE: 9.5 I.D.X4000 L	Spare Part	2283	15%
1097	06.610.04.0.00	WIRE HOSE CLIP S/F: 16MM PIPE	Spare Part	83	15%
1098	06.610.08.0.00	ADAPTOR FOR 2R1040 FOR WATER CONNECTION	Spare Part	440	15%
1099	06.610.10.0.00	HOSE TAIL CONNECTION S/F M14	Spare Part	212	15%
1100	06.628.02.0.00	SLEEVE FOR EXHAUST SILENCER	Spare Part	1289	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
1101	06.631.01.0.00	VALVE GUIDE	Spare Part	246	15%
1102	06.631.02.0.00	VALVE STEM SEAL	Spare Part	246	15%
1103	06.635.14.0.00	FUEL PIPE TANK TO FEED PUMP	Spare Part	1603	15%
1104	06.654.10.0.00	FUEL PIPE 4MTR AND CLAMPS	Spare Part	3249	15%
1105	06.672.01.0.00	V BELT: LP1176 AX45 RAW EDGE COGGED	Spare Part	1418	15%
1106	06.677.10.0.00	LUBE OIL SUMP	Spare Part	14778	15%
1107	06.699.01.0.00	ADAPTOR FOR AUTOTIMER	Spare Part	794	15%
1108	06.699.02.0.00	FUEL PUMP GEAR	Spare Part	4923	15%
1109	06.711.10.0.00	LEAK OFF PIPE ASSLY	Spare Part	265	15%
1110	06.712.01.0.00	RPM INDICATOR: BUILT IN REGULATOR	Spare Part	6957	15%
1111	06.713.03.0.00	T- BOLT CLAMP (90 MM)	Spare Part	191	15%
1112	06.713.04.0.00	T BOLT CLAMP 104 MM	Spare Part	172	15%
1113	06.718.02.0.00	FUEL PIPE (RETURN) M12X15 MALE PLUG X M14X15 BANJO	Spare Part	2111	15%
1114	06.718.04.0.00	FUEL PIPE PRE-FILTER TO TANK	Spare Part	806	15%
1115	06.718.05.0.00	FUEL PIPE PRE-FILTER TO FEED PUMP	Spare Part	622	15%
1116	06.718.11.0.00	FUEL PIPE INLET: M14X1.5 BANJO BOTH SIDE 650MM	Spare Part	1092	15%
1117	06.738.10.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	40886	15%
1118	06.751.01.0.00	RIGHT ANGLE ADAPTOR FOR SC160 COMP	Spare Part	1412	15%
1119	06.751.06.0.00	BANJO BOLT (M22X1.5)	Spare Part	523	15%
1120	06.751.40.0.00	BANJO COUPLING	Spare Part	2323	15%
1121	06.757.03.0.00	PRIMARY FILTER ELEMENT	Filter	1745	20%
1122	06.757.04.0.00	SAFETY AIR FILTER ELEMNT	Filter	848	20%
1123	06.757.30.0.00	AIR CLEANER ASSLY + STRAP	Spare Part	8893	20%
1124	06.757.40.0.00	MOUNTING STRAP ASSEMBLY (FOR AIR CLEANER)	Spare Part	724	20%
1125	06.761.20.0.00	AIR CLEANER ASSLY+ STRAP	Spare Part	8156	20%
1126	06.764.02.0.00	ADAPTOR: TURBOCHARGER MOUNTING	Spare Part	1188	15%
1127	06.764.03.0.00	JOINT: TURBOCHARGER	Spare Part	545	15%
1128	06.765.01.0.00	BRACKET FOR TURBOCHARGER MOUNTING	Spare Part	1754	15%
1129	06.765.02.0.00	SWIVEL ADAPTOR	Spare Part	1160	15%
1130	06.766.10.0.00	TURBOCHARGER	Spare Part	103663	15%
1131	06.766.20.0.00	TURBOCHARGER	Spare Part	123220	15%
1132	06.767.10.0.00	ASSEMBLY OF LUBE OIL INLET PIPE	Spare Part	1231	15%
1133	06.767.20.0.00	SUB ASSEMBLY OF LUBE OIL DRAIN PIPE (LONG)	Spare Part	369	15%
1134	06.767.30.0.00	SUBASSEMBLY OF LUBE OIL DRAIN PIPE	Spare Part	332	15%
1135	06.770.01.0.00	HOSE: AIR CLEANER	Spare Part	772	15%
1136	06.770.02.0.00	PLATE FOR AIR CLEANER MOUNTING	Spare Part	957	15%
1137	06.770.03.0.00	HOSE: AIR CLEANER	Spare Part	3477	15%
1138	06.776.10.0.00	DIPSTICK ASSEMBLY 25 DEG INCL SUMP	Spare Part	92	15%
1139	06.776.30.0.00	DIPSTICK ASSEMBLY S F 25 DEG SUMP S F VOLVO	Spare Part	1052	15%
1140	06.786.20.0.00	EXPANSION BELLOW	Spare Part	8305	15%
1141	06.791.01.0.00	STOPPING BAR FOR STOP SOLENOID	Spare Part	52	15%
1142	06.793.01.0.00	STOP SOLENOID 24V SING COIL 75 DIA	Spare Part	11834	15%
1143	06.819.20.0.00	NOZZLE LEAK OFF PIPE	Spare Part	1569	15%
1144	06.820.01.0.00	RUBBER HOSE (82 X 82 X 90 DEG) FOR AIR CLEANER	Spare Part	1385	15%
1145	06.821.01.0.00	EXHAUST BEND (76.2 X 70.5 X 90 DEG)	Spare Part	2840	15%
1146	06.821.03.0.00	EXPANSION BELLOW: 3"	Spare Part	8791	15%
1147	06.821.04.0.00	EXPANSION BELOW (3.0")	Spare Part	7415	15%
1148	06.866.10.0.00	ASSEMBLY AIR GUIDE RING MOUNT	Spare Part	4892	15%
1149	06.875.25.0.PR	ELECTRICAL DWG FOR ANTI CONDENSATION HEATER CONTROL PANEL 230V AC 1 PH 50HZ	Spare Part	73645	15%
1150	06.886.04.0.00	RUBBER HOSE (TURBO AIR OUTLET)	Spare Part	569	15%
1151	06.887.01.0.00	ONE PIPE EXHAUST MANIFOLD	Spare Part	2658	15%
1151	06.887.07.0.00	JOINT: EGR PIPE-HA6 BSIII	Spare Part	483	15%
		JOINT: EGR PIPE-HA6 BSIII JOINT: EGR PIPE-50 CRS EXH M'FOLD	Spare Part	538	15%
1153	06.887.09.0.00 06.890.40.0.00				
	100.090.40.0.00	CRANKCASE WITHOUT BEARINGS	Spare Part	232785	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
31.110.	T dit italiibei	Ture Description	dutingo.,	without Vat in	Charge%
1156	06.891.06.0.00	ADAPTOR FOR LUBE OIL IN PIPE ON CRANCKCASE	Spare Part	NPR 151	15%
1157	06.891.07.0.00	HOSE (L.O TURBO DRAIN)S/F L.H.DSA	Spare Part	320	15%
1158	06.891.13.0.00	ADAPTOR ON CRANKCASE FOR TORBO INLET PIPE	Spare Part	182	15%
1159	06.891.40.0.00	ASSEMBLY OF LUBE OIL INLET PIPE	Spare Part	1092	15%
1160	06.915.20.0.00	WIRING HARNESS: ESU UNIT SIDE MOUNTED CONTROL PANEL	Spare Part	7295	15%
1161	06.953.18.0.00	INDICATING LAMP GREEN- 240V	Spare Part	1028	15%
1162	06.953.38.0.00	TERMINAL TYPE CTS 2 5UN	Spare Part	43	15%
1163	06.971.10.0.00	WIRING HARNESS WITH PUMP MOUNTED STOP SOLENOID	Spare Part	5652	15%
1164	06.972.01.0.00	MOUNTING RING FOR TURBO	Spare Part	1708	15%
1165	06.972.02.0.00	DOG BONE FOR KKK27 TURBO	Spare Part	1225	15%
1166	06.973.40.0.00	B.T. UNIT ASSLY & ACTUATOR	Spare Part	5711	15%
1167	06.973.60.0.00	SUB ASSEMBLY OF B.T UNIT (MODIFIED FOR BANDED BELT)	Spare Part	7120	15%
1168				8477	15%
	06.973.70.0.00	B.T UNIT ASSEMBLY (MODIFIED) WITH ACTUATOR PLATE	Spare Part	8194	15%
1169	06.973.90.0.00 06.973.95.0.00	B.T. UNIT SUB ASSLY MODIFIED	Spare Part		
1170		ASSEMBLY OF BELT TENSION UNIT	Spare Part	9089	15%
1171	06.980.07.0.00	RELAY 12 VDC 100 AMP CAPACITY TYPE BGR 215	Spare Part	914	15%
1172	06.999.35.0.00	HA694 CPCB II Service Kit - B Check	Filter	4137	20%
1173	06.999.36.0.00	HA696 CPCB II Service Kit with Air Filter - C Check	Filter	6383	20%
1174	06.M801.17.0.00	6A 1 POLE MCB MAKE SCHNEIDER TYPE A9N1P06C	Spare Part	1289	15%
1175	08.001.18.0.00	CORE PLUG FOR OIL GALLERY	Spare Part	71	15%
1176	08.010.12.0.00	VALVE STEM SEAL	Spare Part	222	15%
1177	08.021.02.0.00	JOINT: FEED PUMP	Spare Part	15	15%
1178	08.030.04.0.00	FORK FOR INJECTOR	Spare Part	265	15%
1179	10.004.11.0.00	STEEL BALL HARD 1/4" DIA	Spare Part	22	15%
1180	10.007.02.0.00	WOODRUFF KEY	Spare Part	98	15%
1181	10.007.03.0.00	KEY: FLYWHEEL	Spare Part	225	15%
1182	10.008.07.0.00	JT CR CASE FWE M B HSG SSPL SS KO 1243	Spare Part	249	15%
1183	10.011.04.0.00	NUT (7/16" BSF)	Spare Part	62	15%
1184	10.013.08.0.00	STUD: 5/16" BSF X 1-5/16" LG	Spare Part	62	15%
1185	10.016.04.0.00	VALVE TAPPET (STEEL) AV1	Spare Part	225	15%
1186	10.018.02.0.00	GOVERNOR SPRING(1500 & 1800 RPM)	Spare Part	86	15%
1187	10.018.10.0.00	GOVERNOR WT ASSLY: 1500 RPM	Spare Part	425	15%
1188	10.020.03.0.00	HARD WASHER (F)	Spare Part	25	15%
1189	10.024.07.0.00	JOINT: F-BKT & ADAPT-PL	Spare Part	31	15%
1190	10.024.11.0.00	JOINT: ADAPT-PL & C'CASE	Spare Part	37	15%
1191	10.025.08.0.00	JOINT: FP BKT & C'CASE	Spare Part	34	15%
1192	10.027.02.0.00	LEAD SEAL 5945010300	Spare Part	25	15%
1193	10.027.11.0.00	JOINTT-0010"	Spare Part	31	15%
1194	10.027.12.0.00	JOINT-0015"	Spare Part	28	15%
1195	10.027.29.0.00	JOINT: 0.005" AL	Spare Part	25	15%
1196	10.027.35.0.00	JOINT: FP BRACKET & SHIMS	Spare Part	18	15%
1197	10.029.07.0.00	WASHER FOR INJECTOR	Spare Part	25	15%
1198	10.030.05.0.00	OIL SEAL	Spare Part	1637	15%
1199	10.031.05.0.00	LUBE OIL FILTER ELEMENT	Filter	111	20%
1200	10.043.02.0.00	JOINT: WATER FLANGE	Spare Part	25	15%
1201	10.046.02.0.00	P K DRIVE SCREW 1/8"X3/8" (RIVET)	Spare Part	9	15%
1202	10.062.01.0.00	EXTENSION SHAFT (7.625" LONG)	Spare Part	3606	15%
1203	10.079.02.0.00	STRAINER HOLDER	Spare Part	188	15%
1204	10.323.03.0.00	JOINT: WATER INLET M'FOLD	Spare Part	49	15%
1205	10.366.40.0.00	GEAR PUMP-AV1,SR,WITH REL.VALVE	Spare Part	2012	15%
1206	10.710.10.0.00	OVERLOAD STOPPER ASSLY	Spare Part	209	15%
1207	10.950.12.0.00	FLYWHEEL KEY PULLER 101812	Spare Part	13375	15%
1208	11.002.04.0.00	LOCKING PIN F FOR INT BRG HSG	Spare Part	95	15%
1209	11.006.02.0.00	GEAR COVER PLATE	Spare Part	2495	15%
1210	11.006.04.0.00	JT GEAR COVER PLATE& C'CASE	Spare Part	222	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		,		without Vat in NPR	Charge%
1211	11.013.22.0.00	RACK ADJ SCREW TWIN FUEL PUMP LINKAGE	Spare Part	135	15%
1212	11.013.23.0.00	SET SCREW	Spare Part	108	15%
1213	11.014.04.0.00	JT GEAR COVER& GR COVER PLATE	Spare Part	406	15%
1214	11.015.01.0.00	INSPECTION COVER F AV2	Spare Part	1366	15%
1215	11.015.03.0.00	JOINT: INSP COVER	Spare Part	83	15%
1216	11.018.04.0.00	FUEL FILTER ELEMENT -AV2	Filter	145	20%
1217	11.037.03.0.00	GOVN PUSH ROD F W E	Spare Part	37	15%
1218	11.037.20.0.00	ASSLY OF GOV PUSH ROD GEAR END TWIN	Spare Part	212	15%
1219	11.169.05.0.00	DOWEL F	Spare Part	25	15%
1220	11.203.09.0.00	FUEL FILTER ELEMENT	Filter	777	20%
1221	11.203.95.0.00	FUEL FILTER ASSLY(0.5 LIT)(VAVE)	Spare Part	1231	20%
1222	11.242.10.0.00	L O PIPE ASSLY -C'CASE-FWE BRG HSG	Spare Part	375	15%
1223	12.005.05.0.00	O RING: PUSH ROD TUBE VITON	Spare Part	52	15%
1224	12.005.08.0.00	RUBBER BUSH: BOTTOM	Spare Part	52	15%
1225	12.005.09.0.00	SUPPORT FOR PUSH ROD TUBE	Spare Part	637	15%
1226	12.005.11.0.00	JOINT: PUSH ROD TUBE SUPPORT	Spare Part	52	15%
1227	12.020.03.0.00	V BELTS A40	Spare Part	545	15%
1228	12.034.02.0.00	COGGED 'V' BELT - AX-54	Spare Part	1052	15%
1229	12.143.10.0.00	VSC UNIT ASSLY WITH BKT CABLE REMOTE	Spare Part	3354	15%
1230		FUEL PIPE: TANK TO FEED PUMP TA1/TA2		425	
	13.027.02.0.00		Spare Part	425	15% 20%
1231	13.046.07.0.00	AIR CLEANER ELEMENT-AV2 O RING 28 IDX2 5 21509	Filter	37	15%
1232	16.014.19.0.00		Spare Part		
1233	16.016.70.0.00	DECOM ARRANGEMENT	Spare Part	302	15%
1234	16.051.11.0.00	HOLLOW DOWEL	Spare Part	22	15%
1235	18.011.26.0.00	FUEL OIL STRAINER	Spare Part	46	15%
1236	18.026.40.0.00	FILTER CASING ASSEMBLY (METALLIC PLUG)	Spare Part	2492	15%
1237	18.026.50.0.00	DIPSTICK ASSLY WITH "O" RING S/F SINGLE CYL.E	Spare Part	178	15%
1238	18.034.17.0.00	OIL FILLING BODY - TV1	Spare Part	963	15%
1239	18.051.61.0.00	CAP FOR FUEL TANK NEW	Spare Part	262	15%
1240	18.067.30.0.00	DIPSTICK ASSEMBLY METALLIC	Spare Part	102	15%
1241	18.078.02.0.00	FLEXIBLE PIPE (T TO F)	Spare Part	575	15%
1242	18.097.05.0.00	STARTER RING	Spare Part	4403	20%
1243	18.137.01.0.00	CAMSHAFT EXTENSION SHAFT 4.437"LONG	Spare Part	2372	15%
1244	19.002.30.0.00	INTERMEDIATE BEARING HOUSING ASSLY TV2	Spare Part	3148	15%
1245	19.003.30.0.00	CR SHAFT	Spare Part	29277	15%
1246	19.216.03.0.00	OIL SEAL FLYWHEEL END 73 OD CLOCKWISE	Spare Part	1634	15%
1247	19.216.04.0.00	OIL SEAL FLYWHEEL END	Spare Part	982	15%
1248	19.216.30.0.00	MAIN BRG.HSG(FWE)FW HSG+MAIN BRG.	Spare Part	2754	15%
1249	20.007.30.0.00	MAIN BRG HSG(FWE) FW HSG+MAIN BRG	Spare Part	4012	15%
1250	20.367.01.0.00	ANTI VIBRATION MOUNTS	Spare Part	1369	15%
1251	21.115.03.0.00	JOINT FOR ADAPTOR	Spare Part	86	15%
1252	21.115.04.0.00	JOINT: EXH ADAPTOR	Spare Part	135	15%
1253	21.255.01.0.00	SUPPORT FOR ALTBRACKET	Spare Part	735	15%
1254	21.255.02.0.00	PULLEY FOR ALTERNATOR	Spare Part	1065	15%
1255	21.255.03.0.00	LEVER BELT TENSION FOR ALTERNATOR	Spare Part	188	15%
1256	21.255.06.0.00	ALTERNATOR BRACKET FINISH E SERIES AGRI ENGINES	Spare Part	1031	15%
1257	21.267.06.0.00	EXTENSION SHAFT FOR CRANK PULLEY FINISH BOLTED CR PULLEY	Spare Part	2969	15%
1258	21.279.02.0.00	ADAPTOR FOR PRESSURE SWITCH	Spare Part	145	15%
1259	21.279.04.0.00	LUBE OIL PRESS SENDOR 0.75 +/- 0.15 B	Spare Part	5403	15%
1260	21.343.01.0.00	ADAPTOR FOR SENDER UNIT YENKEY	Spare Part	209	15%
1261	22.078.04.0.00	PLUG FOR BREATHER TUBE	Spare Part	15	15%
1262	22.118.01.0.00	RUBBER SLEEVE(12DIA)	Spare Part	28	15%
1263	24.083.01.0.00	RUBBER SLEEVE (20DIA)	Spare Part	74	15%
1264	29.224.28.0.00	R.E.BEARING M6 RH THREADS	Spare Part	1080	15%
1265	29.224.29.0.00	R.E.BEARING M6 LH THREADS	Spare Part	883	15%



				Price to	
C: N-	Don't November	Book Bookships	Catanami	Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
				NPR	.=0/
1266	2H.001.50.0.00	CRANKCASE ASSEMBLY	Spare Part	108472	15%
1267	2H.003.10.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	19947	15%
1268	2H.004.04.0.00	RETAINING PLATE FOR INTERMEDIATE GEAR	Spare Part	655	15%
1269	2H.004.11.0.00	SUPPORT FOR INTERMEDIATE GEAR	Spare Part	3935	15%
1270	2H.005.11.0.00	JOINT: GEAR COVER	Spare Part	388	15%
1271	2H.006.01.0.00	OIL SEAL HOUSING: FLYWHEEL END	Spare Part	2502	15%
1272	2H.006.11.0.00	JOINT FOR OIL SEAL HOUSING	Spare Part	274	15%
1273	2H.006.20.0.00	PLATE: RUBBER MOULDING	Spare Part	1560	15%
1274	2H.008.07.0.00	O RING: CYLINDER LINER	Spare Part	86	15%
1275	2H.008.10.0.00	CYL LINER ASSEMBLY	Spare Part	5541	15%
1276	2H.008.11.0.00	O RING: CYLINDER LINER- VITON	Spare Part	249	15%
1277	2H.009.10.0.00	PISTON ASSEMBLY	Spare Part	6338	15%
1278	2H.009.30.0.00	PISTON RING SET 105 DIA	Spare Part	2308	15%
1279	2H.009.35.0.00	PISTON RING SET	Spare Part	2898	15%
1280	2H.009.55.0.00	PISTON RING SET	Spare Part	2360	15%
1281	2H.011.02.0.00	HUB: FUEL PUMP GEAR	Spare Part	1597	15%
1282	2H.013.01.0.00	DELIVERY BODY	Spare Part	646	15%
1283	2H.013.10.0.00	DELIVERY BODY	Spare Part	1068	15%
1284	2H.013.11.0.00	JOINT: DELIVERY BODY	Spare Part	31	15%
1285	2H.014.01.0.00	DELIVERY TUBE	Spare Part	514	15%
1286	2H.014.02.0.00	O RING: DELIVERY TUBE	Spare Part	49	15%
1287	2H.017.10.0.00	FUEL PUMP COVER WITH JOINT	Spare Part	1246	15%
1288	2H.017.11.0.00	JOINT FOR COVER FOR FUEL PUMP GEAR	Spare Part	138	15%
1289	2H.018.01.0.00	COVER FOR HYDRAULIC PUMP GEAR	Spare Part	643	15%
1290	2H.018.11.0.00	JOINT: HYDRAULIC PUMP COVER	Spare Part	77	15%
1291	2H.022.06.0.00	OIL METERING ORIFICE	Spare Part	18	15%
1292	2H.023.01.0.00	INJECTOR YOKE	Spare Part	170	20%
1293	2H.023.10.0.00	INJECTOR	Spare Part	7858	15%
1294	2H.023.91.0.00	NOZZLE	Spare Part	4375	15%
1295	2H.028.03.0.00	CLIP FOR BREATHER PIPE	Spare Part	71	15%
1296	2H.032.11.0.00	JOINT: AIR INLET MANIFOLD	Spare Part	46	15%
1297	2H.034.01.0.00	CRANK PULLEY	Spare Part	3800	15%
1298	2H.035.02.0.00	PRECOATED DRAIN PLUG	Spare Part	406	15%
1299	2H.035.10.0.00	DRAIN PLUG ASSEMBLY	Spare Part	418	15%
1300	2H.036.01.0.00	GEAR CASING SUITABLE FOR P T O FINISH	Spare Part	15061	15%
1301	2H.036.02.0.00	GEAR CASING	Spare Part	15874	15%
1301	2H.037.04.0.00	FRONT COVER	Spare Part	8588	15%
	+				
1303	2H.037.06.0.00	TIMING POINTER	Spare Part	1711	15%
1304	2H.037.11.0.00	JOINT: FRONT COVER	Spare Part	1711	15%
1305	2H.038.02.0.00	THRUST WASHER	Spare Part	634	15%
1306	2H.038.10.0.00	ASSLY INTERMEDIATE GEAR & BUSH	Spare Part	7123	15%
1307	2H.039.10.0.00	PLATE WITH RUBBER MOULDING: OIL SEAL HOUSING	Spare Part	1892	15%
1308	2H.048.11.0.00	INLINE FIP: 2R1050 G1	Spare Part	43935	15%
1309	2H.059.12.0.00	HOSE: FUEL FILLING HOSE 10 & 15 KVA GENSET	Spare Part	566	15%
1310	2H.064.03.0.00	WORM DRIVE HOSE CLIP (20-25 MM)	Spare Part	289	15%
1311	2H.065.01.0.00	HOSE THERMOSTAT TO RADIATOR	Spare Part	960	15%
1312	2H.065.02.0.00	PIPE RADIATOR TO PUMP INLET	Spare Part	729	15%
1313	2H.065.03.0.00	HOSE: WATER PUMP INLET TO RADIATOR OUTLET	Spare Part	1040	15%
1314	2H.065.06.0.00	HOSE: THERMOSTAT TO RADIATOR	Spare Part	858	15%
1315	2H.065.07.0.00	HOSE: RADIATOR OUTLET TO PUMP INLET	Spare Part	1209	15%
1316	2H.071.30.0.00	SUCTION TUBE ASSEMBLY	Spare Part	329	15%
1317	2H.088.03.0.00	LEAK OFF PIPE	Spare Part	1175	15%
1318	2H.088.03.0.PR	LEAK OFF PIPE	Spare Part	1175	15%
1319	2H.088.10.0.00	LEAK OFF PIPE ASSLY	Spare Part	806	15%
1320	2H.088.20.0.00	COMBINED LEAK OFF PIPE: M12 UNION	Spare Part	1717	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		·		without Vat in NPR	Charge%
1321	2H.092.11.0.00	LUBE OIL PRESSURE SENDOR	Spare Part	5212	15%
1322	2H.094.01.0.00	AIR INLET MANIFOLD	Spare Part	3366	15%
1323	2H.094.02.0.00	INLET MANIFOLD	Spare Part	3381	15%
1324	2H.1025.10.0.00	R-121 AVR	Spare Part	20095	15%
1325	2H.107.02.0.00	JOINT: ROCKER	Spare Part	329	15%
1326	2H.107.04.0.00	JOINT FOR ROCKER COVER	Spare Part	1083	15%
1327	2H.107.10.0.00	ROCKER COVER	Spare Part	4332	15%
1328	2H.112.01.0.00	SPRING BAND CLIP	Spare Part	182	15%
1329	2H.112.02.0.00	WORM DRIVE CLAMP (29 TO 45 DIA)	Spare Part	188	15%
1330	2H.112.07.0.00	HOSE CLAMP 12 TO 18 MM JUPITER	Spare Part	142	15%
1331	2H.116.01.0.00	FUEL PIPE: FEED PUMP TO FUEL FILTER	Spare Part	923	15%
1332	2H.116.02.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	751	15%
1333	2H.116.12.0.00	FUEL INLET PIPE M14X15 BANJO M16X15 UNION NUT	Spare Part	1108	15%
1334	2H.116.14.0.PR	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	1228	15%
1335	2H.116.21.0.00	FUEL INLET PIPE M14X1 5 BANJO	Spare Part	1040	15%
1336	2H.116.22.0.00	FUEL PIPE RETURN WITH M14 MALE PLUG M14X1 5 BANJO	Spare Part	926	15%
1337	2H.116.26.0.PR	FUEL PIPE RETURN WITH M12 MALE PLUG M14X1 5 BANJO	Spare Part	1065	15%
1338	2H.122.01.0.00	ANTI VIBRATION MOUNTS	Spare Part	1948	15%
1339	2H.122.03.0.00	ANTI VIBRATION MOUNTS	Spare Part	2382	15%
1340	2H.124.03.0.00	CRANKCASE FOOT (GEAR END, FUEL PUMP SIDE)	Spare Part	1068	15%
1341	2H.124.04.0.00	CRANKCASE FOOT (GEAR END, STARTER SIDE)	Spare Part	1215	15%
1342	2H.124.05.0.00	SUPPORT FOR MOUNTING FOOT	Spare Part	1129	15%
1343	2H.127.41.0.00	BRACKET FOR FUEL FILTER	Spare Part	2225	15%
1344	2H.131.27.0.00	72V DC COIL FOR SOLENOID DRAIN VALVE	Spare Part	98260	15%
1345	2H.135.02.0.00	EXPANSION BELLOW: EXH M'FOLD	Spare Part	6603	15%
1346	2H.135.03.0.00	EXPANSION BELLOW: TWO PLY	Spare Part	6877	15%
1347	2H.139.05.0.00	RADIATOR BALANCE WATER TANK	Spare Part	1948	15%
1348	2H.139.07.0.00	RADIATOR FAN: 15" DIA PUSHER	Spare Part	2160	15%
1349	2H.139.65.0.00	RADIATOR FAN 17"	Spare Part	28350	15%
1350	2H.139.70.0.PR	Copper Radiator Assembly	Spare Part	100300	15%
1351	2H.139.75.0.00	Aluminium Radiator Assembly	Spare Part	24200	15%
1352	2H.148.01.0.00	CANOPY DOOR BIDDING 18mm DIA BULB FOR CPCB PROJECT 1 no 1 mtr	Spare Part	329	15%
1353	2H.148.11.0.PR	CANOPY DOOR SWITCH MAKE SHREE SURAJ 2A 250V PUSH TO OFF	Spare Part	114	15%
1354	2H.154.01.0.00	SILENCER	Spare Part	14637	15%
1355	2H.154.02.0.00	FLANGE (AT SILENCER INLET & OUTLET) FOR 2R1040,3R1040 SILENT SET	Spare Part	1175	15%
		SILENCER FLANGE VAVE	Spare Part	797	15%
1356 1357	2H.154.04.0.00 2H.161.20.0.00	Silencer Assembly	•	15157	15%
1358	2H.164.01.0.00	BREATHER PIPE	Spare Part	988	15%
		FUEL TANK UNIT S F 219 EFFECTIVE TANK HEIGHT	Spare Part	4785	15%
1359	2H.1649.31.0.PR		Spare Part		
1360	2H.174.10.0.00	SILENCER FUEL TANK UNIT	Spare Part Spare Part	13831 5151	15% 15%
	2H.177.19.0.PR		•		15%
1362	2H.188.10.0.00 2H.201.10.0.00	SILENCER FEED PUMP (MICO NO. 9 440 030 029)	Spare Part Spare Part	15480 13326	15%
1363					
1364	2H.205.10.0.00	FLYWHEEL ASSEMBLY RATTERY CHARGER DC TO DC CONVERTED I B SURDLY, 60 TO 90 VDC, O B VOLTAGE 12 VDC B	Spare Part	52464	15%
1365	2H.226.26.0.00	BATTERY CHARGER DC TO DC CONVERTER I P SUPPLY 60 TO 90 VDC O P VOLTAGE 12 VDC F	Spare Part	13960	15% 15%
1366	2H.226.28.0.00	DC CT I P 0 150AMP O P 0 5 VDC CONTROL VOLATGE5VDC 24MM ID MAKE HORIZON ELEC	Spare Part	23027	15%
1367	2H.226.32.0.00	POWER RELAY, 1 C/O, 2 CH, 12V DC, 70A	Spare Part	1640	
1368	2H.226.33.0.00	RELAY 2 C O 2CH 12VDC 5A MAKE UL EQUIVALENT	Spare Part	2855	15%
1369	2H.228.02.0.00	BATTERY CLAMPING STUD (M8)	Spare Part	142	15%
	2H.241.60.0.00	CONNECTOR ASSLY: CONTROL PANEL WITH KG934	Spare Part	563	15%
	2H.241.70.0.00	CONNECTOR ASSEMBLY FOR CONTROL PANEL WITH KG645 UNIT	Spare Part	1511	15%
	2H.268.20.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	8834	15%
1373	2H.268.50.0.PR	ENGINE WIRING HARNESS FOR 2R1040 ENGINE	Spare Part	5532	15%
1374	2H.268.70.0.PR	ENGINE WIRING HARNESS FOR 2R 20KVA EMERALD	Spare Part	10738	15%
1375	2H.269.50.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	12791	15%



Sr.No. Part Number Part Description Category without Val in NPI 1376 2H.269.60.00 ENGINE WIRING HARNESS ASSEMBLY Spare Part 1345.2 1377 2H.269.70.00 ENGINE WIRING HARNESS WITH GEMS SENSOR Spare Part 1037.2 1378 2H.277.03.0.00 RUBBER HOSE: AIR CLEANER Spare Part 866. 1379 2H.277.05.0.00 PRIMARY AIR CLEANER ELEMENT Filter 190. 1380 2H.277.06.0.00 VACUUATOR VALVE FOR AIR CLEANER Spare Part 154. 1381 2H.277.09.0.00 SAFETY ELEMENT FOR AIR CLEANER (DONALDSON NO P755809) Filter 164. 1382 2H.277.19.0.00 PVC PIPE FOR AIR CLEANER Spare Part 178. 1383 2H.277.20.0.00 AIR CLEANER ASSLY+ STRAINER Spare Part 95. 1384 2H.277.21.0.00 HOSE FOR PVC PIPE Spare Part 95. 1385 2H.277.20.000 HOSE FOR PVC PIPE Spare Part 87. 1386 2H.277.20.000 HOSE FOR PVC PIPE Spare Part 25. 1386 2H.277.2					Price to	
1370	Sr.No.	Part Number	Part Description	Category	Customer	Custom
1377 21-280 00.00 ENGNE WIRRIN HANDESS ASSEMBLY Spare Part 1377 21-280 00.00 ENGNE WIRRIN HANDESS SHOTE CAND SENSOR Spare Part 1377 21-287 00.00 ENGNE WIRRIN HANDESS SHOTE CAND SENSOR Spare Part 1378 21-277 00.00 PART 10-277 21-287 21-277 00.00 PART 10-277 21-277 2			·			Charge%
1979 1277.08.000 RUBBER HOSE, AIR CLEANER Spies Part 1970 1977.08.000 PRIMARY AIR CLEANER ELEMENT Filts 1970 1970 1977.08.000 VACULATOR VAIV ET GAR ACLEANER Spies Part 1970 1977.08.000 VAPOULATOR VAIV ET GAR ACLEANER Spies Part 1970 1978 1977.08.000 VAPOULATOR VAIV ET GAR ACLEANER Spies Part 1978 1978 1977.08.000 PVP DEFE CREAT RICHARDER (DONALDSON NO P759500) Filter 1974 197	1376	2H.269.60.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	13452	15%
1977			ENGINE WIRING HARNESS WITH GEMS SENSOR		10375	15%
1977 1977 1970	1378	2H.277.03.0.00	RUBBER HOSE: AIR CLEANER		868	15%
1930 24:277.08.00 VACUUATOR VALVE FOR AIR CLEANER Spare Part 154					1903	20%
1391 24 277.09.00 SAFETY ELEMENT FOR AIR CLEANER (DONALDSON NO P75899) Filled 1481 1481 1482 14277.19.00 PVC PIPE FOR AIR CLEANER Spare Part 1783 24 277.79.00 AIR CLEANER ASSE, VS TRAINER Spare Part 1573 1583 24 277.20.00 HOSE FOR IVO PIPE Spare Part 1573 1586 24 277.20.00 HOSE FOR IVO PIPE Spare Part 1573 1586 24 277.20.00 HOSE FOR IVO PIPE Spare Part 1573 1586 24 277.20.00 HOSE FOR IVO PIPE Spare Part 1573 1586 24 277.40.00 ASSEMBLY OF AIR CLEANER (AIR CLEANER + STRAP + RAIN CAP) Spare Part 1573 1597 24 275 00.00 DRY PYE AIR CLEANER ASSLY FOR IX Spare Part 24 25 25 25 25 25 25 25 25 25 25 25 25 25				Spare Part	154	15%
1939 24:277:20.00 ARCLEANER ASSLY+STRAINER Spare Part 572	1381		SAFETY ELEMENT FOR AIR CLEANER (DONALDSON NO P755809)		1649	20%
1934 24.277.21.000	1382	2H.277.19.0.00		Spare Part	1782	15%
1385 241277.20.000	1383	2H.277.20.0.00	AIR CLEANER ASSLY+ STRAINER	Spare Part	5720	15%
1385 2H 277 20 0.00			HOSE FOR PVC PIPE	Spare Part	957	15%
1,936					877	15%
24277 90 0.00 DRY TYPE AIR CLEANER ASSLY FOR 2R Spare Part 2543 2383 241,301,02.0 PR STARTER 12VD C 27KW SUITABLE FOR 20 dog Spare Part 2543 2393 241,301,02.0 PR STARTER 12V 27KW SUITABLE FOR 20 dog Spare Part 2543 243,301,00.0 4 POLE 40 AMP MCB Spare Part 2543 243,301,00.0 4 POLE 40 AMP MCB Spare Part 947. 243,301,00.0 4 POLE 40 AMP MCB Spare Part 947. 243,301,00.0 4 POLE 40 AMP MCB Spare Part 947. 243,301,00.0 4 POLE 40 AMP MCB Spare Part 947. 243,301,00.0 AVAIT VIERATION MOUNTS Spare Part 2544 243,302,00.0 ANTI VIERATION MOUNTS Spare Part 2544 243,302,00.0 ANTI VIERATION MOUNTS Spare Part 2544 243,302,00.0 ANTI VIERATION MOUNTS Spare Part 2574 257			ASSEMBLY OF AIR CLEANER (AIR CLEANER + STRAP + RAIN CAP)		6471	15%
1388					2932	20%
1389						15%
1390						15%
1391						15%
1392					255	15%
1938						15%
1394						15%
1395						15%
1396						15%
1397 2H.345.36.0 PR					34	15%
1398						15%
1399 2H.471.40.000 AMF CONTROL PANEL FOR 14KW DG SET RELIANCE JID Spare Part 157901				· · · · · · · · · · · · · · · · · · ·		15%
1400 2H.471.86.0.00 COIL. 220V AC, 50HZ, CONTACTOR 4 POLE, TYPE : TYPE-LC1E80004M5WB) Spare Part 906- 1401 2H.472.30.0.PR Conversion Kit K6934 to K6645 w.o. controller For DC Interface card Spare Part 6260- 1402 2H.472.40.0.PR Conversion Kit K6934 to K6645 w.o. controller For DC Interface card old type Spare Part 6260- 1403 2H.481.40.0.PR CANOPY WIRING HARNESS FOR 2R1040 GENSET Spare Part 2900- 1404 2H.542.06.0.00 HOSE: AIR CLEANER Spare Part 1414- 1405 2H.545.01.0.00 EXPANSION BELLOW Z70MM Spare Part 6481- 1406 2H.764.80.0.PR CONTROL PANEL SCHEMATIC 20KVA FOR 2R 3PH WITH K6640 IP B Spare Part 6725- 1407 2H.811.05.0.00 VARISTOR FOR KGS 160 AND KGS180 ALT. FRAME Spare Part 6725- 1408 2H.813.0.00 KIRLOSKAR GREEN AVR (MODEL : TAVR-10/TAVR-20/TAVR-14 Spare Part 6725- 1409 2H.811.35.0.00 KIRLOSKAR GREEN AVR (MODEL : TAVR-10/TAVR-20/TAVR-14 Spare Part 2032- 2H.811.35.0.00 KOEL GREEN AVR: SUITABLE TO EXTERNAL ADJUST POTENTIOMETER Spare Part 1494- 1411 2H.811.36.0.00 EXCITOR ROTTA RSSEMBLY WITH FORWARD AND REVERSE DIODE Spare Part 1494- 1411 2H.811.36.0.00 EXCITOR ROTTOR ASSEMBLY (16A105)SFKG164E, KG164F, KG164G, KG184D Spare Part 1964- 1412 2H.811.39.0.00 EXCITOR STATOR ASSEMBLY (16A105)SFKG164E, KG164F, KG164G, KG184D, KG184B, KG184C, KG184D Spare Part 1964- 1411 2H.811.30.000 EXCITOR STATOR ASSEMBLY (16A106)SFKG164E, KG164G, KG164G, KG164B, KG164B, KG184B,			·			15%
1401 2H.472.30.0.PR						15%
1402 2H.472.40.0.PR						15%
1403						15%
1404						15%
1405 2H.545.01.0.00 EXPANSION BELLOW 270MM Spare Part 6488 1406 2H.764.80.0.PR CONTROL PANEL SCHEMATIC 20KVA FOR 2R 3PH WITH KG640 IP B Spare Part 97254 1407 2H.811.05.0.00 VARISTOR FOR KGS 160 AND KGS180 ALT. FRAME Spare Part 618 1408 2H.811.32.0.00 KIRLOSKAR GREEN AVR (MODEL : TAVR-10/TAVR-20/TAVR-14 Spare Part 2032; Spare Part 2032; Spare Part 20455 1409 2H.811.33.0.00 KOEL GREEN AVR: SUITABLE TO EXTERNAL ADJUST POTENTIOMETER Spare Part 20455 1410 2H.811.35.0.00 ROTATING RECTIFIER ASSEMBLY WITH FORWARD AND REVERSE DIODE Spare Part 14944 1411 2H.811.36.0.00 EXCITOR ROTOR ASSEMBLY (16A105) S/F KG164E, KG164F, KG164G Spare Part 19645 1412 2H.811.37.0.00 EXCITOR ROTOR ASSEMBLY (16S105) S/F KG164E, KG164F, KG164G Spare Part 19645 1413 2H.811.38.0.00 EXCITOR STATOR ASSEMBLY (16S106) S/F KG164E, KG164F, KG164G Spare Part 3183; Spare Part 24815 1414 2H.811.39.0.00 EXCITOR STATOR ASSEMBLY (16S106) S/F KG164E, KG164F, KG164J, KG184B, KG184B, KG184C, KG184D Spare Part 28157 1415 2H.811.42.0.00 TERMINAL BLOCK (16A110) S/F KG.164E, KG164G, KG164H, KG164J, KG184A, KG184B, KG18						15%
1406 2H.764.80.0.PR CONTROL PANEL SCHEMATIC 20KVA FOR 2R 3PH WITH KG640 IP B Spare Part 9725-1407 2H.811.05.0.00 VARISTOR FOR KGS 160 AND KGS180 ALT. FRAME Spare Part 612-1408 2H.811.32.0.00 KIRLOSKAR GREEN AVR (MODEL: TAVR-10/TAVR-20/TAVR-14 Spare Part 2032-1409 2H.811.33.0.00 KOEL GREEN AVR. SUITABLE TO EXTERNAL ADJUST POTENTIOMETER Spare Part 2015-1410 2H.811.35.0.00 ROTATING RECTIFIER ASSEMBLY WITH FORWARD AND REVERSE DIDDE Spare Part 1872-1411 2H.811.36.0.00 EXCITOR ROTOR ASSEMBLY (HGA105) S/F KG164E, KG164F, KG164G Spare Part 1872-1411 2H.811.37.0.00 EXCITOR ROTOR ASSEMBLY (168105)S/F KG164E, KG164F, KG164G Spare Part 1872-1412 2H.811.37.0.00 EXCITOR ROTOR ASSEMBLY (168105)S/F KG164E, KG164F, KG164G Spare Part 19645 1413 2H.811.38.0.00 EXCITOR STATOR ASSEMBLY (168106)S/F KG164E, KG164F, KG164G Spare Part 2815-1415 2H.811.39.0.00 EXCITOR STATOR ASSEMBLY (168106)S/F KG164E, KG164F, KG164G, KG184B, KG184C, KG184D Spare Part 2815-1415 2H.811.42.0.00 TERMINAL BLOCK (168110)S/F KG.164E, KG164F, KG164J, KG184J, KG184J, KG184B, KG18						15%
1407 2H.811.05.0.00						15%
1408 2H.811.32.0.00 KIRLOSKAR GREEN AVR (MODEL: TAVR-10/TAVR-20/TAVR-14 Spare Part 2032: 1409 2H.811.33.0.00 KOEL GREEN AVR: SUITABLE TO EXTERNAL ADJUST POTENTIOMETER Spare Part 2015: 1410 2H.811.35.0.00 ROTATING RECTIFIER ASSEMBLY WITH FORWARD AND REVERSE DIODE Spare Part 1494: 1411 2H.811.35.0.00 EXCITOR ROTOR ASSEMBLY (16A105) SIF KG164E, KG164F, KG164G Spare Part 1872 1412 2H.811.37.0.00 EXCITOR ROTOR ASSEMBLY (16S105) SIF KG164E, KG164F, KG164G, KG184B, KG184B, KG184C, KG184D Spare Part 1964s 1413 2H.811.38.0.00 EXCITOR STATOR ASSEMBLY (16S106) SIF KG164E, KG164F, KG164F, KG164G, KG184B, KG184B, KG184C, KG184D Spare Part 31833 1415 2H.811.39.0.00 EXCITOR STATOR ASSEMBLY (16S106) SIF KG164B, KG164B, KG164B, KG164B, KG184B, KG184B, KG184B, KG184B Spare Part 2815 1416 2H.811.42.0.00 TERMINAL BLOCK (16A110)SIF KG.164E, KG164F, KG164G, KG164H, KG164J, KG184B, KG184B, KG184B Spare Part 1107 1417 2H.817.14.0.PR KOEL GREEN Alternator KG 20 S T Frame L KG 40 H SAE 2 11 5 415V 50 Hz 0 8 PF Spare Part 18030 1418 2H.818.14.0.PR KOEL GREEN Alter						15%
1409 2H.811.33.0.00 KOEL GREEN AVR: SUITABLE TO EXTERNAL ADJUST POTENTIOMETER Spare Part 2015; 1410 2H.811.35.0.00 ROTATING RECTIFIER ASSEMBLY WITH FORWARD AND REVERSE DIODE Spare Part 1494* 1411 2H.811.36.0.00 EXCITOR ROTOR ASSEMBLY(16A105) S/F KG164E,KG164F,KG164G Spare Part 1872(1412 2H.811.37.0.00 EXCITOR ROTOR ASSEMBLY(16S105)S/FKG164H,KG164J,KG184B,KG184C,KG184D Spare Part 1964* 1412 2H.811.38.0.00 EXCITOR STATOR ASSEMBLY(16A106)S/FKG164E,KG164F,KG164G Spare Part 3183; 2H.811.39.0.00 EXCITOR STATOR ASSEMBLY(16S106)S/FKG164H,KG164J,KG184B,KG184C,KG184D Spare Part 21815; 2H.811.42.0.00 TERMINAL BLOCK(16A110)S/F KG.164E,KG164F,KG164J,KG184B,KG184C,KG184B,KG184B,KG184B,KG184D Spare Part 21815; 2H.811.42.0.00 TERMINAL BLOCK(16A110)S/F KG.164E,KG164F,KG164J,KG184B,KG184B,KG184B,KG184B,KG184B,KG184D Spare Part 21815; 2H.811.43.0.00 FAN WITH KEY FOR 164 FRAME (16A108) Spare Part 1107; 2H.817.14.0.PR KOEL GREEN Alternator KG 20 S T Frame L KG 40 H SAE 2 11 5 415V 50 Hz 0 8 PF Spare Part 180300 2H.818.150.00 D120 AVR Spare Part 31856 2H.818.150.00 D120 AVR Spare Part 31856 2H.818.150.00 D120 AVR Spare Part 37844 2H.818.150.00 D120 AVR Spare Part 37844 2H.818.150.00 FORGRAMMING KIT Spare Part 37845 2H.864.120.00 FORGRAMMING KIT Spare Part 37845 2H.864.120.00 FORGRAMMING KIT Spare Part 8565 2H.865.520.00 CONTROL RELAY 12VDC 3CHANEL 2V DC RED COLOUR TYPE 3PLBR3L Spare Part 8565 2H.865.520.00 CONTROL RELAY 12VDC 3CHANEL Spare Part 8856 2H.865.520.00 CANOPY TEMPERATURE SWITCH 2 - 85 deg C Spare Part 37645 2H.868.020.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 37645 2H.868.020.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 37645 2H.866.520.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 37645 2H.8						15%
1410 2H.811.35.0.00 ROTATING RECTIFIER ASSEMBLY WITH FORWARD AND REVERSE DIODE Spare Part 1494* 1411 2H.811.36.0.00 EXCITOR ROTOR ASSEMBLY (16A105) S/F KG164E, KG164F, KG164G Spare Part 1872(1412) 2H.811.37.0.00 EXCITOR ROTOR ASSEMBLY (16S105) S/F KG164E, KG164F, KG164G Spare Part 19648 1412 2H.811.38.0.00 EXCITOR STATOR ASSEMBLY (16S106) S/F KG164E, KG164F, KG164G Spare Part 3183 1414 2H.811.39.0.00 EXCITOR STATOR ASSEMBLY (16S106) S/F KG164E, KG164F, KG164J, KG184B, KG184C, KG184D. Spare Part 2815 1415 2H.811.42.0.00 TERMINAL BLOCK (16A110) S/F KG.164E, KG164F, KG164J, KG184B, KG184A, KG184B, KG184C Spare Part 2185 1416 2H.811.43.0.00 FAN WITH KEY FOR 164 FRAME (16A108) Spare Part 1107* 1417 2H.811.41.0.PR KOEL GREEN Alternator KG 20 S T Frame L KG 40 H SAE 2 11 5 415V 50 Hz 0 8 PF Spare Part 180300 1418 2H.818.15.0.00 D120 AVR KOEL GREEN Alternator, KG 20 S S Frame: L KG 42.3 C, SAE-2 11.5", 230V, 50 Hz, 0.8 PF Spare Part 31856 1420 2H.818.35.0.00 AVR (MODEL- TAVR27) Spare Part 31856 1421						15%
1411 2H.811.36.0.00 EXCITOR ROTOR ASSEMBLY(16A105) S/F KG164E,KG164G Spare Part 18720 1412 2H.811.37.0.00 EXCITOR ROTOR ASSEMBLY(16S105)S/F KG164H,KG164J,KG184B,KG184C,KG184D Spare Part 19648 1413 2H.811.38.0.00 EXCITOR STATOR ASSEMBLY(16S106)S/F KG164E,KG164F,KG164G Spare Part 31833 1414 2H.811.39.0.00 EXCITOR STATOR ASSEMBLY(16S106)S/F KG164H,KG164J,KG184B,KG184C,KG184D. Spare Part 28157 1415 2H.811.42.0.00 TERMINAL BLOCK(16A110)S/F KG.164E,KG164F,KG164G,KG164H,KG164J,KG184B,KG184C,KG184B Spare Part 21857 1416 2H.811.43.0.00 FAN WITH KEY FOR 164 FRAME (16A108) Spare Part 11077 1417 2H.817.40.PR KOEL GREEN Alternator KG 20 S T Frame L KG 40 H SAE 2 11 5 415V 50 Hz 0 8 PF Spare Part 18030 1418 2H.818.15.0.00 D120 AVR KOEL GREEN Alternator, KG 20 S S Frame: L KG 42.3 C, SAE-2 11.5", 230V, 50 Hz, 0.8 PF Spare Part 23280 1420 2H.818.35.0.00 AVR (MODEL- TAVR27) Spare Part 3155 1421 2H.836.31.12.0.00 PROGRAMMING KIT Spare Part 851 1422 2H.8				· ·		15%
1412 2H.811.37.0.00 EXCITOR ROTOR ASSEMBLY(16S105)S/FKG164H,KG164J,KG184B,KG184C,KG184D Spare Part 19648 1413 2H.811.38.0.00 EXCITOR STATOR ASSEMBLY(16A106)S/FKG164E,KG164F,KG164G Spare Part 31833 1414 2H.811.39.0.00 EXCITOR STATOR ASSEMBLY(16S106)S/FKG164H,KG164J,KG184B,KG184C,KG184D. Spare Part 2815 1415 2H.811.42.0.00 TERMINAL BLOCK(16A110)S/F KG.164E,KG164F,KG164G,KG164H,KG164J,KG184B,KG184C Spare Part 218 1416 2H.811.43.0.00 FAN WITH KEY FOR 164 FRAME (16A108) Spare Part 1107 1417 2H.811.43.0.00 FAN WITH KEY FOR 164 FRAME (16A108) Spare Part 1107 1417 2H.818.14.0.PR KOEL GREEN Alternator KG 20 S T Frame L KG 40 H SAE 2 11 5 415V 50 Hz 0 8 PF Spare Part 180300 1418 2H.818.15.0.00 D120 AVR KOEL GREEN Alternator, KG 20 S S Frame: L KG 42.3 C, SAE-2 11.5", 230V, 50 Hz, 0.8 PF Spare Part 232800 1420 2H.818.35.0.00 AVR (MODEL- TAVR27) Spare Part 31850 1421 2H.831.12.0.00 PROGRAMMING KIT Spare Part 63150 1422 2H.850.14.0.00						15%
1413 2H.811.38.0.00 EXCITOR STATOR ASSEMBLY(16A106)S/FKG164E,KG164F,KG164G Spare Part 31833 1414 2H.811.39.0.00 EXCITOR STATOR ASSEMBLY(16S106)S/FKG164H,KG164J,KG184B,KG184C,KG184D. Spare Part 2815 1415 2H.811.42.0.00 TERMINAL BLOCK(16A110)S/F KG.164E,KG164F,KG164G,KG164H,KG164J,KG184B,KG184B Spare Part 2184 1416 2H.811.43.0.00 FAN WITH KEY FOR 164 FRAME (16A108) Spare Part 1107 1417 2H.811.43.0.00 FAN WITH KEY FOR 164 FRAME (16A108) Spare Part 1107 1417 2H.811.43.0.0P KOEL GREEN Alternator KG 20 S T Frame L KG 40 H SAE 2 11 5 415V 50 Hz 0 8 PF Spare Part 180308 1418 2H.818.15.0.0D D120 AVR KOEL GREEN Alternator, KG 20 S S Frame: L KG 42.3 C, SAE-2 11.5", 230V, 50 Hz, 0.8 PF Spare Part 232800 1420 2H.818.15.0.00 D120 AVR Spare Part 31850 1421 2H.818.35.0.00 AVR (MODEL- TAVR27) Spare Part 63150 1422 2H.850.14.0.00 FORGRAMMING KIT Spare Part 1920 1423 2H.864.12.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC GREEN COLOUR TYPE 3PLBR3L Spare Part 850 1424						15%
1414 2H.811.39.0.00 EXCITOR STATOR ASSEMBLY(16S106)S/FKG164H,KG164J,KG184B,KG184C,KG184D. Spare Part 2815. 1415 2H.811.42.0.00 TERMINAL BLOCK(16A110)S/F KG.164E,KG164F,KG164G,KG164H,KG164J,KG184B,KG184B Spare Part 218. 1416 2H.811.43.0.00 FAN WITH KEY FOR 164 FRAME (16A108) Spare Part 1107. 1417 2H.817.14.0.PR KOEL GREEN Alternator KG 20 S T Frame L KG 40 H SAE 2 11 5 415V 50 Hz 0 8 PF Spare Part 180304 1418 2H.818.15.0.00 KOEL GREEN Alternator, KG 20 S S Frame: L KG 42.3 C, SAE-2 11.5", 230V, 50 Hz, 0.8 PF Spare Part 232804 1419 2H.818.15.0.00 D120 AVR Spare Part 31856 1420 2H.818.35.0.00 AVR (MODEL- TAVR27) Spare Part 63156 1421 2H.831.12.0.00 PROGRAMMING KIT Spare Part 63156 1422 2H.850.14.0.00 FUEL LEVEL SENSOR 110MM HEIGHT(PRICOL C20 5289) Spare Part 1920 1423 2H.864.12.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC GREEN COLOUR TYPE 3PLBR3L Spare Part 850 1424 2H.865.52.0.00 CONTROL RELAY 12VDC 3CHANEL Spare Part						15%
1415 2H.811.42.0.00 TERMINAL BLOCK(16A110)S/F KG.164E,KG164F,KG164F,KG164J,KG184A,KG184B,KG184F Spare Part 2188 1416 2H.811.43.0.00 FAN WITH KEY FOR 164 FRAME (16A108) Spare Part 1107 1417 2H.817.14.0.PR KOEL GREEN Alternator KG 20 S T Frame L KG 40 H SAE 2 11 5 415V 50 Hz 0 8 PF Spare Part 180308 1418 2H.818.14.0.PR KOEL GREEN Alternator, KG 20 S S Frame: L KG 42.3 C, SAE-2 11.5", 230V, 50 Hz, 0.8 PF Spare Part 232800 1419 2H.818.15.0.00 D120 AVR Spare Part 31856 1420 2H.818.35.0.00 AVR (MODEL- TAVR27) Spare Part 63156 1421 2H.831.12.0.00 PROGRAMMING KIT Spare Part 63156 1422 2H.850.14.0.00 FUEL LEVEL SENSOR 110MM HEIGHT(PRICOL C20 5289) Spare Part 1920 1423 2H.864.12.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC GREEN COLOUR TYPE 3PLBR3L Spare Part 850 1424 2H.865.52.0.00 CONTROL RELAY 12VDC 3CHANEL Spare Part 840 1426 2H.865.56.0.00 CANOPY TEMPERATURE SWITCH 2 - 85 deg C Spare Part Spare						15%
1416 2H.811.43.0.00 FAN WITH KEY FOR 164 FRAME (16A108) Spare Part 1107 1417 2H.817.14.0.PR KOEL GREEN Alternator KG 20 S T Frame L KG 40 H SAE 2 11 5 415V 50 Hz 0 8 PF Spare Part 180300 1418 2H.818.14.0.PR KOEL GREEN Alternator, KG 20 S S Frame: L KG 42.3 C, SAE-2 11.5", 230V, 50 Hz, 0.8 PF Spare Part 232800 1419 2H.818.15.0.00 D120 AVR Spare Part 31850 1420 2H.818.35.0.00 AVR (MODEL- TAVR27) Spare Part 37845 1421 2H.831.12.0.00 PROGRAMMING KIT Spare Part 63150 1422 2H.850.14.0.00 FUEL LEVEL SENSOR 110MM HEIGHT(PRICOL C20 5289) Spare Part 1920 1423 2H.864.12.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC GREEN COLOUR TYPE 3PLBR3L Spare Part 850 1424 2H.864.13.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC RED COLOUR TYPE 3PLBR4L Spare Part 840 1425 2H.865.52.0.00 CONTROL RELAY 12VDC 3CHANEL Spare Part 885 1426 2H.865.56.0.00 CANOPY TEMPERATURE SWITCH 2 - 85 deg C Spare Part Spare Part 1427 2H.868.02.0.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WIT				· ·		
1417 2H.817.14.0.PR KOEL GREEN Alternator KG 20 S T Frame L KG 40 H SAE 2 11 5 415V 50 Hz 0 8 PF Spare Part 180300 1418 2H.818.14.0.PR KOEL GREEN Alternator, KG 20 S S Frame: L KG 42.3 C, SAE-2 11.5", 230V, 50 Hz, 0.8 PF Spare Part 232800 1419 2H.818.15.0.00 D120 AVR Spare Part 31850 1420 2H.818.35.0.00 AVR (MODEL- TAVR27) Spare Part 37840 1421 2H.831.12.0.00 PROGRAMMING KIT Spare Part 63150 1422 2H.850.14.0.00 FUEL LEVEL SENSOR 110MM HEIGHT(PRICOL C20 5289) Spare Part 1920 1423 2H.864.12.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC GREEN COLOUR TYPE 3PLBR3L Spare Part 850 1424 2H.864.13.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC RED COLOUR TYPE 3PLBR4L Spare Part 840 1425 2H.865.52.0.00 CONTROL RELAY 12VDC 3CHANEL Spare Part 885 1426 2H.865.56.0.00 CANOPY TEMPERATURE SWITCH 2 - 85 deg C Spare Part Spare Part 1427 2H.868.02.0.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 373						15% 15%
1418 2H.818.14.0.PR KOEL GREEN Alternator, KG 20 S S Frame: L KG 42.3 C, SAE-2 11.5", 230V, 50 Hz, 0.8 PF Spare Part 232800 1419 2H.818.15.0.00 D120 AVR Spare Part 31854 1420 2H.818.35.0.00 AVR (MODEL- TAVR27) Spare Part 37845 1421 2H.831.12.0.00 PROGRAMMING KIT Spare Part 63152 1422 2H.850.14.0.00 FUEL LEVEL SENSOR 110MM HEIGHT(PRICOL C20 5289) Spare Part 1920 1423 2H.864.12.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC GREEN COLOUR TYPE 3PLBR3L Spare Part 850 1424 2H.864.13.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC RED COLOUR TYPE 3PLBR4L Spare Part 840 1425 2H.865.52.0.00 CONTROL RELAY 12VDC 3CHANEL Spare Part 8852 1426 2H.865.56.0.00 CANOPY TEMPERATURE SWITCH 2 - 85 deg C Spare Part Spare Part 1427 2H.868.02.0.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 372			, ,			15%
1419 2H.818.15.0.00 D120 AVR Spare Part 31850 1420 2H.818.35.0.00 AVR (MODEL- TAVR27) Spare Part 37840 1421 2H.831.12.0.00 PROGRAMMING KIT Spare Part 63150 1422 2H.850.14.0.00 FUEL LEVEL SENSOR 110MM HEIGHT(PRICOL C20 5289) Spare Part 1920 1423 2H.864.12.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC GREEN COLOUR TYPE 3PLBR3L Spare Part 850 1424 2H.864.13.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC RED COLOUR TYPE 3PLBR4L Spare Part 840 1425 2H.865.52.0.00 CONTROL RELAY 12VDC 3CHANEL Spare Part 8850 1426 2H.865.56.0.00 CANOPY TEMPERATURE SWITCH 2 - 85 deg C Spare Part Spare Part 1427 2H.868.02.0.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 370						15%
1420 2H.818.35.0.00 AVR (MODEL- TAVR27) Spare Part 37844 1421 2H.831.12.0.00 PROGRAMMING KIT Spare Part 63155 1422 2H.850.14.0.00 FUEL LEVEL SENSOR 110MM HEIGHT(PRICOL C20 5289) Spare Part 1920 1423 2H.864.12.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC GREEN COLOUR TYPE 3PLBR3L Spare Part 850 1424 2H.864.13.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC RED COLOUR TYPE 3PLBR4L Spare Part 840 1425 2H.865.52.0.00 CONTROL RELAY 12VDC 3CHANEL Spare Part 8850 1426 2H.865.56.0.00 CANOPY TEMPERATURE SWITCH 2 - 85 deg C Spare Part Spare Part 1427 2H.868.02.0.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 373						
1421 2H.831.12.0.00 PROGRAMMING KIT Spare Part 6315 1422 2H.850.14.0.00 FUEL LEVEL SENSOR 110MM HEIGHT(PRICOL C20 5289) Spare Part 1920 1423 2H.864.12.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC GREEN COLOUR TYPE 3PLBR3L Spare Part 850 1424 2H.864.13.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC RED COLOUR TYPE 3PLBR4L Spare Part 840 1425 2H.865.52.0.00 CONTROL RELAY 12VDC 3CHANEL Spare Part 8850 1426 2H.865.56.0.00 CANOPY TEMPERATURE SWITCH 2 - 85 deg C Spare Part 2810 1427 2H.868.02.0.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 370						15%
1422 2H.850.14.0.00 FUEL LEVEL SENSOR 110MM HEIGHT(PRICOL C20 5289) Spare Part 1920 1423 2H.864.12.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC GREEN COLOUR TYPE 3PLBR3L Spare Part 850 1424 2H.864.13.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC RED COLOUR TYPE 3PLBR4L Spare Part 840 1425 2H.865.52.0.00 CONTROL RELAY 12VDC 3CHANEL Spare Part 8850 1426 2H.865.56.0.00 CANOPY TEMPERATURE SWITCH 2 - 85 deg C Spare Part 2812 1427 2H.868.02.0.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 373						15%
1423 2H.864.12.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC GREEN COLOUR TYPE 3PLBR3L Spare Part 850 1424 2H.864.13.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC RED COLOUR TYPE 3PLBR4L Spare Part 840 1425 2H.865.52.0.00 CONTROL RELAY 12VDC 3CHANEL Spare Part 8850 1426 2H.865.56.0.00 CANOPY TEMPERATURE SWITCH 2 - 85 deg C Spare Part 2812 1427 2H.868.02.0.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 372						15%
1424 2H.864.13.0.00 INDICATING LAMP TEKNIC MAKE 12 V DC RED COLOUR TYPE 3PLBR4L Spare Part 840 1425 2H.865.52.0.00 CONTROL RELAY 12VDC 3CHANEL Spare Part 8850 1426 2H.865.56.0.00 CANOPY TEMPERATURE SWITCH 2 - 85 deg C Spare Part 2810 1427 2H.868.02.0.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 370				-		15%
1425 2H.865.52.0.00 CONTROL RELAY 12VDC 3CHANEL Spare Part 885.7 1426 2H.865.56.0.00 CANOPY TEMPERATURE SWITCH 2 - 85 deg C Spare Part 281.7 1427 2H.868.02.0.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 37.7				· · · · · · · · · · · · · · · · · · ·		15%
1426 2H.865.56.0.00 CANOPY TEMPERATURE SWITCH 2 - 85 deg C Spare Part 2812 1427 2H.868.02.0.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 372				· ·		15%
1427 2H.868.02.0.00 EARTHING CABLE BRADED FOR GENSET 4MM DIA WITH SUITABLE LUG ALT TO BASE PLATE Spare Part 372						15%
						15%
1426 ZH. 571. US. U. U LVM PROTON MAKE 20 O 3PH W O PHASE SEQUENCE MONITORING MODEL NO PR 07 REL WI Spare Part 8060				-		15%
1400 CU 070 CO 0 PP						15%
					7286 8068	15% 15%



				Price to	
				Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
				NPR	
1431	2H.876.04.0.00	SELECTOR SWITCH 3 WAY WITH OFF, 3 POLE	Spare Part	1985	15%
1432	2H.876.05.0.00	RELAY BOARD 2CH. 2C/O 12 V DIN MOUNTED	Spare Part	2901	15%
1433	2H.881.05.0.00	1 AMP SINGLE POLE MCB ABB SCHINDER MAKE	Spare Part	2951	15%
1434	2H.881.07.0.PR	0 5 AMP SINGLE POLE MCB SCHINDER ABB MAKE	Spare Part	3031	15%
1435	2H.892.09.0.00	FUSE BLOWN INDICATOR 12 /24 VDC BLACK COLOUR R	Spare Part	345	15%
1436	2H.894.56.0.00	GENERATOR CONTROL UNIT KG984	Spare Part	39603	15%
1437	2H.910.01.0.PR	WATER TEMP SENSOR	Spare Part	1585	15%
1438	2H.956.01.0.00	GASKET (FOR L SERIES GOVERNOR MOUNTING)	Spare Part	43	15%
1439	2H.964.01.0.00	HEADER (FOR LOCOOLER & SPIN-ON-FILTER)	Spare Part	5686	15%
1440	2H.964.03.0.00	HEADER FOR LUBE OIL COOLER & SPIN ON FILTER (3 PLATES)	Spare Part	3935	15%
1441	2H.964.04.0.00	HEADER: SPIN ON FILTER WO COOLER	Spare Part	4415	15%
1442	2H.966.10.0.00	CRANKSHAFT ASSEMBLY	Spare Part	58728	15%
1443	2H.966.20.0.00	CRANKSHAFT ASSEMBLY	Spare Part	48581	15%
1444	2H.970.02.0.00	12V RELAY BOARD-70 AMP	Spare Part	4446	15%
1445	2H.974.32.0.00	AUXILLARY CONTACT BLOCK 2NO 2NC TYPE LAEN22 CS94114OOOO	Spare Part	1868	15%
1446	2H.974.42.0.PR	MCB 10A 1P C CURVE TYPE A9N1P10C BB10100C	Spare Part	397	15%
1447		CONTACTOR 100A 4P AC1 WITH 220VAC COIL TYPE LC1E80004M5WB CS97017F000		35332	15%
	2H.974.46.0.00		Spare Part		
1448	2H.974.47.0.PR	MECHNICAL INTER LOCK TYPE LAEM4 CS930950000	Spare Part	4551	15%
1449	2H.974.48.0.PR	SURGE SUPPRESSOR TYPE LAERCU CS94163B000	Spare Part	1505	15%
1450	2H.974.55.0.PR	MCCB 100A 2P 3P TYPE EZC100H2100 DU100	Spare Part	6394	15%
1451	2H.974.63.0.PR	CONTACTOR MCX13 80A 4P AC1 WITH 240VAC COIL VOLTAGE MAKE LT CATALOGUE No C	Spare Part	31261	15%
1452	2H.976.01.0.00	TERMINAL BAR- 30/40 KVA 1 PHASE, 45/75KVA 3PHASE	Spare Part	1305	15%
1453	2H.976.07.0.00	EXCITER ROTOR	Spare Part	22434	15%
1454	2H.976.08.0.00	RRA AASSEMBLY	Spare Part	26947	15%
1455	2H.976.17.0.00	WOUND EXCITER ROTOR RATING 5 TO 12 5 KVA 1PH 7 5 TO 20 KVA 3PH SEM040RO002B FR	Spare Part	21966	15%
1456	2H.976.18.0.00	WOUND EXCITER STATOR RATING 5 TO 12 5 KVA 1PH 7 5 TO 20 KVA 3PH SEM040ST001B FR	Spare Part	33313	15%
1457	2H.976.19.0.00	FAN, Rating 5 to 12.5 KVA	Spare Part	9692	15%
1458	2H.976.22.0.00	COUPLING DISK SAE 11.5" (AG318196)	Spare Part	4461	15%
1459	2H.976.23.0.00	DE FLANGE SAE 3,RATING- 5 TO 12.5 KVA 1PH,7.5 TO 20 KVA 3PH,(PMA046PU002B),FRAME -KG4	Spare Part	33292	15%
1460	2H.976.25.0.00	TERMINAL BAR RATING 5 TO 12 5 KVA 1PH 7 5 TO 20 KVA 3PH PLA092AI002B FRAME KG40	Spare Part	1289	15%
1461	2H.979.30.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	48138	15%
1462	2H.982.20.0.00	VALVE ROCKER ASSEMBLY	Spare Part	5126	15%
1463	2H.983.30.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	45218	15%
1464	2H.999.07.0.SP	100 Amp Contactor Assembly Make C S Contactor 02 Nos NO NC contacts 02 Nos Mech interLock 0	Spare Part	52624	15%
1465	2H.999.10.0.SP	SET OF JOINTS 2R1040 G1 CPCB II ENGINE	Spare Part	3963	15%
1466	30.182.01.0.00	THERMOSTAT ELEMENT 60C	Spare Part	3255	15%
1467	30.650.02.0.00	HOSE CLIP	Spare Part	151	15%
1468	30.735.06.0.00	PROTECTION CAP	Spare Part	3243	20%
1469	34.001.07.0.00	PLAIN WASHER FOR BEARING CAP	Spare Part	49	15%
1470	34.001.18.0.00	NUT: CYL HEAD STUD M14X1.5	Spare Part	65	15%
1471	34.001.19.0.00	DOME NUT	Spare Part	95	15%
1472	34.001.19.0.00	DOWEL FOR GEAR CASING	Spare Part	22	15%
1473	34.001.29.0.00	PLAIN WASHER	Spare Part	34	15%
1473	34.001.35.0.00	PRECOATED PLUG FOR OIL GALLERY	Spare Part	31	15%
1475	34.003.02.0.00	KEY FOR CRANK SHAFT	Spare Part	154	15%
1476	34.003.07.0.00	CRANK SHAFT PLUG ALUMINIUM WASHER FOR ALUPLUG	Spare Part	34	15%
1477	34.003.08.0.00		Spare Part	25	15%
1478	34.005.01.0.00	CRANKSHAFT GEAR	Spare Part	1452	15%
1479	34.005.02.0.00	CRANKSHAFT GEAR	Spare Part	1425	15%
1480	34.007.20.0.00	INTERMEDIATE GEAR	Spare Part	2283	15%
1481	34.009.02.0.00	THRUST PLATE	Spare Part	182	15%
1482	34.010.06.0.00	VALVE TAPPET	Spare Part	342	15%
1483	34.011.02.0.00	CUP FOR P R TUBE	Spare Part	37	15%
1484	34.011.05.0.00	SPRING FOR PUSH ROD TUBE	Spare Part	34	15%
1485	34.011.06.0.00	RUBBER BUSH TOP	Spare Part	169	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
1486	34.011.07.0.00	RUBBER BUSH BOTTOM	Spare Part	77	15%
1487	34.012.05.0.00	OIL SEAL	Spare Part	1889	15%
1488	34.012.12.0.00	OIL SEAL: CR SEAL	Spare Part	1582	15%
1489	34.012.13.0.00	OIL SEAL: GEAR END	Spare Part	1046	15%
1490	34.013.03.0.00	VALVE SEAT INSERT: INLET	Spare Part	363	15%
1491	34.013.04.0.00	VALVE SEAT INSERT: EXHAUST	Spare Part	342	15%
1492	34.013.05.0.00	VALVE GUIDE	Spare Part	123	15%
1493	34.013.06.0.00	STUD FOR ROCKER SUPPORT	Spare Part	83	15%
1494	34.013.07.0.00	STUD FOR ROCKER SUPPORT	Spare Part	92	15%
1495	34.013.08.0.00	VALVE GUIDE	Spare Part	148	15%
1496	34.013.13.0.00	CUP FOR VALVE SPRING	Spare Part	22	15%
1497	34.013.19.0.00	VALVE STEM SEAL	Spare Part	15	15%
1498	34.013.70.0.00	VALVE	Spare Part	806	15%
1499	34.016.12.0.00	JOINT: FUEL PUMP	Spare Part	31	15%
1500	34.016.15.0.00	BANJO BOLT WITH STRAINER	Spare Part	723	15%
1501	34.016.40.0.00	FEED PUMP W/O BOWL FILTER	Spare Part	10778	15%
1502	34.016.60.0.00	LEAK OFF PIPE	Spare Part	225	15%
1503	34.017.04.0.00	FUEL PUMP GEAR	Spare Part	2523	15%
1504	34.017.05.0.00	WASHER FOR FUEL PUMP GEAR	Spare Part	15	15%
1505	34.018.10.0.00	LUBE OIL PUMP ASSLY	Spare Part	5529	15%
1506	34.020.02.0.00	JOINT: LOPBODY	Spare Part	25	15%
1507	34.020.03.0.00	O RING : DEL BODY 2.7X17-21516	Spare Part	28	15%
1508	34.020.20.0.00	DELIVERY BODY	Spare Part	1231	15%
1509	34.021.05.0.00	JOINT: LUBE OIL FILTER ADAPTOR	Spare Part	34	15%
1510	34.021.06.0.00	JOINT FOR L.O.FILTER ADAPTOR (SSPL-SS/KO/1194)	Spare Part	68	15%
1511	34.023.06.0.00	BANJO BOLT	Spare Part	74	15%
1512	34.025.24.0.00	PISTON PIN	Spare Part	1215	15%
1513	34.026.02.0.00	DOWEL FOR CONNECTING ROD	Spare Part	132	15%
1514	34.026.03.0.00	CON ROD ASSLY	Spare Part	218	15%
1515	34.028.20.0.00	RELIEF VALVE ASSLY	Spare Part	397	15%
1516	34.030.05.0.00	BANJO BOLT : 10X1	Spare Part	283	15%
1517	34.032.01.0.00	SEALING RING: FUEL FILTER	Spare Part	55	15%
1518	34.032.02.0.00	PREFILTER ELEMENT	Filter	186	20%
1519	34.032.03.0.00	FUEL FILTER ELEMENT	Filter	161	20%
1520	34.032.12.0.00	FUEL FILTER ELEMENT	Filter	415	20%
1521	34.032.60.0.00	O F VALVE ASSLY	Spare Part	729	15%
1522	34.034.05.0.00	LEAK OFF PIPE CONNECTION	Spare Part	95	15%
1523	34.035.03.0.00	FUEL PIPE 90,14X14 B,260 WB	Spare Part	215	15%
1524	34.036.50.0.00	PERFORATED DISC	Spare Part	52	15%
1525	34.036.60.0.00	CAP ASSLY	Spare Part		15%
1526	34.040.02.0.00	JOINT: FLANGE/FUEL SPOUT	Spare Part		15%
1527	34.042.02.0.00	CLIP FOR RAIN CAP MOUNTING ON EXHAUST SILENCER	Spare Part	412	15%
1528	34.043.02.0.00	STARTER RING	Spare Part	4132	15%
1529	34.046.02.0.00	DOWEL	Spare Part	249	15%
1530	34.046.05.0.00	FLYWHEEL BOLT: M14X15X40	Spare Part	157	15%
1531	34.046.07.0.00	FLYWHEEL BOLT: M14X15X45	Spare Part	169	15%
1532	34.053.01.0.00	V BELT A56	Spare Part	874	15%
1533	34.077.05.0.00	PIN FOR STOPPING CABLE	Spare Part		15%
1534	34.084.01.0.00	DIAPHRAGM	Spare Part	5926	15%
1535	34.088.02.0.00	JOINT: ROCKER COVER	Spare Part	102	15%
1536	34.101.03.0.00	START/STOP BUTTON 12V/24V40A	Spare Part		15%
1537	34.107.06.0.00	JOINT SS: ADAPTOR ON EX M'FOLD	Spare Part	95	15%
1538	34.107.12.0.00	GASKET (FOR INLET AIR HEATER)	Spare Part	1215	15%
1539	34.151.01.0.00	FUEL PIPE 7.5 14X14 B 700 WB	Spare Part	538	15%
. 500			- Spare Fait	550	1370



				Price to	
C: N-	Don't November	Book Bookships	Catanami	Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
4544	04.454.04.0.00	FUEL DIDE 7.5 AAVAA D 700 DD	Corres Dord	NPR	450/
1541	34.151.04.0.00	FUEL PIPE 7.5 14X14 B 700 PB	Spare Part	902	15%
1542	34.151.06.0.00	CLIP FOR FLEXIBLE PIPE WITH SLEEVE	Spare Part	95	15%
1543	34.174.01.0.00	FUEL PIPE: WIRE BRAIDED	Spare Part	455	15%
1544	34.183.03.0.00	LUBE OIL TEMP GAUGE	Spare Part	3095	15%
1545	34.184.01.0.00	ADAPTOR FOR PRESSURE SWITCH	Spare Part	95	15%
1546	34.184.02.0.00	PRESSURE SWITCH 0.8 TO 1.2	Spare Part	723	15%
1547	34.188.05.0.00	PIN	Spare Part	65	15%
1548	34.242.11.0.00	JOINT: BLANKING PLATE	Spare Part	206	15%
1549	34.250.02.0.00	FLEXIBLE PIPE: LOP GAUGE	Spare Part	849	15%
1550	34.265.03.0.00	FLANGE FOR 20" FLEXIBLE EXHAUST PIPE	Spare Part	258	15%
1551	34.341.10.0.00	INTERMEDIATE GEAR	Spare Part	3237	15%
1552	34.990.01.0.00	PUSH ROD KIT	Spare Part	1412	15%
1553	34.999.02.0.00	OIL SEAL	Spare Part	794	15%
1554	34.999.15.0.00	FUEL FILTER KIT 0.5 LTR	Filter	306	20%
1555	35.008.70.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	1702	15%
1556	35.047.01.0.00	V BELT A55	Spare Part	803	15%
1557	35.107.01.0.00	FUEL PIPE 8MM ID 14X14B 2M LONG PB	Spare Part	1169	15%
1558	35.107.02.0.00	FUEL PIPE: 8.0 14X14 B 2500L PB	Spare Part	1228	15%
1559	35.107.03.0.00	EXT NOZZLE LEAK OFF: 4.4 14BX12U, 2500PP	Spare Part	2446	15%
1560	36.010.06.0.00	STARTER 12V	Spare Part	40843	15%
1561	36.011.80.0.00	High pressure pipe assembly	Spare Part	2372	15%
1562	36.040.01.0.00	FUEL PIPE 8.0 14 B 1000 WB	Spare Part	705	15%
1563	36.040.03.0.PR	FUEL PIPE	Spare Part	742	15%
1564	38.002.03.0.00	JOINT RING: LINER	Spare Part	34	15%
1565	38.002.06.0.00	JOINT: CYL LINER TO BLOCK	Spare Part	135	15%
1566	38.002.13.0.00	JOINT: LINER TO HEAD	Spare Part	138	15%
1567	38.002.15.0.00	TUBE	Spare Part	62	15%
1568	38.002.18.0.00	SEALING RING: WATER FERRULE	Spare Part	68	15%
1569	38.006.01.0.00	V BELT B46	Spare Part	908	15%
1570	38.009.05.0.00	JOINT: WATER PUMP VOLUTE	Spare Part	95	15%
1571	38.013.11.0.00	JOINT: WATER INLET MANIFOLD	Spare Part	49	15%
1572	38.014.11.0.00	JOINT: WATER OUTLET MANIFOLD	Spare Part	43	15%
1573	38.022.11.0.00	W T GAUGE 3.6 CAP 40-100	Spare Part	3360	15%
1574	38.027.02.0.00	WATER TEMP GAUGE 1.8M	Spare Part	2960	15%
1575	38.054.01.0.00	STUD FOR GEAR CASING	Spare Part	302	15%
1576	38.066.01.0.00	V BELT: B47 1237 LONG	Spare Part	588	15%
1577	38.100.10.0.00	SET OF JOINTS	Spare Part	2498	15%
1578	38.156.01.0.00	FUEL PIPE: 400MM	Spare Part	498	15%
1579	38.156.02.0.00	FUEL PIPE: 9.0 14X14B 520 WB	Spare Part	634	15%
-		SET OF O RINGS	Spare Part	988	15%
1580	38.164.10.0.00	HOSE: RADIATOR TO PUMP	Spare Part	726	15%
1581 1582	38.167.14.0.00 38.167.15.0.00	HOSE: ENGINE TO RADIATOR	Spare Part	612	15%
					15%
1583	38.181.02.0.00	VALVE GUIDE	Spare Part	145	15%
1584	38.181.03.0.00	VALVE SEAT INSERT EXHAUST	Spare Part	505	15%
1585	38.181.70.0.00	VALVE PAIR	Spare Part	1169	
1586	38.195.20.0.00	LUBE OIL FILTER ASSLY	Spare Part	3289	15% 15%
1587	38.196.02.0.00	CYLINDER HEAD BOLT: SHORT	Spare Part	597	
1588	38.196.03.0.00	CYL HEAD STUD: LONG	Spare Part	609	15%
1589	38.197.05.0.00	GASKET: CYLINDER HEAD 1.2MM THK	Spare Part	505	15%
1590	38.197.06.0.00	CYL HEAD STEEL GASKET 0.80 MM THK	Spare Part	62	15%
1591	38.197.07.0.00	CYL HEAD STEEL GASKET 1.0MM THK	Spare Part	68	15%
1592	38.197.08.0.00	CYL HEAD STEEL GASKET 1.2 MM THK	Spare Part	89	15%
1593	38.197.10.0.00	CYL LINER ASSEMBLY	Spare Part	2895	15%
1594	38.198.30.0.00	PISTON RING SET	Spare Part	1569	15%
1595	38.198.90.0.00	PISTON ASSEMBLY	Spare Part	7341	15%



				Price to Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
				NPR	
1596	38.201.10.0.00	PUSH ROD TUBE ASSEMBLY	Spare Part	182	15%
1597	38.207.40.0.00	WATER PUMP ASSEMBLY	Spare Part	6415	15%
1598	38.226.03.0.00	FUEL FILTER WITH SEALING WIRE	Filter	2206	20%
1599	38.258.10.0.00	LEAK OFF PIPE SUB ASSLY	Spare Part	1120	15%
1600	38.260.01.0.00	HOSE: THERMOSTAT TO RADIATOR INLET	Spare Part	452	15%
1601	38.260.03.0.00	HOSE: RADIATOR TO WATER PIPE	Spare Part	622	15%
1602	38.260.04.0.00	HOSE: WATER OUTLET MANIFOLD TO RADIATOR	Spare Part	809	15%
1603	38.260.90.0.00	ALUMINIUM RADIATOR	Spare Part	60655	15%
1604	38.359.01.0.00	COGGED V BELT: B X47	Spare Part	1262	15%
1605	38.394.01.0.00	ANTI VIBRATION MOUNTS	Spare Part	1686	15%
1606	39.002.01.0.00	WATER INLET MANIFOLD	Spare Part	1763	15%
1607	39.027.22.0.00	FUEL PIPE: 7.5 14X14B 320 WB)	Spare Part	335	15%
1608	39.032.10.0.00	BALL JOINT ASSY	Spare Part	428	15%
1609	39.040.09.0.00	THERMOSTAT ELEMENT 74?	Spare Part	3532	15%
1610	39.092.10.0.00	FUEL CONNECTION	Spare Part	154	15%
1611	39.130.10.0.00	SET OF JOINTS	Spare Part	3200	15%
1612	39.169.02.0.00	HOSE: RADIATOR	Spare Part	462	15%
1613	39.170.10.0.00	WATER PUMP ASSLY WITH PULLEY: RV3 STD	Spare Part	8871	15%
1614	39.173.10.0.00	SET OF JOINTS	Spare Part	3434	15%
1615	39.179.10.0.00	SET OF HIGH PRESSURE PIPES	Spare Part	2092	15%
1616	39.185.20.0.00	CRANKCASE LH ASSEMBLY	Spare Part	112334	15%
1617	39.220.10.0.00	SET OF JOINTS	Spare Part	3049	15%
1618	39.224.02.0.00	JOINT: LUBE OIL SUMP	Spare Part	505	15%
1619	39.230.10.0.00	WATER PUMP ASSLY: 120 PCD	Spare Part	6978	15%
1620	39.231.01.0.00	HOSE: WATER PIPE TO TEE CONNECTION	Spare Part	471	15%
1621	39.231.03.0.00	HOSE: RADIATOR TO WATER PIPE	Spare Part	357	15%
1622	39.236.10.0.00	LEAK OFF PIPE SUB ASSLY	Spare Part	2388	15%
1623	39.237.02.0.00	HOSE: THERMOSTAT TO RADIATOR INLET	Spare Part	498	15%
1624	39.238.10.0.00	COMBINED LEAK OFF PIPE	Spare Part	2037	15%
1625	39.240.01.0.00	DRAIN PIPE: LUBE OIL SUMP	Spare Part	1760	15%
1626	39.385.20.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	15224	15%
1627	39.405.03.0.00	FIP NUT	Spare Part	135	15%
1628	39.406.01.0.00	ADAPTOR FLANGE FOR FIP	Spare Part	658	15%
1629	39.901.10.0.00	WIRING HARNESS ENGINE TO CONTROL PANEL	Spare Part	4889	15%
1630	39.902.10.0.00	WIRING HARNESS ASSLY: ENG TO CONTROL	Spare Part	3280	15%
1631	3H.001.02.0.00	STUD FOR FRONT AXLE SUPPORT	Spare Part	520	15%
1632	3H.001.60.0.00	CRANKCASE ASSEMBLY	Spare Part	112478	15%
1633	3H.003.10.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	21686	15%
1634	3H.003.30.0.00	SUBASSLY OF EGR CAMSHAFT FOR 3R1040TA / TC CPCB II	Spare Part	24089	15%
1635	3H.004.20.0.00	FUEL INJECTION PUMP	Spare Part	105709	15%
1636	3H.005.10.0.00	LUBE OIL PUMP ASSLY.	Spare Part	10012	15%
1637	3H.005.30.0.00	SUB ASSLY LO PUMP INT GEAR & BUSH	Spare Part	3514	15%
1638	3H.005.60.0.00	ASSLY FOR INTERNAL GEAR	Spare Part	3720	15%
1639	3H.005.70.0.00	LUBE OIL PUMP	Spare Part	9984	15%
1640	3H.006.20.0.00	SUCTION TUBE	Spare Part	609	15%
1641	3H.007.01.0.00	HEADER: LUBE OIL COOLER -FILTER	Spare Part	3508	15%
1642	3H.007.02.0.00	JOINT: HEADER	Spare Part	126	15%
1643	3H.007.05.0.00	ADAPTOR FOR SPIN ON FILTER	Spare Part	255	15%
1644	3H.007.10.0.00	LUBE OIL COOLER & HEADER ASSLY	Spare Part	8901	15%
1645	3H.007.11.0.00	LUBE OIL COOLER (3 PLATE)	Spare Part	3046	15%
1646	3H.007.13.0.00	JOINT: LUBE OIL COOLER NON ASBESTOS	Spare Part	37	15%
1647	3H.007.15.0.00	JOINT: HEADER	Spare Part	108	15%
1648	3H.007.19.0.00	LUBE OIL COOLER	Spare Part	4486	15%
1649	3H.007.30.0.00	LUB OIL COOLER & HEADER ASSLY	Spare Part	11344	15%
1650	3H.009.06.0.00	CYL HEAD GASKET 1.22 MM THK	Spare Part	3018	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
1651	3H.009.11.0.00	O RING: NOZZLE	Spare Part	NPR 31	15%
1652	3H.009.30.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	57999	15%
1653	3H.010.06.0.00	OIL METERING ORIFICE DIA 8	Spare Part	31	15%
1654	3H.010.10.0.00	VALVE ROCKER ASSEMBLY	Spare Part	12141	15%
1655	3H.011.10.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	4305	15%
1656	3H.012.20.0.00	LEAK OFF PIPE ASSLY	Spare Part	2526	15%
1657	3H.013.03.0.PR	INLET MANIFOLD	Spare Part	7861	15%
1658	3H.013.04.0.PR	GASKET FOR AIR INLET MANIFOLD	Spare Part	477	15%
1659	3H.014.11.0.00	JOINT: ROCKER COVER	Spare Part	308	15%
		JOINT FOR ROCKER COVER	· · · · · · · · · · · · · · · · · · ·	1286	15%
1660	3H.014.13.0.00	INLET MANIFOLD	Spare Part	5191	15%
1661	3H.015.01.0.00	JOINT: AIR INLET M'FOLD	Spare Part Spare Part	188	15%
1662	3H.015.11.0.00		· · · · · · · · · · · · · · · · · · ·		
1663	3H.016.02.0.00	ADAPTER FOR EXHAUST SILENCER	Spare Part	948	15%
1664	3H.016.04.0.00	EXHAUST MANIFOLD	Spare Part	3332	15%
1665	3H.019.11.0.SP	50 Hrs. A check Maintenance Kit	Spare Part	7255	20%
1666	3H.019.13.0.SP	1500 Hrs C Check Maintenance Kit	Spare Part	11690	20%
1667	3H.024.10.0.00	DIPSTICK ASSEMBLY	Spare Part	145	15%
1668	3H.028.01.0.00	BREATHER PIPE	Spare Part	529	15%
1669	3H.029.02.0.00	PIPE (RADIATOR TO PUMP INLET)	Spare Part	1003	15%
1670	3H.029.03.0.00	LOWER CLAMP(FOR RADIATOR PIPE)	Spare Part	363	15%
1671	3H.029.04.0.00	TOP CLAMP(FOR RADIATOR PIPE)	Spare Part	440	15%
1672	3H.029.05.0.00	HOSE: THERMOSTAT TO RADIATOR INLET	Spare Part	902	15%
1673	3H.029.08.0.00	HOSE FOR THERMOSTAT TO RADIATOR	Spare Part	969	15%
1674	3H.029.17.0.00	CLIP FOR HOSE	Spare Part	600	15%
1675	3H.032.04.0.PR	GASKET ROCKER COVER	Spare Part	1625	15%
1676	3H.034.04.0.00	RUBBER HOSE : AIR CLEANER	Spare Part	3000	15%
1677	3H.039.01.0.00	FRONT COVER	Spare Part	7578	15%
1678	3H.039.04.0.00	COVER PLATE FOR FRONT COVER COMPRESSOR MOUNTING	Spare Part	655	15%
1679	3H.039.05.0.00	JOINT: COVER PLATE	Spare Part	49	15%
1680	3H.040.10.0.PR	H P PIPE FOR CYL 1	Spare Part	2102	15%
1681	3H.040.20.0.PR	H P PIPE FOR CYL 2	Spare Part	2117	15%
1682	3H.040.30.0.PR	H P PIPE FOR CYL 3	Spare Part	2102	15%
1683	3H.040.40.0.PR	H P PIPE PUMP TO RAIL	Spare Part	1858	15%
1684	3H.040.50.0.PR	H P PIPE PUMP TO RAIL	Spare Part	1858	15%
1685	3H.041.02.0.00	PULLEY: ALTERNATOR 68 PCD	Spare Part	597	15%
1686	3H.041.04.0.00	PULLEY: ALTERNATOR 68 PCD SPZ	Spare Part	843	15%
1687	3H.042.01.0.00	OIL FILLING BODY 57 MM HEIGHT	Spare Part	1003	15%
1688	3H.042.03.0.00	JOINT: OIL FILLING BODY	Spare Part		15%
1689	3H.043.03.0.00	JOINT: ADAPTOR	Spare Part		15%
1690	3H.061.10.0.00	THERMOSTAT ASSEMBLY	Spare Part		15%
1691	3H.074.10.0.00	SET OF COPPER WASHER	Spare Part		15%
1692	3H.074.20.0.SP	SET OF JOINTS	Spare Part		15%
1693	3H.074.30.0.00	SET OF O RINGS FOR CODE 3H.2001/3H.3021	Spare Part	883	15%
1694	3H.079.03.0.00	CRANK CASE FOOT (STARTER SIDE)	Spare Part	3526	15%
1695	3H.079.04.0.00	CRANK CASE FOOT (FUEL PUMP SIDE)	Spare Part	3474	15%
1696	3H.082.20.0.00	DIPSTICK ASSEMBLY	Spare Part		15%
1697	3H.085.01.0.00	FLYWHEEL HOUSING	Spare Part		15%
1698	3H.085.03.0.00	FLYWHEEL HOUSING	Spare Part		15%
1699	3H.088.10.0.00	FLYWHEEL ASSEMBLY	Spare Part		15%
1700	3H.096.10.0.PR	CRANKCASE ASSLY WITH MB CAP	Spare Part	130383	15%
1701	3H.096.40.0.PR	CRANKCASE ASSLY WITH MB CAP	Spare Part		15%
1702	3H.099.10.0.00	CRANKSHAFT ASSLY WITH GEAR	Spare Part		15%
1703	3H.1007.01.0.00	F 002 A0Z 776 FUEL PUMP for 3R1040NA 49 5HP 2200 rpm	Spare Part	73781	15%
1704	3H.1007.04.0.00	F 002 A3Z 010 FIP (PLAIN ELEMENT) FOR 3R1040TC_42HP@1500RPM (BOSCH E04028890000) FO	Spare Part	50384	15%
1705	3H.1007.05.0.00	F 002 A3Z 009 FIP PLAIN ELEMENTS 3R1040TA 56HP 1500RPM BOSCH E040 2887 00 FOR CPCE	Spare Part	51125	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer without Vat in	Custom Charge%
				NPR	
1706	3H.1007.06.0.00	FIP: 3R1040_45HP@2000RPM	Spare Part	50365	15%
1707	3H.1008.01.0.00	TURBOCHARGER	Spare Part	44719	15%
1708	3H.1008.04.0.00	TURBOCHARGER	Spare Part	44719	15%
1709	3H.1009.60.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	4531	20%
1710	3H.1017.02.0.PR	BRACKET FOR RELAY BOX MTG	Spare Part	1138	15%
1711	3H.1018.01.0.PR	EGR COOLER 3 KW	Spare Part	26597	15%
1712	3H.1043.10.0.PR	ENGINE WIRING HARNESS FOR 3RTA CRDI CPCB4 ENGINE ENGINE WIRING HARNESS FOR 3RTA 40KVA CRDI CPCB4 ENGINE	Spare Part	62168	15%
1713 1714	3H.1043.50.0.PR 3H.106.30.0.00	PISTON ASSEMBLY	Spare Part Spare Part	60928 9071	15% 15%
1714	3H.106.60.0.00	PISTON ASSEMBLY COMPLETE	Spare Part	7831	15%
1716	3H.107.02.0.00	COMPRESSOR: SC160	Spare Part	56501	15%
1717	3H.107.03.0.00	ADAPTOR: COMPRESSOR	Spare Part	575	15%
1718	3H.113.01.0.00	MC NO 1 421 910 012 C TYPE STOP LEVER MICO	Spare Part	2886	15%
1719	3H.113.02.0.00	REDUCING END	Spare Part	295	15%
1720	3H.113.03.0.00	SCREW PLUG	Spare Part	403	15%
1721	3H.113.04.0.00	WASHER	Spare Part	25	15%
1722	3H.115.03.0.00	GEAR CASING SUITABLE FOR ROTARY FIP MOUNTING	Spare Part	20160	15%
1723	3H.120.01.0.00	ADAPTOR PLATE	Spare Part	1714	15%
1724	3H.120.02.0.00	GEAR	Spare Part	5425	15%
1725	3H.120.03.0.00	JOINT: ADAPTOR PLATE	Spare Part	58	15%
1726	3H.130.01.0.00	DIGITAL RPM METER HOURMETER	Spare Part	12572	15%
1727	3H.130.03.0.00	MAGNETIC PICK UP M16X15 THREADING LENGTH 60 MM	Spare Part	2631	15%
1728	3H.130.05.0.00	DIGITAL RPM METER HOURMETER	Spare Part	9732	15%
1729	3H.132.01.0.00	FUEL FILTER ELEMENT PRIMARY	Filter	1015	20%
1730	3H.132.02.0.00	FUEL FILTER ELEMENT SECONDARY	Filter	1015	20%
1731	3H.132.10.0.00	SPINON FUEL FILTER 0.6L TBOWL	Filter	2463	20%
1732	3H.133.11.0.00	WATER JACKET HEATER KIM HOT TYPE TPS152GT12 000 240V AC 1500W WITH 120 140F THERN	Spare Part	25557	15%
1733	3H.135.10.0.00	STOP SOLENOID ASSLY	Spare Part	5268	15%
1734	3H.135.20.0.00	STOP SOLENOID ASSLY 12VDC	Spare Part	5246	15%
1735	3H.136.11.0.00	WATER CONNECTION	Spare Part	603	15%
1736	3H.136.12.0.00	WATER CONNECTION 0 75 14 NPTF THREADS	Spare Part	489	15%
1737	3H.147.03.0.00	ADAPTOR: OIL SUMP MALE BOTH SIDE	Spare Part	200 612	15%
1738 1739	3H.147.04.0.00	ADAPTOR: OIL SUMP MALE BENJO TYPE ADAPTOR: LUBE OIL SUMP	Spare Part	191	15% 15%
1739	3H.147.07.0.00 3H.147.09.0.00	ADAPTOR: LUBE OIL SUMP ADAPTOR: LUBE OIL DRAIN	Spare Part Spare Part	582	15%
1740	3H.148.01.0.00	INJECTOR	Spare Part	11098	15%
1742	3H.148.53.0.00	BANJO BOLT	Spare Part	243	15%
1743	3H.151.10.0.00	NOZZLE LEAK OFF PIPE:KVA20/25	Spare Part	1880	15%
1744	3H.153.01.0.00	RADIATOR DRAIN PIPE	Spare Part	298	15%
1745	3H.153.02.0.00	ADAPTOR: DRAIN COCK	Spare Part	428	15%
1746	3H.153.08.0.00	PLUG FOR DRAIN COCK	Spare Part	74	15%
1747	3H.153.11.0.00	DRAIN COCK	Spare Part	1517	15%
1748	3H.153.12.0.00	ADAPTOR WITH HOSE TAIL	Spare Part	720	15%
1749	3H.153.14.0.00	ADAPTOR WITH HOSE TAIL	Spare Part	489	15%
1750	3H.153.21.0.00	DRAIN COCK	Spare Part	1126	15%
1751	3H.160.01.0.00	STRIP CLAMP	Spare Part	1108	15%
1752	3H.171.10.0.00	F 002 A0Z 391 FUEL INJECTION PUMP FOR 3R1040PG MICO NO	Spare Part	69996	15%
1753	3H.173.04.0.00	INLET & OUTLET CONNECTION	Spare Part	440	15%
1754	3H.175.10.0.00	LEAK OFF PIPE ASSLY	Spare Part	1105	15%
1755	3H.181.01.0.00	FUEL INLET PIPE: 20-25KVA 750MM LONG	Spare Part	1243	15%
1756	3H.181.02.0.00	FUEL RETURN PIPE	Spare Part	1412	15%
1757	3H.181.05.0.00	FUEL PIPE RETURN M12X15 MALE PLUG X M16X15UNION	Spare Part	615	15%
1758	3H.181.13.0.00	FUEL PIPE RETURN M12X1.5 MALE PLUG & M16X1.5 UNION NUT 900MM LONG	Spare Part	1360	15%
1759	3H.183.16.0.00	FUEL PIPE RETURN: M12 MALE PLUG 14 UNION NUT: 400MM LONG	Spare Part	794	15%
1760	3H.183.17.0.00	FUEL PIPE RETURN WITH M12 MALE PLUG & ,14 UNION NUT; 250MM LONG	Spare Part	560	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
0101		, was 2550, pass.	,	without Vat in	Charge%
1761	3H.183.21.0.00	FUEL PIPE RETURN WITH M14 X 15 MALE PLUG & ,M14 X 15 UNION NUT 250MM	Spare Part	NPR 825	15%
1762	3H.183.24.0.00	FUEL PIPE RETURN WITH M14 X 1 5 MALE PLUG M14 X 1 5 UNION NUT 400MM LONG	Spare Part	1105	15%
1763	3H.183.25.0.PR	FUEL RETURN PIPE M14X1 5 MALE PLUGM16X1 5 UNION NUT	Spare Part	803	15%
1764	3H.183.27.0.PR	FUEL INLET PIPE METAILIC PRE FILTER TO TANK	Spare Part	2314	15%
1765	3H.183.33.0.PR	FUEL PIPE RETURN WITH M14 MALE PLUG M16 UNION NUT	Spare Part	2926	15%
1766	3H.183.37.0.PR	FUEL RETURN PIPE M22X1 5 MALE PLUG M22X1 5 UNION NUT	Spare Part	1505	15%
1767	3H.185.01.0.00	AIR INLET MANIFOLD FOR SHANTI ALUMINIUM	Spare Part	6175	15%
1768	3H.190.10.0.00	ROCKER COVER	Spare Part	6083	15%
1769	3H.190.30.0.00	ROCKER COVER SUB ASSEMBLY	Spare Part	5705	15%
1770	3H.192.01.0.00	HEADER FOR L.O. COOLER & FILTER S/F WATER JACKET HEATING	Spare Part	4594	15%
1771	3H.208.40.0.PR	BATTERY CABLE 35SQMM	Spare Part	5301	15%
1771	3H.217.04.0.00	HOSE-THERMOSTAT TO RADIATOR	Spare Part	754	15%
1773		DRAIN PIPE FOR LUB OIL SUMP FOR 6R1080T, 6R1080TA WITH LENGTH 640MM	Spare Part	1468	15%
	3H.219.03.0.00				
1774	3H.219.05.0.00	DIAL TYPE MECHANICAL FUEL LEVEL GAUGE (105MM)	Spare Part	1148	15%
1775	3H.223.05.0.00	EXPANSION BELLOW: 3R VAVE GENSET 290MM	Spare Part	6197	15%
1776	3H.241.03.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	760	15%
1777	3H.241.04.0.00	FUEL PIPE FUEL FILTER TO FIP	Spare Part	742	15%
1778	3H.246.11.0.PR	INJECTOR LEAK OFF PIPE 3R1190 CPCB4	Spare Part	6172	15%
1779	3H.280.01.0.00	FUEL PIPE I/L - M16X1.5 UNION	Spare Part	1862	15%
1780	3H.282.01.0.00	PIPE (FROM RADIATOR OUTLET TO WATER PUMP INLET)	Spare Part	898	15%
1781	3H.282.04.0.00	HOSE FROM WATER PUMP IN TO RADIATOR OUT	Spare Part	754	15%
1782	3H.282.05.0.00	PIPE FROM RADIATOR OUTLET TO WATER PUMP INLET	Spare Part	862	15%
1783	3H.283.05.0.00	SPOUT FOR FUEL FILLING	Spare Part	1388	15%
1784	3H.289.02.0.00	PIPE INLET M16 X 1 5 UNION	Spare Part	1292	15%
1785	3H.289.03.0.00	FUEL PIPE (FEED PUMP TO FILTER)	Spare Part	649	15%
1786	3H.289.07.0.00	FUEL PIPE PRE FILTER TO TANK UNIT	Spare Part	852	15%
1787	3H.289.14.0.00	FUEL PIPE FEED PUMP TO TANK UNIT	Spare Part	1938	15%
1788	3H.289.15.0.00	FUEL PIPE (FEED PUMP TO TANK UNIT)	Spare Part	1815	15%
1789	3H.289.21.0.PR	FUEL PIPE FEED PUMP TO TANK UNIT	Spare Part	1969	15%
1790	3H.291.01.0.00	HOSE: THERMOSTAT TO RADIATOR	Spare Part	757	15%
1791	3H.291.02.0.00	HOSE: WATER PUMP INLET TO RADIATOR OUTLET	Spare Part	689	15%
1792	3H.291.03.0.00	BRACKET FOR STAY	Spare Part	1231	15%
1793	3H.291.04.0.00	STAY FOR RADIATOR	Spare Part	151	15%
1794	3H.291.07.0.00	HOSE: MAKE UP CONNECTION	Spare Part	492	15%
1795	3H.291.09.0.00	HOSE: MAKE UP CONNECTION	Spare Part	705	15%
1796	3H.291.10.0.00	ALUMINIUM RADIATOR: 3R	Spare Part	37944	15%
1797	3H.291.101.0.PR	HOSE FROM WATER PUMP IN TO RADIATOR OUTLET	Spare Part	1311	15%
1798	3H.291.102.0.PR	HOSE THERMOSTAT TO RADIATOR	Spare Part	1243	15%
1799	3H.291.18.0.00	HOSE: RADIATOR TO PUMP INLET	Spare Part	1188	15%
1800	3H.291.34.0.00	HOSE FROM WATER PUMP IN TO RADIATOR OUTLET	Spare Part	1114	15%
1801	3H.291.36.0.00	HOSE THERMOSTAT TO RADIATOR	Spare Part	1332	15%
1802	3H.291.37.0.PR	HOSE THERMOSTAT TO RADIATOR	Spare Part	1428	15%
1803	3H.291.41.0.00	PIPE - THERMOSTAT TO RAD IN.	Spare Part	1323	15%
1804	3H.291.42.0.00	HOSE: THERMOSTAT OUTLET TO RADIATOR IN	Spare Part	357	15%
1805	3H.291.43.0.00	HOSE- METALLIC PIPE TO RADIATOR IN.	Spare Part	492	15%
1806	3H.291.44.0.00	HOSE - RADIATOR TO PUMP IN PIPE	Spare Part	1240	15%
1807	3H.291.46.0.00	HOSE: MAKE UP CONNECTION	Spare Part	385	15%
1808	3H.291.47.0.PR	PIPE THERMOSTAT TO RADIATOR IN	Spare Part	1151	15%
1809	3H.291.48.0.PR	PIPE FROM RADIATOR TO PUMP INLET	Spare Part	892	15%
1810	3H.291.90.0.00	ALUMINIUM RADIATOR ASSLY: 3R1040	Spare Part	48070	15%
1811	3H.291.94.0.00	ALUMINIUM RADIATOR ASSEMBLY FOR 3R1040 CPCB ENGINES	Spare Part	37347	15%
1812	3H.291.95.0.PR	Aluminium Radiator Assembly	Spare Part	79768	15%
1813	3H.291.96.0.PR	ALUMINIUM RADIATOR ASSEMBLY	Spare Part	72177	15%
1814	3H.292.01.0.00	LEAK OFF PIPE	Spare Part	1849	15%
1815	3H.292.02.0.00	LEAK OFF PIPE	Spare Part	1920	20%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
1816	3H.292.05.0.PR	ARaymond clamp (018030-0-00)	Spare Part	71	15%
1817	3H.299.10.0.00	CRANKSHAFT ASSEMBLY	Spare Part	73196	15%
1818	3H.299.20.0.00	CRANKSHAFT ASSLY WITHOUT GEAR	Spare Part	66713	15%
1819	3H.301.02.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	523	15%
1820	3H.301.03.0.00	FUEL PIPE FUEL FILTER TO FIP	Spare Part	643	15%
1821	3H.315.01.0.00	CHARGING ALTERNATOR 12V, 35A	Spare Part	13692	15%
1822	3H.315.03.0.PR	CHARGING ALTERNATOR 35A MICO MAKE K1 MODEL 13 5V REGULATOR WITH BATTERY SENSI	Spare Part	16698	15%
1823	3H.328.11.0.00	STUD COUPLER 70MM	Spare Part	102	15%
1824	3H.345.10.0.00	LUBE OIL DRAIN H& PUMP ASSEMBLY	Spare Part	6175	15%
1825	3H.408.31.0.00	RAD WATER FILL CAP WITH RUBBER SEAL FOR CANOPY	Spare Part	215	15%
1826	3H.408.52.0.00	ALUMINIUM SHEET 24 GAUGE	Spare Part	2757	15%
1827	3H.408.54.0.00	CERAMIC WOOL 64 DENSITY	Spare Part	1649	15%
1828	3H.408.58.0.00	CHIKEN MESH ROLL 3 FEET X 30 MTR LONG	Spare Part	3471	15%
1829	3H.408.90.0.00	SS LH HINGE FOR CANOPY	Spare Part	1157	15%
1830	3H.408.91.0.00	SS RH HINGE FOR CANOPY	Spare Part	1157	15%
		HOSE: AIR CLEANER		772	15%
1831	3H.415.06.0.00		Spare Part		15%
1832	3H.415.07.0.00	PVC PIPE FOR AIR CLEANER	Spare Part	1120	
1833	3H.415.10.0.00	AIR CLEANER ASSLY: 4.5m3	Spare Part	5374	20%
1834	3H.415.22.0.00	HOSE FOR AIR CLEANER WITH RESTRICTION INDICATOR PORT	Spare Part	1351	15%
1835	3H.415.23.0.00	HOSE FOR PVC PIPE	Spare Part	594	15%
1836	3H.415.24.0.00	PVC PIPE FOR AIR CLEANER	Spare Part	1031	15%
1837	3H.415.25.0.00	AIR CLEANER ASSEMBLY	Spare Part	3570	20%
1838	3H.415.46.0.00	PRIMARY ELEMENT	Filter	1228	20%
1839	3H.432.03.0.PR	AVM CYLINDRICAL H 30 X DIA 30 X M8 RADIATOR 40 45 SH	Spare Part	760	15%
1840	3H.465.40.0.PR	CONTROL PANEL SCHEMATIC FOR 45KVA, 3PH WITH KG645 IP+A	Spare Part	70430	15%
1841	3H.465.70.0.PR	CONTROL PANEL SCHEMATIC FOR 45KVA 3PH WITH KG640 IP A	Spare Part	74085	15%
1842	3H.469.80.0.PR	CONTROL PANEL SCHEMATIC FOR 25KVA 3PH WITH KG640 IP A	Spare Part	65679	15%
1843	3H.470.80.0.PR	CONTROL PANEL 25 30 KVA FOR 3RT 3PH WITH KG640 IP B	Spare Part	95980	15%
1844	3H.488.02.0.PR	FUEL PIPE FROM PRE FILTER OUT TO FUEL FILTER IN	Spare Part	1360	15%
1845	3H.488.03.0.PR	FUEL PIPE PRE FILTER TO TANK UNIT	Spare Part	1674	15%
1846	3H.488.04.0.PR	FUEL PIPE RETURN WITH M14 X 1 5 MALE PLUG M14 X 1 5 UNION NUT	Spare Part	1323	15%
1847	3H.488.06.0.PR	AIR CLEANER HOSE	Spare Part	1458	15%
1848	3H.488.07.0.PR	HOSE FOR PVC PIPE	Spare Part	1018	15%
1849	3H.488.33.0.PR	FUEL PIPE PRE FILTER TO TANK UNIT	Spare Part	1228	15%
1850	3H.488.34.0.PR	AIR CLEANER HOSE TO TURBO	Spare Part	2271	15%
1851	3H.488.44.0.PR	HOSE THERMOSTAT TO RADIATOR	Spare Part	1243	15%
1852	3H.501.20.0.00	CRANKCASE ASSEMBLY	Spare Part	114937	15%
1853	3H.501.30.0.00	SPECIAL BANJO BOLT ASSEMBLY FOR OIL SPRAY NOZZLE	Spare Part	228	15%
1854	3H.501.40.0.00	OIL SPRAY NOZZLE ASSLY	Spare Part	372	15%
1855	3H.502.01.0.00	INLET MANIFOLD	Spare Part	6661	15%
1856	3H.502.03.0.00	INLET MANIFOLD	Spare Part	7314	15%
1857	3H.503.01.0.00	EXHAUST MANIFOLD	Spare Part	3886	15%
1858	3H.504.03.0.00	HOSE: TURBOCHARGER	Spare Part	1637	15%
1859	3H.504.05.0.00	AIR PIPE	Spare Part	6172	15%
1860	3H.505.01.0.00	LUBE OIL SUPPLY PIPE	Spare Part	809	15%
1861	3H.505.02.0.00	LUBE OIL DRAIN PIPE ASSEMBLY	Spare Part	763	15%
1862	3H.506.02.0.00	AIR PIPE TURBO SIDE	Spare Part	1618	15%
1863	3H.506.05.0.00	BRACKET FOR AIR PIPE	Spare Part	369	15%
1864	3H.506.06.0.00	JOINT FOR AIR PIPE	Spare Part	154	15%
1865	3H.506.08.0.00	AIR PIPE CAC SIDE	Spare Part	4640	15%
1866	3H.506.11.0.00	AIR PIPE CAC TO INLET MANIFOLD	Spare Part	3234	15%
1867	3H.506.17.0.00	AIR PIPE TURBO SIDE	Spare Part	3483	15%
1868	3H.506.18.0.00	CAC HOSE (HOT SIDE 4 PLIES)	Spare Part	1782	15%
1869	3H.506.19.0.00	CAC HOSE COLD SIDE	Spare Part	1169	15%
1870	3H.518.01.0.00	EXHAUST DIFFUSER	Spare Part	2262	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
1871	3H.518.02.0.00	BRACKET FOR DIFFUSER	Spare Part	NPR 745	15%
1872	3H.519.20.0.00	VALVE ROCKER ASSEMBLY	Spare Part	9071	15%
1873	3H.520.01.0.00	ADAPTOR ON INLET MANIFOLD	Spare Part	1354	15%
1874	3H.577.01.0.00	CPS MODULE	Spare Part	2055	15%
1875	3H.577.05.0.SP	1 PIN CONNECTOR (F) 350 SERIES (MSSL/TT/AMP/UVS)	Spare Part	95	15%
1876	3H.577.20.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	4837	15%
1877	3H.577.80.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	10157	15%
1878	3H.578.100.0.00	COLD START WIRING HARNESS SF FLANGE HEATER	Spare Part	10117	15%
1879	3H.578.40.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	13529	15%
1880	3H.578.50.0.00	ENGINE WIRING HARNESS WITH CPS 4-20MA GEMS SENSOR	Spare Part	8068	15%
1881	3H.579.20.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	4123	15%
1882	3H.580.10.0.00	ENGINE WIRING HARNESS SF 3R ENGINE	Spare Part	10415	15%
1883	3H.580.20.0.PR	ENGINE WIRING HARNESS 30KVA 3R	Spare Part	4305	15%
1884	3H.580.40.0.PR	TEMP SENSOR PIGTAIL	Spare Part	348	15%
1885	3H.581.57.0.00	SELECTOR SWITCH 6A 3WAY WITH OFF 4 POLE	Spare Part	3040	15%
1886	3H.581.58.0.00	SELECTOR SWITCH 6A 2WAY WITH OFF 2 POLE	Spare Part	1342	15%
1887	3H.584.10.0.00	ENGINE WIRING HARNESS WITH CPS 3R SF KG934	Spare Part	9895	15%
1888	3H.584.40.0.PR	ENGINE WIRING HARNESS FOR 3RT 30KVA EMERALD	Spare Part	5529	15%
1889	3H.5960.33.0.00	MCB 2POLE 2 AMPS PART NO A9N2P02C MAKE SCHNEIDER	Spare Part	4763	15%
1890	3H.792.40.0.PR	Silencer Assembly	Spare Part	32790	15%
1891	3H.816.01.0.ASP	Terminal Block Assembly- 25-40 KVA 1 Phase	Spare Part	2717	15%
1892	3H.816.23.0.PR	KOEL GREEN Alternator KG 30 S T Frame M ECP28A VL 4 SAE 3 11 5 415V 50 Hz 0 8 PF	Spare Part	237089	15%
1893	3H.853.01.0.00	RELAY BOARD-12VDC THERM ELECT	Spare Part	1812	15%
1894	3H.853.10.0.00	12V CONTROL PANEL ASSEMBLY FOR FF PUMPSET WITH MALE CONNECTOR	Spare Part	42778	15%
1895	3H.854.10.0.00	CONTROL PANEL 24V FIGHTING	Spare Part	47418	15%
1896	3H.864.04.0.00	MCB: 32A SP	Spare Part	1317	15%
1897	3H.864.09.0.00	MCB SINGLE POLE 6AMP - A9N1P06C	Spare Part	822	15%
1898	3H.870.15.0.00	BATTERY CHARGER : 4A 24 VDC	Spare Part	14046	15%
1899	3H.894.07.0.00	MCB 50A 3POLE	Spare Part	6898	15%
1900	3H.901.01.0.PR	KOEL GREEN Alternator KG 25 S T Frame L KG 42 3 B SAE 3 11 5 415V 50 Hz 0 8 PF	Spare Part	187991	15%
1901	3H.901.02.0.PR	KOEL GREEN Alternator KG 25 S S Frame L KG 42 3 F SAE 3 11 5 230V 50 Hz 0 8 PF	Spare Part	245486	15%
1902	3H.901.03.0.PR	KOEL GREEN Alternator KG 30 S S Frame M KG 32 1M 4B SAE 3 11 5 230V 50 Hz 0 8 PF	Spare Part	304688	15%
1903	3H.901.05.0.PR	KOEL GREEN Alternator KG 35 S T Frame L KG 42 3 E SAE 3 11 5 415V 50 Hz 0 8 PF	Spare Part	217139	15%
1904	3H.905.02.0.00	CLIP 25 DIA FOR FLEXIBLE PIPE	Spare Part	62	15%
1905	3H.905.04.0.00	CLIP 20 DIA FOR FLEXIBLE PIPE	Spare Part	62	15%
1906	3H.905.05.0.00	RUBBER SLEEVE FOR TEMPSWITCH	Spare Part	46	15%
1907	3H.905.07.0.00	TIE WRAP 200 MM LENGTH	Spare Part	12	15%
1908	3H.905.15.0.00	RUBBER SLEEVE 16 DIA	Spare Part	86	15%
1909	3H.905.16.0.00	RUBBER SLEEVE 27 DIA	Spare Part	95	15%
1910	3H.905.17.0.PR	P-CLIP(SUITABLE FOR 25MM DIA. CONDUIT), MAKE: JUPITER,	Spare Part	289	15%
1911	3H.905.18.0.PR	P-CLIP(SUITABLE FOR 32MM DIA. CONDUIT), MAKE: JUPITER,	Spare Part	308	15%
1912	3H.913.10.0.00	WIRING HARNESS WITH CONNECTOR FOR SWITCHES	Spare Part	1942	15%
1913	3H.922.10.0.00	WIRING HARNESS FOR FF PUMPSET ALLICATION	Spare Part	10178	15%
1914	3H.962.01.0.00	GEAR CASINING MACHINING	Spare Part	15901	15%
1915	3H.967.10.0.PR	CRANK SHAFT ASSEMBLY WITH GEAR	Spare Part	83273	15%
1916	3H.968.20.0.PR	CAMSHAFT ASSLY	Spare Part	16357	15%
1917	3H.969.02.0.PR	CYLINDER HEAD GASKET	Spare Part	6265	15%
1918	3H.969.20.0.PR	CYL HEAD WITH VALVE GUIDE VALVE SEAT INSERT	Spare Part	58772	15%
1919	3H.971.30.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	57990	15%
1920	3H.972.02.0.00	BRACKET FOR FUEL FILTER	Spare Part	729	15%
1921	3H.989.11.0.SP	KIT FOR REPLACEMENT OF INTERFACE CARD FROM 3H.982.31 AND 3H.982.32 TO 3H.989.12	Spare Part	8704	15%
1922	3H.989.12.0.00	DC INTERFACE CARD	Spare Part	6345	15%
1923	3H.992.01.0.PR	LEAK OFF PIPE CPCB M12U	Spare Part	2505	15%
1924	3H.999.10.0.SP	SET OF JOINTS	Spare Part	8895	15%
1925	3H.M001.01.0.00	CRANKSHAFT PULLEY	Spare Part	5809	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		, w. 2550 p	,	without Vat in	Charge%
1926	40.002.06.0.00	HOSE PIPE: INLET MANIFOLD	Spare Part	NPR 212	15%
1927	40.003.02.0.00	HOSE: WATER OUTLET MANIFOLD	Spare Part	403	15%
1928	40.054.03.0.00	SPACER FOR FAN (15 MM)	Spare Part	785	15%
1929	40.123.01.0.00	V BELT: B48 1262 LONG	Spare Part	662	15%
1930	42.003.02.0.00	O RING: CYINDER LINER -21507	Spare Part	308	15%
1931	42.003.20.0.00	CYL LINER ASSEMBLY	Spare Part	5523	15%
1932	42.004.19.0.00	SEALING BUSH: CYL HD STUD	Spare Part	71	15%
1933	42.004.21.0.00	VALVE SEAT INSERT: EXHAUST	Spare Part	655	15%
1934	42.004.22.0.00	O RING: P R FERRULE 2.7X18 - 21509	Spare Part	58	15%
1935	42.004.23.0.00	JOINT CYLLINER TO HEAD 0 40MM THICK	Spare Part	138	15%
1936	42.004.26.0.00	FERRULE TUBE	Spare Part	65	15%
1937	42.004.28.0.00	SEALING RING	,	43	15%
1937	42.004.70.0.00	VALVE PAIR	Spare Part	1357	15%
1939			Spare Part	37	15%
	42.005.05.0.00	SLEEVE: NOZZLE HOLDER	Spare Part		
1940	42.008.02.0.00	PISTON PIN	Spare Part	1191	15%
1941	42.008.72.0.00	PISTON RING SET STD RB00	Spare Part	1582 166	15% 15%
1942	42.014.02.0.00	JOINT: CYL HEAD TO EXH MANIFOLD	Spare Part		
1943	42.014.03.0.00	JOINT: CYL HEAD TO AIR INLET MANIFOLD	Spare Part	92	15%
1944	42.066.02.0.00	EXHAUST SILENCER	Spare Part	3594	15%
1945	42.091.30.0.00	STARTING H&LE	Spare Part	2009	15%
1946	42.102.01.0.00	ADAPTOR: 23MM	Spare Part	7132	15%
1947	42.107.01.0.00	SUMP DRAIN PIPE: 700MM BENJO ON BOTH SIDE	Spare Part	1446	15%
1948	43.075.10.0.00	WATER SEPARATOR	Spare Part	2785	20%
1949	43.075.20.0.00	MUD COLLECTOR - FILTER	Filter	2679	20%
1950	44.035.05.0.00	ANTI VIBRATION MOUNTS	Spare Part	308	15%
1951	45.052.01.0.00	LEAK OFF PIPE	Spare Part	1080	15%
1952	45.106.05.0.00	HOSE	Spare Part	311	15%
1953	46.005.10.0.00	CYL LINER ASSEMBLY	Spare Part	3858	15%
1954	46.008.20.0.00	PUSH ROD	Spare Part	458	15%
1955	46.039.10.0.00	SET OF JOINTS	Spare Part	1760	15%
1956	46.039.30.0.00	SET OF COPPER WASHER	Spare Part	560	15%
1957	46.048.01.0.00	FLEXIBLE PIPE: 1 MT LONG	Spare Part	1982	15%
1958	46.065.02.0.00	ELECTRIC WATER TEMP GAUGE 12V	Spare Part	1754	15%
1959	46.066.02.0.00	ELECTRIC WATER TEMP GAUGE 40-120 DEGC24V	Spare Part	1363	15%
1960	46.072.04.0.00	COLLET PAIR	Spare Part	52	15%
1961	46.072.22.0.00	JOINT: CYL HEAD 1.00	Spare Part	108	15%
1962	46.072.23.0.00	STEEL JOINT:CYL HEAD 1.2MM	Spare Part	105	15%
1963	46.072.24.0.00	STEEL JOINT:CYL HEAD 1.4MM	Spare Part	135	15%
1964	46.072.25.0.00	STEEL JOINT:CYL HEAD 1.6MM	Spare Part	154	15%
1965	46.072.26.0.00	JOINT: CYL HEAD 1.1MM TH	Spare Part	135	15%
1966	46.072.27.0.00	CYL HEAD JOINT:1.3MM	Spare Part	135	15%
1967	46.072.28.0.00	STEEL JOINT:CYL HEAD 1.5MM	Spare Part	142	15%
1968	46.084.01.0.00	LUBE OIL TEMP GAUGE ELECT:40-150/160 D	Spare Part	1369	15%
1969	46.085.01.0.00	LUBE OIL TEMP GAUGE ELE:40-150/160 D	Spare Part	1548	15%
1970	46.085.02.0.00	SENSOR UNIT: ELEC TEMP GAUGE	Spare Part	702	15%
1971	46.107.10.0.00	PISTON ASSEMBLY	Spare Part	6138	15%
1972	46.148.01.0.00	ADAPTOR FOR EXHAUST SILENCER	Spare Part	1065	15%
1973	46.177.01.0.00	ELEC HOUR METER 12V	Spare Part	3861	15%
1974	46.178.01.0.00	ELECTRONIC HOUR METERR 24V	Spare Part	4012	15%
1975	46.179.05.0.00	MAGNETIC PICKUP	Spare Part	10068	15%
1976	46.188.70.0.00	VALVE PAIR	Spare Part	1311	15%
1977	46.244.01.0.00	LUBE OIL PRESS GAUGE 0-10 KG/SQCM	Spare Part	1545	15%
1978	46.250.01.0.00	ELECTRICAL LUBE OIL PRESS GAUGE 0-10BAR	Spare Part	1655	15%
1979	46.251.01.0.00	LUBE OIL PRESS GAUGE ELECTRICAL:0-10 BAR 24V	Spare Part	1483	15%
1980	46.252.02.0.00	RUBBER SLEEVE 38X10 FOR PR GAUGE SENSOR	Spare Part	95	15%



				Price to	
Cu No	Doub Number	Doub Description	Catagoni	Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
1001	40.050.05.0.00	LUDE OIL DESCRIPE CENCOD WITH OWITCH TUDES DOINT DUAL WIDED TVDS	Corner Dord	NPR	450/
1981	46.252.05.0.00 46.252.20.0.00	LUBE OIL PRESSURE SENSOR WITH SWITCH THREE POINT DUAL WIPER TYPE	Spare Part	4105	15%
1982		WIRING HARNESS FOR ELEC PR GAUGE SENDOR WIRING HARNESS FOR LUBE OIL PRESSURE	Spare Part	311	15%
1983	46.252.40.0.00		Spare Part	388 4265	15%
1984	46.253.02.0.PR	DIGITAL HOUR METER TWINTECH MAKE 9 60VDC	Spare Part		15%
1985	46.256.05.0.00	SILENSOR CLAMP RUBBER BLOCK 0.12 RB COUPLING	Spare Part	243	15%
1986	46.349.04.0.00		Spare Part	4117	15%
1987	46.349.05.0.00	INNER MEMBER	Spare Part	4415	15%
1988	46.349.10.9.00	COUPLING: 0.12 RB	Spare Part	13723	15%
1989	46.353.08.0.00	SET OF COPPER WASHER	Spare Part	1028	15%
1990	46.357.10.0.00	EXPANSION BELLOW ASSLY: 2.5"	Spare Part	7612	15%
1991	46.367.03.0.00	SLEEVE FOR EXHAUST SILENCER 55 2 DIA	Spare Part	1105	15%
1992	46.388.03.0.00	WATER PUMP WITH SPINDLE BRG	Spare Part	5806	15%
1993	46.390.01.0.00	ALTERNATOR: 12V 35A	Spare Part	12794	15%
1994	46.999.01.0.00	PUSH ROD KIT	Spare Part	723	15%
1995	47.002.02.0.00	LUBE OIL DRAIN PIPE ASSEMBLY	Spare Part	782	15%
1996	47.014.02.0.00	JOINT BET CR CASE & BLOCK (0.80 MM THICK	Spare Part	988	15%
1997	47.014.08.0.00	JOINT: CYL BLOCK 0.80 MM THK	Spare Part	1335	15%
1998	47.014.09.0.00	COPPER SHIM	Spare Part	169	15%
1999	47.014.11.0.00	COPPER SHIM: 0.50 MM	Spare Part	169	15%
2000	47.027.01.0.00	HOSE: THERMOSTAT TO RADIATOR INLET	Spare Part	535	15%
2001	47.033.02.0.00	JOINT: BRG HOUSING WATER PUMP	Spare Part	154	15%
2002	47.035.10.0.00	LUBE OIL FILTER ASSLY	Spare Part	6917	15%
2003	47.045.10.0.00	SET OF JOINTS	Spare Part	2314	15%
2004	47.045.20.0.00	SET OF O RINGS: RB33-RB00	Spare Part	2178	15%
2005	47.045.30.0.00	SET OF COPPER WASHER	Spare Part	646	15%
2006	47.051.01.0.00	SPACER FOR FAN	Spare Part	2422	15%
2007	47.094.10.0.00	SET OF JOINTS	Spare Part	4314	15%
2008	47.094.20.0.00	SET OF "O" RINGS FOR SWARAJ 855 TRACTOR	Spare Part	1117	15%
2009	47.094.30.0.00	SET OF COPPER WASHER	Spare Part	1588	15%
2010	47.113.04.0.00	PRIMARY FILTER ELEMENT	Filter	2017	20%
2011	47.113.05.0.00	SAFETY FILTER ELEMENT	Filter	879	20%
2012	47.113.15.0.00	RESTRICTION INDICATOR -20"WG	Spare Part	1252	15%
2013	47.127.01.0.00	RADIATOR FAN: RR ENGINE 15" PUSHER	Spare Part	1822	15%
2014	47.204.04.0.00	RUBBER BUSH: TOP	Spare Part	55	15%
2015	47.212.04.0.00	JOINT: COOLER COVER PLATE	Spare Part	191	15%
2016	47.277.10.0.00	SEALED WATER SAPARATOR ASSEMBLY	Spare Part	1209	15%
2017	47.278.01.0.00	WATER SEPARATOR	Spare Part	3728	20%
2018	47.278.05.0.00	WATER SEPARATOR	Spare Part	1002	20%
2019	47.297.04.0.00	GEAR CASING GASKET	Spare Part	609	15%
2020	47.305.01.0.00	V BELT COGGED (BX-48)	Spare Part	966	15%
2021	47.307.05.0.00	BEARING FOR HYD GEAR FAG6006	Spare Part	477	15%
2022	47.329.02.0.00	V BELT BX52 COG	Spare Part	1117	15%
2023	47.383.30.0.00	CAP ASSEMBLY	Spare Part	323	15%
2024	47.387.01.0.00	HOSE: WATER PIPE TO ADAPTOR	Spare Part	372	15%
2025	47.387.03.0.00	HOSE: RADIATOR TO WATER PIPE	Spare Part	305	15%
2026	47.387.07.0.00	HOSE: RADIATOR TO THERMOSTAT	Spare Part	1043	15%
2027	47.491.01.0.00	HOSE (THERMOSTAT TO RADIATOR)	Spare Part	1289	15%
2028	47.491.04.0.00	HOSE: RADIATOR TO PUMP INLET	Spare Part	732	15%
2029	47.491.05.0.00	MAKE-UP HOSE	Spare Part	1631	15%
2030	47.491.09.0.00	MAKEUP HOSE: RB33	Spare Part	2520	15%
2031	47.491.90.0.00	ALUMINIUM RADIATOR: RB33	Spare Part	59310	15%
2032	47.492.01.0.00	HOSE: THERMOSTAT TO RADIATOR INLET	Spare Part	1606	15%
2033	47.507.20.0.00	PISTON ASSEMBLY	Spare Part	6821	15%
2034	47.512.10.0.00	EXPANSION BELLOW	Spare Part	7409	15%
2035	47.515.02.0.00	JOINT: GEAR CASING	Spare Part	957	15%
			Opare i art	931	1370



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
2036	47.531.10.0.00	LEAK OFF PIPE SUB ASSLY	Spare Part	2022	15%
2037	47.533.10.0.00	PISTON ASSEMBLY	Spare Part	7575	15%
2038	47.533.30.0.00	PISTON RING SET	Spare Part	1428	15%
2039	47.542.02.0.00	STEPLESS EAR CLAMP	Spare Part	68	15%
2040	47.601.01.0.00	OETIKER CLAMP ID361	Spare Part	55	15%
2041	47.601.08.0.00	OETIKER CLAMP WITH 565 ID	Spare Part	65	15%
2042	47.990.01.0.00	PUSH ROD KIT	Spare Part	1412	15%
2043	48.019.02.0.00	HOSE: THERMOSTAT TO RADIATOR 160LG	Spare Part	723	15%
2044	48.019.06.0.00	HOSE	Spare Part	403	15%
2045	48.019.07.0.00	ADAPTOR: WATER PUMP	Spare Part	1040	15%
2046	48.019.08.0.00	JOINT: WATER PUMP ADOPTER	Spare Part	34	15%
2047	48.032.07.0.00	CLAMP FOR RAISED DIP STICK GUIDE	Spare Part	105	15%
2048	48.039.10.0.00	SET OF JOINTS	Spare Part	2895	15%
2049	48.039.30.0.00	SET OF COPPER WASHER	Spare Part	625	15%
2050	48.067.03.0.00	DOWEL BOLT: ALTERNATOR -M10X130LG	Spare Part	185	15%
2051	48.067.04.0.00	BUSH FOR ALTERNATOR 32MM	Spare Part	65	15%
2052	48.112.01.0.00	LEAK OFF PIPE 1000 MM LONG	Spare Part	1289	15%
2053	48.113.01.0.00	PLATE FOR FUEL FILTER	Spare Part	498	15%
2054	48.115.30.0.00	OVERHAUL KIT RB44 JCB	Spare Part	59092	15%
2055	48.117.03.0.00	O RING	Spare Part	95	15%
2056	48.117.04.0.00	FUEL FILTER ELEMENT PRE	Filter	306	20%
2057	48.117.05.0.00	FUEL FILTER ELEMENT MICRO	Filter	337	20%
2058	48.117.10.0.00	FUEL FILTER 1.1 L TWIN BOWL	Filter	4555	20%
2059	48.121.01.0.00	L.O.P.G.PIPE - 2 MTR LONG	Spare Part	2646	15%
2060	48.122.01.0.00	SEALING RING: PUSH ROD TUBE	Spare Part	95	15%
2061	48.129.01.0.00	FUEL PIPE	Spare Part	812	15%
2062	48.145.02.0.00	OUTER ELEMENT	Filter	2946	20%
2063	48.145.03.0.00	INNER ELEMENT	Filter	1912	20%
2064	48.145.10.0.00	AIR CLEANER ASSLY: DRY TYPE	Spare Part	28898	15%
2065	48.155.04.0.00	SEALING RING FOR WATER FERRULE	Spare Part	74	15%
2066	48.156.10.0.00	SET OF JOINT	Spare Part	2769	15%
2067	48.156.20.0.00	SET OF O RINGS	Spare Part	2332	15%
2068	48.156.30.0.00	SET OF COPPER WASHER	Spare Part	951	15%
2069	48.173.08.0.00	JOINT FOR BEARING HOUSING	Spare Part	169	15%
2070	48.188.01.0.00	FUEL PIPE-9.5,14X14B,450R	Spare Part	1191	15%
2071	48.212.01.0.00	RADIATOR FAN 17"DIA-PUSHER	Spare Part	2963	15%
2072	48.213.08.0.00	ANTI VIBRN MTG: BOTTOM RADIATOR	Spare Part	883	15%
2073		RADIATOR CAP: 7PSI SEALED	Spare Part	440	15%
2074	48.214.04.0.00	THERMOSTAT BYPASS HOSE	Spare Part	529	15%
2075	48.215.04.0.00	RUBBER HOSE	Spare Part	523	15%
2076	48.215.10.0.00	PRE CLEANER ASSLY	Spare Part	4335	15%
2077	48.231.03.0.00	FLEX PIPE -ENGINE TO COOLER	Spare Part	2218	15%
2078	48.288.02.0.00	PLUG FOR DIP STICK HOLE	Spare Part	31	15%
2079	48.305.06.0.00	JUPITER WORM DRIVE CLAMP TYPE 603 65mm DIA S F 65mm HOSE O D	Spare Part	246	15%
2080	48.305.07.0.00	WORM DRIVE HOSE CLAMP 80MM	Spare Part	228	15%
2081	48.305.08.0.00	HOSE CLAMP: 110MM DIA	Spare Part	345	15%
2082	48.318.10.0.00	SILENCER ASSLY	Spare Part	14643	15%
2083	48.338.02.0.00	SUCKER FAN 494 DIA METALLIC	Spare Part	3055	15%
2084	48.340.02.0.00	HOLDER FOR INNER CABLE	Spare Part	157	15%
2085	48.406.01.0.00	FUEL PIPE: M14XM14-1800 LENGTH	Spare Part	1086	15%
		SPACER FOR SUPPORT BRACKET	Spare Part Spare Part	188	15%
2086	48.414.01.0.00		·		15%
2087	48.417.01.0.00	LUBE OIL SUPPLY HOSE: FIP	Spare Part	1222	
2088	48.436.01.0.00 48.503.01.0.00	ALTERNATOR: 24V 40A ACTUATOR	Spare Part Spare Part	18092 114657	15% 15%
2089					



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
2091	49.079.10.0.00	SET OF JOINTS	Spare Part	NPR 4711	15%
	49.079.20.0.00	SET OF 0 RINGS: RB66-RB00	Spare Part	3711	15%
	49.079.30.0.00	SET OF COPPER WASHER	Spare Part	855	15%
	49.079.40.0.00	SET OF JOINTS	Spare Part	4529	15%
	49.080.01.0.00	RADIATOR FAN: 494 DIA PUSHER	Spare Part	4157	15%
	49.097.01.0.00	WORM DRIVE HOSE CLIP 38X54	Spare Part	163	15%
	49.097.07.0.00	WORM DRIVE HOSE CLIP	Spare Part	138	15%
-	49.097.08.0.00	HOSE CLIP SIZE NO 1 28X30	Spare Part	98	15%
	49.106.02.0.00	NUT: SS M8	Spare Part	95	15%
	49.114.01.0.00	EXHAUST SILENCER	Spare Part	2818	15%
	49.117.03.0.00	JOINT: ELEMENT & BODY(LOCOOLER)	Spare Part	58	15%
	49.117.06.0.00	O RING: ELEMENT HEADER	Spare Part	769	15%
-	49.119.01.0.00	FAN: 20" PUSHER	Spare Part	3935	15%
	49.120.04.0.00	JOINT: TURBO INLET	Spare Part	308	15%
	49.121.03.0.00	JOINT: INLET PIPE	Spare Part	22	15%
	49.121.05.0.00	JOINT: DRAIN PIPE	Spare Part	68	15%
	49.135.03.0.00	OFF/ON/START SWITCH 1160A	Spare Part	1505	15%
	49.156.01.0.00	LOW OIL PRES SWITCH 1.7KG/CMSQ	Spare Part	3477	15%
	49.162.01.0.00	BRACKET FOR RPM METER (FITTED ON BODY)	Spare Part	194	15%
	49.202.01.0.00	V BELT: BX51 RAW EDGE COGGED	Spare Part	942	15%
	49.403.03.0.00	AIR INLET CAP	Spare Part	2760	15%
	49.438.05.0.00	INNER MEMBER	Spare Part	6935	15%
-	49.438.10.9.00	COUPLING 0.24 RB	Spare Part	23101	15%
	49.462.04.0.00	RUBBER BLOCK 0.2 RB COUPLING	Spare Part	5006	15%
	49.462.10.9.00	COUPLING: 0.20 RB	Spare Part	16744	15%
	49.472.08.0.00	HOSE(FOR DRAIN PIPE)	Spare Part	849	15%
	49.480.10.0.00	PISTON ASSEMBLY	Spare Part	8880	15%
	49.480.30.0.00	PISTON RING SET (3RING)	Spare Part	1782	15%
	49.480.60.0.00	PISTON ASSEMBLY RB33 H1	Spare Part	7028	15%
	49.491.20.0.00	SET OF 'O'RINGS.	Spare Part	2102	15%
	49.491.30.0.00	SET OF COPPER WASHERS	Spare Part	1489	15%
	49.626.05.0.00	RELAY FOR STOP SOLENOID	Spare Part	997	15%
	49.902.02.0.00	ENGINE SAFETY UNIT: KRB101	Spare Part	18286	15%
	4H.001.03.0.00	BLANKING PLATE FOR CAM BORE	Spare Part	308	15%
	4H.001.05.0.00	SEALING CAP	Spare Part	112	20%
	4H.001.13.0.00	HOLLOW DOWEL (16 DIA)	Spare Part	46	15%
	4H.001.14.0.00	JOINT: CAM BORE BLANKING PLATE	Spare Part	52	15%
	4H.001.22.0.00	PRECOATED PLUG	Spare Part	40	15%
	4H.001.70.0.00	MONOBLOCK C'CASE W/O BEARING	Spare Part	152472	15%
	4H.002.01.0.00	CRANKSHAFT GEAR	Spare Part	4375	15%
	4H.002.01.0.00	CRANKSHAFT GEAR ASSLY	Spare Part	94479	15%
	4H.002.60.0.00	CRANKSHAFT ASSLY WITH GEAR	Spare Part	101076	15%
	4H.003.02.0.00	THRUST WASHER - CAM SHAFT	Spare Part	637	15%
	4H.003.20.0.00	CAMSHAFT SUB ASSLY	Spare Part	29215	15%
	4H.003.70.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	28898	15%
	4H.003.70.0.00 4H.003.80.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	33009	15%
	4H.004.10.0.00	LUBE OIL COOLER & HEADER ASSEMBLY	Spare Part	13794	15%
-	4H.006.01.0.00	LO SUPPLY HOSE FIP M10 BANJO X 235	Spare Part	908	15%
	4H.006.04.0.00	DELIVERY VALVE	Spare Part	1188	15%
		FUEL PUMP: 9 MM LIFT VSC		71119	15%
	4H.006.10.0.00		Spare Part	271	15%
	4H.007.02.0.00	VALVE GUIDE VALVE SEAT INSERT INLET	Spare Part		15%
	4H.007.03.0.00	VALVE SEAT INSERT-INLET	Spare Part	560 532	15%
	4H.007.04.0.00	VALVE SEAT INSERT-EXHAUST	Spare Part		
	4H.007.07.0.00	BOLT FOR CYLINDER HEAD.	Spare Part	372	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
2146	4H.007.11.0.00	GASKET: CYLINDER HEAD 1.10 THK	Spare Part	3148	15%
2147	4H.007.24.0.00	CYL HEAD GASKET 1.22 MM THK	Spare Part	3828	15%
2148	4H.007.39.9.00	VALVE SEAT INSERT INLET SEMI FINISH	Spare Part	502	15%
2149	4H.007.40.0.00	VALVE PAIR INLET & EXHAUST	Spare Part	1954	15%
2150	4H.007.55.0.00	CYLINDER HEAD RECONDITIONING KIT 4R1040 ENGINES (PG & INDL BSII)	Spare Part	18938	15%
2151	4H.008.10.0.00	VALVE ROCKER ASSLY	Spare Part	17695	15%
2152	4H.008.20.0.00	ROCKER SHAFT SUB ASSLY	Spare Part	5003	15%
2153	4H.009.12.0.00	ROCKER COVER JOINT METALIC	Spare Part	1150	20%
2154	4H.009.15.0.00	GASKET FOR ROCKER COVER	Spare Part	3234	15%
2155	4H.010.23.0.00	LEAK OFF PIPE ASSLY	Spare Part	1508	15%
2156	4H.010.29.0.00	LEAK OFF PIPE ASSEMBLY	Spare Part	2277	15%
2157	4H.012.01.0.00	AUTO TIMER	Spare Part	31569	15%
2158	4H.012.02.0.00	FUEL PUMP GEAR	Spare Part	5052	15%
2159	4H.012.20.0.00	BOLT ASSLY.(AUTOTIMER)	Spare Part	108	15%
2160	4H.015.10.0.00	SUCTION TUBE ASSLY	Spare Part	1234	15%
2161	4H.016.01.0.00	HYDRAULIC PUMP GEAR	Spare Part	3501	15%
2162	4H.019.01.0.00	CRANK PULLEY: FINISH	Spare Part	4625	15%
2163	4H.019.93.0.00	MUD SLINGER	Spare Part	234	15%
2164	4H.019.94.0.00	SPACER FOR MUD SLINGER	Spare Part	43	15%
2165	4H.020.02.0.00	SPACER FOR FAN(EJCB-3DX)	Spare Part	1655	15%
2166	4H.020.03.0.00	SPACER: FAN	Spare Part	1474	15%
2167	4H.020.91.0.00	RADIATOR FAN: EJCB	Spare Part	2680	15%
2168	4H.021.03.0.00	JOINT: DELIVERY VOLUTE	Spare Part	62	15%
2169	4H.021.08.0.00	WATER PUMP PULLEY: 120PCD SPA SECTION	Spare Part	1677	15%
2170	4H.021.20.0.00	WATER PUMP ASSLY 345 CRS	Spare Part	11640	15%
2171	4H.021.30.0.00	WATER PUMP ASSLY WO DEL VOL 345CRS	Spare Part	8095	15%
2172	4H.022.11.0.00	JOINT: WATER OUTLET MANIFOLD	Spare Part	31	15%
2173	4H.023.02.0.00	THERMOSTAT BYPASS HOSE	Spare Part	225	15%
2174	4H.023.03.0.00	BYPASS HOSE: 58MM LONG	Spare Part	249	15%
2175	4H.023.06.0.PR	THERMOSTAT BYPASS HOSE	Spare Part	145	15%
2176	4H.024.03.0.00	VACUATOR VALVE	Spare Part	342	15%
2177	4H.024.12.0.00	PRIMARY FILTER ELEMENT	Filter	2249	20%
2178	4H.024.13.0.00	SAFETY FILTER ELEMENT	Filter	968	20%
2179	4H.024.70.0.00	AIR CLEANER ASSLY	Spare Part	17465	20%
2180	4H.025.10.0.00	SET OF HIGH PRESS PIPE: 530X1.5 ID	Spare Part	3874	15%
2181	4H.027.10.0.00	OIL FILLING BODY SUB ASSLY	Spare Part	978	15%
2182	4H.027.11.0.00	JOINT: OIL FILLING BODY	Spare Part	15	15%
2183		EXHAUST MANIFOLD (END OPENING)	Spare Part	10994	15%
2184	4H.029.02.0.00	HOSE: DRY TYPE AIR CLEANER	Spare Part	1148	15%
2185	4H.029.05.0.00	"T" BOLT CLAMP, KLIPCO TB 88 /JUPITOR (92 TO 100 DIA)	Spare Part	228	15%
2186	4H.029.06.0.00	T BOLT CLAMP TB78: 84	Spare Part	252	15%
2187	4H.030.01.0.00	AIR INLET MANIFOLD	Spare Part	9391	15%
2188	4H.030.06.0.00	METTALIC JOINT: INLET MANIFOLD	Spare Part	212	20%
2189	4H.030.11.0.00	JOINT: AIR INLET MANIFOLD	Spare Part	178	15%
2190	4H.031.01.0.00	BRACKET FOR FUEL FILTER	Spare Part	505	15%
2191	4H.031.04.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	969	15%
2192	4H.031.05.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	1145	15%
2193	4H.031.06.0.00	CLAMP	Spare Part	135	15%
2194	4H.031.07.0.00	RUBBER SLEEVE	Spare Part	71	15%
2194	4H.031.30.0.00	CLAMP ASSEMBLY WITHOUT RUBBER SLEEVE	Spare Part	345	15%
		LIFTING HOOK	Spare Part Spare Part	800	15%
2196 2197	4H.033.01.0.00 4H.033.03.0.00	ENGINE LIFTING HOOK	·	720	15%
			Spare Part		
2198	4H.034.10.0.00 4H.035.02.0.00	DIPSTICK ASSLY GASKET: EXH MANIFOLD	Spare Part Spare Part	145 68	15% 15%
2199					



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
2201	4H.035.05.0.00	PLASTIC COVER FOR EXHAUST MANIFOLD OPENING	Spare Part	37	15%
2202	4H.035.07.0.00	EXHAUST M'FOLD GE TOP OPEN	Spare Part	5477	15%
2203	4H.036.01.0.00	ADAPTOR: EXHAUST SILENCER	Spare Part	1471	15%
2204	4H.038.01.0.00	FLYWHEEL HOUSING	Spare Part	32864	15%
2205	4H.038.02.0.00	FLANGE: STARTER 13- 6MM EFF	Spare Part	440	15%
2206	4H.038.04.0.00	BLANKING PLATE FOR FLYWHEEL HOUSING	Spare Part	86	15%
2207	4H.039.01.0.00	WATER INLET CONNECTION 38 CORE	Spare Part	1422	15%
2208	4H.039.02.0.00	JOINT: W.I CONN & THERM HSG	Spare Part	28	15%
2209	4H.040.01.0.00	THERMOSTAT HOUSING	Spare Part	1043	15%
2210	4H.042.05.0.00	GEAR END FOOT(FUEL PUMP SIDE)	Spare Part	4268	15%
2211	4H.042.06.0.00	GEAR END FOOT(ALTERNATOR SIDE)	Spare Part	4268	15%
2212	4H.044.01.0.00	PULLEY: ALTERNATOR 90 PCD	Spare Part	1175	15%
2213	4H.044.05.0.00	PULLEY ALTERNATOR 84 3 PCD S F ECEL 6H 2117	Spare Part	1489	15%
2214	4H.044.20.0.00	MOUNTING SUBASSEMBLY FOR ALTERNATOR	Spare Part	1354	15%
2215	4H.046.01.0.00	V BELT	Spare Part	1418	15%
2216	4H.046.02.0.00	V BELT RAW EDGED COGGED	Spare Part	1738	15%
2217	4H.047.11.0.00	FLYWHEEL HOUSING	Spare Part	19135	15%
2218	4H.047.12.0.00	Adaptor SAE 3 to SAE 4 FOR LTK	Spare Part	10040	15%
2219	4H.049.04.0.PR	V BELT RAW EDGE COGGED SPA X 1307 L	Spare Part	963	15%
2220	4H.050.60.0.00	HP PIPE COMPLETE SET 700 MM	Spare Part	5006	15%
2221	4H.050.70.0.00	High pressure pipe assembly	Spare Part	4541	15%
2222	4H.052.11.0.00	JOING: BEARING HOUSING	Spare Part	92	15%
2223	4H.052.12.0.00	JOINT: DELIVERY VOLUTE	Spare Part	111	15%
2224	4H.052.20.0.00	WATER PUMP ASSLY WITH DEL VOL 282.5 CRS	Spare Part	12532	15%
2225	4H.052.95.0.00	WATER PUMP ASSEMBLY (HIGHER BEARING SIZE)	Spare Part	13544	15%
2226	4H.053.02.0.00	THERMOSTAT COVER(PG - 116 HEIGHT)	Spare Part	1117	15%
2227	4H.053.04.0.00	THERMOSTAT HOUSING	Spare Part	1511	15%
2228	4H.053.08.0.00	JOINT: THERMOSTAT COVER	Spare Part	103	20%
2229	4H.053.10.0.00	THERMOSTAT HOUSING ASSLY(PG)	Spare Part	6031	15%
2230	4H.053.11.0.00	JOINT: THERMOSTAT HOUSING	Spare Part	55	15%
2231	4H.053.12.0.00	JOINT: THERMOSTAT COVER	Spare Part	98	15%
2232	4H.053.50.0.00	ASSEMBLY THERMOSTAT HOUSING	Spare Part	5698	15%
2233	4H.053.60.0.00	THERMOSTAT HOUSING ASSEMBLY	Spare Part	6228	15%
2234	4H.057.08.0.00	ADAPTOR M10X15 FOR LOP GUAGE	Spare Part	108	15%
2235	4H.061.01.0.00	CRANKCASE FOOT	Spare Part	3154	15%
2236	4H.061.02.0.00	CRANKCASE FOOT	Spare Part	3012	15%
2237	4H.064.10.0.00	SUCTION TUBE	Spare Part	1046	15%
2238	4H.064.20.0.00	SUCTION TUBE ASSLY.(SHEET METAL SUMP)	Spare Part	640	15%
2239	4H.065.02.0.00	STARTER BRACKET: PG	Spare Part	2117	15%
2240	4H.065.03.0.00	BRACKET STARTER	Spare Part	2252	15%
	4H.069.01.0.00	V BELT: XPA 1250 COGGED	Spare Part	1283	15%
2241	4H.069.02.0.00	BELT: SPAX 1300 COGGED	Spare Part	1123	15%
2243	4H.073.01.0.00	HOSE: RADIATOR TO WATER PUMP 45X45X130L	Spare Part	1012	15%
2244	4H.073.02.0.00	HOSE: PIPE TO WATER PUMP 45x45X80L PIPE: RADIATOR TO WATER PUMP INLET	Spare Part	1902	15%
2245	4H.073.03.0.00		Spare Part	1902	15%
2246	4H.073.04.0.00	UPPER CLAMP FOR PIPE	Spare Part	308	15%
2247	4H.073.05.0.00	LOWER CLAMP FOR PIPE	Spare Part	391	15%
2248	4H.073.07.0.00	PIPE(RADIATOR TO PUMP INLET)	Spare Part	1329	15%
2249	4H.073.08.0.00	HOSE: THERMOSTAT TO RADIATOR	Spare Part	2052	15%
2250	4H.073.36.0.PR	HOSE WATER PUMP INLET TO RADIATOR OUTLET	Spare Part	385	15%
2251	4H.077.02.0.00	FUEL PIPE: FEED PUMP TO FUEL FILTER	Spare Part	538	15%
2252	4H.077.03.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	532	15%
2253	4H.081.01.0.00	RADIATOR SUPPORT STARTER SIDE	Spare Part	1342	15%
2254	4H.081.02.0.00	RADIATOR SUPPORT FUEL PUMP SIDE	Spare Part	1108	15%
2255	4H.081.03.0.00	CROSS MEMBER FOR RADIATOR SUPPORT	Spare Part	1791	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		·		without Vat in NPR	Charge%
2256	4H.085.01.0.00	LUBE OIL SUMP: 3CX	Spare Part	22458	15%
2257	4H.087.05.0.SP	SET OF JOINTS (TURBO PG ENGINE)	Spare Part	4566	15%
2258	4H.087.10.0.SP	SET OF JOINTS	Spare Part	5846	15%
2259	4H.087.20.0.00	SET OF O RINGS	Spare Part	234	15%
2260	4H.087.30.0.00	SET OF COPPER WASHERS	Spare Part	1000	15%
2261	4H.087.40.0.SP	SET OF JOINTS	Spare Part	3914	15%
2262	4H.087.50.0.00	SET OF O RINGS FOR PG: 4H.3031	Spare Part	1049	15%
2263	4H.087.60.0.00	SET OF COPPER WASHER 4H.3031	Spare Part	1606	15%
2264	4H.087.96.0.SP	SET OF JOINT: 4R TC/TA BSIII APPLICATION ENGINES	Spare Part	4080	15%
2265	4H.087.97.0.SP	SET OF JOINT: 4R TC/TA BSIII APPLICATION ENGINES	Spare Part	4181	15%
2266	4H.088.01.0.00	ACCELERATOR LEVER PULL TYPE (37 MM)	Spare Part	234	15%
2267	4H.088.02.0.00	ACCELERATOR LEVER PULL TYPE (27 MM)	Spare Part	258	15%
2268	4H.088.03.0.00	PULL TYPE ACCELERATOR LEVER	Spare Part	243	15%
2269	4H.088.04.0.00	BRACKET FOR MOUNTING ACCELERATOR & STOP CABLE	Spare Part	1077	15%
2270	4H.089.01.0.00	STOP LEVER	Spare Part	105	15%
2271	4H.096.03.0.00	THERMOSTAT COVER	Spare Part	1058	15%
2272	4H.096.10.0.00	THERMOSTAT & HOUSING	Spare Part	3948	15%
2273	4H.096.40.0.00	THERMOSTAT AND MOUNTING (M14 ADAPATOR ON BOTH END)	Spare Part	4037	15%
2274	4H.1005.20.0.00	RADIATOR	Spare Part	147370	15%
2275	4H.1005.60.0.00	ALUMINIUM RADIATOR ASSLY	Spare Part	136678	15%
2276	4H.1009.90.0.00	ROCKER COVER	Spare Part	6252	15%
2277	4H.1027.10.0.00	DIPSTICK ASSLY: 290MM	Spare Part	132	15%
2278	4H.1027.20.0.00	DIPSTICK ASSEMBLY	Spare Part	178	15%
2279	4H.1028.10.0.00	ROCKER COVER	Spare Part	6511	15%
2280	4H.1034.01.0.00	GEAR CASING	Spare Part	14015	15%
2281	4H.1034.02.0.00	GEAR CASING	Spare Part	14289	15%
2282	4H.1044.10.0.00	FLYWHEEL L T 8 10 DP ST RING	Spare Part	10821	15%
2283	4H.1047.10.0.00	DIPSTICK ASSEMBLY COMPLETE 350 MM, S.F.35 DEG SUMP	Spare Part	775	15%
2284	4H.1048.02.0.00	HOSE	Spare Part	1855	15%
2285	4H.1050.10.0.00	TURBOCHARGER FOR 4RTA 1800 RPM ENGINE (K24 2460 GGA 6.11)	Spare Part	80187	15%
2286	4H.1062.11.0.00	120 OHM 14 WATT MFR TYPE RESISTANCE	Spare Part	52	15%
2287	4H.107.02.0.00	SPACER: EXT MANIFOLD	Spare Part	108	15%
2288	4H.1086.01.0.00	PRIMARY FILTER ELEMENT ASSLY	Filter	2602	20%
2289	4H.1086.02.0.00	SAFETY FILTER ELEMENT	Filter	1776	20%
2290	4H.1086.10.0.00	AIR CLEANER ASSLY: RADIAL SEAL	Spare Part	8929	15%
2291	4H.1089.01.0.00	LOCATING BOLT 80 MM : EYE BOLT	Spare Part	218	15%
2292	4H.1089.02.0.00	LOCATING BOLT 60MM	Spare Part	185	15%
2293	4H.1091.05.0.00	BRACKET: STAY ROD	Spare Part	880	15%
2294	4H.1093.01.0.00	DRIVEN HUB FOR COMPRESSOR	Spare Part	3674	15%
2295	4H.1093.02.0.00	HOUSING FOR COMPRESSOR DRIVE ARRANGEMENT	Spare Part	2911	15%
2296	4H.1093.03.0.00	DRIVING HUB FOR COMPRESSOR	Spare Part	6732	15%
2297	4H.1093.04.0.00	SPIDER COUPLING (FOR COMPRESSOR DRIVE)	Spare Part	1763	15%
2298	4H.1093.06.0.00	JOINT GEAR CASING SIDE	Spare Part	46	15%
2299	4H.1093.07.0.00	GEAR FOR COMPRESSOR DRIVING	Spare Part	3975	15%
2300	4H.1093.08.0.00	DEEP GROOVE BALL BEARING BOTH SIDE SEALED (55 X 90)	Spare Part	3705	15%
2301	4H.1097.21.0.PR	LEAK OFF FOR FIP	Spare Part	705	15%
2302	4H.1097.22.0.PR	LEAK OFF FOR RAIL AND FIP	Spare Part	4132	15%
2303	4H.1097.23.0.PR	LEAK OFF FOR INJECTOR	Spare Part	997	15%
2304	4H.1097.31.0.PR	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	1332	15%
2304	4H.1097.32.0.PR	FUEL PIPE FUEL FILTER TO FIP	Spare Part	1311	15%
2305	4H.1097.32.0.FK	FRONT COVER (HYDRAULIC PUMP GEAR BORE)	Spare Part	7840	15%
2307	4H.1098.02.0.00	COVER (HYDRAULIC PUMP GEAR BORE)	Spare Part	766	15%
2307	4H.1098.03.0.00	JOINT: COVER PLATE	Spare Part	62	15%
	Ti i. 1080.03.0.00	JOHN. JOYLNELAIL	Spare Part	02	13%
2309	4H.1120.10.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	33092	15%



				Price to	
		2.2	C-4	Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
		LUDE OF SURE		NPR	
2311	4H.1128.01.0.00	LUBE OIL SUMP	Spare Part	12212	15%
2312	4H.1141.01.0.00	SPACER FOR RADIATOR FAN (35 MM)	Spare Part	5594	15%
2313	4H.1143.10.0.00	DIPSTICK ASSLY: S/F FAB SUMP	Spare Part	95	15%
2314	4H.1143.20.0.00	DIPSTICK ASSLY	Spare Part	132	15%
2315	4H.1171.10.0.00	FLYWHEEL ASSEMBLY	Spare Part	14997	15%
2316	4H.1171.30.0.00	FLYWHEEL ASSEMBLY	Spare Part	19034	15%
2317	4H.1171.60.0.00	FLYWHEEL ASSLY	Spare Part	23344	15%
2318	4H.1172.30.0.00	PISTON RING SET 105 DIA	Spare Part	1382	15%
2319	4H.1172.70.0.00	PISTON ASSEMBLY	Spare Part	6532	15%
2320	4H.1174.01.0.00	GEAR CASING	Spare Part	8615	15%
2321	4H.1174.02.0.00	GEAR CASING	Spare Part	11231	15%
2322	4H.1174.04.0.00	GEAR CASING	Spare Part	11966	15%
2323	4H.1174.11.0.00	GEAR CASING FOR 4K 6K ENGINE	Spare Part	14760	15%
2324	4H.1176.01.0.00	EXHAUST M'FOLD CEN UP OPEN	Spare Part	4837	15%
2325	4H.1179.40.0.00	CRANKCASE WITH MB CAPS LINE BORE OPERATION	Spare Part	152238	15%
2326	4H.1180.01.0.00	FLYWHEEL HOUSING	Spare Part	12511	15%
2327	4H.1183.01.0.00	FLYWHEEL HOUSING	Spare Part	13012	15%
2328	4H.1183.06.0.PR	FLYWHEEL HOUSING SAE 3	Spare Part	13714	15%
2329	4H.1188.01.0.00	ALTERNATOR: 12V 65A	Spare Part	24581	15%
2330	4H.1190.02.0.00	COVER FOR FUEL PUMP BORE	Spare Part	760	15%
2331	4H.1190.03.0.00	JOINT FOR FUEL PUMP GEAR COVER	Spare Part	172	15%
2332	4H.1196.01.0.ASP	Condenser Diode & Varistor-45/62.5KVA-1 PHASE	Spare Part	18449	15%
2333	4H.1196.02.0.ASP	Terminal Block Assembly- 45-62.5 KVA 1 Phase	Spare Part	8664	15%
2334	4H.1196.12.0.PR	KOEL GREEN Alternator, KG 82.5 S T Frame: L KG 443 B, SAE-3 11.5", 415V, 50 Hz, 0.8 PF	Spare Part	397250	15%
2335	4H.1196.17.0.PR	KOEL GREEN ALTERNATOR COASTAL HUMID ENVIRONMENT KG 82 5 S T FRAME KG 44 3 B2	Spare Part	503009	15%
2336	4H.1198.01.0.00	PRIMARY ELEMENT FOR 6m3 AIR CLEANER (2990217219)	Filter	2265	20%
2337	4H.1198.02.0.00	SAFETY ELEMENT FOR 6m3 AIR CLEANER (2990217223)	Filter	1213	20%
2338	4H.1198.10.0.00	AIR CLEANER: DRY TYP 6" P92	Spare Part	10373	20%
2339	4H.1205.01.0.00	HOSE: RADIATOR TO THERMOSTAT	Spare Part	1535	15%
2340	4H.1205.02.0.00	PUSH ROD	Spare Part	443	15%
2341	4H.1205.03.0.00	HOSE: MAKEUP WATER CONNECTION	Spare Part	705	15%
2342	4H.1205.90.0.00	ALUMINIUM RADIATOR ASSLY: 4R1040	Spare Part	56307	15%
2343	4H.1205.92.0.00	RADIATOR WITH 17" FAN	Spare Part	43073	15%
2344	4H.1210.10.0.00	WATER PUMP ASSLY 282.5 W/O PULLEY	Spare Part	12363	15%
2345	4H.1216.02.0.00	HOSE FOR BRATHER PIPE 4RT		763	15%
		BRACKET FOR SPEED ADJUSTMENT	Spare Part Spare Part	582	15%
2346	4H.122.01.0.00 4H.122.02.0.00	BAR FOR SPEED ADJUSTMENT	Spare Part	46	15%
	+				
2348	4H.1221.02.0.00	HOSE: AIR CLEANER	Spare Part	5455	15%
2349	4H.1221.04.0.00	RUBBER HOSE TURBO TO AIR CLEANER	Spare Part	4680	15%
2350	4H.1223.03.0.00	ENGINE MTG. FOOT (FIP SIDE)	Spare Part	4163	15%
2351	4H.1223.04.0.00	ENGINE MTG. FOOT (STARTER SIDE)	Spare Part	4194	15%
2352	4H.1228.01.0.00	MOUNTING PLATE FOR FUEL FILTER	Spare Part	1382	15%
2353	4H.1234.09.0.00	EMERGENCY STOP	Spare Part	1406	15%
2354	4H.1235.02.0.00	COVER FOR CAMSHAFT BORE ON GEAR CASING	Spare Part	1462	15%
2355	4H.1235.03.0.00	GEAR CASING JOINT	Spare Part	182	15%
2356	4H.1235.05.0.00	COVER JOINT	Spare Part	117	15%
2357	4H.1235.06.0.00	TIMING POINTER	Spare Part	49	15%
2358	4H.1235.08.0.00	GEAR CASING	Spare Part	9332	15%
2359	4H.1235.12.0.00	MUD SLINGER	Spare Part	249	15%
2360	4H.1235.13.0.00	JOINT FOR GEAR CASING	Spare Part	418	15%
2361	4H.1235.17.0.00	GEAR CASING	Spare Part	17067	15%
2362	4H.1247.01.0.00	LUBE OIL SUMP	Spare Part	4074	15%
2363	4H.125.60.0.00	THERMOSTAT HOSUING ASSEMBLY	Spare Part	4418	15%
2364	4H.1253.02.0.00	ADAPTOR FOR FAN	Spare Part	33929	15%
2365	4H.1266.01.0.00	FULE PIPE - FULE PUMP TO FUEL FILTER (475 HOSE LENGTH)	Spare Part	1262	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		·		without Vat in NPR	Charge%
2366	4H.1266.02.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	929	15%
2367	4H.1268.05.0.00	CURRENT TRANSFARMOR 100/5, 5 VA	Spare Part	2080	15%
2368	4H.1269.01.0.00	V BELT	Spare Part	963	15%
2369	4H.1274.10.0.00	FLYWHEEL ASSEMBLY	Spare Part	17378	15%
2370	4H.1284.05.0.00	FRONT COVER	Spare Part	2406	15%
2371	4H.1284.07.0.00	COVER FOR FUEL PUMP GEAR	Spare Part	3003	15%
2372	4H.1284.09.0.00	FUEL PUMP GEAR	Spare Part	3465	15%
2373	4H.1284.11.0.00	HUB FOR FUEL PUMP GEAR	Spare Part	4394	15%
2374	4H.1285.04.0.00	ADAPTOR FOR FUEL TANK BREATHER WITH M12 x 1.5 BOTH SIDE	Spare Part	151	15%
2375	4H.1285.07.0.00	LUB OIL SUMP DRAIN PIPE S F NEW LUB OIL HAND PUMP	Spare Part	1151	15%
2376	4H.1285.43.0.00	BUSH FOR AVM LOCKING	Spare Part	89	15%
2377	4H.1288.01.0.00	FLYWHEEL HOUSING	Spare Part	33073	15%
2378	4H.129.02.0.00	EXHAUST M'FOLD: K26 TURBOCHARGER	Spare Part	4837	15%
2379	4H.129.03.0.00	HEXAGONAL SOCKET HEAD CAP SCREW (COPPER COATED)	Spare Part	62	15%
2380	4H.1295.01.0.00	CRANK PULLEY: S/F 172 PCD 1GR	Spare Part	6772	15%
2381	4H.1295.02.0.00	MUD SLINGER S/F 4H.1295.01 CRANK PULLEY	Spare Part	178	15%
2382	4H.1295.11.0.00	PULLEY: CRANK 4R1040 JCB ENG	Spare Part	5945	15%
2383	4H.1295.14.0.00	CRANKSHAFT PULLEY S/F GEAR CASING (6PK 143 PCD)	Spare Part	4255	15%
2384	4H.1296.01.0.00	PULLEY: ALTERNATOR 68 PCD	Spare Part	886	15%
2385	4H.1297.01.0.00	WATER PUMP PULLEY: 120PCD	Spare Part	2105	15%
2386	4H.1298.01.0.00	ALTERNATOR PULLEY: 90 PCD A SEC	Spare Part	1302	15%
2387	4H.130.03.0.00	EXHAUST DIFFUSER	Spare Part	1680	15%
2388	4H.130.04.0.00	BRACKET FOR EXHAUST DIFFUSER	Spare Part	954	15%
2389	4H.130.05.0.00	SWIVEL ADAPTOR	Spare Part	871	15%
2390	4H.130.06.0.00	ADAPTOR RING ON K26 TURBOCHARGER	Spare Part	1028	15%
2391	4H.130.07.0.00	JOINT SS: ADAPTOR RING	Spare Part	455	15%
2392	4H.1301.10.0.00	CRANKCASE WITHOUT BEARINGS	Spare Part	186158	15%
2393	4H.1301.110.0.PR	CRANKCASE ASSLY WITH MB CAP 4K1080 4V	Spare Part	173013	15%
2394	4H.1301.110.0.SP	CRANKCASE ASSLY WITH MB CAP (4K1080 4V) (4H.1301.110.0.PR)	Spare Part	164773	15%
2395	4H.1301.60.0.00	CRANKCASE MONOBLOCK WITH SEALING CAP	Spare Part	172693	15%
2396	4H.1301.90.0.00	PISTON COOLING NOZZLE	Spare Part	560	15%
2397	4H.1302.10.0.00	CRANKSHAFT ASSLY	Spare Part	97706	15%
2398	4H.1308.02.0.00	F 002 AOZ 637 FUEL PUMP 4R1040TC 105 HP 2200 RPM	Spare Part	81568	15%
2399	4H.1308.03.0.00	FUEL PUMP 4R1040TC 110 HP 2500 RPM F 002 AOZ 638	Spare Part	78977	15%
2400	4H.1308.04.0.00	F 002 AOZ 629 FUEL PUMP 4R1040TC 90 HP 2200 RPM MICO NUMBER	Spare Part	74368	15%
2401	4H.1308.06.0.00	FUEL PUMP 4R1040TC 96 HP @ 2200 RPM	Spare Part	73494	15%
2402	4H.1308.09.0.00	TURBOCHARGER: K24	Spare Part	70867	15%
2403	4H.1308.16.0.PR	FUEL INJECTION PUMP FOR 4R1040T ENGINE (105HP @ 2200RPM) FOR SMOKE REDUCTION (BQ	Spare Part	117094	15%
2404	4H.131.01.0.00	AIR DELIVERY PIPE	Spare Part	12901	15%
2405	4H.131.02.0.00	SLEEVE	Spare Part	849	15%
	4H.131.03.0.00	BRACKET FOR AIR DELIVERY PIPE	Spare Part	1674	15%
2407	4H.131.04.0.00	HEAT SHIELD	Spare Part	837	15%
2408	4H.1318.01.0.00	HOSE: RADIATOR INLET	Spare Part	772	15%
2409	4H.1319.01.0.00	INJECTOR S-TYPE (5X0.284X150X13 , 950 HTF; NHA NO. E043 2252 00)	Spare Part	4363	15%
2410	4H.1319.03.0.00	INJECTOR	Spare Part	4465	15%
2411	4H.132.02.0.00	ADAPTOR: TURBOCHARGER SIDE	Spare Part	751	15%
2412	4H.132.04.0.00	ADAPTOR: CRANKCASE SIDE	Spare Part	751	15%
2413	4H.132.21.0.00	LUBE OIL INLET PIPE: K24 TURBO	Spare Part	560	15%
2414	4H.132.23.0.00	LUBE OIL DRAIN PIPE: K24 TURBO	Spare Part	889	15%
2414	4H.132.27.0.00	JOINT: ADAPTOR TURBO SIDE	Spare Part	22	15%
	4H.132.28.0.00	JOINT: ADAPTOR TORBO SIDE	Spare Part	25	15%
2417	4H.132.29.0.00	JOINT: LUBE OIL DRAIN PIPE	Spare Part	31	15%
2417	4H.132.31.0.00	JOINT: ADAPTOR C'CASE SIDE	Spare Part	25	15%
	TI 1. 102.01.0.00	VOILLI-NEAL TOTAL OFFICE OFFI	Spare Fait	20	10%
2419	4H.132.32.0.00	ADAPTOR FOR TURBO DRAIN (CRANKCASE SIDE)	Spare Part	1040	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
			<i>,</i>	without Vat in NPR	Charge%
2421	4H.1321.02.0.PR	LEAK OFF PIPE ASSEMBLY	Spare Part	1957	15%
2422	4H.1323.20.0.00	LEAK OFF PIPE ASSLY	Spare Part	1969	15%
2423	4H.1323.30.0.00	LEAK OFF PIPE ASSLY: 4R1050TA CPCB	Spare Part	1969	15%
2424	4H.133.02.0.00	V BELT: XPA 1345 RAW EDGED COGGED	Spare Part	1046	15%
2425	4H.133.03.0.00	V BELT SPAX 1332	Spare Part	1188	15%
2426	4H.1331.07.0.00	KOEL GREEN Alternator KG 62 5 S T Frame L KG 42 3 K SAE 3 11 5 415V 50 Hz 0 8 PF	Spare Part	335017	15%
2427	4H.1331.08.0.PR	KOEL GREEN ALTERNATOR COASTAL HUMID ENVIRONMENT KG 62 5 S T FRAME KG 42 3 K 6	Spare Part	403825	15%
2428	4H.1333.01.0.00	SPACER 30 MM FOR FAN MOUNTING	Spare Part	3141	15%
2429	4H.1343.02.0.00	RUBBER HOSE HEAT EXCHANGER TO THERMOSTAT	Spare Part	255	15%
2430	4H.1343.03.0.00	HOSE H EXCHANGER TO W PUMP	Spare Part	1680	15%
2431	4H.1343.04.0.00	ADAPTOR FOR HEAT EXCHANGER	Spare Part	843	15%
2431	4H.1343.05.0.00	BRACKET FOR HEAT EXCHANGER MNTG	Spare Part	6455	15%
2433				121411	
	4H.1343.14.0.00	HEAT EXCHANGER(S/F FRESH WATER) FOR 4R1040 F.F. ENGINES	Spare Part		15%
2434	4H.1343.24.0.PR	HOSE HE TO WATER PUMP S F 3000RPM	Spare Part	1474	15%
2435	4H.1345.01.0.00	AIR CLEANER F.F. ENGINES	Filter	8042	20%
2436	4H.1345.10.0.00	AIR CLEANER ASSEMBLY S F FIRE FIGHTING	Spare Part	6825	15%
2437	4H.1346.01.0.00	AIR CLEANER F.F. ENGINES	Filter	7336	20%
2438	4H.1346.20.0.00	AIR CLEANER ASSEMBLY, S/F FIRE FIGHTING	Spare Part	8547	20%
2439	4H.1347.01.0.00	STARTER SOLENOID(DUMORE, 535-0127) 12V FOR F.F. ENGINES	Spare Part	74356	15%
2440	4H.1353.30.0.00	CLAMP FOR RAISED TYPE DIPSTICK	Spare Part	105	15%
2441	4H.1355.05.0.00	HOSE FOR WATER HEATER PIPE	Spare Part	142	15%
2442	4H.1355.13.0.00	RUBBER HOSE(FOR WATER HEATER)	Spare Part	1034	15%
2443	4H.1357.05.0.00	FUEL STOP SOLENOID ASSEMBLY	Spare Part	4572	15%
2444	4H.1357.07.0.00	FUEL STOP SOLENOID ASSEMBLY S/F 4RNA ENGINE(ELECTRAL CONTROL MAKE,INDIGENIOUS,	Spare Part	4268	15%
2445	4H.1359.22.0.PR	FUEL PIPE FROM FEED PUMP TO FUEL FILTER	Spare Part	2597	15%
2446	4H.1359.24.0.PR	FUEL PIPE FROM FUEL FILTER TO FIP	Spare Part	2542	15%
2447	4H.136.10.0.00	TURBOCHARGER	Spare Part	93916	15%
2448	4H.136.11.0.PR	TURBOCHARGER K16-2371N 5.82 FOR 4R1040TC HYUNDAI	Spare Part	71461	15%
2449	4H.136.20.0.00	TURBOCHARGER	Spare Part	90063	15%
2450	4H.1364.12.0.00	RECTIFIER DIODE BRIDGE 16AMP HIND MAKE MODEL NO HB37 02	Spare Part	8221	15%
2451	4H.1364.15.0.00	DIODE MOUDLE FOR BATTERY CHARGING 150AMP	Spare Part	29018	15%
2452	4H.1364.33.0.00	FIRE PUMP ENGINE DISPLAY CONTROLLER 12VDC	Spare Part	55205	15%
2453	4H.1364.37.0.00	SELECTOR SWITCH ASSEMBLY EATON MAKE M22 WRK A K10 K01 MAINTAINED	Spare Part	3840	15%
2454	4H.1364.38.0.00	SELECTOR SWITCH ASSEMBLY EATON MAKE M22 WK A K10 MOMENTRY	Spare Part	2305	15%
2455	4H.1364.60.0.00	INSTRUMENT CONTROL PANEL ASSEMBLY DIGITAL DISPLY 12VDC	Spare Part	200840	15%
2456	4H.1374.06.0.00	FUEL SUPPLY PIPE (FROM SUPPLY BLOCK TO FUEL PUMP)	Spare Part	357	15%
2457	4H.1375.03.0.00	FUEL SUPPLY AND RETUN BLOCK	Spare Part	1705	15%
2458	4H.1375.06.0.00	EXTENSION PIPE FOR FUEL SUPPLY	Spare Part	3683	15%
2459	4H.1375.07.0.00	EXTENSION PIPE FOR FUEL RETURN	Spare Part	2911	15%
2460	4H.1377.02.0.00	GASKET: CYLINDER HEAD 1.22 MM THK	Spare Part	4412	15%
2461	4H.1377.30.0.00	CYLINDER HEAD ASSEMBLY COMPLETE	Spare Part	76011	15%
2462	4H.138.23.0.00	PLASTIC CAP FOR WATER PUMP INLET	Spare Part	46	15%
2463	4H.1385.40.0.00	SUCTION TUBE	Spare Part	895	15%
2464	4H.1386.10.0.00	LUBE OIL SUMP ASSLY	Spare Part	6781	15%
2465	4H.1387.10.0.00	CAMSHAFT ASSY 4K ENGINE	Spare Part	28950	15%
2466	4H.1387.40.0.00	CAMSHAFT ASSY 4K ENGINE	Spare Part	32861	15%
2467	4H.1387.80.0.PR	CAMSHAFT ASSEMBLY 4K ENGINE 4V COMMON RAIL	Spare Part	23301	15%
2468	4H.1388.50.0.00	DIPSTICK ASSEMBLY	Spare Part	206	15%
2469	4H.139.30.0.00	SUB ASSEMBLY OF ROCKER COVER & BREATHER TUBE	Spare Part	6105	15%
2470	4H.1390.01.0.00	FIP: 4R1040T	Spare Part	76082	15%
2471	4H.140.01.0.00	ADAPTOR FOR BREATHER PIPE	Spare Part	960	15%
2472	4H.140.03.0.00	BREATHER PIPE	Spare Part	1378	15%
2473	4H.1410.20.0.00	RADIATOR CAP	Spare Part	118368	15%
2474	4H.1410.40.0.PR	Aluminium Radiator Assembly	Spare Part	114537	15%
2475	4H.1415.01.0.00	ADAPTOR ON HEADER	Spare Part	2458	15%



	Price to				
C:: N -	Don't November	Park Danielation	Catanami	Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
				NPR	
2476	4H.1415.02.0.00	ADAPTOR: THROTTLE CABEL MTG BKT	Spare Part	3591	15%
2477	4H.1415.03.0.00	BANJO BOLT	Spare Part	1003	15%
2478	4H.1415.04.0.00	RUBBER SLEEVE FOR HEADER (SPIN ON FILTER MOUNTING ARRENGEMENT)	Spare Part	86	15%
2479	4H.1415.05.0.00	RUBBER SLEEVE FOR HEADER (SPIN ON FILTER MOUNTING ARRENGEMENT)	Spare Part	25	15%
2480	4H.1415.06.0.00	JOINT: HEADER	Spare Part	58	15%
2481	4H.1415.07.0.00	HOSE FOR LUB OIL 960 MM BOTH ENDS STRAIGHT	Spare Part	1468	15%
2482	4H.1415.08.0.00	HOSE: LUBE OIL 1030MM ONE END 90?	Spare Part	1834	15%
2483	4H.1415.12.0.00	HOSE FOR LUBE OIL 600 MM	Spare Part	1225	15%
2484	4H.1415.13.0.00	BRACKET FOR LUB OIL FILTER MOUNTING	Spare Part	1418	15%
2485	4H.1415.16.0.00	HOSE FOR LUBE OIL - HEADER TO FILTER	Spare Part	1498	15%
2486	4H.1415.17.0.PR	OIL RETURN PIPE	Spare Part	1511	15%
2487	4H.1424.03.0.00	HOSE: MAKE UP CONNECTION	Spare Part	1055	15%
2488	4H.1425.02.0.00	HOSE: MAKE UP WATER CONNECTION	Spare Part	778	15%
2489	4H.1425.03.0.00	PIPE (THERMOSTAT TO RADIATOR)	Spare Part	2911	15%
2490	4H.1425.04.0.00	HOSE: MAKE UP WATER CONNECTION	Spare Part	1249	15%
2491	4H.1425.20.0.00	ALUMINIUM RADIATOR: 4R1040T	Spare Part	60725	15%
2492	4H.1429.01.0.00	INJECTOR	Spare Part	7997	15%
2493	4H.1429.05.0.00	INJECTOR	Spare Part	9138	15%
2494	4H.1429.10.0.00	INJECTOR	Spare Part	7209	15%
2495	4H.1429.14.0.00	INJECTOR ASSEMBLY WITH NOZZLE	Spare Part	9018	15%
2496	4H.1429.18.0.00	INJECTOR	Spare Part	9280	15%
2497	4H.1429.23.0.00	INJECTORS FOR 3R1040TA G1 CPCBII (56 hp @ 1500 RPM, NHA NO. F002 C8Z 981, NOZZLE TIP N	Spare Part	8458	15%
2498	4H.1429.26.0.PR	INJECTOR WITH VCO 5X0 190X150X13DEG 17HE 480HTF A 433 390 755 WITH 3MM INJECTOR SE	Spare Part	9009	15%
2499	4H.143.02.0.00	PACKING FOOT (FWE,STARTER SIDE)	Spare Part	720	15%
2500	4H.1432.02.0.00	VALVE SEAT INSERT -INLET	Spare Part	560	15%
2501	4H.1432.02.9.00	VALVE SEAT INSERT: INLET	Spare Part	437	15%
2502	4H.1432.03.0.00	VALVE SEAT INSERT-EXHAUST	Spare Part	560	15%
2503	4H.1432.03.9.00	VALVE SEAT INSERT: EXHAUST	Spare Part	391	15%
2504	4H.1432.30.0.00	CYLINDER HEAD ASSLY	Spare Part	83100	15%
2505	4H.1432.41.0.00	VALVE PAIR INLET & EXHAUST	Spare Part	1951	15%
2506	4H.1432.60.0.00	CYLINDER HEAD ASSLY	Spare Part	79350	15%
2507	4H.1432.90.0.00	CYLINDER HEAD RECONDITIONING KIT 4R1040 SERIES (INDL BSIII & PG ENGINE POST 2011)	Spare Part	17443	15%
2508	4H.1433.40.0.00	ROCKER SUPPORT ASSEMBLY	Spare Part	11554	15%
2509	4H.1436.01.0.00	EXHAUST MANIFOLD (4K ENGINE) CENTRAL UPWARD OPEN	Spare Part	5828	15%
2510	4H.1437.01.0.00	JOINT: TURBO	Spare Part	729	15%
2511	4H.1437.02.0.00	JOINT: ADAPTOR	Spare Part	43	15%
2512	4H.1437.04.0.00	ADAPTOR (TURBOCHARGER)	Spare Part	246	15%
2513	4H.1437.06.0.00	TURBOCHARGER	Spare Part	58608	15%
2514	4H.1437.10.0.00	TURBOCHARGER	Spare Part	57578	15%
2515	4H.1437.11.0.00	ADAPTOR FOR TURBO DRAIN	Spare Part	1068	15%
2516	4H.1437.15.0.PR	JOINT FOR TURBOCHARGER	Spare Part	969	15%
2517	4H.1437.16.0.PR	JOINT	Spare Part	1542	15%
2518	4H.1437.18.0.PR	OIL INLET PIPE	Spare Part	1129	15%
2519	4H.1437.18.0.FK	LUBE OIL DRAIN PIPE ASSEMBLY	Spare Part	655	15%
2520	4H.1437.50.0.00	LUBE OIL SUPPLY PIPE FOR TURBOCHARGER	Spare Part	837	15%
2520	4H.1437.70.0.00	LUBE OIL SUPPLY PIPE FOR TURBOCHARGER LUBE OIL SUPPLY PIPE FOR TURBOCHARGER	Spare Part	926	15%
2521				837	15%
2522	4H.1437.80.0.00 4H.1438.24.0.00	LUBE OIL DRAIN PIPE ASSEMBLY FLEXIBLE HOSE 1.1.4. RSP BOTH SIDE S.E. 6R1080TA COOLING LINE	Spare Part Spare Part	11711	15%
2523		FLEXIBLE HOSE 1.1.4 BSP BOTH SIDE S.F. 6R.1080TA COOLING LINE AVM FOR COOLING LINE MTG. S.F. 6R. SL 90			15%
	4H.1438.41.0.00	AVM FOR COOLING LINE MTG S F 6R SL90	Spare Part	686	
2525	4H.144.04.0.00	HEADER FOR LUBE OIL COOLER & SPIN ON FILTER	Spare Part	3901	15%
2526	4H.144.05.0.00	LUBE OIL COOLER -8 PLATES	Spare Part	7052	15%
2527	4H.144.06.0.00	HEADER (FOR LUBE OIL COOLER & SPIN ON FILTER) (8 & 12 PLATES)	Spare Part	6000	15%
2528	4H.144.100.0.00	LUBE OIL HEADER ASSEMBLY	Spare Part	10818	15%
2529	4H.144.60.0.00	LUBE COOLER & HEADER ASSEMBLY	Spare Part	14197	15%
2530	4H.1441.19.0.00	DRIVE SHAFT[2040] FOR FIRE FIGHTING PUMP APPLICATION	Spare Part	96606	20%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
		NUTCOTOR	0 5 1	NPR	450/
2531	4H.1454.07.0.00	INJECTOR	Spare Part	7926	15%
2532	4H.1454.13.0.00	SPECIAL STUD FOR INJECTOR	Spare Part	77	15%
2533	4H.1454.14.0.00	NUT FOR INJECTOR STUD	Spare Part	18	15%
2534	4H.1454.19.0.00	INJECTOR	Spare Part	10080	15%
2535	4H.1455.150.0.PR	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	5829	20%
2536	4H.1464.20.0.00	ENGINE WIRING HARNESS ASSEMBLY WITH 4PIN &15 PIN CONNECTOR	Spare Part	6720	15%
2537	4H.1464.30.0.00	EXTENDED HARNESS ASSEMBLY	Spare Part	6397	15%
2538	4H.1464.40.0.00	ENGINE WIRING HARNESS ASSEMBLY WITH 4PIN &15 PIN CONNECTOR	Spare Part	12668	15%
2539	4H.1464.70.0.00	ENGINE WIRING HARNESS WITH CSA UNIT WITH 420MA GEMS SENSOR	Spare Part	10584	15%
2540	4H.1465.70.0.PR	ENGINE WIRING HARNESS FOR 125KVA 4K WITH B12 ECU EMERALD	Spare Part	11606	15%
2541	4H.1475.03.0.00	ACTUATOR XADC225D1S 12 FOR FIRE FIGHTING APPLN	Spare Part	176462	15%
2542	4H.1483.11.0.00	WATER PUMP PULLEY: 100 PCD	Spare Part	2588	15%
2543	4H.1483.12.0.00	WATER PUMP AND FAN PULLEY	Spare Part	2668	15%
2544	4H.1483.15.0.00	WATER PUMP PULLEY-105 PCD, POLY V,6PK	Spare Part	3240	15%
2545	4H.1484.11.0.00	ALTERNATOR PULLEY: 56.5 PCD	Spare Part	929	15%
2546	4H.1484.12.0.00	ALTERNATOR PULLEY	Spare Part	975	15%
2547	4H.1484.15.0.00	ALTERNATOR PULLEY (59 PCD, POLY V, 6PK)	Spare Part	1588	15%
2548	4H.1484.16.0.PR	ALTERNATOR PULLEY 59 PCD POLY V 8PK	Spare Part	1277	15%
2549	4H.1488.10.0.00	ASSEMBLY FOR RAISED DIPSTICK	Spare Part	1289	15%
2550	4H.1488.40.0.00	DIPSTICK ASSEMBLY	Spare Part	2055	15%
2551	4H.1489.01.0.00	V BELT SPAX 1265	Spare Part	1625	15%
2552	4H.1491.01.0.00	EXHAUST DIFFUSER FOR CMVR TURBO S/F TEREX SERIES-II PROJECT	Spare Part	2366	15%
2553	4H.1493.01.0.00	POLY V BELT	Spare Part	1655	15%
2554	4H.1493.02.0.PR	POLY V BELT (8 PK 1215 EPDM)	Spare Part	3012	15%
2555	4H.1493.03.0.00	POLY V BELT (6PK-1190)	Spare Part	1378	15%
2556	4H.1493.07.0.PR	POLY V BELT 8PK 1148 EPDM	Spare Part	2622	15%
2557	4H.1494.25.0.PR	RAW WATER PIPE CAC TO HE	Spare Part	4105	15%
2558	4H.150.30.0.00	STOP SOLENOID ASSLY-12VDC SINGLE COIL	Spare Part	7575	15%
2559	4H.1502.10.0.00	PISTON ASSLY R1040NA CMVR STG-II	Spare Part	8735	15%
2560	4H.1519.01.0.00	TURBOCHARGER HSG: TR59 6.1	Spare Part	68454	15%
2561	4H.1519.02.0.00	TURBOCHARGER	Spare Part	69864	15%
2562	4H.1519.04.0.00	TURBOCHARGER	Spare Part	62325	15%
2563	4H.1519.05.0.00	TR59 6.1 HSG TURBOCHARGER (TEL PART NO. 5966 902 023X, ALPHA 155, BETA 45)	Spare Part	59473	15%
2564	4H.1519.10.0.00	TURBO IN LUB OIL PIPE	Spare Part	846	15%
2565	4H.1519.20.0.00	TURBO OUT LUB OIL PIPE	Spare Part	772	15%
2566	4H.1524.10.0.00	FLYWHEEL ASSEMBLY	Spare Part	14249	15%
2567	4H.1529.02.0.00	F 002 C8Z 994 INJECTOR FOR 4R 6R FMUL ENGINES	Spare Part	8295	15%
2568	4H.153.10.0.00	PISTON ASSEMBLY	Spare Part		15%
2569	4H.1534.01.0.00	ROTARY FIP: 4K1080TA 125 KVA	Spare Part	101036	15%
2570	4H.1534.11.0.00	FIP 12V SYSTEM WITH CSA	Spare Part	138269	15%
2571	4H.1534.12.0.00	4K CPCB II FIP 24V system with CSA	Spare Part		15%
2572	4H.154.10.0.00	INJECTOR	Spare Part		15%
2573		ADAPTOR FOR CRANKPULLEY, PTL	Spare Part	4163	15%
2574	4H.1542.01.0.00 4H.1543.01.0.00	EXHAUST MANIFOLD FOR K-26 TURBOCHARGER	Spare Part	4905	15%
2574	4H.1543.01.0.00 4H.1543.02.0.00	AIR PIPE TURBOCHARGER TO INLET MANIFOLD	Spare Part	2545	15%
2576	4H.1543.03.0.PR	AIR PIPE TURBO TO INLET MANIFOLD	Spare Part	4234	15% 15%
2577	4H.1543.04.0.PR	EXHAUST MANIFOLD	Spare Part	6831	
2578	4H.1546.01.0.00	BRACKET FOR REMOTE HAND PRIMER PUMP MOUNTING	Spare Part		20%
2579	4H.1547.01.0.00	ADAPTOR FOR AIR CLEANER FOR ACE	Spare Part	1412	15%
2580	4H.1548.10.0.00	FLYWHEEL ASSEMBLY	Spare Part		15%
2581	4H.1549.04.0.00	4466 MOTORPAL FIP FOR 4R1040TA 2600 2350 RPM FIREFIGHTING APPLICATION	Spare Part	369254	15%
2582	4H.156.07.0.00	SUB ASSLY SPL BANJO BOLT (FOR OIL SPRAY NOZZLE)	Spare Part	163	15%
2583	4H.156.11.0.PR	PISTON COOLING NOZZLE	Spare Part	332	15%
2584	4H.156.20.0.00	C'CASE ASSLY W/O BEARING	Spare Part	169115	15%
2585	4H.1563.01.0.00	MOUNTING BRACKET FOR ALTERNATOR	Spare Part	3160	15%



Part Number					Price to	
Mark 1983-02-0 PR MOUNTING BRACKET FOR ALTERNATOR Space Part 1506 1	Sr.No.	Part Number	Part Description	Category		Custom
3586			·			Charge%
MISSER ADDITION MISSER RADIATOR DUTIETTO WATER PAME NATET Squer Part 1900	2586	4H.1563.02.0.PR	MOUNTING BRACKET FOR ALTERNATOR	Spare Part		15%
1899 HI 1894 01.000	2587	4H.158.04.0.00	HOSE: WATER PUMP INLET TO RADIATOR OUTLET	Spare Part	1145	15%
Space Part 302	2588	4H.158.05.0.00	HOSE: RADIATOR OUTLET TO WATER PUMP INLET	Spare Part	960	15%
1999 44 190 10 0 00 1905 ART CLEAMER 594 PMT 2899 2822 44 190 20 0 00 190 50 0 00 0 00 0 00 0 00 0 00 0 00 0	2589	4H.1584.01.0.00	FLYWHEEL HOUSING SAE 3, 144.5 WIDTH	Spare Part	16172	15%
9.992	2590	4H.1590.10.0.00	FUEL PIPE ASSEMBLY SOLENID TO HEATER	Spare Part	302	15%
Space Part 1959 1	2591	4H.1591.01.0.00	HOSE: AIR CLEANER	Spare Part	2889	15%
1595	2592	4H.160.10.0.00	SUB ASSEMBLY OF ROCKER COVER & BREATHER PIPE	Spare Part	6754	15%
Space Part 1922	2593	4H.160.50.0.00	ROCKER COVER	Spare Part	7289	15%
System Part	2594	4H.1605.10.0.00	FUEL INJECTION PUMP 4R1040NA 60HP@1900RPM	Spare Part	68270	15%
1997 1419-11-10-00 DOINT-BREATHER PIPE Spare Part 132	2595	4H.161.05.0.00	BREATHER PIPE	Spare Part	1292	15%
2598	2596	4H.161.06.0.00	CLIP FOR BREATHER PIPE	Spare Part	62	15%
Separa Description Separa Description Separa Description Separa Description Separa Description Separa Description Separa Separa	2597	4H.161.11.0.00	JOINT: BREATHER PIPE	Spare Part	31	15%
	2598	4H.161.15.0.00	BEND PIPE FOR BREATHER HOSE	Spare Part	1323	15%
2000	2599	4H.161.21.0.00	BEND PIPE FOR BREATHER HOSE	Spare Part	1265	15%
2602	2600	4H.161.27.0.PR		Spare Part	1406	15%
2003 441-1613.05.0.00 VALVE SEAT INSERT; INLET Spare Part 517	2601	4H.1612.56.0.SP	SET OF JOINTS	Spare Part	4455	15%
2003 441-1613.05.0.00 VALVE SEAT INSERT; INLET Spare Part 517				•		15%
2804 44.1613.06.0.0 NJECTOR SLEEVE Spare Part 625	2603	4H.1613.05.9.00	VALVE SEAT INSERT: INLET	Spare Part	517	15%
2805		4H.1613.06.0.00	INJECTOR SLEEVE		625	15%
2606	2605		O RING FOR INJECTOR SLEEVE	•	77	15%
2607			VALVE STEM SEAL			15%
2608			VALVE CUP	•	203	15%
2600						15%
AH.1613.17.0.00 VALVE SPRING Spare Part 126						15%
AH.1613.18.0.00 VALVE BRIDGE Spare Part 625				•		15%
2612						15%
2613						15%
2614 4H.1613.37.0.PR CYLINDER HEAD GASKET MLS Spare Part 6495 2615 4H.1613.50.0.00 VALVE GUIDE & SNAP RING ASSEMBLY Spare Part 194 2616 4H.1613.50.0.00 INILET & EXHAUST VALVE PAIR Spare Part 1557 2617 4H.1614.16.0.00 PUSH ROD Spare Part 215 2618 4H.1614.21.0.00 SPACER (ID 9 X OD 14 X 9 S.L) Spare Part 108 2619 4H.1614.38.0.PR SPACER (ID 9 X OD 14 X 9 S.L) Spare Part 108 2620 4H.1614.80.0.00 VALVE ROCKER ASSEMBLY Spare Part 32458 2621 4H.1615.20.0.00 WIRING HARRESS: ENGINE TO CONTROL PANEL (STARTER SIDE) Spare Part 1594 2622 4H.1616.01.0.00 FLYWHEEL HOUSING Spare Part 6425 2623 4H.1617.02.0.00 ADAPTOR ON FLYWHEEL Spare Part 6425 2624 4H.1618.03.0.00 FLYWHEEL Spare Part 17901 2625 4H.1618.03.0.00 BAFFLE PLATE Spare Part 17901 2626 4H.1618.03.0.00 <td></td> <td></td> <td></td> <td>•</td> <td></td> <td>15%</td>				•		15%
2615 4H.1613.50.0.00 VALVE GUIDE & SNAP RING ASSEMBLY Spare Part 194 2616 4H.1613.90.0.00 INLET & EXHAUST VALVE PAIR Spare Part 1557 2617 4H.1614.16.0.00 PUSH ROD SPACER. HEAD & ROCKER BOX COVER Spare Part 108 2618 4H.1614.21.0.00 SPACER. HEAD & ROCKER BOX COVER Spare Part 108 2619 4H.1614.80.0PR SPACER (ID 9 X OD 14 X 9.5 L) Spare Part 108 2620 4H.1614.80.000 VALVE ROCKER ASSEMBLY Spare Part 32458 2621 4H.1615.20.000 WIRING HARNESS: ENGINE TO CONTROL PANEL (STARTER SIDE) Spare Part 3874 2622 4H.1616.01.000 FLYWHEEL HOUSING Spare Part 15194 2623 4H.1617.10.0.00 FLYWHEEL HOUSING Spare Part 16425 2624 4H.1618.01.0.00 FLYWHEEL HOUSING Spare Part 16427 2625 4H.1618.01.0.00 FLYWHEEL Spare Part 16427 2626 4H.1618.01.0.00 BAFFLE PLATE Spare Part 2243 2626 4H.1619.02.0.00 ASSEMBLY SUCTION TUBE Spare Part 2243 2627 4H.1619.02.0.00 ASSEMBLY SUCTION TUBE Spare Part 2880 2628 4H.1621.02.0.00 FAN SPACER 60 MM Spare Part 2880 2629 4H.1622.02.0.0PR LO DRAIN PIPE Spare Part 1988 2630 4H.1622.02.0.0PR LO DRAIN PIPE Spare Part 1988 2631 4H.1622.02.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 1003 2631 4H.1622.03.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 102 2632 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER Spare Part 13948 2633 4H.1622.03.0.00 GROMMET (FOR ROCKER COVER Spare Part 13948 2633 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER Spare Part 1597 2636 4H.1625.21.0.00 ROCKER BOX Spare Part 1597 2637 4H.1625.21.0.00 OR ROCKER COVER Spare Part 1597 2638 4H.1625.21.0.00 OR ROCKER COVER Spare Part 1598 2638 4H.1625.21.0.00 OR ROCKER COVER Spare Part 1598 2638 4H.1625.21.0.00 OR ROCKER COVER Spare Part 1598 2639 4H.1625.21.0.00 OR ROCKER COVER Spare Part 1598 2630 4H.1625.21.0.00 OR ROCKER COVE						15%
2616				•		15%
2617						15%
2618 4H.1614.21.0.00 SPACER: HEAD & ROCKER BOX COVER Spare Part 108 2619 4H.1614.38.0.PR SPACER (ID 9 X OD 14 X 9.5 L) Spare Part 108 2620 4H.1614.80.0.00 VALVE ROCKER ASSEMBLY Spare Part 32456 2621 4H.1616.20.0.00 WIRING HARNESS: ENGINE TO CONTROL PANEL (STARTER SIDE) Spare Part 3874 2622 4H.1616.01.0.00 FLYWHEEL HOUSING Spare Part 15194 2623 4H.1617.02.0.00 ADAPTOR ON FLYWHEEL Spare Part 6425 2624 4H.1618.01.0.00 FLYWHEEL Spare Part 16427 2625 4H.1618.03.0.00 BAFFLE PLATE Spare Part 17901 2626 4H.1618.03.0.00 BAFFLE PLATE Spare Part 2243 2627 4H.1619.03.0.00 FAN SPACER 60 MM Spare Part 2080 2628 4H.1621.03.0.00 FAN SPACER 60 MM Spare Part 1988 2630 4H.1622.03.0.00 SPACER FOR FAN (50 MM) Spare Part 1988 2630 4H.1622.03.0.00 ADAPTO				•	-	15%
2619						15%
2620						15%
2621 4H.1615.20.0.00 WIRING HARNESS: ENGINE TO CONTROL PANEL (STARTER SIDE) Spare Part 3874 2622 4H.1616.01.0.00 FLYWHEEL HOUSING Spare Part 15194 2623 4H.1617.02.0.00 ADAPTOR ON FLYWHEEL Spare Part 6425 2624 4H.1617.10.0.00 FLYWHEEL Spare Part 15427 2625 4H.1618.01.0.00 LUBE OIL SUMP Spare Part 17901 2626 4H.1618.03.0.00 BAFFLE PLATE Spare Part 2243 2627 4H.1619.20.0.00 ASSEMBLY SUCTION TUBE Spare Part 285 2628 4H.1621.02.0.00 FAN SPACER 60 MM Spare Part 2080 2629 4H.1621.03.0.00 SPACER FOR FAN (50 MM) Spare Part 1988 2630 4H.1622.03.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 994 2631 4H.1622.03.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 538 2633 4H.1622.05.0.00 HEAD MACHINED FOR BOLT 50.003.08.020 - Hyundai Project Spare Part 102 2634 4H.1622.05.0.00 GROMMET (FOR ROCKER COVER) Spare Part 129				•		15%
2622 4H.1616.01.0.00 FLYWHEEL HOUSING Spare Part 15194 2623 4H.1617.02.0.00 ADAPTOR ON FLYWHEEL Spare Part 6425 2624 4H.1617.10.0.00 FLYWHEEL Spare Part 16427 2625 4H.1618.01.0.00 LUBE OIL SUMP Spare Part 17901 2626 4H.1618.03.0.00 BAFFLE PLATE Spare Part 2243 2627 4H.1619.20.0.00 ASSEMBLY SUCTION TUBE Spare Part 585 2628 4H.1621.02.0.00 FAN SPACER 60 MM Spare Part 2080 2629 4H.1621.03.0.00 SPACER FOR FAN (50 MM) Spare Part 1988 2630 4H.1622.03.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 1003 2631 4H.1622.03.0.00 ADAPTOR ASSLY FOR BOLT 50.003.08.020 - Hyundai Project Spare Part 538 2633 4H.1624.02.0.00 ROCKER BOX Spare Part 102 2634 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER) Spare Part 129 2635 4H.1625.03.0.00 BAFFLE PLATE						15%
2623 4H.1617.02.0.00 ADAPTOR ON FLYWHEEL Spare Part 6425 2624 4H.1617.10.0.00 FLYWHEEL Spare Part 16427 2625 4H.1618.01.0.00 LUBE OIL SUMP Spare Part 17901 2626 4H.1618.03.0.00 BAFFLE PLATE Spare Part 2243 2627 4H.1619.20.0.00 ASSEMBLY SUCTION TUBE Spare Part 585 2628 4H.1621.02.0.00 FAN SPACER 60 MM Spare Part 2080 2629 4H.1621.03.0.00 SPACER FOR FAN (50 MM) Spare Part 1988 2630 4H.1622.02.0.PR L O DRAIN PIPE Spare Part 1003 2631 4H.1622.03.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 994 2632 4H.1622.04.0.00 LO DRAIN PIPE ASSEMBLY Spare Part 538 2633 4H.1622.05.0.00 HEAD MACHINED FOR BOLT 50.003.08.020 - Hyundai Project Spare Part 102 2634 4H.1624.02.0.00 ROCKER BOX Spare Part 13948 2635 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER				•		15%
2624 4H.1617.10.0.00 FLYWHEEL Spare Part 16427 2625 4H.1618.01.0.00 LUBE OIL SUMP Spare Part 17901 2626 4H.1618.03.0.00 BAFFLE PLATE Spare Part 2243 2627 4H.1619.20.0.00 ASSEMBLY SUCTION TUBE Spare Part 585 2628 4H.1621.02.0.00 FAN SPACER 60 MM Spare Part 2080 2629 4H.1621.03.0.00 SPACER FOR FAN (50 MM) Spare Part 1988 2630 4H.1622.02.0.PR L O DRAIN PIPE Spare Part 1003 2631 4H.1622.03.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 994 2632 4H.1622.04.0.00 LO DRAIN PIPE ASSEMBLY Spare Part 538 2633 4H.1622.05.0.00 HEAD MACHINED FOR BOLT 50.003.08.020 - Hyundai Project Spare Part 102 2634 4H.1624.02.0.00 ROCKER BOX Spare Part 129 2635 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER) Spare Part 129 2636 4H.1625.30.00 BAFFLE PLATE	2623	4H.1617.02.0.00	ADAPTOR ON FLYWHEEL		6425	15%
2625 4H.1618.01.0.00 LUBE OIL SUMP Spare Part 17901 2626 4H.1618.03.0.00 BAFFLE PLATE Spare Part 2243 2627 4H.1619.20.0.00 ASSEMBLY SUCTION TUBE Spare Part 585 2628 4H.1621.02.0.00 FAN SPACER 60 MM Spare Part 2080 2629 4H.1621.03.0.00 SPACER FOR FAN (50 MM) Spare Part 1988 2630 4H.1622.02.0.PR L O DRAIN PIPE Spare Part 1003 2631 4H.1622.03.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 994 2632 4H.1622.04.0.00 LO DRAIN PIPE ASSEMBLY Spare Part 538 2633 4H.1622.05.0.00 HEAD MACHINED FOR BOLT 50.003.08.020 - Hyundai Project Spare Part 102 2634 4H.1624.02.0.00 ROCKER BOX Spare Part 129 2635 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER) Spare Part 15917 2636 4H.1625.23.0.00 BAFFLE PLATE Spare Part 2535 2638 4H.1625.26.0.00 O RING FOR ROCKE						15%
2626 4H.1618.03.0.00 BAFFLE PLATE Spare Part 2243 2627 4H.1619.20.0.00 ASSEMBLY SUCTION TUBE Spare Part 585 2628 4H.1621.02.0.00 FAN SPACER 60 MM Spare Part 2080 2629 4H.1621.03.0.00 SPACER FOR FAN (50 MM) Spare Part 1988 2630 4H.1622.02.0.PR L O DRAIN PIPE Spare Part 1003 2631 4H.1622.03.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 994 2632 4H.1622.03.0.00 ADAPTOR ASSEMBLY Spare Part 538 2633 4H.1622.05.0.00 HEAD MACHINED FOR BOLT 50.003.08.020 - Hyundai Project Spare Part 102 2634 4H.1624.02.0.00 ROCKER BOX Spare Part 13948 2635 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER) Spare Part 129 2636 4H.1625.23.0.00 BAFFLE PLATE Spare Part 2535 2638 4H.1625.26.0.00 O RING FOR ROCKER COVER Spare Part 428 2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
2627 4H.1619.20.0.00 ASSEMBLY SUCTION TUBE Spare Part 585 2628 4H.1621.02.0.00 FAN SPACER 60 MM Spare Part 2080 2629 4H.1621.03.0.00 SPACER FOR FAN (50 MM) Spare Part 1988 2630 4H.1622.02.0.PR L O DRAIN PIPE Spare Part 1003 2631 4H.1622.03.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 994 2632 4H.1622.04.0.00 LO DRAIN PIPE ASSEMBLY Spare Part 538 2633 4H.1622.05.0.00 HEAD MACHINED FOR BOLT 50.003.08.020 - Hyundai Project Spare Part 102 2634 4H.1624.02.0.00 ROCKER BOX Spare Part 13948 2635 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER) Spare Part 129 2636 4H.1625.11.0.00 ROCKER COVER Spare Part 2535 2638 4H.1625.23.0.00 BAFFLE PLATE Spare Part 428 2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
2628 4H.1621.02.0.00 FAN SPACER 60 MM Spare Part 2080 2629 4H.1621.03.0.00 SPACER FOR FAN (50 MM) Spare Part 1988 2630 4H.1622.02.0.PR L O DRAIN PIPE Spare Part 1003 2631 4H.1622.03.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 994 2632 4H.1622.04.0.00 LO DRAIN PIPE ASSEMBLY Spare Part 538 2633 4H.1622.05.0.00 HEAD MACHINED FOR BOLT 50.003.08.020 - Hyundai Project Spare Part 102 2634 4H.1624.02.0.00 ROCKER BOX Spare Part 13948 2635 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER) Spare Part 129 2636 4H.1625.11.0.00 ROCKER COVER Spare Part 15917 2637 4H.1625.23.0.00 BAFFLE PLATE Spare Part 2535 2638 4H.1625.27.0.00 O RING FOR ROCKER COVER Spare Part 428 2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
2629 4H.1621.03.0.00 SPACER FOR FAN (50 MM) Spare Part 1988 2630 4H.1622.02.0.PR L O DRAIN PIPE Spare Part 1003 2631 4H.1622.03.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 994 2632 4H.1622.04.0.00 LO DRAIN PIPE ASSEMBLY Spare Part 538 2633 4H.1622.05.0.00 HEAD MACHINED FOR BOLT 50.003.08.020 - Hyundai Project Spare Part 102 2634 4H.1624.02.0.00 ROCKER BOX Spare Part 13948 2635 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER) Spare Part 129 2636 4H.1625.11.0.00 ROCKER COVER Spare Part 15917 2637 4H.1625.23.0.00 BAFFLE PLATE Spare Part 2535 2638 4H.1625.26.0.00 O RING FOR ROCKER COVER Spare Part 428 2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
2630 4H.1622.02.0.PR L O DRAIN PIPE Spare Part 1003 2631 4H.1622.03.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 994 2632 4H.1622.04.0.00 LO DRAIN PIPE ASSEMBLY Spare Part 538 2633 4H.1622.05.0.00 HEAD MACHINED FOR BOLT 50.003.08.020 - Hyundai Project Spare Part 102 2634 4H.1624.02.0.00 ROCKER BOX Spare Part 13948 2635 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER) Spare Part 129 2636 4H.1625.11.0.00 ROCKER COVER Spare Part 15917 2637 4H.1625.23.0.00 BAFFLE PLATE Spare Part 2535 2638 4H.1625.26.0.00 O RING FOR ROCKER COVER Spare Part 428 2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
2631 4H.1622.03.0.00 ADAPTOR ASSLY FOR TURBO DRAIN Spare Part 994 2632 4H.1622.04.0.00 LO DRAIN PIPE ASSEMBLY Spare Part 538 2633 4H.1622.05.0.00 HEAD MACHINED FOR BOLT 50.003.08.020 - Hyundai Project Spare Part 102 2634 4H.1624.02.0.00 ROCKER BOX Spare Part 13948 2635 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER) Spare Part 129 2636 4H.1625.11.0.00 ROCKER COVER Spare Part 15917 2637 4H.1625.23.0.00 BAFFLE PLATE Spare Part 2535 2638 4H.1625.26.0.00 O RING FOR ROCKER COVER Spare Part 428 2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
2632 4H.1622.04.0.00 LO DRAIN PIPE ASSEMBLY Spare Part 538 2633 4H.1622.05.0.00 HEAD MACHINED FOR BOLT 50.003.08.020 - Hyundai Project Spare Part 102 2634 4H.1624.02.0.00 ROCKER BOX Spare Part 13948 2635 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER) Spare Part 129 2636 4H.1625.11.0.00 ROCKER COVER Spare Part 15917 2637 4H.1625.23.0.00 BAFFLE PLATE Spare Part 2535 2638 4H.1625.26.0.00 O RING FOR ROCKER COVER Spare Part 428 2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
2633 4H.1622.05.0.00 HEAD MACHINED FOR BOLT 50.003.08.020 - Hyundai Project Spare Part 102 2634 4H.1624.02.0.00 ROCKER BOX Spare Part 13948 2635 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER) Spare Part 129 2636 4H.1625.11.0.00 ROCKER COVER Spare Part 15917 2637 4H.1625.23.0.00 BAFFLE PLATE Spare Part 2535 2638 4H.1625.26.0.00 O RING FOR ROCKER COVER Spare Part 428 2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
2634 4H.1624.02.0.00 ROCKER BOX Spare Part 13948 2635 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER) Spare Part 129 2636 4H.1625.11.0.00 ROCKER COVER Spare Part 15917 2637 4H.1625.23.0.00 BAFFLE PLATE Spare Part 2535 2638 4H.1625.26.0.00 O RING FOR ROCKER COVER Spare Part 428 2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
2635 4H.1625.03.0.00 GROMMET (FOR ROCKER COVER) Spare Part 129 2636 4H.1625.11.0.00 ROCKER COVER Spare Part 15917 2637 4H.1625.23.0.00 BAFFLE PLATE Spare Part 2535 2638 4H.1625.26.0.00 O RING FOR ROCKER COVER Spare Part 428 2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
2636 4H.1625.11.0.00 ROCKER COVER Spare Part 15917 2637 4H.1625.23.0.00 BAFFLE PLATE Spare Part 2535 2638 4H.1625.26.0.00 O RING FOR ROCKER COVER Spare Part 428 2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
2637 4H.1625.23.0.00 BAFFLE PLATE Spare Part 2535 2638 4H.1625.26.0.00 O RING FOR ROCKER COVER Spare Part 428 2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
2638 4H.1625.26.0.00 O RING FOR ROCKER COVER Spare Part 428 2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
2639 4H.1625.27.0.00 DOME NUT Spare Part 157						15%
						15%
2640 4H.1626.03.0.00 SPHERICAL WASHER Spare Part 77						15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
2641	4H.1626.05.0.00	NOZZLE CLAMP	Spare Part	1185	15%
2642	4H.1629.03.0.00	JOINT: AIR INLET MANIFOLD	Spare Part	342	15%
2643	4H.1629.04.0.00	INLET MANIFOLD	Spare Part	10504	15%
2644	4H.1630.02.0.00	GASKET FOR EXHAUST MANIFOLD	Spare Part	132	15%
2645	4H.1630.07.0.00	EXHAUST MANIFOLD	Spare Part	7203	15%
2646	4H.1636.01.0.00	CRANKSHAFT PULLEY	Spare Part	4357	15%
2647	4H.1637.01.0.00	PULLEY FOR ALTERNATOR	Spare Part	1083	15%
2648	4H.1641.02.0.00	`O' Ring	Spare Part	108	15%
2649	4H.1641.10.0.00	THERMOSTAT & HOUSING	Spare Part	5966	15%
2650	4H.1649.06.0.00	FUEL TANK UNIT	Spare Part	3981	15%
2651	4H.1649.14.0.00	JOINT FOR COVER PLATE	Spare Part	145	15%
2652	4H.1649.21.0.00	FUEL TANK: 130 HIGH	Spare Part	2212	15%
2653	4H.1649.24.0.00	FUEL TANK S/F: 180 HIGH	Spare Part	2803	15%
2654	4H.1649.31.0.PR	FUEL TANK UNIT S F 205 EFFECTIVE TANK HEIGHT	Spare Part	4446	15%
2655	4H.1649.34.0.00	FUEL TANK UNIT S F 180 EFFECTIVE TANK HEIGHT	Spare Part	4108	15%
2656	4H.1649.37.0.00	FUEL TANK UNIT WITH 272 EFFECTIVE HEIGHT	Spare Part	4612	15%
2657	4H.1649.41.0.00	FUEL TANK UNIT 280MM	Spare Part	4105	15%
2658	4H.1649.42.0.PR	FUEL TANK UNIT S F 276 EFFECTIVE TANK HEIGHT	Spare Part	4791	15%
2659	4H.165.10.0.00	FUEL INJECTION PUMP TURBO -V.S.	Spare Part	71611	15%
2660	4H.1650.10.0.00	PISTON ASSEMBLY: GALLERY COOLED PISTON	Spare Part	11311	15%
2661	4H.1650.20.0.00	PISTON RING SET	Spare Part	3212	15%
2662	4H.1650.60.0.00	PISTON ASSEMBLY	Spare Part	12221	15%
2663	4H.1653.50.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	4566	15%
2664	4H.1658.01.0.00	LEAK OFF PIPE	Spare Part	1068	15%
2665	4H.1658.04.0.00	LEAK OFF PIPE FOR FIP & INJECTOR	Spare Part	1388	15%
2666	4H.1658.07.0.00	LEAK OFF PIPE (FOR FILTER)	Spare Part	1905	15%
2667	4H.1659.50.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	8505	15%
2668	4H.166.06.0.00	RUBBER HOSE: AIR CLEANER	Spare Part	4606	15%
2669	4H.166.08.0.00	BRACKET FOR AIR CLEANER	Spare Part	3677	15%
2670	4H.166.10.0.00	AIR CLEANER ASSLY: DRY TYPE	Spare Part	17401	20%
2671	4H.166.11.0.00	PRIMARY FILTER ELEMENT	Filter	3642	20%
2672	4H.1660.01.0.00	CLAMP FOR DIPSTICK ASSY. FOR 35 DEG INCLINATION OIL SUMP	Spare Part	206	15%
2673	4H.1660.10.0.00	DIPSTICK ASSLY	Spare Part	1222	15%
2674	4H.1661.01.0.00	CRANK PULLEY WITH POLY V GROOVE	Spare Part	8458	15%
2675	4H.1662.01.0.00	WATER PUMP PULLEY POLY V GROOVE-138 PCD	Spare Part	2668	15%
2676	4H.1662.11.0.00	WATER PUMP PULLEY : POLY V GROOVE	Spare Part	2483	15%
2677	4H.1663.01.0.00	ALTERNATOR PULLEY WITH POLY V GROOVE 90 PCD	Spare Part	1074	15%
2678	4H.1664.01.0.00	POLY V BELT	Spare Part	1705	15%
2679	4H.1664.02.0.00	V BELT SECT 6PK -1215 POLY	Spare Part	1323	15%
2680	4H.1666.05.0.00	62.5 KVA ALTERNATOR TERMINAL BOX	Spare Part	14283	15%
2681	4H.1666.06.0.00	62.5 KVA ALTERNATOR FAN	Spare Part	13243	15%
2682	4H.1666.07.0.00	62.5 KVA ALTERNATOR WOUND EXCITER STATOR	Spare Part	39836	15%
2683	4H.1666.08.0.00	62.5 KVA ALTERNATOR WOUND EXCITER ROTOR	Spare Part	33470	15%
2684	4H.1666.11.0.00	62.5 KVA ALTERNATOR DIODE BRIDGE RECTIFIER	Spare Part	20766	15%
2685	4H.1666.14.0.00	62.5 KVA ALTERNATOR NDE FLANGE	Spare Part	26369	15%
2686	4H.1666.15.0.00	62.5 KVA ALTERNATOR COUPLING DISC ASSLY	Spare Part	8197	15%
2687	4H.1666.16.0.00	SPACE HEATER KIT	Spare Part	15492	15%
2688	4H.167.01.0.00	BRACKET FOR EXHAUST DIFFUSER	Spare Part	658	15%
2689	4H.167.02.0.00	ADAPTOR RING ON K24 TURBOCHARGER	Spare Part	988	15%
2690	4H.167.03.0.00	JOINT: ADAPTOR RING	Spare Part	108	15%
		DIPSTICK BRACKET S F JCB	Spare Part	126	15%
2691	4H.1678.02.0.00	AIR DELIVERY PIPE		7575	15%
2692	4H.168.01.0.00		Spare Part		15%
2693	4H.168.03.0.00 4H.168.11.0.00	RUBBER HOSE: COMPRESSOR OUTLET- K24 TURBO RUBBER HOSE	Spare Part Spare Part	2025	15%
2694	i⇔i⊒ ioo II U UU	I NUDDEN HUSE	i spare Part	754	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer	Custom
31.110.	rait Number	rait Description	category	without Vat in	Charge%
2696	4H.1684.18.0.00	COLD STARTING KIT	Spare Part	NPR 9861	15%
2697	4H.1684.60.0.00	ENGINE HEATER WIRING KIT	Spare Part	8834	15%
2698	4H.1684.71.0.SP	4K ENGINE COLD STARTING KIT	Spare Part	26378	15%
2699	4H.1686.50.0.00	ASSEMBLY FOR 4K ENGINE HEATER KIT	Spare Part	7809	15%
2700	4H.1686.60.0.PR	4K AIR HEATER WIRING HARNESS	Spare Part	11477	15%
2701	4H.169.01.0.00	INLET CAP (76 DIA PIPE)	Spare Part	1132	15%
2702	4H.169.10.0.00	AIR CLEANER ASSEMBLY	Spare Part	16129	20%
2703	4H.1696.80.0.PR	CONTROL PANEL SCHEMATIC FOR 82 5KVA 3PH WITH KG645 IP A	Spare Part	87934	15%
2704	4H.1696.90.0.PR	CONTROL PANEL SCHEMATIC FOR 82 5KVA 3PH WITH KG640 IP A	Spare Part	87934	15%
2705	4H.1697.10.0.PR	AMF (STANDARD) PANEL OF 82.5KVA 3PH FOR EMERALD	Spare Part	126091	15%
2706	4H.170.04.0.00	LIFTING HOOK	Spare Part	640	15%
2707	4H.1705.02.0.00	ROTARY FIP: 4R1040TC 76 HP @ 2200 RPM	Spare Part	95337	15%
2708	4H.1705.04.0.00	JOINT FOR ROTARY FIP	Spare Part	49	15%
2709	4H.1705.08.0.00	ROTARY FIP: 4R1040TC 76 HP @ 2200 RPM	Spare Part	86922	15%
2710	4H.1706.01.0.00	CHARGING ALTERNATOR	Spare Part	21938	15%
2711	4H.1706.11.0.PR	CHARGING ALTERNATOR SEALED TYPE 12 14V 90A	Spare Part	35775	15%
	4H.1706.12.0.PR	PULLEY 65 PCD SPA V SECTION FOR SEALED ALTERNATOR	Spare Part	2889	15%
2713	4H.1706.13.0.PR	PULLEY 68 PCD POLY V 6PK FOR SEALED ALTERNATOR	Spare Part	2975	15%
2714	4H.1707.10.0.00	ROTARY FIP 4R1040TA2 96 HP @ 2200 RPM	Spare Part	88614	15%
2715	4H.1708.20.0.00	ROTARY FIP :4R1040TA3 105 HP @ 2200 RPM	Spare Part	91079	15%
2716	4H.1710.10.0.00	FAN: 494 DIA 30 DEG	Spare Part	16237	15%
	4H.1710.20.0.00	FAN: 494 DIA 30 DEG	Spare Part	16640	15%
2718	4H.1711.12.0.00	FUEL RETURN LINE NRV ADAPTOR TYPE II	Spare Part	126	15%
2719	4H.1712.02.0.00	AIR PIPE(TURBOCHARGER TO CAC)	Spare Part	6846	15%
2720	4H.1712.03.0.00	AIR PIPE(CAC TO AIR INLET)	Spare Part	10286	15%
2721	4H.1712.07.0.00	HOSE: MAKE UP CONNECTION	Spare Part	1474	15%
2722	4H.1712.09.0.00	STAY ROD: RADIATOR	Spare Part	794	15%
2723	4H.1712.11.0.00	VENT PIPE:RADIATOR	Spare Part	403	15%
2724	4H.1712.15.0.00	AIR DELIVERY BEND	Spare Part	3394	15%
2725	4H.1712.18.0.00	HOSE: AIR PIPE -TC TO CAC	Spare Part	6172	15%
2726	4H.1712.22.0.00	BRACKET FOR AIR PIPE	Spare Part	978	15%
2727	4H.1712.23.0.00	BRACKET FOR GAS OUTLET MANIFOLD	Spare Part	2446	15%
2728	4H.1712.24.0.00	HOSE T-BOLT CLAMP	Spare Part	295	15%
2729	4H.1712.28.0.00	AIR PIPE (RADIATOR TO BEND PIPE)	Spare Part	10363	15%
2730	4H.1712.29.0.00	BRACKET FOR CAC PIPE	Spare Part	929	15%
2731	4H.1712.31.0.00	HOSE: RADIATOR OUTLET TO WATER PUMP INLET	Spare Part	1200	15%
	4H.1712.32.0.00	CAC HOSE (HOT SIDE 4 PLIES)	Spare Part	3760	15%
	4H.1712.33.0.00	CAC HOSE COLD SIDE	Spare Part	3468	15%
2734	4H.1712.36.0.00	BRACKET FOR CAC PIPE SUPPORT	Spare Part	1222	15%
2735	4H.1712.39.0.00	CAC HOSE (COLD SIDE)	Spare Part	3683	15%
2736	4H.1713.03.0.00	LUBE OIL DRAIN PIPE FROM PUMP TO BASE PLATE	Spare Part	2062	15%
	4H.1713.04.0.00	DRAIN PIPE FROM SUMP TO HAND PUMP	Spare Part	486	15%
2738	4H.1714.05.0.00	PIPE-THERMOSTAT TO RADIATOR	Spare Part	1480	15%
2739	4H.1714.06.0.00	HOSE: RADIATOR TO WATER PUMP	Spare Part	2495	15%
2740	4H.1714.07.0.00	PIPE (THERMOSTAT TO RADIATOR INLET)	Spare Part	1634	15%
2740	4H.1715.01.0.00	EXPANSION BELLOW	Spare Part	14028	15%
	4H.1715.04.0.00	EXPANSION BELLOW	Spare Part	13544	15%
2743	4H.1715.05.0.00	EXPANSION BELLOW	Spare Part	13108	15%
2744	4H.1716.01.0.00	ANTI VIBRATION MOUNTS	Spare Part	2034	15%
2745	4H.1716.02.0.00	ANTI VIBRATION MOUNTS	Spare Part	2360	15%
2746	4H.1717.02.0.00	SPACER FOR FAN (40MM)	Spare Part	2089	15%
	4H.1717.02.0.00 4H.1717.03.0.00	FAN ASSLY: 26" PUSHER	Spare Part	31609	15%
2748	4H.1717.07.0.00	SPACER FOR FAN	Spare Part	3415	15%
2749	4H.1718.02.0.00	PIPE RADIATOR TO WATER PUMP	Spare Part	1834	15%
2149	-11.17.10.02.0.00	THE TABLETON TO WATERT OWIF	Spare Part	1034	15%



Sr.No. 2751	Part Number			Customer	
2751		Part Description	Category	Customer	Custom
2751		·		without Vat in NPR	Charge%
	4H.1718.08.0.00	BREATHER HOSE	Spare Part	1274	15%
2752	4H.1719.01.0.00	ROTARY FIP: 4R1040TA1 90 HP @ 2200 RPM	Spare Part	85494	15%
2753	4H.1720.01.0.00	ACTUATOR WITH SPRING	Spare Part	21169	15%
2754	4H.1720.02.0.00	ECU: 4K1080TA-125 KVA	Spare Part	16338	15%
2755	4H.1720.05.0.00	ACTUATOR WITH REVERSE SPRING	Spare Part	23504	15%
2756	4H.1720.12.0.00	ECU WITH CSA OUTPUT	Spare Part	18704	15%
2757	4H.1724.10.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	28412	15%
2758	4H.1724.20.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	30504	15%
2759	4H.1729.01.0.00	ROTARY FIP: 4R1040TA4 110 HP @ 2500 RPM	Spare Part	90977	15%
2760	4H.1738.30.0.PR	AMF STANDARD PANEL OF 125KVA 3PH FOR EMERALD	Spare Part	180595	15%
2761	4H.1738.70.0.PR	CONTROL PANEL SCHEMATIC FOR 125KVA 3PH WITH KG645 IP A	Spare Part	105217	15%
2762	4H.1738.75.0.PR	CONTROL PANEL SCHEMATIC FOR 4K 125KVA WITH CSA UNIT	Spare Part	106946	15%
2763	4H.174.02.0.00	ADAPTOR FOR AIR CLEANER	Spare Part	812	15%
2764	4H.1744.01.0.00	POLY V BELT : 6PK 1230	Spare Part	1714	15%
2765	4H.1745.01.0.00	CRANKSHAFT PULLEY 6PK 145 PCD	Spare Part	6677	15%
2766	4H.1746.01.0.00	CRANK PULLEY: POLY V GROOVE	Spare Part	4508	15%
	4H.1747.01.0.00	WATER PUMP PULLEY: V GROOVE	Spare Part	2342	15%
2768	4H.1748.01.0.00	ALTERNATOR PULLEY: POLY V GROOVE	Spare Part	1135	15%
2769	4H.1749.01.0.00	CRANK PULLEY: POLY V GROOVE	Spare Part	5437	15%
2770	4H.1750.01.0.00	ALTERNATOR PULLEY: POLY V GROOVE	Spare Part	1025	15%
	4H.1755.01.0.00	CRANK SHAFT PULLEY WITH POLY V GROOVE (P6PK172)	Spare Part	7865	15%
	4H.178.02.0.00	GEAR CASING	Spare Part	16357	15%
	4H.178.07.0.00	MUD SLINGER (BOTTOM SIDE)	Spare Part	157	15%
	4H.1787.04.0.00	BRACKET FOR SILENCER	Spare Part	2286	15%
	4H.1787.05.0.00	HOSE: AIR CLEANER	Spare Part	4095	15%
	4H.1788.05.0.00	HOSE: AIR CLEANER	Spare Part	4428	15%
	4H.179.02.0.00	FRONT COVER	Spare Part	5311	15%
	4H.179.04.0.00	MUD SLINGER TOP SIDE	Spare Part	182	15%
	4H.1790.10.0.00	ENGINE WIRING HARNESS: KG934	Spare Part	5800	15%
	4H.1790.60.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	4298	15%
	4H.1790.70.0.00	PANEL TO ENGINE WIRING HARNESS	Spare Part	5191	15%
	4H.1791.10.0.00	WIRING HARNESS ASSLY: 4RCPCB	Spare Part	4277	15%
	4H.1791.60.0.00	WIRING HARNESS ASSLY: SURGE SUPPRESS	Spare Part	11714	15%
	4H.1792.01.0.00	EXHAUST MANIFOLD	Spare Part	6197	15%
	4H.1793.01.0.00	CROSS MEMBER FOR RADIATOR SUPPORT	Spare Part	4791	15%
	4H.1795.10.0.00	LUBE OIL SUPPLY PIPE ASSLY	Spare Part	988	15%
	4H.1795.20.0.00	LUBE OIL DRAIN PIPE ASSEMBLY	Spare Part	477	15%
2788	4H.1796.05.0.00	HOSE: PRE CLEAN TO AIR CLEAN BSIII	Spare Part	2037	15%
	4H.1796.10.0.00	AIR CLEANER ASSLY 8 m3/MIN	Spare Part	12818	20%
	4H.1797.01.0.00	SILENCER	Spare Part	14732	15%
	4H.1797.02.0.00	TAIL PIPE FOR EXHAUST SILENCER OF 76 HP 2200 RPM BS III ENGINE	Spare Part	5135	15%
	4H.1799.02.0.00	BRACKET FOR ACCELERATOR & STOP CABLE MOUNTING	Spare Part	1034	15%
	4H.180.10.0.00	PISTON ASSEMBLY	Spare Part	8591	15%
	4H.180.120.0.00	PISTON ASSEMBLY	Spare Part	7501	15%
	4H.180.15.0.00	PISTON ASSEMBLY COMPLETE	Spare Part	9415	15%
	4H.1800.01.0.00	HOSE: WATER PUMP TO RADIATOR	Spare Part	2766	15%
	4H.181.10.0.00	CRANKSHAFT ASSLY WITH GEAR	Spare Part	97777	15%
	4H.181.30.0.00	CRANKSHAFT ASSEMBLY	Spare Part	97156	15%
	4H.1810.01.0.00	AIR CLEANER SAFETY ELEMENT	Filter	2246	20%
	4H.1810.02.0.00	AIR CLEANER PRIMARY ELEMENT	Filter	6290	20%
	4H.1810.03.0.00	HOSE REDICER BET AIR CLEANER AND PRE CLEANER	Spare Part	829	20%
	4H.1810.04.0.00	RUBBER SLEEVE SMALL -FOR PRE-CLEANER	Spare Part	298	15%
	4H.1810.05.0.00	RUBBER SLEEVE LARGE - FOR AIR CLEANER	Spare Part	290	15%
2804	4H.1810.50.0.00 4H.1810.60.0.00	AIR CLEANER AIR CLEANER ASSLY	Spare Part Spare Part	27268 27165	20%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		·		without Vat in NPR	Charge%
2806	4H.1812.01.0.00	EXHAUST DIFFUSER	Spare Part	2003	15%
2807	4H.1814.02.0.00	POLY V BELT 6PK:1325 4R1040TA	Spare Part	1382	15%
2808	4H.1818.10.0.00	FAN: 494 DIA 35 DEG	Spare Part	13455	15%
	4H.1819.10.0.00	FAN: 494 DIA 35 DEG	Spare Part	15757	15%
	4H.1820.01.0.00	EXHAUST SILENCER	Spare Part	13606	15%
	4H.1821.01.0.00	DIFFUSER	Spare Part	2803	15%
2812	4H.1822.04.0.00	BRACKET: EXH DIFF SUPPORT	Spare Part	2154	15%
2813	4H.1822.05.0.00	EXHAUST DIFFUSER	Spare Part	2046	15%
2814	4H.1822.07.0.PR	BRACKET FOR EXHAUST DIFFUSER	Spare Part	1868	15%
	4H.1823.01.0.00	HOSE: AIR CLEANER	Spare Part	5723	15%
	4H.1825.11.0.PR	B12 E GOVERNOR HARNESS DIAGRAM SERIAL PROGRAMMING	Spare Part	5901	15%
	4H.1825.12.0.PR	B12 E GOVERNOR SERIAL PROGRAMMING HARNESS	Spare Part	15744	15%
	4H.1825.30.0.00	ENGINE TO PANEL WIRING HARNESS ASSEMBLY	Spare Part	3169	15%
	4H.1827.02.0.00	CRANKSHAFT PULLEY	Spare Part	4538	15%
	4H.1827.03.0.00	CRANKSHAFT PULLEY	Spare Part	5283	15%
	4H.1828.02.0.00	HOSE: AIR CLEANER	Spare Part	5388	15%
	4H.1828.03.0.00	HOSE: AIR CLEANER	Spare Part	2228	15%
	4H.183.01.0.00	SAFETY FILTER ELEMENT	Filter	1414	20%
	4H.183.10.0.00	AIR CLEANER ASSLY: 8M3 INDL	Spare Part	19362	20%
	4H.1832.01.0.00	FUEL PIPE: FEED PUMP TO FUEL FILTER	Spare Part	852	15%
	4H.1832.02.0.00	FUEL PIPE: MUD FILTER TO FEED PUMP	Spare Part	926	15%
	4H.1832.03.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	751	15%
	4H.1840.15.0.00	230V AC 16MM RED COLOUR LAMP	Spare Part	335	15%
	4H.1867.01.0.00	CRANK PULLEY	Spare Part	5409	15%
	4H.1873.01.0.00	HOSE: AIR CLEANER	Spare Part	7055	15%
	4H.1873.02.0.00	HOSE FOR PRECLEANER	Spare Part	2698	15%
	4H.1874.10.0.00	RAISED DIPSTICK ASSLY	Spare Part	760	15%
	4H.1890.02.0.00	INLINE FIP: 4R1040TA 102 HP @1500 RPM CPCB-II	Spare Part	59412	15%
	4H.1904.40.0.00	ENGINE WIRING HARNESS ASSEMBLY WITH KG 934	Spare Part	11855	15%
	4H.1904.90.0.PR	ENGINE WIRING HARNESS FOR 82 5KVA 4R1040 EMERALD	Spare Part	5991	15%
	4H.1911.03.0.00	SHIM FOR SPEED & PHASE SENSORS	Spare Part	114	15%
	4H.1911.06.0.00	SHIM FOR SPEED PHASE SENSORS THICK 0.8	Spare Part	117	15%
2838	4H.1911.07.0.00	SHIM FOR SPEED PHASE SENSORS THICK 11	Spare Part	178	15%
	4H.1911.08.0.00	SHIM FOR SPEED PHASE SENSORS THICK 15	Spare Part	243	15%
	4H.1915.01.0.00	HUB FOR FUEL PUMP GEAR S F COMMON RAIL ENGINE	Spare Part	3806	15%
	4H.1926.01.0.00	PIPE ASSEMBLY FROM PUMP TO SOLENOID	Spare Part	378	15%
	4H.1926.02.0.00	PIPE ASSEMBLY SOLENOID TO HEATER	Spare Part	431	15%
		BRACKET FOR SOLENOID MOUNTING		305	15%
	4H.1926.03.0.00		Spare Part		15%
	4H.1927.101.0.PR	ROUTED HIGH PRESSURE PIPE 1 PUMP TO RAIL	Spare Part	3148	
	4H.1927.102.0.PR	ROUTED HIGH PRESSURE PIPE 2 PUMP TO RAIL ROUTED HIGH PRESSURE PIPE CYLINDER 1 RAIL TO INJECTOR	Spare Part	3148 12557	15% 15%
	4H.1927.111.0.PR		Spare Part	12557	15%
	4H.1927.112.0.PR	ROUTED HIGH PRESSURE PIPE CYLINDER 2 RAIL TO INJECTOR ROUTED HIGH PRESSURE PIPE CYLINDER 3 RAIL TO INJECTOR	Spare Part		
	4H.1927.113.0.PR		Spare Part	12557	15%
	4H.1927.114.0.PR	ROUTED HIGH PRESSURE PIPE CYLINDER 4 RAIL TO INJECTOR	Spare Part	12557	15%
	4H.1930.01.0.PR	GEAR CASING S F HYDRAULIC PUMP	Spare Part	18018	15%
	4H.1930.03.0.PR	BRACKET FOR ALTERNATOR MOUNTING COVER FOR CAM BORE	Spare Part	1074	15% 15%
	4H.1930.06.0.PR	COVER FOR CAM BORE	Spare Part	5889	
	4H.1930.07.0.00	COVER FOR HYD. PUMP BORE	Spare Part	1834	15%
	4H.1930.08.0.00	JOINT FOR GEAR CASING	Spare Part	498	15%
	4H.1930.09.0.00	JOINT FOR COMPRESSOR COVER	Spare Part	200	15%
	4H.1930.11.0.00	JOINT FOR GEAR COVER	Spare Part	452	15%
2857	4H.1930.12.0.00	JOINT FOR FIP COVER	Spare Part	298	15%
					15%
2858 2859	4H.1932.05.0.PR 4H.1934.06.0.PR	CAM TONE WHEEL S F COMMON RAIL GASKET FOR ADAPTOR	Spare Part Spare Part	5834 443	15% 15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
				NPR	
2861	4H.1942.02.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	726	15%
2862	4H.1942.03.0.00	FUEL PIPE: FEED PUMP TO FILTER	Spare Part	877	15%
2863	4H.1942.12.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	951	15%
2864	4H.1942.13.0.00	FUEL PIPE FUEL FILTER TO FIP	Spare Part	702	15%
2865	4H.1943.60.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	5743	20%
2866	4H.1944.30.0.00	LUBE OIL PUMP	Spare Part	14458	15%
2867	4H.1946.20.0.PR	CYLINDER HEAD ASSY WITH VG VSI	Spare Part	69790	15%
2868	4H.1950.60.0.00	H.P.PIPE COMPLETE SET (700 MM)	Spare Part	3292	15%
2869	4H.1951.01.0.00	EXHAUST DIFFUSER	Spare Part	4508	15%
2870	4H.1951.02.0.00	JOINT: TURBO & DIFFUSER	Spare Part	1111	15%
2871	4H.1951.03.0.00	BRACKET FOR DIFFUSER	Spare Part	702	15%
2872	4H.1951.04.0.00	HEAT SHIELD INTEGRAL WITH DIFFUSER JOINT	Spare Part	1323	15%
2873	4H.1951.17.0.PR	BRACKET FOR DIFFUSER SUPPORT	Spare Part	6298	15%
2874	4H.1966.01.0.PR	EXHAUST DIFFUSER	Spare Part	3548	15%
2875	4H.198.02.0.00	LOCATING BOLT : 65MM EYE BOLT	Spare Part	194	15%
2876	4H.198.03.0.00	SPACER (FOR EYE BOLT)	Spare Part	62	15%
2877	4H.198.04.0.00	BELT GUARD	Spare Part	677	15%
2878	4H.198.07.0.00	BELT GAURD FOR ALTERNATOR	Spare Part	705	15%
2879	4H.198.21.0.00	BELT GUARD FOR ALT	Spare Part	1148	15%
2880	4H.1989.09.0.PR	ADAPTOR	Spare Part	532	15%
2881	4H.1990.01.0.PR	HEADER FOR LUB OIL COOLER SPIN ON FILTER	Spare Part	14935	15%
2882	4H.1990.02.0.PR	GASKET FOR LUB OIL HEADER	Spare Part	342	15%
2883	4H.1998.01.0.PR	BELT V TYPE A SECTION EPDM V13X1318	Spare Part	1403	15%
2884	4H.1999.02.0.PR	BOSCH MD1CE868 Non-ETK version ECU.	Spare Part	71199	15%
2885	4H.1999.03.0.PR	BOSCH MD1CC878 ECU	Spare Part	60522	15%
2886	4H.201.01.0.00	JOINT: SHEET METAL SUMP	Spare Part	603	15%
2887	4H.215.01.0.00	HOSE: AIR CLEANER	Spare Part	4381	15%
2888	4H.220.01.0.00	EXHAUST MANIFOLD	Spare Part	6785	15%
2889	4H.2206.01.0.00	FUEL FILTER CARTRIDGE	Filter	2908	20%
2890	4H.2206.10.0.00	FUEL FILTER ASSLY	Filter	6454	20%
2891	4H.2206.30.0.00	FUEL FILTER ASSLY-ROTRY FIP	Filter	6068	20%
2892	4H.2206.60.0.PR	MAIN FUEL FILTER CARTRIDGE WITH 3 STAGE WATER SEPARATION BOSCH P N F 002 H24 860	Spare Part	7658	15%
2893	4H.221.06.0.00	EXPANSION BELLOW: K24 TURBO	Spare Part	4338	15%
2894	4H.221.07.0.00	HEXAGONAL SOCKET HEAD CAP SCREW M8X18L	Spare Part	25	15%
2895	4H.221.08.0.00	EXHAUST DIFFUSER	Spare Part	1945	15%
2896	4H.221.09.0.00	BRACKET FOR EXHAUST DIFFUSER	Spare Part	649	15%
2897	4H.222.01.0.00	LUBE OIL INLET PIPE	Spare Part	692	15%
2898	4H.222.03.0.00	LUBE OIL DRAIN PIPE	Spare Part	892	15%
2899	4H.223.01.0.00	AIR INLET MANIFOLD	Spare Part	7575	15%
2900	4H.223.03.0.00	AIR INLET MANIFOLD(S/F FLAME HEATER MOUNTING)	Spare Part	7957	15%
2901	4H.223.04.0.00	INLET MANIFOLD	Spare Part	6763	15%
2902	4H.223.05.0.00	INLET MANIFOLD	Spare Part		15%
2903	4H.223.11.0.00	JOINT: AIR INLET MANIFOLD	Spare Part	49	15%
2904	4H.224.02.0.00	BRACKET FOR AIR PIPE	Spare Part	1609	15%
2905	4H.224.03.0.00	U CLAMP	Spare Part	123	15%
2906	4H.224.04.0.00	AIR PIPE: CAC TO AIR INLET M'FOLD	Spare Part	6271	15%
2907	4H.224.06.0.00	AIR PIPE TURBO SIDE	Spare Part		15%
2908	4H.224.07.0.00	AIR PIPE CAC SIDE	Spare Part	5945	15%
2909	4H.224.08.0.00	JOINT: AIR PIPE	Spare Part	86	15%
2910	4H.224.13.0.00	CAP FOR CAC PIPE	Spare Part		15%
2911	4H.224.14.0.00	AIR DELIVERY BEND	Spare Part		15%
2912	4H.224.15.0.00	SPACER (BETWEEN TURBO & AIR PIPE)	Spare Part		15%
2913	4H.224.16.0.00	O RING: SPACER - TURBO & AIR PIPE)	Spare Part	95	15%
2914	4H.224.17.0.00	AIR PIPE (CAC TO AIR INLET)	Spare Part	13797	15%
2915	4H.224.21.0.00	AIR PIPE (CAC TO INLET MANIFOLD)	Spare Part		15%
2010	1.22-7.2 1.0.00	/ (0/10 10 HEET HAVEN OLD)	Opale Fall	37.17	1070



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
2916	4H.224.35.0.00	JOINT: AIR INLET MANIFOLD & AIR PIPE	Spare Part	77	15%
2917	4H.224.38.0.00	AIR PIPE (TURBO SIDE)	Spare Part	3385	15%
2918	4H.224.39.0.00	AIR PIPE (INLET MANIFOLD SIDE)	Spare Part	4668	15%
2919	4H.224.43.0.00	AIR PIPE (BEND)	Spare Part	5825	15%
2920	4H.224.44.0.00	AIR PIPE	Spare Part	4083	15%
2921	4H.224.45.0.00	FLANGE HEATER	Spare Part	41510	15%
2922	4H.224.48.0.00	FLANGE HEATER 24V	Spare Part	41433	15%
2923	4H.224.57.0.PR	O RING	Spare Part	618	15%
2924	4H.224.68.0.PR	CAC HOSE COLD SIDE	Spare Part	1095	15%
2925	4H.224.98.0.PR	FLANGE HEATER 0 5 KW	Spare Part	37636	15%
2926	4H.224.99.0.PR	FLANGE HEATER 1 5KW	Spare Part	39193	15%
2927	4H.225.01.0.00	BRACKET FOR RADIATOR STAY	Spare Part	2508	15%
2928	4H.225.02.0.00	STAY FOR RADIATOR	Spare Part	425	15%
2929	4H.225.06.0.00	SPACER FOR BRACKET	Spare Part	132	15%
2930	4H.225.09.0.00	VENT PIPE	Spare Part	286	15%
2931	4H.225.11.0.00	ADAPTOR FOR VENT PIPE	Spare Part	188	15%
2932	4H.225.12.0.00	HOSE: MAKEUP WATER LINE	Spare Part	797	15%
2933	4H.225.13.0.00	SPACER FOR VENT CONNECTION	Spare Part	231	15%
2934	4H.225.14.0.00	ADAPTOR: WATER TEMP SWITCH	Spare Part	194	15%
2935	4H.225.22.0.00	ADAPTOR FOR WATER TEMP. SENSOR	Spare Part	286	15%
2936	4H.225.25.0.00	STAY FOR RADIATOR	Spare Part	929	15%
2937	4H.225.29.0.00	ADAPTOR FOR WATER TEMP SWITCH	Spare Part	782	15%
2938	4H.225.43.0.PR	ADAPTOR FOR RAW WATER TEMP SWITCH	Spare Part	326	15%
2939	4H.226.02.0.00	PIPE (THERMOSTAT TO RADIATOR INLET)	Spare Part	1049	15%
2940	4H.226.06.0.00	RUBBER PIPE: RADIATOR OUT TO WATER PUMP	Spare Part	1151	15%
2941	4H.226.08.0.00	HOSE: THERMOSTAT TO RADIATOR INLET	Spare Part	1883	15%
2942	4H.226.14.0.00	HOSE: MAKE UP 4R TA	Spare Part	1252	15%
2943	4H.226.15.0.00	HOSE :THERMOSTAT TO RADIATOR INLET	Spare Part	1658	15%
2944	4H.226.16.0.00	HOSE: RAD OUT TO ENGINE IN	Spare Part	2108	15%
2945	4H.227.01.0.00	AIR CLEANER MTG BRACKET	Spare Part	3951	15%
2946	4H.227.02.0.00	HOSE: AIR CLEANER	Spare Part	4178	15%
2947	4H.227.11.0.00	AIR CLEANER BRACKET FOR 6H.412.20 AIR CLEANER	Spare Part	3292	15%
2948	4H.227.12.0.00	HOSE: AIR CLEANER	Spare Part	5468	15%
2949	4H.228.01.0.00	CRANKCASE FOOT (F P SIDE 225 HT)	Spare Part	1880	15%
2950	4H.228.02.0.00	CRANKCASE FOOT (STARTER SIDE 225 HT)	Spare Part	1683	15%
2951	4H.228.11.0.00	BRACKET FOR MUD FILTER	Spare Part	735	15%
	4H.230.01.0.00	SPACER FOR 24V STARTER (29.8 MM WIDTH)	Spare Part	1191	15%
	4H.231.10.0.00	SUCTION TUBE	Spare Part	548	15%
2954	4H.235.01.0.00	ADAPTOR: LUBE OIL PRESS SENSOR	Spare Part	95	15%
2955	4H.235.11.0.00	ADAPTOR FOR LOPSWITCH	Spare Part	95	15%
		ADAPTOR FOR LOP SENSOR CUM SWITCH	Spare Part	114	15%
	4H.235.12.0.00 4H.235.15.0.00	ADAPTOR ADAPTOR	Spare Part	148	15%
		INTERMEDIATE GEAR SUPPORT	Spare Part		
2958	4H.237.01.0.00			2003	15%
2959	4H.237.02.0.00	INTERMEDIATE GEAR SUPPORT	Spare Part	2403	15%
2960	4H.239.01.0.00	S.G.IRON FOOT	Spare Part	2197	15%
2961	4H.242.10.0.00	WATER PUMP SUB ASSEMBLY MA IOR OVERHALIL KIT	Spare Part	12858	15% 15%
2962	4H.246.10.0.SP	MAJOR OVERHAUL KIT	Spare Part	80879	
2963	4H.246.20.0.SP	MAJOR OVERHAUL KIT 4R1040 CMVR	Spare Part	81830	15%
2964	4H.247.10.0.00	LEAK OFF PIPE SUB ASSLY	Spare Part	2188	15%
2965	4H.251.10.0.00	WATER PUMP ASSLY WITH PULLEY	Spare Part	12175	15%
	4H.252.10.0.00	LEAK OFF PIPE SUB ASSLY	Spare Part	2268	15%
2967	4H.252.30.0.00	LEAK OFF PIPE ASSLY: 4K1080TA	Spare Part	2708	15%
2968	4H.253.41.0.SP	INLET EXHAUST VALVE PAIR	Spare Part	3486	15%
2969	4H.2579.03.0.00	FEED PUMP	Spare Part	6092	15%
2970	4H.258.05.0.00	HOSE FOR AIR CLEANER 45 X 45 X 90DEG	Spare Part	609	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
2971	4H.261.01.0.00	CRANKSHAFT PULLEY	Spare Part	4163	15%
2972	4H.262.01.0.00	WATER PUMP PULLEY-120 PCD SPA SECTION	Spare Part	2622	15%
2973	4H.263.01.0.00	ALTERNATOR PULLEY (90 PCD)	Spare Part	1151	15%
2974	4H.267.01.0.00	RADIATOR FAN 17 INCH SUCKER	Spare Part	1982	15%
2975	4H.271.01.0.00	RADIATOR FAN: 24" PUSHER	Spare Part	7061	15%
2976	4H.277.10.0.00	TURBOCHARGER	Spare Part	88971	15%
2977	4H.277.20.0.00	TURBOCHARGER (K24 5.11) FOR HA6 TCI CPCB II	Spare Part	79313	15%
2978	4H.292.10.0.00	MONOBLOCK CRANKCASE W/O BEARING	Spare Part	187241	15%
2979	4H.294.02.0.00	LUBE OIL SUMP: CI BTM DRAIN PLG	Spare Part	14597	15%
2980	4H.294.04.0.00	BAFFLE PLATE	Spare Part	2203	15%
2981	4H.295.10.0.00	FLYWHEEL ASSEMBLY	Spare Part	12772	15%
2982	4H.297.20.0.00	SUCTION TUBE ASSEMBLY	Spare Part	477	15%
2983	4H.301.01.0.00	SILENCER BRACKET	Spare Part	4129	15%
2984	4H.301.02.0.00	U-CLAMPING STUD	Spare Part	292	15%
2985	4H.302.03.0.00	JOINT: TURBO (DIFFUSER SIDE)	Spare Part	258	15%
2986	4H.303.02.0.00	SPACER FOR RADIATOR FAN (40 MM)	Spare Part	1403	15%
2987	4H.307.10.0.00	COOLANT TESTING KIT	Spare Part	16597	15%
2988	4H.311.02.0.00	ALTERNATOR: 12V 90A	Spare Part	27750	15%
2989	4H.317.01.0.00	PLATE FOR FUEL FILTER: INLET M'FOLD	Spare Part	455	15%
2990	4H.323.10.0.00	NOZZLE LEAK OFF PIPE	Spare Part	889	15%
2991	4H.324.10.0.00	SUCTION TUBE	Spare Part	508	15%
2992	4H.325.10.0.00	HIGH PRESSURE PIPE SET 700MM	Spare Part	4585	15%
2993	4H.328.01.0.00	PIPE, RADIATOR TO PUMP INLET	Spare Part	2148	15%
2994	4H.328.02.0.00	HOSE: 45 IDX 5.2 THK X 95L	Spare Part	252	15%
2995	4H.328.05.0.00	CLAMP TOP FOR WATER INLET PIPE (LTK)	Spare Part	403	15%
2996	4H.328.06.0.00	CLAMP BOTTOM FOR WATER INLET PIPE (LTK)	Spare Part	458	15%
2997	4H.329.05.0.00	BUSH FOR ALTERNATOR MOUNTING	Spare Part	95	15%
2998	4H.329.23.0.00	LOCATING BOLT: M8X35	Spare Part	77	15%
2999	4H.329.24.0.00	EYE BOLT (190MM)	Spare Part	462	15%
3000	4H.329.26.0.00	SWIVEL PIECE	Spare Part	108	15%
3001	4H.329.27.0.00	LOCATING BOLT M10 X55MM	Spare Part	86	15%
3002	4H.333.01.0.00	LUB OIL SUPPLY HOSE CRANK CASE TO FIP FOR IRS	Spare Part	2640	15%
3003	4H.333.03.0.00	FUEL FILTER CTG-DUPLEX TYPE	Filter	10037	20%
3004	4H.334.02.0.00	FUEL LEAK OFF PIPE: WIRE BRAIDED	Spare Part	1585	15%
3004	4H.339.01.0.00	FLYWHEEL HOUSING FOR HM LCV 88 9 MM	Spare Part	15064	15%
3006	4H.343.03.0.00	EXHAUST MANIFOLD (CENTRAL OPENING) (FOR JCB T PROJECT)	Spare Part	6498	15%
3007	4H.346.01.0.00	INLET MANIFOLD (TOP & FWE OPENING)	Spare Part	7991	15%
3008	4H.346.06.0.00	BLANKING PLATE FOR INLET MANIFOLD	Spare Part	658	15%
3009	4H.346.07.0.00	JOINT: BLANKING PLATE	Spare Part	37	15%
3010	4H.346.11.0.00	INLET MANIFOLD (TOP OPENING)	Spare Part	6111	15%
	4H.357.02.0.00	JOINT: EXHAUST DIFFUSER	Spare Part	723	15%
3011	4H.358.04.0.00		Spare Part	655	15%
3012		JOINT: FRONT COVER			
3013	4H.358.06.0.00	GEAR END OIL SEAL 80X105X12	Spare Part	2265	15%
3014	4H.358.09.0.00	TIMING POINTER	Spare Part	52	15%
3015	4H.358.12.0.00	OIL DEFLECTOR PLATE	Spare Part	178	15%
3016	4H.359.01.0.00	LUBE OIL SUMP: DRAIN PLUG-FIP SIDE	Spare Part	18960	15% 15%
3017	4H.359.02.0.00	JOINT FOR LUB OIL SUMP	Spare Part	462	
3018	4H.366.07.0.00	HOSE STRAIGHT: 70MM L CENTRAL HUMP	Spare Part	360	15%
3019	4H.366.08.0.00	HOSE: TURBO DRAIN PIPE 170MM	Spare Part	831	15%
3020	4H.366.12.0.00	HOSE FOR TURBO DRAIN PIPE	Spare Part	1234	15%
3021	4H.370.02.0.00	BOLT : CRANK PULLEY	Spare Part	188	15%
3022	4H.371.02.0.00	CRANKSHAFT GEAR	Spare Part	3760	15%
3023	4H.371.50.0.00	CRANKSHAFT ASSLY	Spare Part	95162	15%
3024	4H.372.01.0.00	SHAFT: LUBE OIL PUMP INTERMEDIATE GEAR	Spare Part	375	15%
3025	4H.372.02.0.00	HARD WASHER - INTERMEDIATE GEAR	Spare Part	74	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		·		without Vat in NPR	Charge%
3026	4H.373.01.0.00	COVER FOR FUEL PUMP BORE	Spare Part	1129	15%
3027	4H.373.02.0.00	O RING: FUEL PUMP COVER	Spare Part	49	15%
3028	4H.375.01.0.00	ADAPTOR FOR TACHO DRIVE UNIT	Spare Part	443	15%
3029	4H.375.02.0.00	JOINT: TACHO DRIVE UNIT ADAPTOR	Spare Part	25	15%
3030	4H.376.20.0.00	INJECTOR	Spare Part	7905	15%
3031	4H.380.20.0.00	CAMSHAFT SUBASSEMBLY	Spare Part	36418	15%
3032	4H.383.01.0.00	EXHAUST MANIFOLD	Spare Part	4332	15%
3033	4H.385.01.0.00	HEADER (FOR LO& SPIN ON FILTER)	Spare Part	4191	15%
3034	4H.385.02.0.00	LUBE OIL COOLER -12 PLATES	Spare Part	8828	15%
3035	4H.390.01.0.00	SPACER: FAN	Spare Part	880	15%
3036	4H.394.01.0.00	WATER PUMP PULLEY 108 PCD	Spare Part	2098	15%
3037	4H.395.10.0.00	THERMOSTAT HOUSING	Spare Part	4751	15%
3038	4H.396.06.0.PR	LUB OIL SUMP FOR 4WD ENGINE	Spare Part	22104	15%
3039	4H.396.10.0.PR	DIPSTICK ASSEMBLY FOR 4WD ENGINE	Spare Part	206	15%
3040	4H.397.10.0.00	F002 A0Z 522 FUEL PUMP ASSLY MICO	Spare Part	71310	15%
3041	4H.398.05.0.00	EXHAUST DIFFUSER WITH TRIANGULAR FLANGE	Spare Part	2843	15%
3042	4H.398.11.0.00	DOG BONE FOR K24 TC	Spare Part	603	15%
3043	4H.398.12.0.00	TC HOUSING FOR DOG BONE	Spare Part	902	15%
3044	4H.398.13.0.00	EXHAUST DIFFUSER WITH TRIANGULAR FLANGE	Spare Part	3188	15%
3045	4H.398.14.0.00	BRACKET FOR EXHAUST DIFFUSER	Spare Part	1514	15%
3046	4H.399.01.0.00	PLATE FOR FUEL FILTER	Spare Part	292	15%
3047	4H.399.02.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	815	15%
3048	4H.399.03.0.00	FUEL PIPE: FEED PUMP TO FUEL FILTER	Spare Part	1132	15%
3049	4H.401.10.0.00	RAISED DIPSTICK ASSEMBLY (350 MM)	Spare Part	880	15%
3050	4H.402.20.0.00	THERMOSTAT HSG ASSEMBLY	Spare Part	4483	15%
3051	4H.404.01.0.00	BRACKET FOR AIR CLEANER	Spare Part	1714	15%
3052	4H.404.02.0.00	RUBBER HOSE	Spare Part	942	15%
3053	4H.404.03.0.00	ADAPTER FOR AIR CLEANER	Spare Part	815	15%
3054	4H.405.01.0.00	PIPE: RADIATOR-PUMP INLET	Spare Part	1452	15%
3055	4H.405.02.0.00	HOSE: WATER PUMP INLET TO RADIATOR OUTLET		938	15%
3056		HOSE: MAKE UP WATER CONNECTION	Spare Part Spare Part	625	15%
3057	4H.405.03.0.00 4H.405.04.0.00	HOSE: THERMOSTAT TO RADIATOR INLET	Spare Part	960	15%
	1			209	15%
3058	4H.405.05.0.00	RUBBER HOSE: RADIATOR AIR VENT	Spare Part		
3059	4H.405.06.0.00	STAINLESS STEEL HOSE CLIP S/F 45 TO 61 MM HOSE O.D. (TO REPLACE 50519/11)	Spare Part	166	15%
3060	4H.405.07.0.00	STAINLESS STEEL HOSE CLIP S/F 35 TO 41 MM HOSE O.D (TO REPLACE 50519/08)	Spare Part	145 1431	15% 15%
3061	4H.405.08.0.00	PIPE (RADIATOR TO PUMP INLET)	Spare Part		15%
3062	4H.405.09.0.00	HOSE: WATER PUMP INLET TO RADIATOR OUTLET	Spare Part	1388	
3063	4H.406.01.0.00	RADIATOR SUPPORT (F.I.P. SIDE)	Spare Part	1852	15%
3064	4H.406.02.0.00	RADIATOR SUPPORT (STARTER SIDE)	Spare Part	1938	15%
3065	4H.406.04.0.00	STAY (FOR RADIATOR)	Spare Part	342	15%
3066	4H.410.01.0.00	AIR PIPE (TURBOCHARGER TO INLET MANIFOLD)	Spare Part	4775	15%
3067	4H.412.03.0.00	AIR CLEANER ASSLY: 9.5m3/m	Filter	10777	20%
3068	4H.412.05.0.00	PVC PIPE FOR AIR CLEANER (SUCTION SIDE)	Spare Part	723	15%
3069	4H.412.09.0.00	BRACKET FOR AIR CLEANER	Spare Part	3569	15%
3070	4H.412.32.0.PR	HOSE FOR AIR CLEANER	Spare Part	5268	15%
3071	4H.415.10.0.00	THERMOSTAT ASSEMBLY	Spare Part	3861	15%
3072	4H.416.01.0.00	ADAPTOR (FOR TEMPERATURE GAUGE)	Spare Part	169	15%
3073	4H.422.01.0.00	ALTERNATOR: 24V 55A	Spare Part	25784	15%
3074	4H.422.02.0.00	ALTERNATOR: WO BLOCKING DIODE	Spare Part	25243	15%
3075	4H.425.10.0.00	HIGH PRESS PIPE SET 640MM	Spare Part	3991	15%
3076	4H.4251.76.0.00	MECCALTE AVR PROGRAMMING KIT USD2DXR	Spare Part	67178	15%
3077	4H.433.02.0.00	LIFTING HOOK GEAR END SIDE	Spare Part	1031	15%
3078	4H.442.01.0.00	RUBBER HOSE	Spare Part	2283	15%
3079	4H.442.02.0.00	SLEEVE (FOR AIR CLEANER HOSE)	Spare Part	582	15%
3080	4H.442.03.0.00	RUBBER HOSE	Spare Part	2062	15%



MARCON M	Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
AMAPTION FOR LIBER OIL SUPPLY PIPE Span Part 922 1,	2001	411 442 04 0 00	HOSE, AID OF EAVIED	Spara Part	NPR	15%
1935 1446 07 0.00		+				15%
Separe Part 1083 1444401000 LUBG OLI NILET PIPE FOR COMPRESSOR Spere Part 77 1 1 1 1 1 1 1 1						15%
ALASTOR FOR OLD SUPPLY PIET TO COMPRESSOR Spare Pai 77 1 1 1 1 1 1 1 1				·		15%
						15%
1967 1445/08/10/09 20NT FOR EDHAUST SILENCER WITH 174 OD S F UN SHANTI				·		15%
9888 H-4469 0.000 RAN CAP Spen Pert 1208 14 989 H-448 0.000 PUEL PIPE Span Pert 87 1 1 3090 H-448 0.000 PUEL PIPE SMILL RESTANCIAN Span Pert 717 1 3091 H-448 0.000 TERMANA SLEEVE (RECD) Span Pert 717 1 3092 H-450 1.000 TERMANA SLEEVE (RECD) Span Pert 715 1 3093 H-450 1.000 TERMANA SLEEVE (RECD) Span Pert 175 1 3094 H-450 1.000 TERMANA SLEEVE (RECD) Span Pert 106 3 3095 H-450 1.000 WATER PURP BERT 3 Span Pert 106 3 3096 H-470 2.000 WATER PURP BERT 3 Span Pert 83 1 3097 H-472 0.000 STUD COUPLER (115 MM LONG) Span Pert 43 1 3098 H-472 0.000 SPACER TIO JO 15 I. 25 MM Span Pert 45 1 3100 H-472 0.000 SPACER TIO JOSO 5 I 0				,		15%
Media						
1999 14449 30 0.00 FUEL CAP 1996 PTS MM LENCTH 1996 PTS MM LEN				-		15%
3981 H.44803.0.00 FUEL PRE 75 MM LENGTH Spee Part 717 1 3082 444.60.17.0.00 TERMINAL SLEEVE (RED) Spare Part 175 1 3094 44.460.17.0.00 TERMINAL SLEEVE (RED) Spare Part 175 1 3094 44.460.17.0.00 TERMINAL SLEEVE (RED) Spare Part 4058 1 3095 44.460.10.00 TERMINAL SLEEVE (RED) Spare Part 4058 1 3096 44.476.00.00 RUBBER HOSE: RADIAL SEAL ARC LEARER Spare Part 683 1 3097 44.472.00.00 SPACED COUPLER (115 ML LONG) Spare Part 62 1 3098 44.472.00.00 SPACER (10.70.01.31, 25 MM) Spare Part 52 1 3101 44.472.00.00 SPACER (10.70.01.31, 25 MM) Spare Part 34 1 3101 44.472.00.00 SPACER FOR LIVATOR Spare Part 34 1 3101 44.472.00.00 SPACER FOR LIVATOR Spare Part 36 1 3102 44.472.10.00 </td <td></td> <td></td> <td></td> <td></td> <td></td> <td>15%</td>						15%
M450150.00 TERMINAL SLEEVE (RED.) Spare Part 175 1						15%
3939 4H450370.00 TERMINUL SLEEVE (BLACK) 175 175 175 1304 4H465340.PR LUB OIL PRESSURE ALARM TRIP SWITCH FROM RICO FOR MARINE APPLICATION Spure Part 4068 1 3096 4H4665.40.DR RUB COLL PURE (1518 MICHAN) Spure Part 488 1 3096 4H471.03.00.00 RUBBER HOSE, RADUL SEAL AR CLEANER Spure Part 683 1 3089 4H472.03.00.00 STUD COUPLER (1518 MICHAN) Spure Part 62 1 3089 4H472.03.00.00 NUT. MSKLH HITHEAD Spure Part 52 1 3100 4H472.03.00.00 SPACER (1D 7.0 13.1 2.5 MM) Spure Part 34 1 3101 4H472.03.00.00 SPACER FOR LID ALOR Spure Part 34 1 3101 4H472.03.00.00 SPACER FOR LID ALOR Spure Part 34 1 3102 4H472.03.00.00 SPACER FOR LID ALOR Spure Part 30 1 3103 4H472.03.00.00 SPACER FOR LID ALOR Spure Part 52 1 3104						15%
3994 H.465.34.D.PR LUB OLL PRESSURE ALARM TRIP SWITCH FROM RICO FOR MARRINE APPLICATION Spear Part 4038 1 3065 414.475.03.000 WATER PUMP BELT 3 Spear Part 883 1 3067 414.7103.000 RUBBER HOSE RADUL SEAL AIR CLEANER Spear Part 63 1 3069 414.720.000 STUD COUPLER (115 MM LONG) Spear Part 62 1 3069 414.720.000 SPACER (10 7.0013 L. 25 MM) Spear Part 34 1 3101 414.720.000 SPACER (10 7.0013 L. 25 MM) Spear Part 34 1 3102 414.72.00.000 SPACER (10 7.0013 L. 25 MM) Spear Part 34 1 3102 414.72.00.000 LEVER FOR ELECTRONIC ACTUATOR Spear Part 30 1 3104 414.72.00.000 SPACER FOR LINCAGE Spear Part 40 1 3104 414.72.10.000 SPACER FOR LINCAGE Spear Part 40 1 3104 414.72.10.000 SPACER FOR LINCAGE Spear Part 40 1				·		15%
						15%
						15%
997				·		15%
3098		+				15%
3989 4H47204.00 SPACER (ID 7, O.D 13, L.25 MM) 3,0 1 3100 4H472.05.00 SPACER TID, 1500 & 10 MM LONG Spare Part 34 1 3101 4H472.05.00 LEVER FOR ELECTRONICA CATUATOR Spare Part 150 1 3102 4H472.05.00 BRACKET FOR ACTUATOR Spare Part 130 1 3103 4H472.15.00 SPACER FOR LINKAGE Spare Part 431 1 3106 4H472.15.00 LEVER FOR ELECTRONICACTUATOR Spare Part 403 1 3106 4H472.15.00 VOLT SUPPRESSOR: B12 ECU Spare Part 100 1 3107 4H472.15.00 UNLT SUPPRESSOR: B12 ECU Spare Part 100 1 3108 4H472.67.00 BRACKET FOR ACTUATOR Spare Part 00 1 3109 4H482.03.00 BRACKET FOR STOPI LEVER WOUNTING Spare Part 62 1 3110 4H482.03.00 BRACKET FOR STOP LEVER WOUNTING Spare Part 102 1 3111 4H480.03.00 AD						15%
3101						15%
3101 44.472.07.0.00 LEVER FOR ELECTRONIC ACTUATOR Spare Part 745 1 3102 44.472.09.0.00 SPACKET FOR ACTUATOR Spare Part 1308 1 3103 44.472.19.0.00 SPACER FOR ILLKIKAGE Spare Part 431 1 3104 44.472.19.0.00 LEVER FOR ELECTRONIC ACTUATOR Spare Part 431 1 3105 44.472.60.0.00 BRACKET FOR ACTUATOR Spare Part 600 1 3107 44.472.60.0.00 BRACKET FOR ACTUATOR Spare Part 600 1 3108 44.472.60.0.00 BRACKET FOR ACTUATOR Spare Part 62 1 3109 44.482.00.0.0 SPRING HOLDING BOLT MODIFIED, LTK Spare Part 133 1 3110 44.482.00.0.0 SPRING HOLDING BOLT MODIFIED, LTK Spare Part 1179 1 3111 44.482.00.0.0 SPACKET FOR STOP LEVER MOUNTING Spare Part 1578 1 3111 44.482.00.0.0 ADAPTOR RIVE LINET (BOTH END M14X15) Spare Part 1079 1 <						15%
3102 4H.472.09.000 BRACKET FOR ACTUATOR Spare Part 1308 1 3103 4H.472.13.000 SPACER FOR LINKAGE 1 1 3104 4H.472.14.000 LEVER FOR ELECTRONIC ACTUATOR Spare Part 431 1 3106 4H.472.15.000 VOLT SUPPRESSOR: BI2 ECU Spare Part 600 1 3106 4H.472.65.000 BRACKET FOR ACTUATOR Spare Part 600 1 3107 4H.472.67.000 BRACKET FOR ACTUATOR Spare Part 338 1 3108 4H.482.03.000 TENSION SPRING Spare Part 62 1 3109 4H.482.03.000 SPRING HOLDING BOLT MODIFIED, LTK Spare Part 111 1 3110 4H.482.00.00 BRACKET FOR STOP LEVER MOUNTING Spare Part 116 1 3111 4H.486.01.000 ADAPTOR RIM 2 MI0 Spare Part 106 1 3111 4H.486.01.000 ADAPTOR RIM 2 MI0 Spare Part 202 1 3114 4H.486.13.0.0 PK FUEL PIPE FORM FU			7 7 7 7 7 7 7			15%
3103 4H 472 13 0.00 SPACER FOR LINKAGE Spare Part 52 1 3104 4H 472 14 0.00 LEVER FOR ELECTRONIC ACTUATOR Spare Part 431 1 3106 4H 472 15 0.00 VOLT SUPPRESSOR 912 ECU Spare Part 600 1 3107 4H 472 60.00 BRACKET FOR ACTUATOR Spare Part 338 1 3107 4H 472 60.00 BRACKET FOR ACTUATOR Spare Part 338 1 3108 4H 472 60.00 BRACKET FOR ACTUATOR Spare Part 62 1 3109 4H 482 00.00 SPRING HOLDING BOLT MODIFIED, LTK Spare Part 111 1 3110 4H 482 00.00 BRACKET FOR STOP LEVER MOUNTING Spare Part 111 1 3111 4H 486 00.00 ADAPTOR ROF FUEL INLET (BOTH END M14X15) Spare Part 105 1 3112 4H 486 00.00 ADAPTOR MY X MY U Spare Part 202 1 3113 4H 486 10.00 LEAN OFF PIPE SUB ASSLY Spare Part 202 1 3114						15%
3104 41.472.14.0.00				·		15%
3105						15%
Spare Part Spa						15%
Spare Part Spa				·		15%
3108				,		15%
3109						15%
3110						15%
3111 4H.486.01.0.00 ADAPTOR FOR FUEL INLET (BOTH END M14X15) Spare Part 114 1 3112 4H.486.05.0.00 ADAPTOR M14 X M16 U Spare Part 105 1 3113 4H.486.10.0.00 LEAK OFF PIPE SUB ASSLY Spare Part 2025 1 3114 4H.486.13.0.00 FUEL PIPE FROM FUEL TANK TO FEED PUMP Spare Part 2363 1 3115 4H.486.13.0.00 FUEL PIPE TANK TO MUD FILTER Spare Part 292 1 3116 4H.486.13.0.00 FUEL RETURN PIPE Spare Part 834 1 3117 4H.486.21.0.PR FUEL RETURN PIPE Spare Part 1274 1 3118 4H.486.61.0.00 FUEL RETURN PIPE Spare Part 557 1 3119 4H.486.62.0.00 FUEL RETURN PIPE Spare Part 557 1 3120 4H.486.92.0.00 FUEL RETURN PIPE Spare Part 522 1 3121 4H.486.92.0.00 FUEL RETURN PIPE Spare Part 522 1 3122 4H.486	3109		·	Spare Part		15%
3112 4H.486.05.0.00 ADAPTOR M14 X M16 U Spare Part 105 1 3113 4H.486.10.0.00 LEAK OFF PIPE SUB ASSLY Spare Part 2025 1 3114 4H.486.103.0.PR FUEL PIPE FROM FUEL TANK TO FEED PUMP Spare Part 2363 1 3115 4H.486.13.0.00 FUEL PIPE TANK TO MUD FILTER Spare Part 929 1 3116 4H.486.14.0.00 FUEL RETURN PIPE Spare Part 834 1 3117 4H.486.21.0.PR FUEL RETURN PIPE Spare Part 557 1 3118 4H.486.24.0.00 DRAIN PIPE Spare Part 557 1 3119 4H.486.24.0.00 DRAIN PIPE Spare Part 557 1 3120 4H.486.20.00 FUEL RETURN PIPE Spare Part 822 1 3121 4H.486.90.00 FUEL RETURN PIPE Spare Part 822 1 3121 4H.486.90.00 FUEL RETURN PIPE Spare Part 822 1 3122 4H.486.90.00 FUEL PIPE (FEED PU	3110	4H.482.14.0.00				15%
3113 4H.486.10.000 LEAK OFF PIPE SUB ASSLY Spare Part 2025 1 3114 4H.486.103.0 PR FUEL PIPE FROM FUEL TANK TO FEED PUMP Spare Part 2363 1 3115 4H.486.13.0.00 FUEL PIPE TANK TO MUD FILTER Spare Part 929 1 3116 4H.486.13.0.00 FUEL RETURN PIPE Spare Part 834 1 3117 4H.486.21.0.PR FUEL RETURN PIPE Spare Part 557 1 3118 4H.486.24.0.00 DRAIN PIPE Spare Part 557 1 3119 4H.486.46.0.00 FUEL RETURN PIPE Spare Part 822 1 3120 4H.486.82.0.00 FUEL PIPE PERFILTER TO FIP Spare Part 840 1 3121 4H.487.45.0.00 FUEL PIPE (FEED PUMP TO TANK UNIT) Spare Part 652 1 3122 4H.487.84.0.00 FUEL PIPE (FEED PUMP TO TANK UNIT) Spare Part 652 1 3123 4H.488.04.0.00 FUEL FILLING HOSE: 36-125KVA FOR SKID MOUNTED GENSET Spare Part 920 1	3111	4H.486.01.0.00	ADAPTOR FOR FUEL INLET (BOTH END M14X15)			15%
3114 4H.486.103.0.PR FUEL PIPE FROM FUEL TANK TO FEED PUMP Spare Part 2363 1 3115 4H.486.13.0.00 FUEL PIPE TANK TO MUD FILTER Spare Part 929 1 3116 4H.486.14.0.00 FUEL RETURN PIPE Spare Part 834 1 3117 4H.486.21.0.PR FUEL RETURN PIPE Spare Part 1274 1 3118 4H.486.24.0.00 DRAIN PIPE Spare Part 557 1 3119 4H.486.46.0.00 FUEL RETURN PIPE Spare Part 822 1 3120 4H.486.92.0.00 FUEL PIPE PREFILTER TO FIP Spare Part 840 1 3121 4H.486.92.0.00 FUEL PIPE (FEED PUMP TO TANK UNIT) Spare Part 2025 1 3122 4H.487.94.0.00 FUEL PIPE (FEED PUMP TO TANK UNIT) Spare Part 652 1 3123 4H.488.03.0.00 FUEL FILLING HOSE: 36-125KVA FOR SKID MOUNTED GENSET Spare Part 920 1 3125 4H.488.16.0.PR FUEL INLET PIPE METAILIC FIP TO PRE FILTER Spare Part 920 <	3112	4H.486.05.0.00	ADAPTOR M14 X M16 U	1		15%
3115 4H.486.13.0.00 FUEL PIPE TANK TO MUD FILTER Spare Part 929 1 3116 4H.486.14.0.00 FUEL RETURN PIPE Spare Part 834 1 3117 4H.486.21.0.PR FUEL RETURN PIPE Spare Part 1274 1 3118 4H.486.24.0.00 DRAIN PIPE Spare Part 557 1 3119 4H.486.24.0.00 FUEL RETURN PIPE Spare Part 822 1 3120 4H.486.92.0.00 FUEL PIPE PREFILTER TO FIP Spare Part 840 1 3121 4H.487.45.0.00 FUEL PIPE (FEED PUMP TO TANK UNIT) Spare Part 2025 1 3122 4H.487.84.0.00 FLANGE Spare Part 662 1 3123 4H.488.03.0.00 FUEL FILLING HOSE: 36-125KVA FOR SKID MOUNTED GENSET Spare Part 920 1 3124 4H.488.04.0.00 INLET AND OULET CONNECTION FOR FUEL TANK MAIL END CONNECTION 210 HEIGHT Spare Part 366 1 3125 4H.488.16.0.PR FUEL INLET PIPE METAILIC FIRE FILTER TO TANK Spare Part 2412	3113	4H.486.10.0.00	LEAK OFF PIPE SUB ASSLY	Spare Part	2025	15%
3116 4H.486.14.0.00 FUEL RETURN PIPE Spare Part 834 1 3117 4H.486.21.0.PR FUEL RETURN PIPE Spare Part 1274 1 3118 4H.486.24.0.00 DRAIN PIPE Spare Part 557 1 3119 4H.486.46.0.00 FUEL RETURN PIPE Spare Part 822 1 3120 4H.486.92.0.00 FUEL PIPE PREFILTER TO FIP Spare Part 800 1 3121 4H.487.45.0.00 FUEL PIPE (FEED PUMP TO TANK UNIT) Spare Part 2025 1 3122 4H.487.84.0.00 FLANGE Spare Part 652 1 3123 4H.488.93.0.00 FUEL FILLING HOSE: 36-125KVA FOR SKID MOUNTED GENSET Spare Part 920 1 3124 4H.488.04.0.00 INLET AND OULET CONNECTION FOR FUEL TANK MAIL END CONNECTION 210 HEIGHT Spare Part 366 1 3125 4H.488.16.0.PR FUEL INLET PIPE METAILIC FIP TO PRE FILTER Spare Part 2111 1 3126 4H.488.11.0.PR FUEL INLET PIPE METAILIC FIP TO ANK Spare Part 2412 </td <td>3114</td> <td>4H.486.103.0.PR</td> <td>FUEL PIPE FROM FUEL TANK TO FEED PUMP</td> <td>Spare Part</td> <td></td> <td>15%</td>	3114	4H.486.103.0.PR	FUEL PIPE FROM FUEL TANK TO FEED PUMP	Spare Part		15%
3117 4H.486.21.0.PR FUEL RETURN PIPE Spare Part 1274 1 3118 4H.486.24.0.00 DRAIN PIPE Spare Part 557 1 3119 4H.486.40.00 FUEL RETURN PIPE Spare Part 822 1 3120 4H.486.92.0.00 FUEL PIPE PREFILTER TO FIP Spare Part 800 1 3121 4H.487.45.0.00 FUEL PIPE (FEED PUMP TO TANK UNIT) Spare Part 2025 1 3122 4H.487.45.0.00 FUEL PIPE (FEED PUMP TO TANK UNIT) Spare Part 2025 1 3122 4H.480.00.00 FLANGE Spare Part 652 1 3123 4H.488.03.0.00 FUEL FILLING HOSE: 36-125KVA FOR SKID MOUNTED GENSET Spare Part 920 1 3124 4H.488.04.0.00 INLET AND OULET CONNECTION FOR FUEL TANK MAIL END CONNECTION 210 HEIGHT Spare Part 366 1 3125 4H.488.16.0.PR FUEL INLET PIPE METAILIC FIP TO PRE FILTER Spare Part 2111 1 3126 4H.488.11.0.PR FUEL INLET PIPE METAILIC FIP TO TANK Spare Part	3115	4H.486.13.0.00		Spare Part	929	15%
3118 4H.486.24.0.00 DRAIN PIPE Spare Part 557 1 3119 4H.486.46.0.00 FUEL RETURN PIPE Spare Part 822 1 3120 4H.486.92.0.00 FUEL PIPE PREFILTER TO FIP Spare Part 840 1 3121 4H.487.45.0.00 FUEL PIPE (FEED PUMP TO TANK UNIT) Spare Part 2025 1 3122 4H.487.84.0.00 FLANGE Spare Part 652 1 3123 4H.488.03.0.00 FUEL FILLING HOSE: 36-125KVA FOR SKID MOUNTED GENSET Spare Part 920 1 3124 4H.488.04.0.00 INLET AND OULET CONNECTION FOR FUEL TANK MAIL END CONNECTION 210 HEIGHT Spare Part 366 1 3125 4H.488.16.0.PR FUEL INLET PIPE METAILIC FIP TO PRE FILTER Spare Part 2111 1 3126 4H.488.17.0.PR FUEL INLET PIPE METAILIC PRE FILTER TO TANK Spare Part 2412 1 3127 4H.488.90.0.00 KIT FOR ELECTRICAL FUEL FEED PUMP FITMENT IN 4K Spare Part 3586 1 3128 4H.489.11.0.PR ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 Spare Part 465 1	3116	4H.486.14.0.00		Spare Part	834	15%
3119 4H.486.46.0.00 FUEL RETURN PIPE Spare Part 822 1 3120 4H.486.92.0.00 FUEL PIPE PREFILTER TO FIP Spare Part 840 1 3121 4H.487.45.0.00 FUEL PIPE (FEED PUMP TO TANK UNIT) Spare Part 2025 1 3122 4H.487.84.0.00 FLANGE Spare Part 652 1 3123 4H.488.03.0.00 FUEL FILLING HOSE: 36-125KVA FOR SKID MOUNTED GENSET Spare Part 920 1 3124 4H.488.04.0.00 INLET AND OULET CONNECTION FOR FUEL TANK MAIL END CONNECTION 210 HEIGHT Spare Part 366 1 3125 4H.488.16.0.PR FUEL INLET PIPE METAILIC FIP TO PRE FILTER Spare Part 2111 1 3126 4H.488.17.0.PR FUEL INLET PIPE METAILIC PRE FILTER TO TANK Spare Part 2412 1 3127 4H.488.90.0.00 KIT FOR ELECTRICAL FUEL FEED PUMP FITMENT IN 4K Spare Part 35886 1 3128 4H.489.11.0.PR ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 Spare Part 4465 1 3130 4H.489.12.0.PR ADBLUE PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 4194 <td>3117</td> <td>4H.486.21.0.PR</td> <td>FUEL RETURN PIPE</td> <td>Spare Part</td> <td>1274</td> <td>15%</td>	3117	4H.486.21.0.PR	FUEL RETURN PIPE	Spare Part	1274	15%
3120 4H.486.92.0.00 FUEL PIPE PREFILTER TO FIP Spare Part 840 1 3121 4H.487.45.0.00 FUEL PIPE (FEED PUMP TO TANK UNIT) Spare Part 2025 1 3122 4H.487.84.0.00 FLANGE Spare Part 652 1 3123 4H.488.03.0.00 FUEL FILLING HOSE: 36-125KVA FOR SKID MOUNTED GENSET Spare Part 920 1 3124 4H.488.04.0.00 INLET AND OULET CONNECTION FOR FUEL TANK MAIL END CONNECTION 210 HEIGHT Spare Part 366 1 3125 4H.488.16.0.PR FUEL INLET PIPE METAILIC FIP TO PRE FILTER Spare Part 2111 1 3126 4H.488.17.0.PR FUEL INLET PIPE METAILIC PRE FILTER TO TANK Spare Part 2412 1 3127 4H.488.90.0.00 KIT FOR ELECTRICAL FUEL FEED PUMP FITMENT IN 4K Spare Part 35886 1 3128 4H.489.11.0.PR ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 Spare Part 3729 1 3130 4H.489.12.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 Spare Part 4194 1 3131 4H.489.15.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 <td>3118</td> <td>4H.486.24.0.00</td> <td>DRAIN PIPE</td> <td>Spare Part</td> <td>557</td> <td>15%</td>	3118	4H.486.24.0.00	DRAIN PIPE	Spare Part	557	15%
3121 4H.487.45.0.00 FUEL PIPE (FEED PUMP TO TANK UNIT) Spare Part 2025 1 3122 4H.487.84.0.00 FLANGE Spare Part 652 1 3123 4H.488.03.0.00 FUEL FILLING HOSE: 36-125KVA FOR SKID MOUNTED GENSET Spare Part 920 1 3124 4H.488.04.0.00 INLET AND OULET CONNECTION FOR FUEL TANK MAIL END CONNECTION 210 HEIGHT Spare Part 366 1 3125 4H.488.16.0.PR FUEL INLET PIPE METAILIC FIP TO PRE FILTER Spare Part 2111 1 3126 4H.488.17.0.PR FUEL INLET PIPE METAILIC PRE FILTER TO TANK Spare Part 2412 1 3127 4H.488.90.0.00 KIT FOR ELECTRICAL FUEL FEED PUMP FITMENT IN 4K Spare Part 35886 1 3128 4H.489.11.0.PR ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 Spare Part 4465 1 3129 4H.489.14.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 Spare Part 3729 1 3130 4H.489.14.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 4194 1 3131 4H.489.16.0.PR COOLANT PIPE FOR DOSING MODUL	3119	4H.486.46.0.00	FUEL RETURN PIPE	Spare Part	822	15%
3122 4H.487.84.0.00 FLANGE Spare Part 652 1 3123 4H.488.03.0.00 FUEL FILLING HOSE: 36-125KVA FOR SKID MOUNTED GENSET Spare Part 920 1 3124 4H.488.04.0.00 INLET AND OULET CONNECTION FOR FUEL TANK MAIL END CONNECTION 210 HEIGHT Spare Part 366 1 3125 4H.488.16.0.PR FUEL INLET PIPE METAILIC FIP TO PRE FILTER Spare Part 2111 1 3126 4H.488.17.0.PR FUEL INLET PIPE METAILIC PRE FILTER TO TANK Spare Part 2412 1 3127 4H.488.90.0.00 KIT FOR ELECTRICAL FUEL FEED PUMP FITMENT IN 4K Spare Part 35886 1 3128 4H.489.11.0.PR ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 Spare Part 4465 1 3129 4H.489.12.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 Spare Part 3729 1 3130 4H.489.14.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 4194 1 3131 4H.489.15.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 2695 1 3133 4H.489.18.0.PR ADBLUE PIPE	3120	4H.486.92.0.00	FUEL PIPE PREFILTER TO FIP	Spare Part	840	15%
3123 4H.488.03.0.00 FUEL FILLING HOSE: 36-125KVA FOR SKID MOUNTED GENSET Spare Part 920 1 3124 4H.488.04.0.00 INLET AND OULET CONNECTION FOR FUEL TANK MAIL END CONNECTION 210 HEIGHT Spare Part 366 1 3125 4H.488.16.0.PR FUEL INLET PIPE METAILIC FIP TO PRE FILTER Spare Part 2111 1 3126 4H.488.17.0.PR FUEL INLET PIPE METAILIC PRE FILTER TO TANK Spare Part 2412 1 3127 4H.488.90.0.00 KIT FOR ELECTRICAL FUEL FEED PUMP FITMENT IN 4K Spare Part 35886 1 3128 4H.489.11.0.PR ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 Spare Part 4465 1 3129 4H.489.12.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 Spare Part 3729 1 3130 4H.489.14.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 4194 1 3131 4H.489.15.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 2695 1 3133 4H.489.18.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1 Spare Part 3941 1 3134	3121	4H.487.45.0.00	FUEL PIPE (FEED PUMP TO TANK UNIT)	Spare Part	2025	15%
3124 4H.488.04.0.00 INLET AND OULET CONNECTION FOR FUEL TANK MAIL END CONNECTION 210 HEIGHT Spare Part 366 1 3125 4H.488.16.0.PR FUEL INLET PIPE METAILIC FIP TO PRE FILTER Spare Part 2111 1 3126 4H.488.17.0.PR FUEL INLET PIPE METAILIC PRE FILTER TO TANK Spare Part 2412 1 3127 4H.488.90.0.00 KIT FOR ELECTRICAL FUEL FEED PUMP FITMENT IN 4K Spare Part 35886 1 3128 4H.489.11.0.PR ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 Spare Part 4465 1 3129 4H.489.12.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 Spare Part 3729 1 3130 4H.489.14.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 4194 1 3131 4H.489.15.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 2695 1 3132 4H.489.16.0.PR COOLANT PIPE FOR BUPPLY MODULE OUT TO DOSING MODULE IN 1 Spare Part 3941 1 3133 4H.489.18.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 Spare Part 3708 1	3122	4H.487.84.0.00	FLANGE	Spare Part	652	15%
3125 4H.488.16.0.PR FUEL INLET PIPE METAILIC FIP TO PRE FILTER Spare Part 2111 1 3126 4H.488.17.0.PR FUEL INLET PIPE METAILIC PRE FILTER TO TANK Spare Part 2412 1 3127 4H.488.90.0.00 KIT FOR ELECTRICAL FUEL FEED PUMP FITMENT IN 4K Spare Part 35886 1 3128 4H.489.11.0.PR ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 Spare Part 4465 1 3129 4H.489.12.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 Spare Part 3729 1 3130 4H.489.14.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 4194 1 3131 4H.489.15.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 7554 1 3132 4H.489.16.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 2695 1 3133 4H.489.18.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1 Spare Part 3941 1 3134 4H.489.19.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 Spare Part 3708 1	3123	4H.488.03.0.00	FUEL FILLING HOSE: 36-125KVA FOR SKID MOUNTED GENSET	Spare Part	920	15%
3126 4H.488.17.0.PR FUEL INLET PIPE METAILIC PRE FILTER TO TANK Spare Part 2412 1 3127 4H.488.90.0.00 KIT FOR ELECTRICAL FUEL FEED PUMP FITMENT IN 4K Spare Part 35886 1 3128 4H.489.11.0.PR ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 Spare Part 4465 1 3129 4H.489.12.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 Spare Part 3729 1 3130 4H.489.14.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 4194 1 3131 4H.489.15.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 7554 1 3132 4H.489.16.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 2695 1 3133 4H.489.18.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1 Spare Part 3941 1 3134 4H.489.19.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 Spare Part 3708 1	3124	4H.488.04.0.00	INLET AND OULET CONNECTION FOR FUEL TANK MAIL END CONNECTION 210 HEIGHT	Spare Part	366	15%
3127 4H.488.90.0.00 KIT FOR ELECTRICAL FUEL FEED PUMP FITMENT IN 4K Spare Part 35886 1 3128 4H.489.11.0.PR ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 Spare Part 4465 1 3129 4H.489.12.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 Spare Part 3729 1 3130 4H.489.14.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 4194 1 3131 4H.489.15.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 7554 1 3132 4H.489.16.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 2695 1 3133 4H.489.18.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1 Spare Part 3941 1 3134 4H.489.19.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 Spare Part 3708 1	3125	4H.488.16.0.PR	FUEL INLET PIPE METAILIC FIP TO PRE FILTER	Spare Part	2111	15%
3128 4H.489.11.0.PR ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 Spare Part 4465 1 3129 4H.489.12.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 Spare Part 3729 1 3130 4H.489.14.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 4194 1 3131 4H.489.15.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 7554 1 3132 4H.489.16.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 2695 1 3133 4H.489.18.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1 Spare Part 3941 1 3134 4H.489.19.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 Spare Part 3708 1	3126	4H.488.17.0.PR	FUEL INLET PIPE METAILIC PRE FILTER TO TANK	Spare Part	2412	15%
3129 4H.489.12.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 Spare Part 3729 1 3130 4H.489.14.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 4194 1 3131 4H.489.15.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 7554 1 3132 4H.489.16.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 2695 1 3133 4H.489.18.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1 Spare Part 3941 1 3134 4H.489.19.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 Spare Part 3708 1	3127	4H.488.90.0.00	KIT FOR ELECTRICAL FUEL FEED PUMP FITMENT IN 4K	Spare Part	35886	15%
3130 4H.489.14.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 4194 1 3131 4H.489.15.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 7554 1 3132 4H.489.16.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 2695 1 3133 4H.489.18.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1 Spare Part 3941 1 3134 4H.489.19.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 Spare Part 3708 1	3128	4H.489.11.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1	Spare Part	4465	15%
3131 4H.489.15.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 7554 1 3132 4H.489.16.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 2695 1 3133 4H.489.18.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1 Spare Part 3941 1 3134 4H.489.19.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 Spare Part 3708 1	3129	4H.489.12.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1	Spare Part	3729	15%
3132 4H.489.16.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 2695 1 3133 4H.489.18.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1 Spare Part 3941 1 3134 4H.489.19.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 Spare Part 3708 1	3130	4H.489.14.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1	Spare Part	4194	15%
3133 4H.489.18.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1 Spare Part 3941 1 3134 4H.489.19.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 Spare Part 3708 1	3131	4H.489.15.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2	Spare Part	7554	15%
3134 4H.489.19.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 Spare Part 3708 1	3132	4H.489.16.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3	Spare Part	2695	15%
	3133	4H.489.18.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1	Spare Part	3941	15%
3135 4H.489.21.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 1 Spare Part 2692 1	3134	4H.489.19.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2	Spare Part	3708	15%
	3135	4H.489.21.0.PR	COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 1	Spare Part	2692	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		·		without Vat in NPR	Charge%
3136	4H.489.22.0.PR	COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 2	Spare Part	3705	15%
3137	4H.489.23.0.PR	COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 3	Spare Part	4621	15%
3138	4H.489.24.0.PR	COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 4	Spare Part	4151	15%
3139	4H.491.01.0.00	ADAPTOR (ON AIR INLET MFOLD, ADAPTOR)	Spare Part	200	15%
3140	4H.493.08.0.00	SPACER FOR CONTROL PANNEL (9MM I.D. & 15MM O.D. 10MM L)	Spare Part	37	15%
3141	4H.505.10.0.00	FLYWHEEL ASSLY WITH STARTER RING	Spare Part	24372	15%
3142	4H.506.10.0.00	SUB ASSEMBLY OF SUCTION TUBE	Spare Part	477	15%
3143	4H.508.03.0.PR	RAIL HFRN16+RSD+PLV FOR 4K1080TAE (122.1kW @ 2500RPM) CEV3	Spare Part	44286	15%
3144	4H.508.06.0.PR	PHASE SENSOR PG 3 8 FOR 4K1080TAE 122 1kW 2500RPM CEV3	Spare Part	6295	15%
3145	4H.508.07.0.PR	ENGINE SPEED SENSOR DG6K FOR 4K1080TAE 122 1kW 2500RPM CEV3	Spare Part	4751	15%
3146	4H.508.08.0.00	TEMPERATURE SENSOR: 4K1080TAE 122.1KW	Spare Part	2809	15%
3147	4H.508.09.0.00	MANIFOLD ABSOLUTE PRESSURE SENSOR DS S3 TF 4BAR FOR 4K1080TAE 122 1kW 2500RPM	Spare Part	4381	15%
3148	4H.508.16.0.PR	INJECTOR CRIN 2 16 OHW FOR 4K1040TAE INJECTOR DRG NO 0 445 A44 010 NOZZLE DRG NO	Spare Part	47652	15%
3149	4H.508.23.0.PR	BOSCH EDC17CV44 ECU WITHOUT ETK BOSCH DRG NO 0 281 A01 204	Spare Part	721252	15%
3150	4H.508.24.0.00	HIGH PRESSURE PUMP CB28 3L OHW COMMON RAIL	Spare Part	155819	15%
3151	4H.508.70.0.PR	CRI INJECTOR FOR BS IV PROJECT 300 X 142 X 7	Spare Part	34461	15%
3152	4H.508.73.0.00	CRI INJECTOR FOR BS IV PROJECT KS NOZZLE 375 X 142 X 7	Spare Part	34215	15%
3153	4H.508.73.0.PR	CRI INJECTOR FOR BS IV PROJECT KS NOZZLE 375 X 142 X 7	Spare Part	34867	15%
3154	4H.508.81.0.PR	MANIFOLD ABSOLUTE PRESSURE SENSOR FOR NA GAS ENGINES PART NO 0 261 230 245	Spare Part	2766	15%
3155	4H.508.86.0.PR	Injector for 6K1080TA 200 kVA CPCB4 7 x 142 x 510 K 1 3 HE 10 5	Spare Part	46759	15%
3156	4H.522.03.0.00	JOINT: EXH DIFFUSER	Spare Part	483	15%
3157	4H.522.04.0.00	EXHAUST DIFUSSER	Spare Part	3480	15%
3158	4H.527.01.0.00	ADAPTOR: OIL SUPPLY	Spare Part	674	15%
3159	4H.527.10.0.00	LUBE OIL SUPPLY ASSLY	Spare Part	926	15%
3160	4H.527.20.0.00	LUB OIL DRAIN PIPE ASSEMBLY	Spare Part	529	15%
3161	4H.534.01.0.00	V BELT : XPB1540	Spare Part	1409	15%
3162	4H.535.02.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	923	15%
3163	4H.535.03.0.00	FUEL PIPE: M12XM14-900L	Spare Part	1391	15%
3164	4H.535.04.0.00	FUEL PIPE (M12 X M14) 1400 L	Spare Part	1920	15%
3165	4H.536.02.0.00	HOSE: AIR CLEANER	Spare Part	2345	15%
3166	4H.536.04.0.00	HOSE: AIR CLEANER	Spare Part	2520	15%
3167	4H.541.02.0.00	ADOPTER FOR ALTERNATOR MOUNTING	Spare Part	206	15%
3168	4H.541.05.0.00	SPACER (10.5 I.D X 20 O.D. X 23 LENGTH / MATERIAL - EN1A OR M.S.)	Spare Part	46	15%
3169	4H.544.01.0.00	LIFTING HOOK GEAR END SIDE	Spare Part	843	15%
3170	4H.546.01.0.00	EXHAUST ADAPTOR	Spare Part	3412	15%
3171	4H.5460.56.0.00	MCB 1POLE 20 AMPS PART NO C60 A9N1P20C MAKE SCHNEIDER	Spare Part	1212	15%
	4H.5460.58.0.00	MCB 1POLE 4 AMPS PART NO C60 A9N1P04C MAKE SCHNEIDER	Spare Part	2040	15%
3173	4H.548.01.0.00	BRACKET FOR RETURN SPRING	Spare Part	108	15%
3174	4H.550.10.0.00	THERMOSTAT & HOUSING	Spare Part	4449	15%
3175	4H.554.01.0.00	SPACER: RADIATOR FAN 30MM	Spare Part	1120	15%
	4H.560.10.0.00	LUBE OIL COOLER & HEADER ASSLY	Spare Part	11775	15%
3177	4H.560.30.0.PR	LUB OIL COOLER AND HEADER ASSEMBLY	Spare Part	17544	15%
3178	4H.560.40.0.PR	LUB OIL COOLER HEADER ASSEMBLY	Spare Part	9791	15%
3179	4H.561.01.0.00	SPACER: 11 IDX 24 OD X 25.5 L	Spare Part	68	15%
3180	4H.562.10.0.00	FUEL PUMP K ELEMENT: 4R1040	Spare Part	90590	15%
3181	4H.562.20.0.00	FEED PUMP	Spare Part	11188	15%
3182	4H.572.07.0.00	HOSE: FUEL FILLING	Spare Part	988	15%
3183	4H.573.10.0.00	DIPSTICK ASSEMBLY	Spare Part	129	15%
3184	4H.578.10.0.00	RAISED DIPSTICK ASSLY: 350MM	Spare Part	929	15%
3185	4H.585.14.0.00	LOW FUEL LEVEL SENSOR 145MM	Spare Part	2889	15%
3186	4H.585.16.0.PR	FUEL LEVEL SENSOR	Spare Part	3905	15%
3187	4H.592.10.0.00	FUEL INJECTION PUMP FOR 4R1040T PG	Spare Part	143937	15%
3188	4H.594.10.0.00	FUEL INJECTION PUMP : 4R1040TA-PG	Spare Part	134371	15%
	71 1.007. 10.0.00	I GEL INCESTION FORM . TIMETOTATES	Spare Fait	104011	10%
3189	4H.598.10.0.00	LEAK OFF PIPE ASSLY	Spare Part	1382	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
3191	4H.615.10.0.00	FLYWHEEL ASSLY	Spare Part	11978	15%
3192	4H.616.01.0.00	CRANK PULLEY 172 PCD, 1 GR,SPA	Spare Part	5348	15%
3193	4H.618.01.0.00	WATER PUMP PULLEY: 120PCD	Spare Part	2298	15%
3194	4H.618.10.0.00	WATER PUMP ASSLY 282.5 CRS PULLEY	Spare Part	13424	15%
3195	4H.626.11.0.00	ADAPTOR FOR AIR CLEANER	Spare Part	2255	15%
3196	4H.626.12.0.00	RUBBER HOSE FOR AIR CLEANER	Spare Part	2458	15%
3197	4H.626.13.0.00	BRACKET FOR AIR CLEANER MOUNTING ON INLET MANIFOLD	Spare Part	1000	15%
3198	4H.626.14.0.00	SPACER FOR AIR CLEANER BRACKET (OD 20X ID 9 X L 52)	Spare Part	83	15%
3199	4H.626.15.0.00	MOUNTING PLATE FOR FUEL FILTER	Spare Part	662	15%
3200	4H.641.03.0.00	BRACKET: ALTERNATOR MOUNTS	Spare Part	812	15%
3201	4H.643.01.0.00	HOSE: AIR CLEANER	Spare Part	2120	15%
3202	4H.652.10.0.00	FUEL PUMP: 4R1040PG	Spare Part	128728	15%
3203	4H.655.01.0.00	EXPANSION BELLOW	Spare Part	7597	15%
3204	4H.656.03.0.SP	SET OF JOINTS	Spare Part	8495	15%
3205	4H.656.23.0.00	SET OF O'RING (FOR 4H.2416/4H.3421/4H.3521	Spare Part	1677	15%
3206	4H.656.53.0.00	SET OF COPPER / RUBBER WASHER	Spare Part	1092	15%
3207	4H.657.01.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	683	15%
3208	4H.658.01.0.00	HEADER FOR L.O.C & FILTER S/F WATER JACKET HEATER	Spare Part	4708	15%
3209	4H.665.01.0.00	BRACKET FOR WATER SEPARATOR	Spare Part	723	15%
3210	4H.671.02.0.00	PUSH BUTTON (FOR HEATER)	Spare Part	655	15%
3211	4H.673.10.0.00	THERMOSTAT AND HOUSING ASSEMBLY	Spare Part	3951	15%
3212	4H.682.01.0.00	FLYWHEEL HOUSING	Spare Part	20914	15%
3213	4H.682.02.0.00	BLANKING PLATE FOR STARTER BORE	Spare Part	815	15%
3214	4H.682.03.0.00	FLANGE FOR STARTER	Spare Part	640	15%
3215	4H.682.04.0.00	FLYWHEEL HOUSING	Spare Part	21944	15%
3216	4H.683.01.0.00	STARTER RING	Spare Part	3913	20%
3217	4H.685.11.0.00	EXHAUST MANIFOLD (FWE TOP OPEN)	Spare Part	7015	15%
3218	4H.686.12.0.00	AIR PIPE(TURBO TO INLET PIPE)	Spare Part	3455	15%
3219	4H.687.50.0.00	ASSLY LUBE OIL INLET PIPE: K24 TC	Spare Part	837	15%
3220	4H.687.60.0.00	LUBE OIL DRAIN PIPE	Spare Part	495	15%
3221	4H.692.01.0.00	V BELT XPA 1280	Spare Part	1037	15%
3222	4H.692.02.0.00	V BELT SPA X 1280 X 2 PAIR	Spare Part	2271	15%
3223	4H.692.03.0.00	V BELT: SPA 1300AR ARMIDE WRAP	Spare Part	1831	15%
3224	4H.703.07.0.00	EYE BOLT : DIA 12X 220 LONG	Spare Part	582	15%
3225	4H.715.01.0.00	BRACKET FOR ACCELERATOR CABLE	Spare Part	978	15%
3226	4H.719.12.0.PR	ADAPTOR FOR SOLENOID	Spare Part	151	15%
3227	4H.719.20.0.00	LEAK OFF PIPE ASSEMBLY	Spare Part	1849	15%
3228	4H.723.01.0.00	ELECT RPM CUM HOUR METER 24V SF 172 PCD C PULLEY & 90 PCD ALT PULLEY	Spare Part	4585	15%
3229	4H.739.03.0.00	FUEL PIPE (90,14X14B-90 DEG, 700 WB)	Spare Part	566	15%
3230	4H.739.04.0.00	FUEL PIPE: 7.5 14X14B-90 DEG 520 WB	Spare Part	520	15%
3231	4H.760.03.0.00	RECOVERY TANK WITH PIPE:4RTA	Spare Part	1388	15%
3232	4H.761.02.0.00	STAY ROD: RADIATOR	Spare Part	283	15%
3233	4H.762.03.0.00	RECOVERY TANK WITH PIPE (FOR 2R TO 4R RADIATORS)	Spare Part	1603	15%
3234	4H.763.02.0.00	EXHAUST MANIFOLD	Spare Part	4366	15%
3235	4H.764.11.0.00	AIR PIPE TC TO INLET MFOLD	Spare Part	3941	15%
3236	4H.765.02.0.PR	LUBE OIL INLET PIPE	Spare Part	831	15%
3237	4H.765.50.0.00	ASSLY LUBE OIL INLET PIPE	Spare Part	1043	15%
3238	4H.765.60.0.00	L O DRAIN ARRANGEMENT FOR K24 VS TURBO TEREX VECTRA	Spare Part	437	15%
3239	4H.769.10.0.00	LEAK OFF PIPE ASSEMBLY	Spare Part	1683	15%
3240	4H.769.20.0.00	LEAK OFF PIPE ASSLY	Spare Part	1646	15%
3241	4H.774.04.0.00	HOSE: AIR CLEANER	Spare Part	3166	15%
3242	4H.775.04.0.00	FLANGE (AT SILENCER INLET & OUTLET) FOR 4R1040,4R1040T SILENT SET	Spare Part	1163	15%
3243	4H.779.01.0.00 4H.779.10.0.00	ADAPTOR (5/8 INCH UNF X M14)	Spare Part	169	15%
3244	1/1H / /U 3D D DD	THERMOSTAT & HSG ASSLY	Spare Part	3978	15%



				Price to	
C. No	Part Number	Part Description	Catagony	Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
20.40	411 770 00 0 00	THE DIAGOTAT AND HOUGHO (4/0) INT MALLOHOLD OCA David COVED +- FID CIDE	0 Dt	NPR	450/
3246	4H.779.60.0.00	THERMOSTAT AND HOUSING (1/2"NPT-M14 HOUSING, 90deg Bend COVER to FIP SIDE)	Spare Part	5526	15%
3247	4H.779.80.0.00	THERMOSTAT AND HSG ASSEMBLY (282.5 CRS, 1/2" NPTF BOTH SIDES AND UPWARD OPENING	Spare Part	6037	15%
3248	4H.781.01.0.00	GEAR END FOOT	Spare Part	1982	15%
3249	4H.781.02.0.00	GEAR END FOOT	Spare Part	2329	15%
3250	4H.781.11.0.00	NYLOCK NUT FOR JCB LOGING (M8X1.25)	Spare Part	25	15%
3251	4H.781.13.0.00	NYLOCK NUT FOR JCB LOGING (M14X 2)	Spare Part	46	15%
3252	4H.790.07.0.00	DRAIN PIPE FOR LUBE OIL SUMP	Spare Part	1391	15%
3253	4H.791.03.0.00	HOSE: AIR CLEANER	Spare Part	5289	15%
3254	4H.792.40.0.00	EXHAUST SILENCER	Spare Part	36473	15%
3255	4H.792.50.0.00	EXHAUST SILENCER SET: 82.5KVA	Spare Part	27043	15%
3256	4H.792.60.0.00	EXHAUST SILENCER	Spare Part	23744	15%
3257	4H.793.11.0.00	EXHAUST MANIFOLD (GE, TOP OPEN)	Spare Part	5492	15%
3258	4H.837.03.0.ASP	SAE 2DE BRKT PROT SCREEN ASLY KG34 KVA Rating 45 62 5 1Ph 82 5 160 3Ph Meccalte P	Spare Part	36107	15%
3259	4H.837.04.0.ASP	EXCITOR STATOR KG34 H 55mm 8P KVA Rating 45 62 5 1Ph	Spare Part	49233	15%
3260	4H.837.05.0.ASP	EXCITER ROTOR	Spare Part	50089	15%
3261	4H.837.06.0.ASP	FAN ASSEMBLY	Spare Part	32086	15%
3262	4H.844.02.0.00	DRAIN PIPE FOR LUB OIL SUMP	Spare Part	1560	15%
3263	4H.851.02.0.00	EMERGENCY PUSH STOP BUTTON	Spare Part	1594	15%
3264	4H.851.11.0.00	EMERGENCY STOP PUSH BUTTON TUNR TO RELESE NC ELMENT TECKNIC MAKE	Spare Part	997	15%
3265	4H.864.02.0.00	RELAY BOARD	Spare Part	5191	15%
3266	4H.864.07.0.00	SPACER FOR CONTROL PANEL ID 9 X OD 15X 30L	Spare Part	37	15%
3267	4H.865.01.0.00	RELAY BOARD: 4 RELAY	Spare Part	6071	15%
3268	4H.865.08.0.00	FUSE HOLDER WITH FUSE BLOWN INDICATOR	Spare Part	345	15%
3269	4H.865.09.0.00	GLASS FUSE 2AMP 20 MM	Spare Part	49	15%
3270	4H.865.16.0.00	SINGLE POLE MCB 32A	Spare Part	2877	15%
3271	4H.865.17.0.00	SELECTOR SWITCH	Spare Part	2618	15%
3272	4H.865.23.0.00	POWER TERMINAL BOARD 125 AMP. 4 WAY 8 MM STUD	Spare Part	735	15%
3273	4H.865.27.0.00	RELAY BOARD 2 & 1/2 12V DC	Spare Part	6683	15%
3274	4H.865.33.0.00	RELAY BOARD (4 RELAY) CONTACT RAITING 5 AMP.12 V DC 1 C/OWITH RELAY.	Spare Part	5246	15%
3275	4H.872.03.0.00	EARTHING CABLE (BRADED) 6MM DIA. WITH SUITABLE LUG. ALT. TO BASE PLATE FOR 50 & 72 M	Spare Part	649	15%
3276	4H.873.01.0.00	MCCB 200A, 3 POLE	Spare Part	56399	15%
3277	4H.878.07.0.00	BATTERY CHARGER - 6A 12V	Spare Part	6991	15%
3278	4H.878.14.0.PR	12V, 2A, BATTERY CHARGER, 15KV COMMON MODE SURGE ISOLATION	Spare Part	5920	15%
3279	4H.881.01.0.PR			138	15%
		EGT INLET OUTLET JOINT	Spare Part		
3280	4H.890.40.0.00	VDO SENSOR ASSEMBLY	Spare Part	4917	15%
3281	4H.896.07.0.00	FUEL PIPE: M14XM14B PARALLEL 750L FUEL PIPE: M14XM14 BANJO WITH 60 DEG. 370 L. 9.5 ID	Spare Part	1492 772	15%
3282	4H.896.08.0.00		Spare Part		15%
3283	4H.896.09.0.00	FUEL PIPE INLET: M14XM14 BANJO BOTH SIDE 900L	Spare Part	1615	15%
3284	4H.899.02.0.00	SPACER FOR AIR CLEANER BRACKET (OD 20X ID 9 X L 39)	Spare Part	52	15%
3285	4H.899.03.0.00	HOSE: AIR CLEANER	Spare Part	2689	15%
3286	4H.899.04.0.00	SLEEVE FOR AIR CLEANER HOSE	Spare Part	652	15%
3287	4H.899.11.0.00	RUBBER HOSE: K24 TC	Spare Part	735	15%
3288	4H.900.30.0.00	ENGINE WIRING HARNESS ASSEMBLY FOR PAVER APPLICATION BSIII	Spare Part	5394	15%
3289	4H.901.05.0.PR	KOEL GREEN Alternator, KG 125 S T Frame: L KG 44.3 D, SAE-2 11.5", 415V, 50 Hz, 0.8 PF	Spare Part	590503	15%
3290	4H.901.08.0.PR	KOEL GREEN ALTERNATOR COASTAL HUMID ENVIRONMENT KG 125 S T FRAME KG 44 3 D 1	Spare Part	628499	15%
3291	4H.901.11.0.PR	KOEL GREEN ALTERNATOR 40kVA KG32 1L4C SS FRAME M SAE 3 VOL 11 5 230V 50HZ 0 8 P F	Spare Part	371758	15%
3292	4H.901.12.0.PR	KOEL GREEN ALTERNATOR 40KVA ST FRAME M KG32 2S4C SAE3 VOL 11 5 415V 50HZ 0 8 P	Spare Part	295002	15%
3293	4H.905.20.0.00	WIRING HARNESS: 4R1040	Spare Part	11394	15%
3294	4H.906.11.0.00	RELAY 12VDC 100A MODEL BGR 256	Spare Part	1443	15%
3295	4H.906.40.0.00	WIRING HARNESS ASSEMBLY 4R1040TA	Spare Part	31406	15%
3296	4H.906.70.0.00	WIRING HARNESS ASSEMBLY 4R1040TA	Spare Part	28230	15%
3297	4H.907.01.0.00	COOLANT TEMP SWITCH 95 +1/-3 DEG	Spare Part	1037	15%
3298	4H.907.03.0.00	COOLANT TEMP SWITCH 104 1 3 DEG	Spare Part	1129	15%
3299	4H.924.30.0.00	WIRING HARNESS ASSEMBLY FOR KPCL WITH ETR TYPE SOL.	Spare Part	14600	15%
3300	4H.933.02.0.00	INJECTOR	Spare Part	11114	15%



				Price to	
				Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
				NPR	
	4H.933.04.0.00	INJECTOR	Spare Part	5126	15%
3302	4H.933.10.0.00	FUEL INJECTION PUMP 4R1040NA ENGINE (76HP @ 2200RPM)	Spare Part	85171	15%
3303	4H.933.35.0.PR	FUEL INJECTION PUMP FOR 4R1040NA 49 HP 2200 RPM WITH STOP LEVER BS III INDUSTRIAL	Spare Part	95648	15%
3304	4H.940.01.0.00	LUBE OIL SUMP FABRICATED (35 DEG, 265 HT, DRAIN PLUG ON FWE & GE BOTH))	Spare Part	12904	15%
3305	4H.941.10.0.00	SUB ASSEMBLY OF SUCTION TUBE	Spare Part	391	15%
3306	4H.944.02.0.00	COVER PLATE FOR FLYWHEEL HOUSING	Spare Part	295	15%
3307	4H.947.10.0.00	FLYWHEEL ASSEMBLY	Spare Part	14172	15%
3308	4H.947.20.0.00	FLYWHEEL ASSEMBLY	Spare Part	25680	15%
3309	4H.948.96.0.00	WASHER FOR WELD STUD M5	Spare Part	9	15%
3310	4H.954.10.0.00	MONOBLOCK CRANKCASE W/O MAIN BEARING	Spare Part	180204	15%
3311	4H.956.03.0.00	L SERIES 43MM INTEGRATED MIXER WITH THROTTLE BODY	Spare Part	198333	15%
3312	4H.956.05.0.00	SPARK PLUG, SIZE M12	Spare Part	572	15%
3313	4H.956.13.0.00	HT CABLE SET	Spare Part	7686	15%
3314	4H.956.15.0.00	DISTRIBUTOR IGNITION COIL 26941094A	Spare Part	7563	15%
3315	4H.956.39.0.00	WOODWARD R 600Z ZPR ZERO PRESSURE REGULATOR	Spare Part	54716	15%
3316	4H.956.44.0.00	SKF DEEP GROOVE SINGLE ROW, SEALED BALL BEARING (NO-61806-2RS1)	Spare Part	3138	15%
3317	4H.956.59.0.00	GASKET FOR L-SERIES GOVERNOR MOUNTING	Spare Part	28	15%
3318	4H.956.84.0.00	ADAPTOR 1 BSP TO 3 4 BSP	Spare Part	1068	15%
3319	4H.956.98.0.00	L SERIES 25MM INTEGRATED MIXER WITH THROTTLE BODY 8404 4001	Spare Part	188893	15%
3320	4H.964.01.0.00	TIMING POINTER	Spare Part	46	15%
3321	4H.973.10.0.00	EXPANSION BELLOW	Spare Part	8246	15%
3322	4H.979.06.0.00	BREATHER PIPE	Spare Part	822	15%
3323	4H.985.12.0.00	B12 ECU 40KVA APPL	Spare Part	18372	15%
3324	4H.986.20.0.00	WIRING HARNESS ASSLY: CPCB	Spare Part	5637	15%
3325	4H.996.20.0.PR	BATTERY CABLE 50 SQ MM FOR 24V SYSTEM	Spare Part	14301	15%
	4H.998.35.0.TOL	Nozzle Puller	Spare Part	7772	15%
3327	4H.999.120.0.00	COLD START KIT L3 FOR 4K	Spare Part	240068	15%
3328	4H.999.30.0.SP	SET OF JOINTS	Spare Part	9006	15%
3329	4H.999.35.0.00	4R1040 CPCB II Service Kit - B Check	Filter	3007	20%
3330	4H.999.36.0.00	4R1040 CPCB II Service Kit with Air Filter - C Check	Filter	6495	20%
	4H.999.50.0.00	HALF OVERHAUL KIT 4R1040 INDL	Spare Part	59830	15%
3332	4H.999.60.0.SP	MAJOR OVERHAUL KIT 4R1040 BSIII CAT, CNH, ECEL, ACE, ATLAS APPLICATION ENGINES	Spare Part	84900	15%
3333	4H.999.70.0.SP	MAJOR OH KIT 4R1040 BSIII TEREX, APOLLO, ECEL, AJAX APPLICATION ENGINES	Spare Part	86242	15%
3334	4H.999.80.0.00	SERVICE KIT 500 HRS: 4R1040 BSIII INDL	Filter	4035	20%
	4H.999.85.0.00	AIR FILTER KIT A-4R1040 BS3 INDL	Filter	4638	20%
3336	4H.999.90.0.00	AIR FILTER KIT B -4R1040 BS3 INDL	Filter	8317	20%
3337	4H.EGT4.22.0.PR	7.5 Gasket DOC TO Mixer 82544598	Spare Part	3868	15%
		DOSING MODULE B444 606 505 DM2 2 3 HOLE 5 BAR		27332	15%
	4H.EGT4.23.0.PR		Spare Part		
	50.002.05.025.	SET BOLT - M5X0.8X25- 8.8	Spare Part	18	15%
3340	50.002.06.035.	SET BOLT - M6X1X35 - 8.8	Spare Part	46	15%
3341	50.002.06.040.	SET BOLT - M6X1X40 - 8.8	Spare Part	43	15%
3342	50.002.06.050.	SET BOLT - M6X1X50 - 8.8	Spare Part	28	15%
3343	50.002.06.060.	SET BOLT - M6X1X60 - 8.8	Spare Part	43	15%
3344	50.002.08.016.	SET BOLT - M8X1.25X16 - 8.8	Spare Part	46	15%
3345	50.002.08.025.	SET BOLT - M8X1.25X25 - 8.8	Spare Part	31	15%
3346	50.002.08.030.	SET BOLT - M8X1.25X30 - 8.8	Spare Part	46	15%
3347	50.002.08.035.	SET BOLT : M8X1.25X35 -8.8	Spare Part	46	15%
3348	50.002.08.040.	SET BOLT - M8X1.25X40 - 8.8	Spare Part	46	15%
3349	50.002.08.045.	SET BOLT : M8X1.25X45 - 8.8	Spare Part	58	15%
3350	50.002.08.050.	SET BOLT - M8X1.25X50 - 8.8	Spare Part	49	15%
3351	50.002.08.055.	SET BOLT - M8X1.25X55 - 8.8	Spare Part	52	15%
3352	50.002.08.060.	SET BOLT - M8X1.25X60 - 8.8	Spare Part	52	15%
3353	50.002.08.065.	SET BOLT - M8X1.25X65 - 8.8	Spare Part	49	15%
3354	50.002.08.070.	SET BOLT: M8X1.25X70 -8.8	Spare Part	46	15%
3355	50.002.08.075.	SET BOLT - M8X1.25X75 - 8.8	Spare Part	58	15%



Section					Price to	
### Without Mark 3836 \$0.002.08.080 SET BOLT - MINK 1,2590 - 8 8 Spere Part C 3836 \$0.002.08.085 SET BOLT - MINK 1,2590 - 8 8 Spere Part C 3836 \$0.002.08.085 SET BOLT - MINK 1,2590 - 8 8 Spere Part C 3837 \$0.002.08.085 SET BOLT - MINK 1,2590 - 8 8 Spere Part C 3839 \$0.002.08.085 SET BOLT - MINK 1,2590 - 8 8 Spere Part C 3839 \$0.002.08.085 SET BOLT - MINK 1,2590 - 8 8 Spere Part C 3839 \$0.002.08.085 SET BOLT - MINK 1,2590 - 8 8 Spere Part C 3839 \$0.002.08.085 SET BOLT - MINK 1,2590 - 8 8 Spere Part C 3839 \$0.002.08.105 SET BOLT - MINK 1,2590 - 8 8 Spere Part C 3839 \$0.002.08.105 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3839 \$0.002.08.105 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3839 \$0.002.08.105 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3839 \$0.002.08.105 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3839 \$0.002.08.105 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3839 \$0.002.08.105 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3839 \$0.002.08.105 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3839 \$0.002.08.105 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3839 \$0.002.002.005 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3839 \$0.002.002.005 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3839 \$0.002.005 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3839 \$0.002.005 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3837 \$0.002.005 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3837 \$0.002.005 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3837 \$0.002.005 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3837 \$0.002.005 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3837 \$0.002.005 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3838 \$0.002.005 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3838 \$0.002.005 SET BOLT - MINK 1,25910 - 8 8 Spere Part C 3839 \$0.002.005	Sr.No.	Part Number	Part Description	Category	Customer	Custom
3596 50.002.08.090			, was 2550 page.	,	without Vat in	Charge%
3398 00.002.08.096 SET BOLT - MINEX (22000 - 8.8 Spare Plant 6.8	3356	50 002 08 080	SET BOLT - M8X1,25X80 - 8.8	Spare Part	58	15%
Spec Part				,	65	15%
1999 20 0002 08 095 SET BOLT - MINEY JESSIS - 8 Spee Part 6				•	52	15%
Space Spac				•	86	15%
Saper Sape				•	71	15%
Separa S					68	15%
Span Part					68	15%
September Sept			SET BOLT - M8X1.25X115 - 8.8	•	98	15%
Space Part					71	15%
13366 50 002 08 130 HEXAGONAL HEADED BOLT - MIX 130L Spare Part 7 7 7 7 7 7 7 7 7					215	15%
Spare Part Spa					77	15%
3368 50.0021.0.020. SET BOLT - MIOXI 5X20 - 8.8 Spare Part 6.8				,	95	15%
3370 3000210.025. SET BOLT - MIOX1.5X25 - 8.8 Spare Part 3.3371 500021.0035. SET BOLT - MIOX1.5X35 - 8.8 Spare Part 3.3371 500021.0035. SET BOLT - MIOX1.5X35 - 8.8 Spare Part 3.3371 500021.0035. SET BOLT - MIOX1.5X35 - 8.8 Spare Part 7.7 Spare				•	62	15%
3370				•	89	15%
3371				•	37	15%
3372 50.002.10.040. SET BOLT - M10X1.5X40 - 8.8 Spare Part 57 55.002.10.045. SET BOLT - M10X1.5X45 - 8.8 Spare Part 58					58	15%
3373 50.002.10.045. SET BOLT - M10X1.5X45 - 8.8 Spare Part 5.8				,	71	15%
3374 50.002.10.050. SET BOLT - M10X1.5X50 - 8.8 Spare Part 50.002.10.055. SET BOLT - M10X1.5X50 - 8.8 Spare Part 73.3376 50.002.10.065. SET BOLT - M10X1.5X65 - 8.8 Spare Part 73.3378 50.002.10.065. SET BOLT - M10X1.5X65 - 8.8 Spare Part 50.002.10.065. SET BOLT - M10X1.5X65 - 8.8 Spare Part 50.002.10.075. SET BOLT - M10X1.5X75 - 8.8 Spare Part 50.002.10.075. SET BOLT - M10X1.5X75 - 8.8 Spare Part 50.002.10.075. SET BOLT - M10X1.5X75 - 8.8 Spare Part 50.002.10.075. SET BOLT - M10X1.5X75 - 8.8 Spare Part 50.002.10.075. SET BOLT - M10X1.5X75 - 8.8 Spare Part 50.002.10.075. SET BOLT - M10X1.5X75 - 8.8 Spare Part 50.002.10.080. SET BOLT - M10X1.5X80 - 8.8 Spare Part 50.002.10.080. SET BOLT - M10X1.5X80 - 8.8 Spare Part 50.002.10.080. SET BOLT - M10X1.5X80 - 8.8 Spare Part 50.002.10.080. SET BOLT - M10X1.5X80 - 8.8 Spare Part 50.002.10.080. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.100. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.100. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.100. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.110. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.110. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.110. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.110. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.110. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.110. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.10. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.10. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.10. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.10. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.10. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.10. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.10. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.10. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.10. SET BOLT - M10X1.5X10 - 8.8				•	86	15%
3376				•	58	15%
3376				•	77	15%
3377					55	15%
3378 \$0.002.10.070. SET BOLT - M10X1.5X70 - 8.8 Spare Part \$0.002.10.075. SET BOLT - M10X1.5X75 - 8.8 Spare Part \$0.002.10.076. SET BOLT - M10X1.5X75 - 8.8 Spare Part \$0.002.10.080. SET BOLT - M10X1.5X80 - 8.8 Spare Part \$0.002.10.080. SET BOLT - M10X1.5X80 - 8.8 Spare Part \$0.002.10.080. SET BOLT - M10X1.5X80 - 8.8 Spare Part \$0.002.10.090. SET BOLT - M10X1.5X90 - 8.8 Spare Part \$0.002.10.100. SET BOLT - M10X1.5X10 - 8.8 Spare Part \$0.002.10.100. SET BOLT - M10X1.5X10 - 8.8 Spare Part \$0.002.10.100. SET BOLT - M10X1.5X110 - 8.8 Spare Part \$0.002.10.100. SET BOLT - M10X1.5X110 - 8.8 Spare Part \$0.002.10.100. SET BOLT - M10X1.5X110 - 8.8 Spare Part \$0.002.10.100. SET BOLT - M10X1.5X120 - 8.8 Spare Part \$0.002.10.120. SET BOLT - M10X1.5X120 - 8.8 Spare Part \$0.002.10.120. SET BOLT - M10X1.5X120 - 8.8 Spare Part \$0.002.10.120. SET BOLT - M10X1.5X120 - 8.8 Spare Part \$0.002.10.120. SET BOLT - M10X1.5X120 - 8.8 Spare Part \$0.002.10.120. SET BOLT - M10X1.5X120 - 8.8 Spare Part \$0.002.10.120. SET BOLT - M10X1.5X120 - 8.8 Spare Part \$0.002.10.120. SET BOLT - M10X1.5X140 - 8.8 Spare Part \$0.002.10.120. SET BOLT - M10X1.5X140 - 8.8 Spare Part \$0.002.10.120. SET BOLT - M10X1.5X140 - 8.8 Spare Part \$0.002.10.120. SET BOLT - M10X1.5X160 - 8.8 Spare Part \$0.002.10.120. SET BOLT - M10X1.5X160 - 8.8 Spare Part \$0.002.10.120. SET BOLT - M10X1.5X160 - 8.8 Spare Part \$0.002.10.120. SET BOLT - M10X1.5X160 - 8.8 Spare Part \$0.002.12.000. SET BOLT - M12X1.75X20 - 8.8 Spare Part \$0.002.12.000. SET BOLT - M12X1.75X20 - 8.8 Spare Part \$0.002.12.000. SET BOLT - M12X1.75X20 - 8.8 Spare Part \$0.002.12.000. SET BOLT - M12X1.75X20 - 8.8 Spare Part \$0.002.12.000. SET BOLT - M12X1.75X20 - 8.8 Spare Part \$0.002.12.000. SET BOLT - M12X1.75X20 - 8.8 Spare Part \$0.002.12.000. SET BOLT - M12X1.75X20 - 8.8 Spare Part \$0.002.12.000. SET BOLT - M12X1				,	58	15%
3379 50.002.10.075. SET BOLT - M10X1.5X75 - 8.8 Spare Part 50.002.10.080. SET BOLT - M10X1.5X80 - 8.8 Spare Part 50.002.10.080. SET BOLT - M10X1.5X80 - 8.8 Spare Part 50.002.10.085. SET BOLT - M10X1.5X80 - 8.8 Spare Part 50.002.10.085. SET BOLT - M10X1.5X80 - 8.8 Spare Part 50.002.10.085. Spare Part 50.002.10.190. SET BOLT - M10X1.5X100 - 8.8 Spare Part 50.002.10.110. SET BOLT - M10X1.5X110 - 8.8 Spare Part 50.002.10.115. SET BOLT - M10X1.5X110 - 8.8 Spare Part 50.002.10.115. SET BOLT - M10X1.5X120 - 8.8 Spare Part 50.002.10.120. SET BOLT - M10X1.5X125 - 8.8 Spare Part 50.002.10.120. SET BOLT - M10X1.5X125 - 8.8 Spare Part 50.002.10.130. SET BOLT - M10X1.5X125 - 8.8 Spare Part 50.002.10.130. SET BOLT - M10X1.5X140 - 8.8 Spare Part 50.002.10.130. SET BOLT - M10X1.5X140 - 8.8 Spare Part 50.002.10.130. SET BOLT - M10X1.5X140 - 8.8 Spare Part 50.002.10.130. SET BOLT - M10X1.5X160 - 8.8 Spare Part 50.002.10.150. SET BOLT - M10X1.5X160 - 8.8 Spare Part 50.002.10.150. SET BOLT - M10X1.5X160 - 8.8 Spare Part 50.002.10.150. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.040. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.040. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.040. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X40 - 8.8 Spare Part 5				•	68	15%
3380 50.002.10.080. SET BOLT - M10X1.5X80 - 8.8 Spare Part 50.002.10.085. SET BOLT - M10X1.5X85 - 8.8 Spare Part 50.002.10.086. SET BOLT - M10X1.5X85 - 8.8 Spare Part 50.002.10.080. SET BOLT - M10X1.5X90 - 8.8 Spare Part 50.002.10.080. SET BOLT - M10X1.5X10 - 8.8 Spare Part 50.002.10.100. SET BOLT - M10X1.5X110 - 8.8 Spare Part 50.002.10.110. SET BOLT - M10X1.5X115 - 8.8 Spare Part 50.002.10.110. SET BOLT - M10X1.5X115 - 8.8 Spare Part 50.002.10.120. SET BOLT - M10X1.5X115 - 8.8 Spare Part 50.002.10.120. SET BOLT - M10X1.5X120 - 8.8 Spare Part 50.002.10.120. SET BOLT - M10X1.5X120 - 8.8 Spare Part 50.002.10.120. SET BOLT - M10X1.5X130 - 8.8 Spare Part 50.002.10.130. SET BOLT - M10X1.5X130 - 8.8 Spare Part 50.002.10.130. SET BOLT - M10X1.5X140 - 8.8 Spare Part 50.002.10.150. SET BOLT - M10X1.5X140 - 8.8 Spare Part 50.002.10.150. SET BOLT - M10X1.5X140 - 8.8 Spare Part 50.002.10.150. SET BOLT - M10X1.5X140 - 8.8 Spare Part 50.002.10.150. SET BOLT - M10X1.5X140 - 8.8 Spare Part 50.002.10.150. SET BOLT - M10X1.5X150 - 8.8 Spare Part 50.002.10.150. SET BOLT - M10X1.5X150 - 8.8 Spare Part 50.002.10.150. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.10.150. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.030. SET BOLT - M12X1.75X40 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 50.002.12.050. SET BOLT - M				•	92	15%
3381 50.002.10.085. SET BOLT - M10X1.5X85 - 8.8 Spare Part 55.				•	92	15%
3382 50.002.10.090. SET BOLT - M10X1.5X90 - 8.8 Spare Part 66.					95	15%
3383 50.002.10.100. SET BOLT - M10X1.5X100 - 8.8 Spare Part 14				,	65	15%
3384 50.002.10.110. SET BOLT - M10X1.5X110 - 8.8 Spare Part 15 3385 50.002.10.115. SET BOLT - M10X1.5X115 - 8.8 Spare Part 6 3386 50.002.10.120. SET BOLT - M10X1.5X120 - 8.8 Spare Part 14 3387 50.002.10.125. SET BOLT - M10X1.5X130 - 8.8 Spare Part 18 3388 50.002.10.130. SET BOLT - M10X1.5X130 - 8.8 Spare Part 18 3389 50.002.10.140. SET BOLT - M10X1.5X150 - 8.8 Spare Part 18 3390 50.002.10.160. SET BOLT - M10X1.5X160 - 8.8 Spare Part 18 3391 50.002.12.030. SET BOLT - M10X1.5X160 - 8.8 Spare Part 18 3392 50.002.12.040. SET BOLT - M12X1.75X40 - 8.8 Spare Part 8 3393 50.002.12.040. SET BOLT - M12X1.75X45 - 8.8 Spare Part 9 3394 50.002.12.045. SET BOLT - M12X1.75X45 - 8.8 Spare Part 9 3396 50.002.12.045. SET BOLT - M12X1.75X45 - 8.8 Spare Part 10 3397 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 10 <td></td> <td></td> <td></td> <td>•</td> <td>142</td> <td>15%</td>				•	142	15%
3385 50.002.10.115. SET BOLT - M10X1.5X115 - 8.8 Spare Part 6 3386 50.002.10.120. SET BOLT - M10X1.5X120 - 8.8 Spare Part 14 3387 50.002.10.125. SET BOLT - M10X1.5X130 - 8.8 Spare Part 8 3388 50.002.10.130. SET BOLT - M10X1.5X130 - 8.8 Spare Part 13 3389 50.002.10.140. SET BOLT - M10X1.5X140 - 8.8 Spare Part 18 3390 50.002.10.160. SET BOLT - M10X1.5X160 - 8.8 Spare Part 18 3391 50.002.10.160. SET BOLT - M12X1.75X30 - 8.8 Spare Part 8 3393 50.002.12.040. SET BOLT - M12X1.75X40 - 8.8 Spare Part 8 3394 50.002.12.045. SET BOLT - M12X1.75X45 - 8.8 Spare Part 5 3395 50.002.12.066. SET BOLT - M12X1.75X45 - 8.8 Spare Part 10 3396 50.002.12.066. SET BOLT - M12X1.75X55 - 8.8 Spare Part 10 3397 50.002.12.066. SET BOLT - M12X1.75X65 - 8.8 Spare Part 8 3399 50.				•	191	15%
3386 50.002.10.120. SET BOLT - M10X1.5X120 - 8.8 Spare Part 14 3387 50.002.10.125. SET BOLT - M10X1.5X125 - 8.8 Spare Part 8 3388 50.002.10.130. SET BOLT - M10X1.5X140 - 8.8 Spare Part 13 3389 50.002.10.140. SET BOLT - M10X1.5X140 - 8.8 Spare Part 18 3390 50.002.10.150. SET BOLT - M10X1.5X150 - 8.8 Spare Part 18 3391 50.002.10.160. SET BOLT - M10X1.5X160 - 8.8 Spare Part 18 3392 50.002.12.030. SET BOLT - M12X1.75X30 - 8.8 Spare Part 18 3393 50.002.12.040. SET BOLT - M12X1.75X45 - 8.8 Spare Part 26 3394 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 10 3396 50.002.12.050. SET BOLT - M12X1.75X60 - 8.8 Spare Part 10 3397 50.002.12.055. SET BOLT - M12X1.75X60 - 8.8 Spare Part 10 3398 50.002.12.060. SET BOLT - M12X1.75X60 - 8.8 Spare Part 10 3399 50.002.12.060. SET BOLT - M12X1.75X60 - 8.8 Spare Part 50				•	68	15%
3387 50.002.10.125. SET BOLT - M10X1.5X125 - 8.8 Spare Part 8 3388 50.002.10.130. SET BOLT - M10X1.5X130 - 8.8 Spare Part 13 3389 50.002.10.140. SET BOLT - M10X1.5X140 - 8.8 Spare Part 16 3390 50.002.10.150. SET BOLT - M10X1.5X150 - 8.8 Spare Part 18 3391 50.002.10.160. SET BOLT - M10X1.5X160 - 8.8 Spare Part 18 3392 50.002.12.040. SET BOLT - M12X1.75X30 - 8.8 Spare Part 8 3393 50.002.12.040. SET BOLT - M12X1.75X40 - 8.8 Spare Part 8 3394 50.002.12.045. SET BOLT - M12X1.75X50 - 8.8 Spare Part 10 3396 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 10 3397 50.002.12.060. SET BOLT - M12X1.75X60 - 8.8 Spare Part 10 3398 50.002.12.060. SET BOLT - M12X1.75X70 - 8.8 Spare Part 26 3399 50.002.12.060. SET BOLT - M12X1.75X60 - 8.8 Spare Part 10 3400 50.002.12.000. SET BOLT - M12X1.75X10 - 8.8 Spare Part 12 </td <td></td> <td></td> <td></td> <td></td> <td>145</td> <td>15%</td>					145	15%
3388 50.002.10.130. SET BOLT - M10X1.5X130 - 8.8 Spare Part 13 3389 50.002.10.140. SET BOLT - M10X1.5X140 - 8.8 Spare Part 18 3390 50.002.10.150. SET BOLT - M10X1.5X150 - 8.8 Spare Part 18 3391 50.002.10.160. SET BOLT - M10X1.5X160 - 8.8 Spare Part 18 3392 50.002.12.030. SET BOLT - M12X1.75X30 - 8.8 Spare Part 8 3393 50.002.12.040. SET BOLT - M12X1.75X45 - 8.8 Spare Part 8 3394 50.002.12.045. SET BOLT - M12X1.75X55 - 8.8 Spare Part 10 3395 50.002.12.045. SET BOLT - M12X1.75X55 - 8.8 Spare Part 10 3396 50.002.12.055. SET BOLT - M12X1.75X55 - 8.8 Spare Part 10 3397 50.002.12.066. SET BOLT - M12X1.75X60 - 8.8 Spare Part 8 3398 50.002.12.065. SET BOLT - M12X1.75X60 - 8.8 Spare Part 10 3399 50.002.12.065. SET BOLT - M12X1.75X60 - 8.8 Spare Part 10 3400				,	89	15%
3389 50.002.10.140. SET BOLT - M10X1.5X140 - 8.8 Spare Part 18 3390 50.002.10.150. SET BOLT - M10X1.5X150 - 8.8 Spare Part 18 3391 50.002.10.160. SET BOLT - M10X1.5X160 - 8.8 Spare Part 18 3392 50.002.12.030. SET BOLT - M12X1.75X30 - 8.8 Spare Part 8 3393 50.002.12.040. SET BOLT - M12X1.75X40 - 8.8 Spare Part 8 3394 50.002.12.045. SET BOLT - M12X1.75X45 - 8.8 Spare Part 10 3395 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 10 3396 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 10 3397 50.002.12.060. SET BOLT - M12X1.75X60 - 8.8 Spare Part 10 3398 50.002.12.065. SET BOLT - M12X1.75X70 - 8.8 Spare Part 12 3399 50.002.12.065. SET BOLT - M12X1.75X70 - 8.8 Spare Part 14 3400 50.002.12.070. SET BOLT - M12X1.75X90 - 8.8 Spare Part 15 3401 <td< td=""><td></td><td></td><td></td><td>•</td><td></td><td>15%</td></td<>				•		15%
3390 50.002.10.150. SET BOLT - M10X1.5X150 - 8.8 Spare Part 18 3391 50.002.10.160. SET BOLT : M10X1.5X160 - 8.8 Spare Part 18 3392 50.002.12.030. SET BOLT - M12X1.75X30 - 8.8 Spare Part 8 3393 50.002.12.040. SET BOLT - M12X1.75X40 - 8.8 Spare Part 8 3394 50.002.12.045. SET BOLT - M12X1.75X50 - 8.8 Spare Part 9 3395 50.002.12.050. SET BOLT - M12X1.75X55 - 8.8 Spare Part 10 3396 50.002.12.055. SET BOLT - M12X1.75X56 - 8.8 Spare Part 10 3397 50.002.12.060. SET BOLT - M12X1.75X60 - 8.8 Spare Part 8 3398 50.002.12.065. SET BOLT - M12X1.75X60 - 8.8 Spare Part 9 3399 50.002.12.066. SET BOLT - M12X1.75X70 - 8.8 Spare Part 9 3399 50.002.12.065. SET BOLT - M12X1.75X00 - 8.8 Spare Part 9 3400 50.002.12.006. SET BOLT - M12X1.75X00 - 8.8 Spare Part 9 3401 50.002.12.000. SET BOLT - M12X1.75X100 - 8.8 Spare Part 16					182	15%
3391 50.002.10.160. SET BOLT: M10X1.5X160 -8.8 Spare Part 18 3392 50.002.12.030. SET BOLT - M12X1.75X30 - 8.8 Spare Part 8 3393 50.002.12.040. SET BOLT - M12X1.75X45 - 8.8 Spare Part 8 3394 50.002.12.045. SET BOLT - M12X1.75X45 - 8.8 Spare Part 10 3395 50.002.12.050. SET BOLT - M12X1.75X55 - 8.8 Spare Part 10 3396 50.002.12.065. SET BOLT - M12X1.75X56 - 8.8 Spare Part 10 3397 50.002.12.060. SET BOLT - M12X1.75X65 - 8.8 Spare Part 8 3398 50.002.12.060. SET BOLT - M12X1.75X66 - 8.8 Spare Part 8 3399 50.002.12.060. SET BOLT - M12X1.75X766 - 8.8 Spare Part 9 3399 50.002.12.060. SET BOLT - M12X1.75X766 - 8.8 Spare Part 9 3400 50.002.12.070. SET BOLT - M12X1.75X70 - 8.8 Spare Part 14 3401 50.002.12.090. SET BOLT - M12X1.75X100 - 8.8 Spare Part 15 3402 50.002.12.160. SET BOLT - M12X1.75X160 - 8.8 Spare Part 42 <td></td> <td></td> <td></td> <td>•</td> <td></td> <td>15%</td>				•		15%
3392 50.002.12.030. SET BOLT - M12X1.75X30 - 8.8 Spare Part 8 3393 50.002.12.040. SET BOLT - M12X1.75X40 - 8.8 Spare Part 8 3394 50.002.12.045. SET BOLT - M12X1.75X45 - 8.8 Spare Part 9 3395 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 10 3396 50.002.12.055. SET BOLT - M12X1.75X50 - 8.8 Spare Part 10 3397 50.002.12.060. SET BOLT - M12X1.75X60 - 8.8 Spare Part 8 3398 50.002.12.065. SET BOLT - M12X1.75X70 - 8.8 Spare Part 9 3400 50.002.12.070. SET BOLT - M12X1.75X70 - 8.8 Spare Part 14 3401 50.002.12.090. SET BOLT - M12X1.75X100 - 8.8 Spare Part 15 3402 50.002.12.100. SET BOLT - M12X1.75X160 - 8.8 Spare Part 48 3403 50.002.12.160. SET BOLT - M12X1.75X160 - 8.8 Spare Part 42 3404 50.002.12.160. SET BOLT - M12X1.75X160 - 8.8 Spare Part 42 3404 50.002.12.160. SET BOLT - M12X1.75X160 - 8.8 Spare Part 58					188	15%
3393 50.002.12.040. SET BOLT - M12X1.75X40 - 8.8 Spare Part 8 3394 50.002.12.045. SET BOLT - M12X1.75X45 - 8.8 Spare Part 9 3395 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 10 3396 50.002.12.055. SET BOLT - M12X1.75X55 - 8.8 Spare Part 10 3397 50.002.12.060. SET BOLT - M12X1.75X60 - 8.8 Spare Part 8 3398 50.002.12.065. SET BOLT - M12X1.75X65 - 8.8 Spare Part 9 3399 50.002.12.070. SET BOLT - M12X1.75X70 - 8.8 Spare Part 14 3400 50.002.12.090. SET BOLT - M12X1.75X10 - 8.8 Spare Part 15 3401 50.002.12.100. SET BOLT - M12X1.75X10 - 8.8 Spare Part 15 3402 50.002.12.160. SET BOLT - M12X1.75X160 - 8.8 Spare Part 46 3404 50.002.12.160. SET BOLT - M12X1.75X200 - 8.8 Spare Part 56 3405 50.002.14.045. SET BOLT - M14X2X45 - 8.8 Spare Part 16 3406 50.002.14.050. SET BOLT - M14X2X60 - 8.8 Spare Part 26				,	89	15%
3394 50.002.12.045. SET BOLT - M12X1.75X45 - 8.8 Spare Part 9 3395 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 10 3396 50.002.12.065. SET BOLT - M12X1.75X60 - 8.8 Spare Part 10 3397 50.002.12.060. SET BOLT - M12X1.75X60 - 8.8 Spare Part 8 3398 50.002.12.065. SET BOLT - M12X1.75X70 - 8.8 Spare Part 9 3400 50.002.12.070. SET BOLT - M12X1.75X70 - 8.8 Spare Part 14 3400 50.002.12.090. SET BOLT - M12X1.75X90 - 8.8 Spare Part 15 3401 50.002.12.100. SET BOLT - M12X1.75X100 - 8.8 Spare Part 15 3402 50.002.12.150. SET BOLT - M12X1.75X160 - 8.8 Spare Part 48 3403 50.002.12.160. SET BOLT - M12X1.75X200 - 8.8 Spare Part 42 3404 50.002.12.200. SET BOLT - M14X1.75X200 - 8.8 Spare Part 16 3405 50.002.14.045. SET BOLT - M14X2X50 - 8.8 Spare Part 16 3406 50.002.14.050. SET BOLT - M14X2X50 - 8.8 Spare Part 26 <td></td> <td></td> <td></td> <td></td> <td>86</td> <td>15%</td>					86	15%
3395 50.002.12.050. SET BOLT - M12X1.75X50 - 8.8 Spare Part 10 3396 50.002.12.055. SET BOLT - M12X1.75X55 - 8.8 Spare Part 10 3397 50.002.12.060. SET BOLT - M12X1.75X60 - 8.8 Spare Part 8 3398 50.002.12.065. SET BOLT - M12X1.75X70 - 8.8 Spare Part 14 3400 50.002.12.070. SET BOLT - M12X1.75X90 - 8.8 Spare Part 14 3401 50.002.12.090. SET BOLT - M12X1.75X100 - 8.8 Spare Part 15 3401 50.002.12.100. SET BOLT - M12X1.75X150 - 8.8 Spare Part 15 3402 50.002.12.150. SET BOLT - M12X1.75X160 - 8.8 Spare Part 48 3403 50.002.12.160. SET BOLT - M12X1.75X200 - 8.8 Spare Part 42 3404 50.002.12.200. SET BOLT - M12X1.75X200 - 8.8 Spare Part 58 3405 50.002.14.045. SET BOLT - M14X2X45 - 8.8 Spare Part 16 3406 50.002.14.050. SET BOLT - M14X2X60 - 8.8 Spare Part 28					95	
3396 50.002.12.055. SET BOLT - M12X1.75X55 - 8.8 Spare Part 10 3397 50.002.12.060. SET BOLT - M12X1.75X60 - 8.8 Spare Part 8 3398 50.002.12.065. SET BOLT - M12X1.75X76 - 8.8 Spare Part 9 3399 50.002.12.070. SET BOLT - M12X1.75X70 - 8.8 Spare Part 14 3400 50.002.12.090. SET BOLT - M12X1.75X90 - 8.8 Spare Part 9 3401 50.002.12.100. SET BOLT - M12X1.75X100 - 8.8 Spare Part 15 3402 50.002.12.150. SET BOLT - M12X1.75X160 - 8.8 Spare Part 48 3403 50.002.12.160. SET BOLT - M12X1.75X200 - 8.8 Spare Part 42 3404 50.002.12.200. SET BOLT - M12X1.75X200 - 8.8 Spare Part 58 3405 50.002.14.045. SET BOLT - M14X2X45 - 8.8 Spare Part 16 3406 50.002.14.050. SET BOLT - M14X2X50 - 8.8 Spare Part 28 3407 50.002.14.060. SET BOLT - M14X2X60 - 8.8 Spare Part 28				•	108	15%
3397 50.002.12.060. SET BOLT - M12X1.75X60 - 8.8 Spare Part 8 3398 50.002.12.065. SET BOLT - M12X1.75X65 - 8.8 Spare Part 9 3399 50.002.12.070. SET BOLT - M12X1.75X70 - 8.8 Spare Part 14 3400 50.002.12.090. SET BOLT - M12X1.75X90 - 8.8 Spare Part 9 3401 50.002.12.100. SET BOLT - M12X1.75X100 - 8.8 Spare Part 15 3402 50.002.12.150. SET BOLT - M12X1.75X150 - 8.8 Spare Part 48 3403 50.002.12.160. SET BOLT - M12X1.75X160 - 8.8 Spare Part 42 3404 50.002.12.200. SET BOLT - M12X1.75X200 - 8.8 Spare Part 58 3405 50.002.14.045. SET BOLT - M14X2X45 - 8.8 Spare Part 16 3406 50.002.14.050. SET BOLT - M14X2X50 - 8.8 Spare Part 9 3407 50.002.14.060. SET BOLT - M14X2X60 - 8.8 Spare Part 26					108	15% 15%
3398 50.002.12.065. SET BOLT - M12X1.75X65 - 8.8 Spare Part 9 3399 50.002.12.070. SET BOLT - M12X1.75X70 - 8.8 Spare Part 14 3400 50.002.12.090. SET BOLT - M12X1.75X90 - 8.8 Spare Part 9 3401 50.002.12.100. SET BOLT - M12X1.75X100 - 8.8 Spare Part 15 3402 50.002.12.150. SET BOLT - M12X1.75X150 - 8.8 Spare Part 48 3403 50.002.12.160. SET BOLT - M12X1.75X160 - 8.8 Spare Part 42 3404 50.002.12.200. SET BOLT - M12X1.75X200 - 8.8 Spare Part 58 3405 50.002.14.045. SET BOLT - M14X2X45 - 8.8 Spare Part 16 3406 50.002.14.050. SET BOLT - M14X2X50 - 8.8 Spare Part 9 3407 50.002.14.060. SET BOLT - M14X2X60 - 8.8 Spare Part 26				· ·	83	15%
3399 50.002.12.070. SET BOLT - M12X1.75X70 - 8.8 Spare Part 14 3400 50.002.12.090. SET BOLT - M12X1.75X90 - 8.8 Spare Part 9 3401 50.002.12.100. SET BOLT - M12X1.75X100 - 8.8 Spare Part 15 3402 50.002.12.150. SET BOLT - M12X1.75X150 - 8.8 Spare Part 48 3403 50.002.12.160. SET BOLT - M12X1.75X160 - 8.8 Spare Part 42 3404 50.002.12.200. SET BOLT - M12X1.75X200 - 8.8 Spare Part 58 3405 50.002.14.045. SET BOLT - M14X2X45 - 8.8 Spare Part 16 3406 50.002.14.050. SET BOLT - M14X2X50 - 8.8 Spare Part 9 3407 50.002.14.060. SET BOLT - M14X2X60 - 8.8 Spare Part 28					92	15%
3400 50.002.12.090. SET BOLT - M12X1.75X90 - 8.8 Spare Part 9 3401 50.002.12.100. SET BOLT - M12X1.75X100 - 8.8 Spare Part 15 3402 50.002.12.150. SET BOLT - M12X1.75X150 - 8.8 Spare Part 48 3403 50.002.12.160. SET BOLT - M12X1.75X160 - 8.8 Spare Part 42 3404 50.002.12.200. SET BOLT - M12X1.75X200 - 8.8 Spare Part 58 3405 50.002.14.045. SET BOLT - M14X2X45 - 8.8 Spare Part 16 3406 50.002.14.050. SET BOLT - M14X2X50 - 8.8 Spare Part 9 3407 50.002.14.060. SET BOLT - M14X2X60 - 8.8 Spare Part 28						
3401 50.002.12.100. SET BOLT - M12X1.75X100 - 8.8 Spare Part 19 3402 50.002.12.150. SET BOLT - M12X1.75X150 - 8.8 Spare Part 48 3403 50.002.12.160. SET BOLT - M12X1.75X160 - 8.8 Spare Part 42 3404 50.002.12.200. SET BOLT - M12X1.75X200 - 8.8 Spare Part 58 3405 50.002.14.045. SET BOLT - M14X2X45 - 8.8 Spare Part 16 3406 50.002.14.050. SET BOLT - M14X2X50 - 8.8 Spare Part 9 3407 50.002.14.060. SET BOLT - M14X2X60 - 8.8 Spare Part 28				•	145	15%
3402 50.002.12.150. SET BOLT - M12X1.75X150 - 8.8 Spare Part 48 3403 50.002.12.160. SET BOLT - M12X1.75X160 - 8.8 Spare Part 42 3404 50.002.12.200. SET BOLT - M12X1.75X200 - 8.8 Spare Part 58 3405 50.002.14.045. SET BOLT - M14X2X45 - 8.8 Spare Part 16 3406 50.002.14.050. SET BOLT - M14X2X50 - 8.8 Spare Part 9 3407 50.002.14.060. SET BOLT - M14X2X60 - 8.8 Spare Part 28					92	15% 15%
3403 50.002.12.160. SET BOLT - M12X1.75X160 - 8.8 Spare Part 42 3404 50.002.12.200. SET BOLT - M12X1.75X200 - 8.8 Spare Part 58 3405 50.002.14.045. SET BOLT - M14X2X45 - 8.8 Spare Part 16 3406 50.002.14.050. SET BOLT - M14X2X50 - 8.8 Spare Part 9 3407 50.002.14.060. SET BOLT - M14X2X60 - 8.8 Spare Part 28				· ·	191 483	15%
3404 50.002.12.200. SET BOLT - M12X1.75X200 - 8.8 Spare Part 58 3405 50.002.14.045. SET BOLT - M14X2X45 - 8.8 Spare Part 16 3406 50.002.14.050. SET BOLT - M14X2X50 - 8.8 Spare Part 9 3407 50.002.14.060. SET BOLT - M14X2X60 - 8.8 Spare Part 28						
3405 50.002.14.045. SET BOLT - M14X2X45 - 8.8 Spare Part 16 3406 50.002.14.050. SET BOLT - M14X2X50 - 8.8 Spare Part 9 3407 50.002.14.060. SET BOLT - M14X2X60 - 8.8 Spare Part 28					428	15%
3406 50.002.14.050. SET BOLT - M14X2X50 - 8.8 Spare Part S 3407 50.002.14.060. SET BOLT - M14X2X60 - 8.8 Spare Part 28				•	588	15%
3407 50.002.14.060. SET BOLT - M14X2X60 - 8.8 Spare Part 28					169 98	15% 15%
				,	286	15%
1. 3900 DOUBLE DUEL - WIDAZASU - 0.0				•		
		50.002.16.040.	SET BOLT - M16X2X40 - 8.8	Spare Part	126	15%
				•	169 138	15% 15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
3411	50.002.20.060.	SET BOLT - M20X2.5X60 - 8.8	Spare Part	320	15%
3412	50.002.20.070.	SET BOLT - M20X2.5X70 - 8.8	Spare Part	412	15%
3413	50.003.04.016.	HEXAGONAL HEADED BOLT - M4 X 16L	Spare Part	28	15%
3414	50.003.05.010.	SET SCREW - M5X0.8X10 - 8.8	Spare Part	12	15%
3415	50.003.05.020.	SET SCREW - M5X0.8X20 - 8.8	Spare Part	77	15%
3416	50.003.05.030.	SET SCREW - M5X0.8X30 - 8.8	Spare Part	22	15%
3417	50.003.06.010.	SET SCREW - M6X1X10 - 8.8	Spare Part	83	15%
3418	50.003.06.012.	SET SCREW: M6X1X12 -8.8	Spare Part	58	15%
3419	50.003.06.014.	SET SCREW - M6X1X14 - 8.8	Spare Part	43	15%
3420	50.003.06.015.	SET SCREW - M6X1X15 - 8.8	Spare Part	65	15%
3421	50.003.06.016.	SET SCREW: M6X1X16 -8.8	Spare Part	58	15%
3422	50.003.06.020.	SET SCREW - M6X1X20 - 8.8	Spare Part	102	15%
3423	50.003.06.022.	SET SCREW	Spare Part	43	15%
3424	50.003.06.025.	SET SCREW - M6X1X25 - 8.8	Spare Part	43	15%
3425	50.003.06.030.	SET SCREW - M6X1X30 - 8.8	Spare Part	25	15%
3426	50.003.06.035.	SET SCREW M6X1X35 8 8	Spare Part	25	15%
3427	50.003.06.040.	SET SCREW - M6X1X40 - 8.8	Spare Part	43	15%
3428	50.003.06.045.	SET SCREW	Spare Part	34	15%
3429	50.003.06.050.	SET SCREW - M6X1X50 - 8.8	Spare Part	43	15%
3430	50.003.06.060.	SET SCREW - M6 X O60 LONG	Spare Part	34	15%
3431	50.003.08.010.	SET SCREW - M8X1.25X10 - 8.8	Spare Part	34	15%
3432	50.003.08.014.	SET SCREW - M8X1.25X14 - 8.8	Spare Part	31	15%
3433	50.003.08.015.	SET SCREW - M8X1.25X15 - 8.8	Spare Part	43	15%
3434	50.003.08.016.	SET SCREW: M8X1.25X16 -8.8	Spare Part	34	15%
3435	50.003.08.018.	SET SCREW - M8X1.25X18 - 8.8	Spare Part	49	15%
3436	50.003.08.020.	SET SCREW: M8X1.25X20 -8.8	Spare Part	34	15%
3437	50.003.08.022.	SET SCREW - M8X1.25X22 - 8.8	Spare Part	31	15%
3438	50.003.08.025.	SET SCREW: M8X1.25-8.8	Spare Part	43	15%
3439	50.003.08.030.	SET SCREW: M8X1.25X30-8.8	Spare Part	43	15%
3440	50.003.08.035.	SET SCREW - M8X1.25X35 - 8.8	Spare Part	77	15%
3441	50.003.08.040.	SET SCREW M8X1 25X40 8 8	Spare Part	31	15%
3442	50.003.08.045.	SET SCREW - M8X1.25X45 - 8.8	Spare Part	34	15%
3443	50.003.08.050.	SET SCREW - M8X1.25X50 - 8.8	Spare Part	46	15%
3444	50.003.08.055.	SET SCREW - M8X1.25X55 - 8.8	Spare Part	102	15%
3445	50.003.08.060.	SET SCREW M8X1 25X60 8 8	Spare Part	71	15%
3446	50.003.08.080.	SET SCREW	Spare Part	65	15%
3447	50.003.10.015.	SET SCREW - M10X1.5X15 - 8.8	Spare Part	43	15%
3448	50.003.10.020.	SET SCREW: M10X1.5X20 -8.8	Spare Part	77	15%
3449	50.003.10.025.	SET SCREW: M10X1.5X25 -8.8	Spare Part	83	15%
3450	50.003.10.030.	SET SCREW: M10X1.5X30 -8.8	Spare Part	65	15%
3451	50.003.10.035.	SET SCREW: M10X1.5X35 -8.8	Spare Part	58	15%
3452	50.003.10.040.	SET SCREW - M10X1.5X40 - 8.8	Spare Part	65	15%
3453	50.003.10.045.	SET SCREW - M10X1.5X45 - 8.8	Spare Part	68	15%
3454	50.003.10.050.	SET SCREW - M10X1.5X50 - 8.8	Spare Part	102	15%
3455	50.003.10.055.	SET SCREW - M10X1.5X55 - 8.8	Spare Part	86	15%
3456	50.003.10.070.	SET SCREW M10X1 5X70 8 8	Spare Part	77	15%
3457	50.003.12.020.	SET SCREW - M12X1.75X20 - 8.8	Spare Part	86	15%
3458	50.003.12.025.	SET SCREW - M12X1.75X25 - 8.8	Spare Part	92	15%
3459	50.003.12.030.	SET SCREW - M12X1.75X30 - 8.8	Spare Part	89	15%
3460	50.003.12.035.	SET SCREW - M12X1.75X35 - 8.8	Spare Part		15%
3461	50.003.12.040.	SET SCREW - M12X1.75X40 - 8.8	Spare Part		15%
3462	50.003.12.045.	SET SCREW - M12X1.75X45 - 8.8	Spare Part		15%
3463	50.003.12.050.	SET SCREW - M12X1.75X50 - 8.8	Spare Part	89	15%
3464	50.003.12.060.	SET SCREW	Spare Part	123	15%
3465	50.003.14.035.	SET SCREW M14X2X35 8 8	Spare Part		15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		·		without Vat in NPR	Charge%
3466	50.003.14.040.	SET SCREW - M14X2X40 - 8.8	Spare Part	132	15%
3467	50.003.16.040.	SET SCREW - M16X2X40 - 8.8	Spare Part	163	15%
3468	50.003.16.050.	SET SCREW - M16X2X50 - 8.8	Spare Part	157	15%
3469	50.003.20.050.	SET SCREW - M20X2.5X50 - 8.8	Spare Part	255	15%
3470	50.003.20.060.	SET SCREW - M20X2.5X60 - 8.8	Spare Part	892	15%
3471	50.006.04.000.	NUT - M4X0.7 - GR.8.8	Spare Part	18	15%
3472	50.006.05.000.	NUT - M5X0.8 - GR.8.8	Spare Part	31	15%
3473	50.006.06.000.	NUT: M6X1 - GR8	Spare Part	31	15%
3474	50.006.08.000.	NUT M8X1.25 -GR8	Spare Part	31	15%
3475	50.006.10.000.	NUT : M10X1.5 -GR8	Spare Part	31	15%
3476	50.006.12.000.	NUT: M12X1.75 - GR8	Spare Part	31	15%
3477	50.006.14.000.	NUT - M14X2 - GR.8.8	Spare Part	52	15%
3478	50.006.16.000.	NUT - M16X2 - GR.8.8	Spare Part	83	15%
3479	50.006.18.000.	NUT - M18X2.5 - GR.8.8	Spare Part	92	15%
3480	50.006.20.000.	NUT - M20X2.5 - GR.8	Spare Part	123	15%
3481	50.007.08.000.	NUT - M8X1 - GR.8	Spare Part	43	15%
3482	50.007.16.000.	NUT - M16X1.5 - GR.8	Spare Part	58	15%
3483	50.008.06.000.	LOCK NUT - M6X1 - GR.8	Spare Part	31	15%
3484	50.008.10.000.	LOCK NUT - M10X1.5 - GR.8	Spare Part	46	15%
3485	50.009.10.000.	NUT	Spare Part	37	15%
3486	50.009.14.000.	LOCK NUT - M14X1.5 - GR.8	Spare Part	55	15%
3487	50.009.14.000.	LOCK NUT 20X1.5	Spare Part	169	15%
3488	50.010.06.020.	STUD - M6X1X20 - 8.8	Spare Part	12	15%
3489	50.010.08.016.	STUD - M8X1.25X16 - 8.8		31	15%
3490	50.010.08.020.		Spare Part	43	15%
		STUD - M8X1.25X20 - 8.8 STUD: M8X1.25X25 - 8.8	Spare Part Spare Part	31	15%
3491 3492	50.010.08.025. 50.010.08.030.	STUD -M8X 1.25X30 -8.8	Spare Part	31	15%
3493	50.010.08.035.	STUD: M8X1.25X35 -8.8	Spare Part	31	15%
3494	50.010.08.040.	STUD-M8X1.25X40 -8.8	Spare Part	31	15%
3494	50.010.08.045.		•	43	15%
		STUD: M8X1.25X45 -8.8	Spare Part Spare Part	31	15%
3496 3497	50.010.08.050. 50.010.08.055.	STUD: M8X1.25X50 - 8.8 STUD-M8X1.25X55 -8.8	Spare Part	31	15%
		STUD: M8X1.25X60 - 8.8	Spare Part	58	15%
3498	50.010.08.060.	STUD - M8 X1.25 X 65 MM - 8.8 GRADE		28	
3499	50.010.08.065. 50.010.08.075.		Spare Part	68	15%
3500		STUD: M8X1.25X75 - 8.8	Spare Part	52	15%
3501	50.010.08.080.	STUD - M8X1.25X80 - 8.8	Spare Part	68	15% 15%
3502	50.010.08.085.	STUD - M8X1.25X85 - 8.8	Spare Part		
3503	50.010.08.090.	STUD M8X1.25X090 GR. 8.8	Spare Part	49	15%
3504	50.010.08.095.	STUD - M8X1.25X95 - 8.8	Spare Part	77	15%
3505	50.010.08.100.	STUD	Spare Part	86	15%
3506	50.010.10.025.	STUD: M10X1.5X25 - 8.8	Spare Part	31	15%
3507	50.010.10.030.	STUD-M8X1.25X55 -8.8	Spare Part	43	15%
3508	50.010.10.035.	STUD: M10X1.5X35 - 8.8	Spare Part	43	15%
3509	50.010.10.045.	STUD: M10X1.5X45 -8.8	Spare Part	49	15%
3510	50.010.10.050.	STUD: M10X1.5X50 - 8.8	Spare Part	52	15%
3511	50.010.10.060.	STUD - M10X1.5X60 - 8.8	Spare Part	92	15%
3512	50.010.10.065.	STUD - M10X1.5X65 - 8.8	Spare Part	58	15%
3513	50.010.10.070.	STUD - M10X1.5X70 - 8.8	Spare Part	58	15%
3514	50.010.10.075.	STUD: M10X1.5X75 - 8.8	Spare Part	65	15%
3515	50.010.10.110.	STUD	Spare Part	357	15%
3516	50.010.12.025.	STUD - M12X1.75X25 - 8.8	Spare Part	280	15%
3517	50.010.12.030.	STUD - M12X1.75X30 - 8.8	Spare Part	92	15%
3518	50.010.12.200.	STUD - M12X1.75X200 - 8.8	Spare Part	360	15%
3519	50.011.06.014.	SOCKET HEAD SCREW - M6X1X14 - 8.8	Spare Part	31	15%
3520	50.011.06.016.	SOCKET HEAD SCREW - M6X1X16 - 8.8	Spare Part	28	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
3521	50.011.06.020.	SOCKET HEAD SCREW - M6X1X20 - 8.8	Spare Part	34	15%
3522	50.011.06.025.	SOCKET HEAD SCREW - M6X1X25 - 8.8	Spare Part	15	15%
3523	50.011.06.030.	SOCKET HEAD SCREW M6X1X30	Spare Part	28	15%
3524	50.011.08.016.	SOCKET HEAD SCREW: M8X1.25X16-8.8	Spare Part	43	15%
3525	50.011.08.020.	SOCKET HEAD SCREW M8X1.25X20 -8.8	Spare Part	58	15%
3526	50.011.08.025.	SOCKET HEAD SCREW - M8X1.25X25 - 8.8	Spare Part	49	15%
3527	50.011.08.030.	SOCKET HEAD SCREW - M8X1.25X30 - 8.8	Spare Part	55	15%
3528	50.011.08.035.	SOCKET HEAD SCREW - M8X1.25X35 - 8.8	Spare Part	25	15%
3529	50.011.08.040.	SOCKET HEAD SCREW - M8X1.25X40 - 8.8	Spare Part	58	15%
3530	50.011.08.045.	SOCKET HEAD SCREW M8X1 25X45 8 8	Spare Part	77	15%
3531	50.011.08.055.	SOCKET HEAD SCREW - M8X1.25X55 - 8.8	Spare Part	62	15%
3532	50.011.08.060.	SOCKET HEAD CAP BOLT M8X60 LG	Spare Part	49	15%
3533	50.011.08.070.	SOCKET HEAD SCREW - M8X1.25X70 - 8.8	Spare Part	102	15%
3534	50.011.08.075.	SOCKET HEAD SCREW: M8X1.25X75-8.8	Spare Part	102	15%
3535	50.011.08.090.	SOCKET HEAD SCREW - M8X1.25X90 - 8.8	Spare Part	228	15%
3536	50.011.10.020.	SOCKET HEAD SCREW - M10X1.5X20 - 8.8	Spare Part	89	15%
3537	50.011.10.025.	SOCKET HEAD SCREW - M10X1.5X25 - 8.8	Spare Part	43	15%
3538	50.011.10.030.	SOCKET HEAD SCREW - M10X1.5X30 - 8.8	Spare Part	92	15%
3539	50.011.10.035.	SOCKET HEAD SCREW - M10X1.5X35 - 8.8	Spare Part	71	15%
3540	50.011.10.040.	SOCKET HEAD SCREW - M10X1.5X40 - 8.8	Spare Part	83	15%
3541	50.011.10.050.	SOCKET HEAD SCREW - M10X1.5X50 - 8.8	Spare Part	86	15%
3542	50.011.10.120.	SOCKET HEAD SCREW - M10X1.5X120 - 8.8	Spare Part	283	15%
3543	50.011.12.040.	SOCKET HEAD SCREW - M12X1.75X40 - 8.8	Spare Part	132	15%
3544	50.013.02.014.	SET BOLT - 5/16 INCH BSFX2 INCH LONG - 8.8	Spare Part	37	15%
3545	50.013.02.017.	SET BOLT - 5/16 INCH BSFX2-3/4 INCH LONG - 8.8	Spare Part	49	15%
3546	50.013.02.018.	SET BOLT - 5/16 INCH BSFX3.0 INCH LONG - 8.8	Spare Part	86	15%
3547	50.013.03.012.	SET BOLT - 3/8"BSFX1-5/8"L - 8.8	Spare Part	62	15%
3548	50.014.02.004.	SET SCREW - 5/16"BSFX5/8"L - 8.8	Spare Part	31	15%
3549	50.014.02.007.	SET SCREW - 5/16"BSFX1"L - 8.8	Spare Part	34	15%
3550	50.014.02.011.	SET SCREW - 5/16"BSFX1-1/2"L - 8.8	Spare Part	55	15%
3551	50.015.02.000.	NUT - 5/16" BSF NORMAL CLASS - GRADE P	Spare Part	12	15%
3552	50.016.02.000.	LOCK NUT - 5/16"BSF NORMAL CLASS - GR.P	Spare Part	49	15%
3553	50.016.05.000.	LOCK NUT - 1/2"BSF NORMAL CLASS - GR.P	Spare Part	43	15%
3554	50.025.03.016.	SLOTTED CHEESE HEAD SCREW - M3X16	Spare Part	12	15%
3555	50.030.02.004.	STUD 5/16"BSFX1.1/8" GRADE R	Spare Part	77	15%
3556	50.030.02.007.	STUD 5/16"BSFX1.1/2" GRADE R	Spare Part	34	15%
3557	50.036.03.001.	SPLIT COTTER PIN - 1/16"X1/2"	Spare Part	12	15%
3558	50.036.07.010.	SPLIT COTTER PIN - 1/8"X1-1/2"	Spare Part	12	15%
3559	50.037.06.000.	SELF LOCKING NYLOC NUT - M6	Spare Part	31	15%
3560	50.037.08.000.	SELF LOCKING NYLOC NUT - M8	Spare Part	43	15%
3561	50.037.16.000.	SELF LOCKING NYLOC NUT - M16	Spare Part	95	15%
3562	50.051.12.050.	SET SCREW: M12X1.75X 50L - 10.9	Spare Part	71	15%
3563	50.051.16.050.	SET SCREW "10.9" CLASS	Spare Part	243	15%
3564	50.051.20.050.	SET SCREW	Spare Part	440	15%
3565	50.052.10.030.	SET BOLT-M10X30-10.9	Spare Part	58	15%
3566	50.052.10.035.	SET BOLT M10X35 10 9	Spare Part	77	15%
3567	50.052.10.040.	SET BOLT-M10X40-10.9	Spare Part	49	15%
3568	50.052.10.080.	BOLT 10X80 10.9 GRADE	Spare Part	108	15%
3569	50.052.12.030.	SET BOLT-M12X30-10.9	Spare Part	77	15%
3570	50.052.12.045.	SET BOLT: M12 X 45 - 10.9	Spare Part	132	15%
3571	50.052.12.065.	SET BOLT-M12X65-10.9	Spare Part	191	15%
3572	50.052.14.045.	SET BOLT M14 GR.10.9	Spare Part	185	15%
3573	50.052.14.080.	SET BOLT: M14 X 80	Spare Part	182	15%
3574	50.052.14.100.	SET BOLT	Spare Part	138	15%
3575	50.052.16.150.	SET BOLT-M16X150-10.9	Spare Part	323	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
3576	50.052.20.060.	SET BOLT-M20X60-10.9	Spare Part	406	15%
3577	50.056.02.000.	HEADLESS PIPE PLUG 1 8 27 NPTF	Spare Part	34	15%
3578	50.056.06.000.	HEADLESS PIPE PLUG 1/2"-14 NPTF	Spare Part	105	15%
3579	50.056.08.000.	HEADLESS PIPE PLUG 1"-11.5 NPTF	Spare Part	246	15%
3580	50.076.06.012.	SOCKET HEAD CAP SCREW M6X012 12 9	Spare Part	83	15%
3581	50.076.06.040.	SOCKET HEAD CAP SCREW M6X040 12 9	Spare Part	28	15%
3582	50.076.08.030.	CHC SCREW	Spare Part	34	15%
3583	50.076.08.040.	ALLEN SCREW	Spare Part	65	15%
3584	50.076.08.045.	ALLEN SCREW	Spare Part	74	15%
3585	50.076.08.070.	SOCKET HEAD CAP SCREW M8X70 -12.9	Spare Part	92	15%
3586	50.076.08.090.	SOCKET HEAD CAP SCREW M8X90 -12.9	Spare Part	148	15%
3587	50.076.10.020.	ALLEN SCREW	Spare Part	34	15%
3588	50.076.10.025.	SOCKET HEAD CAP SCREW-M10X25-12.9	Spare Part	62	15%
3589	50.076.10.030.	SOCKET HEAD CAP SCREW-M10X30-12.9	Spare Part	77	15%
3590	50.076.10.045.	SOCKET HEAD CAP SCREW M10X045 12 9	Spare Part	157	15%
3591	50.076.10.055.	SOCKET HEAD SCREW M10X1 5X55 12 9	Spare Part	132	15%
3592	50.076.10.060.	SOCKET HEAD CAP SCREW-M10X60-12.9	Spare Part	86	15%
3593	50.076.10.070.	ALLEN SCREW M 10 X 70 MM	Spare Part	188	15%
3594	50.076.10.075.	SOCKET HEAD CAP SCREW M10X75 12 9	Spare Part	163	15%
3595	50.076.16.035.	SOCKET HEAD CAP SCREW-M16X35-12.9	Spare Part	172	15%
3596	50.076.16.050.	SOCKET HEAD SCREW (DIN912 M16X50 -12.5)	Spare Part	366	15%
3597	50.076.16.090.	ALLEN SCREW	Spare Part	271	15%
3598	50.080.08.000.	NUT (SS) - M8x1.25	Spare Part	46	15%
3599	50.080.10.000.	S.S. NUT M10-AISI-304	Spare Part	83	15%
3600	50.085.12.000.	BANJO ONE SIDED SF M18 BOLT FOR 1 2 RUBBER HOSE	Spare Part	1409	15%
3601	50.302.36.000.	OIL SEAL-32X45X6W-(21502)	Spare Part	105	15%
3602	50.401.05.010.	DOWEL PIN BAR	Spare Part	22	15%
3603	50.401.06.010.	DOWEL (5 x 10)	Spare Part	157	15%
3604	50.401.06.012.	DOWEL	Spare Part	25	15%
3605	50.401.06.014.	DOWEL PIN	Spare Part	46	15%
3606	50.401.06.025.	DOWEL PIN	Spare Part	49	15%
3607	50.401.07.012.	DOWEL PIN	Spare Part	25	15%
3608	50.401.08.012.	DOWEL	Spare Part	132	15%
3609	50.401.08.014.	DOWEL	Spare Part	46	15%
3610	50.401.08.016.	DOWEL PIN	Spare Part	52	15%
3611	50.401.08.025.	DOWEL PIN 8X25	Spare Part	52	15%
3612	50.401.08.045.	DOWEL PIN 8X45	Spare Part	58	15%
		DOWEL PIN 8X60	Spare Part	62	15%
3614	50.401.08.065.	DOWEL PIN 8X65	Spare Part	52	15%
3615	50.401.09.020.	DOWEL PIN 10X20	Spare Part	191	15%
		DOWEL PIN 10X20	Spare Part	52	15%
3616	50.401.10.030. 50.405.10.000.			52	15%
3617	50.405.10.000.	WOODRUFF KEY (4 X 6.5) WOODRUFF KEY	Spare Part Spare Part	65	15%
3618					
3619	50.501.15.000.	CIRCLIP EXTERNAL - 15 MM	Spare Part	55	15%
3620	50.501.16.000.	CIRCLIP EXTERNAL: 16 MM	Spare Part	31	15%
3621	50.501.20.000.	CIRCLIP EXTERNAL - 20 MM	Spare Part	31	15%
3622	50.501.30.000.	CIRCLIP EXTERNAL - 30 MM	Spare Part	52	15%
3623	50.501.35.000.	CIRCLIP EXTERNAL - 35 MM	Spare Part	34	15%
3624	50.501.40.000.	CIRCLIP EXTERNAL - 40 MM	Spare Part	132	15%
3625	50.501.55.000.	EXTERNAL CIRCLIP (55 DIA SHAFT)	Spare Part	43	15%
3626	50.502.32.000.	CIRCLIP INTERNAL : 32 MM	Spare Part	28	15%
3627	50.502.35.000.	CIRCLIP (INTERNAL)-35 MM	Spare Part	65	15%
3628	50.502.40.000.	CIRCLIP INTERNAL - 40 MM	Spare Part	71	15%
3629	50.502.42.000.	CIRCLIP: INTERNAL 42MM	Spare Part	108	15%
3630	50.502.45.000.	CIRCLIP INTERNAL : 45 MM	Spare Part	62	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
3631	50.502.47.000.	CIRCLIP INTERNAL - 47 MM	Spare Part	62	15%
3632	50.502.52.000.	CIRCLIP INTERNAL - 52 MM	Spare Part	68	15%
3633	50.502.55.000.	CIRCLIP INTERNAL 55 MM	Spare Part	95	15%
3634	50.502.62.000.	CIRCLIP INTERNAL - 62 MM	Spare Part	102	15%
3635	50.502.72.000.	CIRCLIP INTERNAL - 72 MM	Spare Part	154	15%
3636	50.502.80.000.	CIRCLIP INTERNAL - 80 MM	Spare Part	335	15%
3637	50.502.90.000.	CIRCLIP INTERNAL - 90 MM	Spare Part	228	15%
3638	50.503.04.000.	BANJO	Spare Part	105	15%
3639	50.504.01.000.	BANJO BOLT: M8X1.25	Spare Part	52	15%
3640	50.504.02.000.	BANJO BOLT: M10X1.5	Spare Part	58	15%
3641	50.504.03.000.	BANJO BOLT: M12X1.5	Spare Part	71	15%
3642	50.504.04.000.	BANJO BOLT :M14X1.5	Spare Part	58	15%
3643	50.504.05.000.	BANJO BOLT - M16X1.5	Spare Part	178	15%
3644	50.504.06.000.	BANJO BOLT: M18X1.5	Spare Part	108	15%
3645	50.504.07.000.	BANJO BOLT M22X1 5	Spare Part	200	15%
3646	50.504.09.000.	BANJO BOLT M30X1 5	Spare Part	723	15%
3647	50.505.05.000.	SPRING WASHER - M5	Spare Part	12	15%
3648		SPRING WASHER -M6	Spare Part	31	15%
	50.505.06.000.		·	31	15%
3649	50.505.08.000.	SPRING WASHER - M8 SPRING WASHER - M10	Spare Part		15%
3650	50.505.10.000.		Spare Part	31 12	15%
3651	50.505.12.000.	SPRING WASHER - M12	Spare Part	12	15%
3652	50.505.14.000.	SPRING WASHER M14	Spare Part		
3653	50.505.16.000.	SPRING WASHER - M16	Spare Part	31	15%
3654	50.505.18.000.	SPRING WASHER - M18	Spare Part	18	15%
3655	50.505.20.000.	SPRING WASHER - M20	Spare Part	43	15%
3656	50.505.24.000.	SPRING WASHER - M24	Spare Part	43	15%
3657	50.506.04.000.	PLAIN MACHINED WASHER - M4	Spare Part	12	15%
3658	50.506.05.000.	PLAIN MACHINED WASHER M5	Spare Part	15	15%
3659	50.506.06.000.	PLAIN MACHINED WASHER - M6	Spare Part	31	15%
3660	50.506.08.000.	PLAIN MACHINE WASHER - M8	Spare Part	31	15%
3661	50.506.10.000.	PLAIN MACHINED WASHER - M10	Spare Part	43	15%
3662	50.506.12.000.	PLAIN MACHINE WASHER - M12	Spare Part	43	15%
3663	50.506.14.000.	PLAIN MACHINED WASHER - M14	Spare Part	31	15%
3664	50.506.16.000.	PLAIN MACHINED WASHER - M16	Spare Part	58	15%
3665	50.506.18.000.	PLAIN MACHINED WASHER M18	Spare Part	58	15%
3666	50.506.20.000.	PLAIN MACHINED WASHER - M20	Spare Part	28	15%
3667	50.506.22.000.	PLAIN MACHINED WASHER - M22	Spare Part	58	15%
3668	50.506.24.000.	PLAIN MACHINED WASHER - M24	Spare Part	62	15%
3669	50.507.06.000.	PLAIN PUNCHED WASHER - M6	Spare Part	12	15%
3670	50.507.08.000.	PLAIN PUNCHED WASHER - M8	Spare Part	31	15%
3671	50.507.10.000.	PLAIN PUNCHED WASHER - M10	Spare Part	31	15%
3672	50.507.12.000.	PLAIN PUNCHED WASHER M12	Spare Part	15	15%
3673	50.508.03.000.	COPPER WASHER (6X9)	Spare Part	31	15%
3674	50.508.04.000.	COPPER WASHER (6X10)	Spare Part	31	15%
3675	50.508.05.000.	COPPER WASHER (8X12)	Spare Part	31	15%
3676	50.508.06.000.	COPPER WASHER (8X14)	Spare Part	31	15%
3677	50.508.07.000.	COPPER WASHER (10X14)	Spare Part	31	15%
3678	50.508.08.000.	COPPER WASHER (10X16)	Spare Part	31	15%
3679	50.508.09.000.	COPPER WASHER (12X16)	Spare Part	46	15%
3680	50.508.10.000.	COPPER WASHER (12X18)	Spare Part	58	15%
3681	50.508.11.000.	COPPER WASHER (14X18)	Spare Part	46	15%
3682	50.508.12.000.	COPPER WASHER (14X20)	Spare Part	49	15%
3683	50.508.13.000.	COPPER WASHER (16X20)	Spare Part	46	15%
3684	50.508.14.000.	COPPER WASHER (16X22)	Spare Part	46	15%
3685	50.508.15.000.	COPPER WASHER (17X23)	Spare Part	62	15%



				Price to	Custom
Sr.No.	Part Number	Part Description	Category	Customer without Vat in	Custom Charge%
				NPR	C.i.u.ge/c
3686	50.508.16.000.	COPPER WASHER (18X22)	Spare Part	55	15%
3687	50.508.17.000.	COPPER WASHER (18X24)	Spare Part	52	15%
3688	50.508.18.000.	COPPER WASHER (20X24)	Spare Part	52	15%
3689	50.508.19.000.	COPPER WASHER (20X26)	Spare Part	52	15%
3690	50.508.20.000.	COPPER WASHER (20X27)	Spare Part	55	15%
3691	50.508.21.000.	COPPER WASHER 21X27	Spare Part	25	15%
3692	50.508.22.000.	COPPER WASHER (21X31)	Spare Part	31	15%
3693	50.508.23.000.	COPPER WASHER (22X27)	Spare Part	74	15%
3694	50.508.24.000.	COPPER WASHER (22X29)	Spare Part	62	15%
3695	50.508.25.000.	COPPER WASHER(22.2X28.5)	Spare Part	55	15%
3696	50.508.27.000.	COPPER WASHER (24X29)	Spare Part	74	15%
3697	50.508.29.000.	COPPER WASHER (26X32)	Spare Part	58	15%
3698	50.508.31.000.	COPPER WASHER (27X34)	Spare Part	135	15%
3699	50.508.32.000.	COPPER WASHER (28X33)	Spare Part	62	15%
3700	50.508.33.000.	COPPER WASHER (30X34)	Spare Part	55	15%
3701	50.508.34.000.	COPPER WASHER (30X36)	Spare Part	71	15%
3702	50.508.35.000.	COPPER WASHER (30X38)	Spare Part	77	15%
3703	50.508.45.000.	COPPER WASHER (48X52)	Spare Part	86	15%
3704	50.519.02.000.	HOSE CLIP	Spare Part	52	15%
3705	50.519.09.000.	HOSE CLIP 48 MM For 39 464 02 0 00	Spare Part	25	15%
3706	50.538.03.000.	BANJO BOLT 14 BSP	Spare Part	175	15%
3707	50.540.09.016.	SPRING DOWEL PIN	Spare Part	49	15%
3708	50.540.10.045.	SPRING DOWEL (6 X 45)	Spare Part	34	15%
3709	50.540.11.018.	SPRING DOWEL	Spare Part	43	15%
3710	50.541.01.000.	PIPE CLIP (FOR 2 PIPES)	Spare Part	31	15%
3711	50.543.09.010.	NOTCHED PIN	Spare Part	43	15%
3712	50.548.05.000.	WASHER M5	Spare Part	6	15%
3713	50.548.06.000.	WASHER	Spare Part	34	15%
3714	50.548.08.000.	SPL PLAIN MACHINED WASHER	Spare Part	31	15%
3715	50.548.10.000.	SPECIAL PLAIN WASHER - M10	Spare Part	34	15%
3716	50.548.12.000.	SPL PLAIN WASHER - M12	Spare Part	31	15%
3717	50.548.14.000.	SPL PLAIN WASHER - M14	Spare Part	49	15%
3718	50.548.18.000.	WASHER	Spare Part	46	15%
3719	50.548.20.000.	SPECIAL WASHER.	Spare Part	92	15%
3720	50.601.02.000.	CORE PLUG 1/4"BSP	Spare Part	95	15%
3721	50.601.03.000.	DRAIN PLUG 3/8" BSP	Spare Part	95	15%
3722	50.602.10.000.	CORE PLUG	Spare Part	148	15%
3723	50.602.14.000.	PLUG: M14X1.5	Spare Part	102	15%
3724	50.602.16.000.	CORE PLUG 16X1.5	Spare Part	102	15%
3725	50.602.18.000.	CORE PLUG	Spare Part	71	15%
3726	50.609.13.000.	CORE PLUG (DISH TYPE)	Spare Part	108	15%
3727	50.610.12.000.	CORE PLUG	Spare Part	65	15%
3728	50.610.14.000.	CORE PLUG-HEXAGONAL SOCKET HEAD(DIN-908)	Spare Part	71	15%
3729	50.610.16.000.	CORE PLUG HEXAGONAL SOCKET HEAD DIN 908	Spare Part	83	15%
3730	50.610.20.000.	CORE PLUG HEXAGONAL SOCKET HEAD(DIN 908)	Spare Part	132	15%
3731	50.610.22.000.	CORE PLUG HEXAGONAL SOCKET HEAD(M22x1.5)	Spare Part	175	15%
3732	50.610.24.000.	CORE PLUG	Spare Part	169	15%
3733	50.610.27.000.	CORE PLUG(M27X2)-HEXAGONAL SOCKET HEAD(DIN 908)	Spare Part	222	15%
3734	50.610.30.000.	CORE PLUG HEXAGONAL SOCKET HEAD DIN 908	Spare Part	249	15%
3735	50.611.06.000.	CORE PLUG	Spare Part	105	15%
3736	50.907.02.000.	WORM DRIVE HOSE CLIP 18 MM	Spare Part	138	15%
3737	50.907.03.000.	WORM DRIVE HOSE CLIP (22 MM)	Spare Part	86	15%
3738	50.907.04.000.	WORM DRIVE HOSE CLIP (25 MM)	Spare Part	126	15%
3739	50.907.05.000.	WORM DRIVE HOSE CLIP (28 MM)	Spare Part	129	15%
3740	50.907.06.000.	HOSE CLIP: WORM DRIVE 32MM	Spare Part	95	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		'		without Vat in NPR	Charge%
3741	50.907.07.000.	WORM DRIVE HOSE CLIP (41 MM)	Spare Part	95	15%
3742	50.907.08.000.	WORM DRIVE HOSE CLIP 45 MM	Spare Part	151	15%
3743	50.907.09.000.	WORM DRIVE HOSE CLIP (55 MM)	Spare Part	102	15%
3744	50.907.10.000.	WORM DRIVE HOSE CLIP (70 MM)	Spare Part	151	15%
3745	50.907.11.000.	WORM DRIVE HOSE CLIP 80 MM	Spare Part	166	15%
3746	50.907.12.000.	WORM DRIVE HOSE CLIP 90 MM	Spare Part	151	15%
3747	50.907.13.000.	WORM DRIVE HOSE CLIP (102 MM)	Spare Part	169	15%
3748	50.907.14.000.	WORM DRIVE HOSE CLIP (115 MM)	Spare Part	178	15%
3749	50.907.15.000.	WORM DRIVE HOSE CLIP (127 MM)	Spare Part	200	15%
3750	50.908.06.000.	FLANGED NUT GRADE 8	Spare Part	9	15%
3751	50.908.08.000.	FLANGED M8 NUT GRADE 8	Spare Part	12	15%
3752	50.908.10.000.	FLANGED NUT (HEXAGON)	Spare Part	18	15%
3753	50.911.06.010.	FLANGED BOLT GRADE 8.8 M6 X 1 X 10	Spare Part	25	15%
3754	50.911.06.012.	FLANGED BOLT GRADE 8.8 M6 X 1 X 012	Spare Part	22	15%
3755	50.911.06.016.	FLANGED BOLT GRADE 8.8 M6 X 1.25 X 16	Spare Part	12	15%
3756	50.911.06.025.	FLANGED BOLT GRADE 8.8 M6 X 1 X 25	Spare Part	18	15%
3757	50.911.06.035.	FLANGED BOLT GRADE 8.8 M6 X 1 X 035	Spare Part	25	15%
3758	50.911.06.040.	FLANGED BOLT GRADE 8.8 M6 X 1 X 40	Spare Part	28	15%
3759	50.911.06.050.	FLANGED BOLT GRADE 8.8 M6 X 1 X 050	Spare Part	31	15%
3760	50.911.08.012.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 012	Spare Part	25	15%
3761	50.911.08.015.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 15	Spare Part	28	15%
3762	50.911.08.016.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 16	Spare Part	25	15%
3763	50.911.08.018.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 018	Spare Part	28	15%
3764	50.911.08.020.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 20	Spare Part	34	15%
3765	50.911.08.022.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 022	Spare Part	31	15%
3766	50.911.08.025.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 25	Spare Part	31	15%
3767	50.911.08.030.	FLANGED BOLT GRADE 8.8	Spare Part	31	15%
3768	50.911.08.035.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 35	Spare Part	34	15%
3769	50.911.08.040.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 40	Spare Part	43	15%
3770	50.911.08.045.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 45	Spare Part	46	15%
3771	50.911.08.050.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 050	Spare Part	49	15%
3772	50.911.08.055.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 055	Spare Part	58	15%
3773	50.911.08.060.	FLANGED BOLT GRADE 8 8	Spare Part	49	15%
3774	50.911.08.065.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 65	Spare Part	68	15%
3775	50.911.08.070.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 070	Spare Part	62	15%
3776	50.911.08.080.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 80	Spare Part	71	15%
3777	50.911.08.085.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 085	Spare Part	68	15%
3778	50.911.08.090.	FLANGED BOLT GRADE 8 8 M8 X 1 25 X 090	Spare Part	86	15%
3779	50.911.08.110.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 110	Spare Part	92	15%
3780	50.911.08.115.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 115	Spare Part	102	15%
3781	50.911.08.130.	FLANGED BOLT GRADE 8.8 M8 X 1.25 X 130	Spare Part	108	15%
3782	50.911.10.015.	FLANGED BOLT GRADE 8.8	Spare Part	43	15%
3783	50.911.10.020.	FLANGED BOLT GRADE 8.8 M10 X 1.5 X 20	Spare Part	43	15%
3784	50.911.10.022.	FLANGED BOLT GRADE 8.8 M10 X 1.5 X 022	Spare Part	46	15%
3785	50.911.10.025.	FLANGED BOLT GRADE 8.8 M10 X 1.5 X 25	Spare Part	49	15%
3786	50.911.10.030.	FLANGED BOLT GRADE 8.8 M10 X 1.5 X 30	Spare Part	68	15%
3787	50.911.10.035.	FLANGED BOLT GRADE 8.8 M10 X 1.5 X 35	Spare Part	71	15%
3788	50.911.10.040.	FLANGED BOLT GRADE 8.8 M10 X 1.5 X 40	Spare Part	86	15%
3789	50.911.10.055.	FLANGED BOLT GRADE 8.8 M10 X 1.5 X 55	Spare Part	77	15%
3790	50.911.10.065.	FLANGED BOLT GRADE 8.8 M10 X 1.5 X 65	Spare Part	92	15%
3791	50.911.10.070.	FLANGED BOLT GRADE 8.8 M10 X 1.5 X 70	Spare Part	126	15%
3792	50.911.10.075.	FLANGED BOLT GRADE 8.8	Spare Part	102	15%
3793	50.911.10.080.	FLANGED BOLT GRADE 8 8 M10 X 1 5 X 80	Spare Part	142	15%
3794	50.911.10.085.	FLANGED BOLT GRADE 8 8 M10 X 1 5 X 85	Spare Part	114	15%
3795	50.911.10.105.	FLANGED BOLT GRADE 8 8 M10 X 1 5 X 105	Spare Part	151	15%



MODE SOLD PR	Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
1979 1979						. = 0.
MPM				·		
9799 0915 081000			 	·	-	
1000 1001 100 PR				'		
MODE MODE CHANKCASE ASS Y WITH MC CAP Spee Part 127959 1998				·		
				·		
				·		
100.05 10.05 PR						
MINUT SALD PR						
MODE SOLD PR				·		
MOSIBED 20.00 ORNIG CYLINER ASSEMBLY Spare Part 662 159 159 150	3805	5H.007.30.0.PR		·		15%
9808 BH 1008 10 0.00 CVL LINER ASSEMBLY Spee Part 677 1575 3810 9H 009 50 0.0P PISTON ASSEMBLY 1597 1595 3810 1590 250 1597 1595 3811 3810 08 00 09 P PISTON ASSEMBLY 1500 1500 3811 3810 08 00 00 00 P PISTON ASSEMBLY COMPLETE Spee Part 1502 1503 3813 3810 00 00 00 P PISTON ASSEMBLY COMPLETE Spee Part 2520 1593 3813 3810 00 00 P PISTON ASSEMBLY COMPLETE Spee Part 2520 1593 3813 3810 00 00 P PISTON ASSEMBLY COMPLETE Spee Part 2523 1593 3813 3810 00 00 P PISTON ASSEMBLY COMPLETE Spee Part 2523 1593 3813 3810 00 00 00 P PISTON ASSEMBLY COMPLETE Spee Part 2523 1593 3813 3810 00 00 00 00 00 00 00 00 00 00 00 00 0						
\$9.00 \$9.0	3807			·		15%
9310 951,000 50,0 PR PISTON ASSLY COMPLETE Spare Part 10007 159 1391	3808	5H.008.10.0.00	CYL LINER ASSEMBLY	Spare Part	6628	15%
Separage	3809	5H.009.10.0.00		Spare Part	8711	15%
September Sept	3810	5H.009.50.0.PR		·		15%
September Sept	3811	5H.009.60.0.PR	PISTON RING SET 3 RING VERSION	Spare Part	2520	15%
Separa S	3812	5H.009.90.0.PR	PISTON ASSLY COMPLETE	Spare Part	13024	15%
Separa S	3813	5H.010.02.0.PR	INJECTOR CLAMP	Spare Part	2283	15%
Separa S	3814	5H.010.03.0.PR	DOWEL PIN FOR INJECTOR CLAMP	Spare Part	425	15%
3817 5H 014 03.0 PR EXHAUST MANIFOLD Spare Part 8385 159 3818 5H 014 08.0 PR EXPANSION BELLOW Spare Part 5098 159 3819 5H 015 02.0 00 GEAR CASING Spare Part 13766 159 3820 5H 016 01.0 00 CB18 FUEL PUMP Spare Part 8616 159 3821 5H 016 01.0 PR CB18 FUEL PUMP Spare Part 382 159 3822 5H 016 02.0 PR OL SUPPLY PIPE FOR FUEL PUMP Spare Part 732 159 3823 5H 019 001.0 00 SPIN ON CARTRIDGE FOR 5H019 02 0 PR BS IV PRE FILTER Spare Part 2573 209 3824 5H 019 002.0 00 SPIN ON CARTRIDGE FOR 5H019 07 0 PR BS IV MAIN FUEL FILTER Spare Part 4297 209 3826 5H 019 0.1 0.PR FUEL FILTER WITH HAND PRIMER Spare Part 4299 209 3826 5H 019 0.2 0.PR PRE FILTER Spare Part 9441 209 3827 5H 019 1.0 S.P 501 Hs. A check Maintenance kit Spare Part 9441	3815	5H.013.01.0.PR		Spare Part	9464	15%
3818 5H 014 08 0.PR EXPANSION BELLOW Spare Part 5098 159 3819 5H 015 02 0.00 GEAR CASING Spare Part 13766 159 3820 5H 016 01 0.00 CBIS FULL PUMP Spare Part 87617 159 3821 5H 016 01 0.PR CBIS FULL PUMP Spare Part 88463 159 3822 5H 016 02 0.PR OIL SUPPLY PIPE FOR FUEL PUMP Spare Part 223 159 3823 5H 019 010 0.00 SPIN ON CARTRIDGE FOR SH019 02 0 PR BS IV PRE FILTER Spare Part 4207 209 3824 5H 019 020 0.00 SPIN ON CARTRIDGE FOR SH019 01 0 PR BS IV MAIN FUEL FILTER Spare Part 4207 209 3825 5H 019 10.0 PR FUEL FILTER WITH HAND PRIMER Spare Part 4207 209 3825 5H 019 13.0 SP 50 Hrs. S chack Maintenance kit Spare Part 7640 209 3826 5H 019 13.0 SP 50 Hrs. S chack Maintenance kit Spare Part 16376 209 3828 5H 019 14.0 SP 50 Hrs. S chack Maintenance kit Spare Part<	3816	5H.014.01.0.PR	EXHAUST MANIFOLD 4 VALVE	Spare Part	12437	15%
Spare Spar	3817	5H.014.03.0.PR	EXHAUST MANIFOLD	Spare Part	8385	15%
3820 5H:016.01.0.00 CB18 FUEL PUMP Spare Part 87617 159 3821 5H:016.01.0.PR CB18 FUEL PUMP Spare Part 88463 159 3822 5H:016.01.0.PR OB. SUPPLY PIPE FOR FUEL PUMP Spare Part 227 159 3822 5H:019.001.0.00 SPIN ON CARTRIDGE FOR SH019 02 0 PR BS IV PRE FILTER Spare Part 2573 209 3824 5H:019.002.0.00 SPIN ON CARTRIDGE FOR SH019 01 0 PR BS IV MAIN FUEL FILTER Spare Part 4297 209 3825 5H:019.01.0.PR FUEL FILTER WITH HAND PRIMER Spare Part 7416 209 3826 5H:019.10.0.PR FUEL FILTER WITH HAND PRIMER Spare Part 7446 209 3827 5H:019.13.0.SP 5D Hrs. A check Maintenance Kit Spare Part 7640 209 3828 5H:019.13.0.SP 5D Hrs. B Check Maintenance Kit Spare Part 1764 209 3829 5H:019.13.0.SP 1500 Hrs. Check Maintenance Kit Spare Part 2379 209 3820 5H:019.13.0.SP 1500 Hrs. Check Maintenance Ki	3818	5H.014.08.0.PR	EXPANSION BELLOW	Spare Part	5098	15%
3821 \$H.016.01.0.PR CB18 FUEL PUMP Spare Part 88463 1.59 3822 \$H.016.02.0.PR OIL SUPPLY PIPE FOR FUEL PUMP Spare Part 732 1.59 3823 \$H.019.002.0.00 SPIN ON CARTRIDGE FOR \$H.019.01.0 PR BS IV PRE FILTER Spare Part 4297 2.09 3824 \$H.019.002.0.00 SPIN ON CARTRIDGE FOR \$H.019.01.0 PR BS IV MAIN FUEL FILTER Spare Part 4297 2.09 3825 \$H.019.01.0.PR FUEL FILTER WITH HAAD PRIMER Spare Part 7146 2.09 3826 \$H.019.01.0.PR PRE FILTER Spare Part 7640 2.09 3828 \$H.019.13.0.SP 50 Hrs. Acheek Maintenance Kit Spare Part 16376 2.09 3828 \$H.019.14.0.SP 50 Hrs. Acheek Maintenance Kit Spare Part 16376 2.09 3829 \$H.019.16.0.SP 1500 Hrs. C Cheek Maintenance Kit Spare Part 1108 1.19 3831 \$H.020.00.0.PR ADAPTOR ROCKER COVER BREATHER HOSE Spare Part 1108 1.19 3833 \$H.020.00.0.PR GASKET BREATHER	3819	5H.015.02.0.00	GEAR CASING	Spare Part	13766	15%
3822 \$h.016.02.0.PR OIL SUPPLY PIPE FOR FUEL PUMP Spare Part 732 159 3823 \$h.019.001.000 SPIN ON CARTRIDGE FOR \$h019 02 OPR BS IV PRE FILTER Spare Part 2573 209 3824 \$h.019.002.000 SPIN ON CARTRIDGE FOR \$h019 01 OPR BS IV MAIN FUEL FILTER Spare Part 4297 209 3825 \$h.019.01.0.PR FUEL FILTER WITH HAND PRIMER Spare Part 7146 209 3826 \$h.019.02.0.PR PRE FILTER Spare Part 9441 209 3827 \$h.019.13.0.SP 50 Hrs. A check Maintenance Kit Spare Part 7640 209 3828 \$h.019.14.0.SP 50 Hrs. A check Maintenance Kit Spare Part 23179 209 3829 \$h.019.14.0.SP 50 Hrs. B Check Maintenance Kit Spare Part 23179 209 3829 \$h.019.16.0.SP 1500 Hrs. C Check Maintenance Kit Spare Part 23179 209 3830 \$h.020.0.2.0.PR A DAPTOR ROCKER COVER Spare Part 21169 1538 3831 \$h.020.0.0.PR A DAPTOR ROCKER COVER </td <td>3820</td> <td>5H.016.01.0.00</td> <td>CB18 FUEL PUMP</td> <td>Spare Part</td> <td>87617</td> <td>15%</td>	3820	5H.016.01.0.00	CB18 FUEL PUMP	Spare Part	87617	15%
3823 \$H.019.001.0.00 SPIN ON CARTRIDGE FOR SH019 02 0 PR BS IV PRE FILTER Spare Part 2573 20% 3824 \$H.019.002.0.00 SPIN ON CARTRIDGE FOR SH019 01 0 PR BS IV MAIN FUEL FILTER Spare Part 4297 20% 3825 \$H.019.01.0.PR FUEL FILTER WITH HAND PRIMER Spare Part 7146 20% 3826 \$H.019.02.0.PR PRE FILTER Spare Part 7440 20% 3827 \$H.019.13.0.SP SO Hris A check Maintenance Kit Spare Part 16376 20% 3828 \$H.019.14.0.SP 500 Hris B Check Maintenance Kit Spare Part 16376 20% 3829 \$H.019.16.0.SP 1500 Hris C Check Maintenance Kit Spare Part 2179 20% 3830 \$H.020.02.0.PR ADAPTOR ROCKER COVER BREATHER HOSE Spare Part 2119 15% 3831 \$H.020.04.0.PR GASKET BREATHER ADAPTOR ROCKER COVER Spare Part 21 15% 3833 \$H.020.04.0.PR BREATHER PIPE Spare Part 21 15% 3834 \$H.020.04.0.PR HOSE (540L)	3821	5H.016.01.0.PR	CB18 FUEL PUMP	Spare Part	88463	15%
Section	3822	5H.016.02.0.PR	OIL SUPPLY PIPE FOR FUEL PUMP	Spare Part	732	15%
3825 \$H.019.01.0.PR FUEL FILTER WITH HAND PRIMER Spare Part 7146 20% 3826 \$H.019.02.0.PR PRE FILTER \$pare Part 9441 20% 3827 \$H.019.13.0.SP \$D Hrs A check Maintenance Kit \$pare Part 7640 20% 3828 \$H.019.14.0.SP \$50 Hrs B Check Maintenance Kit \$pare Part 18376 20% 3829 \$H.019.16.0.SP \$1500 Hrs C Check Maintenance Kit \$pare Part 23179 20% 3830 \$H.020.02.0.PR ADAPTOR ROCKER COVER BREATHER HOSE \$pare Part 1108 15% 3831 \$H.020.08.0.PR ADAPTOR ROCKER COVER BREATHER HOSE \$pare Part 21 15% 3832 \$H.020.08.0.PR BREATHER PIPE \$pare Part 21 15% 3833 \$H.020.14.0.PR BREATHER PIPE \$pare Part 403 15% 3834 \$H.020.18.0.PR HOSE \$pare Part 403 15% 3835 \$H.020.18.0.PR HOSE (540L) \$pare Part 403 15% 3836<	3823	5H.019.001.0.00	SPIN ON CARTRIDGE FOR 5H019 02 0 PR BS IV PRE FILTER	Spare Part	2573	20%
3826 \$H.019.02.0.PR PRE FILTER Spare Part 9441 20% 3827 \$H.019.13.0.SP \$50 Hrs. & check Maintenance Kit \$pare Part 7640 20% 3828 \$H.019.14.0.SP \$50 Hrs. & Check Maintenance Kit \$pare Part 16376 20% 3829 \$H.019.16.0.SP \$500 Hrs. & Check Maintenance Kit \$pare Part 2177 20% 3830 \$H.020.02.0.PR ADAPTOR ROCKER COVER BREATHER HOSE \$pare Part 1108 15% 3831 \$H.020.04.0.PR GASKET BREATHER ADAPTOR ROCKER COVER \$pare Part 22 15% 3832 \$H.020.04.0.PR BREATHER PIPE \$pare Part 2172 15% 3833 \$H.020.15.0.PR HOSE \$pare Part 403 15% 3834 \$H.020.15.0.PR HOSE (540L) \$pare Part 782 15% 3835 \$H.020.19.0.PR HOSE (540L) \$pare Part 437 15% 3836 \$H.020.19.0.PR HOSE 660L \$pare Part 480 15% 3837 <td< td=""><td>3824</td><td>5H.019.002.0.00</td><td>SPIN ON CARTRIDGE FOR 5H019 01 0 PR BS IV MAIN FUEL FILTER</td><td>Spare Part</td><td>4297</td><td>20%</td></td<>	3824	5H.019.002.0.00	SPIN ON CARTRIDGE FOR 5H019 01 0 PR BS IV MAIN FUEL FILTER	Spare Part	4297	20%
3827 5H.019.13.0.SP 50 Hrs A check Maintenance Kit Spare Part 7640 20% 3828 5H.019.14.0.SP 500 Hrs B Check Maintenance Kit Spare Part 16376 20% 3829 5H.019.16.0.SP 1500 Hrs C Check Maintenance Kit Spare Part 23179 20% 3830 5H.020.02.0.PR ADAPTOR ROCKER COVER BREATHER HOSE Spare Part 1108 1159 3831 5H.020.04.0.PR GASKET BREATHER ADAPTOR ROCKER COVER Spare Part 22 15% 3832 5H.020.08.0.PR BREATHER PIPE Spare Part 2172 15% 3833 5H.020.15.0.PR BREATHER PIPE Spare Part 6661 15% 3834 5H.020.15.0.PR HOSE Spare Part 403 15% 3835 5H.020.19.0.PR HOSE (540L) Spare Part 437 15% 3836 5H.020.19.0.PR HOSE 660L Spare Part 437 15% 3837 5H.020.21.0.PR HOSE 660L Spare Part 2603 15% 3839 <td< td=""><td>3825</td><td>5H.019.01.0.PR</td><td>FUEL FILTER WITH HAND PRIMER</td><td>Spare Part</td><td>7146</td><td>20%</td></td<>	3825	5H.019.01.0.PR	FUEL FILTER WITH HAND PRIMER	Spare Part	7146	20%
3828 5H.019.14.0.SP 500 Hrs B Check Maintenance Kit Spare Part 16376 20% 3829 5H.019.16.0.SP 1500 Hrs C Check Maintenance Kit Spare Part 23179 20% 3830 5H.020.02.0.PR ADAPTOR ROCKER COVER BREATHER HOSE Spare Part 1108 15% 3831 5H.020.08.0.PR GASKET BREATHER ADAPTOR ROCKER COVER Spare Part 22 15% 3832 5H.020.08.0.PR BREATHER PIPE Spare Part 2172 15% 3833 5H.020.14.0.PR BREATHER PIPE Spare Part 403 15% 3834 5H.020.15.0.PR HOSE HOSE 403 15% 3835 5H.020.19.0.PR HOSE 401 5pare Part 403 15% 3836 5H.020.19.0.PR HOSE 580L Spare Part 403 15% 3837 5H.020.19.0.PR HOSE 580L Spare Part 437 15% 3838 5H.022.0.0.PR COVER FOR CAM BORE Spare Part 2603 15% 3839 5H.023.	3826	5H.019.02.0.PR	PRE FILTER	Spare Part	9441	20%
3829 5H.019.16.0.SP 1500 Hrs. C Check Maintenance Kit Spare Part 23179 209 3830 5H.020.02.0.PR ADAPTOR ROCKER COVER BREATHER HOSE Spare Part 1108 15% 3831 5H.020.04.0.PR GASKET BREATHER ADAPTOR ROCKER COVER Spare Part 22 15% 3832 5H.020.08.0.PR BREATHER PIPE Spare Part 2172 15% 3833 5H.020.15.0.PR HOSE Spare Part 403 15% 3834 5H.020.15.0.PR HOSE Spare Part 403 15% 3835 5H.020.15.0.PR HOSE (540L) Spare Part 762 15% 3836 5H.020.19.0.PR HOSE (540L) Spare Part 437 15% 3837 5H.020.19.0.PR HOSE 660L Spare Part 480 15% 3838 5H.022.0.0.PR COVER FOR CAM BORE Spare Part 2603 15% 3839 5H.022.0.0.PR COVER PLATE FOR FUEL PUMP Spare Part 2071 15% 3840 5H.022.0.0.PR <t< td=""><td>3827</td><td>5H.019.13.0.SP</td><td>50 Hrs A check Maintenance Kit</td><td>Spare Part</td><td>7640</td><td>20%</td></t<>	3827	5H.019.13.0.SP	50 Hrs A check Maintenance Kit	Spare Part	7640	20%
3830 SH.020.02.0.PR ADAPTOR ROCKER COVER BREATHER HOSE Spare Part 1108 15% 3831 5H.020.04.0.PR GASKET BREATHER ADAPTOR ROCKER COVER Spare Part 22 15% 3832 5H.020.08.0.PR BREATHER PIPE Spare Part 2172 15% 3833 5H.020.14.0.PR BREATHER PIPE Spare Part 6661 15% 3834 5H.020.15.0.PR HOSE 6401 15% 3835 5H.020.18.0.PR HOSE (540L) Spare Part 782 15% 3836 5H.020.19.0.PR HOSE (540L) Spare Part 437 15% 3837 5H.020.21.0.PR HOSE 660L Spare Part 480 15% 3838 5H.022.0.0.PR COVER FOR CAM BORE Spare Part 2603 15% 3839 5H.022.0.0.PR COVER PLATE FOR FUEL PUMP Spare Part 2603 15% 3840 5H.024.20.0.PR CAMSHAFT ASSEMBLY Spare Part 2627 15% 3841 5H.025.00.PR CAMSHAFT ASSEMBLY Spare Part 252 15% 3842 5H.025.00.PR	3828	5H.019.14.0.SP	500 Hrs B Check Maintenance Kit	Spare Part	16376	20%
3831 5H.020.04.0.PR GASKET BREATHER ADAPTOR ROCKER COVER Spare Part 22 15% 3832 5H.020.08.0.PR BREATHER PIPE Spare Part 2172 15% 3833 5H.020.14.0.PR BREATHER PIPE Spare Part 6661 15% 3834 5H.020.15.0.PR HOSE Spare Part 403 15% 3835 5H.020.18.0.PR HOSE (540L) Spare Part 782 15% 3836 5H.020.19.0.PR HOSE 660L Spare Part 437 15% 3837 5H.020.21.0.PR HOSE 660L Spare Part 2603 15% 3838 5H.022.02.0.PR COVER FOR CAM BORE Spare Part 2603 15% 3840 5H.023.02.0.PR COVER PLATE FOR FUEL PUMP Spare Part 2071 15% 3841 5H.024.20.0.PR CAMSHAFT ASSEMBLY Spare Part 2627 15% 3842 5H.025.02.0.PR CAMSHAFT ASSLY Spare Part 252 15% 3843 5H.025.0.0.PR CAMSHAFT ASSLY	3829	5H.019.16.0.SP	1500 Hrs C Check Maintenance Kit	Spare Part	23179	20%
3832 5H.020.08.0.PR BREATHER PIPE Spare Part 2172 159 3833 5H.020.14.0.PR BREATHER PIPE Spare Part 6661 159 3834 5H.020.15.0.PR HOSE Spare Part 403 159 3835 5H.020.18.0.PR HOSE (540L) Spare Part 437 159 3836 5H.020.19.0.PR HOSE 580L Spare Part 437 159 3837 5H.020.21.0.PR HOSE 660L Spare Part 480 159 3838 5H.022.02.0.PR COVER FOR CAM BORE Spare Part 2603 159 3839 5H.023.02.0.PR COVER PLATE FOR FUEL PUMP Spare Part 2071 159 3840 5H.024.20.0.PR CAMSHAFT ASSEMBLY Spare Part 26270 159 3841 5H.024.50.0.PR CAMSHAFT ASSLY Spare Part 26270 159 3842 5H.025.02.0.PR GASKET BELLOW EXHAUST MANIFOLD Spare Part 252 159 3843 5H.025.00.0.PR CAMSHAFT ASSLY	3830	5H.020.02.0.PR	ADAPTOR ROCKER COVER BREATHER HOSE	Spare Part	1108	15%
3833 5H.020.14.0.PR BREATHER PIPE Spare Part 6661 15% 3834 5H.020.15.0.PR HOSE Spare Part 403 15% 3835 5H.020.18.0.PR HOSE (540L) Spare Part 782 15% 3836 5H.020.19.0.PR HOSE 580L Spare Part 437 15% 3837 5H.020.21.0.PR HOSE 660L Spare Part 480 15% 3838 5H.022.02.0.PR COVER FOR CAM BORE Spare Part 2603 15% 3849 5H.023.02.0.PR COVER PLATE FOR FUEL PUMP Spare Part 2071 15% 3840 5H.024.20.0.PR CAMSHAFT ASSLY Spare Part 37978 15% 3841 5H.024.50.0.PR CAMSHAFT ASSLY Spare Part 26270 15% 3842 5H.025.02.0.PR CAMSHAFT ASSLY Spare Part 252 15% 3843 5H.025.02.0.PR CASKET BELLOW EXHAUST MANIFOLD Spare Part 252 15% 3844 5H.025.04.0.PR CYRON BELLOW FOR EXHAUST Spare Part 252 15% 3844 5H.025.04.0.PR<	3831	5H.020.04.0.PR	GASKET BREATHER ADAPTOR ROCKER COVER	Spare Part	22	15%
3834 5H.020.15.0.PR HOSE Spare Part 403 15% 3835 5H.020.18.0.PR HOSE (540L) Spare Part 782 15% 3836 5H.020.19.0.PR HOSE 580L Spare Part 437 15% 3837 5H.020.21.0.PR HOSE 660L Spare Part 480 15% 3838 5H.022.02.0.PR COVER FOR CAM BORE Spare Part 2603 15% 3849 5H.023.02.0.PR COVER PLATE FOR FUEL PUMP Spare Part 2071 15% 3840 5H.024.20.0.PR CAMSHAFT ASSEMBLY Spare Part 37978 15% 3841 5H.024.50.0.PR CAMSHAFT ASSEMBLY Spare Part 26270 15% 3842 5H.025.02.0.PR GASKET BELLOW EXHAUST MANIFOLD Spare Part 252 15% 3843 5H.025.04.0.PR EXPANSION BELLOW FOR EXHAUST Spare Part 7501 15% 3844 5H.025.08.0.PR O' RING (EGR WATER IN & OUT) Spare Part 123 15% 3845 5H.025.13.0.PR O RING EGR COOLER WATER IN Spare Part 114 15% <t< td=""><td>3832</td><td>5H.020.08.0.PR</td><td>BREATHER PIPE</td><td>Spare Part</td><td>2172</td><td>15%</td></t<>	3832	5H.020.08.0.PR	BREATHER PIPE	Spare Part	2172	15%
3835 5H.020.18.0.PR HOSE (540L) Spare Part 782 159 3836 5H.020.19.0.PR HOSE 580L Spare Part 437 159 3837 5H.020.21.0.PR HOSE 660L Spare Part 480 159 3838 5H.022.02.0.PR COVER FOR CAM BORE Spare Part 2603 159 3839 5H.023.02.0.PR COVER PLATE FOR FUEL PUMP Spare Part 2071 159 3840 5H.024.20.0.PR CAMSHAFT ASSEMBLY Spare Part 26270 159 3841 5H.024.50.0.PR CAMSHAFT ASSLY Spare Part 26270 159 3842 5H.025.02.0.PR GASKET BELLOW EXHAUST MANIFOLD Spare Part 252 159 3843 5H.025.04.0.PR EXPANSION BELLOW FOR EXHAUST Spare Part 7501 159 3844 5H.025.04.0.PR O' RING (EGR WATER IN & OUT) Spare Part 123 159 3845 5H.025.13.0.PR O' RING EGR COOLER WATER IN Spare Part 114 159 3846 5H.025.	3833	5H.020.14.0.PR	BREATHER PIPE	Spare Part	6661	15%
3836 5H.020.19.0.PR HOSE 580L Spare Part 437 159 3837 5H.020.21.0.PR HOSE 660L Spare Part 480 159 3838 5H.022.02.0.PR COVER FOR CAM BORE Spare Part 2603 159 3839 5H.023.02.0.PR COVER PLATE FOR FUEL PUMP Spare Part 2071 159 3840 5H.024.20.0.PR CAMSHAFT ASSEMBLY Spare Part 37978 159 3841 5H.024.50.0.PR CAMSHAFT ASSLY Spare Part 26270 159 3842 5H.025.02.0.PR GASKET BELLOW EXHAUST MANIFOLD Spare Part 252 159 3843 5H.025.04.0.PR EXPANSION BELLOW FOR EXHAUST Spare Part 7501 159 3844 5H.025.08.0.PR O'RING (EGR WATER IN & OUT) Spare Part 123 159 3845 5H.025.11.0.PR GASKET Exhaust pipe EGR cooler Spare Part 114 159 3846 5H.025.13.0.PR O RING EGR COOLER WATER IN Spare Part 95 159 3848	3834	5H.020.15.0.PR	HOSE	Spare Part	403	15%
3837 5H.020.21.0.PR HOSE 660L Spare Part 480 159 3838 5H.022.02.0.PR COVER FOR CAM BORE Spare Part 2603 159 3839 5H.023.02.0.PR COVER PLATE FOR FUEL PUMP Spare Part 2071 159 3840 5H.024.20.0.PR CAMSHAFT ASSEMBLY Spare Part 37978 159 3841 5H.024.50.0.PR CAMSHAFT ASSLY Spare Part 26270 159 3842 5H.025.02.0.PR GASKET BELLOW EXHAUST MANIFOLD Spare Part 252 159 3843 5H.025.04.0.PR EXPANSION BELLOW FOR EXHAUST Spare Part 7501 159 3844 5H.025.04.0.PR O' RING (EGR WATER IN & OUT) Spare Part 123 159 3845 5H.025.11.0.PR GASKET Exhaust pipe EGR cooler Spare Part 3058 159 3846 5H.025.13.0.PR O RING EGR COOLER WATER IN Spare Part 114 159 3847 5H.025.14.0.PR O RING EGR COOLER WATER OUT Spare Part 95 159	3835	5H.020.18.0.PR	HOSE (540L)	Spare Part	782	15%
3838 5H.022.02.0.PR COVER FOR CAM BORE Spare Part 2603 15% 3839 5H.023.02.0.PR COVER PLATE FOR FUEL PUMP Spare Part 2071 15% 3840 5H.024.20.0.PR CAMSHAFT ASSEMBLY Spare Part 37978 15% 3841 5H.024.50.0.PR CAMSHAFT ASSLY Spare Part 26270 15% 3842 5H.025.02.0.PR GASKET BELLOW EXHAUST MANIFOLD Spare Part 252 15% 3843 5H.025.04.0.PR EXPANSION BELLOW FOR EXHAUST Spare Part 7501 15% 3844 5H.025.04.0.PR O' RING (EGR WATER IN & OUT) Spare Part 123 15% 3845 5H.025.11.0.PR GASKET Exhaust pipe EGR cooler Spare Part 3058 15% 3846 5H.025.13.0.PR O RING EGR COOLER WATER IN Spare Part 114 15% 3847 5H.025.14.0.PR O RING EGR COOLER WATER OUT Spare Part 95 15% 3848 5H.025.16.0.PR EXPANSION BELLOW Spare Part 1394 15% <t< td=""><td>3836</td><td>5H.020.19.0.PR</td><td>HOSE 580L</td><td>Spare Part</td><td>437</td><td>15%</td></t<>	3836	5H.020.19.0.PR	HOSE 580L	Spare Part	437	15%
3839 5H.023.02.0.PR COVER PLATE FOR FUEL PUMP Spare Part 2071 15% 3840 5H.024.20.0.PR CAMSHAFT ASSEMBLY Spare Part 37978 15% 3841 5H.024.50.0.PR CAMSHAFT ASSLY Spare Part 26270 15% 3842 5H.025.02.0.PR GASKET BELLOW EXHAUST MANIFOLD Spare Part 252 15% 3843 5H.025.04.0.PR EXPANSION BELLOW FOR EXHAUST Spare Part 7501 15% 3844 5H.025.08.0.PR O' RING (EGR WATER IN & OUT) Spare Part 123 15% 3845 5H.025.11.0.PR GASKET Exhaust pipe EGR cooler Spare Part 3058 15% 3846 5H.025.13.0.PR O RING EGR COOLER WATER IN Spare Part 114 15% 3847 5H.025.14.0.PR O RING EGR COOLER WATER OUT Spare Part 95 15% 3848 5H.025.16.0.PR EXPANSION BELLOW Spare Part 1394 15% 3849 5H.025.17.0.PR EGR PIPE EGR VALVE SIDE Spare Part 1394 15% <	3837	5H.020.21.0.PR	HOSE 660L	Spare Part	480	15%
3840 5H.024.20.0.PR CAMSHAFT ASSEMBLY Spare Part 37978 159 3841 5H.024.50.0.PR CAMSHAFT ASSLY Spare Part 26270 159 3842 5H.025.02.0.PR GASKET BELLOW EXHAUST MANIFOLD Spare Part 252 159 3843 5H.025.04.0.PR EXPANSION BELLOW FOR EXHAUST Spare Part 7501 159 3844 5H.025.08.0.PR O' RING (EGR WATER IN & OUT) Spare Part 123 159 3845 5H.025.11.0.PR GASKET Exhaust pipe EGR cooler Spare Part 3058 159 3846 5H.025.13.0.PR O RING EGR COOLER WATER IN Spare Part 114 159 3847 5H.025.14.0.PR O RING EGR COOLER WATER OUT Spare Part 95 159 3848 5H.025.16.0.PR EXPANSION BELLOW Spare Part 8385 159 3849 5H.025.17.0.PR EGR PIPE EGR VALVE SIDE Spare Part 1394 159	3838	5H.022.02.0.PR	COVER FOR CAM BORE	Spare Part	2603	15%
3841 5H.024.50.0.PR CAMSHAFT ASSLY Spare Part 26270 159 3842 5H.025.02.0.PR GASKET BELLOW EXHAUST MANIFOLD Spare Part 252 159 3843 5H.025.04.0.PR EXPANSION BELLOW FOR EXHAUST Spare Part 7501 159 3844 5H.025.08.0.PR O' RING (EGR WATER IN & OUT) Spare Part 123 159 3845 5H.025.11.0.PR GASKET Exhaust pipe EGR cooler Spare Part 3058 159 3846 5H.025.13.0.PR O RING EGR COOLER WATER IN Spare Part 114 159 3847 5H.025.14.0.PR O RING EGR COOLER WATER OUT Spare Part 95 159 3848 5H.025.16.0.PR EXPANSION BELLOW Spare Part 8385 159 3849 5H.025.17.0.PR EGR PIPE EGR VALVE SIDE Spare Part 1394 159	3839	5H.023.02.0.PR	COVER PLATE FOR FUEL PUMP	Spare Part	2071	15%
3842 5H.025.02.0.PR GASKET BELLOW EXHAUST MANIFOLD Spare Part 252 15% 3843 5H.025.04.0.PR EXPANSION BELLOW FOR EXHAUST Spare Part 7501 15% 3844 5H.025.08.0.PR O' RING (EGR WATER IN & OUT) Spare Part 123 15% 3845 5H.025.11.0.PR GASKET Exhaust pipe EGR cooler Spare Part 3058 15% 3846 5H.025.13.0.PR O RING EGR COOLER WATER IN Spare Part 114 15% 3847 5H.025.14.0.PR O RING EGR COOLER WATER OUT Spare Part 95 15% 3848 5H.025.16.0.PR EXPANSION BELLOW Spare Part 8385 15% 3849 5H.025.17.0.PR EGR PIPE EGR VALVE SIDE Spare Part 1394 15%	3840	5H.024.20.0.PR	CAMSHAFT ASSEMBLY	Spare Part	37978	15%
3843 5H.025.04.0.PR EXPANSION BELLOW FOR EXHAUST Spare Part 7501 15% 3844 5H.025.08.0.PR O'RING (EGR WATER IN & OUT) Spare Part 123 15% 3845 5H.025.11.0.PR GASKET Exhaust pipe EGR cooler Spare Part 3058 15% 3846 5H.025.13.0.PR O RING EGR COOLER WATER IN Spare Part 114 15% 3847 5H.025.14.0.PR O RING EGR COOLER WATER OUT Spare Part 95 15% 3848 5H.025.16.0.PR EXPANSION BELLOW Spare Part 8385 15% 3849 5H.025.17.0.PR EGR PIPE EGR VALVE SIDE Spare Part 1394 15%	3841	5H.024.50.0.PR	CAMSHAFT ASSLY	Spare Part	26270	15%
3844 5H.025.08.0.PR O'RING (EGR WATER IN & OUT) Spare Part 123 15% 3845 5H.025.11.0.PR GASKET Exhaust pipe EGR cooler Spare Part 3058 15% 3846 5H.025.13.0.PR O RING EGR COOLER WATER IN Spare Part 114 15% 3847 5H.025.14.0.PR O RING EGR COOLER WATER OUT Spare Part 95 15% 3848 5H.025.16.0.PR EXPANSION BELLOW Spare Part 8385 15% 3849 5H.025.17.0.PR EGR PIPE EGR VALVE SIDE Spare Part 1394 15%	3842	5H.025.02.0.PR	GASKET BELLOW EXHAUST MANIFOLD	Spare Part	252	15%
3845 5H.025.11.0.PR GASKET Exhaust pipe EGR cooler Spare Part 3058 15% 3846 5H.025.13.0.PR O RING EGR COOLER WATER IN Spare Part 114 15% 3847 5H.025.14.0.PR O RING EGR COOLER WATER OUT Spare Part 95 15% 3848 5H.025.16.0.PR EXPANSION BELLOW Spare Part 8385 15% 3849 5H.025.17.0.PR EGR PIPE EGR VALVE SIDE Spare Part 1394 15%	3843	5H.025.04.0.PR	EXPANSION BELLOW FOR EXHAUST	Spare Part	7501	15%
3846 5H.025.13.0.PR O RING EGR COOLER WATER IN Spare Part 114 159 3847 5H.025.14.0.PR O RING EGR COOLER WATER OUT Spare Part 95 159 3848 5H.025.16.0.PR EXPANSION BELLOW Spare Part 8385 159 3849 5H.025.17.0.PR EGR PIPE EGR VALVE SIDE Spare Part 1394 159	3844	5H.025.08.0.PR	O' RING (EGR WATER IN & OUT)	Spare Part	123	15%
3846 5H.025.13.0.PR O RING EGR COOLER WATER IN Spare Part 114 159 3847 5H.025.14.0.PR O RING EGR COOLER WATER OUT Spare Part 95 159 3848 5H.025.16.0.PR EXPANSION BELLOW Spare Part 8385 159 3849 5H.025.17.0.PR EGR PIPE EGR VALVE SIDE Spare Part 1394 159	3845	5H.025.11.0.PR	GASKET Exhaust pipe EGR cooler	Spare Part	3058	15%
3847 5H.025.14.0.PR O RING EGR COOLER WATER OUT Spare Part 95 15% 3848 5H.025.16.0.PR EXPANSION BELLOW Spare Part 8385 15% 3849 5H.025.17.0.PR EGR PIPE EGR VALVE SIDE Spare Part 1394 15%				·		15%
3848 5H.025.16.0.PR EXPANSION BELLOW Spare Part 8385 15% 3849 5H.025.17.0.PR EGR PIPE EGR VALVE SIDE Spare Part 1394 15%				·		15%
3849 5H.025.17.0.PR EGR PIPE EGR VALVE SIDE Spare Part 1394 15%				·		15%
						15%
	3850	5H.025.21.0.PR	EXHAUST PIPE BELLOW TO EGR	Spare Part		15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
3851	5H.025.22.0.PR	EGR PIPE EGR COOLER SIDE	Spare Part	2458	15%
3852	5H.025.23.0.PR	ADAPTOR EGR COOLER WATER IN	Spare Part	1009	15%
3853	5H.025.24.0.PR	ADAPTOR EGR COOLER WATER OUT	Spare Part	982	15%
3854	5H.025.25.0.PR	EGR COOLER 5 KW	Spare Part	26338	15%
3855	5H.025.26.0.PR	GASKET BETWEEN EGR COOLER AND EXHAUST PIPE	Spare Part	286	15%
3856	5H.026.02.0.PR	FUEL PIPE FUEL PUMP TO FUEL FILTER	Spare Part	676	20%
3857	5H.026.06.0.PR	BRACKET FOR FUEL FILTER	Spare Part	1951	15%
3858	5H.027.01.0.PR	EGR VALVE ASSEMBLY FOR 4R1190 BS-IV	Spare Part	29668	20%
3859	5H.027.03.0.PR	ADAPTOR	Spare Part	8652	15%
3860	5H.027.05.0.PR	GASKET EGR MIXER INLET MANIFOLD	Spare Part	95	15%
3861	5H.027.06.0.PR	HOSE EGR VALVE WATER INLET	Spare Part	265	15%
3862	5H.027.07.0.PR	HOSE EGR VALVE WATER OUT	Spare Part	295	15%
3863	5H.027.08.0.PR	GASKET BETWEEN EGR VALVE AND EGR PIPE	Spare Part	114	15%
3864	5H.027.09.0.PR	GASKET BETWEEN EGR MIXER AND EGR VALVE	Spare Part	142	15%
3865	5H.027.11.0.PR	PLATE FOR HOSE CLAMP	Spare Part	126	15%
3866	5H.027.12.0.PR	ARAYMOND CLAMP 018099 ID 14	Spare Part	166	15%
3867	5H.027.14.0.PR	ARAYMOND CLAMP 015553 ID 14 15	Spare Part	252	15%
3868	5H.027.16.0.PR	ADAPTOR	Spare Part	8828	15%
3869	5H.029.01.0.PR	INTAKE THROTTLE VALVE	Spare Part	21670	20%
3870	5H.029.02.0.PR	GASKET THROTTLE VALVE MIXER	Spare Part	62	15%
3871	5H.029.03.0.PR	GASKET THROTTLE VALVE HEATER	Spare Part	62	15%
3872	5H.029.05.0.PR	SPACER FOR INTAKE THROTTLE VALVE	Spare Part	3474	15%
3873	5H.030.01.0.PR	V BAND CLAMP	Spare Part	668	15%
3874	5H.031.02.0.PR	BRACKET FOR ECU MOUNTING	Spare Part	1898	15%
3875	5H.032.02.0.PR	GASKET ROCKER COVER	Spare Part	1782	15%
3876	5H.032.03.0.PR	WIRE MESH 66 5x10x18 2 36 GAUGE STEEL WIRE	Spare Part	123	15%
3877	5H.032.04.0.PR	BAFFLE PLATE	Spare Part	5181	15%
3878	5H.032.05.0.PR	BOLT FOR ROCKER COVER	Spare Part	182	15%
3879	5H.032.06.0.PR	ROCKER COVER	Spare Part	11498	15%
3880	5H.032.09.0.PR	BAFFLE PLATE	Spare Part	5711	15%
3881	5H.034.09.0.PR	VALVE BRIDGE FOR ROCKER LEVER	Spare Part	560	15%
3882	5H.034.50.0.PR	VALVE ROCKER LEVER ASSY COMPLETE	Spare Part	11212	15%
3883	5H.034.90.0.PR	VALVE ROCKER LEVER ASSY COMPLETE	Spare Part	37778	15%
3884	5H.035.01.0.PR	LEAKOFF PIPE	Spare Part	2874	15%
3885	5H.035.08.0.PR	PLATE FOR LEAK OFF CLAMP	Spare Part	98	15%
3886	5H.035.11.0.PR	ARAYMOND CLAMP 019050	Spare Part	108	15%
3887	5H.035.15.0.PR	LEAK OFF PIPE INJECTOR SIDE	Spare Part	41113	15%
3888	5H.035.18.0.PR	METALLIC LEAK OFF PIPE (INJECTOR SIDE)	Spare Part	6375	15%
3889	5H.036.02.0.PR	BRACKET DOC MOUNTING	Spare Part	7809	15%
3890	5H.036.08.0.PR	BRACKET FOR DOC MOUNTING	Spare Part	8101	15%
3891	5H.036.09.0.PR	BRACKET FOR SCR MOUNTING	Spare Part	12775	15%
3892	5H.036.10.0.PR	UREA TANK ASSEMBLY 4R1190TA - BSIV	Spare Part	89684	20%
3893	5H.036.100.0.PR	ADBLUE TANK BRACKET ASSLY	Spare Part	21138	15%
3894	5H.036.101.0.PR	UREA RETURN PIPE SUPPLY MODULE TO TANK	Spare Part	1714	15%
3895	5H.036.102.0.PR	UREA PIPE TANK TO SUPPLY MODULE	Spare Part	2203	15%
3896	5H.036.103.0.PR	ARAYMOND CLAMP TWO PIPE CLIP ID 8 9	Spare Part	77	15%
3897	5H.036.17.0.PR	MOUNTING BRACKET FOR DOC SCR	Spare Part	15772	15%
3898	5H.036.18.0.PR	4R1190TA BSIV UREA TANK ASSEMBLY WITH MODIFIED FILTER AND RUA TABLE UREA TANK AS	Spare Part	86457	15%
3899	5H.036.19.0.PR	BRACKET FOR SCU MOUNTING	Spare Part	772	15%
3900	5H.036.20.0.PR	DOC UPWARD OPENING (diesel oxidation catalyst)	Spare Part	54783	20%
		DOC MOUNTING BRACKET	Spare Part	2302	15%
3901	5H.036.24.0.PR	+	•		15%
3902	5H.036.25.0.PR	DOC MOUNTING BRACKET SUPPORT 2	Spare Part	812	
3903	5H.036.26.0.PR	DOC MOUNTING BRACKET SUPPORT 1	Spare Part	2172	15%
3904	5H.036.30.0.PR	DOC DOWNWARD OPENING 20	Spare Part	54709	20%



				Price to	
				Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
		LIDEA TANKO DINO DADENO JEDAGO	0 5 1	NPR	450/
3906	5H.036.32.0.PR	UREA TANK O RING PART NO JZR0607	Spare Part	62	15%
3907	5H.036.33.0.PR	UREA TANK FILLING NECK PART NO JS21980	Spare Part	2806	15%
3908	5H.036.34.0.PR	UREA TANK LOCKING CAP PART NO JKE00558	Spare Part	4261	15%
3909	5H.036.35.0.PR	Urea tank AdBlue sensor	Spare Part	54409	15%
3910	5H.036.36.0.PR	UREA TANK FILLER FILTER PART NO JZP0321 UREA TANK DRAIN PLUG PART NO JSM05502	Spare Part	526 705	20% 15%
3911	5H.036.37.0.PR	O RING FOR UREA TANK SENSOR	Spare Part	320	15%
3912	5H.036.41.0.PR		Spare Part		
3913	5H.036.43.0.PR	5H 036 43 0 PR CNAAT 301 JKA04030	Spare Part	51793	15%
3914	5H.036.88.0.PR	RUBBER MOUNT 25X20	Spare Part	357	15%
3915	5H.036.89.0.PR	PLATE PURPLE CTUR	Spare Part	74	15%
3916	5H.036.96.0.PR	RUBBER STRIP	Spare Part	342	15%
3917	5H.037.20.0.SP	DOC UPWARD OPENING	Spare Part	57787	15%
3918	5H.039.02.0.PR	O RING AIR SENSOR ADAPTOR	Spare Part	191	15%
3919	5H.039.03.0.PR	SPACER PLATE	Spare Part	1603	15%
3920	5H.039.04.0.PR	PIPE (AIR INLET)	Spare Part	2483	15%
3921	5H.039.05.0.PR	ADAPTOR FOR AIR SENSOR	Spare Part	4308	15%
3922	5H.039.06.0.PR	V BAND CLAMP	Spare Part	868	15%
3923	5H.040.10.0.PR	H P PIPE FOR CYL 1	Spare Part	2221	20%
3924	5H.040.20.0.PR	H P PIPE FOR CYL 2	Spare Part	2221	20%
3925	5H.040.30.0.PR	H P PIPE FOR CYL 3	Spare Part	2221	20%
3926	5H.040.40.0.PR	H P PIPE FOR CYL 4	Spare Part	2221	20%
3927	5H.040.50.0.PR	H P PIPE PUMP TO RAIL	Spare Part	2099	20%
3928	5H.040.60.0.PR	H P PIPE PUMP TO RAIL	Spare Part	2099	20%
3929	5H.043.22.0.PR	ENGINE WIRING HARNESS FOR 4R1190NA BSIV ENGINE	Spare Part	34332	15%
3930	5H.043.32.0.PR	ENGINE WIRING HARNESS FOR 4R1190TA BSIV ENGINE	Spare Part	47439	15%
3931	5H.045.01.0.PR	HEADER FOR LUB OIL COOLER AND SPIN ON FILTER	Spare Part	5861	15%
3932	5H.045.02.0.PR	HEADER FOR REMOTE LUB OIL FILTER	Spare Part	6095	15%
3933	5H.045.32.0.PR	EXTENSION WIRING HARNESS FOR 4R1190TA BS IV ENGINE 110HP FOR TOP MTG EGT	Spare Part	63605	15%
3934	5H.045.50.0.PR	EXTENSION WIRING HARNESS FOR 4R1190TA BS IV ENGINE 110HP FOR FLYWHEEL MTG EGT	Spare Part	86497	15%
3935	5H.045.90.0.PR	LUB OIL COOLER HEADER ASSEMBLY	Spare Part	6652	15%
3936	5H.046.122.0.PR	HEATER WIRE SUPPORT BRACKET S F 4R1190 BSIV ENGINE	Spare Part	418	15%
3937	5H.050.10.0.PR	AIR CLEANER ASSEMBLY (350 KG/HR) 90 DEG BEND OUTLET SPOUT (FP-G080726)	Spare Part	11018	15%
3938	5H.051.05.0.PR	PLATE FOR ROLLER TAPPET	Spare Part	692	15%
3939	5H.051.07.0.PR	PLATE FOR ROLLER TAPPET	Spare Part	566	15%
3940	5H.051.10.0.PR	ROLLER TAPPET ASSEMBLY	Spare Part	3751	15%
3941	5H.051.30.0.PR	PUSH ROD WELDED	Spare Part	231	15%
3942	5H.053.01.0.PR	ADAPTOR (FOR TURBO OIL INLET 11/16-16 UNF TO 12)	Spare Part	418	15%
3943	5H.053.02.0.PR	ADAPTOR CRANKCASE SIDE UNF 11 16 16	Spare Part	1034	15%
3944	5H.053.10.0.PR	LUB OIL SUPPLY PIPE FOR TURBOCHARGER	Spare Part	1157	15%
3945	5H.053.20.0.PR	DRAIN PIPE WITH FLANGE AND SLEEVE	Spare Part	1618	15%
3946	5H.053.22.0.PR	TURBO DRAIN PIPE	Spare Part	3665	15%
3947	5H.053.30.0.PR	LUB OIL SUPPLY PIPE FOR TURBOCHARGER	Spare Part	1025	15%
3948	5H.053.40.0.PR	DRAIN PIPE WITH FLANGE AND SLEEVE	Spare Part	9391	15%
3949	5H.053.50.0.PR	TURBO OIL IN PIPE	Spare Part	862	15%
3950	5H.053.60.0.PR	TURBO OIL DRAIN PIPE	Spare Part	2714	15%
3951	5H.053.70.0.PR	TURBO DRAIN PIPE	Spare Part	9440	15%
3952	5H.053.71.0.PR	DRAIN PIPE WITH FLANGE SLEEVE	Spare Part	8594	15%
3953	5H.053.80.0.PR	TURBO DRAIN PIPE WITH FLANGE SLEEVE	Spare Part	1840	15%
3954	5H.054.01.0.PR	CRANKSHAFT PULLEY WITH POLY V GROOVE FOR 143 PCD	Spare Part	6523	15%
3955	5H.055.01.0.PR	PULLEY 100 PCD POLY V FOR WATER PUMP	Spare Part	2142	15%
3956	5H.056.01.0.PR	TURBOCHARGER	Spare Part	82531	15%
3957	5H.056.02.0.PR	TURBOCHARGER	Spare Part	68331	15%
3958	5H.056.03.0.PR	TURBO CHARGER	Spare Part	82211	15%
3959	5H.056.04.0.PR	TURBOCHARGER FOR 4R1190TA 74 5 HP 2200 RPM ENGINE	Spare Part	81070	15%
3960	5H.056.05.0.PR	TURBOCHARGER	Spare Part	82614	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
				without Vat in NPR	Charge%
3961	5H.056.07.0.PR	TURBOCHARGER FOR 4R CPCB4 ENGINE B1 055C81QS24A01EN C11 0 24 058X71AF18R70ES C	Spare Part	82020	15%
3962	5H.057.01.0.PR	FLYWHEEL HOUSING SAE 3 W 155 SS BB	Spare Part	40396	15%
3963	5H.058.20.0.PR	FLYWHEEL ASSEMBLY	Spare Part	22150	15%
3964	5H.059.10.0.PR	THERMOSTAT HOUSING ASSEMBLY OPENING TOWARD EXHAUST AND TALL HEIGHT	Spare Part	7865	15%
3965	5H.060.01.0.PR	EXHAUST DIFFUSER	Spare Part	2662	15%
3966	5H.060.03.0.PR	EXPANSION BELLOW	Spare Part	17052	15%
3967	5H.060.04.0.PR	EXHAUST PIPE	Spare Part	8541	15%
3968	5H.060.05.0.PR	GASKET EXAHUST PIPE AND DOC	Spare Part	222	15%
3969	5H.060.08.0.PR	EXHAUST PIPE BETWEEN DIFFUSER AND EXPANSION BELLOW	Spare Part	4563	15%
3970	5H.061.02.0.PR	V CLAMP FOR DM 3 2 BOSCH PART NUMBER 0449 Z98 417 00	Spare Part	785	15%
3971	5H.062.01.0.PR	LUB OIL SUMP DRAIN PLUG AT BOTTOM SIDE	Spare Part	28000	15%
3972	5H.063.01.0.PR	CLOSED CRANKCASE VENTILATION CCV 4R1190TA	Spare Part	4049	15%
3973	5H.063.02.0.PR	BRACKET FOR MAHLE CCV MTG 4R1190TA	Spare Part	662	15%
3974	5H.063.03.0.PR	HOSE BLOW BY IN	Spare Part	975	15%
3975	5H.063.04.0.PR	OIL DRAIN HOSE 4R1190TA	Spare Part	1249	15%
3976	5H.063.05.0.PR	BLOW BY OUT HOSE CCV SIDE	Spare Part	843	15%
3977	5H.063.06.0.PR	INTERMEDIATE PIPE CCV OUT	Spare Part	1929	15%
3978	5H.063.08.0.PR	CLAMP DIA 9 11	Spare Part	465	15%
3979	5H.063.12.0.PR	CLAMP	Spare Part	212	15%
3980	5H.063.17.0.PR	INTERMEDIATE PIPE (CCV OUT)	Spare Part	754	15%
3981	5H.063.18.0.PR	HOSE PIPE OIL DRAIN TO SUMP	Spare Part	2268	15%
3982	5H.063.21.0.PR	OIL DRAIN HOSE PIPE CCV TO SUMP	Spare Part	2160	15%
3983	5H.063.25.0.PR	OIL DRAIN HOSE PIPE CCV TO CI SUMP	Spare Part	3434	15%
3984	5H.063.31.0.PR	BRACKET FOR CCV MOUNTING	Spare Part	2262	15%
3985	5H.063.32.0.PR	HOSE PIPE ROCKER COVER TO CCV	Spare Part	1240	15%
3986	5H.063.33.0.PR	HOSE PIPE CCV TO AIR INLET PIPE	Spare Part	2775	15%
3987	5H.063.34.0.PR	OIL DRAIN HOSE CCV TO CI SUMP	Spare Part	3880	15%
3988	5H.064.01.0.PR	LUBE OIL SUMP FABRICATED	Spare Part	13566	15%
3989	5H.064.03.0.PR	LUB OIL SUMP FABRICATED	Spare Part	15775	15%
3990	5H.070.01.0.PR	GASKET	Spare Part	1748	15%
3991	5H.070.02.0.PR	V BAND CLAMP	Spare Part	4837	15%
3992	5H.070.10.0.PR	ASSEMBLY OF EMISSION AFTER TREATMENT FOR 110 HP BS IV DOC DCOM TUBE SCR VARIA	Spare Part	116595	15%
3993	5H.070.100.0.PR	DOC (SIDE MOUNTED)	Spare Part	81676	15%
3994	5H.070.110.0.PR	SCR SIDE MOUNTED	Spare Part	96679	15%
3995	5H.070.120.0.SP	4R1190TA BSIV EGT strap assembly spare part	Spare Part	5945	15%
3996	5H.070.130.0.SP	4R1190NA BSIV EGT STRAP ASSEMBLY SPARE PART	Spare Part	7166	15%
3997	5H.070.20.0.PR	ASSEMBLY OF EMISSION AFTER TREATMENT FOR 110 HP BS IV DOC DCOM TUBE SCR VARIA	Spare Part	121155	15%
3998	5H.070.200.0.PR	DOC TOP MOUNTED	Spare Part	86107	15%
3999	5H.070.210.0.PR	SCR TOP MOUNTED DOWNWARD OPENING	Spare Part	96823	15%
4000	5H.071.01.0.PR	POLY V BELT 6PK 1215 EPDM	Spare Part	2086	15%
4001	5H.071.02.0.PR	POLY V BELT 6PK 1270 EPDM	Spare Part	2154	15%
4002	5H.085.04.0.PR	PFM SENSOR AIR MASS FLOW SENSOR B SAMPLE VARIANT	Spare Part	26560	15%
4003	5H.085.06.0.PR	DOSING MODULE FOR 4R1190 BS4	Spare Part	21070	15%
4004	5H.085.07.0.PR	Adblue Inlet Line Filter	Spare Part	1676	20%
4005	5H.085.08.0.PR	NOX SENSOR	Spare Part	63578	15%
4006	5H.085.09.0.PR	SUPPLY MODULE FOR 4R1190 BS4	Spare Part	115672	15%
4007	5H.085.10.0.SP	SERVICE KIT; (DM 3.2) RE-ASSEMBLY KIT (CLAMP AND SEAL)	Spare Part	1018	15%
4008	5H.085.11.0.PR	NOX SENSOR SUITABLE FOR 24V SYSTEM	Spare Part	56962	15%
4009	5H.085.16.0.SP	UREA FILTER	Spare Part	3086	20%
4010	5H.085.21.0.SP	SUCTION CONNECTION PIECE	Spare Part	6871	15%
4011	5H.085.51.0.SP	FILTER SERVICE SET FOR 4R1190TA SM (FILTER ELEMENT, EQUALIZING ELEMENT AND DISASS	Spare Part	4461	20%
4012	5H.085.53.0.SP	INLET CONNECTOR SET FOR 4R1190TA SM (SUCTION CONNECTION PIECE WITH O - RING, FIXA	Spare Part	5538	20%
4013	5H.085.54.0.SP	OUTLET CONNECTOR SET FOR 4R1190TA SM (OUTLET CONNECTION PIECE WITH O - RING, FIX.	Spare Part	3230	20%
4014	5H.085.55.0.SP	BACKFLOW CONNECTOR SET 4R1190TA SM (BACKFLOW CONNECTOR PIECE WITH O RING, FIX	Spare Part	4355	20%
4015	5H.086.01.0.PR	RUBBER SLEEVE BETWEEN AIR CLEANER AND PRE CLEANER P758662	Spare Part	769	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
4016	5H.086.10.0.PR	AIR PRE CLEANER SUITABLE FOR 4R1190NA ENGINE PB H000858	Spare Part	3794	15%
4017	5H.087.01.0.PR	LIFTING HOOK G E SUITABLE FOR BRACKET MOUNTING	Spare Part	3652	15%
4018	5H.087.02.0.PR	LIFTING HOOK F W E LOW HEIGHT	Spare Part	4498	15%
4019	5H.089.01.0.PR	BRACKET AIR CLEANER ZIGZAG WELDING	Spare Part	4818	15%
4020	5H.089.02.0.PR	HOSE AIR SUCTION ID70xID90 ZIGZAG EPDM	Spare Part	3985	15%
4021	5H.089.03.0.PR	BRACKET AIR CLEANER ZIGZAG SINGLE Z SHAPE	Spare Part	711	15%
4022	5H.089.04.0.PR	HEAT SHIELD BETWEEN AIR CLEANER HOSE AND DOC	Spare Part	3021	15%
4023	5H.092.01.0.PR	FLYWHEEL HOUSING SAE 3 W 144 5 SS BB	Spare Part	33243	15%
4024	5H.093.20.0.PR	FLYWHEEL ASSEMBLY	Spare Part	33356	15%
4025	5H.095.03.0.PR	HOSE AIR SUCTION ID89XID89 BEND EPDM	Spare Part	2769	15%
4026	5H.096.01.0.PR	BRACKET ALTERNATOR ZIGZAG SINGLE casting	Spare Part	1114	15%
4027	5H.097.01.0.PR	BRACKET LUB OIL FILTER ZIGZAG SINGLE	Spare Part	2102	15%
4028	5H.099.20.0.PR	FLYWHEEL ASSEMBLY	Spare Part	21572	15%
4029	5H.102.10.0.PR	THERMOSTAT ASSEMBLY LOW MOUNTED INTAKE MANIFOLD SIDE OPEN	Spare Part	8237	15%
4030	5H.105.10.0.PR	THERMOSTAT HOUSING ASSEMBLY OPENING TOWARD EXHAUST AND SMALL HEIGHT	Spare Part	7809	15%
4031	5H.106.01.0.PR	SPACER FOR FAN STUD MOUNTING ID9 OD14 L70	Spare Part	105	15%
4032	5H.108.02.0.PR	FUEL PIPE PA12 M14 BANJO FUEL PUMP TO FUEL FILTER	Spare Part	578	15%
4033	5H.109.02.0.00	ELEMENT ASSEMBLY SAFETY (P691151)	Spare Part	2054	20%
4034	5H.109.03.0.00	ELEMENT ASSEMBLY PRIMARY (P691152)	Spare Part	3230	20%
4035	5H.109.10.0.PR	AIR CLEANER ASSEMBLY 350 KG HR 90 DEG BEND OUTLET SPOUT	Spare Part	11544	15%
4036	5H.112.01.0.PR	PIPE TURBO COMPRESSOR OUT TO CAC	Spare Part	10612	15%
4037	5H.112.02.0.PR	O RING ID 48 X DIA 3	Spare Part	98	15%
4038	5H.112.03.0.PR	V BAND CLAMP NOM DIA 65	Spare Part	917	15%
4039	5H.112.04.0.PR	BRACKET FOR TURBO COMPRESSOR OUT PIPE BEND SINGLE	Spare Part	1628	15%
4040	5H.112.06.0.PR	CCV PIPE OD 63 5 AT TURBOCHARGER SUCTION STRAIGHT METALLIC	Spare Part	1425	15%
4041	5H.112.07.0.PR	HOSE TURBO AIR SUCTION ID 60 63 5 STRAIGHT EPDM	Spare Part	471	15%
4042	5H.112.08.0.PR	U CLAMP FOR CAC PIPE SUPPORT PIPE O D 75	Spare Part	234	15%
4043	5H.112.09.0.PR	CLAMPING PLATE FOR U CLAMP ZIGZAG SINGLE	Spare Part	505	15%
4044	5H.112.10.0.PR	PLUG CAP 1 8 27 NPTF FOR AIR CLEANER RESTRICTION INDICATOR	Spare Part	800	15%
4045	5H.113.01.0.PR	BRACKET ALTERNATOR ZIGZAG SINGLE Casting	Spare Part	1212	15%
4046	5H.115.01.0.PR	PIPE CAC IN AIR PRESURE ID 65 OD 75 ZIGZAG CASTING AL	Spare Part	2142	15%
4047	5H.115.02.0.PR	PIPE CAC OUT AIR PRESURE OD 70 ZIGZAG CASTING AL	Spare Part	1588	15%
4048	5H.117.02.0.PR	BRACKET EXHAUST PIPE ZIGZAG SINGLE	Spare Part	480	15%
4049	5H.117.03.0.PR	GASKET EXHAUST GAS CRS 85X4 DIAMETER 9 ID 89 SS	Spare Part	255	15%
4050	5H.121.10.0.PR	AIR CLEANER ASSEMBLY 350 KG HR 90 DEG BEND OUTLET SPOUT	Spare Part	11544	15%
4051	5H.122.01.0.PR	BRACKET AIR CLEANER ZIGZAG WELDING	Spare Part	2572	15%
4052	5H.122.02.0.PR	HOSE AIR SUCTION ID70XID89 ZIGZAG EPDM	Spare Part	1785	15%
4053	5H.122.03.0.PR	HOSE AIR SUCTION ID70XID70 ZIGZAG EPDM	Spare Part	1649	15%
4054	5H.122.04.0.PR	PIPE AIR SUCTION OD70 METALLIC STRAIGHT WELDING	Spare Part	794	15%
4055	5H.123.01.0.PR	PIPE AIR SUCTION ID15XOD18 ZIGZAG METALLIC RUBBER	Spare Part	2052	15%
4056	5H.123.02.0.PR	BRACKET COMPRESSOR AIR PIPE FLAT SINGLE	Spare Part	231	15%
4057	5H.124.10.0.PR	AIR CLEANER ASSEMBLY 350 KG HR 90 DEG BEND OUTLET SPOUT G080747	Spare Part	9861	15%
4058	5H.125.201.0.PR	BRACKET FOR ECU WIRING HARNESS INTERFACE CONNECTOR SUPPORT	Spare Part	1831	15%
4059	5H.127.02.0.PR	HOSE AIR SUCTION ID70XID89 ZIGZAG EPDM	Spare Part	3905	15%
4060	5H.128.01.0.PR	HEAT SHIELD INBETWEEN ALTERNATOR AND EXHAUST MANIFOLD	Spare Part	1006	15%
4061	5H.133.10.0.PR	AIR CLEANER ASSEMBLY 350 KGHR 90 DEG BEND OUTLET I 0 O 41 FP G080754	Spare Part	11544	15%
4062	5H.1415.02.0.PR	HOSE FOR REMOTE LUB OIL FILTER PRESSURE ID 16 M22 BOTH SIDE BEND RUBBER AND MI	Spare Part	3049	15%
4063	5H.1415.03.0.PR	HOSE FOR REMOTE LUB OIL FILTER PRESSURE ID 16 M22 ONE SIDE BEND RUBBER AND MET	Spare Part	2246	15%
4064	5H.1415.04.0.PR	HOSE FOR REMOTE LUB OIL FILTER PRESSURE ID 16 M22 BOTH SIDE BEND RUBBER AND ME	Spare Part	2369	15%
4065	5H.302.01.0.PR	AUTOLEK 12V 3 6KW STARTER MOTOR WITH GEAR REDUCTION MODEL NO STM 27B04	Spare Part	30572	15%
4066	5H.302.02.0.PR	12V STARTER MOTOR S F 4R1190 BSIV ENGINE	Spare Part	100380	15%
4067	5H.488.01.0.PR	AIR CLEANER HOSE TO TURBO	Spare Part	4508	15%
4068	5H.488.04.0.PR	ADAPTOR M16 X 1.5 TO M14 X 1.5	Spare Part	218	15%
4069	5H.488.28.0.PR	COOLENT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1	Spare Part	5415	15%
.500	1	COOLENT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2	Spare Part	5763	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
0101			eurego.,	without Vat in	Charge%
4071	5H.488.31.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2	Spare Part	NPR 3948	15%
4072	5H.488.32.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1	Spare Part	4040	15%
4073	5H.488.34.0.PR	ADBLUE PIPE FOR ADD BLUE TANK OUT TO SUPPLY MODULE IN	Spare Part	3658	15%
4074	5H.488.36.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADD BLUE TANK IN	Spare Part	2932	15%
4075	5H.488.37.0.PR	COOLENT PIPE FOR CRANKCASE OUT TO DOSING MODEL IN 1	Spare Part	2372	15%
4076	5H.488.38.0.PR	COOLENT PIPE FOR CRANKCASE OUT TO DOSING MODEL IN 2	Spare Part	2886	15%
4077	5H.488.39.0.PR	COOLENT PIPE FOR CRANKCASE OUT TO DOSING MODEL IN 3	Spare Part	4218	15%
4078	5H.488.41.0.PR	COOLENT PIPE FOR CRANKCASE OUT TO DOSING MODEL IN 4	Spare Part	3843	15%
4079	5H.488.43.0.PR	FUEL PIPE FROM PRE FILTER OUT TO FUEL FILTER IN	Spare Part	1412	15%
4080	5H.488.44.0.PR	FUEL PIPE PRE FILTER TO TANK UNIT	Spare Part	2271	15%
4081	5H.488.49.0.PR	RETURN FUEL PIPE	Spare Part	1449	15%
4081	5H.501.50.0.00	VCI COMPLETE ASSEMBLY(VCI Dongle with 9pin connector harness with OTG Cable set), TESTER TO	Spare Part	66747	15%
4083	5H.501.60.0.00	VCI COMPLETE ASSEMBLE (VCI DOINGLE WILLI SPIN CONTROLL MILLION CADILE SEL), TESTER TO VCI DONGLE ONLY FOR TESTER TOOL UDS PROTOCOL AUTOPEEPAL		63713	15%
4083	5H.501.70.0.00	VCI HARNESS ONLY FOR TESTER TOOL UDS PROTOCOL AUTOPEEPAL	Spare Part	6071	15%
			Spare Part		
4085	5H.501.80.0.00	VCI OTG CABLE SET ONLY TESTER TOOL UDS PROTOCOL AUTOPEEPAL	Spare Part	2126 2951	15% 15%
4086	5H.501.90.0.SP	INDUSTRIAL PIGTAIL HARNESS	Spare Part		
4087	5H.800.13.0.PR	HIGH TEMPERATURE SENSOR DARTS200 AW ID25 MI54 SENSATA	Spare Part	10557	15%
4088	5H.999.01.0.SP	CONNECTING ROD END BEARING 4R1190	Spare Part	2874	15%
4089	5H.999.02.0.SP	BSIV COLD START KIT TILL 0 DEGREE	Spare Part	38929	15%
4090	5H.999.05.0.SP	BS IV DIAGNOSTIC KIT	Spare Part	196647	15%
4091	5H.999.06.0.SP	BSIV 4R1190 COLD START KIT FOR TOP MOUNTED EGT	Spare Part	149989	15%
4092	5H.999.07.0.SP	BSIV 1190 COLD START KIT FOR SIDE MOUNTED EGT	Spare Part	159733	15%
4093	5H.999.08.0.SP	BSIV 1190 COLD START KIT FOR SIDE MOUNTED NISARG	Spare Part	159733	15%
4094	5H.999.10.0.SP	OIL SEPARATOR BSIV	Spare Part	8351	15%
4095	5H.999.13.0.SP	DYNAPAC CLOSED CRANKCASE VENTILATION KIT	Spare Part	16747	15%
4096	5H.999.22.0.SP	BS IV 74 5 HP NA HT ENGINES CONSUMABLES FILTER KIT FOR 50 HRS 500 HRS AND 1500 HRS	Spare Part	7752	20%
4097	5H.999.23.0.SP	BS IV 74 5 HP NA ENGINES CONSUMABLES FILTER KIT FOR 1000 HRS	Spare Part	12232	20%
4098	5H.999.24.0.SP	BS IV 74 5 HP HT ENGINES CONSUMABLES FILTER KIT FOR 1000 HRS	Spare Part	12677	20%
4099	5H.999.25.0.SP	BS IV 110 HP ENGINES CONSUMABLES FILTER KIT FOR 500 HRS AND 1500 HRS	Spare Part	18689	20%
4100	5H.999.26.0.SP	BS IV 110 HP ENGINES CONSUMABLES FILTER KIT FOR 1000 HRS	Spare Part	26210	20%
4101	5H.999.27.0.SP	BREATHER ASSEMBLY KIT	Spare Part	9658	15%
4102	5H.999.28.0.SP	MODIFIED UREA TANK STRAINER	Spare Part	2142	15%
4103	5H.E110.110.0.PR	ENGINE WIRING HARNESS FOR BSV 4R1190 ENGINES FOR 110 HP TA1 (TOP MOUNTED),	Spare Part	40510	15%
4104	5H.X074.120.0.PR	EGT WIRING HARNESS FOR BSV 4R1190 ENGINE OF 74.5 HP TA-H.T (FWH MOUNTED)	Spare Part	62279	15%
4105	60.007.03.0.00	NUT	Spare Part	37	15%
4106	60.053.01.0.00	V BELT : A43	Spare Part	520	15%
4107	60.060.01.0.00	V BELT: A44	Spare Part	529	15%
4108	60.139.01.0.00	V BELT A-45	Spare Part	449	15%
4109	61.143.08.0.00	GOVERNER SPRING	Spare Part	86	15%
4110	65.073.01.0.00	STRAINER	Spare Part	157	20%
	6H.001.100.0.PR	MONOBLOCK CRANK CASE WITHOUT BEARINGS	Spare Part	239212	15%
4112	6H.001.17.0.00	PISTON COOLING NOZZLE ASSLY	Spare Part	240	15%
4113	6H.001.21.0.00	ADAPTER FOR LUBE OIL TEMP SWITCH	Spare Part	95	15%
4114	6H.002.20.0.00	CRANKSHAFT ASSLY WITH BAL WT	Spare Part	134343	15%
4115	6H.002.40.0.00	CRANKSHAFT ASSLY WITH BAL WT	Spare Part	132943	15%
4116	6H.003.10.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	40676	15%
4117	6H.004.10.0.00	LUBE OIL PUMP ASSLY	Spare Part	12317	15%
4118	6H.006.20.0.00	SUCTION TUBE	Spare Part	720	15%
4119	6H.007.06.0.00	CYL HEAD GASKET 1.22 MM THK	Spare Part	5514	15%
4120	6H.007.10.0.00	CYLINDER HEAD ASSLY	Spare Part	140287	15%
4121	6H.009.70.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	6674	15%
4122	6H.011.01.0.00	EXHAUST MANIFOLD (FINISH)	Spare Part	3683	15%
4123	6H.011.04.0.00	EXHAUST MANIFOLD (SIDE PIECE)	Spare Part	6621	15%
4124	6H.011.05.0.00	EXHAUST MANIFOLD (CENTRAL PIECE)	Spare Part	5249	15%
4125	6H.011.06.0.00	SPACER PLATE (FOR TURBO CHARGER)	Spare Part	917	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
4126	6H.012.03.0.00	ASSEMBLY OF ADAPTOR & PIPE	Spare Part	NPR 255	15%
4127	6H.012.10.0.00	ROCKER SHAFT ASSEMBLY	Spare Part	15151	15%
4128	6H.012.140.0.00	ROCKER SHAFT ASSEMBLY	Spare Part	18049	15%
4129	6H.012.50.0.00	ROCKER SHAFT ASSEMBLY	Spare Part	19529	15%
4130	6H.013.15.0.00	ROCKER COVER GASKET	Spare Part	2015	15%
4131	6H.013.40.0.00	ROCKER COVER	Spare Part	15086	15%
4132	6H.014.03.0.00	HEADER(FOR LOCOOLER & SPIN ON FILTER)	Spare Part	11720	15%
4133	6H.014.11.0.00	JOINT: HEADER	Spare Part	302	15%
4134	6H.014.20.0.00	HEADER & COOLER ASSLY	Spare Part	43310	15%
4135	6H.018.02.0.00	CRANKSHAFT PULLEY	Spare Part	3621	15%
4136	6H.018.03.0.00	EXTENSION PULLEY (140 PCD)	Spare Part	2686	15%
4137	6H.019.01.0.00	PLATE FOR STAY	Spare Part	625	15%
4138	6H.019.06.0.00	RUBBER BUSH	Spare Part	86	15%
4139	6H.019.07.0.00	STEEL BUSH	Spare Part	28	15%
4140	6H.019.08.0.00	SPECIAL WASHER	Spare Part	34	15%
4141	6H.019.09.0.00	STAY FOR RADIATOR	Spare Part	677	15%
4142	6H.019.12.0.00	HOSE: WATER PIPE	Spare Part	1154	15%
4143	6H.019.15.0.00	STAY FOR RADIATOR	Spare Part	689	15%
4144	6H.020.04.0.00	JOINT: CRANKCASE & GEAR CASING	Spare Part	520	15%
4145	6H.020.11.0.00	JOINT: CRANKCASE & GEAR COVER	Spare Part	345	15%
4146	6H.021.01.0.00	ADAPTOR FOR CENTRIFUGAL LUBE OIL FILTER	Spare Part	1705	15%
4147	6H.021.10.0.00	CENTRIFUGE FILTER & ADAPTER ASSLY	Spare Part	14117	15%
4148	6H.021.11.0.00	JOINT -CENTRIFUGAL FILTER ADOPTER	Spare Part	34	15%
4149	6H.021.40.0.00	CENTRIFUGE FILTER AND ADAPTOR ASSEMBLY	Spare Part	13108	15%
4150	6H.023.10.0.00	LEAK OFF PIPE SUB ASSLY	Spare Part	2105	15%
4151	6H.024.03.0.00	BREATHER PIPE	Spare Part	917	15%
4152	6H.024.04.0.00	CLIP FOR BREATHER PIPE	Spare Part	77	15%
4153	6H.024.05.0.00	HOSE: BREATHER PIPE 32 ID	Spare Part	785	15%
4154	6H.024.06.0.00	BREATHER EXTENSION PIPE	Spare Part	1182	15%
4155	6H.024.10.0.PR	ADAPTOR FOR BREATHER PIPE	Spare Part	1643	15%
4156	6H.024.11.0.00	JOINT: ADAPTOR FOR BREATHER	Spare Part	34	15%
4157	6H.026.01.0.00	HOUSING: EXH OUTLET	Spare Part	1157	15%
4158	6H.026.02.0.00	SS JOINT: TURBO OUTLET	Spare Part	111	15%
4159	6H.027.01.0.00	BRACKET FOR GAS OUTLET MANIFOLD	Spare Part	2191	15%
4160	6H.027.02.0.00	GAS OUTLET MANIFOLD	Spare Part	5763	15%
4161	6H.027.03.0.00	COPPER COATED BOLT(M10X025)	Spare Part	111	15%
4162	6H.027.06.0.00	GAS OUTLET MANIFOLD 6K1080 4V CPCB II	Spare Part	4268	15%
4163	6H.028.01.0.00	BRACKET FOR AIR CLEANER	Spare Part	5212	15%
4164	6H.028.02.0.00	AIR PIPE: AIR FILTER-TURBO IN	Spare Part	2609	15%
4165	6H.028.03.0.00	BRACKET FOR AIR PIPE	Spare Part	578	15%
4166	6H.029.01.0.00	JOINT SS: TURBOCHARGER	Spare Part	74	15%
4167	6H.029.06.0.00	TURBOCHARGER	Spare Part	93233	15%
4168	6H.029.10.0.00	TURBOCHARGER	Spare Part	67061	15%
4169	6H.030.03.0.00	CLAMP FOR CAC PIPE	Spare Part	129	15%
4170	6H.030.05.0.00	JOINT: AIR PIPE	Spare Part	52	15%
4171	6H.030.07.0.00	AIR PIPE(CAC TO INLET)	Spare Part	7941	15%
4172	6H.030.08.0.00	AIR PIPE: TURBO TO CAC T/C SIDE	Spare Part	3071	15%
4173	6H.030.09.0.00	AIR PIPE: TURBO TO CAC	Spare Part	6375	15%
4174	6H.030.11.0.00	BRACKET FOR AIR PIPE	Spare Part	643	15%
4175	6H.031.01.0.00	BRACKET	Spare Part	2283	15%
4176	6H.031.03.0.00	PULLEY: FAN 140 PCD B SEC	Spare Part	5455	15%
4177	6H.031.06.0.00	WASHER (FAN DRIVE PULLEY)	Spare Part	95	15%
4178	6H.031.10.0.00	BEARING HOUSING SUB ASSLY	Spare Part	7498	15%
4179	6H.032.01.0.00	FUEL PIPE: FEED PUMP TO FILTER	Spare Part	843	15%
4180	6H.032.02.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	720	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
				without Vat in NPR	Charge%
4181	6H.033.01.0.00	ENGINE MOUNTING FOOT (GE)	Spare Part	6926	15%
4182	6H.033.02.0.00	ENGINE MOUNTING FOOT (FWE)	Spare Part	6415	15%
4183	6H.033.13.0.00	ENGINE MOUNTING FOOT (GEAR END SIDE)	Spare Part	4806	15%
4184	6H.034.03.0.00	ADAPTOR FOR OIL PIPE	Spare Part	163	15%
4185	6H.034.04.0.00	LUBE OIL INLET PIPE: K20 TURBO	Spare Part	542	15%
4186	6H.034.05.0.00	LUBE OIL DRAIN PIPE: K26 TURBO	Spare Part	1320	15%
4187	6H.034.11.0.00	LUBE OIL DRAIN PIPE: K26 TURBO	Spare Part	646	15%
4188	6H.034.12.0.00	LUBE OIL INLET PIPE: K26 TURBO	Spare Part	895	15%
4189	6H.034.13.0.PR	LUB OIL INLET PIPE FOR TURBOCHARGER	Spare Part	775	15%
4190	6H.034.14.0.PR	LUB OIL DRAIN PIPE FOR TURBOCHARGER	Spare Part	843	15%
4191	6H.036.03.0.00	PIPE: THERMOSTAT TO RADIATOR	Spare Part	1049	15%
4192	6H.036.04.0.00	PIPE: RADIATOR TO PUMP INLET	Spare Part	1683	15%
4193	6H.036.11.0.00	PIPE (RADIATOR TO PUMP INLET)	Spare Part	902	15%
4194	6H.036.13.0.00	HOSE: RADIATOR OUTLET TO WATER PUMP INLET	Spare Part	1123	15%
4195	6H.045.01.0.00	OIL SEAL HOUSING	Spare Part	1557	15%
4196	6H.045.11.0.00	JOINT: OIL SEAL HSG	Spare Part	157	15%
4197	6H.047.150.0.00	LUBE OIL PUMP ASSEMBLY	Spare Part	9366	15%
4198	6H.047.30.0.00	LUBE OIL PUMP ASSLY	Spare Part	12181	15%
4199	6H.050.02.0.00	DAMPER FOR APPLICATIONS AT 1800 RPM ABOVE	Spare Part	10464	15%
4200	6H.050.03.0.00	EXTENSION PULLEY (140 PCD)	Spare Part	3283	15%
4201	6H.056.02.0.00	HOSE: WATER PIPE	Spare Part	677	15%
4202	6H.056.03.0.00	VENT PIPE FOR RADIATOR	Spare Part	763	15%
4203	6H.057.01.0.00	PIPE THERMOSTAT TO RADIATOR	Spare Part	892	15%
4204	6H.057.02.0.00	PIPE (RADIATOR TO PUMP INLET)	Spare Part	1582	15%
4205	6H.058.01.0.00	AIR PIPE (TURBOCHARGER TO INLET)	Spare Part	6923	15%
4206	6H.058.02.0.00	JOINT: AIR PIPE	Spare Part	114	15%
4207	6H.058.16.0.PR	JOINT 95 EGT OUTLET	Spare Part	351	15%
4208	6H.058.17.0.PR	JOINT 95 EGT INLET	Spare Part	329	15%
4209	6H.061.10.0.00	SET OF COPPER WASHER - 6R1080 TA	Spare Part	754	15%
4210	6H.061.20.0.SP	SET OF JOINTS - 6R1080TA	Spare Part	7354	15%
4211	6H.061.30.0.00	SET OF O-RINGS: 6R1080TA 125 KVA	Spare Part	342	15%
4212	6H.062.03.0.00	HOSE: WATERPUMP INLET TO HEAT EXCHANGER	Spare Part	760	15%
4213	6H.063.180.0.00	HIGH PRESSURE PIPE ASSEMBLY (INTEGRAL SLEEVE 6.35.DIA)	Spare Part	10366	15%
4214	6H.063.80.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	9769	15%
4215	6H.065.01.0.00	FLYWHEEL HOUSING	Spare Part	26169	15%
4216	6H.068.10.0.00	FLYWHEEL ASSEMBLY	Spare Part	44095	15%
4217	6H.073.01.0.00	FUEL PUMP VS	Spare Part	71787	15%
4218	6H.077.01.0.00	STARTER 24V	Spare Part	33956	15%
4219	6H.080.01.0.00	ADAPTER FOR EXHAUST SILENCER	Spare Part	1243	15%
4220	6H.081.02.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	1354	15%
4221	6H.081.03.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	1714	15%
4222	6H.081.15.0.00	ADAPTOR ON FUEL FILTER FOR FUEL PIPES	Spare Part	151	15%
4223	6H.084.01.0.00	CRANK PULLEY SPA,TWO GROOVE,172 PCD	Spare Part	5298	15%
4224	6H.086.10.0.PR	WOODWARD TRIM DOWN PG PLUS SYSTEM FOR 6 CYLINDER NATURAL GAS GENSET	Spare Part	633136	15%
4225	6H.086.45.0.PR	GAS TRAIN ASSEMBLY	Spare Part	161099	15%
4226	6H.097.01.0.00	ADAPTOR FOR L.O.P.SWITCH (M14X1.5 -0.125"-27 NPTF)	Spare Part	154	15%
4227	6H.100.10.0.00	FUEL INJECTION PUMP FOR 6K1080 TA 160 KVA MICO No F002 A0Z 847	Spare Part	177530	15%
4228	6H.1001.10.0.00	CAMSHAFT & GEAR ASSLY	Spare Part	43750	15%
4229	6H.1003.01.0.00	ACTUATOR	Spare Part	25744	15%
4230	6H.1003.02.0.00	ECU: ELECTRONIC GOVERNOR B1	Spare Part	15067	15%
4231	6H.1003.04.0.00	ENGINE CONTROL UNIT	Spare Part	15877	15%
4232	6H.1003.05.0.00	VOLTAGE SUPPRESSOR FOR B12 ECU	Spare Part	1735	15%
4233	6H.1006.60.0.00	CONTROL PANEL ASSEMBLY FOR 6K ELECTRONIC GOVERNER WITH KG 645 CONTROL PANEL E	Spare Part	34427	15%
4234	6H.1008.30.0.00	ENGINE WIRING HARNESS ASSEMBLY WITH KG 545	Spare Part	15126	15%
4235	6H.1008.80.0.00	ENGINE WIRING HARNESS 6R 125KVA	Spare Part	14861	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
4236	6H.1009.80.0.00	ENGINE WIRING HARNESS ASSEMBLY WITH KG 545	Spare Part	8225	15%
4237	6H.1011.40.0.PR	ENGINE WIRING HARNESS S F KG645 UNIT 6R GAS ENGINE	Spare Part	14744	15%
4238	6H.1011.50.0.PR	ENGINE WIRING HARNESS FOR 6K EMERALD	Spare Part	13649	15%
4239	6H.1011.80.0.PR	ENGINE WIRING HARNESS FOR 6R 62 5 KVA PNG GENSET	Spare Part	93660	15%
4240	6H.1013.01.0.00	GEAR CASING FOR 6K1080	Spare Part	21578	15%
4241	6H.1014.30.0.PR	ENGINE WIRING HARNESS SF 6R 125KVA	Spare Part	12898	15%
4242	6H.1019.07.9.00	VALVE SEAT INSERT: INLET	Spare Part	431	15%
4243	6H.1019.08.9.00	VALVE SEAT INSERT: EXHAUST	Spare Part	415	15%
4244	6H.1019.50.0.00	CYLINDER HEAD ASSEMBLY 6K ENGINE	Spare Part	138032	15%
4245	6H.1019.60.0.00	VALVE PAIR	Spare Part	1462	15%
4246	6H.1029.02.0.00	MECHANICAL FUEL LEVEL INDICATOR	Spare Part	2403	15%
4247	6H.1043.20.0.PR	ENGINE WIRING HARNESS FOR 6K 200KVA CPCB4 ENGINE	Spare Part	59021	15%
4248	6H.1043.60.0.PR	WIRING HARNESS ASSEMBLY FOR FUEL PUMP ADDED 4K & 6K GENSET	Spare Part	3800	15%
4249	6H.1061.05.0.00	LUB OIL SUMP FOR CAT	Spare Part	21550	15%
4250	6H.1061.10.0.00	DIPSTICK ASSEMBLY	Spare Part	151	15%
4251	6H.1062.07.0.00	JOINT: SUCTION TUBE	Spare Part	49	15%
4252	6H.1062.09.0.00	CLAM FOR SUCTION PIPE	Spare Part	86	15%
4253	6H.1062.11.0.00	CLAMP SUPPORT	Spare Part	43	15%
4254	6H.1062.50.0.00	SUB ASSEMBLY OF SUCTION TUBE	Spare Part	818	15%
4255	6H.1063.01.0.00	DELIVERY BODY	Spare Part	892	15%
4256	6H.1063.02.0.00	DELIVERY TUBE	Spare Part	582	15%
4257	6H.1063.04.0.00	O RING: DELIVERY TUBE	Spare Part	77	15%
4258	6H.1063.05.0.00	JOINT: DELIVERY BODY	Spare Part	55	15%
4259	6H.1063.06.0.PR	DELIVERY TUBE WITH ADAPTORS ASSEMBLY	Spare Part	2735	15%
4260	6H.1063.10.0.00	DELIVERY TUBE WITH FLANGE	Spare Part	972	15%
4261	6H.1064.70.0.00	LUBE OIL PUMP ASSLY	Spare Part	30230	15%
4262	6H.1065.10.0.00	LUBE OIL PUMP INT GEAR & BUSH ASSEMBLY	Spare Part	2369	15%
4263	6H.1066.60.0.00	PISTON COOLING NOZZLE ASSLY	Spare Part	338	15%
4264	6H.1081.03.0.PR	JOINT FOR HEADER	Spare Part	311	15%
4265	6H.1081.05.0.00	HEADER FOR LUB OIL COOLER SPIN ON FILTER MACHINING	Spare Part	17726	15%
4266	6H.1081.06.0.PR	COVER PLATE FOR COOLER HEADER	Spare Part	1206	15%
4267	6H.1081.07.0.PR	HEADER (FOR COMMON RAIL)	Spare Part	18166	15%
4268	6H.1081.08.0.PR	HEADER FOR LUB OIL COOLER AND FILTER (S/F JACKET WATER HEATER)	Spare Part	14751	15%
4269	6H.1081.40.0.PR	HEADER AND COOLER ASSEMBLY COMMON RAIL	Spare Part	53396	15%
4270	6H.1081.60.0.PR	HEADER AND COOLER ASSEMBLY COMMON RAIL	Spare Part	53842	15%
4271	6H.1081.70.0.PR	LUBE OIL COOLER ASSEMBLY COMMON RAIL	Spare Part	44206	15%
4272	6H.1087.01.0.PR	DELIVERY TUBE	Spare Part	1855	15%
4273	6H.1087.02.0.PR	CLAMP STRIP FOR DELIVERY TUBE	Spare Part	135	15%
4274	6H.1090.02.0.00	GASKET CYLINDER HEAD & CRANKCASE	Spare Part	8431	15%
4275	6H.1090.50.0.PR	CYL HEAD WITH VALVE GUIDE VALVE SEAT INSERT 4V COMMON RAIL	Spare Part	103645	15%
4276	6H.1091.50.0.00	VALVE ROCKER ASSEMBLY	Spare Part	37556	15%
4277	6H.1092.06.0.00	ROCKER BOX	Spare Part	19258	15%
4278	6H.1093.01.0.00	ROCKER COVER (FINISH)	Spare Part	20154	15%
4279	6H.1093.12.0.00	O RING (FOR ROCKER COVER)	Spare Part	809	15%
4280	6H.1094.02.0.00	JOINT FOR AIR INLET MANIFOLD - 6R1080 - 4VALVES	Spare Part	415	15%
4281	6H.1094.03.0.00	AIR INLET MANIFOLD	Spare Part	17969	15%
4282	6H.1094.05.0.00	INLET MANIFOLD FINISH	Spare Part	18384	15%
4283	6H.1097.08.0.PR	FUEL PIPE FEED PUMP TO FUEL FILTER ID 12 X OD 15	Spare Part	1465	15%
4284	6H.1097.09.0.PR	FUEL PIPE FUEL FILTER TO FIP ID 12 X OD 15	Spare Part	1440	15%
4285	6H.1097.10.0.00	LEAK OFF PIPE ASSEMBLY	Spare Part	1418	15%
4286	6H.1097.120.0.00	LEAK OFF PIPE	Spare Part	1538	15%
4287	6H.1098.50.0.PR	CRANKCASE MONOBLOCK WITHOUT BEARINGS 6R1080 4 VALVE	Spare Part	234741	15%
4288	6H.1099.20.0.PR	CAMSHAFT ASSEMBLY	Spare Part	44636	15%
4289	6H.1099.55.0.PR	CAMSHAFT ASSEMBLY	Spare Part	35212	15%
4290	6H.1100.03.0.PR	HUB FOR MOTORPAL FIP	Spare Part	10166	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
4291	6H.1100.05.0.PR	OIL DRAIN PIPE FIP TO SUMP	Spare Part	5566	15%
4292	6H.1100.09.0.PR	LUB OIL SUMP SHALLOW	Spare Part	15963	15%
4293	6H.1100.11.0.PR	FUEL PIPE FUEL FILTER TO FIP	Spare Part	1286	15%
4294	6H.1100.12.0.PR	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	1369	15%
4295	6H.1100.13.0.PR	LEAK OFF PIPE INJECTOR TO TANK	Spare Part	1702	15%
4296	6H.1100.14.0.PR	LEAK OFF PIPE FUEL FILTER TO TANK	Spare Part	1286	15%
4297	6H.1104.110.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	13572	15%
4298	6H.1124.20.0.00	LEAK OFF PIPE ASSEMBLY	Spare Part	2415	15%
4299	6H.1124.30.0.00	LEAKOFF ASSLY	Spare Part	6668	15%
4300	6H.1124.50.0.00	COMB LEAKOFF PIPE ASSLY	Spare Part	1766	15%
4301	6H.1126.02.0.00	EXHAUST BEND	Spare Part	9218	15%
4302	6H.1126.03.0.00	EXHAUST SILENCER(5", INDUSTRIAL TYPE) FOR 6R1080TA ENGINES FOR FIRE FIGHTING APPLIC	Spare Part	23578	15%
4303	6H.1128.01.0.00	AIR CLEANER F.F. ENGINES	Filter	8413	20%
4304	6H.1128.02.0.00	HOSE: AIR CLEANER	Spare Part	3228	15%
4305	6H.1128.11.0.00	AIR CLEANER ASSEMBLY S F FIRE FIGHTING	Spare Part	8185	15%
4306	6H.113.01.0.00	HEADER FOR LUB OIL COOLER AND FILTER (S/F JACKET WATER HEATER)	Spare Part	9372	15%
4307	6H.113.20.0.00	HEADER & COOLER ASSEMBLY	Spare Part	43359	15%
4308	6H.1130.01.0.00	CRANK PULLEY WITH POLY V GROVES	Spare Part	6726	15%
4309	6H.1130.02.0.00	FAN DRIVE PULLEY (POLY V SECTION ,140 PCD)	Spare Part	3428	15%
4310	6H.1130.05.0.00	CRANK PULLEY: POLY V GROOVE	Spare Part	6452	15%
4311	6H.1130.08.0.00	CRANK PULLEY PCD 140, PCD 143	Spare Part	6120	15%
4312	6H.1130.09.0.00	FAN PULLEY (PCD 130) POLY `V', 7 PK	Spare Part	5194	15%
4313	6H.1130.11.0.00	CRANK PULLEY 150 PCD,POLY V,6PK	Spare Part	7572	15%
4314	6H.1130.14.0.00	FAN DRIVE PULLEY (140 PCD POLY-V 7PK)	Spare Part	3975	15%
4315	6H.1135.01.0.00	Turbocharger for 6R1080TA SPP Firefighting pump application(K27.2 3371 OLAKE 15.21)	Spare Part	71725	15%
4316	6H.1135.02.0.PR	GASKET FOR TURBO DRAIN PIPE	Spare Part	46	15%
4317	6H.1142.01.0.00	WATER COOLED CAC FOR 6R1080TA ENGINE(FIRE FIG	Spare Part	195179	15%
4318	6H.1143.02.0.00	STICKER(ENGINE COOLANT HEATER, 2000W)	Spare Part	102	15%
4319	6H.1145.01.0.00	BRACKET FOR HEAT EXCHANGER MTG	Spare Part	8929	15%
4320	6H.1145.03.0.00	HOSE (H.EXCHANGER TO W.PUMP)	Spare Part	2625	15%
4321	6H.1145.04.0.00	HOSE (THERMOSTAT TO HE)	Spare Part	960	15%
4322	6H.1145.05.0.00	HOSE(HEAT EXCHANGER TO W.PUMP)	Spare Part	2132	15%
4323	6H.1154.02.0.00	FUEL SUPPLY PIPE (FROM SUPPLY BLOCK TO FUEL PUMP)	Spare Part	286	15%
4324	6H.1154.40.0.00	LEAK OFF PIPE ASSEMBLY	Spare Part	3600	15%
4325	6H.1156.09.0.PR	BRACKET FOR COOLING LINE MTG G E	Spare Part	3668	15%
4326	6H.1156.11.0.PR	BRACKET FOR COOLING LINE MTG F W E	Spare Part	3938	15%
4327	6H.1156.50.0.00	COOLING LINE(1 1/4", 12V) ASSLY FOR KFP6R-UF25(6R1080TA) ENGINES S/F FLOW SWITCH	Spare Part	432573	15%
4328	6H.1160.01.0.00	SAFETY FILTER ELEMENT	Filter	2664	20%
4329	6H.1160.02.0.00	PRIMARY FILTER ELEMENT	Filter	6668	20%
4330	6H.1160.08.0.00	HOSE REDUCER (AIR CLEANER TO AIR PIPE)	Spare Part	4606	15%
4331	6H.1160.40.0.00	ASSEMBLY OF AIR CLEANER	Spare Part	27739	20%
4332	6H.1167.01.0.00	EXPANSION BELLOW	Spare Part	3898	15%
4333	6H.1167.02.0.00	DIFFUSER	Spare Part	2723	15%
4334	6H.1167.05.0.00	JOINT: DIFFUSER	Spare Part	132	15%
4335	6H.1167.06.0.00	BRACKET FOR DIFFUSER	Spare Part	1538	15%
4336	6H.1171.01.0.00	V BELT: 6R1080T/TA 7PK	Spare Part	2000	15%
4337	6H.1175.01.0.00	FUEL PIPE FEED PUMP OUTLET CONNECTION	Spare Part	218	15%
4338	6H.1175.02.0.00	FUEL PIPE FEED PUMP INLET CONNECTION	Spare Part	225	15%
4339	6H.118.01.0.00	ANTI VIBRATION MOUNTS	Spare Part	1815	15%
4340	6H.118.02.0.00	ANTI VIBRATION MOUNTS	Spare Part	2335	15%
4341	6H.1187.01.0.00	OIL SUPPLY PIPE	Spare Part	938	15%
4342	6H.1187.02.0.00	DRAIN PIPE	Spare Part	637	15%
4343	6H.1187.04.0.PR	TURBO OIL SUPPLY PIPE	Spare Part	1126	15%
4344	6H.1188.01.0.00	AIR PIPE	Spare Part	3403	15%
.0	6H.1189.01.0.00	LUBE OIL SUMP	Spare Part	19378	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
4346	6H.1190.01.0.00	EXHAUST MANIFOLD	Spare Part	6474	15%
4347	6H.1191.10.0.00	SUCTION TUBE (SUB. ASSLY.)	Spare Part	726	15%
4348	6H.1192.10.0.00	DIPSTICK ASSEMBLY	Spare Part	969	15%
4349	6H.1193.02.0.00	BYPASS FILTER	Spare Part	3387	20%
4350	6H.1193.02.0.PR	BYPASS FILTER	Spare Part	3711	20%
4351	6H.1193.04.0.PR	ADAPTOR FOR BYPASS FILTER	Spare Part	348	15%
4352	6H.1213.11.0.PR	KOEL GREEN Alternator KG 125 S T Frame KG 34 M 4 SAE 2 11 5 415V 50 Hz 0 8 PF	Spare Part	577740	15%
4353	6H.1249.01.0.00	FUEL PIPE FEED PUMP TO FILTER	Spare Part	991	15%
4354	6H.1249.02.0.00	FUEL PIPE FILTER TO FIP	Spare Part	858	15%
4355	6H.1250.03.0.00	BRACKET FOR LEAK OFF MTG	Spare Part	43	15%
4356	6H.1250.04.0.00	LEAK OFF PIPE	Spare Part	1151	15%
4357	6H.1250.05.0.00	LEAK OFF PIPE FOR FIP & INJECTOR	Spare Part	1206	15%
4358	6H.1251.03.0.00	OIL SUPPLY PIPE (HEADER TO FIP)	Spare Part	769	15%
4359	6H.1251.18.0.PR	OIL SUPPLY PIPE	Spare Part	902	15%
4360	6H.1258.80.0.PR	MONOBLOCK CRANK CASE SUB ASSLY 6R1080 4 VALVE	Spare Part	245443	15%
4361	6H.127.01.0.00	TURBOCHARGER	Spare Part	91202	15%
4362	6H.127.02.0.00	TURBOCHARGER FOR 6R1080TA 169 HP BS III ENGINE TR70 3067N 9 21	Spare Part	168930	15%
4363	6H.137.03.0.00	BRACKET FOR GAS OUTLET MANIFOLD	Spare Part	2957	15%
4364	6H.138.01.0.00	HOUSING (FOR EXHAUST OUTLET)	Spare Part	1203	15%
4365	6H.139.01.0.00	AIR PIPE (AIR CLEANER TO COMPRESSOR)	Spare Part	3508	15%
4366	6H.139.02.0.00	AIR PIPE TURBOCHARGER SIDE RADIATOR CAC 800 X 800	Spare Part	4683	15%
4367	6H.141.10.0.00	LUBE OIL INLET PIPE ASSLY:K27	Spare Part	1083	15%
4368	6H.141.20.0.00	LUB OIL DRAIN PIPE ASSEMBLY	Spare Part	705	15%
4369	6H.141.26.0.PR	LUB OIL INLET PIPE FOR S300 TURBOCHARGER	Spare Part	1123	15%
4370	6H.141.70.0.PR	LUB OIL INLET PIPE FOR TURBOCHARGER	Spare Part	1098	15%
4371	6H.141.80.0.PR	LUB OIL DRAIN PIPE FOR TURBOCHARGER	Spare Part	1418	15%
4372	6H.143.02.0.00	EXHAUST MANIFOLD (CENTRAL PIECE)	Spare Part	6941	15%
4373	6H.145.10.0.00	NOZZLE LEAK OFF PIPE (M12 U)	Spare Part	2314	15%
4374	6H.146.11.0.00	PIPE RADIATOR TO PUMP INLET	Spare Part	2640	15%
4375	6H.147.20.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	140401	15%
4376	6H.147.50.0.00	CYL HEAD ASSEMBLY P TYPE	Spare Part	133863	15%
4377	6H.147.60.0.00	CYL HEAD WITH VALVE GUIDE AND INSERTS S TYPE	Spare Part	133204	15%
4378	6H.147.70.0.PR	CYL HEAD ASSEMBLY P TYPE	Spare Part	134017	15%
4379	6H.155.10.0.00	INJECTOR	Spare Part	5200	15%
4380	6H.165.01.0.00	AIR DELIVERY PIPE FOR URAL 375D	Spare Part	7200	15%
4381	6H.1684.10.0.SP	COLD START KIT 6R (L3)	Spare Part	345032	15%
4382	6H.172.21.0.00	WATER CONNECTION HOSE PIPE HOTSTART TO RADIATOR -125 KVA	Spare Part	1763	15%
4383	6H.172.22.0.00	WATER CONNECTION HOSE PIPE HOTSTART TO ENGINE -125 KVA	Spare Part	1302	15%
4384	6H.172.28.0.00	HOSE: MAKE UP - 1000 CORE RADIATOR	Spare Part	2037	15%
4385	6H.179.13.0.PR	CON ROD BEARING UPPER	Spare Part	1406	15%
4386	6H.179.14.0.PR	CON ROD BEARING LOWER	Spare Part	366	15%
4387	6H.179.30.0.PR	CONNECTING ROD ASSLY WITH SMALL END BUSH	Spare Part	9498	15%
4388	6H.186.01.0.00	DAMPER	Spare Part	27547	15%
4389	6H.188.10.0.00	FUEL PUMP: 6R1080T V.S.	Spare Part	106389	15%
4390	6H.192.04.0.00	FUEL FILLING HOSE FOR 125 KVA TRAILER MOUNTED GENSET	Spare Part		15%
4391	6H.192.14.0.00	LFL SENSOR (LOW FUEL LEVEL) 165 MM HIGHT	Spare Part		15%
4392	6H.195.10.0.00	FUEL INJECTION PUMP :6R1080TA-PG	Spare Part		15%
4393	6H.196.10.0.00	FUEL INJECTION PUMP FOR 6R1080T PG MICO NO F 002 AOZ 421	Spare Part		15%
4394	6H.2003.30.0.PR	AMF (STANDARD) PANEL OF 160KVA 3PH FOR EMERALD	Spare Part	195287	15%
4395	6H.2024.20.0.00	ENGINE CONTROL PANEL TO ALTERNATOR HARNESS FOT C T 3PH SUPPLY CONN	Spare Part		15%
4396	6H.204.03.0.00	INLET MANIFOLD	Spare Part		15%
4397	6H.222.10.0.00	ROCKER COVER	Spare Part		15%
4398	6H.224.30.0.00	SUBASSEMBLY OF SUCTION TUBE	Spare Part		15%
4399	6H.225.02.0.00	JOINT: GEAR CASING	Spare Part		15%
7000	011.220.02.0.00	CAMSHAFT GEAR	Spare Part		15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
4401	6H.226.03.0.00	THRUST PLATE	Spare Part	428	15%
4402	6H.226.10.0.00	CAMSHAFT THRUST PLATE AND CAMGEAR SUB ASSEMBLY	Spare Part	50695	15%
4403	6H.227.01.0.00	LUBE OIL SUMP	Spare Part	22083	15%
4404	6H.228.01.0.00	CRANKSHAFT PULLEY	Spare Part	5397	15%
4405	6H.229.01.0.00	FRONT COVER	Spare Part	9520	15%
4406	6H.233.90.0.SP	CRANKCASE WITH M B CAPS 6H 233 90 0 PR	Spare Part	241901	15%
4407	6H.247.14.0.00	PISTON PIN 42.1 MM DIA FOR 6K1080TA	Spare Part	942	15%
4408	6H.247.30.0.00	PISTON RING SET	Spare Part	2351	15%
4409	6H.247.50.0.00	PISTON ASSEMBLY	Spare Part	9495	15%
4410	6H.247.60.0.00	PISTON ASSEMBLY	Spare Part	9151	15%
4411	6H.266.30.0.00	STOP SOLENOID ASSLY: 12V DC	Spare Part	5480	15%
4412	6H.267.01.0.00	INTERMEDIATE GEAR SUPPORT S F AUTO TIMER	Spare Part	1883	15%
4413	6H.273.03.0.00	GEAR CASING	Spare Part	17858	15%
4414	6H.286.10.0.00	SUCTION TUBE ASSLY	Spare Part	462	15%
4415	6H.295.05.0.00	ROTARY FIP: 6R1080TA3 115HP @ 2300RPM	Spare Part	109322	15%
4416	6H.311.04.0.00	GEAR CASING FOR FMUL ENGINE	Spare Part	19123	15%
4417	6H.322.50.0.00	CON ROD ASSLY WITH SE BUSH	Spare Part	10071	15%
4418	6H.326.10.9.00	COUPLING 0.37RB	Spare Part	33809	15%
4419	6H.330.01.0.00	FAN: 21" PUSHER MET	Spare Part	3154	15%
4420	6H.345.04.0.00	BREATHER HOSE	Spare Part	1289	15%
4421	6H.352.01.0.00	SILENCER	Spare Part	64162	15%
4422	6H.352.02.0.00	JOINT: EXHAUST SILENCER	Spare Part	717	15%
4423	6H.352.03.0.00	FLANGE(AT SILENCER INLET AND OUTLET) FOR 6R1080T AND 6R1080TA SILENT SET	Spare Part	2797	15%
4424	6H.357.01.0.00	FRONT COVER	Spare Part	10523	15%
4425	6H.360.01.0.00	FAN ADAPTOR	Spare Part	4548	15%
4426	6H.366.01.0.00	HOSE REDUCER FOR TURBO	Spare Part	806	15%
4427	6H.366.03.0.00	HOSE SILICONE 3" FOR CAC PIPE	Spare Part	1329	15%
4428	6H.378.01.0.00	LUB OIL SUMP (SHALLOW)	Spare Part	19329	15%
4429	6H.378.20.0.00	DIPSTICK ASSEMBLY	Spare Part	95	15%
4430	6H.387.20.0.00	CRANKSHAFT ASSEMBLY	Spare Part	144140	15%
4431	6H.387.30.0.00	CRANKSHAFT ASSEMBLY WITH CRANK GEAR	Spare Part	113728	15%
4432	6H.391.01.0.00	TURBOCHARGER	Spare Part	65642	15%
4433	6H.391.10.0.00	TURBOCHARGER(FOR 6K-140 KVA ENGINE) K27 2964 MXA 10.21	Spare Part	60913	15%
4434	6H.394.02.0.00	FIP: 6K1080 TA CPCBII	Spare Part	273061	15%
4435	6H.394.03.0.00	INLINE FIP: 6R1080 T 150HP@1900RPM CPCBII	Spare Part	103328	15%
4436	6H.394.05.0.PR	4440 MOTORPAL FIP FOR 6R1080TA 3000RPM CPCB II ENGINE	Spare Part	269566	15%
4437	6H.411.01.0.00	SAFETY AIR FILTER ELEMENT	Filter	1185	20%
4438	6H.411.02.0.00	PRIMARY AIR FILTER ELEMENT	Filter	3685	20%
4439	6H.411.10.0.00	AIR CLEANER ASSLY+SAFETY ELEMT	Spare Part	11681	20%
4440	6H.411.20.0.00	AIR CLEANER ASSLY+SAFETY ELEMT	Spare Part	10902	20%
4441	6H.412.03.0.00	STRAIGHT RUBBER HOSE	Spare Part	5077	15%
4442	6H.412.06.0.00	HOSE FOR AIR SUCTION PIPE	Spare Part	1080	15%
4443	6H.412.10.0.00	AIR CLEANER ASSLY WO ELEMT	Spare Part	9691	20%
4444	6H.412.11.0.00	HOSE: AIR CLEANER	Spare Part	4938	15%
4445	6H.412.12.0.00	HOSE: AIR CLEANER	Spare Part	6132	15%
4446	6H.413.02.0.00	AIR CLEANER PRIMARY ELEMENT	Filter	9675	20%
4447	6H.413.10.0.00	RADIAL SEAL AIR CLEANER ASSLY,15 CU METER	Spare Part	29434	20%
4448	6H.413.30.0.00	AIR CLEANER ASSEMBLY	Spare Part	29434	20%
4449	6H.413.32.0.PR	AIR FILTER PRIMARY	Filter	9796	20%
4450	6H.426.10.0.00	PISTON COOLING NOZZLE ASSLY	Spare Part	255	15%
		HOSE: AIR CLEANER	Spare Part	5652	15%
4451	6H.466.47.0.00		· ·		15%
4452	6H.477.101.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2	Spare Part	4185	
4453 4454	6H.477.102.0.PR 6H.477.103.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3	Spare Part	2428	15%
	IDE 477 TU3 0 PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1	Spare Part	2203	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
0101		1 411 2 554 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		without Vat in	Charge%
4456	6H.477.106.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 3	Spare Part	NPR 3258	15%
4457	6H.477.107.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 4	Spare Part	3055	15%
4458	6H.477.108.0.PR	COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 1	Spare Part	2702	15%
4459	6H.477.109.0.PR	COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 2	Spare Part	2865	15%
4460	6H.477.111.0.PR	COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 3	Spare Part	6261	15%
4461	6H.477.1112.0.PR	COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 4	Spare Part	5071	15%
4462	6H.477.113.0.PR	BRACKET ASSEMBLY FOR PIPE CLAMPING ON DOSING MODULE	Spare Part	8861	15%
4463	6H.477.114.0.PR	FUEL INLET PIPE TANK TO PRE FILTER	Spare Part	2729	15%
4464	6H.477.117.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 2	Spare Part	1314	15%
4465	6H.477.118.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2	Spare Part	1354	15%
4466	6H.477.119.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 5	Spare Part	1603	15%
4467	6H.477.140.0.SP	O RING	Spare Part	68	15%
4468	6H.477.141.0.SP	FILLER FILTER	•	658	15%
4469		DRAIN PLUG	Spare Part	803	15%
	6H.477.142.0.SP		Spare Part		
4470	6H.477.143.0.SP	AIR VENT	Spare Part	3588 3388	15% 15%
4471	6H.477.144.0.SP	FILLING NECK	Spare Part		
4472	6H.477.145.0.SP	LOCKING CAP	Spare Part	5145	15%
4473	6H.477.15.0.00	RADIATOR OUTLET HOSE RADIATOR TO PUMP INLET	Spare Part	1723	15%
4474	6H.477.22.0.00	ALUMINIUM RADIATOR ASSLY	Spare Part	166619	15%
4475	6H.477.23.0.00	ALUMINIUM RADIATOR ASSEMBLY	Spare Part	165281	15%
4476	6H.477.26.0.PR	RECOVERY BOTTEL 3.5 LTRS	Spare Part	791	15%
4477	6H.477.27.0.PR	25L AD BLUE TANK ASSEMBLY CPCB4	Spare Part	92433	15%
4478	6H.477.31.0.00	METALIC PIPE THERMOSTAT TO RAD IN	Spare Part	1852	15%
4479	6H.477.32.0.00	HOSE FROM RADIATOR TO PIPE	Spare Part	972	15%
4480	6H.477.33.0.00	HOSE FOR MAKE UP CONNECTION	Spare Part	2342	15%
4481	6H.477.37.0.00	CLAMP FOR 160 KVA	Spare Part	409	15%
4482	6H.477.38.0.00	PLATE	Spare Part	480	15%
4483	6H.477.47.0.PR	HOSE BETWEEN PUMP INLET AND RADIATOR PIPE OUTLET	Spare Part	1262	15%
4484	6H.477.53.0.PR	ALUMINIUM RADIATOR ASSEMBLY, MAKE: TEKSON	Spare Part	279489	15%
4485	6H.477.94.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1	Spare Part	3492	15%
4486	6H.477.96.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 3	Spare Part	2985	15%
4487	6H.477.97.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1	Spare Part	3566	15%
4488	6H.477.98.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 3	Spare Part	2258	15%
4489	6H.477.99.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1	Spare Part	5228	15%
4490	6H.488.10.0.00	AIR CLEANER WO SAFTY ELEMT 6m3	Spare Part	9085	20%
4491	6H.501.10.0.00	ALUMINIUM RADIATOR: 6R1080TA	Spare Part	159561	15%
4492	6H.502.02.0.00	HOSE: MAKE UP CONNECTION	Spare Part	935	15%
4493	6H.502.11.0.00	HOSE FOR RADIATOR OUT TO WATER PUMP IN	Spare Part	1317	15%
4494	6H.502.12.0.00	STAY ROD (FOR RADIATOR)	Spare Part	831	15%
4495	6H.502.13.0.00	HOSE THERMOSTAT TO RADIATOR INLET (45X45X155L)	Spare Part	612	15%
4496	6H.502.40.0.00	RADIATOR	Spare Part	122534	15%
4497	6H.504.11.0.00	LOWER CLAMP FOR NEW GEAR CASING 6H 972	Spare Part	415	15%
4498	6H.508.03.0.PR	MAIN FUEL FILTER	Spare Part	54443	20%
4499	6H.508.04.0.PR	PRE FUEL FILTER	Filter	24858	20%
4500	6H.508.05.0.PR	6H 508 05 0 PR CARTRIDGE FOR FILTER 6H 508 03 0 PR 083689901 D 01	Spare Part	5150	20%
4501	6H.508.06.0.PR	6H 508 06 0 PR CARTRIDGE FOR FILTER 6H 508 04 0 PR E083689902 D 01	Spare Part	7762	20%
4502	6H.508.16.0.SP	500 Hrs B Check Maintenance Kit	Spare Part	27768	20%
4503	6H.508.17.0.SP	1500 Hrs C Check Maintenance Kit	Spare Part	34494	20%
4504	6H.508.18.0.SP	1500 hrs C Check Maintenance Kit	Spare Part	42990	20%
4505	6H.508.19.0.SP	50 Hrs A check Maintenance Kit	Spare Part	19756	20%
4506	6H.510.03.0.PR	CAC OUTLET PIPE STAGE 1 CAC TO INLET MANIFOLD S F SCHWING BP2800	Spare Part	7345	15%
4507	6H.510.04.0.00	CAC OUTLET PIPE CAC TO INLET MANIFOLD STAGE 2	Spare Part	3012	15%
4508	6H.510.08.0.00	RUBBER HOSE FOR CAC OUTLET PIPE	Spare Part	2342	15%
4509	6H.510.10.0.00	RADIATOR &CAC ASSEMBLY.(S/F - SCHWING C.P)	Spare Part	211803	15%
4510	6H.510.11.0.00	WATER PIPE THERMOSTAT TO RADIATOR	Spare Part	1046	15%



				Price to	
Sr.No.	Part Number	umber Part Description	Category	Customer	Custom Charge*
				without Vat in NPR	Charge%
4511	6H.516.01.0.00	AIR PIPE TURBOCHARGER TO CAC	Spare Part	6135	15%
4512	6H.516.02.0.00	AIR PIPE (CAC TO AIR INLET)	Spare Part	7397	15%
4513	6H.516.04.0.00	AIR PIPE BEND PIPE TO RADIATOR	Spare Part	44818	15%
4514	6H.520.10.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	4738	15%
4515	6H.522.40.0.SP	SET OF JOINTS	Spare Part	5286	15%
4516	6H.531.65.0.PR	FUEL TANK FOR 6K1080 SET (250 LTRS - CPCB II) (LAKSHA)	Spare Part	60701	15%
4517	6H.540.01.0.00	RADIATOR FAN (22")	Spare Part	34747	15%
4518	6H.541.01.0.00	EXPANSION BELLOW	Spare Part	6434	15%
4519	6H.548.04.0.00	SPACER: SILENCER - TURBOCHARGER	Spare Part	3255	15%
4520	6H.548.05.0.00	JOINT:SPACER & SILENCER	Spare Part	588	15%
4521	6H.548.10.0.00	SOLENCER	Spare Part	23107	15%
4522	6H.553.21.0.00	SILENCER CLAMP- 275 DIA	Spare Part	997	15%
4523	6H.554.10.0.00	FAN ASSLY:22.5/6-6/2ZR/40/PAG/PUSHER	Spare Part	30812	15%
4524	6H.565.13.0.00	COOLANT LEVEL SENSOR FOR 6K CRDI	Spare Part	3332	15%
4525	6H.599.02.0.00	BREATHER HOSE	Spare Part	972	15%
4526	6H.599.05.0.00	HOSE: AIR CLEANER	Spare Part	3425	15%
4527	6H.599.11.0.00	FUEL PIPE PRE-FILTER TO TANK	Spare Part	1123	15%
4528	6H.599.12.0.00	FUEL RETURN PIPE	Spare Part	674	15%
4529	6H.599.13.0.00	ACTUATOR & ECU MTG. BRACKET	Spare Part	1855	15%
4530	6H.599.14.0.00	FUEL PIPE FEED PUMP TO PRE-FILTER	Spare Part	834	15%
4531	6H.599.15.0.00	DRAIN PIPE	Spare Part	1498	15%
4532	6H.599.16.0.00	LEVER FOR ELE ACTUATOR	Spare Part	508	15%
4533	6H.599.17.0.00	LINK M6X1	Spare Part	95	15%
4534	6H.599.21.0.00	HOSE: RADIATOR INLET	Spare Part	495	15%
4535	6H.599.22.0.00	RADIATOR OUTLET HOSE	Spare Part	1898	15%
4536	6H.599.23.0.00	FUEL PIPE (PRE-FILTER TO TANK UNIT	Spare Part	1738	15%
4537	6H.599.24.0.00	FUEL PIPE FROM FEED PUMP TO PRE FILTER	Spare Part	834	15%
4538	6H.599.29.0.PR	FUEL PIPE FROM FEED PUMP TO PRE FILTER	Spare Part	1308	15%
4539	6H.599.36.0.PR	SUCTION HOSE	Spare Part	1363	15%
4540	6H.599.42.0.PR	PVC PIPE FOR AIR CLEANER	Spare Part	7865	15%
4541	6H.599.43.0.PR	RADIATOR OUTLET HOSE	Spare Part	622	15%
4542	6H.599.48.0.PR	LINK M6	Spare Part	108	15%
4543	6H.599.53.0.PR	FUEL INLET PIPE BOTH SIDE UNION NUT	Spare Part	2440	15%
4544	6H.599.74.0.PR	FUEL RETURN PIPE	Spare Part	809	15%
4545	6H.599.76.0.PR	JUNCTION BOX SUPPORT BRACKET	Spare Part	2545	15%
4546	6H.599.86.0.PR	FUEL PIPE (FROM NRV TO PRE-FILTER)	Spare Part	2089	15%
4547	6H.599.90.0.00	KIT FOR ELECTRICAL FUEL FEED PUMP FITMENT IN 6K	Spare Part	32926	15%
4548	6H.610.10.0.00	WIRING HARNESS ASSEMBLY FOR STARTER SIDE PANEL	Spare Part	4151	15%
4549	6H.621.10.0.00	EXHAUST SILENCER	Spare Part	29335	15%
4550	6H.623.25.0.00	RH LOCK WITH CATCHER: 50MM THK	Spare Part	2237	15%
4551	6H.623.30.0.00	LH LOCK WITH CATCHER: 50MM THK	Spare Part	2218	15%
4552	6H.652.01.0.00	FUEL PUMP GEAR	Spare Part	3486	15%
4553	6H.652.02.0.00	HUB FOR MOTORPAL FIP FITMENT	Spare Part	3369	15%
4554	6H.675.01.0.00	STARTER 12V 3KW	Spare Part	26030	15%
4555	6H.715.11.0.00	CONTROL RELAY	Spare Part	2092	15%
4556	6H.801.05.0.PR	KOEL GREEN ALTERNATOR KG 50 S T FRAME LS KG423K SAE 3 11 5 415 V 50 HZ 0 8 PF	Spare Part	317531	15%
4557	6H.816.07.0.00	ADAPTOR FOR LUB OIL TRIP	Spare Part	228	15%
4558	6H.831.09.0.00	CURRENT TRANSFORMER (SET OF 3 CT) 300/5A FOR FRAME 254	Spare Part	16911	15%
4559	6H.831.16.0.00	FAN HPD RATING 70 160 KVA AG3141890000 FRAME KG44 3	Spare Part	18978	15%
4560	6H.831.17.0.00	WOUND EXCITER ROTOR SCL35 RATING 50 KVA 1PH 82 5 100 KVA SEM443R0010B FRAME K	Spare Part	36418	15%
4561	6H.831.18.0.00	WOUND EXCITER STATOR SCL35 RATING 50 KVA 1PH 82 5 100 KVA SEM443ST005B FRAME KG	Spare Part	38310	15%
4562	6H.831.19.0.00	WOUND EXCITER ROTOR RATING 62 5 KVA 1 PH 125 160 KVA SEM443RO009B FRAME KG44 3	Spare Part	37883	15%
4563	6H.831.22.0.00	DIODE ASSEMBLY RATING 70 60KVA AEM000RE137B FRAME KG44 3	Spare Part	21280	15%
4564	6H.831.27.0.00	COUPLING DISC 11 5 RATING 70 160 KVA PDE352DA021B FRAME KG44 3	Spare Part	8889	15%
4565	6H.831.30.0.00	AVR- D350	Spare Part	244089	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
4566	6H.831.40.0.00	R450 TO D350 RETRO FITMENT KIT FOR KG45 FRAME	Spare Part	28667	15%
4567	6H.846.06.0.00	RELAY BOARD 4 CHANNEL	Spare Part	8695	15%
4568	6H.846.07.0.00	RELAY BOARD 4CH, 2 C/O, 24 VDC, PART NO : UL24D04-2C B, MAKE: UL	Spare Part	4668	15%
4569	6H.846.35.0.00	RELAY 100 AMP.TYPE- BGR 213/24VDC	Spare Part	2575	15%
4570	6H.849.09.0.00	BATTERY CHARGER: 10A 24 VDC	Spare Part	12360	15%
4571	6H.849.31.0.00	4 PIN CONNECTOR 3102R 14S 2 P SQG C C	Spare Part	1228	15%
4572	6H.877.14.0.PR	CONTROLLER	Spare Part	37593	15%
4573	6H.880.12.0.00	ON/FF SELECTOR SW.(WITH NO ELEMENT)TELEMECANIQUE RANGE 2 WAY SELECT. STAY TYP	Spare Part	1514	15%
4574	6H.880.13.0.00	EMERGENCY STOP PB WITH NC ELEMENT	Spare Part	1766	15%
4575	6H.880.16.0.00	DOOR LOCK DARSHANA MAKE TYPE DM3WL EQUIV DIE CAST STANDARD GRIP 30MM	Spare Part	717	15%
4576	6H.880.41.0.00	ON/OFF SELECTOR SWITCH WITH NO ELEMENT	Spare Part	1720	15%
4577	6H.880.42.0.00	EMG STOP WITH NO ELEMENT	Spare Part	1003	15%
4578	6H.880.43.0.00	EMG STOP WITH NC ELEMENT	Spare Part	1071	15%
4579	6H.880.48.0.00	ASSEMBLY OF EMERGENCY STOP SWITCH NO ELEMENT WITH ILLUMINATED LEGEND PLATE	Spare Part	2495	15%
4580	6H.880.58.0.00	ASSEMBLY OF EMERGENCY STOP SWITCH NC ELEMENT WITH ILLUMINATED LEGEND PLATE	Spare Part	2388	15%
4581	6H.899.01.0.00	AIR CLEANER MOUNTING BRACKET	Spare Part	4698	15%
4582	6H.899.02.0.00	HOSE: AIR CLEANER	Spare Part	3905	15%
4583	6H.900.10.0.00	WIRING HARNESS ASSLY: 6R1080TA	Spare Part	4114	15%
4584	6H.901.03.0.PR	KOEL GREEN Alternator, KG 160 S T Frame: L KG 44.3 H , SAE-2 11.5", 415V, 50 Hz, 0.8 PF	Spare Part	625284	15%
4585	6H.901.11.0.00	DIODE ASSEMBLY KG 45	Spare Part	38498	15%
4586	6H.901.14.0.00	TERMINAL BAR FOR KG 45	Spare Part	8434	15%
4587	6H.901.28.0.PR	KOEL GREEN ALTERNATOR COASTAL HUMID ENVIRONMENT KG 160 S T FRAME L KG 44 3 H	Spare Part	731086	15%
4588	6H.901.32.0.00	DE ADAPTOR KG 40 (SAE 2)	Spare Part	43070	15%
4589	6H.902.25.0.00	23 PIN CONNECTOR ALLIED MAKE MS 3102 R 32 6 P MALE TYPE PINS C C SQG	Spare Part	5471	15%
4590	6H.902.30.0.00	WIRING HANESS ASSEMBLY (FIRE FIGHTING)	Spare Part	15111	15%
4591	6H.902.31.0.00	TEMPERATURE SWITCH ENGINE COOLANT	Spare Part	2886	15%
4592	6H.902.32.0.00	TEMPERATURE SWITCH ENGINE COOLANT LOW	Spare Part	3000	15%
4593	6H.902.33.0.00	TEMPERATURE SWITCH RAW WATER	Spare Part	2938	15%
4594	6H.902.35.0.00	WIRING HARNESS ASSEMBLY 6R1080TA FM_UL NEW	Spare Part	30858	15%
4595	6H.902.80.0.00	PANEL TO PANEL WIRING HARNESS	Spare Part	16147	15%
4596	6H.903.11.0.PR	FLOW SWITCH 4RTA	Spare Part	15089	15%
4597	6H.903.14.0.PR	RAW WATER FLOW SWITCH SL90 FM UL NEW	Spare Part	15683	15%
4598	6H.924.20.0.00	ENGINE WIRING HARNESS: 6R CPCB	Spare Part	8129	15%
4599	6H.931.40.0.00	WIRING HARNESS (FOR KPC 6H.2575) COMPRESSOR SC1012C OIL INDIA WITH PVC PIPE, GLAND	Spare Part	12252	15%
4600	6H.9408.01.0.00	RAIL FOR 6K1080TAE PROJECT BOSCH DRG NO A 445 226 902	Spare Part	35910	15%
4601	6H.9408.01.0.PR	RAIL FOR 6K1080TAE PROJECT BOSCH SERIES RELEASE PART NO 0 445 226 231	Spare Part	36593	15%
4602	6H.949.02.0.00	HOSE: AIR CLEANER	Spare Part	3175	15%
4603	6H.956.13.0.00	H T CABLE SET	Spare Part	10803	20%
4604	6H.956.27.0.00	DISTR HOUSING	Spare Part	2274	15%
4605	6H.956.28.0.00	DISTRIBUTOR DRIVING SHAFT FOR 6R GAS ENGINE	Spare Part	10895	15%
4606	6H.956.29.0.PR	DISTRIBUTOR SUITABLE FOR 6R ENGINE REPUTABLE MAKE	Spare Part	39966	15%
4607	6H.980.05.0.00	CURRENT TRANSFARMOR 200/5, 5 VA	Spare Part	2055	15%
4608	6H.985.07.0.00	SHAFT FOR LUBE OIL PUMP INTERMEDIATE GEAR	Spare Part	302	15%
4609	6H.985.30.0.00	LUBE OIL PUMP ASSLY	Spare Part	10009	15%
4610	6H.986.05.0.00	JOINT: SUCTION FLANGE	Spare Part	46	15%
4611	6H.986.30.0.00	SUB ASM OF SUCTION TUBE	Spare Part	914	15%
4612	6H.986.31.0.00	FUNNEL FILTER	Spare Part	9835	20%
4613	6H.986.32.0.TOL	FUNNEL FILTER 45 4 LPM	Spare Part	28880	20%
4614	6H.986.34.0.SP	FUNNEL FILTER 18 9 LPM	Spare Part	15828	20%
4615	6H.990.08.0.PR	GASKET BET CRANKCASE AND PUMP VOLUTE	Spare Part	169	15%
4616	6H.990.20.0.PR	WATER PUMP AASEMBLY	Spare Part	20317	15%
4617	6H.996.02.0.00	FUEL PUMP 6R1080TC 169 HP @ 2300 RPM_F 002 AOZ 651	Spare Part	81645	15%
4618	6H.999.02.0.SP	MODIFICATION KIT FOR OIL FUEL MIXING ISSUE	Spare Part	58879	15%
4619	6H.999.03.0.SP	MAIN BEARING KIT FOR BIO GAS	Spare Part	4618	15%
4620	6H.999.60.0.00	MAJOR OVERHAL KIT FOR 6R1080 BSIII	Spare Part	106546	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
1001	011 5074 40 0 00	DOG CATALVOT OF DIA VE LENGTH 45 C OFT 54 DT DD EDFOLL	On our Don't	NPR	450/
4621	6H.EGT4.10.0.PR	DOC CATALYST 9 5 DIA X 5 LENGTH 15 G CFT 5 1 PT PD FRESH	Spare Part	131866	15%
4622	6H.EGT4.23.0.PR	9 5 Gasket DOC TO Mixer 82429423	Spare Part	3538 107297	15% 15%
4623 4624	6H.EGT4.24.0.PR	SUPPLY MODULE B444 606 940 SM 2 2 EVO BL 12 V 9 BAR	Spare Part	8025	15%
4625	6H.M412.05.0.00 82.020.35.1.01	AIR CLEANER MODEL JJM 02	Spare Part	443	15%
	82.020.35.1.05	KOEL CARE GENUINE COOLANT PREMIX 1 LITRE CAN KOEL CARE GENUINE COOLANT PREMIX 5 LITRE CAN	Spare Part Spare Part	2049	15%
4626 4627	82.020.35.1.10	KOEL CARE GENUINE COOLANT PREMIX 3 LITTLE CAN	Spare Part	3963	15%
4628	82.020.35.1.11	KOEL CARE GENUINE COOLANT PREMIX TO ETTAL CARY KOEL CARE GENUINE COOLANT PREMIX 205 Ltrs Barrel	Spare Part	75494	15%
4629	82.020.35.1.11	KOEL CARE Genuine Coolant Premix 26 Litres Can	Spare Part	9849	15%
4630	82.020.35.5.01	K CLEAN 1LTR CAN	Spare Part	1563	15%
4631	82.050.10.0.01	KOEL CARE Super Genuine Oil 1 Liter CAN	Oil	698	30%
4632	82.050.10.0.01	KOEL CARE Super Genuine Oil 1 Etter CAN	Oil	3419	30%
4633	82.050.10.0.07	KOEL CARE Super Genuine Oil 7.5 Liters CAN	Oil	5075	30%
4634	82.050.10.0.07	KOEL CARE Super Genuine Oil 7.3 Liters CAN	Oil	8478	30%
	82.050.10.0.13			13020	30%
4635 4636	82.050.10.0.20 82.050.10.0.50	KOEL CARE Super Genuine Oil 20 Liters CAN KOEL CARE Super Genuine Oil 50 Liters CAN	Oil	30916	30%
4637		KOEL CARE Super Genuine Oil 30 Liters CAN KOEL CARE Super Genuine Oil 210 Liters Barrel	Oil	121041	30%
4638	82.050.10.2.10	KOEL CARE Super Gentaine Oil 210 Ellers Barrel KOEL CARE Premium Genuine Oil 1 Liter CAN	Oil	757	30%
4639	82.060.10.0.01	KOEL CARE Premium Genuine Oil 1 Liter CAN KOEL CARE Premium Genuine Oil 5 Liters CAN	Oil	3685	30%
	82.060.10.0.05			5516	30%
4640	82.060.10.0.07 82.060.10.0.13	KOEL CARE Premium Genuine Oil 7.5 Liters CAN KOEL CARE Premium Genuine Oil 13 Liters CAN	Oil	9402	30%
4641					
4642	82.060.10.0.20	KOEL CARE Premium Genuine Oil 20 Liters CAN	Oil	14260	30%
4643	82.060.10.0.50	KOEL CARE Premium Genuine Oil 50 Liters CAN	Oil	32808	30%
4644	82.060.10.0.80	K SEALENT (80 ML)	Spare Part	1392	11%
4645	82.060.10.0.92	Rust Buster	Spare Part	440	15% 30%
4646	82.060.10.2.10	KOEL CARE Premium Genuine Oil 210 Liters Barrel	Oil	127106 37287	30%
4647	82.070.10.0.50	KOEL CARE GOLD Genuine Oil 50 litre Can			30%
4648	82.110.20.0.10	Genuine D.E.F. 10 litre can	Oil	1579	30%
4649	82.110.20.0.20	Genuine D.E.F. 20 litre can		3401 34656	30%
4650	82.110.22.10.00	AdBlue (AUS32) 210 litre barrel KOEL CARE - PETRO PLUS 1.2 LITRES PETROL ENGINE OIL	Spare Part Oil	850	30%
4651	82.110.30.0.000			9434	15%
4652	82.170.50.0.50	Genset alternator DE/NDE bearing grease (500 gm) for Power Car application	Spare Part		15%
4653	ACL.0001.007.0.00	MECHNICAL INTER LOCK	Spare Part	1228	
4654	ACL.0001.008.0.00	SURGE SUPPRESSOR KOEL MAKE FOR FRAME 1 TYPE KUS 3	Spare Part	877	15%
4655	ACL.0001.110.0.00	CONTACTOR AUXILLARY 1 NO 1 NC CONTACT FOR TOP FOR FRAME 1, KOEL MAKE (TYPE : KUA	Spare Part	618	15% 15%
4656	ACL.0002.007.0.00	MECHNICAL INTER LOCK	Spare Part	1212	
4657	ACL.0002.008.0.00	SURGE SUPPRESSOR, KOEL MAKE FOR FRAME 2(TYPE: KAS-3)	Spare Part	868	15%
	ACL.0002.110.0.00	CONTACTOR AUXILLARY 1 NO 1 NC CONTACT FOR TOP FOR FRAME 2 , KOEL MAKE (TYPE : KAL	Spare Part	535	15%
4659	ACL 0003.007.0.00	MECHNICAL INTER LOCK KOEL MAKE FOR FRAME 3 TYPE KAR 180	Spare Part	1714	15%
4660	ACL.0003.220.0.00	CONTACTOR AUXILLARY	Spare Part	1034	15%
4661	ACL.0004.110.0.00	CONTACTOR AUXILLARY 1 NO 1 NC CONTACT FOR SIDE FOR FRAME 4 KOEL MAKE TYPE KAL	Spare Part	1277	15%
4662	ALL.0100.003.0.00	MCCB AUXULIARY SHUNT RELEASE CONTACT UPTO 100 AMP KOEL MAKE FOR TYPE KLL1	Spare Part	1969	15%
4663	ALL.0100.036.0.00	MCCB SPREADERS 100/125AMP, 3 POLE	Spare Part	1018	15%
4664	ALL.0100.046.0.00	MCCB SPREADERS 100 AMP, 4 POLE, KOEL MAKE FOR TYPE KLL1 (SET OF 8) WITH HARDWARE	Spare Part	1400	15%
4665	ALL.0250.003.0.00	MCCB AUXULIARY SHUNT RELEASE CONTACT 125-250 AMP	Spare Part	3049	15%
4666	ALL.0250.036.0.00	MCCB SPREADERS 250 AMP, 3 POLE	Spare Part	1766	15%
4667	ALL.0250.046.0.00	MCCB SPREADERS 250 AMP, 4 POLE, KOEL MAKE FOR TYPE KLL3 (SET OF 8) WITH HARDWARE	Spare Part	2246	15%
4668	ALL.0800.003.0.00	MCCB AUXULIARY SHUNT RELEASE CONTACT 400-800 AMP	Spare Part	4123	15%
4669	ALL.0800.005.0.00	MCCB ROTARY HANDLE KOEL MAKE, FOR TYPE KILS	Spare Part	8545	15%
4670	ALL.0800.036.0.00	MCCB SPREADERS 800 AMP, 3 POLE, KOEL MAKE FOR TYPE KLL5 (SET OF 6) WITH HARDWARE	Spare Part	8363	15%
4671	ALL.1250.005.0.00	MCCB ROTARY HANDLE KOEL MAKE FOR TYPE KLL6	Spare Part	26501	15%
4672	AP1.001.12.0.PR	REGULATING SWAY BAR	Spare Part	538	15%
4673	AP1.001.15.0.PR	OIL SAFEGUARD SWITCH	Spare Part	582	15%
4674	AP1.001.20.0.00	OIL LEVEL SWITCH ASSEMBLY	Spare Part	1329	15%
4675	AP1.002.02.0.00	FRONT OIL SEAL	Spare Part	397	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
				without Vat in NPR	Charge%
4676	AP1.002.04.0.00	CRANCASE COVER GASKET	Spare Part	763	15%
4677	AP1.002.06.0.PR	DIPSTICK WITH SEAL	Spare Part	471	15%
4678	AP1.003.05.0.00	CYLINDER HEAD GASKET	Spare Part	763	15%
4679	AP1.003.06.0.00	EXHAUST GASKET	Spare Part	49	15%
4680	AP1.003.10.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	5895	15%
4681	AP1.004.02.0.00	FAN COOLING	Spare Part	1071	15%
4682	AP1.005.06.0.PR	PUSHER	Spare Part	262	15%
4683	AP1.006.04.0.00	STARTER MOTOR SOLENOID	Spare Part	2794	15%
4684	AP1.006.10.0.00	STARTER MOTOR ASSEMBLY	Spare Part	9221	15%
4685	AP1.007.09.0.PR	RECOIL STARTER ROPE	Spare Part	271	15%
4686	AP1.007.20.0.PR	RECOIL STARTER ASSEMBLY	Spare Part	5181	15%
4687	AP1.008.02.0.00	FILTER ELEMENT	Spare Part	268	15%
4688	AP1.008.10.0.00	AIR CLEANER ASSEMBLY	Spare Part	2492	15%
4689	AP1.008.11.0.00	FILTER ELEMENT	Spare Part	406	15%
4690	AP1.009.03.0.00	ALTERNATOR FAN	Spare Part	1000	15%
4691	AP1.009.10.0.PR	ALTERNATOR ASSEMBLY	Spare Part	55061	15%
4692	AP1.009.15.0.00	ALTERNATOR REAR FRAME	Spare Part	2618	15%
4693	AP1.009.42.0.00	VOLTAGE REGULATOR- 2 KVA	Spare Part	3012	15%
4694	AP1.009.44.0.PR	ROTOR REAR FAN	Spare Part	505	15%
4695	AP1.009.55.0.PR	2 6KW PM ALTERNATOR ASSEMBLY	Spare Part	33624	15%
4696	AP1.009.64.0.PR	PM Alternator Module	Spare Part	42633	15%
4697	AP1.009.75.0.PR	STATOR ASSEMBLY FOR 2 6KW PM	Spare Part	18141	15%
4698	AP1.010.10.0.00	IGNITION COIL ASSEMBLY	Spare Part	3166	15%
4699	AP1.011.01.0.00	MUFFLER	Spare Part	5849	15%
4700	AP1.011.22.0.00	MUFFLER FOR 2.8KW PMG	Spare Part	9551	15%
4701	AP1.011.29.0.PR	EXHAUST GASKET MUFFLER	Spare Part	148	15%
4702	AP1.011.50.0.SPR	CATCON AND CATCON PIPE ASSEMBLY	Spare Part	7597	15%
4703	AP1.012.01.0.PR	ANTI VIBRATION MOUNT 708A Mix 01 Yellow 15 4 to 5 Alternator side	Spare Part	772	15%
4704	AP1.012.02.0.PR	ANTI VIBRATION MOUNT 708A Mix 02 Green 25 4 to 5 Engine side	Spare Part	772	15%
4705	AP1.013.10.0.PR	PISTON ASSEMBLY	Spare Part	3120	15%
4706	AP1.014.10.0.00	CARBURETOR ASSEMBLY	Spare Part	7665	15%
4707	AP1.014.12.0.00	CARBURETTOR METAL GASKET	Spare Part	95	15%
4708	AP1.014.13.0.00	CARBURETTOR CONNECTING BLOCK GASKET	Spare Part	65	15%
4709	AP1.014.14.0.00	CARBURETTOR CONNECTING BLOCK	Spare Part	514	15%
4710	AP1.014.15.0.00	CARBURETTOR METAL GASKET	Spare Part	769	15%
4711	AP1.015.04.0.PR	FINE REGULATING SPRING	Spare Part	283	15%
4712	AP1.015.05.0.PR	BACK SPRING	Spare Part	283	15%
4713	AP1.016.03.0.00	IGNITION SWITCH	Spare Part	2800	15%
4714	AP1.016.08.0.00	MCB 9 AMP	Spare Part	1548	15%
4715	AP1.016.40.0.PR	POWER HARNESS FOR CHHOTA CHILLI	Spare Part	2926	15%
4716	AP1.018.04.0.PR	REGULATOR CHARGER	Spare Part	1200	15%
4717	AP1.018.32.0.PR	12V, 8Ah VRLA Kirloskar Green Battery	Battery	4450	15%
4718	AP1.022.05.0.00	FUEL GAUGE WITH GASKET	Spare Part	609	15%
4719	AP1.022.10.0.00	FUEL TANK ASSEMBLY 6 5 LTR	Spare Part	6437	15%
4720	AP1.022.13.0.00	FUEL FILTER	Spare Part	106	20%
4721	AP1.022.14.0.00	FUEL COCK	Spare Part	446	15%
4722	AP1.022.35.0.PR	FUEL FILTER AND FUEL PIPE ASSEMBLY	Spare Part	492	15%
4723	AP1.023.65.0.00	CHOKE CABLE ASSEMBLY	Spare Part	271	15%
4724	AP1.026.11.0.00	LUB OIL DRAIN PIPE ASSEMBLY	Spare Part	778	15%
4725	AP1.101.14.0.00	AXLE	Spare Part	2172	15%
4726	AP1.101.17.0.00	CIRCLIP	Spare Part	65	15%
4727	AP1.101.18.0.00	WHEEL-160	Spare Part	1385	15%
4728	AP1.120.003.0.00	DIGITAL DISPLAY UNIT VOLTAGE FREQUENCY CUMMULATIVE HOURS RUNNING HOURS	Spare Part	3538	15%
4729	AP1.7001.100.0.PR	COMPLETE ENGINE ASSEMBLY WITH 2 6KW PM ALTERNATOR	Spare Part	94094	15%
4730	AP5.003.05.0.PR	CYLINDER HEAD GASKET	Spare Part	206	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
4731	AP5.003.07.0.PR	CYLINDER HEAD COVER GASKET	Spare Part	86	15%
4732	AP5.007.20.0.PR	RECOIL STARTER ASSEMBLY	Spare Part	2191	15%
4733	AP5.014.20.0.00	CARBURETOR ASSEMBLY	Spare Part	5628	15%
4734	AP5.014.47.0.00	STEPPER MOTOR ASSY	Spare Part	1988	15%
4735	AP5.016.11.0.PR	GASKET FOR MUFFLER	Spare Part	83	15%
4736	APK.0253.10.0.00	AMF PANEL ASSEMBLY FOR 20 TO 25 KVA, 3PH. AMFI WALL MOUNTING.	Spare Part	50729	15%
4737	APK.0301.10.0.00	AMF PANEL ASSEMBLY FOR 20 TO 30 KVA, 1PH. AMFI WALL MOUNTING.	Spare Part	75827	15%
4738	APK.0400.006.0.PR	63 AMP 4 POLE REAR MOUNTING CHAGEOVER SWITCH KOEL	Spare Part	8788	15%
4739	B.006.4.00.003	CON ROD BEARING: 6R1080 STD	Spare Part	4458	15%
4740	B.006.4.00.013	CON ROD BEARING: 6R1080 0.25	Spare Part	5311	15%
4741	B.006.4.00.023	CONNECTING ROD BEARING 020	Spare Part	5295	15%
4742	B.006.4.00.033	CONNECTING ROD BEARING 030	Spare Part	5560	15%
4743	B.006.4.00.043	CONNECTING ROD BEARING 040	Spare Part	5963	15%
4744	B.006.4.30.003	CONNECTING ROD BEARING	Spare Part	3400	15%
4745	B.012.4.00.023	CONNECTING ROD BEARING 020	Spare Part	1265	15%
4746	B.019.3.00.003	BRG C/R	Spare Part	397	15%
4747	B.019.3.00.013	BRG C R 010KIR TV1	Spare Part	428	15%
4748	B.019.3.00.023	BRG C R 020KIR TV1	Spare Part	437	15%
4749	B.019.3.10.003	CONNECTING ROD BEARING	Spare Part	471	15%
4750	B.038.4.00.003	CON ROD BEARING RA3	Spare Part	1625	15%
4751	B.038.4.00.013	CON ROD BEARING RA3	Spare Part	1748	15%
4752	B.038.4.00.023	CON ROD BEARING: RA3	Spare Part	1665	15%
4753	B.038.4.00.033	CON ROD BEARING: RA3 030	Spare Part	1665	15%
4754	B.040.4.00.013	CONNECTING ROD BEARING 010	Spare Part	2335	15%
4755	B.040.4.00.023	CONNECTING ROD BEARING 020	Spare Part	2335	15%
4756	B.055.4.00.003	CON ROD BEARING: SL90	Spare Part	7760	15%
4757	B.055.4.00.013	CONNECTING ROD BEARING 010	Spare Part	9437	15%
4758	B.055.4.00.023	CONNECTING ROD BEARING 020	Spare Part	7960	15%
4759	B.055.4.10.003	CON ROD BEARING: SL90 250KVA	Spare Part	7760	15%
4760	B.055.4.10.013	Connecting Rod bearing 010 U/S	Spare Part	9132	15%
4761	B.055.4.10.023	Connecting Rod bearing 020 U/S	Spare Part	8357	15%
4762	B.055.4.10.033	BEARING C R KIR SL90 250KVA 0 75	Spare Part	7960	15%
4763	B.073.4.00.003	CON ROD BEARING : HA394	Spare Part	2289	15%
4764	B.073.4.00.013	CON ROD BEARING : HA394	Spare Part	2345	15%
4765	B.073.4.00.023	CON ROD BEARING: HA394	Spare Part	2345	15%
4766	B.073.4.00.033	CON ROD BEARING: HA394 030	Spare Part	2345	15%
4767	B.073.4.00.043	CONNECTING ROD BEARING 040	Spare Part	2538	15%
4768	B.073.4.10.003	CON ROD BEARING :HA394 STD	Spare Part	2289	15%
4769	B.073.4.10.013	CON ROD BEARING: HA394 0.25	Spare Part	2366	15%
4770	B.073.4.10.023	CON ROD BEARING: HA394 020 U/S NICK	Spare Part	2345	15%
4771	B.073.4.10.033	CON ROD BEARING: HA394 030 U/S NICK	Spare Part	2345	15%
4772	B.074.4.00.003	CON ROD BEARING: HA 494	Spare Part	3046	15%
4773	B.074.4.00.013	CON ROD BEARING: HA494	Spare Part	3286	15%
4774	B.074.4.00.023	CON ROD BEARING: HA 494	Spare Part	3286	15%
4775	B.074.4.00.033	CON ROD BEARING: HA494	Spare Part	3286	15%
4776	B.074.4.10.003	CON ROD BRG HA494 STD	Spare Part	3046	15%
4777	B.074.4.10.013	CON ROD BEARING HA494 0.25	Spare Part	3129	15%
4778	B.074.4.10.023	CON ROD BEARING: HA494 0.50	Spare Part		15%
4779	B.074.4.10.033	CON ROD BEARING: HA494 030 U/S NICK	Spare Part	3286	15%
4780	B.075.4.00.003	CON ROD BEARING: HA694	Spare Part	4738	15%
4781	B.075.4.00.013	CON ROD BEARING: HA694 010	Spare Part		15%
4782	B.075.4.00.023	CONNECTING ROD BEARING 020	Spare Part	5092	15%
4783	B.075.4.00.033	CONNECTING ROD BEARING 030	Spare Part	5092	15%
4784	B.075.4.10.003	CON ROD BEARING: HA694 STD NICK	Spare Part	4634	15%
	B.075.4.10.013	CON ROD BEARING: HA694 010 U/S NICK	Spare Part		15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
4786	B.075.4.10.023	Connecting Rod bearing 020 U/S	Spare Part	5092	15%
4787	B.093.4.00.003	CON ROD BEARING: HA294	Spare Part	1563	15%
4788	B.093.4.00.013	CON ROD BEARING: HA294 010	Spare Part	1563	15%
4789	B.093.4.00.023	CONNECTING ROD BEARING 020	Spare Part	1640	15%
4790	B.093.4.10.003	CON ROD BEARING: HA294 STD NICK	Spare Part	1563	15%
4791	B.093.4.10.013	CON ROD BEARING: HA294 010 U/S NICK	Spare Part	1563	15%
4792	B.093.4.10.023	Connecting Rod bearing 020 U/S	Spare Part	1640	15%
4793	B.547.4.00.003	CON ROD BEARING: DV10 STD	Spare Part	13071	15%
4794	B.552.0.10.003	KIR 4R810 TA B/E BRG T4160030, STD	Spare Part	3043	15%
4795	B.552.4.00.003	BEARING BIG END: 4R810 STD	Spare Part	1148	15%
4796	B.584.4.00.003	CON ROD BEARING: 4RTA STD	Spare Part	1942	15%
4797	B.584.4.00.013	CONNECTING ROD BEARING 025	Spare Part	2188	15%
4798	B.584.4.00.023	CONNECTING ROD BEARING 050	Spare Part	2188	15%
4799	B.584.4.00.033	CONNECTING ROD BEARING 075	Spare Part	2206	15%
4800	B.584.4.10.003	CON ROD BEARING: 6TRA STD	Spare Part	3037	15%
4801	B.584.4.10.013	CON ROD BEARING: 6RTA 0.25	Spare Part	3634	15%
4802	B.584.4.10.023	CONNECTING ROD BEARING 050	Spare Part	3132	15%
4803	B.584.4.10.033	KIR 6RTA C R BRG 0 75 04692020	Spare Part	3141	15%
4804	B2.005.16.0.00	HOLLOW DOWEL(M.B.CAP)	Spare Part	55	15%
4805	BP1.001.02.0.PR	OIL SAFEGUARD SWITCH	Spare Part	612	15%
4806	BP1.001.20.0.00	OIL LEVEL SWITCH ASSEMBLY	Spare Part	1431	15%
4807	BP1.002.02.0.00	CRANKCASE COVER GASKET	Spare Part	849	15%
4808	BP1.003.02.0.00	INTAKE VALVE GUIDE SEAL	Spare Part	526	15%
4809	BP1.003.05.0.00	CYLINDER HEAD GASKET	Spare Part	929	15%
4810	BP1.003.10.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	9003	15%
4811	BP1.003.13.0.00	CYLINDER COVER GASKET	Spare Part	529	15%
4812	BP1.003.17.0.00	SPARK PLUG	Spare Part	412	15%
4813	BP1.003.18.0.00	SPARK PLUG F7TC NHSP W8DC BOSCH BP6ES NGK	Spare Part	415	15%
4814	BP1.003.20.0.00	CYLINDER HEAD COVER ASSEMBLY	Spare Part	2981	15%
4815	BP1.004.10.0.PR	FLYWHEEL ASSEMBLY	Spare Part	13794	15%
4816	BP1.005.10.0.00	PISTON ASSEMBLY	Spare Part	5969	15%
4817	BP1.005.20.0.00	PISTON RING SET	Spare Part	2326	15%
4818	BP1.005.30.0.00	CON ROD ASSLY	Spare Part	3317	15%
4819	BP1.005.40.0.00	CRANKSHAFT ASSEMBLY	Spare Part	11701	15%
4820	BP1.005.40.0.00	STARTER MOTOR	Spare Part	11843	15%
4821	BP1.007.09.0.00	PUSHER	Spare Part	338	15%
4822	BP1.007.09.0.00	INTAKE VALVE	Spare Part	1077	15%
4823	BP1.007.16.0.00	EXHAUST VALVE	Spare Part	1077	15%
4824	BP1.007.18.0.00	VALVE SPRING	Spare Part	486	15%
4825	BP1.007.10.0.00	VALVE COLLET	Spare Part	655	15%
		FILTER ELEMENT	Spare Part	365	20%
4826 4827	BP1.008.03.0.00 BP1.008.08.0.PR	AIR CLEANER GASKET	Spare Part	28	15%
	 		·		
4828	BP1.008.10.0.00	AIR CLEANER ASSEMBLY	Spare Part	4378	15%
4829	BP1.010.10.0.00	CARBURETOR ASSEMBLY CARBURETTOR METAL CASKET	Spare Part	9538	15%
4830	BP1.010.23.0.00	CARBURETTOR METAL GASKET	Spare Part	55	15%
4831	BP1.010.24.0.00	CARBURETTOR FRONT GASKET	Spare Part	58	15%
4832	BP1.010.25.0.00	CARBURETTOR CONNECTING BLOCK CASKET	Spare Part	662	15%
4833	BP1.010.26.0.00	CARBURETTOR CONNECTING BLOCK GASKET	Spare Part	6202	15%
4834	BP1.011.01.0.PR	MUFFLER	Spare Part	6203	15%
4835	BP1.011.08.0.00	EXHAUST GASKET	Spare Part	46	15%
4836	BP1.011.10.0.SPR	CATCON AND CATCON PIPE ASSEMBLY	Spare Part	3981	15%
4837	BP1.020.10.0.00	RECOIL STARTER ASSEMBLY	Spare Part	6225	15%
4838	BP1.022.02.0.00	FUEL PIPE TANK TO COCK 160 MM	Spare Part	52	15%
4839	BP1.022.03.0.00	FUEL PIPE COCK TO FILTER 35 MM	Spare Part	25	15%
4840	BP1.022.04.0.00	FUEL PIPE FILTER TO CARBURETOR	Spare Part	108	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
4841	BP1.022.14.0.00	FUEL PIPE CLIP	Spare Part	28	15%
4842	BP1.022.20.0.PR	FUEL FILTER FUEL COCK AND FUEL PIPE ASSEMBLY	Spare Part	948	15%
4843	BP1.022.30.0.00	FUEL TANK & STRAINER ASSLY	Spare Part	4923	15%
4844	BP1.023.41.0.00	MCB 13 AMP	Spare Part	1668	15%
4845	BP1.026.10.0.00	SPEED REGULATING ASSEMBLY	Spare Part	2532	15%
4846	BP1.027.02.0.00	SPARK PLUG CAP	Spare Part	729	15%
4847	BP1.027.07.0.00	CHARGE COIL	Spare Part	1914	15%
4848	BP1.027.10.0.00	IGNITION COIL ASSEMBLY	Spare Part	2486	15%
4849	BP1.027.20.0.00	CHARGE COIL ASSEMBLY	Spare Part	2375	15%
4850	BP1.1001	CHHOTA CHILLI 302 CC PETROL.ONE.AIR.6.2HP(MAX OUTPUT)@3000RPM.ISO:3046.	Spare Part	107448	15%
4851	C.055.5.00.703	bearing CAM BUSH	Spare Part	5981	15%
4852	C.073.6.00.003	C.073.6.00.003 BEARING C/BUSH KIR HA 394	Spare Part	326	15%
4853	C.073.6.00.703	C.073.6.00.703 BEARING C/BUSH KIR HA 394	Spare Part	342	15%
4854	C.547.5.00.003	bearing CAM BUSH	Spare Part	4138	15%
4855	C.547.5.10.003	BEARING C/B KIR DV10, STD PF (Single piece)	Spare Part	443	15%
4856	C.597.6.00.003	BEARING C/BUSH: RB33 STD PF	Spare Part	382	15%
4857	CC1.001.003.0.00	CYLINDER HEAD NUT (LONG)	Spare Part	212	15%
4858	CC1.001.004.0.00	CYLINDER HEAD NUT (SHORT)	Spare Part	172	15%
4859	CC1.001.007.0.00	RECTANGLE RING GASKET (4.1 X 4.25 X 2.3)	Spare Part	258	15%
4860	CC1.001.011.0.00	OIL SEAL: REAR 35X50X8	Spare Part	397	15%
4861	CC1.001.012.0.00	OIL PRESSURE SWITCH	Spare Part	1265	15%
4862	CC1.001.018.0.00	OIL DIPSTICKWITH O RING	Spare Part	185	15%
4863	CC1.001.020.0.00	SEALING PLATE GASKET	Spare Part	25	15%
4864	CC1.001.021.0.00	SEALING PLATE	Spare Part	92	15%
4865	CC1.001.024.0.00	NEEDLE BEARING 7941/15	Spare Part	209	15%
4866	CC1.001.025.0.00	BALL BEARING	Spare Part	5994	15%
4867	CC1.001.026.0.00	CRANKCASE COVER GASKET	Spare Part	514	15%
4868	CC1.001.027.0.00	BEARING 6207	Spare Part	883	15%
4869	CC1.001.033.0.00	OIL SEAL: FRONT 35X50X10	Spare Part	446	15%
4870	CC1.001.036.0.00	DRAIN BOLT ENTENSION WITH WASHER	Spare Part	335	15%
4871	CC1.001.043.0.00	START SWITCH ASSEMBLY	Spare Part	2372	15%
4872	CC1.001.052.0.00	CYLINDER HEAD STUD (LONG) M10x118	Spare Part	215	15%
4873	CC1.001.053.0.00	CYLINDER HEAD STUD (SHORT) M10x105	Spare Part	228	15%
4874	CC1.001.054.0.00	OIL DRAIN PLUG M16x15 WITH GASKET	Spare Part	443	15%
4875	CC1.001.061.0.00	CYLINDER HEAD GASKET 0.1	Spare Part	111	15%
4876	CC1.001.062.0.00	CYLINDER HEAD GASKET 0.2	Spare Part	182	15%
4877	CC1.001.063.0.00	CYLINDER HEAD GASKET 0.3	Spare Part	246	15%
4878	CC1.001.064.0.00	CYLINDER HEAD GASKET 0.4	Spare Part	252	15%
4879	CC1.001.065.0.00	CYLINDER HEAD GASKET 0.5	Spare Part	302	15%
4880	CC1.001.10.0.00	CYLINDER BLOCK	Spare Part	106774	15%
4881	CC1.001.40.0.00	CRANKCASE COVER ASSEMBLY	Spare Part	16744	15%
4882	CC1.002.008.0.00	GASKET: ROCKER COVER	Spare Part	148	15%
4883	CC1.002.009.0.00	ROCKER ARM ASSEMBLY	Spare Part	3037	15%
4884	CC1.002.011.0.00	ADJUSTING VALVE SPACER	Spare Part	369	15%
4885	CC1.002.012.0.00	VALVE COLLET	Spare Part	169	15%
4886	CC1.002.013.0.00	VALVE SPRING SEAT	Spare Part	252	15%
4887	CC1.002.014.0.00	VALVE SPRING	Spare Part	480	15%
4888	CC1.002.015.0.00	VALVE GUIDE OIL SEAL	Spare Part	271	15%
4889	CC1.002.016.0.00	VALVE SPRING WASHER	Spare Part	132	15%
4890	CC1.002.021.0.00	INTAKE VALVE	Spare Part	1225	15%
4891	CC1.002.022.0.00	EXHAUST VALVE	Spare Part	1200	15%
4892	CC1.002.042.0.00	ROCKER COVER GASKET	Spare Part	95	15%
4893	CC1.002.10.0.00	ROCKER COVER ASSEMBLY	Spare Part	2529	15%
4894	CC1.002.20.0.00	ROCKER ARM ASSEMBLY	Spare Part	2729	15%
4895	CC1.002.30.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	16178	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
4896	CC1.003.007.0.00	BEARING 6203	Spare Part	689	15%
4897	CC1.003.020.0.00	NUT: FLYWHEEL	Spare Part	326	15%
4898	CC1.003.021.0.00	FLYWHEEL GEAR RING: ELECT STARTER	Spare Part	2815	15%
4899	CC1.003.022.0.00	SLEEVE FOR FUEL PUMP	Spare Part	431	15%
4900	CC1.003.023.0.00	PUSH ROD	Spare Part	926	15%
4901	CC1.003.024.0.00	TAPPET	Spare Part	403	15%
4902	CC1.003.029.0.00	CON ROD BEARING	Spare Part	1345	15%
4903	CC1.003.040.0.00	CON ROD ASSLY	Spare Part	5541	15%
4904	CC1.003.10.0.00	PISTON ASSEMBLY	Spare Part	5498	15%
4905	CC1.003.40.0.00	BALANCING SHAFT ASSLY	Spare Part	3409	15%
4906	CC1.003.42.0.00	FLYWHEEL ALTERNATOR ROTOR	Spare Part	3640	15%
4907	CC1.003.43.0.00	FLYWHEEL ALTERNATOR STATOR COIL	Spare Part	4083	15%
4908	CC1.003.44.0.00	FLYWHEEL ALTERNATOR SCREW M6	Spare Part	37	15%
4909	CC1.003.50.0.00	CRANKSHAFT AND GEAR ASSLY	Spare Part	16729	15%
4910	CC1.003.60.0.00	FLYWHEEL ASSEMBLY	Spare Part	24892	15%
4911	CC1.003.70.0.00	CAMSHAFT ASSLY	Spare Part	8218	15%
4912	CC1.004.023.0.00	FUEL CONTROLLER	Spare Part	286	15%
4913	CC1.004.10.0.00	OIL PUMP DRIVING GEAR ASSEMBLY	Spare Part	1388	15%
4914	CC1.004.20.0.00	FORK LEVER ASSEMBLY	Spare Part	1277	15%
4915	CC1.004.30.0.00	SPEED CONTROL HANDLE ASSEMBLY	Spare Part	926	15%
4916	CC1.004.40.0.00	LUB OIL PUMP ASSEMBLY	Spare Part	852	15%
4917	CC1.004.50.0.00	OIL FILTER	Spare Part	269	20%
4918	CC1.005.10.0.00	WIND LEADING CASE ASSEMBLY	Spare Part	4255	15%
4919	CC1.005.28.0.00	FLANGE BOLT M8X1.25X25-8.8	Spare Part	25	15%
4920	CC1.005.29.0.00	FLANGE BOLT M8X1.25X15-8.8	Spare Part	15	15%
4921	CC1.005.37.0.00	FLANGE BOLT M5X0 8X15 8 8	Spare Part	15	15%
4922	CC1.006.003.0.00	AIR CLEANER GASKET	Spare Part	46	15%
4923	CC1.006.008.0.00	AIR FILTER ELEMENT	Spare Part	1237	20%
4924	CC1.006.013.0.00	EXTENSION PIPE	Spare Part	677	15%
4925	CC1.006.014.0.00	AIR FILTER HOSE PIPE	Spare Part	655	15%
4926	CC1.006.026.0.00	INLET MANIFOLD GASKET	Spare Part	298	15%
4927	CC1.006.027.0.00	INLET MANIFOLD	Spare Part	1422	15%
4928	CC1.006.035.0.PR	INLET MANIFOLD FLAME HEATER ARRANGEMENT	Spare Part	3163	15%
4929	CC1.006.10.0.00	INLET MANIFOLD	Spare Part	1517	15%
4930	CC1.006.110.0.00	AIR CLEANER ASSEMBLY	Spare Part	3492	15%
4931	CC1.006.28.0.PR	AIR INLET MANIFOLD WITH BUSH	Spare Part	1397	15%
4932	CC1.006.32.0.PR	GASKET	Spare Part	52	15%
4933	CC1.006.36.0.PR	GASKET	Spare Part	668	15%
4934	CC1.006.80.0.00	COLD STARTING KIT FOR KCC GENSET MINUS 10 DEGREE	Spare Part	14391	15%
4935	CC1.006.90.0.PR	COLD STARTING ELECTRICAL KIT FOR KCC GENSET MINUS 10 DEGREE	Spare Part	11858	15%
4936	CC1.008.001.0.00	FUEL FILTER WIRE MESH TYPE	Spare Part	686	20%
4937	CC1.009.25.0.PR	ROTOR REAR FAN BUSH	Spare Part	1135	15%
4938	CC1.010.002.0.00	FUEL TANK CAP	Spare Part	535	15%
4939	CC1.010.005.0.00	FUEL GAUGE WITH GASKET	Spare Part	689	15%
4940	CC1.010.007.0.00	FUEL FILTER	Spare Part	554	20%
4940	CC1.010.007.0.00	HOSE CLIP n16	Spare Part	86	15%
4941	CC1.010.014.0.00	HOSE CLIP IN6	Spare Part	62	15%
4943	CC1.010.016.0.00	RUBBER RING GASKET	Spare Part	169	15%
4943	CC1.010.016.0.00	RUBBER WINDOW	Spare Part	182	15%
4945	CC1.010.021.0.00	FUEL PIPE ID 7, OD 15, L 50 MM	Spare Part	37	15%
4946	CC1.010.022.0.00	FUEL PIPE ID 7, OD 15,L 130 MM	Spare Part	77	15%
4947 4948	CC1.010.023.0.00	T-JOINT	Spare Part	209	15%
/14/18	CC1.010.031.0.00	FUEL PIPE ID 5, OD 10,L 175 MM	Spare Part	83	15%
4949	CC1.010.032.0.00	FUEL PIPE ID 7, OD 15, L 400 MM	Spare Part	240	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
4951	CC1.010.056.0.PR	FUEL PIPE FROM TANK TO FILTER	Spare Part	388	15%
4952	CC1.010.057.0.PR	FUEL PIPE FROM FILTER TO T JOINT	Spare Part	554	15%
4953	CC1.010.058.0.PR	FUEL PIPE FROM T JOINT TO ENGINE	Spare Part	440	15%
4954	CC1.010.059.0.PR	AIR VENT PIPE FROM T JOINT TO FUEL TANK	Spare Part	212	15%
4955	CC1.010.060.0.PR	T JOINT	Spare Part	458	15%
4956	CC1.010.20.0.00	FUEL TANK SUB ASSEMBLY WITH CAP	Spare Part	8163	15%
4957	CC1.010.72.0.PR	SPECIAL BANJO BOLT	Spare Part	409	15%
4958	CC1.010.80.0.00	FUEL TANK WITH STRAINER	Spare Part	5529	15%
4959	CC1.012.001.0.00	12V DC, 32Ah, Lead Acid Kirloskar Green Battery	Battery	7716	15%
4960	CC1.013.06.0.PR	ANTI VIBRATION MOUNT P MOUNT P 1B WHITE P 503	Spare Part	471	15%
4961	CC1.013.10.0.00	FIXED WHEEL ASSLY	Spare Part	1234	15%
4962	CC1.013.20.0.00	CASTOR WHEEL ASSLY	Spare Part	1372	15%
4963	CC1.013.40.0.00	ANTI VIBRATION MOUNTS: C'CHILII CPCBII	Spare Part	1049	15%
4964	CC1.014.009.0.00	FIP ADJUSTING GASKET: 0.5	Spare Part	58	15%
4965	CC1.014.011.0.00	SEALING PLATE GASKET	Spare Part	25	15%
4966	CC1.014.012.0.00	HIGH PRESSURE PIPE	Spare Part	1077	15%
4967	CC1.014.014.0.00	SOLENOID BASE	Spare Part	1228	15%
4968	CC1.014.016.0.00	SOLENOID COIL	Spare Part	3785	15%
4969	CC1.014.019.0.00	FUEL INJECTOR STUD M6X1X50	Spare Part	142	15%
4970	CC1.014.021.0.00	FUEL INJ PUMP ASSLY	Spare Part	46	15%
4971	CC1.014.022.0.00	FUEL INJ PUMP ASSLY	Spare Part	68	15%
4972	CC1.014.023.0.00	FUEL INJECTOR ADJUSTING GASKET	Spare Part	83	15%
4973	CC1.014.40.0.00	SOLENOID ASSLY	Spare Part	4606	15%
4974	CC1.015.10.0.00	FUEL PIPING ASSEMBLY	Spare Part	3431	15%
4975	CC1.016.012.0.00	CATCON BOX WITH FOAM	Spare Part	6569	15%
4976	CC1.016.013.0.00	CATCON BOX COVER WITH FOAM	Spare Part	3871	15%
4977	CC1.016.016.0.00	ENGINE TOP COWL	Spare Part	6135	15%
4978	CC1.016.017.0.00	ENGINE FOR COWL	Spare Part	6366	15%
4979	CC1.016.034.0.00	KEY TYPE LOCK: SMALL	Spare Part	677	15%
4980	CC1.016.034.0.00	SNAP TYPE LOCK-POLYMIDE SLIDE LATCH		378	15%
4980	CC1.018.20.0.00	COWLING ASSEMBLY	Spare Part Spare Part	1825	15%
4981	CC1.018.20.0.00 CC1.020.001.0.00	32AMP PLUG 2P + E	Spare Part	2378	15%
					15%
4983	CC1.022.03.0.PR	FUEL LEVEL SENSOR SAM MAKE HIGHT 132MM	Spare Part	2766	
4984	CC1.073.02.0.00	FUEL FEED PUMP	Spare Part	4818	15%
4985	CC1.073.03.0.PR	ELECTRIC FUEL PUMP BOSCH P N A 580 062 448 HEAD GASKET 0.1 MM.	Spare Part	21763	15%
4986	CC1.099.006.0.00	HEAD GASKET 0.2 MM.	Spare Part	89	15% 15%
4987	CC1.099.007.0.00		Spare Part	169	
4988	CC1.099.010.0.00	CHARGING RECTIFIER	Spare Part	2622	15%
4989	CC1.099.011.0.00	CHARGING MAGNETO	Spare Part	7797	15%
4990	CC1.099.013.0.00	INLET GASKET AIR FILTER	Spare Part	38	20%
4991	CC1.099.019.0.00	PUSH ROD	Spare Part	677	15%
4992	CC1.099.021.0.00	INLET VALVE ASSLY	Spare Part	1369	15%
4993	CC1.099.022.0.00	EXHAUST VALVE	Spare Part	1409	15%
4994	CC1.1010.10	BARE ENGINE WO EXH CPCBII	Spare Part	156607	15%
4995	CC1.108.01.0.PR	FLAME HEATER	Spare Part	1505	15%
4996	CC1.120.002.0.00	0-300 VAC ANALOGUE VOLTMETER	Spare Part	2422	15%
4997	CC1.120.05.0.00	32AMP SOCKET 2P E	Spare Part	3960	15%
4998	CC1.120.09.0.00	HOUR METER 230V AC: C'CHILI	Spare Part	3135	15%
4999	CC1.120.14.0.00	WIRING HARNESS FROM ENGINE TO PANEL FOR CHHOTA CHILLI	Spare Part	2548	15%
5000	CC1.120.29.0.00	MCB: 17.5A 1 POLE POWER ON/OFF	Spare Part	1437	15%
5001	CC1.120.33.0.PR	6A 12V DC BATTERY CHARGER NHP MAKE	Spare Part	5151	15%
5002	CC1.120.48.0.00	5A 12V DC BATTERY CHARGER NHP MAKE	Spare Part	4228	15%
5003	CC1.120.52.0.00	LOAD ON LAMP	Spare Part	215	15%
5004	CC1.120.61.0.00	KEY LOCK SWITCH	Spare Part	1080	15%
5005	CC1.121.004.0.00	AVR C'CHILLI ALTERERNATOR 5KVA	Spare Part	4320	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
5006	CC1.121.11.0.00	5KVA ALTERNATOR ROTOR	Spare Part	40483	15%
5007	CC1.121.15.0.00	ALTERNATOR REAR FRAME FOR CHHOTA CHILLI	Spare Part	3978	15%
5008	CC1.121.17.0.00	ALTERNATOR FAN: CHOTA CHILI	Spare Part	2455	15%
5009	CC1.121.29.0.00	BEARING 6204	Spare Part	1468	15%
5010	CC1.121.38.0.00	ROTOR SET BOLT M10x1.25x260	Spare Part	2108	15%
5011	CC1.121.42.0.00	ALTERNATOR FRONT FRAME	Spare Part	3089	15%
5012	CC1.121.44.0.00	5KVA ALTERNATOR CARBON BUSH	Spare Part	335	15%
5013	CC1.121.53.0.00	ROTOR REAR FAN	Spare Part	415	15%
5014	CC1.121.64.0.PR	AVR MODEL AV 132 S	Spare Part	16649	15%
5015	CC1.121.67.0.PR	AVR MODEL DSR MAKE MECCALTE	Spare Part	23818	15%
5016	CC1.122.05.0.00	16 AMP SOCKET 2P E GIC MAKE	Spare Part	2738	15%
5017	CC1.122.06.0.00	16 AMP PLUG 2P E GIC MAKE	Spare Part	2138	15%
5018	CC1.130.05.0.00	6A/10A TOGGLE SWITCH FOR DC SUPPLY ON/ OFF	Spare Part	486	15%
5019	CC1.130.30.0.00	5KVA KCC AMF PANEL ASSEMBLY	Spare Part	27215	15%
5020	CC1.150.53.0.PR	12V 2A BATTERY CHARGER WITH INPUT OUTPUT LEADS	Spare Part	4981	15%
5021	CC1.151.06.0.SPR	EXHAUST SYSTEM FOR CC 418 ENGINE	Spare Part	10809	15%
5022	CC1.151.11.0.PR	EXHAUST SILENCER FOR CHOTTA CHILLI	Spare Part	10400	15%
5023	CC1.151.13.0.00	EXHAUST GASKET	Spare Part	77	15%
5024	CC1.151.16.0.00	EXHAUST GASKET ENGINE SIDE	Spare Part	83	15%
5025	CC1.151.21.0.00	EXPANSION BELLOW	Spare Part	8628	15%
5026	CC1.151.23.0.00	EXHAUST GASKET	Spare Part	46	15%
5027	CC1.151.66.0.PR	EXHAUST SILENCER UPPER FOR CHOTTA CHILLI	Spare Part	21006	15%
5028	CC1.151.75.0.PR	LOWER SILENCER ASSLY	Spare Part	8474	15%
5029	CC1.151.76.0.PR	UPPER SILENCER ASSLY	Spare Part	8449	15%
5030	CC1.151.99.0.PR	GASKET GRAPHITE	Spare Part	92	15%
5031	CC1.153.03.0.PR	5KVA BRUSHLESS ALTERNATOR S F CC418 ENGINE	Spare Part	125128	15%
5032	CC1.153.10.0.00	ALTERNATOR ASSLY	Spare Part	77150	15%
5033	CC1.153.20.0.00	ALTERNATOR FOR ROTOR ASSEMBLY FOR CHHOTA CHILLI	Spare Part	51144	15%
5034	CC1.153.30.0.00	5KVA ALTERNATOR STATOR ASSEMBLY	Spare Part	47698	15%
5035	CC1.153.33.0.00	RECTIFIER SUITABLE FOR ALTERNATOR CC1 153 03 0 PR	Spare Part	6840	15%
5036	CC1.153.34.0.00	RECTIFIER SUITABLE FOR ALTERNATOR CC1 153 03 0 PR	Spare Part	6840	15%
5037	CC1.153.36.0.00	MOV SUITABLE FOR ALTERNATOR CC1 153 03 0 PR	Spare Part	785	15%
5038	CC1.153.40.0.00	CONNECTOR PLATE ASSEMBLY	Spare Part	582	15%
5039	CC1.156.20.0.00	ALTERNATOR ASSEMBLY	Spare Part	69544	15%
5040	CC1.175.10.8.00	CANOPY FOR 5kVA CHHOTA CHILLI DIESEL FABRICATION PARTS WITH FOAM LOCKS	Spare Part	91811	15%
5041	CC1.175.32.0.00	5 KVA DIESEL STD FRONT DOOR ASSLY	Spare Part	6495	15%
5042	CC1.175.36.0.00	5 KVA DIESEL STD RH PANEL ASSY	Spare Part	6772	15%
5043	CC1.180.20.0.PR	BATTERY CABLE ASSY FOR 5KVA CHHOTA CHILLI GENSET	Spare Part	3966	15%
5044	CC1.190.06.0.00	INJECTOR	Spare Part		15%
5045	CC1.190.11.0.00	FUEL INJ PUMP: CC 418	Spare Part	8185	15%
5046	CC1.190.25.0.00	FUEL OVERFLOW CONNECTION FOR INJECTOR	Spare Part	375	15%
5047	CC1.191.30.0.00	PISTON RING SET	Spare Part		15%
5048	CC1.193.01.0.00	STARTER 12V	Spare Part	15855	15%
5049	CC1.193.02.0.00	ADAPTOR: CHOTA CHILLI	Spare Part	1489	15%
5050	CC1.196.10.0.00	RECOIL STARTER ASSEMBLY	Spare Part	5074	15%
5051	CC1.300.01.0.00	FLANGE BOLT M6X1X30	Spare Part		15%
5052	CC1.300.24.0.00	GAS SPRING 600N	Spare Part		20%
5053	CC3.001.006.0.00	REAR OIL SEAL	Spare Part	388	15%
5054	CC3.001.010.0.00	BALL BEARING	Spare Part	342	15%
5055	CC3.001.010.0.00	CYLINDER HEAD STUD (SHORT)	Spare Part	142	15%
		RECTANGLE RING GASKET 4.5X2.2	Spare Part	234	15%
5056	CC3.001.017.0.00	+	Spare Part	455	15%
5057	CC3.001.025.0.00 CC3.001.026.0.00	CRANKCASE COVER GASKET BALL BEARING	Spare Part	766	15%
5058	CC3.001.026.0.00 CC3.001.032.0.00		· ·		15%
	1003.001.032.0.00	FRONT OIL SEAL	Spare Part	388	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer	Custom
				without Vat in NPR	Charge%
5061	CC3.002.003.0.00	INTAKE VALVE	Spare Part	569	15%
5062	CC3.002.004.0.00	EXHAUST VALVE	Spare Part	569	15%
5063	CC3.002.017.0.00	ROCKER ARM	Spare Part	803	15%
5064	CC3.002.018.0.00	ADJUSTING VALVE SPACER	Spare Part	382	15%
5065	CC3.002.019.0.00	VALVE COLLET	Spare Part	62	15%
5066	CC3.002.020.0.00	VALVE SPRING SEAT	Spare Part	126	15%
5067	CC3.002.022.0.00	VALVE GUIDE OIL SEAL	Spare Part	228	15%
5068	CC3.002.20.0.00	ROCKER ARM ASSEMBLY	Spare Part	1406	15%
5069	CC3.002.30.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	10188	15%
5070	CC3.003.001.0.00	ROCKER COVER GASKET	Spare Part	68	15%
5071	CC3.003.040.0.00	CON ROD ASSLY	Spare Part	2806	15%
5072	CC3.004.10.0.00	LUB OIL PUMP ASSEMBLY	Spare Part	1028	15%
5073	CC3.004.20.0.00	OIL PUMP DRIVING GEAR ASSEMBLY	Spare Part	929	15%
5074	CC3.004.30.0.00	FORK LEVER ASSEMBLY	Spare Part	751	15%
5075	CC3.005.009.0.00	CONNECTING ROD BEARING	Spare Part	258	15%
5076	CC3.005.10.0.00	PISTON ASSEMBLY	Spare Part	3415	15%
5077	CC3.005.30.0.00	PISTON RING SET	Spare Part	972	15%
5078	CC3.006.009.0.00	BALL BEARING	Spare Part	1351	15%
5079	CC3.006.011.0.00	FLYWHEEL GEAR RING	Spare Part	1988	15%
5080	CC3.006.10.0.00	BALANCING SHAFT ASSLY	Spare Part	2298	15%
5081	CC3.006.21.0.00	INLET MANIFOLD GASKET	Spare Part	363	15%
5082	CC3.007.001.0.00	PUSH ROD	Spare Part	782	15%
5083	CC3.007.002.0.00	TAPPET	Spare Part	372	15%
5084	CC3.007.10.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	4948	15%
5085	CC3.007.20.0.00	CRANKSHAFT AND GEAR ASSLY	Spare Part	11304	15%
5086	CC3.008.001.0.00	AIR FILTER HOSE PIPE	Spare Part	1391	15%
5087	CC3.008.004.0.00	AIR CLEANER GASKET	Spare Part	52	15%
5088	CC3.008.008.0.00	AIR FILTER ELEMENT	Spare Part	545	20%
5089	CC3.008.015.0.00	EXTENSION PIPE	Spare Part	575	15%
5090	CC3.012.014.0.00	OIL SEAL	Spare Part	163	15%
5091	CC3.012.015.0.00	FUEL CONTROLLER	Spare Part	243	15%
5092	CC3.013.08.0.PR	ANTI VIBRATION MOUNT P MOUNT P 1A BLUE P 503	Spare Part	514	15%
5093	CC3.015.20.0.00	RECOIL STARTER ASSMBLY	Spare Part	5046	15%
5094	CC3.017.20.0.00	ENGINE SPEED CONTROL ASSEMBLY	Spare Part	1105	15%
5095	CC3.1010.10	3KVA DISEL BARE ENGINE (WITHOUT EXHAUST SYSTEM)	Spare Part	145561	15%
5096	CP1.002.02.0.00	CRANKCASE COVER GASKET	Spare Part	1129	15%
5097	CP1.002.10.0.00	CRANKCASE COVER ASSEMBLY	Spare Part	16886	15%
5098	CP1.003.05.0.00	CYLINDER HEAD GASKET	Spare Part		15%
5099	CP1.003.10.0.00	CYLINDER HEAD ASSEMBLY	Spare Part		15%
5100	CP1.003.13.0.00	CYLINDER COVER GASKET	Spare Part		15%
5101	CP1.004.10.0.00	FLYWHEEL ASSEMBLY	Spare Part		15%
5102	CP1.005.10.0.00	PISTON ASSLY	Spare Part		15%
5103	CP1.005.20.0.00	PISTON RING SET: STD	Spare Part	2323	15%
5104	CP1.005.30.0.00	CONNECTING ROD ASSY	Spare Part	3305	15%
5105	CP1.005.40.0.00	CRANKSHAFT ASSEMBLY	Spare Part	14464	15%
5106	CP1.006.10.0.00	STARTER MOTOR	Spare Part	14904	15%
5107	CP1.007.09.0.00	PUSHER	Spare Part		15%
5108	CP1.007.15.0.00	INTAKE VALVE	Spare Part		15%
5109	CP1.007.16.0.00	EXHAUST VALVE	Spare Part		15%
5110	CP1.007.10.0.00	ROCKER ARM ASSEMBLY	Spare Part	4769	15%
5111	CP1.007.20.0.00	CARBURETOR ASSEMBLY	Spare Part		15%
5111	CP1.010.10.0.00	CARBURETTOR REAR GASKET	Spare Part		15%
5112	CP1.010.23.0.00	CARBURETTOR FRONT GASKET	Spare Part		15%
	CP1.010.24.0.00 CP1.010.25.0.00	CARBURETTOR METAL GASKET	Spare Part	1000	15%
5114			·		
5115	CP1.011.20.0.SPR	CATCON AND CATCON PIPE ASSEMBLY	Spare Part	7255	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
31.110.	Part Number	Fait Description	Category	without Vat in	Charge%
5116	CP1.027.10.0.00	IGNITION COIL ASSEMBLY	Spare Part	NPR 4452	15%
5117	CP1.1001	ENGINE MODEL CCP389 G1 CYLINDERS ONE COOLING AIR ENGINE RATING 9 3HP MAX OUTPL	Spare Part	129484	15%
5118	D1.005.03.0.00	SMALL END BUSH-DM10.	Spare Part	514	15%
5119	D1.008.02.0.00	JOINT RING: LINER DM10	Spare Part	55	15%
5120	D1.011.40.0.00	CRANKSHAFT ASSLY: DM10	Spare Part	16880	15%
5121	D1.035.10.0.00	CON.ROD ASSLY-DM10(70 MM PIN)	Spare Part	7351	15%
5122	D1.131.01.0.00	FUEL PUMP BRACKET	Spare Part	1803	15%
5123	D1.131.02.0.00	FUEL PUMP TAPPET PLUNGER:EW10	Spare Part	188	15%
5124	D1.131.03.0.00	F.P.ROCKER LEVER	Spare Part	889	15%
5125	D1.131.04.0.00	ROLLER	Spare Part	163	15%
5126	D1.131.05.0.00	ROLLER PIN	Spare Part	95	15%
5127	D1.131.10.0.00	ASSEMBLY OF FPR LEVER - EW10	Spare Part	2157	15%
5128	D1.133.09.0.00	JOINT: ROCKER COVER	Spare Part	295	15%
5129	D1.134.20.0.00	PISTON ASSEMBLY	Spare Part	5646	15%
5130	D1.134.30.0.00	PISTON RING SET - EW10,3 RV	Spare Part	2145	15%
5131	D1.134.40.0.00	PISTON RING SET-EA10 102.12	Spare Part	1542	15%
5132	D1.134.50.0.00	PISTON ASSEMBLY: EA10 WITH RING SET 102.12	Spare Part	5843	15%
5133	D1.135.02.0.00	GASKET: CYLINDER HEAD EW10	Spare Part	172	15%
5134	D1.135.03.9.00	VALVE GUIDE SEMI FINISH EW10	Spare Part	135	15%
5135	D1.135.18.0.00	CYLINDER HEAD GASKET	Spare Part	520	15%
5136	D1.138.01.0.00	VALVE PUSH ROD	Spare Part	200	15%
5137	D1.139.01.0.00	AIR INLET MANIFOLD	Spare Part	2012	15%
5138	D1.139.03.0.00	JOINT: AIR INLET M'FOLD-EW10	Spare Part	62	15%
5139	D1.140.03.0.00	GASKET: EXHAUST EW10	Spare Part	157	15%
5140	D1.148.20.0.00	FULCRUM BRACKET ASSLY: EW10	Spare Part	1145	15%
5141	D1.311.10.0.00	CYL LINER ASSEMBLY-EW10	Spare Part	4375	15%
5142	D1.314.01.0.00	ANTI VIBRATION MOUNTS	Spare Part	2458	15%
5143	D1.314.02.0.00	ANTI VIBRATION MOUNTS	Spare Part	1600	15%
5144	D1.316.05.0.00	BUSH FOR AVM LOCKING S F 90 CRS AVMs	Spare Part	163	15%
5145	D1.317.40.0.00	SET OF JOINTS	Spare Part	2142	15%
5146	D1.318.60.0.00	PISTON ASSEMBLY: EW24	Spare Part	6175	15%
5147	D1.326.01.0.00	FUEL PIPE: FEED PUMP TO FUEL FILTER	Spare Part	1557	15%
5148	D1.326.02.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	1058	15%
5149	D1.328.10.0.00	GEAR PUMP ASSEMBLY WITH RELIEF VALVE	Spare Part	4225	15%
5150	D1.329.10.0.00	MB HSG + BRG ASSEMBLY GE - EW10	Spare Part	1982	15%
5151	D16.001.31.0.PR	JOINT FOR CORE WINDOW 120 CRS 6 HOLES	Spare Part	935	15%
5152	D16.001.32.0.PR	JOINT FOR CORE WINDOW 100 CRS 6 HOLES	Spare Part	375	15%
	D16.001.36.0.PR	FERRUL TUBE FOR PUSH ROD	Spare Part	505	15%
	D16.001.39.0.PR	NOZZLE BODY	Spare Part	10828	15%
5155	D16.001.48.0.00	SEALING RING (FOR PUSH ROD)	Spare Part	228	15%
	D16.003.20.0.PR	CRANK SHAFT ASSLY	Spare Part	1086592	15%
5157	D16.007.150.0.PR	CYLINDER HEAD ASSEMBLY COMPLETE	Spare Part	273578	15%
5158	D16.012.02.0.00	JOINT FOR OIL SEAL HOUSING	Spare Part	1895	15%
	D16.012.02.0.PR	JOINT FOR OIL SEAL HOUSING	Spare Part	1843	15%
5160	D16.013.30.0.PR	LUB OIL PUMP SUB ASSLY 100MM WIDE	Spare Part	130927	15%
	D16.014.05.0.00	FUELPIPE(FUELPUMPTOMAINFILTER)(LHFROMGE)	Spare Part	1274	15%
5162	D16.014.12.0.PR	OIL COOLER	Spare Part	20270	15%
5163	D16.014.14.0.00	O RING FOR RELIEF VALVE BODY	Spare Part	1274	15%
	D16.014.15.0.PR	JOINT FOR LUB OIL HEADER RH	Spare Part	1274	15%
5165	D16.014.21.0.PR	O RING FOR RELIEF VALVE BODY	Spare Part	314	15%
5166	D16.014.22.0.PR	JOINT FOR OIL FILTER ADAPTOR	Spare Part	102	15%
E107	D16.016.03.0.00	O RING FOR W.P. HOUSING	Spare Part	68	15%
5167		IOINT DETWEEN WATER RUMP. THERMOSTAT COVER	O D	00.40	450/
5167 5168 5169	D16.016.04.0.PR D16.016.100.0.PR	JOINT BETWEEN WATER PUMP THERMOSTAT COVER WATER PUMP ASSEMBLY	Spare Part Spare Part	2049 42049	15% 15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
5171	D16.016.26.0.PR	JOINT FOR PLATE W P HOUSING RH	Spare Part	188	15%
5172	D16.016.29.0.PR	JOINT FOR PLATE WATER PUMP HOUSING LH	Spare Part	188	15%
5173	D16.017.14.0.PR	LUB OIL SUMP FABRICATED	Spare Part	126451	15%
5174	D16.017.18.0.00	JOINT FOR OIL FILLING BODY	Spare Part	126	15%
5175	D16.017.50.0.PR	DIPSTICK ASSEMBLY DIPSTICK WITH ADAPTOR	Spare Part	1228	15%
5176	D16.021.15.0.00	RAIL ASSLY 1 LH VIEW FROM PULLEY END	Spare Part	237785	15%
5177	D16.021.150.0.PR	HP PIPE ASSEMBLY RAIL TO CYLINDER NO 9 13	Spare Part	6080	15%
5178	D16.021.160.0.PR	HP PIPE ASSEMBLY RAIL TO CYLINDER NO 10 14	Spare Part	6080	15%
5179	D16.021.170.0.PR	HP PIPE ASSEMBLY RAIL TO CYLINDER NO 11 15	Spare Part	6080	15%
5180	D16.021.180.0.PR	HP PIPE ASSEMBLY RAIL TO CYLINDER NO 12 16	Spare Part	6080	15%
5181	D16.021.210.0.PR	HP PIPE ASSEMBLY PUMP TO RAIL LHS	Spare Part	7157	15%
5182	D16.021.25.0.00	RAIL ASSLY 2 LH from pulley end	Spare Part	262344	15%
5183	D16.021.34.0.PR	HP PIPE RAIL TO CYLINDER NO 1 16	Spare Part	29993	15%
5184	D16.021.35.0.00	RAIL ASSLY 1 RH FROM PULLEY END	Spare Part	239711	15%
5185	D16.021.36.0.PR	HP PIPE RAIL TO CYLINDER NO 2 15	Spare Part	15951	15%
5186	D16.021.37.0.PR	HP PIPE RAIL TO CYLINDER NO 3 14	Spare Part	15951	15%
5187	D16.021.38.0.PR	HP PIPE RAIL TO CYLINDER NO 4 13	Spare Part	15717	15%
5188	D16.021.39.0.00	HP PIPE RAIL TO CYLINDER NO 5 12	Spare Part	15861	15%
5189	D16.021.41.0.00	HP PIPE (RAIL TO CYLINDER NO. 6 & 11)	Spare Part	19427	15%
5190	D16.021.42.0.00	HP PIPE RAIL TO CYLINDER NO 8 9	Spare Part	15618	15%
5191	D16.021.43.0.PR	HP PIPE RAIL TO CYLINDER NO 7 10	Spare Part	15951	15%
5192	D16.021.44.0.PR	HP PIPE PUMP TO RAIL LHS	Spare Part	22123	15%
5193	D16.021.45.0.00	RAIL ASSLY 2 RH FROM PULLET END	Spare Part	239135	15%
5194	D16.021.46.0.PR	HP PIPE PUMP TO RAIL RHS	Spare Part	21766	15%
5195	D16.021.47.0.00	HP PIPE (BALANCING PIPE)	Spare Part	21184	15%
5196	D16.021.48.0.00	RAIL CONNECTION	Spare Part	9929	15%
5197	D16.021.49.0.00	CLAMP FOR HP PIPE (PUMP TO RAIL) (MNTG. ON RAIL CLAMP)	Spare Part	686	15%
5198	D16.021.55.0.PR	HP PIPE FIP TO RAIL RH SIDE	Spare Part	93291	15%
5199	D16.021.56.0.PR	HP PIPE FIP TO RAIL LH SIDE	Spare Part	93291	15%
5200	D16.021.91.0.PR	RAIL ASSEMBLY 1 PULLEY END	Spare Part	75168	15%
5201	D16.021.92.0.PR	RAIL ASSEMBLY 2 FLYWHEEL END	Spare Part	75168	15%
5202	D16.022.102.0.00	FUEL PIPE FUEL PUMP TO MAIN FILTER LH FROM GE	Spare Part	7551	15%
5203	D16.022.103.0.PR	FUEL PIPE FUEL PUMP TO MAIN FILTER RH FROM GE	Spare Part	7941	15%
5204	D16.022.112.0.00	FUEL PIPE PRE FILTER TO MAIN FILTER COMMON	Spare Part	9391	15%
5205	D16.022.114.0.00	DEAIRAZATION PIPE	Spare Part	15575	15%
5206	D16.022.139.0.PR	FUEL PIPE PUMP LEAK OFF L H FROM G E	Spare Part	8769	15%
5207	D16.022.141.0.00	FUEL PIPE PUMP LEAK OFF PIPE R H FROM GE	Spare Part	6523	15%
5208	D16.023.01.0.PR	INLET MANIFOLD L H GEAR END	Spare Part	31406	15%
5209	D16.023.03.0.00	INLET MANIFOLD R H GEAR END	Spare Part	27747	15%
5210	D16.023.13.0.PR	SLEEVE FOR INLET MANIFOLD DIA 94	Spare Part	2658	15%
5211	D16.023.15.0.00	JOINT FOR COVER PLATE	Spare Part	609	15%
5212	D16.023.18.0.PR	BANJO BOLT	Spare Part	351	15%
5213	D16.023.28.0.PR	O RING FOR INLET MANIFOLD ADAPTOR SLEEVE DIA 104	Spare Part	105	15%
5214	D16.023.29.0.PR	O RING FOR INLET MANIFOLD SLEEVE DIA 94	Spare Part	95	15%
5215	D16.023.31.0.00	JOINT BET. INLET MANIFOLD & CYL HEAD	Spare Part	222	15%
5216	D16.023.35.0.00	O RING FOR DOME NUT	Spare Part	234	15%
5217	D16.023.43.0.00	SLEEVE FOR INLET MANIFOLD DIA 117	Spare Part	1902	15%
5218	D16.023.44.0.00	O RING FOR INLET MANIFOLD ADAPTOR SLEEVE (DIA 117)	Spare Part	163	15%
5219	D16.023.46.0.PR	JOINT FOR INLET MANIFOLD	Spare Part	1135	15%
5220	D16.023.48.0.00	JOINT FOR INLET MANIFOLD R H	Spare Part	2323	15%
	D16.023.48.0.00	JOINT FOR INLET MANIFOLD L H	Spare Part Spare Part	2323	15%
5221			·		15%
5222	D16.024.12.0.00	EXHAUST MANIFOLD	Spare Part	9338	
5223 5224	D16.024.13.0.00	EXHAUST MANIFOLD (RH, LH 2 PORT)	Spare Part	9477	15%
5/1/1	D16.024.14.0.00	EXHAUST MANIFOLD (2 PORT)	Spare Part	9483	15%



1927 10.002.45.00.00 EPAPASION BELLOW 3 MM Spure Part 6645 1.9	Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
SEASON 100 SEASON 100 SEASON SELLOW SIM 5645 100 1						
1922 1910.04.4.2.PR						15%
BRACKET FOR TUMBO ADAPTION SOLATS Spere Pain 1577 1				•		15%
South Sout				-		15%
		D16.024.43.0.PR		Spare Part		15%
1902.05 MJ ORP 1902	5230	D16.025.02.0.00				15%
15233 151.00 15		+				15%
1928 1910.02697.000 STAPTER RING Spee Part 15968 1920						15%
5233 Infl. 2003 10 PR SENSOR RING Spore Part 5552 11 5267 70 16 009 50 0 PR AV 96W STARTER LA IS FROM FLYWHEEL END SIDE PRESTOLITE MS7 30KK Spare Part 130244 1 5267 70 16 009 50 0 PR FAN DRIVE SUB ASSEMBLY Spare Part 130244 1 5269 70 16 033 17 0 PR PIPE THERMOSTAT TO RADIATOR N Spare Part 35027 1 5260 70 16 033 17 0 PR DIG 51 17 0 PR CALMIFING BARCKET FOR THERMOSTAT PIPE Spare Part 35020 1 5261 70 16 033 17 0 PR DIG 51 17 0 PR CALMIFING BRACKET FOR THERMOSTAT PIPE Spare Part 3502 1 1 5502 1 1 5502 1 1 1 5502 1 1 5502 1 1 5502 1 1 5502 1 1 5502 1 1 5502 1 1 5502 1 1 5502 1 1 5502 1 1 5502 1 1 5502 1 1 5502	5233	D16.025.12.0.00	O RING (FOR COVER PLATE)	Spare Part	111	15%
1922 14.0 DPR	5234	D16.026.07.0.00	STARTER RING	Spare Part		15%
1823 101 6023 50.0 PR	5235	D16.026.13.0.PR	SENSOR RING	Spare Part	5532	15%
Space Part Space Part Space Part Space	5236	D16.027.14.0.PR	24V 9KW STARTER L H S FROM FLYWHEEL END SIDE PRESTOLITE MS7 304K	Spare Part	139094	15%
19.203 101.0311.50.PR	5237	D16.029.50.0.PR	FAN DRIVE SUB ASSEMBLY	Spare Part	133241	15%
1940 1940	5238	D16.031.07.0.PR	PIPE THERMOSTAT TO RADIATOR IN	Spare Part	4889	15%
September Sept	5239	D16.031.15.0.PR	COOLING FAN FOR RADIATOR	Spare Part	337251	15%
SAME Dis Dis	5240	D16.031.17.0.PR	D16 031 17 0 PR CLAMPING BRACKET FOR THERMOSTAT PIPE	Spare Part	5529	15%
5243 D16.031.61.0 PR	5241	D16.031.18.0.PR	DV2 031 18 0 PR CLAMP	Spare Part	769	15%
Search S	5242	D16.031.60.0.PR	RADIATOR FOR DV16 GENSET	Spare Part	2373787	15%
5246 D16.032.32.0.PR	5243	D16.031.61.0.PR	RECOVERY BOTTEL BRACKET(LH)	Spare Part	360	15%
5246 D16.032.36.0.00 TURBO OIL INLET PIPE (LH FROM PE) Spare Part 2055 19.003.27.0.00 TURBO OIL INLET PIPE (H FROM PE Spare Part 2157 19.003.27.0.00 TURBO OIL INLET PIPE (H FROM PE Spare Part 2157 19.003.27.0.00 TURBO OIL INLET PIPE (H FROM PE Spare Part 27935 19.003.24.0.00 JOINT FOR TURBO CHARGER Spare Part 77 19.003.24.0.00 JOINT FOR TURBO CHARGER Spare Part 77 19.003.24.0.00 JOINT FOR TURBO CHARGER Spare Part 77 19.003.24.0.00 JOINT FOR FLANGE FOR TC LUB OIL OUTLET PIPE Spare Part 3708.25 19.003.24.0.00 JURBOCHARGER ASSLY RH FROM PE Spare Part 3708.25 19.003.24.0.00 TURBOCHARGER ASSLY RH FROM PE Spare Part 3708.25 19.003.24.0.00 TURBOCHARGER ASSLY RH FROM PE Spare Part 450.0 19.003.14.0.0PR SLEEVE FOR CAC PIPE DIA 14) Spare Part 450.0 19.003.14.0.0PR SLEEVE FOR CAC PIPE DIA 24) Spare Part 215 19.003.14.0.0PR Spare Part 220 19.003.14.0.0PR Sp	5244	D16.031.62.0.PR	RECOVERY BOTTEL BRACKET(RH)	Spare Part	360	15%
5247 D16.032.37 0.00 TURBO OIL INLET PIPE RH FROM PE Spare Part 2157 15248 D16.032.38 0.00 TURBO OIL INLET PIPE RH FROM PE Spare Part 27935 15249 D16.032.38 0.00 TURBO OIL DRAIN PIPE LH FROM PE Spare Part 1132 11526 D16.032.44 0.00 JOINT FOR TURBOCHARGER Spare Part 1132 11525 D16.032.44 0.00 JOINT FOR FLANGE FOR T C LUB OIL OUTLET PIPE Spare Part 77 11525 D16.032.44 0.00 JOINT FOR FLANGE FOR T C LUB OIL OUTLET PIPE Spare Part 66 11525 D16.032.44 0.00 JOINT FOR FLANGE FOR T C LUB OIL OUTLET PIPE Spare Part 67 Spare Part 67 Spare Part 68 Spare Part 69 Sp	5245	D16.032.32.0.PR	V BAND FOR TURBINE OUT EXHAUST BEND D16 CTT TURBOCHARGER ID 127 MM	Spare Part	1255	15%
5240 D16.032.38 0.00 TURBO OIL DRAIN PIPE LIF FROM PE Spare Part 27935 1 5249 D16.032.43 0.PR JOINT FOR TURBOCHARGER Spare Part 1132 1 5250 D16.032.44 0.PR JOINT FOR TURBOCHARGER Spare Part 7 1 5251 D16.032.44 0.PR JOINT FOR FLANGE FOR TC LUB OIL OUTLET PIPE Spare Part 36 1 5252 D16.032.45 0.00 TURBOCHARGER ASSLY RIF FROM PE Spare Part 3708.33 1 5252 D16.033.31 0.DR SLEEVE FOR CAC PIPE DIA 114) Spare Part 4520 1 5253 D16.033.24 0.00 RUBBER SLEEVE Spare Part 4520 1 5256 D16.033.28 0.00 RUBBER SLEEVE Spare Part 253 1 5257 D16.033.28 0.00 JOINT Spare Part 523 1 5258 D16.033.28 0.00 JOINT Spare Part 403 2 5259 D16.033.28 0.00 TBOILT SAND CLAMPS (108 DIA) Spare Part 403 2 5259	5246	D16.032.36.0.00	TURBO OIL INLET PIPE (LH FROM PE)	Spare Part	2055	15%
5240 D16.032.38 0.00 TURBO OIL DRAIN PIPE LIF FROM PE Spare Part 27935 1 5249 D16.032.43 0.PR JOINT FOR TURBOCHARGER Spare Part 1132 1 5250 D16.032.44 0.PR JOINT FOR TURBOCHARGER Spare Part 7 1 5251 D16.032.44 0.PR JOINT FOR FLANGE FOR TC LUB OIL OUTLET PIPE Spare Part 786 1 5252 D16.032.45 0.00 TURBOCHARGER ASSLY RH FROM PE Spare Part 450 1 5252 D16.033.13 0.0PR SLEEVE FOR CAC PIPE DIA 14) Spare Part 450 1 5255 D16.033.24 0.00 RUBBER SLEEVE Spare Part 215 1 5256 D16.033.28 0.00 RUBBER SLEEVE Spare Part 215 1 5257 D16.033.33 0.00 JOINT Spare Part 702 1 5258 D16.033.33 0.00 TBOLT V BAND CLAMPS (108 DIA) Spare Part 403 2 5259 D16.033.35 0.PR O RING FOR CAC PIPE SLEEVE DIA 84 Spare Part 403 2	5247	D16.032.37.0.00	TURBO OIL INLET PIPE RH FROM PE	Spare Part	2157	15%
5249 D16.032.43.0.PR JOINT FOR TURBOCHARGER Spare Part 1132 1 5250 D16.032.44.0.00 JOINT FOR FLANGE FOR TC LUB OIL OUTLET PIPE Spare Part 77 1 5251 D16.032.44.0.00 JOINT FOR FLANGE FOR TC LUB OIL OUTLET PIPE Spare Part 370823 1 5252 D16.032.45.0.00 TURBOCHARGER ASSLY R H FROM PE Spare Part 370823 1 5253 D16.033.17.0.PR SLEEVE FOR CAC PIPE DIA 114) Spare Part 4520 1 5254 D16.033.17.0.PR SLEEVE FOR CAC PIPE DIA 84) Spare Part 313 1 5255 D16.033.19.0.PR SLEEVE FOR CAC PIPE DIA 84) Spare Part 215 1 5256 D16.033.24.0.00 RUBBER SLEEVE Spare Part 215 1 1 5259 D16.033.24.0.00 JOINT Spare Part 702 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	5248	D16.032.38.0.00			27935	15%
5250 D16.032.44.0.00 JOINT FOR FLANGE FOR TC LUB OIL OUTLET PIPE Spare Part 77 11 5251 D16.032.44.0.PR JOINT FOR FLANGE FOR TC LUB OIL OUTLET PIPE Spare Part 36 11 5252 D16.032.45.0.00 TURBOCHARGER ASSLY R H FROM PE Spare Part 4520 11 5253 D16.033.17.0.PR SLEEVE FOR CAC PIPE DIA 114) Spare Part 4520 11 5254 D16.033.16.0.PR SLEEVE FOR CAC PIPE DIA 84) Spare Part 215 11 5255 D16.033.24.0.00 RUBBER SLEEVE Spare Part 215 11 5256 D16.033.24.0.00 RUBBER SLEEVE Spare Part 523 1 5257 D16.033.24.0.00 T BOLT V BAND CLAMPS (108 DIA). Spare Part 702 1 5259 D16.033.35.0.PR O RING FOR CAC PIPE SLEEVE 114 DIA Spare Part 405 1 5269 D16.033.36.0.PR O RING FOR CAC PIPE SLEEVE DIA 84 Spare Part 465 1 5260 D16.033.37.0.PR O RING FOR CAC PIPE SLEEVE DIA 84 Spare Part		D16.032.43.0.PR	JOINT FOR TURBOCHARGER	·		15%
5251 D16.032.44 0.PR JOINT FOR FLANGE FOR TC LUB OIL OUTLET PIPE Spare Part 370823 15252 D16.032.45 0.00 TURBOCHARGER ASSLY R H FROM PE Spare Part 370823 15253 D16.033.71.0 PR SLEEVE FOR CAC PIPE DIA 114) Spare Part 4520 11.0				·		15%
5252 D16.032.45.0.00 TURBOCHARGER ASSLY R H FROM PE Spare Part 370823 11 5253 D16.033.17.0.PR SLEEVE FOR CAC PIPE DIA 114) Spare Part 4520 11 5254 D16.033.17.0.PR SLEEVE FOR CAC PIPE DIA 184) Spare Part 3163 1 5255 D16.033.24.0.00 RUBBER SLEEVE Spare Part 215 1 5256 D16.033.28.0.00 JOINT Spare Part 523 1 5257 D16.033.28.0.00 JOINT Spare Part 702 1 5258 D16.033.34.0.00 T BOLT V BAND CLAMPS (108 DIA). Spare Part 4038 2 5259 D16.033.34.0.00 T BOLT V BAND CLAMPS (108 DIA). Spare Part 4038 2 5259 D16.033.34.0.00 T BOLT V BAND CLAMPS (108 DIA). Spare Part 4038 2 5259 D16.033.35.0.PR O RING FOR CAC PIPE SLEEVE DIA 84 Spare Part 465 11 5260 D16.033.35.0.PR O RING FOR CAC PIPE SLEEVE DIA 84 Spare Part 455 11						15%
5253 D16.033.17.0.PR SLEEVE FOR CAC PIPE DIA 114) Spare Part 4520 11.						15%
Spare Part 3163 16 16 16 16 16 16						15%
Spare Part 215 15 15 15 15 15 15 1						15%
5256 D16,033,28,0,00 JOINT Spare Part 523 525			,	·		15%
5257 D16.033.28.0.PR JOINT Spare Part 702 11.						15%
5258 D16.033.34.0.00 T BOLT V BAND CLAMPS (108 DIA). Spare Part 4038 22 5259 D16.033.35.0.PR O RING FOR CAC PIPE SLEEVE 114 DIA Spare Part 465 11 5260 D16.033.35.0.PR O RING FOR CAC PIPE SLEEVE DIA 84 Spare Part 455 11 5261 D16.033.37.0.PR C CMPRESSOR OUT PIPE O RING (DV16 ? CTT TURBOCHARGER) Spare Part 326 11 5262 D16.033.38.0.00 C COMPRESSOR OUT PIPE (DV16 ? CTT TURBOCHARGER RHS FROM PE) Spare Part 7815 11 5263 D16.033.39.0.PR C COMPRESSOR OUT PIPE (DV16 ? CTT TURBOCHARGER RHS FROM PE) Spare Part 8514 11 5264 D16.033.410.PR V BAND FOR COMPRESSOR OUT PIPE D16 CTT TURBOCHARGER ID 100 MM Spare Part 1018 11 5265 D16.033.47.0.PR H OSE FOR CAC PIPE ID 138 XID 144 Spare Part 5486 11 5266 D16.033.45.0.PR H OSE FOR CAC OUT PIPE ID 138 BOTH SIDES Spare Part 225 11 5267 D16.036.05.0.PR T BOLT CLAMP FOR DIA 141 149 Spare Part 225 11		+				15%
5259 D16.033.35.0.PR O RING FOR CAC PIPE SLEEVE 114 DIA Spare Part 465 11 5260 D16.033.35.0.PR O RING FOR CAC PIPE SLEEVE DIA 84 Spare Part 455 11 5261 D16.033.37.0.PR COMPRESSOR OUT PIPE O RING (DV16 ? CTT TURBOCHARGER) Spare Part 326 11 5262 D16.033.39.0.00 COMPRESSOR OUT PIPE (DV16 ? CTT TURBOCHARGER RIS FROM PE) Spare Part 7815 15 5263 D16.033.39.0.PR COMPRESSOR OUT PIPE (DV16 ? CTT TURBOCHARGER RIS FROM PE) Spare Part 7815 15 5264 D16.033.410.PR V BAND FOR COMPRESSOR OUT PIPE D16 CTT TURBOCHARGER ID 100 MM Spare Part 1018 11 5265 D16.033.410.PR V BAND FOR CAC PIPE ID 138 X ID 144 Spare Part 5486 11 5265 D16.033.47.0.PR HOSE FOR CAC OUT PIPE ID 138 BOTH SIDES Spare Part 5486 11 5266 D16.033.55.0.PR HOST FOR LADDER IN Spare Part 225 11 5268 D16.036.07.0.00 O RING FOR LADDER OIL HOLE Spare Part 21 1				· · · · · · · · · · · · · · · · · · ·		20%
5260 D16.033.36.0.PR O RING FOR CAC PIPE SLEEVE DIA 84 Spare Part 455 1 5261 D16.033.36.0.PR COMPRESSOR OUT PIPE O RING (DV16 ? CTT TURBOCHARGER) Spare Part 326 1 5262 D16.033.38.0.00 COMPRESSOR OUT PIPE (DV16 ? CTT TURBOCHARGER RHS FROM PE) Spare Part 7815 1 5263 D16.033.38.0.PR COMPRESSOR OUT PIPE (DV16 ? CTT TURBOCHARGER LHS FROM PE) Spare Part 8514 1 5264 D16.033.41.0.PR V BAND FOR COMPRESSOR OUT PIPE D16 CTT TURBOCHARGER ID 100 MM Spare Part 1018 1 5265 D16.033.47.0.PR HOSE FOR CAC PIPE ID 138 x ID 144 Spare Part 5486 1 5266 D16.033.48.0.PR HOSE FOR CAC PIPE ID 138 BOTH SIDES Spare Part 6418 1 5267 D16.033.55.0.PR T BOLT CLAMP FOR DIA 141 149 Spare Part 225 1 5268 D16.036.08.0.PR O RING FOR LADDER NI Spare Part 71 1 5269 D16.036.08.0.PR O RING FOR LADDER OIL HOLE Spare Part 41 1 5270						15%
5261 D16.033.37.0.PR COMPRESSOR OUT PIPE O RING (DV16 ? CTT TURBOCHARGER) Spare Part 326 15 5262 D16.033.38.0.00 COMPRESSOR OUT PIPE (DV16 ? CTT TURBOCHARGER RHS FROM PE) Spare Part 7815 18 5263 D16.033.39.0.PR COMPRESSOR OUT PIPE (DV16 ? CTT TURBOCHARGER LHS FROM PE) Spare Part 8514 19 5264 D16.033.41.0.PR V BAND FOR COMPRESSOR OUT PIPE D16 CTT TURBOCHARGER ID 100 MM Spare Part 1018 11 5265 D16.033.47.0.PR HOSE FOR CAC PIPE ID 138 x ID 144 Spare Part 5466 11 5266 D16.033.48.0.PR HOSE FOR CAC OUT PIPE ID 138 BOTH SIDES Spare Part 6418 11 5267 D16.033.55.0.PR T BOLT CLAMP FOR DIA 141 149 Spare Part 225 11 5268 D16.036.07.0.00 O RING FOR LADDER IN Spare Part 22 11 5269 D16.036.08.0.PR O RING FOR LADDER OIL HOLE Spare Part 12 11 5270 D16.036.15.0.PR SLEEVE BETWEEN LADDER AND CRANKCASE Spare Part 98 11 527						15%
5262 D16.033.38.0.00 COMPRESSOR OUT PIPE (DV16 ? CTT TURBOCHARGER RHS FROM PE) Spare Part 7815 15 5263 D16.033.39.0.PR COMPRESSOR OUT PIPE (DV16 ? CTT TURBOCHARGER LHS FROM PE) Spare Part 8514 11 5264 D16.033.34.0.PR V BAND FOR COMPRESSOR OUT PIPE D16 CTT TURBOCHARGER ID 100 MM Spare Part 1018 11 5265 D16.033.47.0.PR HOSE FOR CAC PIPE ID 138 X ID 144 Spare Part 5486 11 5266 D16.033.48.0.PR HOSE FOR CAC OUT PIPE ID 138 BOTH SIDES Spare Part 6418 11 5267 D16.033.55.0.PR T BOLT CLAMP FOR DIA 141 149 Spare Part 225 11 5268 D16.036.07.0.00 O RING FOR LADDER IN Spare Part 71 11 5269 D16.036.08.0.PR O RING FOR LADDER OIL HOLE Spare Part 22 11 5270 D16.036.08.0.PR O RING FOR LADDER (WATER OUT) Spare Part 412 11 5271 D16.036.01.0.00 O RING FOR LADDER AND CRANKCASE Spare Part 426 11 5272 D16.036						15%
5263 D16.033.39.0.PR COMPRESSOR OUT PIPE (DV16 ? CTT TURBOCHARGER LHS FROM PE) Spare Part 8514 15 5264 D16.033.34.0.PR V BAND FOR COMPRESSOR OUT PIPE D16 CTT TURBOCHARGER ID 100 MM Spare Part 1018 15 5265 D16.033.47.0.PR HOSE FOR CAC PIPE ID 138 x ID 144 Spare Part 5486 15 5266 D16.033.48.0.PR HOSE FOR CAC OUT PIPE ID 138 BOTH SIDES Spare Part 6418 11 5267 D16.033.55.0.PR T BOLT CLAMP FOR DIA 141 149 Spare Part 225 11 5268 D16.036.07.0.00 O RING FOR LADDER IN Spare Part 71 11 5269 D16.036.08.0.PR O RING FOR LADDER OIL HOLE Spare Part 22 11 5270 D16.036.01.0.00 O RING FOR LADDER (WATER OUT) Spare Part 412 11 5271 D16.036.15.0.PR SLEEVE BETWEEN LADDER AND CRANKCASE Spare Part 98 11 5272 D16.036.15.0.PR JOINT BET DELIVARY ADAPTOR LADDER Spare Part 2462 11 5273 D16.040.2.04.0.PR		+	,			15%
5264 D16.033.41.0.PR V BAND FOR COMPRESSOR OUT PIPE D16 CTT TURBOCHARGER ID 100 MM Spare Part 1018 11 5265 D16.033.47.0.PR HOSE FOR CAC PIPE ID 138 x ID 144 Spare Part 5486 18 5266 D16.033.48.0.PR HOSE FOR CAC OUT PIPE ID 138 BOTH SIDES Spare Part 6418 11 5267 D16.033.55.0.PR T BOLT CLAMP FOR DIA 141 149 Spare Part 225 11 5268 D16.036.07.0.00 O RING FOR LADDER IN Spare Part 22 11 5279 D16.036.08.0.PR O RING FOR LADDER OIL HOLE Spare Part 22 11 5270 D16.036.14.0.00 O RING FOR LADDER (WATER OUT) Spare Part 412 11 5271 D16.036.15.0.PR SLEEVE BETWEEN LADDER AND CRANKCASE Spare Part 98 11 5272 D16.041.10.0.00 CENTRIFUGE OIL IN PIPE Spare Part 2462 11 5273 D16.042.04.0.PR JOINT FOR SUCTION Spare Part 166 11 5274 D16.046.13.0.PR STAINER BASKET Spare Part						
5265 D16.033.47.0.PR HOSE FOR CAC PIPE ID 138 x ID 144 Spare Part 5486 1. 5266 D16.033.48.0.PR HOSE FOR CAC OUT PIPE ID 138 BOTH SIDES Spare Part 6418 1. 5267 D16.033.48.0.PR T BOLT CLAMP FOR DIA 141 149 Spare Part 225 1. 5268 D16.036.07.0.00 O RING FOR LADDER IN Spare Part 71 1. 5269 D16.036.08.0.PR O RING FOR LADDER OIL HOLE Spare Part 22 1. 5270 D16.036.14.0.00 O RING FOR LADDER (WATER OUT) Spare Part 412 1. 5271 D16.036.15.0.PR SLEEVE BETWEEN LADDER AND CRANKCASE Spare Part 98 1. 5272 D16.041.10.0.00 CENTRIFUGE OIL IN PIPE Spare Part 2462 1. 5273 D16.042.04.0.PR JOINT BET DELIVARY ADAPTOR LADDER Spare Part 166 1. 5274 D16.043.02.0.PR JOINT FOR SUCTION Spare Part 1283 1. 5275 D16.046.13.0.PR CCV HOSE PIPE IN Spare Part 2523						15%
5266 D16.033.48.0.PR HOSE FOR CAC OUT PIPE ID 138 BOTH SIDES Spare Part 6418 1.5 5267 D16.033.55.0.PR T BOLT CLAMP FOR DIA 141 149 Spare Part 225 1.5 5268 D16.036.07.0.00 O RING FOR LADDER IN Spare Part 71 1.5 5269 D16.036.08.0.PR O RING FOR LADDER OIL HOLE Spare Part 22 1.5 5270 D16.036.14.0.00 O RING FOR LADDER (WATER OUT) Spare Part 412 1.5 5271 D16.036.15.0.PR SLEEVE BETWEEN LADDER AND CRANKCASE Spare Part 98 1.5 5272 D16.041.10.0.00 CENTRIFUGE OIL IN PIPE Spare Part 2462 1.5 5273 D16.042.04.0.PR JOINT BET DELIVARY ADAPTOR LADDER Spare Part 166 1.5 5274 D16.043.02.0.PR JOINT FOR SUCTION Spare Part 1283 1.5 5275 D16.043.04.0.PR STAINER BASKET Spare Part 2523 1.5 5276 D16.046.25.0.00 JOINT BETWEEN BELL HOUSING ADAPTOR Spare Part 4378				·		15%
5267 D16.033.55.0.PR T BOLT CLAMP FOR DIA 141 149 Spare Part 225 15 5268 D16.036.07.0.00 O RING FOR LADDER IN Spare Part 71 11 5269 D16.036.08.0.PR O RING FOR LADDER OIL HOLE Spare Part 22 11 5270 D16.036.14.0.00 O RING FOR LADDER (WATER OUT) Spare Part 412 11 5271 D16.036.15.0.PR SLEEVE BETWEEN LADDER AND CRANKCASE Spare Part 98 11 5272 D16.041.10.0.00 CENTRIFUGE OIL IN PIPE Spare Part 2462 11 5273 D16.042.04.0.PR JOINT BET DELIVARY ADAPTOR LADDER Spare Part 166 15 5274 D16.043.02.0.PR JOINT FOR SUCTION Spare Part 1283 15 5275 D16.043.04.0.PR STAINER BASKET Spare Part 720 15 5276 D16.046.13.0.PR CCV HOSE PIPE IN Spare Part 4378 15 5277 D16.046.25.0.00 JOINT BETWEEN BELL HOUSING ADAPTOR Spare Part 4403 11 <td></td> <td></td> <td></td> <td></td> <td></td> <td>15%</td>						15%
5268 D16.036.07.0.00 O RING FOR LADDER IN Spare Part 71 1. 5269 D16.036.08.0.PR O RING FOR LADDER OIL HOLE Spare Part 22 1. 5270 D16.036.14.0.00 O RING FOR LADDER (WATER OUT) Spare Part 412 1. 5271 D16.036.15.0.PR SLEEVE BETWEEN LADDER AND CRANKCASE Spare Part 98 1. 5272 D16.041.10.0.00 CENTRIFUGE OIL IN PIPE Spare Part 2462 1. 5273 D16.042.04.0.PR JOINT BET DELIVARY ADAPTOR LADDER Spare Part 166 1. 5274 D16.043.02.0.PR JOINT FOR SUCTION Spare Part 1283 1. 5275 D16.043.04.0.PR STAINER BASKET Spare Part 720 1. 5276 D16.046.13.0.PR CCV HOSE PIPE IN Spare Part 4378 1. 5277 D16.046.25.0.00 JOINT BETWEEN BELL HOUSING ADAPTOR Spare Part 4403 1. 5278 D16.046.26.0.PR CCV HOSE PIPE IN 1 Spare Part 6221 1. <td></td> <td></td> <td></td> <td>·</td> <td></td> <td>15%</td>				·		15%
5269 D16.036.08.0.PR O RING FOR LADDER OIL HOLE Spare Part 22 1. 5270 D16.036.14.0.00 O RING FOR LADDER (WATER OUT) Spare Part 412 1. 5271 D16.036.15.0.PR SLEEVE BETWEEN LADDER AND CRANKCASE Spare Part 98 1. 5272 D16.041.10.0.00 CENTRIFUGE OIL IN PIPE Spare Part 2462 1. 5273 D16.042.04.0.PR JOINT BET DELIVARY ADAPTOR LADDER Spare Part 166 1. 5274 D16.043.02.0.PR JOINT FOR SUCTION Spare Part 1283 1. 5275 D16.043.04.0.PR STAINER BASKET Spare Part 720 1. 5276 D16.046.13.0.PR CCV HOSE PIPE IN Spare Part 4378 1. 5277 D16.046.25.0.00 JOINT BETWEEN BELL HOUSING ADAPTOR Spare Part 4403 1. 5278 D16.046.26.0.PR CCV HOSE PIPE 2 BREATHER HOSE TO AIR CLEANER PIPE Spare Part 6221 1. 5279 D16.046.27.0.PR CCV HOSE PIPE IN 1 Spare Part 6221						15%
5270 D16.036.14.0.00 O RING FOR LADDER (WATER OUT) Spare Part 412 11 5271 D16.036.15.0.PR SLEEVE BETWEEN LADDER AND CRANKCASE Spare Part 98 11 5272 D16.041.10.0.00 CENTRIFUGE OIL IN PIPE Spare Part 2462 11 5273 D16.042.04.0.PR JOINT BET DELIVARY ADAPTOR LADDER Spare Part 166 11 5274 D16.043.02.0.PR JOINT FOR SUCTION Spare Part 1283 11 5275 D16.043.04.0.PR STAINER BASKET Spare Part 720 18 5276 D16.046.13.0.PR CCV HOSE PIPE IN Spare Part 4378 11 5277 D16.046.25.0.00 JOINT BETWEEN BELL HOUSING ADAPTOR Spare Part 4378 11 5278 D16.046.26.0.PR CCV HOSE PIPE 2 BREATHER HOSE TO AIR CLEANER PIPE Spare Part 4403 11 5279 D16.046.27.0.PR CCV HOSE PIPE IN 1 Spare Part 6221 11						15%
5271 D16.036.15.0.PR SLEEVE BETWEEN LADDER AND CRANKCASE Spare Part 98 1.5 5272 D16.041.10.0.00 CENTRIFUGE OIL IN PIPE Spare Part 2462 1.5 5273 D16.042.04.0.PR JOINT BET DELIVARY ADAPTOR LADDER Spare Part 166 1.5 5274 D16.043.02.0.PR JOINT FOR SUCTION Spare Part 1283 1.5 5275 D16.043.04.0.PR STAINER BASKET Spare Part 720 1.5 5276 D16.046.13.0.PR CCV HOSE PIPE IN Spare Part 2523 1.5 5277 D16.046.25.0.00 JOINT BETWEEN BELL HOUSING ADAPTOR Spare Part 4378 1.5 5278 D16.046.26.0.PR CCV HOSE PIPE 2 BREATHER HOSE TO AIR CLEANER PIPE Spare Part 4403 1.5 5279 D16.046.27.0.PR CCV HOSE PIPE IN 1 Spare Part 6221 1.5				·		15%
5272 D16.041.10.0.00 CENTRIFUGE OIL IN PIPE Spare Part 2462 1.1 5273 D16.042.04.0.PR JOINT BET DELIVARY ADAPTOR LADDER Spare Part 166 1.1 5274 D16.043.02.0.PR JOINT FOR SUCTION Spare Part 1283 1.1 5275 D16.043.04.0.PR STAINER BASKET Spare Part 720 1.1 5276 D16.046.13.0.PR CCV HOSE PIPE IN Spare Part 2523 1.1 5277 D16.046.25.0.00 JOINT BETWEEN BELL HOUSING ADAPTOR Spare Part 4378 1.1 5278 D16.046.26.0.PR CCV HOSE PIPE 2 BREATHER HOSE TO AIR CLEANER PIPE Spare Part 4403 1.1 5279 D16.046.27.0.PR CCV HOSE PIPE IN 1 Spare Part 6221 1.1						15%
5273 D16.042.04.0.PR JOINT BET DELIVARY ADAPTOR LADDER Spare Part 166 15 5274 D16.043.02.0.PR JOINT FOR SUCTION Spare Part 1283 15 5275 D16.043.04.0.PR STAINER BASKET Spare Part 720 15 5276 D16.046.13.0.PR CCV HOSE PIPE IN Spare Part 2523 15 5277 D16.046.25.0.00 JOINT BETWEEN BELL HOUSING ADAPTOR Spare Part 4378 15 5278 D16.046.26.0.PR CCV HOSE PIPE 2 BREATHER HOSE TO AIR CLEANER PIPE Spare Part 4403 11 5279 D16.046.27.0.PR CCV HOSE PIPE IN 1 Spare Part 6221 15				·		15%
5274 D16.043.02.0.PR JOINT FOR SUCTION Spare Part 1283 11 5275 D16.043.04.0.PR STAINER BASKET Spare Part 720 11 5276 D16.046.13.0.PR CCV HOSE PIPE IN Spare Part 2523 11 5277 D16.046.25.0.00 JOINT BETWEEN BELL HOUSING ADAPTOR Spare Part 4378 11 5278 D16.046.26.0.PR CCV HOSE PIPE 2 BREATHER HOSE TO AIR CLEANER PIPE Spare Part 4403 11 5279 D16.046.27.0.PR CCV HOSE PIPE IN 1 Spare Part 6221 11		1				15%
5275 D16.043.04.0.PR STAINER BASKET Spare Part 720 11 5276 D16.046.13.0.PR CCV HOSE PIPE IN Spare Part 2523 11 5277 D16.046.25.0.00 JOINT BETWEEN BELL HOUSING ADAPTOR Spare Part 4378 11 5278 D16.046.26.0.PR CCV HOSE PIPE 2 BREATHER HOSE TO AIR CLEANER PIPE Spare Part 4403 11 5279 D16.046.27.0.PR CCV HOSE PIPE IN 1 Spare Part 6221 11	5273	D16.042.04.0.PR				15%
5276 D16.046.13.0.PR CCV HOSE PIPE IN Spare Part 2523 1 5277 D16.046.25.0.00 JOINT BETWEEN BELL HOUSING ADAPTOR Spare Part 4378 1 5278 D16.046.26.0.PR CCV HOSE PIPE 2 BREATHER HOSE TO AIR CLEANER PIPE Spare Part 4403 1 5279 D16.046.27.0.PR CCV HOSE PIPE IN 1 Spare Part 6221 1	5274	D16.043.02.0.PR	JOINT FOR SUCTION	Spare Part	1283	15%
5277 D16.046.25.0.00 JOINT BETWEEN BELL HOUSING ADAPTOR Spare Part 4378 11 5278 D16.046.26.0.PR CCV HOSE PIPE 2 BREATHER HOSE TO AIR CLEANER PIPE Spare Part 4403 11 5279 D16.046.27.0.PR CCV HOSE PIPE IN 1 Spare Part 6221 11	5275	D16.043.04.0.PR	STAINER BASKET	Spare Part	720	15%
5278 D16.046.26.0.PR CCV HOSE PIPE 2 BREATHER HOSE TO AIR CLEANER PIPE Spare Part 4403 13 5279 D16.046.27.0.PR CCV HOSE PIPE IN 1 Spare Part 6221 13	5276	D16.046.13.0.PR	CCV HOSE PIPE IN	Spare Part	2523	15%
5279 D16.046.27.0.PR CCV HOSE PIPE IN 1 Spare Part 6221 1	5277	D16.046.25.0.00	JOINT BETWEEN BELL HOUSING ADAPTOR	Spare Part	4378	15%
	5278	D16.046.26.0.PR	CCV HOSE PIPE 2 BREATHER HOSE TO AIR CLEANER PIPE	Spare Part	4403	15%
5280 D16.046.28.0.PR	5279	D16.046.27.0.PR	CCV HOSE PIPE IN 1	Spare Part	6221	15%
	5280	D16.046.28.0.PR	CCV HOSE PIPE 2	Spare Part	5800	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		·		without Vat in NPR	Charge%
5281	D16.051.07.0.00	SPACER FOR HEAT SHIELD	Spare Part	151	15%
5282	D16.052.09.0.00	EYE BOLT	Spare Part	1243	15%
5283	D16.052.10.0.PR	IDLER BRACKET WITH PULLEY ASSLY RH	Spare Part	18046	15%
5284	D16.052.12.0.00	SPACER 15X28	Spare Part	77	15%
5285	D16.052.20.0.PR	IDLER BRACKET WITH PULLEY ASSLY LH	Spare Part	17224	15%
5286	D16.057.06.0.PR	FUEL LEVEL SENSOR HEIGHT 220 MM WITH HIGH LOW PRESSURE SWITCH	Spare Part	3594	15%
5287	D16.061.06.0.PR	ANTI VIBRATION MOUNTS FOR D16	Spare Part	7003	15%
5288	D16.064.04.0.PR	EXPANSION BELLOW	Spare Part	29037	15%
5289	D16.064.05.0.PR	JOINT BETWEEN DIFFUSER AND BELLOW	Spare Part	2905	15%
5290	D16.064.09.0.PR	JOINT BETWEEN SILENCER AND EXTENSION PIPE	Spare Part	6991	15%
5291	D16.064.11.0.PR	RAIN CAP ASSEMBLY FOR TAIL PIPE	Spare Part	4437	15%
5292	D16.064.13.0.PR	EXHAUST BEND	Spare Part	55181	15%
5293	D16.064.14.0.PR	HOSE BETWEEN THERMOSTAT RADIATOR IN	Spare Part	834	15%
5294	D16.064.18.0.PR	HOSE	Spare Part	1486	15%
5295	D16.064.19.0.PR	HOSE FOR THERMOSTAT TO HE OUT PIPE	Spare Part	1591	15%
5296	D16.064.21.0.PR	HOSE FOR RAW WATER IN	Spare Part	1157	15%
5297	D16.064.50.0.PR	Silencer Assembly	Spare Part	200431	15%
5298	D16.064.61.0.PR	EXHAUST PIPE FLANGE SPACER	Spare Part	3477	15%
5299	D16.072.60.0.00	COMMON RAIL FUEL PUMP ASSLY	Spare Part	924557	15%
5300	D16.099.10.0.PR	WIRING BOX ASSEMBLY R H S FROM PULLEY END SIDE	Spare Part	12028	15%
5301	D16.099.20.0.PR	WIRING BOX ASSEMBLY R H S FROM PULLEY END SIDE	Spare Part	12326	15%
5302	D16.099.30.0.PR	ENGINE WIRING HARNESS BOX L H FROM PULLEY END	Spare Part	10560	15%
5303	D16.099.50.0.PR	WIRING HARNESS BOX ASSEMBLY LHS FROM PULLY END SIDE	Spare Part	13068	15%
5304	D16.505.41.0.00	AIR FILTER PRIMARY	Filter	17646	20%
5305	D16.505.42.0.00	AIR FILTER SAFETY	Filter	6696	20%
5306	D16.505.46.0.00	HOSE CLAMP -T BOLT FOR AIR CLEANER 1010 KVA	Spare Part	586	20%
5307	D16.505.52.0.00	HOSE	Spare Part	4083	20%
5308	D16.507.03.0.00	PRE-FILTER CARTRIDGE	Filter	18633	20%
5309	D16.507.07.0.PR	ADAPTOR	Spare Part	440	15%
5310	D16.507.10.0.00	FUEL PRE-FILTER	Filter	76288	20%
	D16.507.11.0.PR	FUEL PIPE FUEL TANK TO LEAK OFF PIPE	Spare Part	2483	15%
5312	D16.507.12.0.PR	FUEL PIPE FUEL TANK TO LEAK OFF PIPE	Spare Part	3375	15%
	D16.507.13.0.PR	FUEL PIPE FROM TANK TO EXTERNAL FUEL TANK	Spare Part	1957	15%
	D16.507.14.0.PR	ADAPTOR M22X1 5 BOTH SIDE	Spare Part	508	15%
	D16.507.33.0.PR	HOSE	Spare Part	1314	15%
	D16.812.17.0.PR	COOLANT LEVEL SWITCH LOW HIGH LEVEL WITH LED	Spare Part	3766	15%
	D16.850.111.0.PR	RH LOCK FOR CANOPY DOOR 750 KVA AND ABOVE	Spare Part	2375	15%
	D16.850.112.0.PR	LH LOCK FOR CANOPY DOOR 750 KVA AND ABOVE	Spare Part	2375	15%
5319	D16.850.51.0.PR	DOOR HANDLE SUITABLE FOR DV	Spare Part	818	15%
5320	D16.858.11.0.PR	RMS (REMOTE MONITORING SYSTEM) UNIT S/F CRDI	Spare Part	25464	15%
	D16.858.12.0.PR	ASSEMBLY FOR KRM UNIT FOR KG1500 WITH PAKAGE S F CRDI	Spare Part	27781	15%
	D16.902.34.0.PR	BATTERY CHARGER 15AMP 24V NHP MAKE	Spare Part	18215	15%
5323	D16.902.56.0.PR	SET BOLT FOR FLYWHEEL	Spare Part	625	15%
5324	D16.903.13.0.00	2 CHANNEL, 3 CHANGE OVER, 24V, 10A RELAY BOARD	Spare Part	16714	15%
5325	D16.903.30.0.PR	BATTERY CABLES 95 SQMM 650MM LENGTH	Spare Part	12520	15%
5326	D16.906.05.0.00	NFC LINK FOR D350 AVR	Spare Part	35292	15%
5327	D16.906.20.0.PR	ENGINE WIRING HARNESS SF CONTROL PANEL TO INTERFACE BOX	Spare Part	104112	15%
5328	D16.906.50.0.PR	WIRING HARNESS FROM MASTER ECU TO SENSOR AND INJECTOR CONNECTION WITH BOSCH	Spare Part	54612	15%
5329	D16.906.60.0.PR	WIRING HARNESS FROM SLAVE ECU TO SENSOR AND INJECTOR CONNECTION WITH BOSCH P	Spare Part	39796	15%
5330	D16.906.70.0.PR	WIRING HARNESS FROM MASTER ECU TO SENSOR AND INJECTOR CONNECTION WITH STANAL	Spare Part	58212	15%
	D16.908.70.0.PR	CONTROL PANEL ASSEMBLY FOR DV16 3PHASE 1010KVA CRDI SILENT GENSET	Spare Part	169579	15%
5332	D16.999.05.0.SP	KVASER CABLE FOR NIRA ECU CRDI SET	Spare Part	103503	15%
JJJ32		TOOL KIT FOR SOFTWARE PROGRAMMING	Spare Part	204997	15%
5322					15%
5333 5334	D16.999.06.0.SP D2.003.40.0.00	CRANKSHAFT COMPLETE (TACO TYPE)- DM20	Spare Part	36480	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
			· ·	without Vat in NPR	Charge%
5336	D2.009.06.0.00	JOINT: SUCTION TUBE	Spare Part	25	15%
5337	D2.059.01.0.00	ALTERNATOR: 12V 35A	Spare Part	15289	15%
5338	D2.141.40.0.00	GEAR PUMP: DM20/DA20 RR	Spare Part	7708	15%
5339	D2.147.01.0.00	FLYWHEEL HOUSING	Spare Part	40547	15%
5340	D2.148.10.0.00	FLYWHEEL ASSLY,ES,SR - S/F SAE-2 HSG.	Spare Part	55953	15%
5341	D2.149.10.0.00	FLYWHEEL ASSLY,ES,SR - S/F SAE-3 HSG.	Spare Part	54224	15%
5342	D2.156.10.0.00	FLYWHEEL ASSEMBLY	Spare Part	68605	15%
5343	D2.163.01.0.00	ANTI VIBRATION MTG: GENSET	Spare Part	2015	15%
5344	D2.164.02.0.00	V BELT: AX55 COGGED	Spare Part	1012	15%
5345	D2.301.02.0.00	CORE PLUG 1 4 BSP 12 5 LENGTH	Spare Part	175	15%
5346	D2.307.03.0.00	JOINT: CYL HEAD & R'BOX	Spare Part	194	15%
5347	D2.323.40.0.00	SET OF JOINTS	Spare Part	4874	15%
		LEAK OFF PIPE: INJECTOR TO BOTTOM FUEL TANK		794	15%
5348	D2.338.10.0.00		Spare Part	142	
5349	D3.003.06.0.00	CYL HEAD STEEL GASKET:DAF10	Spare Part		15%
5350	D3.005.20.0.00	PUSH ROD TUBE ASSEMBLY	Spare Part	142	15%
5351	D3.030.02.0.00	LE TOP BEARING(WITH HOLE)	Spare Part	243	15%
5352	D3.030.03.0.00	SMALL END BUSH WITH HOLE	Spare Part	425	15%
5353	D3.030.10.0.00	CONNECTING ROD ASSLY: OIL HOLE	Spare Part	3480	15%
5354	D3.032.10.0.00	BLOWER ASLY.RR-DA10	Spare Part	15969	15%
5355	D3.036.03.0.00	CRANK PULLEY (FINISH)(BOLTED TYPE)(175.4 PCD)	Spare Part	3298	15%
5356	D3.176.01.0.00	STARTER 12V	Spare Part	27747	15%
5357	D3.213.08.0.00	IGNITION SWITCH MAKE MINDA TYPE IGN 7618	Spare Part	1243	15%
5358	D3.214.11.0.PR	MCB 17 5AMP 1 POLE MAKE SIDKON LT SIEMENS KOEL CS SCHNEIDER HPL SR	Spare Part	1320	15%
5359	D3.229.24.0.PR	KOEL GREEN Alternator KG 5 S T Frame L KG 40 C0 SAE 3 11 5 415V 50 Hz 0 8 PF	Spare Part	124411	15%
5360	D3.242.22.0.PR	POWER CABLE FOR EA10 5kVA 1PH EMERALD	Spare Part	1578	15%
5361	D3.247.01.0.ASP	RRA Condenser Diode & Varistor	Spare Part	11544	15%
5362	D3.247.02.0.ASP	Terminal Block Assembly- 5-10 KVA 1 Phase	Spare Part	2185	15%
5363	D3.247.05.0.ASP	SAE 2 DE BRKT PROT SCREEN ASLY KG3 KVA Rating 5 10 1Ph 5 15 3Ph Meccalte Part No	Spare Part	27544	15%
5364	D3.247.12.0.ASP	Space heater 54W 230 V KVA Rating 5 to 160 kVA Meccalte Part No 9910342100	Spare Part	25941	15%
5365	D3.247.15.0.ASP	DSRL (Digital Simplified Regulator) FOR FRAME KG3,KG28	Spare Part	31473	15%
5366	D3.247.25.0.PR	KOEL GREEN Alternator KG 5 S S Frame L KG 40 C1 SAE 3 11 5 230V 50 Hz 0 8 PF	Spare Part	130660	15%
5367	D3.256.10.0.00	ENGINE WIRING HARNESS ASSEMBLY: EA10 ENGINE SUITABLE FOR KG934 CONTROL UNIT	Spare Part	4772	15%
5368	D3.256.50.0.PR	ENGINE WIRING HARNESS FOR EA10 EMERALD	Spare Part	5708	15%
5369	D3.301.05.0.00	CYLINDER HEAD STUD (LONG)	Spare Part	542	15%
5370	D3.301.10.0.00	CRANKCASE ASSEMBLY	Spare Part	36258	15%
5371	D3.317.03.0.00	STUD FOR ROCKER SUPPORT	Spare Part	169	15%
5372	D3.317.20.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	23821	15%
5373	D3.317.99.0.00	VALVE PAIR	Spare Part	2148	15%
5374	D3.318.02.0.00	SHIM: LINER TO CR CASE 0.005"TH	Spare Part	28	15%
5375	D3.318.03.0.00	SHIM: LINER TO CR CASE 0.010"TH	Spare Part	34	15%
5376	D3.318.04.0.00	SHIM: LINER TO CR CASE 0.015"TH	Spare Part	46	15%
5377	D3.319.30.0.00	ROCKER SUPPORT ASSLY: EA10	Spare Part	3708	15%
5378	D3.321.03.0.00	BUTTON FOR YOKE	Spare Part	138	15%
5379	D3.324.10.0.00	COWLING SET	Spare Part	5886	15%
5380	D3.325.01.0.00	LEAK OFF CONNECTOR	Spare Part	437	15%
5381	D3.326.10.0.00	LEAK OFF PIPE ASSLY: CR'CASE TO FWE MB HSG & EXT ROCKER SUPPORT	Spare Part	600	15%
5382	D3.329.40.0.00	SET OF JOINTS	Spare Part	1714	15%
5383	D3.331.09.0.00	HANDLE FOR DOOR(DARSHNA PART NO.DHP110)	Spare Part	231	15%
5384	D3.331.18.0.00	HINGE FOR DOOR(STAINLESS STEEL,CLINCHED BOLT)	Spare Part	695	15%
5385	D3.335.01.0.00	CYLINDER LINER- EA10	Spare Part	9591	15%
5386	D3.336.01.0.00	HOSE FOR AIR CLEANER	Spare Part	1517	15%
5387	D3.343.28.0.00	EXH.SILENCER S/F SINGLE & TWIN CYL.AIR-COOLED VE CANOPY	Spare Part	16834	15%
5388	D3.343.29.0.00	TAIL PIPE FOR SILENCER	Spare Part	1705	15%
5389	D3.343.33.0.00	AIR INTAKE ADAPTOR	Spare Part	1255	15%
		10.1511	5pa.5 . uit	50	.570



				Price to	
				Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
				NPR	
5391	D3.343.36.0.00	INLET PIPE(ERW)	Spare Part	1492	15%
5392	D3.343.37.0.00	HOSE AIR INTAKE ADAPTOR TO AIR CLEANER	Spare Part	615	15%
5393	D3.344.01.0.00	EXHAUST BEND UPWARD OPENING	Spare Part	3169	15%
5394	D3.344.02.0.00	EXHAUST SILENCER	Spare Part	15434	15%
5395	D3.345.03.0.00	EXHAUST MANIFOLD	Spare Part	3514	15%
5396	D3.345.05.0.00	JOINT SILENCER EXH PIPE TO TAIL PIPE	Spare Part	145	15%
5397	D3.351.10.0.PR	BLOWER ASSEMBLY FOR EA 10 CPCB II	Spare Part	17437	15%
5398	D3.353.10.0.00	INJECTOR ASSLY	Spare Part	8498	15%
5399	D3.399.01.0.00	LINER PISTON SET: EA10 3RV	Spare Part	15575	15%
5400	D4.007.06.0.00	JOINT: ADAPTOR INLET M'FOLD	Spare Part	28	15%
5401	D4.014.10.0.00	BLOWER ASSEMBLY	Spare Part	14400	15%
5402	D4.023.01.0.00	BRACKET FOR FAN BODY	Spare Part	2028	15%
5403	D4.023.30.0.00	COOLING AIR BLOWER ASSEMBLY WITH BRACKET	Spare Part	19612	15%
5404	D4.117.06.0.00	FUEL LEVEL GAUGE	Spare Part	2022	15%
5405	D4.119.02.0.00	FEED PUMP	Spare Part	11788	15%
5406	D4.119.05.0.00	ECCENTRIC	Spare Part	2406	15%
5407	D4.119.09.0.00	JOINT: FEED PUMP	Spare Part	34	15%
5408	D4.119.12.0.00	GEAR COVER S/F FEED PUMP - VAVE	Spare Part	6283	15%
5409	D4.121.01.0.00	FLYWHEEL HOUSING	Spare Part	27046	15%
5410	D4.122.01.0.00	EXPANSION BELLOW: 285 MM	Spare Part	5406	15%
5411	D4.122.02.0.00	EXPANSION BELLOW: 232MM DOUBLE FLANGE	Spare Part	5649	15%
5412	D4.122.03.0.00	STEEL JOINT FOR DOUBLE FLANGE EXPANSION BELLOW	Spare Part	95	15%
5413	D4.135.01.0.00	CRANKSHAFT GEAR WHEEL	Spare Part	4221	15%
5414	D4.149.15.0.00	PRIMARY AIR CLEANER ELEMENT	Filter	3521	20%
5415	D4.171.04.0.00	HOSE: AIR INLET MANIFOLD	Spare Part	1431	15%
5416	D4.302.30.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	22849	15%
5417	D4.302.40.0.00	CAMSHAFT ASSLY- EA16-EA20 RR	Spare Part	24270	15%
5418	D5.006.02.0.00	PISTON PIN	Spare Part	535	15%
5419	D5.114.02.0.00	BRACKET FOR STOP SOLENOID	Spare Part	126	15%
5420	D5.114.20.0.00	STOP SOLENOID ASSLY-12V SINGLE COIL	Spare Part	6292	15%
5421	D5.302.02.0.00	GASKET: CYLINDER HEAD EW8.5	Spare Part	111	15%
5422	D5.302.03.9.00	VALVE GUIDE(SEMI-FINISH) - EW8.5	Spare Part	154	15%
5423	D5.303.10.0.00	RING SET STD: EW8.5 3RV	Spare Part	1686	15%
5424	D5.303.20.0.00	PISTON ASSEMBLY: EW8.5	Spare Part	5957	15%
5425	D5.304.02.0.00	JOINT: AIR INLET M'FOLD	Spare Part	22	15%
5426	D5.305.02.0.00	GASKET: EXHAUST M'FOLD EW8.5	Spare Part	58	15%
5427	D5.310.20.0.00	INJECTOR	Spare Part	13295	15%
5428	D7.002.01.0.00	CYLINDER LINER	Spare Part	10172	15%
5429	D7.003.06.0.00	CYL HEAD STEEL GASKET:DAF8	Spare Part	138	15%
5430	D7.005.10.0.00	PUSH ROD TUBE ASSEMBLY	Spare Part	234	15%
5431	D7.302.99.0.00	VALVE PAIR	Spare Part	1929	15%
5432	D7.304.01.0.00	ROCKER COVER	Spare Part	1892	15%
5433	D7.304.03.0.00	BREATHER	Spare Part	911	15%
5434	D7.304.04.0.00	JOINT: ROCKER COVER EAF8 7EA10	Spare Part	409	15%
5435	D7.305.01.0.00	FLANGE FOR NOZZLE	Spare Part	483	15%
5436	D7.306.40.0.00	ROCKER SUPPORT SUB ASSLY: EAF8	Spare Part	4695	15%
5437	D7.309.30.0.00	ASSLY.CAMSHAFT,SR,STL,A2,1500 - EAF8 & EA10	Spare Part	14464	15%
5438	D7.310.01.0.00	CYLINDER HEAD STUD (SHORT)	Spare Part	532	15%
5439	D7.311.01.0.00	INLET VALVE ASSLY	Spare Part	757	15%
5440	D7.311.02.0.00	INLET VALVE SEAT INSERT (CPCB)	Spare Part	400	15%
5441	D7.311.02.9.00	INLET VALVE SEAT INSERT SEMI FINISH EAF8	Spare Part	378	15%
5442	D7.312.01.0.00	EXHAUST VALVE(FINISH) - EAF8	Spare Part	1292	15%
5443	D7.312.02.9.00	EXHAUST VALVE (FINISH) - EAF6 EXHAUST VALVE SEAT INSERT SEMI FINISH EAF8	Spare Part	412	15%
5444	D7.313.10.0.00	H.P. PIPE ASSLY G.E.SIDE:EAF8/EA10	Spare Part	1052	15%
5445	D7.317.01.0.00	CYL.LINER,OPTIMISED FINS(STD)(FINISH) - EAF8	Spare Part	8972	15%
5445	.017.01.0.00	012.EliaElia, 01 TilviloED Tilvo(01D)(1 Ilvio11) - EAT 0	Spare Part	0912	13%



				Price to Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
		THE CHIEF CHIEF CONTROL CONTRO		NPR	4=04
5446	D8.066.01.0.00	TEMP. SWITCH - 230 Deg. C	Spare Part	3815	15%
5447	D8.079.26.0.00	EXH FAN: 450MM WITH CONNECTOR	Spare Part	20089	15%
5448	D8.079.48.0.00	TUBE LIGHT 12V DC,6" LONG FOR CANOPY WITH CONNECTOR	Spare Part	2052	15%
5449	D8.079.49.0.00	TUBE LIGHT 24V DC,6" LONG FOR CANOPY WITH CONNECTOR	Spare Part	2178	15%
5450	D8.079.52.0.PR	LED TUBE LIGHT MAKE SAM INT P LTD 12VDC 2W 6 LONG WITH 2 PIN CONNECTOR	Spare Part	1437	15%
5451	D8.105.19.0.00	KOEL GREEN Alternator, KG 10 S S Frame: L KG 40 E, SAE-2 11.5", 230V, 50 Hz, 0.8 PF	Spare Part	153964	15% 15%
5452	D8.106.19.0.PR	KOEL GREEN Alternator KG 10 S T Frame L KG 40 C2 SAE 2 11 5 415V 50 Hz 0 8 PF	Spare Part	137589 6292	15%
5453	D8.108.20.0.00	STOP SOLENOID ASSLY-12V SING COIL FIP: EA16 CPCB-II	Spare Part Spare Part	4760	15%
5454 5455	D8.111.01.0.00 D8.111.02.0.00	FIP: EA16 CPCB-II		6735	15%
	D8.117.23.0.00	KOEL GREEN Alternator, KG 12.5 S S Frame: L KG 423 B, SAE-2 11.5", 230V, 50 Hz, 0.8 PF	Spare Part Spare Part	171419	15%
5456 5457	D8.138.18.0.00	RELAY CARD - 2.5 CHANNEL - 12V DC	Spare Part	4252	15%
5458	D8.176.01.0.PR	STARTER	Spare Part	25612	15%
5459	D8.190.70.0.PR	CONTROL PANEL SCHEMATIC FOR 12 5KVA 3PH WITH KG640 IP A	Spare Part	75045	15%
5460	D8.190.80.0.PR	CONTROL PANEL SCHEMATIC FOR 12 5KVA 1PH WITH KG640 IP A	Spare Part	67519	15%
5461	D8.256.10.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	6138	15%
5462	D8.256.30.0.00	ENGINE WIRING HARNESS ASSEMBLY WITH FUEL TANK UNIT FOR EA16 ENGINE	Spare Part	7197	15%
5463	D8.256.70.0.PR	ENGINE WIRING HARNESS FOR EA16 EMERALD	Spare Part	6825	15%
5464	D8.256.80.0.PR	ENGINE WIRING HARNESS FOR EA16	Spare Part	5175	15%
5465	D8.258.40.0.PR	POWER HARNESS FOR EA16 3PH ENGINE EMRALD	Spare Part	4908	15%
5466	D8.258.50.0.PR	POWER HARNESS FOR EA16 1PH ENGINE EMRALD	Spare Part	5495	15%
5467	D8.301.10.0.00	CRANKCASE ASSEMBLY	Spare Part	79122	15%
5468	D8.303.11.0.00	AIR INLET MANIFOLD FINISH ALUMINUM EA16	Spare Part	4077	15%
5469	D8.305.20.0.00	COWLING SET	Spare Part	1969	15%
5470	D8.306.02.0.00	SPECIAL BANJO BOLT -M6	Spare Part	102	15%
5471	D8.306.10.0.00	LUBE OIL PIPE ASSLY: CR'CASE TO ROCKER SUPPORT	Spare Part	769	15%
5472	D8.307.05.0.00	EXHAUST MANIFOLD (LAGGED) (UPWARD OPENING)	Spare Part	4465	15%
5473	D8.307.06.0.00	SPECIAL SOCKET HEAD SET SCREW 5 16 BSF X 1 COPPER COATED	Spare Part	37	15%
5474	D8.308.07.0.00	FUEL PIPE FEED PUMP TO FILTER	Spare Part	1098	15%
5475	D8.308.08.0.00	FUEL PIPE NOZZLE TO TANK	Spare Part	2308	15%
5476	D8.308.09.0.00	FUEL PIPE TANK TO FEED PUMP	Spare Part	1114	15%
5477	D8.308.20.0.00	NOZZLE LEAK OFF PIPE ASSEMBLY - EA16	Spare Part	751	15%
5478	D8.312.40.0.00	SET OF JOINTS	Spare Part	2338	15%
5479	D8.316.01.0.00	FUEL PUMP BRACKET	Spare Part	2646	15%
5480	D8.319.03.0.00	AIR CLEANER ELEMENT	Filter	1364	20%
5481	D8.319.05.0.00	HOSE FOR CLEANER	Spare Part	3609	15%
5482	D8.319.10.0.00	AIR CLEANER ASSLY: DRY TYPE	Spare Part	3259	20%
5483	D8.334.01.0.00	FUEL PIPE (FEED PUMP TO SPINON FILTER)	Spare Part	902	15%
5484	D8.334.02.0.00	FUEL PIPE (SPINON FILTER TO FUEL PUMP)	Spare Part	902	15%
5485	D8.372.40.0.PR	BLOWER ASSEMBLY WITH BRACKET (EA16 CPCB II)	Spare Part	20960	15%
5486	D8.399.01.0.00	LINER PISTON SET: EA16 3RV	Spare Part	13628	15%
5487	D8.712.10.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	1388	15%
5488	D8.714.03.0.00	V BELT AX56 COG	Spare Part	1246	15%
5489	D8.715.20.0.PR	CYLINDER HEAD ASSLY COMPLETE FOR EA16 CPCB II ENGINE	Spare Part	23950	15%
5490	D9.006.02.0.00	PISTON PIN	Spare Part	766	15%
5491	D9.061.14.0.PR	KOEL GREEN Alternator KG 7 5 S S Frame L KG 40 C2 SAE 2 11 5 230V 50 Hz 0 8 PF	Spare Part	134318	15%
5492	D9.062.18.0.PR	KOEL GREEN Alternator KG 7 5 S T Frame L KG 40 C1 SAE 2 11 5 415V 50 Hz 0 8 PF	Spare Part	126248	15%
5493	D9.302.02.0.00	GASKET: CYLINDER HEAD EW12	Spare Part	154	15%
5494	D9.303.10.0.00	RING SET STD: EW12 3RV	Spare Part	3677	15%
5495	D9.303.20.0.00	PISTON ASSEMBLY: EW14	Spare Part	8821	15%
5496	D9.311.10.0.00	CYL LINER ASSEMBLY-EW14	Spare Part	4665	15%
5497	D9.312.40.0.00	SET OF JOINTS	Spare Part	3003	15%
5498	D9.322.99.0.00	VALVE PAIR	Spare Part	1418	15%
5499	DC.004.10.0.00	LEAK OFF PIPE ASSEMBLY	Spare Part	489	15%
5500	DC.033.10.0.00	RADIATOR ASSLY WITH SHROUD DM26	Spare Part	35329	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
0101		, w. 2550 p	,	without Vat in	Charge%
5501	DC.034.02.0.00	ADAPTOR PLATE FOR LUBE OIL FILTER	Spare Part	NPR 662	15%
5502	DC.034.04.0.00	JOINT: B'WEEN ADAPTOR & CR'CASE	Spare Part	34	15%
5503	DC.123.01.0.00	HOSE: RADIATOR BTM TANK TO THERMOSTAT PIPE	Spare Part	991	15%
5504	DC.123.02.0.00	HOSE: WATER PUMP OUTLET TO WI MANIFOLD	Spare Part	560	15%
5505	DC.123.04.0.00	HOSE: THERMOSTAT BYPASS TO BEND PIPE	Spare Part	148	15%
5506	DC.305.01.0.00	FUEL PIPE: FEED PUMP TO FILTER	Spare Part	1695	15%
5507	DC.305.02.0.00	FUEL PIPE- FILTER TO FIP	Spare Part	917	15%
5508	DC.305.07.0.00	ADAPTOR FOR OVERFLOW VALVE	Spare Part	483	15%
5509	DC.305.08.0.00	FUEL PIPE FILTER TO TANK	Spare Part	618	15%
5510	DC.399.01.0.00	LINER PISTON SET: EW28 3RV	Spare Part	11603	15%
5511	DD.019.03.0.00	CRANK PULLEY (FINISH)(BOLTED TYPE)(175.4 PCD)	Spare Part	2622	15%
5512	DV0.001.03.0.00	BOLT (BEARING CAP)	Spare Part	726	15%
5513	DV0.001.03.0.00	HOLLOW DOWEL FOR BEARING CAP BOLT	•	126	15%
			Spare Part	1043	15%
5514	DV0.001.05.0.00	NOZZLE BODY: OIL SPRAY NOZZLE	Spare Part		
5515	DV0.001.06.0.00	SPECIAL BANJO BOLT : OIL SPRAY NOZZLE	Spare Part	378 711	15% 15%
5516	DV0.001.08.0.00	LIFTING HOOK	Spare Part		
5517	DV0.001.09.0.PR	SPECIAL BANJO BOLT (FOR OIL SPAY NOZZLE)	Spare Part	83	15%
5518	DV0.001.10.0.00	CRANK CASE SUB ASSEMBLY	Spare Part	1440408	15%
5519	DV0.001.15.0.00	CAM BUSH	Spare Part	902	15%
5520	DV0.001.16.0.00	CORE PLUG HEX SOCKET (M24X2)	Spare Part	157	15%
5521	DV0.001.17.0.00	CORE PLUG HEX. SOCKET M33X3.5	Spare Part	382	15%
5522	DV0.001.18.0.00	CORE PLUG HEX. SOCKET M30X1.5	Spare Part	234	15%
5523	DV0.001.21.0.00	GROMMET: 12 DIA FERRULE	Spare Part	43	15%
5524	DV0.001.22.0.00	GROMMET: 22 DIA FERRULE	Spare Part	111	15%
5525	DV0.001.23.0.00	FERRULE: 12 DIA	Spare Part	31	15%
5526	DV0.001.24.0.00	FERRULE: 22DIA	Spare Part	37	15%
5527	DV0.001.25.0.00	DISH PLUG (80DIA)	Spare Part	83	15%
5528	DV0.001.26.0.00	WASHER FOR CRANKCASE PLUG	Spare Part	12	15%
5529	DV0.001.27.0.00	PLUG (CRANKCASE OIL HOLE)	Spare Part	52	15%
5530	DV0.001.31.0.00	SPRING	Spare Part	329	15%
5531	DV0.001.32.0.00	PLUNGER: RELIEF VALVE	Spare Part	243	15%
5532	DV0.001.350.0.PR	CRANKCASE SUB ASSEMBLY	Spare Part	1176138	15%
5533	DV0.001.42.0.00	M.B. CROSS BOLT (LONG)	Spare Part	360	15%
5534	DV0.001.43.0.00	M.B. CROSS BOLT (SHORT)	Spare Part	255	15%
5535	DV0.001.47.0.00	SEALING CAP	Spare Part	185	15%
5536	DV0.001.50.0.00	RELIEF VALVE ASSEMBLY	Spare Part	2040	15%
5537	DV0.001.51.0.00	MAIN BEARING TOP (MIBA)	Spare Part	4511	15%
5538	DV0.001.77.0.00	MAIN BEARING LOWER HALF - SPUTTER+SYNTEC	Spare Part	8791	15%
5539	DV0.001.81.0.00	GROMMET SUPPORT WASHER-20.2	Spare Part	182	15%
5540	DV0.001.82.0.00	GROMMET SUPPORT WASHER-31.5D	Spare Part	240	15%
5541	DV0.001.83.0.00	GROMMET FOR 12DIA FERRULE	Spare Part	71	15%
5542	DV0.001.85.0.00	GROMMET SUPPORT WASHER FOR 31 5	Spare Part	169	15%
5543	DV0.002.02.0.00	O RING: CYLINDER LINER	Spare Part	452	15%
5544	DV0.002.10.0.SP	CYLINDER LINER ASSEMBLY	Spare Part	15375	15%
5545	DV0.002.30.0.00	CYLINDER LINER ASSEMBLY	Spare Part	18440	15%
5546	DV0.003.04.0.00	DOWEL	Spare Part	154	15%
5547	DV0.003.10.0.00	CRANKSHAFT SUB ASSLY.	Spare Part	517805	15%
5548	DV0.003.12.0.00	CRANK PULLEY	Spare Part	16723	15%
5549	DV0.003.13.0.00	CRANK PULLEY FOR FAN DRIVE	Spare Part	5954	15%
5550	DV0.003.14.0.00	CRANK PULLEY BOLT	Spare Part	698	15%
5551	DV0.004.09.0.00	THRUST PLATE FOR CAM SHAFT (WIDHT 18.2)	Spare Part	1049	15%
5552	DV0.004.11.0.00	THRUST PLATE FOR CAMSHAFT (18.7 mm. THICK)	Spare Part	1074	15%
5553	DV0.004.13.0.00	THRUST PLATE FOR CAMSHAFT 17 5 mm THICK	Spare Part	889	15%
5554	DV0.004.14.0.00	THRUST PLATE FOR CAMSHAFT 17 3 mmTHICK	Spare Part	1080	15%
5555	DV0.005.02.0.00	CONNECTING ROD BOLT	Spare Part	406	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
5556	DV0.005.11.0.00	BIG END BEARING TOP MIBA	Spare Part	6628	15%
5557	DV0.005.12.0.00	BIG END BEARING BOTTOM MIBA	Spare Part	3594	15%
5558	DV0.005.20.0.00	CONNECTING ROD ASSLY.WITH SMALL END BUSH WITH LARGE END BEARING	Spare Part	25089	15%
5559	DV0.005.60.0.00	ASSY. CONNECTING ROD (MACHINING WITH SMALL END BUSH) (FOR CRDI ENGINE)	Spare Part	27590	15%
5560	DV0.006.02.0.00	PISTON PIN	Spare Part	2892	15%
5561	DV0.006.06.0.00	CIRCLIP(FOR PISTON)	Spare Part	117	15%
5562	DV0.006.20.0.SP	PISTON RING SET	Spare Part	4551	15%
5563	DV0.006.30.0.00	PISTON ASSEMBLY	Spare Part	21255	15%
5564	DV0.007.02.0.00	CYLINDER HEAD BOLT	Spare Part	809	15%
5565	DV0.007.03.0.00	CORE PLUG (20 MM DIA)	Spare Part	48	20%
5566	DV0.007.06.9.00	INLET VALVE SEAT INSERT SEMI-FINISH	Spare Part	698	15%
5567	DV0.007.09.0.00	CORE PLUG (DIA 32 MM)	Spare Part	77	20%
5568	DV0.007.110.0.00	ROCKER LEVER ADJ SCREW ASSLY	Spare Part	578	15%
5569	DV0.007.113.0.00	UNION ADAPTOR M12XM8	Spare Part	123	15%
5570	DV0.007.114.0.PR	NOZZLE CLAMP	Spare Part	849	15%
5571	DV0.007.230.0.PR	CYLINDER HEAD SUB ASSEMBLY WITH VALVE SPRING VALVE FOR CR	Spare Part	96851	15%
5572	DV0.007.260.0.PR	CYLINDER HEAD ASSEMBLY	Spare Part	154743	15%
5573	DV0.007.33.0.00	NOZZLE CLAMP	Spare Part	2145	15%
5574	DV0.007.34.0.00	BUTTON FOR NOZZLE CLAMP	Spare Part	46	15%
5575	DV0.007.35.0.00	CUP WASHER FOR NOZZLE CLAMP	Spare Part	46	15%
5576	DV0.007.36.0.00	OIL METERING PLUG: ROCKER SUPPORT	Spare Part	52	15%
5577	DV0.007.39.9.00	EXHAUST VALVE SEAT INSERT	Spare Part	640	15%
5578	DV0.007.42.0.00	GASKET: CYLINDER HEAD 1 THK	Spare Part	812	15%
5579	DV0.007.43.0.00	GASKET: CYLINDER HEAD 1.15 THK	Spare Part	803	15%
5580	DV0.007.46.0.00	SEALING CAP	Spare Part	48	20%
5581	DV0.007.60.0.00	ROCKER LEVER ASSLEMBLY	Spare Part	11492	15%
5582	DV0.007.65.0.00	VALVE PAIR	Spare Part	2520	15%
5583	DV0.007.70.0.00	CYL HEAD SUB ASSEMBLY WITH SPRING VALVE	Spare Part	93082	15%
5584	DV0.007.71.0.00	SEALING CAP (FOR DIA 25)	Spare Part	54	20%
5585	DV0.007.75.0.00	CYLINDER HEAD ASSLY	Spare Part	93393	15%
5586	DV0.007.82.0.00	VALVE GUIDE	Spare Part	323	15%
5587	DV0.007.82.9.00	VALVE GUIDE (SEMI-FINISH)	Spare Part	194	15%
5588	DV0.007.90.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	125011	15%
5589	DV0.007.96.0.SP	INLET & EXHAUST VALVE PAIR	Spare Part	3185	15%
5590	DV0.007.98.9.00	VALVE SEAT INSERT (EXHAUST) (SEMIFINISH)	Spare Part	2732	15%
5591	DV0.008.13.0.00	INJECTOR	Spare Part	19535	15%
5592	DV0.008.18.0.00	O RING FOR INJECTOR	Spare Part	142	15%
	DV0.009.05.0.00	JOINT: ROCKER COVER METALLIC	Spare Part	409	15%
5594	DV0.009.07.0.00	ROCKER COVER	Spare Part	4689	15%
5595	DV0.009.11.0.00	ROCKER BOX	Spare Part	5471	15%
5596	DV0.009.12.0.PR	ROCKER COVER	Spare Part	4548	15%
5597	DV0.010.03.0.00	RETAINER PATE FOR GEAR SUPPORT	Spare Part	705	15%
5598	DV0.010.04.0.00	THRUST WASHER: INTERMEDIATE GEAR SUPPORT	Spare Part	557	15%
5599	DV0.010.06.0.00	THRUST WASHER: INTERMEDIATE GEAR SUPPORT	Spare Part	600	15%
5600	DV0.010.10.0.00	SUB ASSLY OF DOUBE GEAR AND BUSH INTERMIDATE	Spare Part	56599	15%
5601	DV0.010.10.0.00	DOUBLE GEAR ASSLY CRANK GEAR AND CAM GEAR	Spare Part	56039	15%
5602	DV0.010.25.0.PR	DOUBLE GEAR ASSLIT CRAIN GEAR AND CAN GEAR DOUBLE GEAR SUPPORT	Spare Part	5037	15%
5603	DV0.010.23.0.PK	INTERMEDIATE GEAR SUPPORT BETWEEN CAM AND FUE PUMP GEAR	Spare Part	2972	15%
5604	DV0.011.04.0.00	THRUST WASHER (39MM THICK)	Spare Part	557	15%
5605	DV0.011.04.0.00	INTERMEDIATE GEAR ASSLY (CAM & FUEL PUMP GEAR)	Spare Part	16560	15%
			· ·		15%
5606	DV0.012.01.0.00	OIL SEAL HOUSING	Spare Part	7566	
5607	DV0.012.03.0.00	JOINT: OIL SEAL HOUSING	Spare Part	345	15%
5608	DV0.012.22.0.PR	OIL SEAL PULLEY END	Spare Part	2954	15%
5609	DV0.013.200.0.PR	LUB OIL PUMP ASSEBLY	Spare Part	103574	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
5611	DV0.014.04.0.SP	LUB OIL COOLER HEADER	Spare Part	84060	15%
5612	DV0.014.05.0.00	FILTER HEADER	Spare Part	13326	15%
5613	DV0.014.06.0.00	JOINT: COOLER COVER	Spare Part	988	15%
5614	DV0.014.07.0.00	THREADED ADAPTOR FOR HEADER	Spare Part	1489	15%
5615	DV0.014.08.0.00	SUCTION TUBE	Spare Part	7474	15%
5616	DV0.014.10.0.00	LUB OIL FILTER HEADER ASSLY (WITH ADAPTOR & CORE PLUG)	Spare Part	15166	15%
5617	DV0.014.11.0.00	LUBE OIL FILTER	Filter	4626	20%
5618	DV0.014.12.0.00	O RING 38 DIA: L.O. HEADER	Spare Part	98	15%
5619	DV0.014.13.0.00	O RING 58 DIA: L.O. HEADER	Spare Part	157	15%
5620	DV0.014.14.0.00	O RING 67 DIA: L.O. HEADER	Spare Part	172	15%
5621	DV0.014.16.0.00	JOINT: WATER PUMP SUCTION	Spare Part	52	15%
5622	DV0.014.17.0.00	GASKET (LUB. OIL HEADER)	Spare Part	37	15%
5623	DV0.014.18.0.00	JOINT: SUCTION PIPE ASSLY	Spare Part	95	15%
5624	DV0.014.23.0.00	O RING 29DIA: ELEMENT OIL COOLER	Spare Part	68	15%
5625	DV0.014.24.0.00	HOSE: RADIATOR TO SUCTION PIPE	Spare Part	1535	15%
5626	DV0.014.25.0.00	HOSE: ENGINE WATER OUT	Spare Part	5015	15%
5627	DV0.014.26.0.00	METALIC PIPE FROM THERMOSTAT TO RAD	Spare Part	4354	15%
5628	DV0.014.27.0.00	LUBE OIL FILTER	Filter	4626	20%
5629	DV0.014.33.0.00	HOSE: PIPE TO THERMOSTAT	Spare Part	1462	15%
5630	DV0.014.38.0.00	HEADER FOR OIL FILTER (320 KVA)	Spare Part	9791	15%
5631	DV0.014.39.0.00	LUBE OIL COOLER COVER (MACHINING)	Spare Part	16932	15%
5632	DV0.014.42.0.00	OIL FILTER	Filter	9505	20%
5633	DV0.014.43.0.00	DOME NUT: LUB OIL COOLER	Spare Part	963	15%
5634	DV0.014.50.0.00	LUBE OIL COOLER HEADER ASSEMBLY	Spare Part	223077	15%
5635	DV0.014.51.0.00	JOINT: COOLER COVER	Spare Part	1163	15%
5636	DV0.014.66.0.00	LUBE OIL FILTER FULL FLOW SPIN ON	Spare Part	9537	20%
5637	DV0.014.67.0.00	LUBE OIL FILTER BY PASS SPIN ON	Spare Part	6589	20%
5638	DV0.014.72.0.PR	LUBE OIL FILTER-FULL FLOW-SPIN ON KIRLOSKAR LOGO REVERSAL APPLICATION	Spare Part	9168	20%
5639	DV0.014.83.0.SP	500 Hrs B Check Maintenance Kit	Spare Part	63214	20%
5640	DV0.014.85.0.SP	1500 Hrs C Check Maintenance Kit	Spare Part	122560	20%
5641	DV0.014.86.0.SP	50 HOURS SERVICE MAINTENANCE KIT	Spare Part	44310	20%
5642	DV0.014.89.0.SP	1500 HRS C CHECK MAINTENANCE KIT	Spare Part	111430	20%
5643	DV0.015.01.0.00	THERMOSTAT ELEMENT	Spare Part	3600	15%
5644	DV0.015.02.0.00	THERMOSTAT HOUSING	Spare Part	9455	15%
5645	DV0.015.03.0.00	THERMOSTAT HOUSING COVER	Spare Part	4932	15%
5646	DV0.015.05.0.00	JOINT: THERMOSTAT HOUSING	Spare Part	77	15%
5647	DV0.015.06.0.00	GASKET: THERMOSTAT COVER	Spare Part	145	15%
5648	DV0.015.07.0.00	WASHER: THERMOSTAT HOUSING ASSLY	Spare Part	222	15%
5649	DV0.015.17.0.PR	THERMOSTAT HOUSING COVER	Spare Part	6354	15%
5650	DV0.016.08.0.00	V BELT: BX58 PITCH 1520 LONG	Spare Part	8283	15%
5651	DV0.016.09.0.00	JOINT:BET WATER PUMP HSG & HEADER	Spare Part	188	15%
5652	DV0.016.21.0.00	WATER PUMP PULLEY-115 PCD	Spare Part	2929	15%
5653	DV0.016.23.0.00	V WRAPPED BELT AR1170 SPB	Spare Part	5726	15%
5654	DV0.016.25.0.00	V WRAPPED BELT: SPB AR1230 - 3 SET	Spare Part	6566	15%
5655	DV0.016.60.0.00	WATER PUMP ASSLY	Spare Part	41544	15%
5656	DV0.017.03.0.00	LUB OIL SUMP	Spare Part	140444	15%
5657	DV0.017.07.0.00	O RING FOR DIPSTICK PLUG	Spare Part	102	15%
5658	DV0.017.30.0.00	DIPSTICK ASSEMBLY	Spare Part	375	15%
5659	DV0.017.80.0.00	DIPSTICK ASSEMBLY	Spare Part	406	15%
5660	DV0.018.01.0.00	TAPPET	Spare Part	385	15%
5661	DV0.018.10.0.00	PUSH ROD ASSLY	Spare Part	1034	15%
5662	DV0.018.11.0.00	RUBBER BUSH :BOTTOM	Spare Part	114	15%
5663	DV0.018.20.0.00	ASSLY PUSH ROD COVER TUBE	Spare Part	305	15%
5664	DV0.018.23.0.00	RUBBER BUSH BOTTOM	Spare Part	105	15%
	DV0.018.40.0.00	PUSH ROD COVER TUBE ASSEMBLY (FOR COMMON RAIL)	Spare Part	295	15%



C+ No	Doub November	Don't Description	Catagony	Price to Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
5000	D) /0 040 44 0 00	FUEL PUMP CAP	Chara Davi	NPR 4185	450/
	DV0.019.11.0.00 DV0.020.01.0.00	FUEL FILTER: DV10	Spare Part Filter	25907	15%
	DV0.020.01.0.00	FUEL FILTER: DV10 FUEL FILTER: CARTRIDGE	Filter	9019	20%
	DV0.020.03.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	26206	15%
	DV0.021.130.0.00	CLAMP COVER FOR H P PIPE		105	15%
	DV0.021.52.0.FK	RUBBER SLEEVE FOR H.P. PIPE CLAMP	Spare Part Spare Part	43	15%
-	DV0.021.53.0.00	BRACKET FOR HP PIPE LH -1	Spare Part	575	15%
	DV0.021.63.0.PR	BRACKET FOR HP PIPE LH -2	Spare Part	603	15%
	DV0.021.64.0.PR	BRACKET FOR HP PIPE LH -3	Spare Part	1006	15%
	DV0.021.65.0.00	BRACKET FOR HP PIPE LH -4	Spare Part	502	15%
	DV0.021.66.0.PR	BRACKET FOR HP PIPE LH -5	Spare Part	2246	15%
	DV0.021.67.0.00	BRACKET FOR HP PIPE RH -1	Spare Part	529	15%
	DV0.021.68.0.PR	BRACKET FOR HP PIPE RH -2	Spare Part	532	15%
	DV0.021.69.0.PR	BRACKET FOR HP PIPE RH -3	Spare Part	606	15%
	DV0.021.09.0.FK	BRACKET FOR HP PIPE RH -4	Spare Part	505	15%
	DV0.021.71.0.00 DV0.021.710.0.PR	HIGH PRESSURE PIPES ASSEMBLY	Spare Part	23624	15%
	DV0.021.710.0.PR DV0.021.75.0.PR	HP PIPE ASSEMBLY FOR CYL 1	Spare Part	6455	15%
	DV0.021.76.0.PR	HP PIPE ASSEMBLY FOR CYL 2		6468	15%
		HP PIPE ASSEMBLY FOR CYL 3	Spare Part		15%
	DV0.021.77.0.PR	HP PIPE ASSEMBLY FOR CYL 6	Spare Part	6468 6468	15%
	DV0.021.78.0.PR	HP PIPE ASSEMBLY FOR CYL 7	Spare Part	6455	15%
	DV0.021.79.0.PR		Spare Part	6852	15%
-	DV0.021.81.0.PR	HP PIPE ASSEMBLY PUMP TO RAIL LHS FROM FWE	Spare Part		
	DV0.021.82.0.PR	HP PIPE ASSEMBLY PUMP TO RAIL RHS FROM FWE	Spare Part	6852	15%
	DV0.022.05.0.00	ADAPTOR (ONE SIDE M16X1.5 & OTHER SIDE M14X1.5)	Spare Part	225	15%
	DV0.022.06.0.00	ELBOW CONNECTION (M16X15) OIL SUPPLY PIPE CRANKCASE TO FUEL PUMP IN	Spare Part	782 10809	15% 15%
	DV0.022.102.0.PR		Spare Part	1154	15%
	DV0.022.103.0.PR DV0.022.106.0.PR	ADAPTOR WITH FERRULE & NUT ASSLY	Spare Part		15%
	DV0.022.106.0.PR	ADAPTOR WITH FERRULE & NUT ASSLY ELBOW CONNECTION	Spare Part	1185 1009	15%
			Spare Part	20169	15%
	DV0.022.110.0.00	FUEL PIPE ASSLY FLEXIBLE HOSE FOR OIL PIPE	Spare Part	4289	15%
	DV0.022.118.0.PR		Spare Part	2302	15%
	DV0.022.15.0.00	NOZZLE LEAK OFF PIPE	Spare Part		
	DV0.022.155.0.PR	FUEL PIPE FOR NOZZLE LEAK OFF	Spare Part	17338	15%
	DV0.022.171.0.PR	PARKAR: GE10LREDCF	Spare Part	505	15%
	DV0.022.175.0.PR	PARKAR: G10LCFX	Spare Part	486	15% 15%
	DV0.022.179.0.PR	PARKAR: RHD10LOMDCF	Spare Part	5631	
	DV0.022.181.0.PR	PARKAR: RBP110X	Spare Part	246	15%
	DV0.022.182.0.PR	ADAPTOR FOR FUEL PIPE	Spare Part	295	15%
	DV0.022.185.0.00	BRACKET-1	Spare Part	812	15%
	DV0.022.187.0.00	BRACKET	Spare Part	523	15%
	DV0.022.188.0.PR	BRACKET	Spare Part	1268	15%
	DV0.022.189.0.00	BRACKET CLAMB (2D)	Spare Part	582	15%
	DV0.022.191.0.PR	CLAMP (2P)	Spare Part	382	15%
	DV0.022.192.0.PR	BRACKET	Spare Part	489	15%
	DV0.022.194.0.PR	HOSE FOR INTAKE 1	Spare Part	19440	15%
	DV0.022.195.0.00	METAL TUBE (FOR FUEL INTAKE-1)	Spare Part	7723	15%
-	DV0.022.196.0.PR	HOSE FOR INTAKE 2	Spare Part	17821 5975	15%
	DV0.022.197.0.00	METAL TUBE FOR FUEL INTAKE 2	Spare Part		
	DV0.022.198.0.00	HOSE FOR FIP RETURN	Spare Part	10169	15%
	DV0.022.198.0.PR	HOSE FOR FIP RETURN	Spare Part	17006	15%
	DV0.022.199.0.00	METAL TUBE (FOR FIP RETURN)	Spare Part	6769	15%
	DV0.022.201.0.00	BRACKET (FOR LP PIPE-6)	Spare Part	818	15%
5718	DV0.022.202.0.PR DV0.022.203.0.00	BRACKET (FOR LP PIPE-7) METAL TUBE (FOR NOZZLE LEAKOFF)	Spare Part Spare Part	646 6031	15%
5719					



				Price to	Custom
Sr.No.	Part Number	Part Description	Category	Customer without Vat in	Custom Charge%
				NPR	
5721	DV0.022.204.0.PR	INJECTOR LEAK OFF PIPE	Spare Part	38163	15%
5722	DV0.022.206.0.00	CLAMP FOR FUEL PIPE (ID19.5)	Spare Part	83	15%
5723	DV0.022.207.0.PR	BRACKET MTG. PLATE	Spare Part	3403	15%
5724	DV0.022.208.0.PR	BRACKET	Spare Part	582	15%
5725	DV0.022.209.0.PR	BRACKET	Spare Part	812	15%
5726	DV0.022.211.0.PR	PLATE FOR CLAMP	Spare Part	157	15%
5727	DV0.022.213.0.PR	INJECTOR LEAKOFF PIPE A BANK	Spare Part	15846	15%
5728	DV0.022.214.0.PR	INJECTOR LEAKOFF PIPE B BANK	Spare Part	15938	15%
5729	DV0.022.215.0.PR	FUEL PIPE FROM TEE TO TANK INTERFACE	Spare Part	3455	15%
5730	DV0.022.216.0.PR	FUEL PIPE FROM FILTER TO PUMP LH FROM FE	Spare Part	6477	15%
5731	DV0.022.217.0.PR	FUEL PIPE FROM FILTER TO ADAPTOR RH FROM FE	Spare Part	6046	15%
5732	DV0.022.218.0.PR	FUEL PIPE FROM ADAPTOR TO PUMP RH FROM F E	Spare Part	3538	15%
5733	DV0.022.219.0.PR	PUMP LEAK OFF PIPE 1 LH FROM F E	Spare Part	3246	15%
5734	DV0.022.221.0.PR	PUMP LEAK OFF PIPE 2 LH FROM F E	Spare Part	2511	15%
5735	DV0.022.222.0.PR	PUMP LEAK OFF PIPE RH FROM F E	Spare Part	4406	15%
5736	DV0.022.226.0.PR	RAIL LEAK OFF PIPE ASSEMBLY	Spare Part	6252	15%
5737	DV0.022.228.0.PR	DEARATION PIPE 1 A BANK	Spare Part	6754	15%
5738	DV0.022.229.0.PR	DEARATION PIPE 2 B BANK	Spare Part	7311	15%
5739	DV0.022.370.0.PR	LEAK OFF PIPE ASSEMBLY	Spare Part	40950	15%
5740	DV0.022.47.0.00	ADAPTOR M18 1 5 M14 1 5 FOR FUEL PUMP OIL DRAIN PIPE	Spare Part	243	15%
5741	DV0.022.71.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	3880	15%
5742	DV0.022.72.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	4141	15%
5743	DV0.022.73.0.00	FEED PUMP FUEL IN PIPE: FLEX	Spare Part	4308	15%
5744	DV0.022.74.0.00	FUEL PIPE: PUMP LEAK OFF (FLEX)	Spare Part	3594	15%
5745	DV0.022.76.0.00	FUEL PIPE: NOZZLE LEAK OFF FLEX	Spare Part	2394	15%
5746	DV0.022.77.0.00	CLAMP FOR LOW PRESSURE (3 PIPE)	Spare Part	289	15%
5747	DV0.022.78.0.00	RUBBER SLEEVE FOR LOW PRESSURE 3 PIPE CLAMP	Spare Part	18	15%
5748	DV0.022.86.0.00	CLAMP 2 PIPE	Spare Part	188	15%
5749	DV0.022.94.0.00	DRAIN PIPE (FOR DIESEL DRAIN)	Spare Part	523	15%
5750	DV0.023.02.0.00	JOINT: MAIN AIR PIPE TO INLET MANIFOLD	Spare Part	68	15%
5751	DV0.023.03.0.00	JOINT: BET INLET MANIFOLD & CYL HEAD	Spare Part	58	15%
5752	DV0.023.06.0.00	COVER PLATE FOR INLET MANIFOLD	Spare Part	612	15%
5753	DV0.023.08.0.00	INLET MANIFOLD 2 PORT	Spare Part	13754	15%
5754	DV0.023.09.0.00	INLET MANIFOLD 3 PORT	Spare Part	14815	15%
5755	DV0.023.11.0.00	EXPANSION BELLOW	Spare Part	4628	15%
5756	DV0.023.12.0.00	AIR PIPE CLAMP (BOTTOM)	Spare Part	1154	15%
5757	DV0.023.13.0.00	AIR PIPE CLAMP (TOP)	Spare Part	923	15%
5758	DV0.023.14.0.00	RUBBER BUSH	Spare Part	1249	15%
5759	DV0.024.05.0.00	EXPANSION BELLOW: EXP M'FOLD	Spare Part	4791	15%
5760	DV0.024.06.0.00	JOINT: EXH MANI & ADAPTOR	Spare Part	1111	15%
5761	DV0.024.07.0.00	JOINT BET EXH MANI AND CYL HEAD	Spare Part	132	15%
5762	DV0.024.08.0.00	JOINT: BET EXH M'FOLD & EXP BELLOW	Spare Part	108	15%
5763	DV0.024.09.0.00	JOINT: BET EXH M'FOLD & CYL HEAD	Spare Part	108	15%
5764	DV0.024.15.0.00	JOINT: BET EXH M'FOLD & CYL HEAD	Spare Part	95	15%
5765	DV0.024.18.0.00	SPECIAL NUT FOR EXHAUST MANIFOLD	Spare Part	329	15%
5766	DV0.024.19.0.00	STUD: EXHAUST MANIFOLD	Spare Part	206	15%
5767	DV0.024.22.0.00	JOINT: BET EXH M'FOLD & CYL HEAD	Spare Part	117	15%
5768	DV0.024.24.0.00	EXHAUST MANIFOLD L H 3 PORT	Spare Part	20354	15%
5769	DV0.024.25.0.00	EXHAUST MANIFOLD (L.H. 2 PORT)	Spare Part	22184	15%
5770	DV0.024.26.0.00	EXHAUST MANIFOLD (RH 3 PORT)	Spare Part	19535	15%
5771	DV0.024.27.0.00	EXHAUST MANIFOLD R H 2 PORT	Spare Part	18766	15%
5772	DV0.024.35.0.00	JOINT BET TURBO ADAPTOR EXHAUST MANIFOLD	Spare Part	1311	15%
5773	DV0.025.03.0.00	JOINT: GEAR CASING	Spare Part	597	15%
5774	DV0.025.05.0.00	SOCKET HEAD SCREW (M12 X 165)	Spare Part	1403	15%
5775	DV0.025.14.0.00	GEAR COVER CUM BELL HOUSING	Spare Part	96946	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
5776	DV0.025.17.0.00	DEFLECTOR	Spare Part	1246	15%
5777	DV0.025.18.0.PR	OIL SEAL FLYWHEEL END	Spare Part	3185	15%
5778	DV0.025.19.0.PR	DEFLECTOR FOR FLYWHEEL END	Spare Part	1034	15%
5779	DV0.025.21.0.PR	MUD SLINGER FWE	Spare Part	1292	15%
5780	DV0.026.02.0.00	BOLT: FLYWHEEL	Spare Part	1240	15%
5781	DV0.026.04.0.00	WASHER (FOR FLYWHEEL BOLT)	Spare Part	200	15%
5782	DV0.026.50.0.00	SUB ASSLY OF FLYWHEEL AND STARTER RING	Spare Part	88291	15%
5783	DV0.027.03.0.00	SPECIAL STUD (FOR STARTER)	Spare Part	172	15%
5784	DV0.027.11.0.00	STARTER 50MT	Spare Part	157881	15%
5785	DV0.027.12.0.PR	LUCAS STARTER 9 0KW SM50 SERIES FOR DV ENGINE	Spare Part	191924	15%
5786	DV0.027.13.0.PR	STARTER DELCO REMY 50MT REIL SERIES R50 TYPE 400 RDSO SPECS RDSO PE SPEC AC	Spare Part	258824	15%
5787	DV0.027.14.0.PR	PRESTOLITE STARTER 9KW MS7-303K DESIGN	Spare Part	160998	15%
5788	DV0.029.01.0.00	FAN PULLEY	Spare Part	9720	15%
5789	DV0.029.03.0.00	BRACKET FOR FAN DRIVE MOUNTING	Spare Part	13994	15%
5790	DV0.029.04.0.00	SHAFT: RADIATOR FAN	Spare Part	2637	15%
5791	DV0.029.06.0.00	WASHER (FOR FAN DRIVE PULLEY)	Spare Part	138	15%
5792	DV0.029.07.0.00	SPECIAL STUD	Spare Part	185	15%
5793	DV0.029.15.0.00	FAN SPACER	Spare Part	8203	15%
5794	DV0.029.17.0.00	FAN SPACER 80 MM	Spare Part	15231	15%
5795	DV0.029.18.0.PR	'V' BELT	Spare Part	10283	15%
5796	DV0.029.21.0.PR	V BELT BX 1170 AR EPDM	Spare Part	3634	15%
5797	DV0.029.210.0.00	FAN DRIVE ASM: 3 GROOVE PULLEY	Spare Part	34935	15%
5798	DV0.029.220.0.PR	FAN DRIVE ASM 3 GROOVE PULLEY	Spare Part	38221	15%
5799	DV0.029.30.0.00	FAN DRIVE ASSEMBLY	Spare Part	40104	15%
5800	DV0.029.32.0.00	BEARING HOUSING FOR FAN DRIVE	Spare Part	6698	15%
5801	DV0.030.03.0.00	DAMPER	Spare Part	93857	15%
5802	DV0.030.09.0.00	DAMPER	Spare Part	91580	15%
5803	DV0.030.11.0.PR	TIMING POINER FOR PULLEY	Spare Part	926	15%
5804	DV0.030.12.0.PR	ANGLE STRIP FOR TAPPET FITTING	Spare Part	105	15%
5805	DV0.031.03.0.00	HOSE: CAC	Spare Part	8966	15%
5806	DV0.031.05.0.00	BREATHER PIPE	Spare Part	1305	15%
5807	DV0.031.06.0.00	BREATHER HOSE	Spare Part	2788	15%
5808	DV0.031.21.0.00	CLIP FOR BREATHER PIPE	Spare Part	188	15%
5809	DV0.031.24.0.00	RADIATOR FAN (40")	Spare Part	51661	15%
5810	DV0.031.27.0.PR	44 MULTIWING FAN FOR DV10	Spare Part	48101	15%
5811	DV0.031.30.0.00	RADIATOR	Spare Part	901345	15%
	DV0.031.36.0.PR	RADIATOR PRESSURE CAP	Spare Part	625	15%
5813		COPPER RADIATOR ASSEMBLY	Spare Part	2578402	15%
5814	DV0.031.45.0.PR	Copper Radiator Assembly	Spare Part	986384	15%
5815	DV0.031.51.0.00	HOSE HEAT EXCHANGER TO ENGINE PIPE	Spare Part	1068	15%
5816	DV0.031.52.0.00	HOSE FOR CAC TO HEAT EXCHANGER PIPE	Spare Part	1209	15%
5817	DV0.031.54.0.00	PIPE THERMOSTAT TO HE	Spare Part	9791	15%
5818	DV0.031.56.0.00	SUCTION PIPE (FOR DV10)	Spare Part	6465	15%
5819	DV0.031.56.0.00	JOINT FOR HE	Spare Part	138	15%
5820	DV0.031.70.0.00	BREATHER HOSE	Spare Part	3677	15%
		ALUMINIUM RADIATOR ASSEMBLY	Spare Part	1167794	15%
5821 5822	DV0.031.78.0.PR DV0.031.80.0.00	CLAMP ASSEMBLY FOR WATER OUTLET PIPE	Spare Part	1767794	15%
5823	1	Aluminium Radiator Assembly	Spare Part	506547	15%
	DV0.031.87.0.PR		-		
5824	DV0.031.88.0.PR	Aluminium Radiator Assembly	Spare Part	663883	15%
5825	DV0.031.89.0.00	RADIATOR ASSY WITH CAC (BANCO) FOR DV10 ENGINE FOR CPCB STAGE II STONE CRUSHER	Spare Part	1189101	15%
5826	DV0.031.97.0.PR	HOSE FOR RAW WTAER HE	Spare Part	997	15%
5827	DV0.032.04.0.00	JOINT: ADAPTOR & TURBO	Spare Part	926	15%
5828	DV0.032.06.0.00	JOINT: FLANGE FOR T/C LUBE OIL OUTLET PIPE	Spare Part	31	15%
5829	DV0.032.08.0.00	FLANGE WITH ADAPTOR (FOR TURBO DRAIN)	Spare Part	2265	15% 15%
5830	DV0.032.12.0.00	CLAMPING SPACER	Spare Part	108	



				Price to Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
				NPR	•
5831	DV0.032.18.0.00	TURBO ADAPTOR	Spare Part	5849	15%
5832	DV0.032.19.0.00	TURBO ADAPTOR	Spare Part	5606	15%
5833	DV0.032.28.0.00	OIL SUPPLY PIPE L.H.: MODIFIED M'FOLD (CRANKCASE TO T/C IN)	Spare Part	942	15%
5834	DV0.032.29.0.00	OIL SUPPLY PIPE R.H.: MODIFIED M'FOLD (CRANKCASE TO T/C IN)	Spare Part	978	15%
5835	DV0.032.33.0.00	JOINT	Spare Part	745	15%
5836	DV0.032.38.0.00	OIL SUPPLY PIPE RH- CRANK CASE- TURBOCHARGER	Spare Part	1772	15%
5837	DV0.032.39.0.00	OIL SUPPLY PIPE L.H. FROM CRANKACSE TO TURBOCHARGER	Spare Part	1766	15%
5838	DV0.032.43.0.00	TURBO DRAIN PIPE	Spare Part	7631	15%
5839	DV0.032.46.0.00	ADAPTOR M30X1 5 X BOTH SIDES	Spare Part	908	15%
5840	DV0.032.49.0.PR	COPPER RADIATOR ASSEMBLY	Spare Part	2257994	15%
5841	DV0.032.73.0.00	SUCTION PIPE ENGINE TO RADIATOR	Spare Part	6040	15%
5842	DV0.032.76.0.00	BREATHER PIPE	Spare Part	1498	15%
5843	DV0.032.78.0.00	BRACKET FOR BREATHER PIPE	Spare Part	1609	15%
5844	DV0.032.79.0.00	BREATHER HOSE	Spare Part	2428	15%
5845	DV0.032.97.0.00	LEFT BANK T'CHARGER: DV10	Spare Part	167173	15%
5846	DV0.032.98.0.00	RIGHT BANK T'CHARGER: DV10	Spare Part	167173	15%
5847	DV0.032.98.0.00	AIR PIPE	Spare Part	11040	15%
5848		SUPPORT BRACKET		2812	15%
	DV0.033.104.0.PR		Spare Part		
5849	DV0.033.11.0.00	JOINT: MAIN AIR PIPE HORIZONTAL & VERTICAL	Spare Part	194	15%
5850	DV0.033.116.0.PR	ORING FOR CAC PIPE	Spare Part	252	15%
5851	DV0.033.12.0.00	JOINT: MAIN AIR PIPE AND VER PIPE	Spare Part	142	15%
5852	DV0.033.13.0.00	JOINT: MAIN AIR PIPE HOR+VER	Spare Part	145	15%
5853	DV0.033.14.0.00	JOINT: BET BEND TO AIR PIPE	Spare Part	117	15%
5854	DV0.033.17.0.00	EXHAUST ELBOW (LHS FROM FWE)	Spare Part	6421	15%
5855	DV0.033.18.0.00	EXHAUST ELBOW (RHS FROM FWE)	Spare Part	6898	15%
5856	DV0.033.26.0.00	AIR INLET PIPE T/C TO CAC	Spare Part	13849	15%
5857	DV0.033.27.0.00	JOINT: AIR INLET MANIFOLD	Spare Part	86	15%
5858	DV0.033.28.0.00	AIR INLET PIPE FROM CAC	Spare Part	17483	15%
5859	DV0.033.33.0.00	V CLAMP: TURBO	Spare Part	1982	15%
5860	DV0.033.34.0.00	TURBO COMPRESSOR OUT PIPE (LH VIEW FROM FWE)	Spare Part	4821	15%
5861	DV0.033.35.0.00	TURBO COMPRESSOR OUT PIPE (RH VIEW FROM FWE)	Spare Part	4551	15%
5862	DV0.033.38.0.00	O RING (FOR COMPRESSOR OUT PIPE)	Spare Part	391	15%
5863	DV0.033.45.0.00	JOINING PLATE	Spare Part	806	15%
5864	DV0.033.61.0.00	MAIN AIR PIPE (HORIZONTAL CAC INLET)	Spare Part	18960	15%
5865	DV0.033.63.0.00	FUEL FILTER BRACKET	Spare Part	1458	15%
5866	DV0.033.67.0.00	V-B& CLAMP (88MM NOMINAL DIA)	Spare Part	3913	20%
5867	DV0.033.70.0.00	EXPANSION BELLOW: 6" ID	Spare Part	15809	15%
5868	DV0.033.73.0.00	JOINT: EXHAUST BEND AND EXPANSION BELLOW	Spare Part	846	15%
5869	DV0.033.74.0.00	JOINT: EXTENSION PIPE AND EXHAUST SILENCER	Spare Part	1815	15%
5870	DV0.033.75.0.00	MAIN AIR PIPE (HORIZONTAL CAC OUT)	Spare Part	28067	15%
5871	DV0.033.79.0.PR	V BAND CLAMP	Spare Part	1006	15%
5872	DV0.033.85.0.PR	AIR PIPE	Spare Part	8145	15%
5873	DV0.033.88.0.00	CAC HOSE HOT SIDE	Spare Part	11440	15%
5874	DV0.033.91.0.00	BRACKET (AIR INLET PIPE FROM CAC)	Spare Part	1369	15%
5875	DV0.033.92.0.00	CLAMP FOR AIR INLET PIPE FROM CAC	Spare Part	252	15%
5876	DV0.033.93.0.PR	CLAMP FOR AIR INLET PIPE FROM CAC	Spare Part	240	15%
5877	DV0.033.94.0.PR	RUBBER SLEEVE FOR AIR INLET PIPE FROM CAC	Spare Part	175	15%
5878	DV0.034.13.0.00	ENGINE MTG. FOOT(PULLEY END)	Spare Part	6763	15%
5879	DV0.035.04.0.00	HOSE REDUCER ELBOW: DV10	Spare Part	3994	15%
5880	DV0.035.08.0.00	HOSE: REDUCER ELBOW	Spare Part	4038	20%
5881	DV0.035.13.0.00	PIPE ASSEMBLY POWDER COATED (DV8/DV10)	Spare Part	2717	20%
5882	DV0.040.01.0.00	FEED PUMP	Spare Part	53079	15%
5883	DV0.040.04.0.00	DRIVE END BEARING SKF No NU2207 ECP	Spare Part	5908	15%
5884	DV0.040.05.0.00	GOVERNOR END BEARING SKF NO 21306 CC	Spare Part	18040	15%
5885	DV0.040.06.0.00	INTERMEDIATE SUPPORT BEARING FOR CAM SHAFT	Spare Part	8135	15%
5505	D V 0.040.00.00.00	INTERNAL DURING TORT DEARING TORT OAK OFFIAT	Opale Palt	0133	1370



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
E006	DV0.040.07.0.00	OIL SEAL FOR DRIVE END	Spare Part	782	15%
5886 5887	DV0.040.07.0.00	OIL SEAL FOR DRIVE END	Spare Part	4289	15%
5888	DV0.040.09.0.00	O RING: OIL SEAL HOUSING	Spare Part	68	15%
5889	DV0.040.10.0.00	FUEL PUMP CAM BOX TYPE	Spare Part	988458	15%
5890	DV0.040.11.0.00	LOCKING NUT FOR GEAR MOUNTING FLANGE	Spare Part	298	15%
5891	DV0.040.115.0.00	GEAR MOUNTING FLANGE HUB	Spare Part	6015	15%
5892	DV0.040.116.0.00	FLAT SEAL FOR OIL SEAL HOUSING	Spare Part	1403	15%
5893	DV0.040.117.0.00	CAM SHAFT	Spare Part	59839	15%
5894	DV0.040.14.0.00	GOVERNOR MOUNTING PLATE	Spare Part	7006	15%
5895	DV0.040.21.0.00	END SUPPORT BUSH FOR RACK	Spare Part	2846	15%
5896	DV0.040.220.0.PR	FUEL PUMP (CAM BOX TYPE)	Spare Part	1429529	15%
5897	DV0.040.23.0.00	RACK SUPPORT ADJ. SCREW	Spare Part	71	15%
5898	DV0.040.24.0.00	DOME NUT FOR RACK SUPPORT	Spare Part	111	15%
5899	DV0.040.25.0.00	LOCKING SCREW FOR RACK	Spare Part	65	15%
5900	DV0.040.27.0.00	PF33 INDIVIDUAL PUMP	Spare Part	28000	15%
5901	DV0.040.30.0.00	ROLLER TAPPET ASSLY.	Spare Part	4769	15%
5902	DV0.040.36.0.00	PF 33 PUMP MOUNTING FLANGE	Spare Part	628	15%
5903	DV0.040.48.0.00	CORE PLUG FOR FUEL PUMP (BOTTOM SIDE)	Spare Part	151	20%
5904	DV0.040.49.0.00	CAP NUT FOR RACK DRIVING SIDE	Spare Part	800	15%
5905	DV0.040.53.0.00	STUD FOR PUMP MOUNTING	Spare Part	83	15%
5906	DV0.040.540.0.PR	FUEL PUMP CAM BOX TYPE	Spare Part	1043918	15%
5907	DV0.040.56.0.00	LINE HAND PRIMER	Spare Part	7367	20%
5908	DV0.040.57.0.00	CORE PLUG FOR FUEL GALLERY	Spare Part	108	15%
5909	DV0.040.58.0.00	BREATHER SCREW	Spare Part	111	15%
5910	DV0.040.59.0.00	VENT FOR BREATHER SCREW	Spare Part	65	15%
5911	DV0.040.61.0.00	LOCK FOR END SUPPORT BUSH	Spare Part	157	15%
5912	DV0.040.63.0.00	WASHER FOR FIP MOUNTING	Spare Part	58	15%
5913	DV0.040.64.0.00	SPHERICAL WASHER: FIP MTG	Spare Part	28	15%
5914	DV0.040.65.0.00	SHIM FOR CAMSHAFT END PLAY (0.5MM THICK)	Spare Part	25	15%
5915	DV0.040.66.0.00	SHIM FOR ROLLER TAPET (2.5MM THICK)	Spare Part	240	15%
5916	DV0.040.67.0.00	SHIM FOR ROLLER TAPPET (2.6MM)	Spare Part	240	15%
5917	DV0.040.68.0.00	SHIM FOR ROLLER TAPPET (2.7MM THICK	Spare Part	240	15%
5918	DV0.040.69.0.00	SHIM FOR CAMSHAFT ENDPLAY (1.00MM THICK)	Spare Part	62	15%
5919	DV0.040.71.0.00	DOME NUT FOR RACK LOCKING SCREW	Spare Part	92	15%
5920	DV0.040.74.0.00	SHIM FOR ROLLER TAPPET (2.8MM THICK)	Spare Part	240	15%
5921	DV0.040.75.0.00	SHIM FOR ROLLER TAPPET (2.9MM THICK)	Spare Part	240	15%
5922	DV0.040.81.0.00	BANJO BOLT FOR FIP OIL SUPPLY M8 X 1 25	Spare Part	62	15%
5923	DV0.040.82.0.00	WASHER FOR CAP NUT	Spare Part	-	15%
5924	DV0.040.85.0.00	LINKAGE ASSEMBLY FOR GOVERNOR	Spare Part	3055	15%
5925	DV0.040.91.0.00	HELICOIL (M14X15X14 MM LONG)	Spare Part		15%
		SPEED CONTROL UNIT	Spare Part		15%
5926 5927	DV0.040.92.0.00 DV0.040.93.0.00	ACTUATOR: 24V	Spare Part		15%
	1	JOINT: GOVERNOR MOUNTING PLATE	Spare Part Spare Part	366	15%
5928	DV0.040.98.0.00				15%
5929	DV0.041.03.0.00	ADAPTOR PIPE FOR CENTRIFUGE MTG	Spare Part	3028	
5930	DV0.041.04.0.00	JOINT: CENTRIFUGAL ADAPTOR & FILTER	Spare Part	77	15%
5931	DV0.041.07.0.00	GASKET: OIL SUMP AND CENTRIFUGE ADAPTOR	Spare Part		15%
5932	DV0.041.15.0.00	ADAPTOR FOR CENTRIFUGE FILTER	Spare Part		15%
5933	DV0.041.16.0.00	OIL FILLING PIPE	Spare Part		15%
5934	DV0.041.17.0.00	O-RING FOR OIL FILLING PIPE	Spare Part		15%
5935	DV0.041.20.0.00	CENTRIFUGE MTG. ASSLY	Spare Part	16366	15%
5936	DV0.041.25.0.00	CENTRIFUGAL OIL CLEANER (BAND DESIGN)	Spare Part		15%
5937	DV0.041.42.0.00	CENTRIFUGE ADAPTOR	Spare Part		15%
5938	DV0.041.46.0.00	OIL INLET PIPE FROM CRANKCASE TO CENTRIFUGE FILTER	Spare Part	1655	15%
5939	DV0.041.80.0.00	OIL INLET PIPE ASSLY (FROM CRANKCASE TO CENTRIFUGE FILTER)	Spare Part	868	15%
5940	DV0.042.03.0.00	JOINT: DELIVERY TUBE FLANGE	Spare Part	43	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		'		without Vat in NPR	Charge%
5941	DV0.042.05.0.00	O RING DIA 36: L.O. DELIVERY TUBE	Spare Part	111	15%
5942	DV0.042.07.0.00	CLAMP (FOR OIL DELIVERY TUBE)	Spare Part	71	15%
5943	DV0.042.08.0.00	STRAP	Spare Part	52	15%
5944	DV0.042.09.0.00	RUBBER BUSH	Spare Part	1265	15%
5945	DV0.042.10.0.00	DELIVERY TUBE	Spare Part	3988	15%
5946	DV0.043.05.0.00	JOINT: SUCTION TUBE FLANGE	Spare Part	43	15%
5947	DV0.043.10.0.00	SUCTION TUBE SUB ASSLY	Spare Part	4948	15%
5948	DV0.044.04.0.00	DOWEL BUSH FOR ALTERNATOR MOUNTING BRACKET	Spare Part	83	15%
5949	DV0.044.08.0.00	ALTERNATOR PULLEY	Spare Part	2062	15%
5950	DV0.044.11.0.00	STUD: ALTERNATOR	Spare Part	662	15%
5951	DV0.044.12.0.00	SWIVEL PIECE	Spare Part	782	15%
5952	DV0.044.13.0.00	EYE BOLT: ALTERNATOR	Spare Part	772	15%
5953	DV0.044.14.0.00	CHARGING ALTERNATOR BRACKET	Spare Part	2385	15%
5954	DV0.044.15.0.00	DOWEL BOLT: ALTERNATOR	Spare Part	554	15%
5955	DV0.045.03.0.00	COUNTER SHUNK HEAD SCREW-DV INJECTOR LEAKOFF	Spare Part	243	15%
5956	DV0.045.30.0.00	CLAMP ASSEMBLY FOR LEAK OFF PIPE & HPPIPE	Spare Part	172	15%
5957	DV0.046.01.0.00	BREATHER PLATE	Spare Part	5785	15%
5958	DV0.046.02.0.00	BREATHER ADAPTOR	Spare Part	2015	15%
5959	DV0.046.03.0.00	O RING: BREATHER PLATE	Spare Part	43	15%
5960	DV0.046.04.0.00	JOINT: BREATHER PLATE & ADAPTER	Spare Part	37	15%
5961	DV0.046.07.0.00	CRANKCASE BREATHER	Spare Part	28489	15%
5962	DV0.046.09.0.00	'O' RING	Spare Part	332	15%
5963	DV0.048.02.0.00	HOSE: RADIATOR TO ENGINE	Spare Part	3846	15%
5964	DV0.051.16.0.00	HEAT SHIELD (R.H)	Spare Part	8505	15%
5965	DV0.051.17.0.00	HEAT SHIELD (L.H)	Spare Part	8111	15%
5966	DV0.051.17.0.00	UPPER HEAT SHIELD LH FROM FWE	Spare Part	65202	15%
5967	DV0.051.53.0.PR	LOWER HEAT SHIELD LH FROM FWE	Spare Part	28384	15%
5968	DV0.051.54.0.PR	UPPER HEAT SHIELD RH FROM FWE	Spare Part	59008	15%
5969	DV0.051.55.0.PR	LOWER HEAT SHIELD RH FROM FWE	Spare Part	29304	15%
5970	DV0.051.56.0.PR	END COVER FOR HEAT SHIELD L.H. FROM FWE	Spare Part	9932	15%
5971	DV0.051.57.0.PR	END COVER FOR HEAT SHIELD R H FROM FWE	Spare Part	9775	15%
5972	DV0.051.60.0.PR	HEAT SHIELD SUB ASSEMBLY RH SIDE FROM FWE END	Spare Part	96208	15%
5973	DV0.051.63.0.PR	BRACKET-1 (FOR HEAT SHIELD MTG.)	Spare Part	1351	15%
5974	DV0.051.64.0.PR	BRACKET-2 (FOR HEAT SHIELD MTG.)	Spare Part	1345	15%
5975	DV0.051.65.0.PR	BRACKET-3 (FOR HEAT SHIELD MTG.)	Spare Part	1345	15%
5976	DV0.051.66.0.PR	BRACKET (FOR HEAT SHIELD WITG.)	Spare Part	1046	15%
5977	DV0.051.67.0.PR	HEAT SHIELD COVER LH SIDE FROM FWE	Spare Part	53815	15%
5978		HEAT SHIELD COVER R H SIDE FROM FWE	-	49759	15%
	DV0.051.68.0.PR		Spare Part		15%
5979	DV0.051.70.0.PR	HEAT SUB ASSEMBLY LH SIDE FROM FWE END	Spare Part	96208	20%
5980	DV0.053.05.0.00	SPINON PRELINE FILTER CTG	Filter	11491 4181	15%
5981 5982	DV0.061.01.0.00	ANTI VIBRATION MOUNTS ANTI VIBRATION MOUNT PGS 3 N1 B POLYBOND MAKE	Spare Part Spare Part	7058	15%
	DV0.061.03.0.00	ANTI VIBRATION MOUNT PGS 3 N1 B POLYBOND MAKE			
5983	DV0.061.07.0.00		Spare Part	6652	15%
5984	DV0.061.15.0.00	ANTI VIBRATION MOUNTS	Spare Part	5338	15%
5985	DV0.061.16.0.00	ANTI VIBRATION MOUNTS	Spare Part	5609	15% 15%
5986	DV0.061.17.0.00	ANTI VIBRATION MOUNTS	Spare Part	4625	
5987	DV0.061.18.0.PR	AVM FOR 500KVA RDSO PROJECT GF B 70 DRG NO 09082363 ISSUE A	Spare Part	20910	15%
5988	DV0.064.01.0.00	JOINT: DV10 TURBO	Spare Part	1622	15%
5989	DV0.069.04.0.00	FUEL PIPE ADAPTOR	Spare Part	222	15%
5990	DV0.069.08.0.00	ADAPTOR FOR FUEL INLET	Spare Part	200	15%
5991	DV0.069.47.0.00	ADAPTOR	Spare Part	308	15%
5992	DV0.069.65.0.00	OIL DRAIN PIPE (FIP TO CRANK CASE)	Spare Part	1065	15%
5993	DV0.069.85.0.00	LEAK OFF PIPE	Spare Part	24030	15%
5994	DV0.071.01.0.00	VENT PIPE	Spare Part	1822	15%
5995	DV0.071.02.0.00	ELBOW CONNECTION	Spare Part	957	



C: No	Doub Neurobou	Port Possifities	Catagony	Price to Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
		VENT DIDE FOR DADIATOR TECHNIA	0 0 1	NPR	450/
5996	DV0.071.03.0.00	VENT PIPE FOR RADIATOR-750 KVA	Spare Part	1686	15%
5997	DV0.072.04.0.00	IMV SOLENOID 43845	Spare Part	65482	15%
5998	DV0.072.06.0.PR	COMMON RAIL FUEL PUMP GEAR	Spare Part	11695	15%
5999	DV0.072.60.0.00	COMMON RAIL FUEL PUMP ASSEMBLY	Spare Part	1131431	15%
6000	DV0.074.09.0.00	JOINT FOR BARRING DEVICE PLASTIC CAP CAC OUTLET	Spare Part	108	15% 15%
6001	DV0.075.06.0.00	FAN CLUTCH ASEMBLY FOR DV10 12 EMC 205 MM LENGTH	Spare Part	330786	15%
6003	DV0.076.40.0.00	FLYWHEEL HOUSING	Spare Part Spare Part	103251	15%
6004	DV0.086.16.0.00 DV0.086.37.0.00	HOSE BET INLET MANIFOLD CAC ADAPTOR R H	Spare Part	1643	15%
6005	DV0.086.39.0.00	COVER FOR GEAR CASING		1742	15%
6006	DV0.086.39.0.00	SPARKPLUG FOR DV0 GAS ENGINE	Spare Part Spare Part	8363	15%
6007	DV0.087.52.0.PR	IGNITION COIL FOR DV GAS ENGINES	Spare Part	33046	15%
6008	DV0.087.53.0.PR	UEGO SENSOR FOR GAS ENGINES	Spare Part	19258	15%
6009	DV0.111.10.0.PR	ENGINE WIRING HARNESS SF DV10 CPCB IV ECU CHAMBER 1	Spare Part	33590	15%
6010	DV0.111.10.0.PR	ENGINE WIRING HARNESS SF DV10 CPCB IV ECU CHAMBER 1	Spare Part	66008	15%
6011	DV0.111.30.0.PR	ENGINE WINING HARNESS SF DV10 CPCB IV ECU CHAMBER 3	Spare Part	17997	15%
6012	DV0.111.40.0.PR	ENGINE WINING HARNESS SF DV10 CPCB IV ECU CHAMBER 4	Spare Part	23347	15%
6013	DV0.111.50.0.PR	ENGINE WIRING HARNESS SF DV10 CPCB IV ECU CHAMBER 5	Spare Part	57685	15%
6014	DV0.111.60.0.PR	ENGINE WIRING HARNESS SF DV10 CPCB IV ECU CHAMBER 6	Spare Part	12581	15%
6015	DV0.111.70.0.PR	ENGINE WIRING HARNESS SF DV10 CPCB IV ECU CHAMBER 7	Spare Part	11458	15%
6016	DV0.111.80.0.PR	ENGINE WIRING HARNESS SF DV10 CPCB IV ECU CHAMBER 8	Spare Part	36129	15%
6017	DV0.111.80.0.PK	RADIATOR DRAIN PIPE FOR DV	Spare Part	868	15%
6018	DV0.159K.01.0.00	GENSET KIT (RDSO POWER CAR)	Spare Part	609967	15%
6019	DV0.188.20.0.00			174505	15%
6020	DV0.1989.01.0.PR	Silencer Assembly ECU EPC 1830 31 MD1CE200	Spare Part	557433	15%
6021	DV0.477.13.0.PR	HYDRAULIC PIPE FROM SUPPLY MODULE OUT TO DOSING MODULE IN 3 LHS EGT F W E	Spare Part Spare Part	1585	15%
6022	DV0.477.17.0.PR	HYDRAULIC PIPE FROM SUPPLY MODULE OUT TO DOSING MODULE IN 3 RHS EGT F W E	Spare Part	1575	15%
6023	DV0.505.02.0.00	HOSE CLAMP	Spare Part	442	20%
6024	DV0.505.07.0.00	SUPPORT FOR AIR CLEANER PIPE	Spare Part	4772	15%
6025	DV0.505.18.0.00	AIR PIPE	Spare Part	18907	15%
6026	DV0.505.30.0.00	AIR CLEANER KIT LH	Spare Part	101810	20%
6027	DV0.505.40.0.00	AIR CLEANER KIT RH	Spare Part	93023	20%
6028	DV0.505.41.0.PR	AIR FILTER PRIMARY	Spare Part	27165	20%
6029	DV0.505.42.0.PR	AIR FILTER SAFETY	Spare Part	10117	20%
6030	DV0.506.01.0.00	RUBBER SLEEVE	Spare Part	594	15%
6031	DV0.506.30.0.00	AIR CLEANER ASSEMBLY (L.H SIDE)	Spare Part	54757	20%
6032	DV0.506.40.0.00	AIR CLEANER ASSEMBLY (R.H SIDE)	Spare Part	54959	20%
6033	DV0.507.02.0.00	FUEL PIPE: FUEL TANK TO LEAK OFF PIPE	Spare Part	7625	15%
6034	DV0.507.02.0.00	FUEL PIPE FUEL TANK TO LEAR OFF PIPE FUEL PIPE FUEL TANK -FUEL FILTER	Spare Part	7025	15%
6035	DV0.507.03.0.00	ADAPTOR (M22 X 15 - M18 X 15)	Spare Part	360	15%
6036	DV0.507.15.0.00	FUEL PIPE - PRE FILTER -FIP	Spare Part	1357	15%
6037	DV0.507.19.0.00	ADAPTOR (M8 X125 - M27 X 15)	Spare Part	652	15%
6038	DV0.507.25.0.00	INLET & OUTLET CONNECTION	Spare Part	831	15%
6039	DV0.507.34.0.PR	FUEL PIPE FROM PRE FILTER TO FEED PUMP	Spare Part	2363	15%
6040	DV0.639.01.0.PR	24V 55A CHARGING ALTERNATOR BOSCH	Spare Part	55904	15%
6041	DV0.801.15.0.00	KOEL GREEN Alternator KG 500 S T Frame L KG 47 2 M7 SAE 1 14 415V 50 Hz 0 8 PF WITH TER	Spare Part	1730281	15%
6042	DV0.801.33.0.PR	500 kVA 750V AC 50Hz 3 PHASE 4 WIRE LONG COUPLED FRAME LSTR 472 L ALTERNATOR F	Spare Part	3667643	15%
6043	DV0.801.37.0.SP	OVER VOLTAGE PROTECTION UNIT	Spare Part	354229	15%
6044	DV0.802.15.0.00	FUEL LEVEL SENSOR 225MM	Spare Part	2883	15%
6045	DV0.802.25.0.00	FUEL LEVEL SENSOR 227MM	Spare Part	2462	15%
6046	DV0.802.35.0.00	FUEL LEVEL SENSOR- 220MM HEIGHT	Spare Part	2828	15%
6047	DV0.802.45.0.PR	FUEL TRANSDUCER SMART CAP 225 ETH	Spare Part	14898	15%
6048	DV0.802.52.0.PR	4 20mA PRESSURE SENSOR 0 10 Bar Output 4 20mA MAKE HONEYWELL PART NO PX3AN2B	Spare Part	9228	15%
6049	DV0.802.53.0.PR	500KVA HARNESS KIT FOR PHASE -1 CHANGES	Spare Part	11031	15%
	- * U.UUE.UU.U.I I\	SOUTH AND THE SOUTH AND A SOUT	opaic rait	11001	1370



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
				NPR	
6051	DV0.806.89.0.PR	DRAIN PIPE FOR 500 KVA RDSO PROJECT	Spare Part	428	15%
6052	DV0.806.91.0.PR	DRAIN PIPE FROM SUMP TO PUMP 500 KVA RDSO PROJECT	Spare Part	1458	15%
6053	DV0.806.93.0.PR	BREATHER HOSE FOR 500 KVA RDSO PROJECT	Spare Part	803	15%
6054	DV0.807.02.0.PR	BELT GUARD	Spare Part	21852	15%
6055	DV0.807.03.0.PR	AVM OF RADIATOR FOR 500KVA RDSO PROJECT GF B 60 DRG NO 09082722 ISSUE B	Spare Part	19864	15%
6056	DV0.807.111.0.00	DSE 2133 RTD THERMOCOUPLE INPUT EXPANSION MODULE	Spare Part	100863	15%
6057	DV0.807.19.0.PR	ELECTROMAGNETIC VACUUM INDICATOR EMVI WITH CONNECTOR	Spare Part	5941	15%
6058	DV0.807.21.0.PR	MATCHWELD COUPLINGS DIA 76 1	Spare Part	13388	15%
6059	DV0.807.24.0.PR	'U' CLAMP FOR FUEL FLOW METER CLAMPING	Spare Part	194	15%
6060	DV0.807.26.0.PR	FLEXIBLE COUPLING VULKON	Spare Part	275058	15%
6061	DV0.807.34.0.PR	TUBULAR LEAD ACID BATTERY 8V 290AH RDSO APPROVED IS 7624 COMPLIANT MAKE EXIL	Spare Part	153875	15%
6062	DV0.807.48.0.PR	AIR FLOW PADDLE SWITCH	Spare Part	73082	15%
6063	DV0.807.52.0.PR	FLOAT TYPE LEVEL SENSOR THREADING EFFECTIVE LENGTH 90 MM	Spare Part	3606	15%
6064	DV0.807.72.0.PR	VENTILATION BLOWER ASSEMBLY COMPLETE WITH FAN MOTOR HOUSING BRACKETS SUIT	Spare Part	436203	15%
6065	DV0.807.89.0.PR	ROOF TOP AIR FILTER WITH LOUVER CONFIG 1X1	Spare Part	37572	15%
6066	DV0.807.98.0.PR	JUNCTION BOX FOR FUEL RETURN PIPES	Spare Part	5215	15%
6067	DV0.808.102.0.PR	EXHAUST PIPE SUPPORT ASSEMBLY	Spare Part	3477	15%
6068	DV0.808.111.0.PR	SUCTION PIPE	Spare Part	7166	15%
6069	DV0.808.112.0.PR	COOLANT PIPE FROM THERMOSTST TO RADIATOR IN DIA 76 2MM	Spare Part	8028	15%
6070	DV0.808.113.0.PR	AIR INLET PIPE FROM ENGINE OUTLET TO RADIATOR IN	Spare Part	28384	15%
6071	DV0.808.114.0.PR	AIR INLET PIPE FROM RADIATOR OUTLET TO ENGINE IN	Spare Part	35636	15%
6072	DV0.808.117.0.PR	FLEXIBLE AIR VENT PIPE	Spare Part	2615	15%
6073	DV0.808.128.0.PR	HEAT SHIELD FOR PRIMARY SILENCER	Spare Part	276532	15%
6074	DV0.808.129.0.PR	HEAT SHIELD FOR SECONDARY SILENCER	Spare Part	97703	15%
6075	DV0.808.132.0.PR	EXHAUST GASKET	Spare Part	6603	15%
6076	DV0.808.141.0.PR	BRACKET FOR FUEL WATER SEPERATOR MOUNTING	Spare Part	2175	15%
6077	DV0.808.143.0.PR	COVER FOR FUEL PIPES AT STARTER SIDE	Spare Part	9418	15%
6078	DV0.808.144.0.PR	FLEXIBLE INLET FUEL PIPE FROM FILTER OUTLET TO ENGINE INLET	Spare Part	25018	15%
6079	DV0.808.145.0.PR	FLEXIBLE INLET FUEL PIPE 1 FROM FILTER OUTLET TO ENGINE INLET	Spare Part	24578	15%
6080	DV0.808.146.0.PR	METALLIC INLET FUEL PIPE FROM FILTER OUTLET TO ENGINE INLET	Spare Part	17529	15%
6081	DV0.808.147.0.PR	METALLIC INLET FUEL PIPE-1 FROM FILTER OUTLET TO ENGINE INLET	Spare Part	19551	15%
6082	DV0.808.148.0.PR	ADAPTOR M16X1 5 M SEAL XM22X1 5 M PARKER PART NO GEO15LM16X1 5OMDCF	Spare Part	8501	15%
6083	DV0.808.149.0.PR	FUEL PIPE FROM FLOW METER OUTLET TO FILTER INLET	Spare Part	20437	15%
6084	DV0.808.152.0.PR	FUEL RETURN PIPE FROM TEE TO FLOW METER	Spare Part	22492	15%
6085	DV0.808.154.0.PR	TUBE CLAMPS FOR 2 TUBES PARKER PART NO RBP215X	Spare Part	366	15%
6086	DV0.808.155.0.PR	TUBE CLAMPS FOR 1 TUBE PARKER PART NO RAP16 215	Spare Part	502	15%
6087	DV0.808.156.0.PR	RETURN FUEL PIPE FROM ENGINE OUTLET TO FLOW METER	Spare Part	22043	15%
6088	DV0.808.157.0.PR	UNION ADAPTOR M22X1 5 X M22X1 5 PARKER PART NO G15LCFX	Spare Part	705	15%
6089	DV0.808.159.0.PR	RETURN FUEL PIPE FROM ENGINE OUTLET TO FLOW METER	Spare Part	12729	15%
6090	DV0.808.162.0.PR	METALLIC INLET FUEL PIPE FROM WATER SEPERATOR TO FLOW METER	Spare Part	9178	15%
6091	DV0.808.163.0.PR	FLEXIBLE INLET FUEL PIPE FROM WATER SEPERATOR TO FLOW METER	Spare Part	24944	15%
6092	DV0.808.164.0.PR	METALLIC RETURN FUEL PIPE FROM FLOW METER TO COACH TANK	Spare Part	15231	15%
6093	DV0.808.165.0.PR	FLEXIBLE RETURN FUEL PIPE FROM FLOW METER TO COACH TANK	Spare Part	32895	15%
6094	DV0.808.166.0.PR	METALLIC INLET FUEL PIPE FROM COACH TANK TO WATER SEPERATOR	Spare Part	10864	15%
6095	DV0.808.167.0.PR	TEE CONNECTION M22X1 5 F XM22X1 5 M XM22X1 5 M PARKER PART NO EL15LOMDCF	Spare Part	3206	15%
6096	DV0.808.168.0.PR	BRACKET FOR FUEL FILTER MOUNTING	Spare Part	6898	15%
6097	DV0.808.171.0.PR	ADAPTOR M22X1 5 M SEAL XM22X1 5 M PARKER PART NO GE15LM22X1 5EDOMDCF	Spare Part	1228	15%
6098	DV0.808.172.0.PR	RETURN FUEL PIPE FROM ENGINE OUTLET TO FLOW METER	Spare Part	20707	15%
6099	DV0.808.176.0.PR	ADAPTOR REDUCER M22X1 5 M XM16X1 5 M PARKER PART NO GR15 10LCFX	Spare Part	852	15%
6100	DV0.808.182.0.PR	ADAPTOR REDUCER M22X1 5 F X1 8 NPT F PARKER PART NO ADAP 150D F 1 8NPT F	Spare Part	2015	15%
6101	DV0.808.183.0.PR	COVER FOR FUEL PIPES AT ALTERNATOR BACK SIDE	Spare Part	5292	15%
6102	DV0.808.198.0.PR	HOSE FOR AIR CLEANER	Spare Part	4741	15%
6103	DV0.808.205.0.PR	ADAPTOR - M30X2(M)X 1" B.S.P(F)	Spare Part	1360	15%
6104	DV0.808.208.0.PR	HOSE CLAMP T BOLT	Spare Part	582	15%
6105	DV0.808.212.0.PR	ADAPTOR M22X1 5 M X 1 B S P F	Spare Part	1452	15%



				Price to	
C. N.	David November		Catanami	Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
0400	D) (0 000 040 0 DD	DDACKET FOR FILE RIDE GURDORT	0 Dt	NPR	450/
6106	DV0.808.213.0.PR	BRACKET FOR FUEL PIPE SUPPORT	Spare Part	1117	15%
6107	DV0.808.214.0.PR	BRACKET FOR FUEL PIPE SUPPORT	Spare Part	1175	15%
6108	DV0.808.216.0.PR	CLAMP FOR ENGINE HARNESS	Spare Part	385	15%
6109	DV0.808.217.0.PR	TRAY FOR FUEL COLLECTOR	Spare Part	557	15%
6110	DV0.808.221.0.PR	METALLIC INLET PIPE FROM FLOW METER TO PUMP	Spare Part	7972	15%
6111	DV0.808.222.0.PR	BRACKET FOR PUMP	Spare Part	6705	15%
6112	DV0.808.223.0.PR	TUBE CLAMPS PLATE FOR RBP215X PARKER PART NO DPB2X	Spare Part	206	15%
6113	DV0.808.224.0.PR	DIGITAL FUEL FLOW METER	Spare Part	208920	15%
6114	DV0.808.226.0.PR	RETURN FUEL PIPE FROM ENGINE OUTLET TO FLOW METER	Spare Part	22203	15%
6115	DV0.808.227.0.PR	RETURN FUEL PIPE FROM ENGINE OUTLET TO FLOW METER	Spare Part	25061	15%
6116	DV0.808.25.0.PR	FLEXIBLE VENT PIPE FOR 500KVA RDSO PROJECT	Spare Part	4040	15%
6117	DV0.808.32.0.PR	JOINT FOR EXHAUST JUNCTION BOX	Spare Part	2901	15%
6118	DV0.808.34.0.PR	JOINT FOR AIR SUCTION JUNCTION BOX	Spare Part	4080	15%
6119	DV0.808.36.0.PR	HOSE FOR AIR SUCTION PIPE	Spare Part	13877	15%
6120	DV0.808.37.0.PR	CLAMP FOR REDUCER HOSE	Spare Part	548	15%
6121	DV0.808.39.0.00	ADAPTOR FOR LUBE OIL TEMP SENSOR	Spare Part	431	15%
6122	DV0.808.41.0.PR	ADAPTOR FOR FUEL INLET AND RETURN PIPE ON COACH PIPING	Spare Part	766	15%
6123	DV0.808.59.0.PR	JOINT FOR AIR SUCTION MOUNTING ON CAOCH	Spare Part	3295	15%
6124	DV0.808.64.0.PR	COOLANT PIPE FROM THERMOSTST TO RADIATOR IN	Spare Part	4458	15%
6125	DV0.808.65.0.PR	PIPE FOR RADIATOR OUT	Spare Part	4065	15%
6126	DV0.808.67.0.PR	COOLANT PIPE FROM THERMOSTST TO RADIATOR IN DIA 76 2MM	Spare Part	4018	15%
6127	DV0.808.78.0.PR	EXPANSION BELLOW	Spare Part	28224	15%
6128	DV0.808.82.0.PR	HOSE FOR AIR SUCTION PIPE	Spare Part	6732	15%
6129	DV0.808.83.0.PR	SUPPORT BRACKET FOR EXHAUST JUNCTION BOX	Spare Part	1898	15%
6130	DV0.808.84.0.PR	HOSE CLIP T BOLT TYPE	Spare Part	542	15%
6131	DV0.809.17.0.00	BASEPLATE ACCESSORIES FOR PUMP FLOW METER & FUEL FILTER MOUNTING	Spare Part	27301	15%
6132	DV0.809.18.0.00	ACCESSORIES FOR PUMP FLOW METER & FUEL FILTER MOUNTING	Spare Part	27046	15%
6133	DV0.809.19.0.00	ACCESSORIES FOR WATER SEPERATOR MOUNTING	Spare Part	2994	15%
6134	DV0.812.22.0.PR	COOLENT LEVEL SWITCH FOZMULA MAKE MODEL S273 CAPACITANCE TYPE	Spare Part	23747	15%
6135	DV0.821.12.0.PR	AIR INLET HOSE FOR 101 6 OD	Spare Part	1751	15%
6136	DV0.831.16.0.PR	DOOR VISOR FOR DV SERIES CANOPY	Spare Part	3634	15%
6137	DV0.853.07.0.00	RELAY BOARD 1.5 CH 70 A CAPA	Spare Part	3778	15%
6138	DV0.853.12.0.00	RELAY BOARD 4 CHANNEL	Spare Part	3809	15%
6139	DV0.853.41.0.PR	AVR TO PANEL WIRING HARNESS	Spare Part	1286	15%
6140	DV0.853.45.0.PR	COMMUNICATION CABLE AND USB CONVERTER CABLE	Spare Part	16237	15%
6141	DV0.853.50.0.00	CONNECTOR FOR PANEL SIDE	Spare Part	1791	15%
6142	DV0.853.60.0.00	CONNECTOR FOR PANEL SIDE	Spare Part	1003	15%
6143	DV0.854.09.0.00	RELAY BOARD 24V DC 2 CH 2C/O	Spare Part	5101	15%
6144	DV0.858.01.0.PR	ASSEMBLY FOR KRM UNIT FOR KG1500 WITH PAKAGE	Spare Part	20194	15%
6145	DV0.858.05.0.00	GENSET CONTROLLER 7320 MK II	Spare Part	107177	15%
6146	DV0.858.06.0.PR	KG1500 - SYNCHRONIZATION CONTROLLER (Model No - 8440-2219)	Spare Part	270803	15%
6147	DV0.859.10.0.PR	ENGINE CONTROL PANEL ASSEMBLY WITH EASY GEN 2500 CONTROLLER	Spare Part	69110	15%
6148	DV0.861.12.0.PR	FRESH AIR IN TEMPRATURE SENSOR TYPE RTD WITH MS 3102R 10SL 3P CONNECTOR ADJUS	Spare Part	21714	15%
6149	DV0.861.13.0.PR	DG COMPARTMENT COACH TEMPTEMPRATURE SENSOR TYPE RTD WITH MS 3102R 10SL 3P (Spare Part	28800	15%
6150	DV0.861.14.0.PR	EXHAUST TEMPERATURE SENSOR K THERMOCOUPLE WITH OMEGA MAKE SOCKET OSTW K F	Spare Part	27686	15%
6151	DV0.861.31.0.00	24V 2.5AMP TRICKLE CHARGER	Spare Part	6781	15%
6152	DV0.862.36.0.00	AVR MODEL TAVR 60	Spare Part	292676	15%
6153	DV0.868.07.0.00	P T 800 415 V 5VA CLASS 1 MAKE SUPER COIL NANAP TRANSFORMERS PVT LTD	Spare Part	3492	15%
6154	DV0.868.10.0.PR	GENSET CONTROL PANEL ASSEMBLY WITH KG 745 UNIT	Spare Part	112128	15%
6155	DV0.900.01.0.SP	PC ENGINE P1 B CHECK KIT DV0 9019 DV0 9021 DV0 9027	Spare Part	113731	15%
6156	DV0.901.11.0.00	FLOAT LEVEL SENSOR	Spare Part	6538	15%
6157	DV0.901.25.0.00	FLOAT TYPE LEVEL SENSOR	Spare Part	7101	15%
6158	DV0.901.29.0.00	FLOAT LEVEL SENSOR 105 LEN	Spare Part	6865	15%
6159	DV0.902.01.0.SP	PC ENGINE P1 B CHECK KIT PHASE II DV0 9026	Spare Part	110525	15%
6160	DV0.902.50.0.PR	FLOAT TYPE LEVEL SENSOR THREADING 1 BSP EFFECTIVE LENGTH 137 MM	Spare Part	5172	15%
0100	2.0.002.00.0.1 1	. 25 2 22 VEL GENOON TIME ABINO 1 BOT ETTEOTIVE EENOTH TO WIN	Opare r art	5172	1370



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
				without Vat in NPR	Charge%
6161	DV0.903.01.0.SP	PC ENGINE C CHECK KIT DV0 9019 9021	Spare Part	142275	15%
6162	DV0.904.01.0.SP	PC ENGINE C CHECK KIT DV0 9027	Spare Part	146152	15%
6163	DV0.905.01.0.SP	PC ENGINE C CHECK KIT DV0 9026	Spare Part	142423	15%
6164	DV0.907.10.0.00	BATTERY CABLE ASSEMBLY 70 SQ.MM	Spare Part	9634	15%
6165	DV0.910.20.0.00	ENGINE WIRING HARNESS ASSLY: DV0	Spare Part	14757	15%
6166	DV0.910.50.0.00	ENGINE WIRING HARNESS ASSEMBLY FOR DV10 ENGINE WITH KG545 UNIT 4 20 MA GEMS LOP	Spare Part	11215	15%
6167	DV0.910.60.0.00	ENGINE WIRING HARNESS ASSEMBLY:DV10 ENGINE WITH KG545 UNIT & 4-20 MA GEMS LOP SE	Spare Part	27501	15%
6168	DV0.910.90.0.00	ENGINE WIRING HARNESS SF DV10 ENGINE	Spare Part	27978	15%
6169	DV0.911.20.0.00	ENGINE CONTROL PANEL TO ALTERNATOR CONTROL HARNESS	Spare Part	4221	15%
6170	DV0.911.40.0.00	ENGINE CONTROL PANEL TO ALTERNATOR CONTROL HARNESS ASSEMBLY FOR C T 3PH SU	Spare Part	3468	15%
6171	DV0.911.70.0.00	ENGINE CONTROL PANEL TO ALTERNATOR CONTROLHARNESS ASSEMBLY FOR C T 3 PH SU	Spare Part	2951	15%
6172	DV0.918.70.0.PR	ENGINE WIRING HARNESS ASSEMBLY FOR DV10 ENGINE WITH NCV CONDUIT T	Spare Part	111168	15%
6173	DV0.921.10.0.PR	GENSET PANEL TO REMOTE PANEL HARNESS	Spare Part	55664	15%
6174	DV0.921.20.0.PR	ENGINE CONTROL ALTERNATOR C T HARNESS	Spare Part	20052	15%
6175	DV0.921.30.0.PR	REMOTE PANEL TO RAILWAY MAIN PANEL HARNESS	Spare Part	29187	15%
6176	DV0.921.70.0.PR	3 3 K OHM PARALLEL RESISTOR MODULE	Spare Part	4108	15%
6177	DV0.950.04.0.00	LINER REMOVING AND PLACING TOOL	Spare Part	58895	15%
6178	DV0.950.505.0.00	COLLET FITTING TOOL	Spare Part	13388	15%
6179	DV0.950.506.0.00	STEM SEAL FITTING TOOL	Spare Part	4317	15%
6180	DV0.950.507.0.00	INJECTOR REMOVING TOOL	Spare Part	9772	15%
6181	DV0.950.523.0.00	GUIDE STUD FOR CRANK PULLEY	Spare Part	3954	15%
6182	DV0.950.525.0.00	GUIDE STUD FOR FLYWHEEL	Spare Part	6665	15%
6183	DV0.950.530.0.00	TOOL FOR PUSH ROD SPRING COMPRESSION	Spare Part	11261	15%
6184	DV0.950.571.0.TOL	GUIDE SLEEVE FOR PISTON INSERTION IN TO LINER FOR DV	Spare Part	47138	15%
6185	DV0.950.572.0.TOL	GUIDE SLEEVE FOR PISTON INSERTION IN TO LINER FOR CRDI	Spare Part	49805	15%
6186	DV0.950.69.0.TOL	Oil Seal Housing Alignment Tool Flywheel End Side DV0 950 69 0 00	Spare Part	28898	15%
6187	DV0.950.70.0.TOL	Oil Seal Housing Alignment Tool Pulley End Side DV0 950 70 0 00	Spare Part	27713	15%
6188	DV0.950.71.0.TOL	Oil Seal pressing tool for flywheel end side for DV series	Spare Part	69153	15%
6189	DV0.950.72.0.TOL	Oil Seal pressing tool for Pulley end side for DV series DV0 950 72 0 00	Spare Part	46753	15%
6190	DV0.998.01.0.SP	AVR SD-02 (NIDEC PART NO - AG418087)	Spare Part	688203	15%
6191	DV0.998.02.0.SP	COMPOUNDING TRANSFORMER (NIDEC PART NO - AG318320)	Spare Part	282541	15%
6192	DV0.998.05.0.SP	VARIABLE RESISTOR (NIDEC PART NO - AG418092)	Spare Part	49602	15%
6193	DV0.998.08.0.SP	RELAY (K1) (NIDEC PART NO - AG420063)	Spare Part	72762	15%
6194	DV0.998.09.0.SP	RELAY (K2) (NIDEC PART NO - AG420064)	Spare Part	77710	15%
6195	DV0.998.11.0.SP	VARISTOR (NIDEC PART NO - AG420060)	Spare Part	1348	15%
6196	DV0.998.13.0.SP	METRING CT ASSBLY (NIDEC PART NO - AG320133)	Spare Part	46587	15%
6197	DV0.998.16.0.SP	DIODE ASSBLY (NIDEC PART NO - AG418099) (RRA)	Spare Part	76562	15%
6198	DV0.998.17.0.SP	METERING CT NEUTRAL (NIDEC PART NO - AG420058)	Spare Part	13326	15%
6199	DV0.998.19.0.SP	FUSE F1 (NIDEC PART NO - AG420061)	Spare Part	15474	15%
6200	DV0.998.20.0.SP	BRIDGE RECTIFIER DIODE NIDEC PART NO AG420062	Spare Part	48322	15%
6201	DV0.998.23.0.SP	CONTACTOR (K3) 24V (NIDEC PART NO - AG420065)	Spare Part	64605	15%
6202	DV0.998.24.0.SP	FUSE F2 (NIDEC PART NO - AG420102)	Spare Part	15474	15%
6203	DV0.998.25.0.SP	PC ENGINE P1/"B" CHECK KIT - DV0.9019, DV0.9021, DV0.9027 WOO	Spare Part	88184	20%
6204	DV0.998.26.0.SP	PC ENGINE P1/"B" CHECK KIT PHASE II - DV0.9026 WOO	Spare Part	82733	20%
6205	DV0.998.27.0.SP	PC ENGINE "C" CHECK KIT - DV0.9019, DV0.9021 WOO	Spare Part	147402	20%
6206	DV0.998.28.0.SP	PC ENGINE "C" CHECK KIT PHASE II - DV0.9027 WOO	Spare Part	147200	20%
6207	DV0.998.29.0.SP	PC ENGINE "C" CHECK KIT PHASE II - DV0.9026 WOO	Spare Part	230286	20%
6208	DV0.998.30.0.SP	PC ENGINE ADD ON KIT PHASE I	Spare Part	17495	15%
6209	DV0.998.31.0.SP	PC ENGINE ADD ON KIT PHASE II	Spare Part	18880	15%
6210	DV0.998.33.0.SP	MULTIWING RADIATOR FAN (DV0.031.39.0.PR) 1210/6-6/29DEG/PAG/6WL/TP	Spare Part	124435	15%
6211	DV0.998.35.0.SP	MULTIWING RADIATOR FAN (DV0.032.01.0.PR) 1220-1228_16-16_32-5_PAG_5ZL	Spare Part	130503	15%
6212	DV0.998.36.0.SP	RADIATOR TOP TANK	Spare Part	52818	15%
6213	DV0.999.01.0.TOL	DV SERVICE TIMING TOOL	Spare Part	2606	15%
6214	DV0.999.05.0.SP	AVR EXCITATION UNIT NIDEC PART NO AG318318	Spare Part	1042718	15%
6215	DV0.999.07.0.SP	COMPOUNDING TRANSFORMER NIDEC PART NO AG318320	Spare Part	282541	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		·		without Vat in NPR	Charge%
6216	DV0.999.28.0.SP	Exciter rotor	Spare Part	131946	15%
6217	DV0.999.33.0.SP	Exciter stator	Spare Part	167582	15%
6218	DV0.999.40.0.00	CENTRIFUGAL FILTER SERVICE KIT FOR DV	Spare Part	1052	15%
6219	DV0.999.40.0.SP	MOTOR 3PH IE2 TYPE V 415D 10 50HZ 5 R MIN 1460 22kW 30HP 42A COS 0 80 Eff 91 60	Spare Part	367072	15%
6220	DV0.999.85.0.SP	BATTERY TESTER	Spare Part	275713	15%
6221	DV0.999.88.0.SP	RADIATOR U HOSE	Spare Part	4665	15%
6222	DV0.999.91.0.SP	PC ENGINE P1/"B" CHECK KIT - DV0.9019, DV0.9021, DV0.9027 WO	Spare Part	142573	20%
6223	DV0.999.92.0.SP	PC ENGINE P1/"B" CHECK KIT PHASE II - DV0.9026 WO	Spare Part	129123	20%
6224	DV0.999.93.0.SP	PC ENGINE "C" CHECK KIT - DV0.9019, DV0.9021 WO	Spare Part	203665	20%
6225	DV0.999.94.0.SP	PC ENGINE "C" CHECK KIT PHASE II - DV0.9027 WO	Spare Part	194516	20%
6226	DV0.999.95.0.SP	PC ENGINE "C" CHECK KIT PHASE II - DV0.9026 WO	Spare Part	200377	20%
6227	DV0.999.96.0.SP	PC ENGINE TAPPET SETTING KIT	Spare Part	27458	15%
6228	DV0.999.97.0.SP	PC ENGINE TAPPET SETTING KIT PHASE II	Spare Part	23237	15%
6229	DV0.EGT4.01.0.PR	DCU VD1CC01	Spare Part	74885	15%
6230	DV0.M001.06.0.00	EXPANSION TANK	Spare Part	40578	15%
6231	DV2.001.05.0.00	PISTON COOLING NOZZLE USUI	Spare Part	10938	15%
6232	DV2.001.30.0.00	CRANKCASE ASSEMBLY	Spare Part	1915273	15%
6233	DV2.002.20.0.PR	CYLINDER LINER ASSEMBLY (WITH ABP RING)	Spare Part	16551	15%
6234	DV2.003.10.0.00	CRANKSHAFT ASSLY WITHOUT GEAR	Spare Part	688375	15%
6235	DV2.003.13.0.00	CRANK PULLEY 200 PCD & SPB PROFILE	Spare Part	7406	15%
6236	DV2.003.18.0.PR	EXTENSION PULLEY FOR FAN DRIVE PCD 176 6 GROOVE	Spare Part	19231	15%
6237	DV2.006.10.0.SPR	PISTON ASSEMBLY	Spare Part	25397	15%
6238	DV2.006.20.0.SPR	PISTON RING SET	Spare Part	3369	15%
6239	DV2.007.04.0.00	NOZZLE CLAMP FINISH	Spare Part	1446	15%
6240	DV2.007.130.0.00	CYLINDER HEAD SUB ASSEMBLY WITH VALVE SPRING VALVE FOR CR	Spare Part	64147	15%
6241	DV2.007.140.0.00	CYLINDER HEAD ASSEMBLY COMPLETE FOR CR	Spare Part	81233	15%
6242	DV2.007.150.0.PR	CYLINDER HEAD ASSEMBLY COMPLETE FOR CR	Spare Part	284365	15%
6243	DV2.014.06.0.00	OIL COOLER 17 PLATE PN NJ 57000 FOR DV ENGINE	Spare Part	86162	20%
6244	DV2.014.07.0.00	FILTER HEADER	Spare Part	14209	15%
6245	DV2.014.120.0.PR	LUB OIL COOLER HEADER ASSLY	Spare Part	228185	15%
6246	DV2.014.24.0.00	HOSE: RADIATOR TO SUCTION PIPE	Spare Part	1394	15%
6247	DV2.014.60.0.00	LUB OIL COOLER HEADER ASSLY	Spare Part	156838	15%
6248	DV2.014.95.0.PR	JOINT FOR COOLER COVER	Spare Part	6825	15%
6249	DV2.016.02.0.00	V BELT 2JBX58 PITCH LENGTH 1550	Spare Part	7335	15%
6250	DV2.016.04.0.00	V BELT SPB AR1250 (6 NOS. SET)	Spare Part	15547	15%
6251	DV2.016.26.0.PR	V BELT BX 1250 AR	Spare Part	24987	15%
6252	DV2.016.27.0.PR	V-BELT-3AV15 x1275	Spare Part	12228	15%
6253	DV2.017.03.0.00	LUBe OIL SUMP	Spare Part	141173	15%
6254	DV2.019.02.0.00	NIRA ECU	Spare Part	355832	15%
6255	DV2.021.130.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	32498	15%
6256	DV2.021.32.0.00	H P PIPE cyl No 2 11	Spare Part	12960	15%
6257	DV2.021.33.0.00	H P PIPE cyl No 3 10	Spare Part	12978	15%
6258	DV2.021.34.0.00	H P PIPE cyl No 4 09	Spare Part	13104	15%
6259	DV2.021.36.0.00	H P PIPE cyl No 6 07	Spare Part	12941	15%
6260	DV2.021.38.0.PR	HP PIPE PUMP TO RAIL LHS	Spare Part	23907	15%
6261	DV2.021.39.0.PR	HP PIPE PUMP TO RAIL RHS	Spare Part	39815	15%
6262	DV2.021.58.0.00	CLAMP FOR LOW PRESSURE PIPE (DIA 16)	Spare Part	169	15%
6263	DV2.021.59.0.00	RUBBER SLEEVE (DIA 9)	Spare Part	34	15%
6264	DV2.021.67.0.00	HP PIPE RAIL TO FUEL PUMP LHS	Spare Part	21920	15%
6265	DV2.021.68.0.00	HP PIPE RAIL TO FUEL PUMP RHS	Spare Part	19077	15%
6266	DV2.021.72.0.PR	RAIL MTG BRACKET	Spare Part	4868	15%
6267	DV2.021.73.0.PR	HP PIPE ASSEMBLY ROUTED FOR CYL NO 4 10	Spare Part	6468	15%
6268	DV2.021.74.0.PR	HP PIPE ASSEMBLY ROUTED FOR CYL NO 5 11	Spare Part	6468	15%
6269	DV2.021.75.0.PR	HP PIPE ASSEMBLY ROUTED FOR CYL NO 6 12	Spare Part	6437	15%
•	DV2.021.76.0.PR	HP PIPE ASSEMBLY ROUTED FOR CYL NO 7	Spare Part	6455	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
0		, was 2550 page.	,	without Vat in	Charge%
6271	DV2.021.77.0.PR	HP PIPE ASSEMBLY PUMP TO RAIL LHS FROM FEW	Spare Part	7400	15%
6272	DV2.021.78.0.PR	HP PIPE ASSEMBLY PUMP TO RAIL RHS FROM FEW	Spare Part	7400	15%
6273	DV2.021.81.0.PR	HIGH PRESSURE RAIL RIGHT BANK VIEWED FROM PULLEY END	Spare Part	53821	15%
6274	DV2.022.102.0.PR	FUEL PIPE FUEL PUMP TO MAIN FILTER LH FROM GE	Spare Part	9812	15%
6275	DV2.022.103.0.00	FUEL PIPE FUEL PUMP TO MAIN FILTER RH FROM GE	Spare Part	11591	15%
6276	DV2.022.104.0.00	FUEL PUMP LEAK OFF 1 RH FROM GE	Spare Part	3738	15%
6277	DV2.022.104.0.00	RAIL LEAK OFF PIPE ASSEMBLY	Spare Part	7397	15%
6278	DV2.022.108.0.00	FUEL PIPE PRE FILTER TO MAIN FILTER 1	Spare Part	5431	15%
6279	DV2.022.109.0.00	FUEL PIPE PRE FILTER TO MAIN FILTER 2	Spare Part	5545	15%
6280	DV2.022.110.0.00	FUEL PIPE ASSLY FLEXIBLE	Spare Part	23750	15%
6281	DV2.022.110.0.00	ADAPTOR M16 TO M18	Spare Part	249	15%
6282	DV2.022.112.0.00	ADAPTOR (M14 TO M18)	Spare Part	320	15%
6283	DV2.022.115.0.00	SPIGOT M22 TO M18		428	15%
6284			Spare Part	692	15%
	DV2.022.117.0.00	HOSE FOR FUEL PUMP LEAK OFF	Spare Part		
6285	DV2.022.123.0.00	COMMON HEAD LEAK OFF	Spare Part	19440 249	15% 15%
6286	DV2.022.124.0.00	UNION ADAPTOR FOR HEAD LEAK OFF	Spare Part		
6287	DV2.022.125.0.PR	CLAMP FOR FUEL PIPE	Spare Part	58	15%
6288	DV2.022.126.0.00	OIL SUPPLY PIPE CRANKCASE TO FUEL PUMP IN	Spare Part	1895	15%
6289	DV2.022.153.0.PR	FUEL PIPE MAIN FILTER TO FUEL PUMP LH FROM GE	Spare Part	5763	15%
6290	DV2.022.157.0.PR	FUEL PIPE FUEL PUMP LEAK OFF BU FROM GE 1	Spare Part	5643	15%
6291	DV2.022.159.0.PR	FUEL PIPE FUEL PUMP LEAK OFF RH FROM GE	Spare Part	8166	15%
6292	DV2.022.165.0.00	FUEL PIPE MAIN FILTER TO FUEL PUMP RH FROM GE FOR BOSCH	Spare Part	7243	15%
6293	DV2.022.166.0.00	FUEL PIPE MAIN FILTER TO FUEL PUMP LH FROM GE FOR BOSCH	Spare Part	4280	15%
6294	DV2.022.167.0.00	FUEL PIPE (FUEL PUMP LEAK OFF RH FROM GE)	Spare Part	3895	15%
6295	DV2.022.168.0.00	FUEL PIPE FUEL PUMP LEAK OFF LH FROM GE FOR BOSCH	Spare Part	7486	15%
6296	DV2.022.172.0.PR	INJECTOR LEAKOFF PIPE A BANK	Spare Part	24606	15%
6297	DV2.022.173.0.PR	INJECTOR LEAKOFF PIPE B BANK	Spare Part	24267	15%
6298	DV2.022.174.0.PR	FUEL PIPE INJECTOR LEAKOFF PIPE	Spare Part	4154	15%
6299	DV2.022.178.0.PR	RAIL LEAKOFF	Spare Part	7791	15%
6300	DV2.022.179.0.PR	FUEL PIPE FUEL PUMP LEAK OFF LH FROM GE 2	Spare Part	5031	15%
6301	DV2.022.182.0.PR	FUEL PIPE PRE FILTER TO MAIN FILTER 1	Spare Part	3486	15%
6302	DV2.022.183.0.PR	FUEL PIPE PRE FILTER TO MAIN FILTER 2	Spare Part	3332	15%
6303	DV2.022.185.0.PR	FUEL PIPE MAIN FILTER TO FUEL PUMP RH FROM GE	Spare Part	8545	15%
6304	DV2.022.66.0.PR	ADAPTOR FOR PRESSURE SENSOR	Spare Part	262	15%
6305	DV2.022.71.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	4917	15%
6306	DV2.022.72.0.00	FUEL PIPE: FEED PUMP TO FUEL FILTER	Spare Part	5000	15%
6307	DV2.022.73.0.00	FEED PUMP FUEL IN PIPE: FLEX	Spare Part	5040	15%
6308	DV2.022.74.0.00	FUEL PIPE: PUMP LEAK OFF: FLEX	Spare Part	4320	15%
6309	DV2.023.03.0.PR	INLET MANIFOLD END R H SIDE	Spare Part	47433	15%
6310	DV2.023.05.0.00	INLET MANIFOLD	Spare Part	77442	15%
6311	DV2.029.01.0.00	FAN PULLEY (185 PCD & SPB PROFILE)	Spare Part	6385	15%
6312	DV2.029.04.0.00	FAN PULLEY (3GROOVE, 222 PCD)	Spare Part	9486	15%
6313	DV2.029.07.0.00	SPECIAL STUD M12X1 75X142 L	Spare Part	203	15%
6314	DV2.029.120.0.00	FAN DRIVE assembly	Spare Part	38618	15%
6315	DV2.029.220.0.PR	FAN DRIVE ASSEMBLY	Spare Part	139657	15%
6316	DV2.029.230.0.PR	FAN DRIVE SUB ASSEMBLY	Spare Part	129161	15%
6317	DV2.029.24.0.PR	BRACKET FOR FAN DRIVE ARRANGEMENT	Spare Part	14126	15%
6318	DV2.029.26.0.PR	PULLEY FOR FAN DRIVE	Spare Part	27517	15%
6319	DV2.029.30.0.00	FAN DRIVE assembly	Spare Part	43267	15%
6320	DV2.029.72.0.00	FAN SPACER	Spare Part	12089	15%
6321	DV2.031.14.0.00	HOSE: RADIATOR TO ENGINE	Spare Part	6889	15%
6322	DV2.031.24.0.00	FAN: 42" DV12	Spare Part	66645	15%
6323	DV2.031.27.0.00	PIPE: THERMOSTAT - RADIATOR	Spare Part	6181	15%
6324	DV2.031.51.0.00	RADIATOR OUTLET HOSE FOR DV12e-750kVA	Spare Part	3200	15%
6325	DV2.031.56.0.00	44 MULTIWING FAN FOR DV12	Spare Part	46766	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
6326	DV2.031.60.0.PR	RADIATOR 750KVA	Spare Part	1033106	15%
6327	DV2.031.61.0.PR	42 FAN FOR DV2	Spare Part	144124	15%
6328	DV2.031.65.0.00	HEAT EXCHANGER PIPE FOR DV12	Spare Part	6425	15%
6329	DV2.031.72.0.00	RADIATOR INLET PIPE FOR DV12e-750kVA	Spare Part	6572	15%
6330	DV2.031.74.0.00	RADIATOR OUTLET PIPE FOR DV12e-750kVA	Spare Part	4286	15%
6331	DV2.031.87.0.PR	ALUMINIUM RADIATOR ASSEMBLY	Spare Part	649062	15%
6332	DV2.031.91.0.00	RAD CAC HOSE	Spare Part	6834	15%
6333	DV2.031.94.0.PR	FAN 58 for 750kVA	Spare Part	308171	15%
6334	DV2.032.108.0.PR	TURBOCHARGER (LEFT BANK FROM FWE)	Spare Part	155601	15%
6335	DV2.032.109.0.PR	TURBOCHARGER (RIGHT BANK FROM FWE)	Spare Part	155601	15%
6336	DV2.032.115.0.PR	JOINT FOR FLANGE FOR T C LUB OIL OUTLET PIPE	Spare Part	286	15%
6337	DV2.032.14.0.PR	JOINT BET BELLO EXH MANIFOLD	Spare Part	268	15%
6338	DV2.032.33.0.00	TURBOCHARGER FOR DV12 750 KVA ENGINE - LEFT BANK (537819020895)	Spare Part	245760	15%
6339	DV2.032.34.0.00	TURBOCHARGER FOR DV12 750 KVA ENGINE RIGHT BANK 537819020896	Spare Part	289547	15%
6340	DV2.032.37.0.00	TURBO DRAIN PIPE (RH) (FROM FLYWHEEL END)	Spare Part	4220	20%
6341	DV2.032.38.0.00	TURBO DRAIN PIPE	Spare Part	4211	20%
6342	DV2.032.41.0.00	SPACER I D 11XO D 20X15L	Spare Part	105	15%
6343	DV2.032.43.0.PR	TURBO DRAIN PIPE (RH) (FROM FLYWHEEL END)	Spare Part	3711	15%
6344	DV2.032.44.0.PR	TURBO DRAIN PIPE (LH) (FROM FLYWHEEL END)	Spare Part	3711	15%
6345	DV2.032.51.0.PR	HOSE FOR AIR INTAK ADAPTOR	Spare Part	868	15%
6346	DV2.032.97.0.00	LEFT BANK T'CHARGER	Spare Part	171032	15%
6347	DV2.032.98.0.00	RIGHT BANK TURBOCHARGER	Spare Part	179179	15%
6348	DV2.033.03.0.00	AIR PIPE (DV2) FROM TURBO COMPRESSOR OUT TO CAC	Spare Part	11268	15%
6349	DV2.033.06.0.00	CAC INLET PIP	Spare Part	11212	15%
6350	DV2.033.07.0.00	CAC OUT PIPE	Spare Part	13326	15%
6351	DV2.033.85.0.00	O RING: CAC PIPE ADAPTOR	Spare Part	535	15%
6352	DV2.033.86.0.PR	O RING FOR CAC PIPE ADAPTOR	Spare Part	252	15%
6353	DV2.033.87.0.00	O RING CAC IN PIPE	Spare Part	548	15%
6354	DV2.040.03.0.00	CAM SHAFT	Spare Part	105091	15%
6355	DV2.040.10.0.00	CAMBOX TYPE FUEL PUMP TOTAL ASSY DV2	Spare Part	1268512	15%
6356	DV2.040.190.0.00	CAMBOX TYPE FUEL PUMP TOTAL ASSY (DV2)	Spare Part	1226796	15%
6357	DV2.042.10.0.00	DELIVERY TUBE	Spare Part	5671	15%
6358	DV2.046.01.0.00	BREATHER	Spare Part	62033	15%
6359	DV2.046.02.0.00	CARTRIDGE (OIL SEPARATOR)	Spare Part	43476	15%
6360	DV2.050.01.0.00	INJECTOR	Spare Part	19544	15%
6361	DV2.050.13.0.PR	MECHANICAL INJECTOR WITH SIDE FUEL ENTRY SUITABLE FOR MOUNTING WITH FEEDTUBE 1	Spare Part	44295	15%
6362	DV2.051.16.0.00	HEAT SHIELD R H	Spare Part	12283	15%
6363	DV2.051.17.0.00	HEAT SHIELD L H	Spare Part	10784	15%
6364	DV2.051.20.0.00	SUPPORT PLATE	Spare Part	200	15%
6365	DV2.054.01.0.00	BREATHER HOSE BREATHER TO BREATHER PIPE	Spare Part	228	15%
6366	DV2.054.92.0.00	HOSE AT BREATHER SIDE	Spare Part	514	15%
6367	DV2.054.93.0.00	BREATHER HOSE FROM PIPE TO BASE PLATE	Spare Part	2335	15%
6368	DV2.060.180.0.PR	CRANKCASE SUB ASSEMBLY	Spare Part	1364397	15%
6369	DV2.061.01.0.PR	CABLE TYPE ANTI VIBRATION MOUNTING Supp Part No SMC015080033	Spare Part	19932	15%
6370	DV2.067.01.0.00	ROCKER BOX COVER (WITH GROOVE)	Spare Part	4385	15%
6371	DV2.067.02.0.00	ROCKER BOX: CLEARANCE CUT	Spare Part	4914	15%
6372	DV2.067.03.0.PR	O Ring for Rocker Cover	Spare Part	415	15%
6373	DV2.067.48.0.00	O RING FOR ROCKER BOX COVER	Spare Part	2326	15%
6374	DV2.067.49.0.00	JOINT FOR ROCKER COVER	Spare Part	2698	15%
6375		BREATHER		13852	15%
	DV2.068.60.0.00		Spare Part		15%
6376	DV2.069.07.0.00	CONICAL COPPER WASHER OIL DRAIN RIDE: FID TO CLOSE	Spare Part	1101	
6377	DV2.069.65.0.00	OIL DRAIN PIPE: FIP TO C'CASE	Spare Part	1191	15%
6378	DV2.069.85.0.00	LEAK OFF PIPE	Spare Part	22372	15%
6379	DV2.072.01.0.00	HIGH PRESSURE RAIL LEFT BANK VIEWED FROM PULLEY END	Spare Part	338374	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
6381	DV2.072.04.0.PR	BOSCH HIGH PRESSURE CP3 3 PUMP FOR DV ENGINES B445080403	Spare Part	314996	15%
6382	DV2.072.10.0.SP	MPROP IMV FOR CP3 3 BOSCH FIP BOSCH PART NUMBER 0 928 400 642 000	Spare Part	38858	15%
6383	DV2.072.171.0.PR	Injector for DV8TA 320 kVA CPCB4 7 x 146 x 575 K 1 3 HE 10 5	Spare Part	86383	15%
6384	DV2.072.173.0.PR	Injector for DV series CPCB4 7 x 146 x 850 K 1 3 HE 10 5	Spare Part	86383	15%
6385	DV2.072.24.0.00	O RING BETWEEN GEAR CASING AND FUEL PUMP	Spare Part	95	15%
6386	DV2.072.24.0.PR	O RING BETWEEN GEAR CASING AND FUEL PUMP	Spare Part	114	15%
6387	DV2.072.57.0.00	PLATE FOR CAM SENSOR LOCATION	Spare Part	794	15%
6388	DV2.072.58.0.00	CAM SENSOR LOCATOR	Spare Part	726	15%
6389	DV2.072.69.0.00	BRIDGE FOR CAM SENSOR	Spare Part	1357	15%
6390	DV2.072.71.0.00	O RING FOR CAM SENSOR LOCATOR	Spare Part	55	15%
6391	DV2.072.77.0.00	BELLEVILLE WASHER FOR CAM SENSOR	Spare Part	22	15%
6392	DV2.072.88.0.00	INLET CONNECTOR FEEDTUBE	Spare Part	9052	15%
6393	DV2.072.89.0.00	RETAINING NUT FOR BOSCH FEEDTUBE	Spare Part	1372	15%
6394	DV2.072.92.0.00	INJECTOR FOR DV CRDI ENGINE	Spare Part	107712	15%
6395	DV2.079.04.0.PR	BRACKET FOR PREFILTER	Spare Part	1394	15%
6396	DV2.082.48.0.00	ADAPTOR (M16XM22)	Spare Part	363	15%
6397	DV2.086.132.0.00	JOINT BET BREATHER GEAR CASING PIPAVAV	Spare Part	286	15%
6398	DV2.086.156.0.00	RUBBER SLEEVE FOR FUEL PIPE	Spare Part	111	15%
6399	DV2.086.157.0.00	CLAMP FOR FUEL PIPE	Spare Part	37	15%
6400	DV2.086.48.0.00	TURBO OIL SUPPLY PIPE LH	Spare Part	4489	15%
6401	DV2.086.52.0.00	HOSE FOR TURBO COMPRESSOR OUT	Spare Part	1702	15%
6402	DV2.086.78.0.00	PLATE FOR THERMOSTAT MARINE	Spare Part	1871	15%
6403	DV2.086.85.0.00	JOINT FOR COOLER COVER LH FROM FWE	Spare Part	1083	15%
6404	DV2.086.86.0.00	JOINT FOR COOLER COVER RH FROM FWE	Spare Part	1145	15%
6405	DV2.086.87.0.00	JOINT BETWEEN CAC TURBO ADAPTOR	Spare Part	385	15%
6406	DV2.112.50.0.PR	DCU WIRING HARNESS SF DV12 CPCB IV ENGINE	Spare Part	104045	15%
6407	DV2.112.30.0.FR	ENGINE WIRING HARNESS SF DV12 CPCB IV ECU CHAMBER 1	Spare Part	42535	15%
6408	DV2.114.20.0.PR	ENGINE WIRING HARNESS SF DV12 CPCB IV ECU CHAMBER 2 3 4	Spare Part	16132	15%
6409	DV2.114.30.0.PR	ENGINE WIRING HARNESS SF DV12 CPCB IV ECU CHAMBER 5 6 7	Spare Part	105048	15%
6410	DV2.114.40.0.PR	ENGINE WIRING HARNESS SF DV12 CPCB IV ECU CHAMBER 8	Spare Part	36033	15%
6411	DV2.188.10.0.00	SILENCER FOR DV SERIES	Spare Part	165410	15%
6412	DV2.188.80.0.00	SILENCER FOR DV 500 - 750 KVA	Spare Part	182733	15%
6413	DV2.477.03.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 LHS EGT F W E	Spare Part	7701	15%
6414	DV2.477.04.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 RHS EGT F W E	Spare Part	6692	15%
6415	DV2.477.06.0.PR	COOLANT PIPE FOR ENGINE OUT TO DOSING MODEL IN 3 LHS EGT F W E	Spare Part	7735	15%
6416	DV2.477.11.0.PR	COOLANT PIPE FOR ENGINE OUT TO DOSING MODEL IN 1 RHS EGT F W E	Spare Part	3668	15%
6417	DV2.477.14.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 LHS EGT F W E	Spare Part	3788	15%
6418	DV2.477.16.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 3 RHS EGT F W E	Spare Part		15%
6419	DV2.477.19.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 RHS EGT F W E	Spare Part	3815	15%
6420	DV2.477.21.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 3 LHS EGT F W E	Spare Part	4357	15%
6421	DV2.477.31.0.PR	COOLANT PIPE FOR ENGINE OUT TO DOSING MODEL IN 1 LHS EGT F W E	Spare Part		15%
6422	DV2.477.32.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 RHS EGT F W E	Spare Part	5474	15%
6423	DV2.477.53.0.PR	HYDRAULIC PIPE FROM ENGINE OUT TO DOSING MODULE IN 2 RHS FROM F W E	Spare Part	1902	15%
6424	DV2.477.78.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 LHS EGT F W E	Spare Part	5969	15%
6425	DV2.477.83.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 LHS TANK SIDE	Spare Part	2754	15%
		ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 2 LHS TANK SIDE	Spare Part	1969	15%
6426 6427	DV2.477.84.0.PR DV2.477.86.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 2 LHS TANK SIDE	Spare Part	3188	15%
6428	DV2.477.86.0.PR		Spare Part	3188	15%
		ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 LHS TANK SIDE ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2 LHS TANK SIDE			15%
6429	DV2.477.89.0.PR		Spare Part	2034	15%
6430	DV2.477.92.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 RHS TANK SIDE	Spare Part	2683	
6431	DV2.477.93.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 2 RHS TANK SIDE	Spare Part	2794	15%
6432	DV2.477.94.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 3 RHS TANK SIDE	Spare Part	3172	15%
6433	DV2.477.96.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 RHS TANK SIDE	Spare Part	3271	15%
6434	DV2.477.97.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2 RHS TANK SIDE	Spare Part	2055	15%
6435	DV2.477.98.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2 RHS TANK SIDE	Spare Part	2800	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		1 3.1 2 3 3 3 1 Photo		without Vat in	Charge%
6436	DV2.477.99.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2 LHS TANK SIDE	Spare Part	NPR 2102	15%
6437	DV2.478.26.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 LHS EGT F W E	Spare Part	5994	15%
6438	DV2.478.28.0.PR	COOLANT PIPE FOR ENGINE OUT TO DOSING MODEL IN 3 LHS EGT F W E	Spare Part	6471	15%
6439	DV2.486.10.0.PR	Copper Radiator Assembly	Spare Part	1306515	15%
6440	DV2.505.01.0.00	HOSE REDUCER ELBOW FOR 600KVA GENSET	Spare Part	3880	15%
6441	DV2.505.07.0.00	HOSE FROM PIPE TO TURBOCHARGER	Spare Part	2720	15%
6442	DV2.505.10.0.00	AIR CLEANER LH SIDE	Spare Part	84670	15%
6443	DV2.505.50.0.00	AIR CLEANER KIT	Spare Part	104018	20%
6444	DV2.505.60.0.00	AIR CLEANER KIT	Spare Part	104018	20%
6445	DV2.505.86.0.PR	AIR CLEANER HOSE BETWEEN PIPE AND AIR CLEANER	Spare Part	2662	15%
6446	DV2.506.01.0.00	ELBOW HOSE	Spare Part	13858	20%
6447	DV2.506.03.0.00	HOSE CLAMP	Spare Part	517	20%
6448	DV2.506.10.0.00	PRE CLEANER METAL	•	10792	20%
6449	DV2.506.60.0.00		Spare Part	58045	20%
		AIR CLEANER ASSLY. AIR FILTER SAFETY	Spare Part		20%
6450	DV2.506.62.0.00		Spare Part	4560	20%
6451	DV2.506.63.0.00	AIR FILTER PRIMARY	Spare Part	13558	
6452	DV2.507.02.0.00	FUEL PIPE TANK TO LEAK OFF PIPE	Spare Part	9941	15%
6453	DV2.507.03.0.00	FUEL PIPE: FUEL TANK TO FUEL PREFILTER FUEL PIPE RETURN	Spare Part	6615	15%
6454	DV2.507.15.0.00		Spare Part	1969	15%
6455	DV2.507.22.0.00	FUEL PIPE (RETURN) FOR 750 KVA	Spare Part	2188	15%
6456	DV2.507.23.0.00	FUEL INLET PIPE (FROM TANK TO PRE-FILTER)STRAIGHT	Spare Part	2274	15%
6457	DV2.507.24.0.00	FUEL DIESE FROM TANK TO PREFITER BEND	Spare Part	1683	15%
6458	DV2.507.26.0.PR	FUEL PIPES FROM TANK TO PREFILTER	Spare Part	3055	15%
6459	DV2.507.27.0.PR	FUEL PIPES FROM TANK TO PREFILTER	Spare Part	3978	15%
6460	DV2.507.32.0.PR	FUEL RETURN PIPE M16X1 5 MALE PLUG AND M22X1 5 UNION NUT	Spare Part	2360	15%
6461	DV2.507.33.0.PR	FUEL INLET PIPE FROM TANK TO PRE FILTER M22X1 5 UNION NUT AND M22X1 5 BANJO	Spare Part	3960	15%
6462	DV2.701.05.0.PR	KOEL GREEN Alternator KG 750 S T Frame L KG 49 1 M75 SAE 1 14 415V 50HZ 0 8P F 750 H H	Spare Part	2375836	15%
6463	DV2.710.11.0.PR	30A FUSE MAKE-LITTLEFUSE 0ATO030.VP	Spare Part	68	15%
6464	DV2.801.35.0.PR	KOEL GREEN Alternator, KG 625 S T Frame: L KG 47 E1, SAE-1 14", 415V, 50 Hz, 0.8 PF	Spare Part	2014527	15%
6465	DV2.806.23.0.00	RAIN CAP ASSEMBLY FOR EXHAUST BEND	Spare Part	1932	15%
6466	DV2.806.25.0.00	TAIL PIPE	Spare Part	25950	15%
6467	DV2.806.65.0.PR	EXHAUST BEND	Spare Part	12418	15%
6468	DV2.850.51.0.00	ENGINE MTG FOOT FOR 750 KVA BASEFRAME	Spare Part	25009	15%
6469	DV2.858.12.0.00	ASSEMBLY FOR RMS (REMOTE MONITORING SYSTEM) UNIT FOR KG934	Spare Part	24544	15%
6470	DV2.858.14.0.PR	ASSEMBLY FOR KRM UNIT FOR KG541 WITH PACKAGE	Spare Part	20360	15%
6471	DV2.858.27.0.PR	ASSEMBLY FOR KRM UNIT FOR KG745 WITH PACKAGE	Spare Part	19363	15%
6472	DV2.858.29.0.PR	ASSEMBLY FOR KRM UNIT FOR KG645 WITH PACKAGE	Spare Part	21150	15%
6473	DV2.858.31.0.PR	KRMS DEVICE SF RDSO PROJECT FOR KG745 UNIT WITH 2 YEARS DATA PACKAGE INCLUSIVE	Spare Part	25790	15%
6474	DV2.858.39.0.PR	ASSEMBLY FOR KRM UNIT FOR KG645C WITH PACKAGE	Spare Part	21154	15%
6475	DV2.858.80.0.00	ASSEMBLY FOR RMS (REMOTE MONITORING SYSTEM) UNIT	Spare Part	640	15%
6476	DV2.858.91.0.SP	SIM FOR KRM - VODAFONE IDEA (VI)	Spare Part	6311	15%
6477	DV2.858.93.0.SP	SIM FOR KRM I AIRTEL	Spare Part	6311	15%
6478	DV2.865.90.0.PR	CANOPY WIRING HARNESS	Spare Part	5905	15%
6479	DV2.866.01.0.00	EARTHING CABLE PANEL TO BASE PLATE FOR 600KVA	Spare Part	2003	15%
6480	DV2.901.01.0.ASP	RRA Assembly KG49 1 KVA Ratings 625 to 750 Kva 3Ph	Spare Part	41138	15%
6481	DV2.901.04.0.ASP	Fan KG49 1 KVA rating 625 to 750KVA 3Ph LS Part No PUS670TA001B	Spare Part	79488	15%
6482	DV2.901.05.0.ASP	Varister-KG49.1,KVA rating-625 to 750KVA,3Ph	Spare Part	1526	15%
6483	DV2.901.12.0.ASP	Coupling Disc KG49 1 KVA rating 625 to 750KVA 3Ph LS Part No PUS466TX003B	Spare Part	15852	15%
6484	DV2.901.14.0.ASP	SET OF 3 CT 1000/5 LS Frame - KG 47.2	Spare Part	37704	15%
6485	DV2.901.22.0.00	EX ROTOR WITH RRA FRAME 38 8P	Spare Part	67150	15%
6486	DV2.901.26.0.00	COOLANT LEVEL SWITCH LOW HIGH LEVEL WITH LED	Spare Part	6889	15%
6487	DV2.901.37.0.00	KIT PD500 FOR ECO 38 A AIRGAP 0.4	Spare Part	35803	15%
6488	DV2.901.63.0.00	COUPLING DISC SET SAE 11.5" KG 42.3	Spare Part	5791	15%
6489	DV2.901.64.0.00	DIODE BRIDGE RECTIFIER KG40	Spare Part	19120	15%
6490	DV2.901.65.0.00	RRA ASSEMBLY KG 47.2	Spare Part	35803	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
			0 ,	without Vat in NPR	Charge%
6491	DV2.901.90.0.00	VARISTER KG47.2	Spare Part	1615	15%
6492	DV2.903.03.0.00	ADAPTOR FOR PRESSURE SENSOR	Spare Part	302	15%
6493	DV2.903.06.0.00	ADAPTOR FOR GEMS LOP SENSOR	Spare Part	305	15%
6494	DV2.903.13.0.00	PRESSURE & TEMPERATURE SENSOR	Spare Part	22572	15%
6495	DV2.903.30.0.00	WIRING HARNESS FROM ENGINE CONTROL PANEL TO ALTERNATOR TERMINAL BOX WITH CT S	Spare Part	2548	15%
6496	DV2.903.31.0.00	CRANK SPEED HALL EFFECT SENSOR	Spare Part	40655	15%
6497	DV2.903.32.0.00	CAM SPEED HALL EFFECT SENSOR (MAKE:JAQUET)	Spare Part	40750	15%
6498	DV2.903.46.0.PR	INSULATOR FOR ECU ORDER NUMBER 20A F M6 30MM	Spare Part	182	15%
6499	DV2.903.60.0.PR	ENGINE WIRING HARNESS FOR 750KVA CRDI	Spare Part	178247	15%
6500	DV2.904.25.0.PR	WATER COOLED CAC FOR FOR 750 AND 1010KVA	Spare Part	625881	15%
6501	DV2.904.25.0.PR	RESTING PLATE FOR ECU	Spare Part	5437	15%
6502	DV2.904.36.0.PR	ECU MOUNTING PLATE	Spare Part	10501	15%
6503	DV2.904.37.0.PR		•		
		SUPPORT BRACKET FOR RESTING PLATE	Spare Part	1483	15%
6504	DV2.904.39.0.PR	ECU MOUNTING SUPPORT CHANNEL	Spare Part	2563	15%
6505	DV2.906.10.0.00	CABLE GLAND ASSEMBLY FOR DV ENGINE	Spare Part	3557	15%
6506	DV2.906.20.0.PR	WIRING HARNESS FROM INTERFACE CARD TO CONTROL PANEL FOR DV12	Spare Part	100934	15%
6507	DV2.906.30.0.PR	WIRING HARNESS FROM INTERFACE RELAY BOX TO MASTER ECU FOR DV12	Spare Part	9717	15%
6508	DV2.906.40.0.PR	WIRING HARNESS FROM INTERFACE RELAY BOX TO SLAVE ECU FOR DV12	Spare Part	8154	15%
6509	DV2.906.50.0.PR	WIRING HARNESS FROM MASTER ECU TO SENSOR AND INJECTOR CONNECTION FOR DV12	Spare Part	51839	15%
6510	DV2.906.60.0.PR	WIRING HARNESS FROM SLAVE ECU TO SENSOR AND INJECTOR CONNECTION FOR DV12	Spare Part	31166	15%
6511	DV2.906.70.0.PR	WIRING HARNESS FROM MASTER ECU TO SENSOR AND INJECTOR CONNECTION WITH STANDY	Spare Part	55008	15%
6512	DV2.906.80.0.PR	WIRING HARNESS FROM SLAVE ECU TO SENSOR AND INJECTOR CONNECTION WITH STANADY	Spare Part	35480	15%
6513	DV2.906.90.0.PR	CONTROL PANEL FOR DV12 750KVA CRDI GENSET	Spare Part	147693	15%
6514	DV2.908.40.0.00	BATTERY CABLE ASSEMBLY 70 SQ MM WITH SUITABLE LUG AND LENGTH RED CABLE 600 MM	Spare Part	9086	15%
6515	DV2.910.50.0.00	ENGINE WIRING HARNESS ASSEMBLY WITH KG545	Spare Part	15415	15%
6516	DV2.910.60.0.00	ENGINE WIRING HARNESS ASSEMBLY FOR DV12 ENGINE 4 20 MA GEMS LOP SENSOR	Spare Part	27397	15%
6517	DV2.911.50.0.PR	WIRING HARNESS FROM MASTER ECU TO SENSOR AND INJECTOR CONNECTION WITH BOSCH	Spare Part	51535	15%
6518	DV2.911.60.0.PR	WIRING HARNESS FROM SLAVE ECU TO SENSOR AND INJECTOR CONNECTION WITH BOSCH PU	Spare Part	32698	15%
6519	DV2.989.24.0.00	CRDI INTERFACE CARD	Spare Part	31790	15%
6520	DV2.993.23.0.00	JOINT FOR RAW WATER PIPE ASSEMBLY 120 OD x 60 ID x 95 PCD	Spare Part	77	15%
6521	DV2.999.01.0.SP	CRDI CAN CABLE GENSET PANEL TO PC	Spare Part	1895	15%
6522	DV2.W055.02.0.PR	O RING FOR HEAT EXCHANGER	Spare Part	326	15%
6523	DV8.001.240.0.PR	CRANKCASE SUB ASSLY	Spare Part	996008	15%
6524	DV8.003.10.0.00	CRANKSHAFT (SUB ASSLY)	Spare Part	491353	15%
6525	DV8.003.13.0.PR	CRANKSHAFT GEAR	Spare Part	37359	15%
6526	DV8.004.03.0.PR	CAM GEAR FINISH	Spare Part	24757	15%
6527	DV8.004.94.0.00	CAMSHAFT WITH INTERNAL EGR WITH 1 25 MM SECONDARY LIFT	Spare Part	79519	15%
6528	DV8.007.14.0.00	BRIDGE FOR ROCKER LEVER	Spare Part	822	15%
6529	DV8.007.14.0.PR	BRIDGE FOR ROCKER LEVER	Spare Part	742	15%
6530	DV8.007.18.0.PR	Bridge For Rocker Lever	Spare Part	1206	15%
6531	DV8.010.70.0.PR	DOUBLE GEAR ASSEMBLY	Spare Part	45242	15%
6532	DV8.011.10.0.PR	SUB ASSLY OF INTERMEDIATE GEAR BUSH	Spare Part	10852	15%
6533	DV8.014.21.0.00	PIPE THERMOSTAT TO RADIATOR IN	Spare Part	3865	15%
6534	DV8.014.22.0.00	HOSE (RADIATOR TO ENGINE)	Spare Part	4345	15%
6535	DV8.017.03.0.00	LUBe OIL SUMP	Spare Part	136266	15%
6536	DV8.019.03.0.PR	FUEL PUMP GEAR FINISH	Spare Part	16431	15%
6537	DV8.021.130.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	20280	15%
6538	DV8.022.101.0.00	FUEL PIPE (FEED PUMP TO FILTER)	Spare Part	6280	15%
6539	DV8.022.103.0.00	FUEL PIPE (TANK TO FEED PUMP IN)	Spare Part	3172	15%
6540	DV8.022.104.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	7354	15%
6541	DV8.022.114.0.PR	FUEL PIPE FEED PUMP TO FILTER	Spare Part	5514	15%
6542	DV8.022.115.0.PR	FUEL PIPE FUEL FILTER TO FUEL PUMP	Spare Part	6418	15%
6543	DV8.022.129.0.PR	FUEL PIPE MAIN FILTER TO FUEL PUMP LH FROM GE	Spare Part	5757	15%
6544	DV8.022.132.0.PR	FUEL PIPE FUEL PUMP LEAK OFF LH FROM GE	Spare Part	8114	15%
6545	DV8.022.136.0.PR	LEAK OFF PIPE A BANK LH FROM GE	Spare Part	13031	15%



				Price to Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
	21/2 222 /22 2 22			NPR	
6546	DV8.022.137.0.PR	LEAK OFF PIPE B BANK RH FROM GE	Spare Part	13301	15%
6547	DV8.022.138.0.PR	LEAK OFF PIPE END CONNECTION	Spare Part	5101	15%
6548	DV8.022.139.0.PR	FUEL PIPE RAIL LEAK OFF	Spare Part	6086	15%
6549	DV8.022.140.0.00	FUEL PIPE ASSLY	Spare Part	21421	15%
6550	DV8.022.152.0.PR	FUEL PIPE PRI FILTER TO MAIN FILTER	Spare Part	7034	15%
6551	DV8.022.160.0.00	FUEL PIPE ASSEMBLY	Spare Part	22477	15%
6552	DV8.022.170.0.PR DV8.022.68.0.PR	FUEL PIPE ASSEMBLY FLEXIBLE	Spare Part	28009 5606	15% 15%
6553 6554		FUEL PIPE: FUEL FILTER TO FIP	Spare Part	4052	15%
6555	DV8.022.71.0.00 DV8.022.72.0.00	FUEL PIPE: FEED PUMP TO FILTER	Spare Part	4043	15%
6556	DV8.022.73.0.00	FEED PUMP FUEL IN PIPE (FLEX)	Spare Part Spare Part	4812	15%
6557	DV8.022.74.0.00	FUEL PIPE: PUMP LEAK OFF (FLEX)	Spare Part	3351	15%
6558	DV8.022.78.0.PR	FUEL PIPE FOR MAIN FILTER LEAKOFF	Spare Part	5917	15%
6559	DV8.022.79.0.PR	CLAMP	Spare Part	502	15%
6560	DV8.023.26.0.PR		Spare Part	102	15%
6561	DV8.024.21.0.00	JOINT BETWEEN THROTTLE VALVE AND HEATER SUPPORT FOR EXHAUST ELBOW L H SIDE	Spare Part	2440	15%
6562	DV8.024.22.0.00	SUPPORT FOR EXHAUST ELBOW R H SIDE	Spare Part	2440	15%
6563	DV8.029.165.0.00	FAN DRIVE ASSEMBLY	Spare Part	38686	15%
6564	DV8.029.30.0.00	FAN DRIVE ASSEMBLY	Spare Part	33529	15%
6565	DV8.031.04.0.00	RADIATOR WATER OUT HOSE	Spare Part	3538	15%
6566	DV8.031.05.0.00	SILICON HOSE 3.5" ID	Spare Part	3037	15%
6567	DV8.032.05.0.00	BRACKET FOR TURBO ADAPTOR RH FROM GEAR END	Spare Part	1135	15%
6568	DV8.032.18.0.00	TURBO ADAPTOR R H FROM F W END	Spare Part	9058	15%
6569	DV8.032.21.0.00	TURBOCHARGER FOR DV8,320 KVA ENGINE-A BANK	Spare Part	74879	15%
6570	DV8.032.22.0.00	TURBOCHARGER FOR DV8	Spare Part	75045	15%
6571	DV8.032.31.0.00	LEFT BANK T'CHARGER	Spare Part	140546	15%
6572	DV8.032.32.0.00	RIGHT BANK TURBOCHARGER	Spare Part	136463	15%
6573	DV8.032.33.0.00	TURBO ADAPTOR LH FROM G E	Spare Part	8572	15%
6574	DV8.032.34.0.00	SPACER FOR TURBO ADAPTOR	Spare Part	178	15%
6575	DV8.032.57.0.PR	GASKET B W TURBO CHARGER DIFFUSER	Spare Part	480	15%
6576	DV8.033.03.0.00	AIR PIPE FROM TURBO COMPRESSOR OUT TO CAC	Spare Part	10394	15%
6577	DV8.033.04.0.00	EXHAUST ELBOW	Spare Part	5908	15%
6578	DV8.033.108.0.PR	O RING FOR CAC PIPE I D 92 15	Spare Part	874	15%
6579	DV8.033.32.0.00	V BAND CLAMP 77MM NOM DIA	Spare Part	3640	20%
6580	DV8.033.34.0.00	TURBO COMPRESSOR OUT PIPE (LH VIEW FROM FWE)	Spare Part	5169	15%
6581	DV8.033.35.0.00	TURBO COMPRESSOR OUT PIPE (RH VIEW FROM FWE)	Spare Part	4972	15%
6582	DV8.033.36.0.00	TURBO COMPRESSOR	Spare Part	4988	15%
6583	DV8.033.37.0.00	TURBO COMPRESSOR	Spare Part	4981	15%
6584	DV8.033.44.0.00	CAC OUT PIPE	Spare Part	7791	15%
6585	DV8.033.45.0.PR	EXPANSION BELLOW 110 ID	Spare Part	15344	15%
6586	DV8.033.67.0.PR	V BAND CLAMP	Spare Part	1089	15%
6587	DV8.033.81.0.PR	EXHAUST DIFFUSER FOR DV8 CPCB II	Spare Part	13009	15%
6588	DV8.033.82.0.PR	EXHAUST DIFFUSER FOR DV8 CPCB II	Spare Part	13034	15%
6589	DV8.033.86.0.PR	CAC PIPE FOR DV8 ENGINE	Spare Part	5585	15%
6590	DV8.035.04.0.00	HOSE: RADIATOR TO ENGINE	Spare Part	3135	15%
6591	DV8.035.05.0.00	PIPE THERMOSTAT TO RAD IN	Spare Part	3206	15%
6592	DV8.035.20.0.00	SUCTION PIPE: RADIATOR TO ENGINE	Spare Part	2742	15%
6593	DV8.035.33.0.00	HOSE TURBO TO PIPE	Spare Part	1523	15%
6594	DV8.036.10.0.00	ALUMINIUM RADIATOR ASSY	Spare Part	342377	15%
6595	DV8.040.03.0.00	CAMSHAFT FOR PF33 N FUEL PUMP	Spare Part	52885	15%
6596	DV8.040.10.0.00	FUEL INJECTION PUMP ASSLY	Spare Part	1063235	15%
6597	DV8.040.22.0.00	FIP: PF33	Spare Part	34843	15%
6598	DV8.040.220.0.00	CAMBOX TYPE FUEL PUMP TOTAL ASSLY DV8	Spare Part	1013220	15%
6599	DV8.040.23.0.00	FUEL FILTER & WATER SEPERATOR	Filter	16263	20%
6600	DV8.040.24.0.00	SPINON FUEL FILTER ASSLY	Filter	4700	20%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
6601	DV8.040.250.0.00	CAMBOX TYPE FUEL PUMP TOTAL ASSLY DV8	Spare Part	874558	15%
6602	DV8.040.33.01.TOL	WATER SEPARATOR FILTER REMOVER RACOR BOWL WRENCH	Spare Part	4385	15%
6603	DV8.042.10.0.00	SUB ASSLY OF DELIVERY TUBE	Spare Part	5003	15%
6604	DV8.050.05.0.00	BREATHER HOSE	Spare Part	391	15%
	DV8.051.06.0.00	CENTER BRACKET (FOR HEAT SHIELD (R.H))	Spare Part	954	15%
6606	DV8.051.11.0.00	BRACKET (FOR HEAT SHIELD G.E. (L.H))	Spare Part	975	15%
6607	DV8.052.01.0.00	PLASTIC FAN 36 INCH MULTIWING	Spare Part	48122	15%
6608	DV8.052.06.0.00	FAN	Spare Part	51153	15%
	DV8.053.03.0.00	SPACER (175MM) FOR DV8 FAN	Spare Part	11674	15%
	DV8.053.05.0.00	FAN SPACER 125MM LENGTH	Spare Part	12286	15%
6611	DV8.064.01.0.00	JOINT: TURBO OUTLET	Spare Part	1348	15%
6612	DV8.069.65.0.00	OIL DRAIN PIPE: FIP-C'CASE	Spare Part	831	15%
	DV8.069.85.0.00	LEAK OFF PIPE	Spare Part	16067	15%
	DV8.072.01.0.00	FUEL FILTER FOR COMMON RAIL	Filter	115295	20%
	DV8.072.02.0.SP	50 Hrs A check Maintenance Kit	Spare Part	28630	20%
	DV8.072.108.0.00	FINAL FILTER CARTRIDGE	Filter	10464	20%
	DV8.072.12.0.SP	1500 Hrs C Check Maintenance Kit	Spare Part	87921	20%
	DV8.072.122.0.PR	FINAL FILTER WITH LIFT PUMP FOR DV CRDI PROJECT 8 PSI PRESSURE REGULATOR	Spare Part	174106	20%
	DV8.072.125.0.SP	500 Hrs B Check Maintenance Kit	Spare Part	45515	20%
	DV8.072.13.0.SP	1500 Hrs C Check Maintenance Kit	Spare Part	87963	20%
	DV8.072.150.0.PR	SUB ASSLY OF INT GEAR BUSH	Spare Part	35030	15%
	DV8.072.27.0.00	JOINT: GEAR CASING	Spare Part	880	15%
	DV8.072.28.0.00	JOINT FOR GEAR CASING COVER	Spare Part	622	15%
	DV8.072.48.0.00	JOINT FOR FUEL PUMP	Spare Part	49	15%
	DV8.072.88.0.00	NUT (M18X1.5) (HARD NUT)	Spare Part	182	15%
	DV8.076.10.0.PR	FAN CLUTCH ASEMBLY FOR DV8 KENDRION MAKE EMC 250 MM LENGTH	Spare Part	305208	15%
	DV8.076.12.0.00	DIODE ASSEMBLY FOR FAN CLUTCH FOR DV SERIES	Spare Part	5698	15%
	DV8.087.100.0.PR	WOODWARD PG PLUS SYSTEM FOR 8 CYLINDER NATURAL GAS ENGINE	Spare Part	1490857	15%
	DV8.087.50.0.PR	THROTTLE BODY L SERIES 50MM	Spare Part	185788	15%
	DV8.088.50.0.PR	GAS TRAIN ASSEMBLY FOR DV8 TA PNG	Spare Part	179601	15%
	DV8.111.10.0.PR	ENGINE WIRING HARNESS SF DV8 CPCB IV ECU CHAMBER 1	Spare Part	33769	15%
	DV8.111.20.0.PR	ENGINE WIRING HARNESS SF DV8 CPCB IV ECU CHAMBER 2	Spare Part	65784	15%
	DV8.111.30.0.PR	ENGINE WIRING HARNESS SF DV8 CPCB IV ECU CHAMBER 3	Spare Part	17304	15%
	DV8.111.40.0.PR	ENGINE WIRING HARNESS SF DV8 CPCB IV ECU CHAMBER 4	Spare Part	18471	15%
	DV8.111.50.0.PR	ENGINE WIRING HARNESS SF DV8 CPCB IV ECU CHAMBER 5	Spare Part	42861	15%
	DV8.111.60.0.PR	ENGINE WIRING HARNESS SF DV8 CPCB IV ECU CHAMBER 6	Spare Part	14929	15%
	DV8.111.70.0.PR	ENGINE WIRING HARNESS SF DV8 CPCB IV ECU CHAMBER 7	Spare Part	7317	15%
6638	DV8.111.80.0.PR	ENGINE WIRING HARNESS SF DV8 CPCB IV ECU CHAMBER 8	Spare Part	35418	15%
	DV8.1172.02.0.00	FLANGE HEATER 24V 2KW FOR DV SERIES	Spare Part	47667	15%
	DV8.1172.03.0.PR	ENGINE PLUG HEATER FOR DV SERIES	Spare Part	48159	15%
	DV8.188.05.0.00	FLANGE FOR BELLOW	Spare Part	3661	15%
	DV8.188.10.0.00	SILENCER	Spare Part	127392	15%
	DV8.235.01.0.PR	ADAPTOR M14 X M10	Spare Part	391	15%
	DV8.301.17.0.PR	RAW WATER PIPE ON HE INLET	Spare Part	7837	15%
	DV8.301.18.0.PR	RAW WATER PIPE CAC OUT TO HE	Spare Part	5172	15%
	DV8.303.04.0.00	HOSE FOR AIR CLEANER	Spare Part	10132	15%
	DV8.303.07.0.PR	HOSE FOR AIR CLEANER	Spare Part	7274	15%
6648	DV8.477.02.0.PR	HYDRAULIC PIPE FROM ENGINE OUT TO DOSING MODULE IN 2 LHS FROM F W E	Spare Part	1837	15%
	DV8.477.06.0.PR	HYDRAULIC PIPE FROM ENGINE OUT TO DOSING MODULE IN 2 RHS FROM F W E	Spare Part	2135	15%
6650	DV8.477.08.0.PR	HYDRAULIC PIPE FROM DOSING MODULE OUT TO RADIATOR IN RHS FROM F W E	Spare Part	2345	15%
	DV8.477.09.0.PR	HYDRAULIC PIPE FROM DOSING MODULE OUT TO RADIATOR IN LHS FROM F W E	Spare Part	2252	15%
	DV8.477.11.0.PR	HYDRAULIC PIPE FROM SUPPLY MODULE OUT TO DOSING MODULE IN 1 LHS EGT F W E	Spare Part	908	15%
	DV8.477.12.0.PR	HYDRAULIC PIPE FROM SUPPLY MODULE OUT TO DOSING MODULE IN 2 LHS EGT F W E	Spare Part	1194	15%
	DV8.477.13.0.PR	HYDRAULIC PIPE FROM SUPPLY MODULE OUT TO DOSING MODULE IN 2 LINS EGT F W E	Spare Part	1286	15%
		1 D. W. COLO E I INOM COLL EL MODOLL COL LO DOCINO MODOLL IN CLIN EDIT WE	oparo rait	1200	1070



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
6656	DV8.477.16.0.PR	HYDRAULIC PIPE FROM SUPPLY MODULE OUT TO DOSING MODULE IN 2 RHS EGT F W E	Spare Part	NPR 1191	15%
6657	DV8.477.17.0.PR	HYDRAULIC PIPE FROM SUPPLY MODULE OUT TO DOSING MODULE IN 3 RHS EGT F W E	Spare Part	1255	15%
6658	DV8.477.19.0.PR	HYDRAULIC PIPE FROM SUPPLY MODULE OUT TO DOSING MODULE IN 4 RHS EGT F W E	Spare Part	951	15%
6659	DV8.478.02.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1 RHS EGT F W E	Spare Part	3117	15%
6660	DV8.478.03.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 RHS EGT F W E	Spare Part	3778	15%
6661	DV8.478.04.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 3 RHS EGT F W E	Spare Part	4963	15%
6662	DV8.478.05.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 4 RHS EGT F W E	Spare Part	3898	15%
6663	DV8.478.07.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1 LHS EGT F W E	Spare Part	4501	15%
6664	DV8.478.08.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 LHS EGT F W E	Spare Part	3938	15%
6665	DV8.478.09.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 3 LHS EGT F W E	Spare Part	4655	15%
6666	DV8.478.12.0.PR	COOLANT PIPE FOR ENGINE OUT TO DOSING MODEL IN 2 RHS EGT F W E	Spare Part	7486	15%
6667	DV8.478.13.0.PR	COOLANT PIPE FOR ENGINE OUT TO DOSING MODEL IN 1 RHS EGT F W E	Spare Part	3735	15%
6668	DV8.478.14.0.PR	COOLANT PIPE FOR ENGINE OUT TO DOSING MODEL IN 2 RHS EGT F W E	Spare Part	3074	15%
6669	DV8.478.16.0.PR	COOLANT PIPE FOR ENGINE OUT TO DOSING MODEL IN 3 LHS EGT F W E	Spare Part	5215	15%
6670	DV8.478.17.0.PR	COOLANT PIPE FOR ENGINE OUT TO DOSING MODEL IN 1 LHS EGT F W E	Spare Part	3840	15%
6671	DV8.478.23.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 RHS EGT F W E	Spare Part	6465	15%
6672	DV8.478.24.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 RHS EGT F W E	Spare Part	4843	15%
6673	DV8.478.25.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 RHS EGT F W E	Spare Part	8311	15%
6674	DV8.478.27.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 LHS EGT F W E	Spare Part	6345	15%
6675	DV8.478.28.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 LHS EGT F W E	Spare Part	5726	15%
6676	DV8.478.31.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 LHS TANK SIDE	Spare Part	3197	15%
6677	DV8.478.32.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 2 LHS TANK SIDE	Spare Part	1818	15%
6678	DV8.478.33.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 3 LHS TANK SIDE	Spare Part	3188	15%
6679	DV8.478.35.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 LHS TANK SIDE	Spare Part	3188	15%
6680	DV8.478.36.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2 LHS TANK SIDE	Spare Part	1877	15%
6681	DV8.478.37.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2 LHS TANK SIDE	Spare Part	2086	15%
6682	DV8.478.39.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1 RHS TANK SIDE	Spare Part	2683	15%
6683	DV8.478.41.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 2 RHS TANK SIDE	Spare Part	1880	15%
6684	DV8.478.42.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 3 RHS TANK SIDE	Spare Part	3172	15%
6685	DV8.478.44.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 RHS TANK SIDE	Spare Part	3265	15%
6686	DV8.478.45.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2 RHS TANK SIDE	Spare Part	1868	15%
6687	DV8.478.46.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2 RHS TANK SIDE	Spare Part	2000	15%
6688	DV8.478.47.0.PR	METALLIC PIPE ENGINE TO EGT RHS SIDE FROM F W E	Spare Part	6357	15%
6689	DV8.478.48.0.PR	COOLANT PIPE FOR ENGINE OUT TO DOSING MODEL IN 1	Spare Part	3828	15%
6690	DV8.478.49.0.PR	COOLANT PIPE FOR ENGINE OUT TO DOSING MODEL IN 2	Spare Part	6911	15%
6691	DV8.478.51.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 RHS EGT F W E	Spare Part	6037	15%
6692	DV8.478.53.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 LHS EGT F W E	Spare Part	7209	15%
6693	DV8.478.54.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 LHS EGT F W E	Spare Part	6375	15%
6694	DV8.478.56.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 RHS EGT F W E	Spare Part	4129	15%
6695	DV8.478.57.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 3 RHS EGT F W E	Spare Part	5483	15%
6696	DV8.478.58.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 4 RHS EGT F W E	Spare Part	3625	15%
6697	DV8.478.59.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 3 LHS EGT F W E	Spare Part	4261	15%
6698	DV8.478.61.0.PR	COOLANT PIPE FOR ENGINE OUT TO DOSING MODEL IN 3 LHS EGT F W E	Spare Part	5003	15%
6699	DV8.478.62.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 2 RHS TANK SIDE	Spare Part	1855	15%
6700	DV8.478.63.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2 RHS TANK SIDE	Spare Part	1855	15%
6701	DV8.478.64.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2 LHS TANK SIDE	Spare Part	1889	15%
6702	DV8.478.66.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 2 LHS TANK SIDE	Spare Part	1828	15%
6703	DV8.505.04.0.00	HOSE FOR DV8 AIR CLEANER	Spare Part	5467	20%
6704	DV8.505.08.0.00	HOSE FOR DV8 AT TURBO END 8240405	Spare Part	6801	20%
6705	DV8.505.28.0.PR	HOSE BETWEEN AIR CLEANER PIPE	Spare Part	1738	15%
6706	DV8.505.30.0.00	AIR CLEANER KIT	Spare Part	89424	20%
6707	DV8.505.71.0.00	HOSE: AIR CLEANER	Spare Part	6492	15%
6708	DV8.505.72.0.00	RAIN CAP CLAMP	Spare Part	4078	20%
6709	DV8.505.74.0.00	AIR CLEANER PRIMARY ELEMENT	Filter	11668	20%
6710	DV8.505.75.0.00	AIR CLEANER SAFETY ELEMENT	Filter	3088	20%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		·		without Vat in NPR	Charge%
6711	DV8.505.76.0.00	HOSE: AIR CLEANER	Spare Part	5366	15%
6712	DV8.505.80.0.00	AIR CLEANER ASSLY+SAFETY ELEMT	Spare Part	26454	20%
6713	DV8.507.02.0.00	FUEL PIPE: FUEL TANK TO LEAK OFF PIPE	Spare Part	7588	15%
6714	DV8.507.03.0.00	FUEL PIPE: FUEL TANK TO FUEL FILTER	Spare Part	5705	15%
6715	DV8.507.06.0.00	FUEL INLET PIPE	Spare Part	1692	15%
6716	DV8.507.22.0.PR	FUEL PIPE FROM PRE FILTER TO TANK	Spare Part	2126	15%
6717	DV8.507.23.0.PR	FUEL PIPE	Spare Part	1166	15%
6718	DV8.507.24.0.PR	FUEL RETURN PIPE M16X1 5 TO M22X1 5	Spare Part	4406	15%
6719	DV8.507.26.0.PR	FUEL RETURN PIPE M16X1 5 MALE PLUG AND M22X1 5 UNION NUT	Spare Part	2415	15%
6720	DV8.801.21.0.00	KOEL GREEN Alternator KG 400 S T Frame L KG 47 2 VS3 SAE 1 14 415V 50 Hz 0 8 PF WITH TER	Spare Part	1500429	15%
6721	DV8.801.24.0.PR	KOEL GREEN LS-AG316294 ALTERNATOR,320KVA,KG- 45C,SAE 1/14", 415V,50HZ,3PH,0.8P.F,WITH	Spare Part	1145022	15%
6722	DV8.801.25.0.PR	KOEL GREEN ALTERNATOR KG320 ST FRAME M KG38 2 5L4A SAE 1 14 415V 50HZ 0 8 PF	Spare Part	1176526	15%
6723	DV8.801.32.0.00	KOEL GREEN ALTERNATOR, KG 380 SS, FRAME KG 47.2 VS2 SAE1/14", 415V, 50HZ, 0.8P.F, (AG31)	Spare Part	1318622	15%
6724	DV8.806.98.0.PR	ADAPTOR M16 X 1 5 AND M20 X 1 5	Spare Part	182	15%
6725	DV8.851.10.0.PR	CONTROL PANEL ASSEMBLY FOR FIRE FIGHTING APPLICATION	Spare Part	65030	15%
6726	DV8.852.10.0.00	ENGINE WIRING HARNESS ASSEMBLY FOR DV8 FIRE FIGHTING APPLICATION	Spare Part	29557	15%
6727	DV8.856.19.0.00	320KVA AVR (DSLR)	Spare Part	39353	15%
6728	DV8.858.16.0.00	ADV LOAD DUMP MODULE 24VDC	Spare Part	2111	15%
6729	DV8.866.10.0.00	ENGINE CONTROL PANEL ASSEMBLY SF KG 745 UNIT & 4-20 MA LOP	Spare Part	45058	15%
6730	DV8.867.10.0.00	ENGINE CONTROL PANEL ASSEMBLY SF KG 745 UNIT & 4-20 mA LOP	Spare Part	54042	15%
6731	DV8.867.50.0.00	ENGINE CONTROL PANEL ASSEMBLY	Spare Part	77931	15%
6732	DV8.868.80.0.PR	INTERFACE BOX ASSEMBLY	Spare Part	12415	15%
6733	DV8.875.21.0.PR	SILENCER FOR DV8 320 KVA PROJECT LAKSHYA	Spare Part	97673	15%
6734	DV8.901.01.0.ASP	AVR R450-KG 47.2,KVA rating-380 to 1010 KVA ,3Ph., LS Part No(AEM110RE031B)	Spare Part	217154	15%
6735	DV8.901.13.0.ASP	Coupling Disc 14 KG 47 2 KVA rating 380 to 600KVA 3Ph LS Part No PUS466TX000B	Spare Part	15135	15%
6736	DV8.910.20.0.00	ENGINE WIRING HARNESS ASSEMBLY FOR DV8 ENGINE WITH KG545 UNIT WITH CONECTOR	Spare Part	12738	15%
6737	DV8.910.50.0.00	ENGINE WIRING HARNESS ASSEMBLY FOR DV8 ENGINE WITH KG545 UNIT & 4-20 MA GEMS LOP	Spare Part	11080	15%
6738	DV8.910.60.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	33944	15%
6739	DV8.910.70.0.00	ENGINE WIRING HARNESS ASSEMBLY	Spare Part	33495	15%
6740	DV8.910.90.0.PR	COLD STARTING WIRING HARNESS FOR DV8 GENSET	Spare Part	25757	15%
6741	DV8.991.35.1.SP	COUPLING ELEMENT	Spare Part	194213	15%
6742	DV8.991.36.0.PR	COUPLING	Spare Part	79187	15%
6743	DV8.EGT4.28.0.PR	EXHAUST TEMP SENSOR T6 BEFORE MIXER FOR CPCB4	Spare Part	11040	15%
6744	F.038.4.01.003	MAIN BEARING PAIR GROOVED RA3	Spare Part	538	15%
6745	F.038.4.01.013	MAIN BEARING PAIR GROOVED RA3	Spare Part	594	15%
6746	F.038.4.01.023	Main Bearing 020 O/S Pair	Spare Part	612	15%
6747	F.073.4.00.003	MAIN BEARING: HA394	Spare Part	766	15%
6748	F.073.4.00.013	MAIN BEARING: HA394	Spare Part	791	15%
6749	F.073.4.00.023	MAIN BEARING: HA394	Spare Part	791	15%
6750	F.073.4.00.033	Main Bearing 030 O/S	Spare Part	831	15%
6751	F.547.4.00.003	BEARING MAIN KIR DV10, STD (PAIR)	Spare Part	3009	15%
6752	F6.001.07.0.00	DOWEL (DIN 1472-6X18-ST)OR GROOVED PINS	Spare Part	58	15%
6753	F6.001.103.0.00	OIL SPRAY ASSEMBLY	Spare Part	871	15%
6754	F6.001.104.0.00	OIL SPRAY ASSEMBLY	Spare Part	871	15%
6755	F6.001.24.0.00	PRESSURE REDUCING NOZZLE	Spare Part	58	15%
6756	F6.001.25.0.00	INTERMEDIATE GEAR ASSEMBLY	Spare Part	11372	15%
6757	F6.001.26.0.00	INTERMEDIATE GEAR FOR OIL PUMP	Spare Part	5514	15%
6758	F6.001.27.0.00	INTERMEDIATE SHAFT	Spare Part	157	15%
6759	F6.001.28.0.00	PLATE COVER FOR REAR SIDE	Spare Part	778	15%
6760	F6.001.29.0.00	BALL BEARING	Spare Part	982	15%
6761	F6.001.30.0.00	SPACER(20X28X1-DIN 988)	Spare Part	37	15%
6762	F6.001.31.0.00	RELIEF VALVE ASSLY	Spare Part	578	15%
6763	F6.001.38.0.00	TAPER SPACER.	Spare Part	185	15%
6764	F6.001.44.0.00	HUB	Spare Part	2938	15%
6765	F6.001.45.0.00	BACK PLATE	Spare Part	483	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
6766	F6.001.52.0.00	HUB & CENTRE RING ASSEMBLY	Spare Part	4578	15%
6767	F6.001.54.0.00	SEALING CAP (26 DIN 443)	Spare Part	46	15%
6768	F6.001.57.0.00	DOWEL (10X32 DIN1474)GROOVED PINS	Spare Part	83	15%
6769	F6.001.58.0.00	SEALING CAP	Spare Part	54	20%
6770	F6.001.66.0.00	INTERMEDIATE MEDIATE GEAR WITH BUSH	Spare Part	25794	15%
6771	F6.001.87.0.00	BANJO BOLT: M12X1.5	Spare Part	132	15%
6772	F6.001.91.0.00	SEALING CAP	Spare Part	37	15%
6773	F6.002.02.0.00	JOINT: FRONT PLATE	Spare Part	637	15%
6774	F6.002.06.0.00	FRONT PLATE	Spare Part	5465	15%
6775	F6.003.04.0.00	DOWEL	Spare Part	43	15%
6776	F6.003.05.0.00	DEFLECTOR	Spare Part	166	15%
6777	F6.003.06.0.00	SOCKET HEAD SCREW(DIN 912 M16X50-10.9)	Spare Part	218	15%
6778	F6.003.09.0.00	DEFLECTOR FOR FWE OIL SEAL	Spare Part	782	15%
6779	F6.003.11.0.00	CRANK GEAR FINISHED	Spare Part	3923	15%
6780	F6.004.03.0.00	CAMSHAFT GEAR	Spare Part	12606	15%
6781	F6.004.09.0.00	SPINON FILTER ASSLY	Filter	4053	20%
6782	F6.004.14.0.00	TAPPET	Spare Part	505	15%
6783	F6.004.40.0.00	PUSH ROD ASSLY	Spare Part	1052	15%
6784	F6.004.58.0.00	FUEL FILTER & WATER SEPERATOR	Filter	13001	20%
6785	F6.005.02.0.00	CONNECTING ROD BOLT	Spare Part	338	15%
6786	F6.005.12.0.00	PISTON PIN	Spare Part	1649	15%
6787	F6.005.30.0.00	CONNECTING ROD ASSLY	Spare Part	15203	15%
6788	F6.005.71.0.00	PISTON RING SET (STD.)	Spare Part	2828	15%
6789	F6.006.02.0.00	RUBBER RING	Spare Part	314	15%
6790	F6.006.03.0.00	SEALING RING: BOTTOM	Spare Part	797	15%
6791	F6.007.02.0.00	VALVE GUIDE	Spare Part	258	15%
6792	F6.007.03.0.00	VALVE SEAT INSERT INLET	Spare Part	1898	15%
6793	F6.007.04.0.00	VALVE SEAT INSERT EXHAUST	Spare Part	760	15%
6794	F6.007.07.0.00	VALVE COLLET PAIR	Spare Part	58	15%
6795	F6.007.08.0.00	VALVE SPRING CUP	Spare Part	203	15%
6796	F6.007.09.0.00	VALVE SPRING -OUTER	Spare Part	326	15%
6797	F6.007.101.0.00	SOCKET HEAD BOLT FOR CYLINDER HEAD (M12X1.75X140 - GRADE 12.9)	Spare Part	523	15%
6798	F6.007.11.0.00	VALVE SPRING (INNER)	Spare Part	206	15%
6799	F6.007.12.0.00	WASHER	Spare Part	37	15%
6800	F6.007.13.0.00	WASHER	Spare Part	28	15%
6801	F6.007.14.0.00	VALVE SEAL	Spare Part	194	15%
6802	F6.007.15.0.00	ROCKER SUPPORT SUB ASSEMBLY	Spare Part	1920	15%
6803	F6.007.19.0.00	BALL SCREW	Spare Part	132	15%
6804	F6.007.21.0.00	LEVER CLAMP	Spare Part	206	15%
6805	F6.007.22.0.00	CYLINDER HEAD BOLT: LONG	Spare Part	406	15%
6806	F6.007.23.0.00	CYLINDER HEAD BOLT: SHORT	Spare Part	378	15%
6807	F6.007.26.0.00	CYL HEAD GASKET 1.25 MM THK	Spare Part	1911	15%
6808	F6.007.31.0.00	BANJO BOLT :M8X1	Spare Part	65	15%
6809	F6.007.33.0.00	STRAIGHT THR SOCKET	Spare Part	68	15%
6810	F6.007.34.0.00	SEALING CAP	Spare Part	54	20%
6811	F6.007.35.0.00	SEALING CAP	Spare Part	67	20%
6812	F6.007.40.0.00	OIL SUPPLY PIPE ASSLY	Spare Part	212	15%
6813	F6.007.55.0.00	VALVE PAIR INLET & EXHAUST	Spare Part	4914	15%
6814	F6.007.60.0.00	V.R. LEVER & BUSH ASSLY	Spare Part	705	15%
	F6.007.96.0.00			1923	15%
6815 6816	F6.007.98.0.00	CYL HEAD GASKET 1.25 MM THK CYLINDER HEAD GASKET	Spare Part Spare Part	2138	15%
	F6.007.98.0.00	WASHER	Spare Part	46	15%
6817			· ·		
6818	F6.008.01.0.00 F6.008.02.0.00	ROCKER COVER JOINT: ROCKER COVER	Spare Part Spare Part	2723 265	15% 15%
6819					



				Price to Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
				NPR	
6821	F6.009.16.0.00	OIL SEAL: 100X75X10 TEFLON GE	Spare Part	2938	15%
6822	F6.009.27.0.00	O RING: ID 65 DIA 5 - 21516	Spare Part	117	15%
6823	F6.009.39.0.00	JOINT: SUCTION CONNECTION	Spare Part	52	15%
6824	F6.011.01.0.00	DIPSTICK ASSEMBLY	Spare Part	271	15%
6825	F6.011.04.0.00	O RING: DIPSTICK 7X2 TGL 6365 - 21511	Spare Part	43	15%
6826	F6.012.01.0.00	LUBE OIL SUMP: SHEET METAL	Spare Part	22070	15%
6827	F6.013.01.0.00	BREATHER HOUSING	Spare Part	1188	15%
6828	F6.013.02.0.00	PIPE	Spare Part	185	15%
6829	F6.013.04.0.00	VENTING POT	Spare Part	1671	15%
6830	F6.013.11.0.00	OUTLET PIPE	Spare Part	465	15%
6831	F6.013.12.0.00	O RING: 30 ID DIA 2- 21509	Spare Part	49	15%
6832	F6.013.13.0.00	RUBBER HOSES: 40LG	Spare Part	222	15%
6833	F6.013.22.0.00	HOSE	Spare Part	148	15%
6834	F6.015.01.0.00	CRANK PULLEY.(FINISH.)	Spare Part	8231	15%
6835	F6.015.02.0.00	DRIVEN HUB	Spare Part	6292	15%
6836	F6.015.03.0.00	DAMPER	Spare Part	28778	15%
6837	F6.015.04.0.00	THRUST PLATE	Spare Part	495	15%
6838	F6.015.07.0.00	HEX BOLT FOR CRANK-PULLEY	Spare Part	452	15%
6839	F6.015.31.0.00	CRANK PULLEY PCD 155, PCD 210	Spare Part	8021	15%
6840	F6.016.12.0.00	RUBBER CAP	Spare Part	95	15%
6841	F6.016.16.0.00	OIL SEAL: 150X120X13.5 TEFLON FWE	Spare Part	3483	15%
6842	F6.017.02.0.00	SHAFT	Spare Part	1637	15%
6843	F6.017.03.0.00	PULLEY	Spare Part	3895	15%
6844	F6.017.17.0.00	BRACKET FOR FAN PULLEY MOUNTING	Spare Part	1523	15%
6845	F6.017.21.0.00	BALL BEARING(DIN 625-6306-2RS1)	Spare Part	1858	15%
6846	F6.017.30.0.00	PULLEY ASSLY: FAN DRIVE	Spare Part	11428	15%
6847	F6.017.31.0.00	FAN PULLEY POLY V PCD 155	Spare Part	7637	15%
6848	F6.018.01.0.00	BRACKET	Spare Part	1535	15%
6849	F6.018.05.0.00	PULLEY	Spare Part	1369	15%
6850	F6.018.14.0.00	DEEP GROOVE BALL BEARING (DIN 625-6204 2RS1-C3)	Spare Part	465	15%
6851	F6.018.19.0.00	EYE BOLT	Spare Part	400	15%
6852	F6.018.20.0.00	BELT TENSIONING UNIT ASSEMBLY	Spare Part	8963	15%
6853	F6.018.21.0.00	SWIVEL PIECE	Spare Part	169	15%
6854	F6.018.22.0.00	ADAPTOR	Spare Part	175	15%
6855	F6.018.30.0.00	BRACKET: PULLEY ASSLY	Spare Part	8889	15%
6856	F6.018.40.0.00	BELT TENSIONING UNIT ASSLY	Spare Part	7249	15%
6857	F6.019.16.0.00	V-BELT (AVX 13 X 1562 L)	Spare Part	1649	15%
6858	F6.019.17.0.00	V BELT: AVX13 X 1015 LENGTH	Spare Part	929	15%
6859	F6.021.11.0.00	PUMP DRIVING GEAR	Spare Part	5911	15%
6860	F6.021.15.0.00	O RING 28X5 TGL 6365 -21509	Spare Part	68	15%
6861	F6.022.05.0.00	RUBBER BOOT	Spare Part	138	15%
6862	F6.022.08.0.00	GASKET.	Spare Part	46	15%
6863	F6.022.20.0.00	SUCTION TUBE	Spare Part	1437	15%
6864	F6.023.20.0.00	PIPE SUB ASSEMBLY	Spare Part	815	15%
6865	F6.024.03.0.00	THREADED ADAPTOR	Spare Part	148	15%
6866	F6.024.07.0.00	JOINT: CENTRIFUGE CLEANER	Spare Part	49	15%
6867	F6.024.103.0.00	JOINT FOR LUB OIL FILTER HEADER	Spare Part	529	15%
6868	F6.024.17.0.00	O RING ID 20 DIA 2 MAT 21516	Spare Part	9	15%
6869	F6.024.40.0.00	RELIEF VALVE ASSLY	Spare Part	1822	15%
6870	F6.024.46.0.00	CENTRIFUGE FILTER	Spare Part	14369	20%
6871	F6.024.47.0.00	O RING: DRAIN PLUG	Spare Part	43	15%
6872	F6.024.50.0.00	ASSEMBLY OF LUBE OIL FILTER & HEADER	Spare Part	26181	15%
6873	F6.024.74.0.00	LUBE OIL FILTER HEADER	Spare Part	10557	15%
6874	F6.024.75.0.00	JOINT: GLACIER FILTER	Spare Part	52	15%
6875	F6.024.77.0.00	JOINT: OIL RETURN TURBO	Spare Part	34	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
				without Vat in NPR	Charge%
6876	F6.024.78.0.00	GASKET FOR CRANKCASE BREATHER)	Spare Part	52	15%
6877	F6.024.81.0.00	JOINT	Spare Part	58	15%
6878	F6.024.82.0.00	JOINT: SPECIAL ADAPTOR PIECE	Spare Part	71	15%
6879	F6.024.83.0.00	JOINT	Spare Part	62	15%
6880	F6.024.85.0.00	JOINT: WATER PUMP	Spare Part	102	15%
6881	F6.024.86.0.00	JOINT: DELIVERY PIPE	Spare Part	46	15%
6882	F6.024.88.0.00	JOINT: COOLER BOX	Spare Part	212	15%
6883	F6.024.91.0.00	JOINT: HEADER	Spare Part	49	15%
6884	F6.024.93.0.00	JOINT: OIL SUMP	Spare Part	1391	15%
6885	F6.024.94.0.00	JOINT: FLANGE	Spare Part	108	15%
6886	F6.024.95.0.00	JOINT: FLYWHEEL HOUSING	Spare Part	412	15%
6887	F6.024.96.0.00	JOINT: FRONT PLATE	Spare Part	415	15%
6888	F6.024.97.0.00	JOINT: GEAR CASING	Spare Part	846	15%
6889	F6.024.98.0.00	JOINT: INLET MANIFOLD	Spare Part	92	15%
6890	F6.025.07.0.00	CHARGE AIR MANIFOLD	Spare Part	14329	15%
6891	F6.026.03.0.00	JOINT: EXHAUST MANIFOLD	Spare Part	138	15%
6892	F6.026.04.0.00	SPACER SLEEVE	Spare Part	89	15%
6893	F6.026.06.0.00	GASKET FOR EXHaust MANIFOLD	Spare Part	138	15%
6894	F6.028.01.0.00	STARTER SM 130PE	Spare Part	170828	15%
6895	F6.029.01.0.00	FLANGE	Spare Part	1892	15%
6896	F6.029.02.0.00	ADAPTOR	Spare Part	3274	15%
6897	F6.029.10.0.00	FUEL PUMP	Spare Part	79014	15%
6898	F6.029.103.0.PR	HOUSING	Spare Part	3305	15%
6899	F6.029.104.0.PR	SHAFT DISTRIBUTOR DRIVE	Spare Part	3434	15%
6900	F6.029.19.0.00	LUBE OIL SUPPLY PIPE(CRANK CASE TO FUEL PUMP)	Spare Part	662	15%
6901	F6.029.60.0.00	LUB OIL SUPPLY PIPE SUB ASSEMBLY	Spare Part	262	15%
6902	F6.029.92.0.00	FUEL PUMP GEAR	Spare Part	4286	15%
6903	F6.030.10.0.00	PIPE ASSEMBLY	Spare Part	7837	15%
6904	F6.030.40.0.00	HIGH PRESS PIPE ASSLY	Spare Part	6295	15%
6905	F6.031.02.0.00	CUP SEAL	Spare Part	62	15%
6906	F6.031.03.0.00	FORK FOR INJECTOR	Spare Part	1225	15%
6907	F6.031.05.0.00	SPEHERICAL WASHER	Spare Part	43	15%
6908	F6.031.07.0.00	INJECTOR	Spare Part	8680	15%
6909	F6.031.51.0.00	Sealing washer [2 916 710 602]	Spare Part	52	15%
6910	F6.032.05.0.00	BANJO BOLT: HOLLOW BOLT	Spare Part	145	15%
6911	F6.032.20.0.00	VENT PIPE SUB ASSLY	Spare Part	1785	15%
6912	F6.032.40.0.00	SUB ASSLY OF VENT TUBE FOR 4 VALVE	Spare Part	2231	15%
6913	F6.032.70.0.00	VENT TUBE ASSEMBLY	Spare Part	2714	15%
6914	F6.034.06.0.00	BRACKET FOR FUEL FILTER	Spare Part	677	15%
6915	F6.034.08.0.00	FUEL PIPE: FEED PUMP TO FUEL FILTER	Spare Part	215	15%
	F6.034.11.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	545	15%
6917	F6.034.12.0.00	FUEL PIPE: FUEL FILTER TO FIP	Spare Part	822	15%
6918	F6.034.14.0.00	FUEL PIPE FUEL FILTER TO FIP	Spare Part	982	15%
6919	F6.036.01.0.00	LUBE OIL COOLER -PLATE TYPE	Spare Part	29895	15%
6920	F6.036.06.0.00	WATER DRAIN PLUG	Spare Part	191	15%
6921	F6.036.11.0.00	JOINT: LUBE OIL COOLER	Spare Part	52	15%
6922	F6.040.01.0.00	SEALING WASHER	Spare Part	43	15%
6923	F6.040.03.0.00	ROCKER COVER	Spare Part	5572	15%
6924	F6.040.04.0.00	OIL FILLER CAP	Spare Part	363	15%
6925	F6.040.05.0.00	OIL FILLER CAP OIL FILLER CAP PLASTIC	Spare Part	212	15%
6926	F6.042.31.0.00	INJECTOR	Spare Part	10031	15%
6927	F6.043.10.0.00	LEAK OFF PIPE ASSEMBLY	Spare Part	2268	15%
	F6.043.10.0.00	LEAK OFF PIPE ASSEMBLY LEAK OFF PIPE WITH FLEX ELEMENT	Spare Part	2772	15%
	1 0.040.20.0.00	LECTION OF THE WITH LEA LELIVICIAL	Spare Part	2112	13%
6928 6929	F6.044.01.0.00	FLYWHEEL HOUSING	Spare Part	59015	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
			ŭ <i>,</i>	without Vat in NPR	Charge%
6931	F6.046.115.0.PR	PIGTAIL FOR LOP SENSOR	Spare Part	1637	15%
6932	F6.046.116.0.PR	PIGTAIL FOR VDO SENSOR	Spare Part	406	15%
6933	F6.063.71.0.00	ADAPTOR FOR WATER TEMP SENSOR	Spare Part	692	15%
6934	F6.063.74.0.00	F002 G1B 345 CHARGING ALTERNATOR	Spare Part	29009	15%
6935	F6.064.52.0.00	HOSE FOR DRAIN PUMP OUT	Spare Part	1649	15%
6936	F6.064.95.0.00	V BELT: 4PK1280 POLY	Spare Part	1006	15%
6937	F6.065.27.0.00	HOSE: AIR CLEANER	Spare Part	6729	15%
6938	F6.086.25.0.PR	GAS TRAIN ASSLY	Spare Part	160690	15%
6939	F6.086.50.0.PR	WOODWARD TRIM DOWN PG PLUS SYSTEM FOR 6 CYLINDER NATURAL GAS GENSET	Spare Part	739325	15%
6940	F6.1002.08.0.00	PIPE CAC TO INLET MANIFOLD	Spare Part	10415	15%
6941	F6.1002.32.0.PR	COPPER WASHER FOR SPARK PLUG THICKNESS 0 5 mm	Spare Part	18	15%
6942	F6.1002.33.0.PR	COPPER WASHER FOR SPARK PLUG THICKNESS 0 8 MM	Spare Part	25	15%
6943	F6.1002.34.0.PR	COPPER WASHER FOR SPARK PLUG THICKNESS 1 MM	Spare Part	25	15%
6944	F6.1005.01.0.00	GOVERNOR CARD	Spare Part	88436	15%
6945	F6.1005.04.0.00	CONVERTER CABLE	Spare Part	17843	15%
6946	F6.1020.10.0.00	WIRING HARNESS ASSEMBLY SUITABLE FOR 250 KVA WITH KG54 UNIT	Spare Part	9335	15%
6947	F6.1020.40.0.00	ENGINE WIRING HARNESS WITH KG 54 UNIT	Spare Part	14689	15%
6948	F6.1020.50.0.00	ENGINE WIRING HARNESS SF KG545 UNIT WITH ELECT. GOV AND 4-20MA LOP TRANSMITTER	Spare Part	18535	15%
6949	F6.1020.70.0.00	ENGINE WIRING HARNESS ASSEMBLY with KG545 UNIT	Spare Part	17507	15%
6950	F6.1020.80.0.00	ENGINE WIRING HARNESS ASSEMBLY WITH KG545 UNIT	Spare Part	17227	15%
6951	F6.1024.10.0.00	ALTERNATOR TO CONTROL PANEL WIRING HARNESS	Spare Part	2178	15%
6952	F6.1034.60.0.PR	ENGINE CONTROL PANEL SF PNG SL90 ENGINE WITH WOODWARD ECU KG645 CONTROLLER	Spare Part	152995	15%
6953	F6.1040.50.0.PR	ENGINE WIRING HARNESS FOR 125KVA BIOGAS GENSET	Spare Part	106306	15%
6954	F6.1041.50.0.00	CONTROL PANEL ASSEMBLY S/F 200/250KVA WITH SEDEMAC & KG745 CONTROLLER	Spare Part	46775	15%
6955	F6.1043.10.0.PR	ENGINE WIRING HARNESS FOR SL90 CRDI CPCB4+	Spare Part	74002	15%
6956	F6.1101.01.0.00	FIP: 200KVA C TYPE LEVER	Spare Part	99506	15%
6957	F6.1106.60.0.00	COOLING LINE ASSEMBLY (1 1/4", 24V)	Spare Part	416684	15%
6958	F6.1127.10.0.PR	H P PIPE ASSLY CYL NO 1 SL90 4V COMMON RAIL	Spare Part	3855	15%
6959	F6.1127.20.0.PR	H P PIPE ASSLY CYL NO 2 SL90 4V COMMON RAIL	Spare Part	3855	15%
6960	F6.1127.30.0.PR	H P PIPE ASSLY CYL NO 3 SL90 4V COMMON RAIL	Spare Part	3855	15%
6961	F6.1127.40.0.PR	H P PIPE ASSLY CYL NO 4 SL90 4V COMMON RAIL	Spare Part	3855	15%
6962	F6.1127.50.0.PR	H P PIPE ASSLY CYL NO 5 SL90 4V COMMON RAIL	Spare Part	3855	15%
6963	F6.1127.60.0.PR	H P PIPE ASSLY CYL NO 6 SL90 4V COMMON RAIL	Spare Part	3840	15%
6964	F6.1127.70.0.PR	H P PIPE ASSEMBLY 1 PUMP TO RAIL SL90 4V	Spare Part	3981	15%
6965	F6.1127.80.0.PR	H P PIPE ASSEMBLY 2 PUMP TO RAIL SL90 4V	Spare Part	3963	15%
6966	F6.121.02.0.00	SUCTION CONNECTION FOR FIRE FIGHTING	Spare Part	2843	15%
6967	F6.123.02.0.00	SILENCER	Spare Part	124866	15%
6968	F6.123.03.0.00	SILENCER	Spare Part	69045	15%
6969	F6.123.06.0.00	FLANGE	Spare Part	2723	15%
6970	F6.126.02.0.00	ANTI VIBRATION MOUNTS	Spare Part	4406	15%
6971	F6.138.01.0.00	BREATHER PIPE(MODULED RUBBER HOSE WITH REINFORCEMENT PLIES) FOR 160 & 250 KVA	Spare Part	2702	15%
6972	F6.138.02.0.00	BREATHER HOSE	Spare Part	3071	15%
6973	F6.138.13.0.PR	PIPE FOR AIR CLEANER	Spare Part	8240	15%
6974	F6.149.02.0.00	JOINT: EXHAUST SILENCER	Spare Part	1098	15%
6975	F6.149.03.0.00	FLANGE	Spare Part	2031	15%
6976	F6.150.01.0.SP	RADIATOR	Spare Part	560402	15%
6977	F6.150.02.0.00	STAY FOR RADIATOR	Spare Part	929	15%
6978	F6.150.03.0.00	HOSE	Spare Part	1797	15%
6979	F6.150.04.0.00	PIPE: THERMOSTAT TO RADIATOR	Spare Part	1317	15%
6980	F6.150.06.0.00	FAN SPACER	Spare Part	7108	15%
6981	F6.150.13.0.00	HOSE: WATER OUT	Spare Part	514	15%
6982	F6.150.17.0.00	HOSE: RADIATOR TO WATER PUMP	Spare Part	2175	15%
6983	F6.150.77.0.00	ALUMINIUM RADIATOR ASSEMBLY FOR 200 KVA BANCO	Spare Part	278725	15%
	1. 0. 100.7 0.0.00	ALCOMING IN INDIA TOTA ACCEMBET TOTAL 200 INVA BANCO	Spare Fall	210123	15%
6984	F6.151.02.0.00	UNION ADOPTOR	Spare Part	255	15%



6986 F6.154.1 6987 F6.155.2 6988 F6.155.3 6989 F6.156.0 6990 F6.156.4 6991 F6.156.4 6992 F6.156.4 6993 F6.156.5 6995 F6.156.6 6996 F6.156.6 6997 F6.157.1 6998 F6.157.1 6998 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.167.1 7004 F6.168.0	5.20.0.00 5.30.0.PR 5.30.0.PR 5.30.0.00 6.42.0.00 6.42.0.00 6.43.0.00 6.44.0.00 6.45.0.00 6.45.0.00 6.59.0.PR 7.10.0.00 7.20.0.00 7.00.000 7.14.0.00 7.00.000	CYL LINER ASSEMBLY CYLINDER HEAD SUB ASSEMBLY CYLINDER HEAD SUBASSEMBLY THERMOSTAT COVER: FINISH JOINT FOR BLANKING PLATE(NON ASBESTOS) COVER PLATE JOINT: THERMOSTAT COVER & GEAR CASING GEAR CASING: CAST IRON SHIM FOR SPEED PHASE SENSOR CYLINDER HEAD ASSLY ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) OR RING: 68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE OR RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET OR RING: 22 ID DIA5 - 21509 OIL SUPPLY PIPE SUB ASSLY (FOR T/C)	Spare Part	Customer without Vat in NPR 7231 26717 34464 1698 117 665 154 62048 212 200 225 35347 4594 7720 21061 49 8458 49 243 136530 705 415 582	Custom Charge% 15% 15% 15% 15% 15% 15% 15% 15% 15% 1
6987 F6.155.2 6988 F6.155.3 6989 F6.156.4 6990 F6.156.4 6991 F6.156.4 6992 F6.156.4 6993 F6.156.5 6995 F6.156.6 6996 F6.156.6 6997 F6.157.1 6998 F6.157.1 6998 F6.157.5 6999 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.167.0 7004 F6.168.0 7007 F6.169.0 7007 F6.169.0 7008 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.1 7020 F6.177.1 7020 F6.177.1 7021 F6.177.1	5.20.0.00 5.30.0.PR 5.30.0.PR 5.30.0.00 6.42.0.00 6.42.0.00 6.43.0.00 6.44.0.00 6.45.0.00 6.45.0.00 6.59.0.PR 7.10.0.00 7.20.0.00 7.00.000 7.14.0.00 7.00.000	CYL LINER ASSEMBLY CYLINDER HEAD SUB ASSEMBLY CYLINDER HEAD SUBASSEMBLY THERMOSTAT COVER: FINISH JOINT FOR BLANKING PLATE(NON ASBESTOS) COVER PLATE JOINT: THERMOSTAT COVER & GEAR CASING GEAR CASING: CAST IRON SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSOR CYLINDER HEAD ASSLY ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) O RING: 68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 COID STATING KIT OF THE STATE OF THE ST	Spare Part	NPR 7231 26717 34464 1698 117 665 154 62048 212 200 225 35347 4594 7720 21061 49 8458 49 243 136530 705 415 582	15% 15% 15% 15% 15% 15% 15% 15% 15% 15%
6987 F6.155.2 6988 F6.155.3 6989 F6.156.4 6990 F6.156.4 6991 F6.156.4 6992 F6.156.4 6993 F6.156.5 6995 F6.156.6 6996 F6.156.6 6997 F6.157.1 6998 F6.157.1 6998 F6.157.5 6999 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.167.0 7004 F6.168.0 7007 F6.169.0 7007 F6.169.0 7008 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.1 7020 F6.177.1 7020 F6.177.1 7021 F6.177.1	5.20.0.00 5.30.0.PR 5.30.0.PR 5.30.0.00 6.42.0.00 6.42.0.00 6.43.0.00 6.44.0.00 6.45.0.00 6.45.0.00 6.59.0.PR 7.10.0.00 7.20.0.00 7.00.000 7.14.0.00 7.00.000	CYLINDER HEAD SUB ASSEMBLY CYLINDER HEAD SUBASSEMBLY THERMOSTAT COVER: FINISH JOINT FOR BLANKING PLATE(NON ASBESTOS) COVER PLATE JOINT: THERMOSTAT COVER & GEAR CASING GEAR CASING: CAST IRON SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSORS CYLINDER HEAD ASSLY ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) O RING: 68X3 TGL 6365; CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	7231 26717 34464 1698 117 665 154 62048 212 200 225 35347 4594 7720 21061 49 8458 49 243 136530 705 415 582 1237 58	15% 15% 15% 15% 15% 15% 15% 15% 15% 15%
6988 F6.155.3 6989 F6.156.4 6990 F6.156.4 6991 F6.156.4 6992 F6.156.4 6993 F6.156.5 6995 F6.156.6 6996 F6.156.6 6997 F6.157.1 6998 F6.157.5 6999 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.167.0 7004 F6.168.0 7007 F6.169.0 7008 F6.169.0 7009 F6.169.0 7010 F6.169.0 7011 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7020 F6.177.1 7021 F6.177.1	5.30.0.PR 5.30.0.PR 5.03.0.00 6.42.0.00 6.43.0.00 6.44.0.00 6.45.0.00 6.59.0.PR 6.61.0.PR 7.10.0.00 7.25.0.00 7.20.0.00 7.30.0.00 7.30.0.00 7.40.0.00	CYLINDER HEAD SUBASSEMBLY THERMOSTAT COVER: FINISH JOINT FOR BLANKING PLATE(NON ASBESTOS) COVER PLATE JOINT: THERMOSTAT COVER & GEAR CASING GEAR CASING: CAST IRON SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSORS CYLINDER HEAD ASSLY ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) O RING: 68X3 TGL 6365; CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE O RING: 22 ID DIA5 - 21509	Spare Part	34464 1698 117 665 154 62048 212 200 225 35347 4594 7720 21061 49 8458 49 243 136530 705 415 582	15% 15% 15% 15% 15% 15% 15% 15% 15% 15%
6989 F6.156.0 6990 F6.156.4 6991 F6.156.4 6992 F6.156.4 6993 F6.156.5 6994 F6.156.6 6996 F6.156.6 6997 F6.157.1 6998 F6.157.5 6999 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.168.0 7005 F6.168.0 7006 F6.169.0 7007 F6.169.0 7008 F6.169.0 7010 F6.169.0 7011 F6.169.0 7012 F6.169.0 7012 F6.169.0 7013 F6.169.0 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7020 F6.177.1 7021 F6.177.1	6.03.0.00 6.42.0.00 6.43.0.00 6.44.0.00 6.44.0.00 6.45.0.00 6.59.0.PR 6.61.0.PR 7.10.0.00 7.50.0.00 7.02.0.00 7.03.0.00 7.14.0.00 7.02.0.00 7.03.0.00 7.04.0.00 7.05.0.00 7.05.0.00 7.05.0.00 7.05.0.00 7.05.0.00 7.05.0.00 7.05.0.00 7.05.0.00 7.05.0.00 7.05.0.00 7.05.0.00 7.05.0.00 7.05.0.00 7.05.0.00 7.05.0.00 7.05.0.00	THERMOSTAT COVER: FINISH JOINT FOR BLANKING PLATE(NON ASBESTOS) COVER PLATE JOINT: THERMOSTAT COVER & GEAR CASING GEAR CASING: CAST IRON SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSORS CYLINDER HEAD ASSLY ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) OR RING: 68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE OR RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE OR RING: 22 ID DIA5 - 21509	Spare Part	1698 1177 665 154 62048 212 200 225 35347 4594 7720 21061 49 8458 49 243 136530 705 415 582 1237 58	15% 15% 15% 15% 15% 15% 15% 15% 15% 15%
6990 F6.156.4 6991 F6.156.4 6992 F6.156.4 6993 F6.156.5 6994 F6.156.6 6996 F6.156.6 6997 F6.157.1 6998 F6.157.5 6999 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.168.0 7005 F6.168.0 7006 F6.169.0 7007 F6.169.0 7008 F6.169.0 7010 F6.169.0 7011 F6.169.1 7011 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7020 F6.177.1 7021 F6.177.1	6.42.0.00 6.43.0.00 6.44.0.00 6.45.0.00 6.59.0.PR 6.61.0.PR 6.62.0.PR 7.10.0.00 7.50.0.00 7.20.0.00 7.00.00 7.14.0.00 7.14.0.00 7.00.00	JOINT FOR BLANKING PLATE (NON ASBESTOS) COVER PLATE JOINT: THERMOSTAT COVER & GEAR CASING GEAR CASING: CAST IRON SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSORS CYLINDER HEAD ASSLY ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) OR RING. (68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE OR RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET OR RING: 22 ID DIA5 - 21509	Spare Part	117 665 154 62048 212 200 225 35347 4594 7720 21061 49 8458 49 243 136530 705 415 582 1237 58	15% 15% 15% 15% 15% 15% 15% 15% 15% 15%
6991 F6.156.4 6992 F6.156.4 6993 F6.156.5 6994 F6.156.6 6996 F6.156.6 6997 F6.157.1 6998 F6.157.5 6999 F6.164.2 7000 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.168.0 7005 F6.168.0 7006 F6.169.0 7007 F6.169.0 7010 F6.169.0 7010 F6.169.1 7011 F6.169.2 7011 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1	6.43.0.00 6.44.0.00 6.45.0.00 6.59.0.PR 6.61.0.PR 6.62.0.PR 7.10.0.00 7.50.0.00 7.20.0.00 7.00.00 7.14.0.00 7.14.0.00 7.14.0.00 7.00.00	COVER PLATE JOINT: THERMOSTAT COVER & GEAR CASING GEAR CASING: CAST IRON SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSORS CYLINDER HEAD ASSLY ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) O RING. (68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	665 154 62048 212 200 225 35347 4594 7720 21061 49 8458 49 243 136530 705 415 582 1237 58	15% 15% 15% 15% 15% 15% 15% 15% 15% 15%
6992 F6.156.4 6993 F6.156.5 6994 F6.156.5 6995 F6.156.6 6996 F6.156.6 6997 F6.157.5 6999 F6.164.2 7000 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.168.0 7005 F6.168.0 7007 F6.169.0 7008 F6.169.0 7010 F6.169.0 7010 F6.169.1 7011 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1	6.44.0.00 6.45.0.00 6.59.0.PR 6.61.0.PR 6.62.0.PR 7.10.0.00 7.50.0.00 7.20.0.00 7.02.0.00 7.14.0.00 7.14.0.00 7.02.0.00	JOINT: THERMOSTAT COVER & GEAR CASING GEAR CASING: CAST IRON SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSORS CYLINDER HEAD ASSLY ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) O RING.(68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	154 62048 212 200 225 35347 4594 7720 21061 49 8458 49 243 136530 705 415 582 1237	15% 15% 15% 15% 15% 15% 15% 15% 15% 15%
6993 F6.156.4 6994 F6.156.5 6995 F6.156.6 6996 F6.156.6 6997 F6.157.5 6998 F6.157.5 6999 F6.164.2 7000 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.168.0 7005 F6.168.0 7006 F6.169.0 7007 F6.169.0 7010 F6.169.0 7010 F6.169.1 7011 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1	6.45.0.00 6.59.0.PR 6.61.0.PR 6.62.0.PR 7.10.0.00 7.50.0.00 7.20.0.00 7.30.0.00 7.40.0.00 7.41.0.00 8.02.0.00 9.02.0.00 9.03.0.00 9.03.0.00 9.03.0.00 9.04.0.00 9.09.0.00 9.09.0.00 9.09.0.00	GEAR CASING: CAST IRON SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSORS CYLINDER HEAD ASSLY ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) O RING.(68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	62048 212 200 225 35347 4594 7720 21061 49 8458 49 243 136530 705 415 582 1237	15% 15% 15% 15% 15% 15% 15% 15% 15% 15%
6994 F6.156.5 6995 F6.156.6 6996 F6.156.6 6997 F6.157.1 6998 F6.157.5 6999 F6.164.2 7000 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.167.1 7004 F6.168.0 7005 F6.168.0 7007 F6.169.0 7008 F6.169.0 7010 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1	3.59.0.PR 3.61.0.PR 3.62.0.PR 7.10.0.00 7.50.0.00 1.20.0.00 7.02.0.00 7.03.0.00 7.04.0.00 3.02.0.00 3.02.0.00 3.02.0.00 3.03.0.00 3.03.0.00 3.04.0.00 3.04.0.00 3.04.0.00 3.04.0.00 3.04.0.00 3.04.0.00 3.05.00 3.05.0.00 3.05.0.00 3.05.0.00 3.05.0.00 3.05.0.00 3.05.00 3.05.00 3.05.00 3.05.00 3.05.00 3.05.00 3.05.00 3.05.00 3.05.00 3.05.00 3.05.00 3.05.00 3.05.00 3.05.00 3.05.00	SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSORS CYLINDER HEAD ASSLY ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) O RING.(68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	212 200 225 35347 4594 7720 21061 49 8458 49 243 136530 705 415 582 1237	15% 15% 15% 15% 15% 15% 15% 15% 15% 15%
6995 F6.156.6 6996 F6.156.6 6997 F6.157.1 6998 F6.157.5 6999 F6.164.2 7000 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.167.1 7004 F6.168.0 7005 F6.1684.2 7006 F6.169.0 7007 F6.169.0 7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1	8.61.0.PR 8.62.0.PR 7.10.0.00 7.50.0.00 1.20.0.00 7.02.0.00 7.03.0.00 7.06.0.00 7.14.0.00 8.02.0.00 8.02.0.00 9.02.0.00 9.03.0.00 9.04.0.00 9.04.0.00 9.04.0.00 9.04.0.00 9.04.0.00	SHIM FOR SPEED PHASE SENSOR SHIM FOR SPEED PHASE SENSORS CYLINDER HEAD ASSLY ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) O RING.(68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	200 225 35347 4594 7720 21061 49 8458 49 243 136530 705 415 582 1237	15% 15% 15% 15% 15% 15% 15% 15% 15% 15%
6996 F6.156.6 6997 F6.157.1 6998 F6.157.1 6998 F6.157.5 6999 F6.164.2 7000 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.167.1 7004 F6.168.0 7005 F6.1684. 7006 F6.169.0 7007 F6.169.0 7008 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1	3.62.0.PR 7.10.0.00 7.50.0.00 1.20.0.00 7.02.0.00 7.03.0.00 7.06.0.00 7.14.0.00 3.02.0.00 3.02.0.00 9.02.0.00 9.03.0.00 9.04.0.00 9.04.0.00 9.09.0.00	SHIM FOR SPEED PHASE SENSORS CYLINDER HEAD ASSLY ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) O RING.(68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	225 35347 4594 7720 21061 49 8458 49 243 136530 705 415 582 1237	15% 15% 15% 15% 15% 15% 15% 15% 15% 15%
6997 F6.157.1 6998 F6.157.1 6999 F6.164.2 7000 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.167.1 7004 F6.168.0 7005 F6.1684.1 7006 F6.169.0 7007 F6.169.0 7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.2	7.10.0.00 7.50.0.00 1.20.0.00 7.02.0.00 7.03.0.00 7.06.0.00 7.14.0.00 8.02.0.00 8.02.0.00 9.02.0.00 9.03.0.00 9.04.0.00 9.04.0.00 9.04.0.00 9.04.0.00	CYLINDER HEAD ASSLY ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) O RING.(68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	35347 4594 7720 21061 49 8458 49 243 136530 705 415 582 1237	15% 15% 15% 15% 15% 15% 15% 15% 15% 15%
6998 F6.157.5 6999 F6.164.2 7000 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.167.1 7004 F6.168.0 7005 F6.1684. 7006 F6.169.0 7007 F6.169.0 7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1	7.50.0.00 1.20.0.00 7.02.0.00 7.03.0.00 7.06.0.00 7.14.0.00 8.02.0.00 8.02.0.00 9.02.0.00 9.03.0.00 9.04.0.00 9.04.0.00 9.09.0.00	ROCKER SUPPORT ASSEMBLY WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) O RING.(68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	4594 7720 21061 49 8458 49 243 136530 705 415 582 1237	15% 15% 15% 15% 15% 15% 15% 15% 15% 15%
6999 F6.164.2 7000 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.167.1 7004 F6.168.0 7005 F6.1684. 7006 F6.169.0 7007 F6.169.0 7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.2	4.20.0.00 7.02.0.00 7.03.0.00 7.06.0.00 7.14.0.00 8.02.0.00 84.90.0.00 9.02.0.00 9.03.0.00 9.04.0.00 9.04.0.00 9.04.0.00 9.04.0.00	WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) O RING. (68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	7720 21061 49 8458 49 243 136530 705 415 582 1237	15% 15% 15% 15% 15% 15% 15% 15% 15%
6999 F6.164.2 7000 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.167.1 7004 F6.168.0 7005 F6.1684. 7006 F6.169.0 7007 F6.169.0 7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.2	4.20.0.00 7.02.0.00 7.03.0.00 7.06.0.00 7.14.0.00 8.02.0.00 84.90.0.00 9.02.0.00 9.03.0.00 9.04.0.00 9.04.0.00 9.04.0.00 9.04.0.00	WATER PUMP SUB ASSLY CHARGED AIR MANIFOLD (FINISH.) O RING. (68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	7720 21061 49 8458 49 243 136530 705 415 582 1237	15% 15% 15% 15% 15% 15% 15% 15% 15%
7000 F6.167.0 7001 F6.167.0 7002 F6.167.0 7003 F6.167.0 7003 F6.1684.1 7006 F6.1680.0 7007 F6.169.0 7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1	7.02.0.00 7.03.0.00 7.06.0.00 7.14.0.00 8.02.0.00 84.90.0.00 9.02.0.00 9.03.0.00 9.04.0.00 9.04.0.00 9.04.0.00 9.04.0.00	CHARGED AIR MANIFOLD (FINISH.) O RING.(68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	49 8458 49 243 136530 705 415 582 1237 58	15% 15% 15% 15% 15% 15% 15% 15%
7001 F6.167.0 7002 F6.167.0 7003 F6.167.0 7003 F6.1684.0 7006 F6.169.0 7007 F6.169.0 7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1	7.03.0.00 7.06.0.00 7.14.0.00 8.02.0.00 84.90.0.00 9.02.0.00 9.03.0.00 9.04.0.00 9.04.0.00 9.04.0.00 9.04.0.00	O RING.(68X3 TGL 6365)CO.STD.21509 BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	49 8458 49 243 136530 705 415 582 1237 58	15% 15% 15% 15% 15% 15% 15% 15%
7002 F6.167.0 7003 F6.167.1 7004 F6.168.0 7005 F6.1684.0 7006 F6.169.0 7007 F6.169.0 7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.1 7020 F6.177.1 7021 F6.177.1	7.06.0.00 7.14.0.00 8.02.0.00 84.90.0.00 9.02.0.00 9.03.0.00 9.04.0.00 9.04.0.00 9.09.0.00	BEND ENGINE SIDE O RING: 90X3 TGL 6365- 21509 R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	8458 49 243 136530 705 415 582 1237 58	15% 15% 15% 15% 15% 15% 15%
7003 F6.167.1. 7004 F6.168.0. 7005 F6.1684. 7006 F6.169.0. 7007 F6.169.0. 7009 F6.169.0. 7010 F6.169.1. 7011 F6.169.2. 7012 F6.169.3. 7014 F6.169.3. 7015 F6.169.3. 7016 F6.177.0. 7017 F6.177.0. 7018 F6.177.0. 7019 F6.177.1. 7020 F6.177.1.	8.02.0.00 34.90.0.00 9.02.0.00 9.03.0.00 9.04.0.00 9.09.0.00 9.09.0.00	R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	49 243 136530 705 415 582 1237 58	15% 15% 15% 15% 15% 15%
7004 F6.168.0 7005 F6.1684.1 7006 F6.169.0 7007 F6.169.0 7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1	8.02.0.00 34.90.0.00 9.02.0.00 9.03.0.00 9.04.0.00 9.09.0.00 9.09.0.00	R RINGS: 65X2.5 Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	243 136530 705 415 582 1237 58	15% 15% 15% 15% 15% 15%
7005 F6.1684. 7006 F6.169.0 7007 F6.169.0 7008 F6.169.0 7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1	34.90.0.00 0.02.0.00 0.03.0.00 0.04.0.00 0.09.0.00 0.15.0.00	Cold Starting kit for SL90 200 kva and 250 kva L1 to L3 OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part	136530 705 415 582 1237 58	15% 15% 15% 15%
7006 F6.169.0 7007 F6.169.0 7008 F6.169.0 7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.2 7013 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.1 7020 F6.177.1 7021 F6.177.1	9.02.0.00 9.03.0.00 9.04.0.00 9.09.0.00	OIL RETURN ADAPTOR PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part Spare Part Spare Part Spare Part Spare Part Spare Part	705 415 582 1237 58	15% 15% 15% 15%
7007 F6.169.0 7008 F6.169.0 7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.2 7013 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.1 7020 F6.177.1 7021 F6.177.1	9.03.0.00 9.04.0.00 9.09.0.00 9.15.0.00	PIPE FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part Spare Part Spare Part Spare Part	415 582 1237 58	15% 15% 15%
7008 F6.169.0 7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.1 7020 F6.177.1 7021 F6.177.1	9.04.0.00 9.09.0.00 9.15.0.00	FLANGE ENGINE SIDE HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part Spare Part Spare Part	582 1237 58	15% 15%
7009 F6.169.0 7010 F6.169.1 7011 F6.169.2 7012 F6.169.2 7013 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.1 7020 F6.177.1 7021 F6.177.1	0.09.0.00 0.15.0.00	HOSE: TURBOCHARGER AIR OUTLET O RING: 22 ID DIA5 - 21509	Spare Part Spare Part	1237 58	15%
7010 F6.169.1 7011 F6.169.2 7012 F6.169.2 7013 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.1 7020 F6.177.1 7021 F6.177.1	9.15.0.00	O RING: 22 ID DIA5 - 21509	Spare Part	58	
7011 F6.169.2 7012 F6.169.2 7013 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.1 7020 F6.177.1 7021 F6.177.1 7022 F6.177.2					1070
7012 F6.169.2 7013 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.1 7020 F6.177.1 7021 F6.177.1 7022 F6.177.2				600	15%
7013 F6.169.3 7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.1 7020 F6.177.1 7021 F6.177.1 7022 F6.177.1		JOINT FOR OIL RETURN PIPE CRANKCASE SIDE	Spare Part	58	15%
7014 F6.169.3 7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1 7022 F6.177.2		JOINT FOR OIL RETURN PIPE TURBOCHARGER (NON ASBESTOS)	Spare Part	37	15%
7015 F6.169.3 7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1 7022 F6.177.2		JOINT FOR OIL SUPPLY TURBOCHARGER (NON ASBESTOS)	Spare Part	74	15%
7016 F6.177.0 7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1 7022 F6.177.2		GASKET FOR OIL RETURN PIPE TURBO CHARGER(NON ASBESTOS)	Spare Part	46	15%
7017 F6.177.0 7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1 7022 F6.177.2		EXHAUST M'FOLD: LH PIECE	Spare Part	3449	15%
7018 F6.177.0 7019 F6.177.1 7020 F6.177.1 7021 F6.177.1 7022 F6.177.2		EXHAUST MANIFOLD (RH)	Spare Part	3449	15%
7019 F6.177.1 7020 F6.177.1 7021 F6.177.1 7022 F6.177.2		EXHAUST M'FOLD: CENTRAL OPEN	Spare Part	6068	15%
7020 F6.177.12 7021 F6.177.12 7022 F6.177.2		T/C L.O.DRAIN CONNECTOR: C'CASE	Spare Part	1028	15%
7021 F6.177.1 7022 F6.177.2		LUBE OIL DRAIN CONNECTOR	Spare Part	1040	15%
7022 F6.177.2		SPACER SLEEVE (COPPER COATED)	Spare Part	83	15%
		EXHAUST MANIFOLD LEFT SIDE	Spare Part	4975	15%
		EXHAUST MANIFOLD R H SIDE	Spare Part	4988	15%
7024 F6.177.2		EXHAUST MANIFOLD CENTRAL OPENING	Spare Part	8157	15%
7025 F6.177.2		CLAMP FOR TURBO OIL INLET PIPE	Spare Part	105	15%
7026 F6.177.3		RUBBER SLEEVE	Spare Part	102	15%
7027 F6.177.4		OIL SUPPLY PIPE SUB ASSEMBLY (WITH FLEX. MEMBER)	Spare Part	3818	15%
7028 F6.177.5		OIL SUPPLY PIPE SUB ASSLY (WITH FLEX MEMBER)	Spare Part	3403	15%
7029 F6.178.1		LUBE OIL PUMP: HIGH DISCHARG	Spare Part	28852	15%
7030 F6.178.5		LUBE OIL PUMP	Spare Part	30067	15%
	2.100.0.00	CRANKCASE ASSLY	Spare Part	335076	15%
		CRANKCASE ASSLY. (WITH 7 BOLT) (F6.182.110.0.PR)	Spare Part	310762	15%
		CRANKCASE ASSEMBLY WITH MAIN BEARING CAP SEALING CAP	Spare Part	373407	15%
		CRANKCASE ASSEMBLY CRANKCASE ASSEMBLY	Spare Part	340008	15%
		V BELT: 4PK-1570 POLY	Spare Part	2760	15%
	2.90.0.SP	V BELT: 8PK 983 POLY	Spare Part	2760	15%
	2.90.0.SP 4.01.0.00	* DEET, OF IN OOUT OET	Spare Part	2978	15%
	2.90.0.SP 4.01.0.00 4.02.0.00		· · · · · · · · · · · · · · · · · · ·	2976	15%
	2.90.0.SP 4.01.0.00 4.02.0.00 4.03.0.00	POLY V BELT 8PK:1065	Spare Port	∠135	1370
7039 F6.184.0 7040 F6.184.0	2.90.0.SP 4.01.0.00 4.02.0.00 4.03.0.00 4.04.0.00		Spare Part Spare Part	2037	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer	Custom
		· ·		without Vat in NPR	Charge%
7041	F6.187.104.0.PR	36 WING FAN FOR SL90 CPCB4 APPLICATION	Spare Part	41796	15%
7042	F6.187.112.0.PR	GASKET FOR DOSING MODULE	Spare Part	557	15%
7043	F6.187.12.0.PR	JOINT 12 EGT INLET	Spare Part	698	15%
7044	F6.187.13.0.PR	JOINT 12 EGT OUTLET	Spare Part	751	15%
7045	F6.187.15.0.00	FAN: 34" PLASTIC	Spare Part	22980	20%
7046	F6.187.19.0.PR	45L AD BLUE TANK ASSEMBLY CPCB4	Spare Part	111642	15%
7047	F6.187.22.0.00	RADIATOR FAN (36")	Spare Part	62150	15%
7048	F6.187.27.0.PR	12 EGT clamp	Spare Part	1400	15%
7049	F6.187.70.0.00	RADIATOR	Spare Part	295424	15%
7050	F6.187.71.0.PR	FAN SPACER	Spare Part	8858	15%
7051	F6.187.72.0.PR	HOSE BETWEEN PUMP INLET AND RADIATOR PIPE OUTLET	Spare Part	714	15%
7052	F6.187.74.0.PR	RADIATOR OUTLET HOSE	Spare Part	588	15%
7053	F6.187.75.0.PR	Aluminium Radiator Assembly	Spare Part	379773	15%
7054	F6.187.96.0.PR	RADIATOR OUTLET HOSE	Spare Part	843	15%
7055	F6.192.04.0.00	SHAFT FOR FAN PULLEY	Spare Part	2486	15%
7056	F6.192.05.0.00	BRACKET FOR FAN PULLEY MOUNTING 250 KVA	Spare Part	2834	15%
7057	F6.192.07.0.00	BALL BEARING	Spare Part	3923	15%
7058	F6.192.11.0.00	V BELT: COGGED BX40-1060	Spare Part	1548	15%
7059	F6.192.20.0.00	BRACKET SUBASSEMBLY S F FAN MOUNTING	Spare Part	5157	15%
7060	F6.192.21.0.00	FAN PULLEY PCD 160	Spare Part	6901	15%
7061	F6.192.30.0.00	FAN PULLEY ASSEMBLY	Spare Part	20569	15%
7062	F6.192.51.0.00	FAN PULLEY ASSEMBLY	Spare Part	24954	15%
7063	F6.193.20.0.00	BELT TENSIONING UNIT ASSLY	Spare Part	9483	15%
7064	F6.193.30.0.00	BELT TENSION UNIT ASSEMBLY	Spare Part	8474	15%
7065	F6.201.02.0.00	JOINT: EXH SILENCER	Spare Part	1268	15%
7066	F6.241.02.0.PR	JOINT FOR THERMOSTAT COVER	Spare Part	154	15%
7067	F6.241.03.0.PR	JOINT BET WATER PUMP CRANKCASE	Spare Part	129	15%
7068	F6.243.04.0.PR	FAN PULLEY FINISH	Spare Part	2822	15%
7069	F6.243.10.0.PR	FAN DRIVE ASSEMBLY 4V COMMON RAIL	Spare Part	18040	15%
7070	F6.244.04.0.PR	JOINT BETWEEN ADAPTOR FRONT PLATE 4V COMMON RAIL	Spare Part	182	15%
7071	F6.247.20.0.PR	CYL HEAD SUB ASSLY WITH VALVE GUIDE VALVE SEAT INSERT	Spare Part	34113	15%
7072	F6.248.08.0.PR	CRDI INJECTOR FOR SL90 750HTF 142 SCA	Spare Part	43701	15%
7073	F6.248.13.0.PR	Injector for 6SL90TA 250 kVA CPCB4 7 x 142 x 625 K 1 3 HE 10 5	Spare Part	47649	15%
7074	F6.249.03.0.PR	JOINT FOR ROCKER COVER	Spare Part	1409	15%
7075	F6.252.03.0.PR	FUEL PIPE FOR FIP TO FILTER	Spare Part	572	15%
7076	F6.252.04.0.PR	FUEL PIPE FOR FILTER TO FIP	Spare Part	585	15%
7077	F6.252.11.0.PR	LEAK OFF PIPE FOR INJECTOR PART 1	Spare Part	1674	15%
	F6.252.12.0.PR	LEAK OFF PIPE FOR INJECTOR PART 2	Spare Part	603	15%
7079	F6.252.13.0.PR	LEAK OFF PIPE FOR RAIL PUMP	Spare Part	3597	15%
7080	F6.252.14.0.PR	LEAK OFF PIPE FOR FIP	Spare Part	686	15%
7081	F6.255.01.0.00	RADIATOR FAN: 28" METALIC	Spare Part	8600	15%
7082	F6.255.03.0.00	HOSE CONNECTION	Spare Part	1643	15%
7083	F6.255.05.0.00	PIPE: THERMOSTAT TO WATER TANK	Spare Part	2394	15%
7084	F6.255.06.0.00	HOSE FOR THERMOSTAT TO WATER TANK	Spare Part	382	15%
7085	F6.255.09.0.00	HOSE: WATER CONNECTION	Spare Part	578	15%
7086	F6.255.12.0.00	AIR INLET MANIFOLD BEND	Spare Part	7243	15%
7087	F6.255.13.0.00	JOINT: BEND	Spare Part	77	15%
7088	F6.255.18.0.00	HOSE: VENT CONNECTION	Spare Part	1123	15%
7089	F6.255.32.0.00	HOSE FOR THERMOSTAT TO WATER TANK	Spare Part	431	15%
7090	F6.255.46.0.00	HOSE: 160KVA	Spare Part	1658	15%
7090	F6.256.03.0.00	THERMOSTAT COVER	Spare Part	1637	15%
7091	F6.259.10.0.00	FIP: 9 MM LIFT	Spare Part	83839	15%
7092	F6.273.20.0.00	FAN DRIVE PULLEY ASSembly	Spare Part	13751	15%
7093	F6.290.20.0.00	RUBBER BLOCK SET FOR HTB1200 COUPLING	Spare Part	15147	15%
1034	0.200.20.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	74959	15%



				Price to	
Cr No	Dart Number	Part Description	Catagory	Customer	Custom
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%
7096	F6.296.10.0.00	FIP: 160KVA CPCB	Spare Part	NPR 91793	15%
7090	F6.297.01.0.00	RADIATOR	Spare Part	285956	15%
7097	F6.304.01.0.00	ASSLY LEAK OFF PIPE	Spare Part	4535	15%
7099	F6.315.01.0.00	GAS OUTLET BEND	Spare Part	4972	15%
7100	F6.315.03.0.00	EXPANSION BELLOW	Spare Part	4000	15%
7101	F6.316.01.0.00	AIR DELIVERY BEND	Spare Part	2865	15%
7102	F6.320.09.0.00	BREATHER PIPE SUPPORT CLAMP	Spare Part	142	15%
7102	F6.322.01.0.00	LEAK OFF PIPE: 250KVA	Spare Part	4477	15%
7104	F6.350.01.0.00	TURBOCHARGER	Spare Part	93420	15%
7105	F6.351.40.0.PR	CRANKSHAFT ASSEBLY WITH GEAR	Spare Part	216957	15%
7106	F6.351.60.0.PR	CRANKSHAFT ASSEBLY WITH GEAR	Spare Part	256258	15%
7107	F6.353.05.0.00	FLEXIBLE CONNECTION: C'CASE-PUMP	Spare Part	554	15%
7108	F6.353.09.0.00	CLAMPING NUT FOR MOTORPAL PUMP	Spare Part	289	15%
7109	F6.353.11.0.00	FUEL PIPE: FILTER TO FIP	Spare Part	711	15%
7110	F6.353.112.0.00	FUEL PIPE PRIMARY TO SECONDARY	Spare Part	5335	15%
7111	F6.353.14.0.00	FUEL PIPE: FIP TO FILTER	Spare Part	514	15%
7111	F6.357.01.0.00	EXHAUST MANIFOLD FRONT	Spare Part	13172	15%
7113	F6.357.02.0.00	EXHAUST MANIFOLD	Spare Part	13720	15%
7114	F6.357.03.0.00	COMPRESSION RING	Spare Part	997	15%
7115	F6.358.01.0.00	LUBE OIL COOLER-PLATE TYPE	Spare Part	28640	15%
7116	F6.358.15.0.00	LUB OIL COOLER CARTRIDGE 16 PLATE	Spare Part	40516	15%
7117	F6.359.02.0.00	VALVE SEAT INSERT INLET	Spare Part	1982	15%
7118	F6.359.04.0.00	VALVE SEAT INSERT EXHAUST	Spare Part	1000	15%
7119	F6.359.08.9.PR	EXHAUST VALVE SEAT INSERT SEMIFINISH GAS ENGINE	Spare Part	3966	15%
7119	F6.359.10.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	37516	15%
7121	F6.359.50.0.00	VALVE PAIR INLET & EXHAUST	Spare Part	5280	15%
7122	F6.361.02.0.00	INJECTOR	Spare Part	20667	15%
7123	F6.362.01.0.00	COOLER MOUNTING BODY	Spare Part	3855	15%
7123	F6.363.08.0.PR	ORING ID 29 OD 3	Spare Part	468	15%
7124	F6.363.10.0.PR	LUB OIL PIPE ASSEMBLY	Spare Part	4969	15%
7126	F6.364.02.0.00	SS JOINT: TURBOCHARGER OUTLET	Spare Part	142	15%
7127	F6.366.02.0.00	STUD: M10X1.5X65 COPPER COATED	Spare Part	62	15%
7128	F6.366.10.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	35892	15%
7129	F6.368.14.0.00	NOZZLE FOR SL90TA	Spare Part	12074	15%
7130	F6.375.11.0.00	V BELT: 106 SPB 1340	Spare Part	2015	15%
7131	F6.375.15.0.00	HOSE CONNECTION	Spare Part	3412	15%
7132	F6.375.25.0.00	FAN: PLASTIC 30"	Spare Part	23557	20%
7133	F6.375.30.0.00	BELT TENSIONING ASSLY: 250KVA	Spare Part	7363	15%
7134	F6.376.10.0.00	SUB ASSLY. COOLER	Spare Part	29670	15%
7135	F6.377.035.0.00	TURBOCHARGER	Spare Part	138044	15%
7136	F6.377.04.0.00	V BEND CLAMP	Spare Part	1397	15%
7137	F6.377.06.0.00	O RING: TURBO OUTLET	Spare Part	366	15%
7138	F6.377.08.0.00	HOSE	Spare Part	7843	15%
7139	F6.377.09.0.00	JOINT: TURBO INLET	Spare Part	114	15%
7140	F6.377.100.0.00	SUPPORT BRACKET ASSEMBLY (FOR AIR PIPE) (FOR CPCB II)	Spare Part	6803	15%
7141	F6.377.11.0.00	STUD: M8 COPPER COATED	Spare Part	28	15%
7142	F6.377.12.0.00	STUD M10X1.5X025 (COPPER COATED)	Spare Part	58	15%
7142	F6.377.13.0.00	AIR DELIVERY MAIN PIPE FROM TC TO CAC	Spare Part	9341	15%
7143	F6.377.13.0.00	AIR DELIVERY MAIN PIPE FROM TO TO CAC	Spare Part	3055	15%
7144	F6.377.15.0.00	JOINT: AIR DELIVERY MAINPIPE & BEND	Spare Part	86	15%
7145	F6.377.16.0.00	T BOLT CLAMP S/F 83MM OD	Spare Part	191	15%
7146	F6.377.18.0.00	CLAMPING BRACKET	Spare Part	7781	15%
7147	F6.377.33.0.00	HOSE FOR INLET MANIFOLD BEND & CAC OUT	Spare Part	2151	15%
1 140	F6.377.39.0.00	CAC HOSE COLD SIDE	Spare Part	1446	15%
7149					



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		·		without Vat in NPR	Charge%
7151	F6.378.04.0.00	ADAPTOR PLATE	Spare Part	5015	15%
7152	F6.378.11.0.00	DAMPER PULLEY	Spare Part	5809	15%
7153	F6.378.21.0.00	DAMPER PULLEY	Spare Part	7354	15%
7154	F6.378.41.0.00	CRANK PULLEY PCD 210	Spare Part	8058	15%
7155	F6.379.01.0.00	CHARGE AIR MANIFOLD	Spare Part	14406	15%
7156	F6.379.03.0.00	INLET MANIFOLD BEND	Spare Part	8455	15%
7157	F6.379.07.0.00	WORM DRIVE HOSE CLIP (115 MM)	Spare Part	243	15%
7158	F6.379.11.0.00	JOINT: INLET MANIFOLD BEND	Spare Part	117	15%
7159	F6.379.14.0.00	INLET MANIFOLD BEND	Spare Part	14932	15%
7160	F6.379.17.0.PR	JOINT HEATER TO CAC PIPE	Spare Part	138	15%
7161	F6.381.01.0.00	GAS OUTLET BEND	Spare Part	5714	15%
7162	F6.381.02.0.00	BRACKET FOR EXHAUST OUTLET	Spare Part	4772	15%
7163	F6.381.03.0.00	EXPANSION BELLOW	Spare Part	5031	15%
7164	F6.381.04.0.00	JOINT: BELLOW & GAS OUTLET	Spare Part	655	15%
7165	F6.381.05.0.00	SET SCREW M8X1.25X025 (COPPER COATED)	Spare Part	28	15%
7166	F6.381.15.0.PR	GASKET BETWEEN TURBOCHARGER DIFFUSER	Spare Part	1132	15%
7167	F6.382.10.0.00	CYL LINER ASSEMBLY	Spare Part	7714	15%
7168	F6.387.03.0.00	ADAPTOR ON COOLER MTG BODY FOR JACKET WATER HEATER CONN	Spare Part	314	15%
7169	F6.4004.03.9.00	VALVE SEAT INSERT: INLET	Spare Part	397	15%
7170	F6.4004.04.9.00	VALVE SEAT INSERT: EXHAUST	Spare Part	391	15%
7171	F6.4004.08.0.00	VALVE BRIDGE	Spare Part	769	15%
7172	F6.4004.100.0.00	VALVE PAIR	Spare Part	2705	15%
7173	F6.4004.12.0.00	CYLINDER HEAD BOLT	Spare Part	462	15%
7174	F6.4004.160.0.PR	CYLINDER HEAD ASSEMBLY COMPLETE SL90 4 VALVES	Spare Part	49612	15%
7175	F6.4004.30.0.00	CYLINDER HEAD ASSEMBLY: SL90 4 VALVE	Spare Part	50421	15%
7176	F6.4004.40.0.00	VALVE GUIDE & SNAP RING ASSEMBLY	Spare Part	206	15%
7177	F6.4004.50.0.00	PUSH ROD ASSLY	Spare Part	1028	15%
7178	F6.4005.70.0.00	ROCKER SUPPORT ASSEMBLY	Spare Part	10455	15%
7179	F6.4006.07.0.00	ROCKER COVER	Spare Part	3126	15%
7179	F6.4006.07.0.00			4006	15%
7181	F6.4006.13.0.00	ROCKER COVER (MACHINING) (WITH OIL FILLING ARRANGEMENT) (4 VALVE) JOINT: ROCKER COVER	Spare Part Spare Part	834	15%
7182	F6.4007.03.0.00	O RING	·	52	15%
7183	1	INLET MANIFOLD	Spare Part	24486	15%
7184	F6.4008.01.0.00 F6.4008.02.0.00	JOINT: INLET MANIFOLD	Spare Part	71	15%
			Spare Part		
7185	F6.4008.03.0.00	BLANKING PLATE FOR INLET MANIFOLD	Spare Part	1431	15% 15%
7186	F6.4009.06.0.00 F6.4009.12.0.00	SPACER FOR EXHAUST MANIFOLD	Spare Part	191 366	15%
7187		GASKET FOR EXHAUST MANIFOLD BET CYL HEAD EXH MANIFOLD	Spare Part		
7188	F6.4012.05.0.00	BANJO BOLT FOR LEAK OFF PIPE	Spare Part	132	15%
7189	F6.4012.11.0.00	FUEL PIPE PRE-FILTER TO FEED PUMP	Spare Part	877	15%
7190	F6.4012.12.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	615	15%
7191	F6.4012.14.0.00	LUBE OIL SUPPLY PIPE TO FUEL PUMP	Spare Part	797	15%
7192	F6.4012.22.0.00	LEAK OFF PIPE	Spare Part	2283	15%
7193	F6.4012.26.0.00	BRACKET FOR FUEL PIPE	Spare Part	86	15%
7194	F6.4012.35.0.00	LEAK OFF PIPE	Spare Part	1920	15%
7195	F6.4012.36.0.00	FUEL PIPE (FUEL FILTER TO FUEL PUMP)	Spare Part	800	15%
7196	F6.4012.91.0.PR	FUEL PIPE FROM FUEL TANK TO FUEL PUMP	Spare Part	3809	15%
7197	F6.4013.100.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	16055	20%
7198	F6.4014.120.0.PR	CAM SHAFT SUB ASSEMBLY SL90 4 VALVES	Spare Part	64205	15%
7199	F6.4014.40.0.00	CAM SHAFT SUB ASSEMBLY SL90 4 VALVES	Spare Part	68488	15%
7200	F6.4015.30.0.00	PISTON ASSEMBLY	Spare Part	15104	15%
7201	F6.4018.02.0.PR	JOINT BET GEAR CASING FRONT PLATE	Spare Part	1234	15%
7202	F6.403.01.0.00	GEAR CASING (CAST IRON)	Spare Part	54384	15%
7203	F6.404.01.0.00	HOSE: AIR CLEANER	Spare Part	3375	15%
7204	F6.404.101.0.PR	AIR FILTER PRIMARY OUTER ELEMENT	Spare Part	16318	20%
7205	F6.404.102.0.PR	AIR FILTER SAFETY	Spare Part	3801	20%



Part Number Part Number Part Description Category Without Year New Year					Price to	
Company Comp	Sr.No.	Part Number	Part Description	Category		Custom
1700 P. P. P. M. A. S. S. D. P. P. M. C. S.			·			Charge%
2006 FR. 404.25.00 AIR CLEAMER ASSLY Squee Part 43930	7206	F6.404.15.0.00	AIR CLEANER KIT FOR SL90	Spare Part		15%
1200 F. 60.43 27.000 AR FILTER PRIMARY Filer 10415 1210 F. 60.43 10.00 AR FILTER SPETTY F. 60.43 10.00 P. 60.55 10.00 AR FILTER SPETTY F. 60.43 10.00 P. 60.55 10.00	7207	F6.404.17.0.00	BRACKET FOR AIR CLEANER	Spare Part	3612	15%
Face	7208	F6.404.25.0.00	AIR CLEANER ASSLY	Spare Part	43938	20%
1241 F.6.40-51.0.00	7209	F6.404.27.0.00	AIR FILTER PRIMARY	Filter	10415	20%
2229 F.4.04.96.00 MOSE REDUCER Spee Part 2290	7210	F6.404.28.0.00	AIR FILTER SAFETY	Filter	3608	20%
1212 F6406 57.DPR	7211	F6.404.31.0.00	RESTRICTION INDICATOR	Spare Part	1644	20%
17215 F6 304 57 DPR	7212	F6.404.36.0.00	HOSE REDUCER	Spare Part	2287	20%
12715 FRADE 90 PR HOSE REDUCE BLOW Span Part 4.296	7213	F6.404.56.0.PR	FUEL RETURN PIPE	Spare Part	2000	15%
12710 FF.4406-74.DPR	7214	F6.404.57.0.PR	FUEL RETURN PIPE	Spare Part	1138	15%
17217 F6-408-33.D.PR ADBILUE PIPE FOR ADBILUE TANK OUT TO SUPPLY MODULE IN 2 Spare Part 3382 17218 F6-408-33.D.PR ADBILUE PIPE FOR ADBILUE TANK OUT TO SUPPLY MODULE BACK FLOW TO ADBILUE TANK N 1 Spare Part 3394 17220 F6-408-36.D.PR ADBILUE PIPE FOR BUPPLY MODULE BACK FLOW TO ADBILUE TANK N 2 Spare Part 2111 1721 F6-408-36.D.PR ADBILUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBILUE TANK N 2 Spare Part 2111 1721 F6-408-36.D.PR COLLANT PIPE FOR DOSING MODULE OUT TO RADIATOR N 1 Spare Part 2492 1722 F6-408-36.D.PR COLLANT PIPE FOR DOSING MODULE OUT TO RADIATOR N 3 Spare Part 6181 1722 F6-408-36.D.PR COLLANT PIPE FOR DOSING MODULE OUT TO RADIATOR N 3 Spare Part 3682 1723 F6-408-43.D.PR ADBILUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE N 1 Spare Part 2492 1725 F6-408-46.D.PR ADBILUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE N 2 Spare Part 4594 1726 F6-408-46.D.PR ADBILUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE N 2 Spare Part 4594 1726 F6-408-46.D.PR ADBILUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE N 3 Spare Part 4594 1727 F6-408-46.D.PR ADBILUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE N 3 Spare Part 4594 1728 F6-408-46.D.PR ADBILUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE N 3 Spare Part 3501 1728 F6-408-46.D.PR COLLANT PIPE FOR HEADER OUT TO DOSING MODEL N 1 Spare Part 3501 1728 F6-408-46.D.PR COLLANT PIPE FOR HEADER OUT TO DOSING MODEL N 1 Spare Part 3501 1729 F6-408-46.D.PR COLLANT PIPE FOR HEADER OUT TO DOSING MODEL N 1 Spare Part 3502 1729 F6-408-46.D.PR COLLANT PIPE FOR HEADER OUT TO TO DOSING MODEL N 2 Spare Part 3502 1720 F6-408-66.D.PR COLLANT PIPE FOR HEADER OUT TO TO DOSING MODEL N 2 Spare Part 3502 1720 F6-408-66.D.PR COLLANT PIPE FOR HEADER OUT TO	7215	F6.404.59.0.PR	HOSE REDUCER ELBOW	Spare Part	4295	15%
17218 F6-400-33.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 Spare Part 3332 17219 F6-400-35.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1 Spare Part 3394 17210 F6-400-35.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2 Spare Part 2932 17210 F6-400-35.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2 Spare Part 2932 17210 F6-400-35.0.PR COOLANT PIPE FOR DOSING MODILLE OUT TO RADIATOR IN 2 Spare Part 2932 1722 F6-400-35.0.PR COOLANT PIPE FOR DOSING MODILLE OUT TO RADIATOR IN 3 Spare Part 3565 1722 F6-400-40.0.PR ADBLUE PIPE FOR SUPPLY MODILLE OUT TO DOSING MODILLE IN 1 Spare Part 5976 1722 F6-400-40.0.PR ADBLUE PIPE FOR SUPPLY MODILLE OUT TO DOSING MODILLE IN 1 Spare Part 5976 1722 F6-400-40.0.PR ADBLUE PIPE FOR SUPPLY MODILLE OUT TO DOSING MODILLE IN 2 Spare Part 5976 1722 F6-400-40.0.PR ADBLUE PIPE FOR SUPPLY MODILLE OUT TO DOSING MODILLE IN 3 Spare Part 4654 1722 F6-400-40.0.PR ADBLUE PIPE FOR SUPPLY MODILLE OUT TO DOSING MODILLE IN 3 Spare Part 4654 1722 F6-400-40.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODILE IN 3 Spare Part 4654 1722 F6-400-40.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODILE IN 3 Spare Part 4656 1723 F6-400-60.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODILE IN 3 Spare Part 4006 1723 F6-400-60.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODILE IN 3 Spare Part 4006 1723 F6-400-60.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODILE IN 4 Spare Part 4006 1724 F6-400-60.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODILE IN 4 Spare Part 4006 1725 F6-400-60.0.PR COOLANT PIPE FOR HEADER OUT TO	7216	F6.404.74.0.PR	HOSE FOR AIR CLEANER	Spare Part	3292	15%
17219 F640638.0.PR ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2 Spare Part 2012 17212 F640638.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 2032 17212 F640638.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 2032 17213 F640638.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 6181 17226 F640638.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 6181 17227 F640638.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO RADIATOR IN 3 Spare Part 3688 17228 F64064.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1 Spare Part 5979 17226 F64064.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 2 Spare Part 4554 17227 F6406.4.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 3 Spare Part 4554 17228 F6406.4.0.PR ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 3 Spare Part 4554 17229 F6406.4.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 1 Spare Part 33001 17229 F6406.4.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 1 Spare Part 3320 17229 F6406.4.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 1 Spare Part 4062 17229 F6406.4.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 1 Spare Part 4062 17230 F6406.6.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 1 Spare Part 4062 17231 F6406.6.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 1 Spare Part 4062 17232 F6406.6.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 1 Spare Part 4062 17233 F6406.6.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 4062 17234 F6406.6.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 4062 17235 F6406.6.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 4062 17246 F6406.6.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 4062 17247	7217	F6.406.32.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 1	Spare Part	2788	15%
17220 F6.406.86.0.PR	7218	F6.406.33.0.PR	ADBLUE PIPE FOR ADBLUE TANK OUT TO SUPPLY MODULE IN 2	Spare Part	3332	15%
Page	7219	F6.406.35.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 1	Spare Part	3394	15%
7222 F4.08.39.0.PR	7220	F6.406.36.0.PR	ADBLUE PIPE FOR SUPPLY MODULE BACK FLOW TO ADBLUE TANK IN 2	Spare Part	2111	15%
7223 F6.406.41.0 PR	7221	F6.406.38.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1	Spare Part	2932	15%
7224 F6.406.43.0 PR	7222	F6.406.39.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2	Spare Part	6181	15%
7224 Fe.406.43.0 PR	7223	F6.406.41.0.PR	COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3	Spare Part	3563	15%
7225 F6.406.44.0 PR	7224	F6.406.43.0.PR	ADBLUE PIPE FOR SUPPLY MODULE OUT TO DOSING MODULE IN 1			15%
T226	7225	F6.406.44.0.PR		Spare Part	5978	15%
7227 F6.408.47.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 1 Spare Part 3501 7228 F6.406.49.DR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 2 Spare Part 3326 7220 F6.406.49.DR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 3 Spare Part 4006 7230 F6.406.51.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 4 Spare Part 4406 7231 F6.406.62.0.PR FUEL INLET PIPE FROM FILTER TO PUMP Spare Part 4406 7232 F6.406.62.0.PR FUEL INLET PIPE FROM FILTER TO PUMP Spare Part 1114 7233 F6.406.67.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 5271 7234 F6.406.68.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 456 7235 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 446 7236 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 446 7235 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 446						15%
T228	7227				3501	15%
7229 F6.406.49.0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 3 Spare Part 6920			COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 2	•		15%
7230 F6.406.51 0.PR COOLANT PIPE FOR HEADER OUT TO DOSING MODEL IN 4 Spare Part 4406 Spare Part 2578 F6.406.62.0.PR FUEL INLET PIPE FROM FILTER TO PUMP Spare Part 2578 Spare Part 1114 F6.406.62.0.PR HOLS BETWEEN PUMP INLET AND RADIATOR PIPE OUTLET Spare Part 5271 F6.406.67.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 5271 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 7588 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 4886 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 4466 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 4466 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 4466 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 4466 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 4466 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 4466 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 4466 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 4466 F6.406.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.		F6.406.49.0.PR				15%
7231 F6.406.62.0 PR						15%
T232						15%
7233 F6.406.67.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 1 Spare Part 5271 7234 F6.406.68.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 7588 7235 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 4886 7236 F6.418.04.0.00 ADAPTOR FOR FUEL SUPPLY AND RETURN BLOCK Spare Part 446 7237 F6.418.05.0.00 FUEL LEAK OFF PIPE ASSLY FIRE FIGHTING Spare Part 2548 7238 F6.420.250.00 BARRING ASSLY Spare Part 2648 7239 F6.424.01.0.00 WATER PUMP PULLEY Spare Part 2068 7240 F6.424.210.00 WATER PUMP PULLEY Spare Part 2683 7241 F6.443.04.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 500/5A FOR FRAME-284 Spare Part 29258 7242 F6.443.01.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 500/5A FRAME-354 Spare Part 29258 7243 F6.443.11.0.PR KOEL GREEN AG318262 ALTERNATOR 200KVA 3PH 415V 50HZ 0 8P F FRAME KG45 M1 SAE1 14 Spare Part 98258 7244						15%
7234 F6.406.68.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 2 Spare Part 7588 7235 F6.406.69.0.PR COOLANT PIPE FOR DOSING MODULE OUT TO RADIATOR IN 3 Spare Part 4866 7236 F6.418.05.0.00 ADAPTOR FOR FUEL SUPPLY AND RETURN BLOCK Spare Part 446 7237 F6.418.05.0.00 FUEL LEAK OFF PIPE ASSLY FIRE FIGHTING Spare Part 2548 7238 F6.420.25.0.00 BARRING ASSLY Spare Part 2068 7240 F6.424.010.00 WATER PUMP PULLEY Spare Part 2068 7240 F6.424.210.00 WATER PUMP PULLEY Spare Part 2068 7241 F6.443.04.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 1000/5A FRAME-284 Spare Part 2668 7242 F6.443.05.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 1000/5A FRAME-354 Spare Part 36547 7243 F6.443.05.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 1000/5A FRAME-354 Spare Part 812796 7244 F6.485.01.0.00 LINGHEROTE TRANSFORMER (SET OF 4 CT) 1000/5A FRAME-354 Spare Part 812796 7245 F6.485.05.0.0.				•		15%
T235						15%
7236 F6.418.04.0.00 ADAPTOR FOR FUEL SUPPLY AND RETURN BLOCK Spare Part 446 7237 F6.418.05.0.00 FUEL LEAK OFF PIPE ASSLY FIRE FIGHTING Spare Part 2548 7238 F6.420.25.0.00 BARRING ASSLY Spare Part 268 7239 F6.424.01.0.00 WATER PUMP PULLEY Spare Part 2683 7241 F6.424.21.0.00 WATER PUMP PULLEY Spare Part 2683 7241 F6.424.21.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 500/5A FOR FRAME-284 Spare Part 29258 7242 F6.443.05.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 1000/5A FRAME-354 Spare Part 36647 7243 F6.443.10.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 1000/5A FRAME-354 Spare Part 36647 7243 F6.443.05.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 1000/5A FRAME-354 Spare Part 36647 7244 F6.465.33.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 1000/5A FRAME-354 Spare Part 36647 7244 F6.465.50.0.00 INSTRUMENTAL TRANSFORMER (SET OF 4 CT) 1400/5A PART STAME S						15%
F6.418.05.0.00						15%
7238 F6.420.25.0.00 BARRING ASSLY Spare Part 13492 7239 F6.424.01.0.00 WATER PUMP PULLEY Spare Part 2068 7240 F6.424.21.0.00 WATER PUMP PULLEY Spare Part 2683 7241 F6.443.04.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 500/5A FOR FRAME-284 Spare Part 29258 7242 F6.443.05.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 1000/5A FRAME-354 Spare Part 36647 7243 F6.443.11.0.PR KOEL GREEN AG318262 ALTERNATOR 200KVA 3PH 415V 50HZ 0 8P F FRAME KG45 M1 SAE1 14 Spare Part 812798 7244 F6.465.30.0.00 ENGINE CONTROL DIGITAL DISPLAY 24VDC Spare Part 91186 7245 F6.467.02.0.00 INSTRUMENTATION CONTROL PANRIL ASSEMBLY Spare Part 237781 7246 F6.474.02.0.00 STARTER SOLENOID(DUMORE, 535-0098)24V FOR F.FIGHTING Spare Part 86190 7247 F6.482.01.0.00 WATER HEATER(KIM HOTSTART, TPS202GT12-006, 2.0kW, 240V) Spare Part 154364 7248 F6.483.01.0.00 ACTUATOR(XADC225D1S - 24) FOR FIRE FIGHTING APPLN. Spare Part 154364						15%
7239 F6.424.01.0.00 WATER PUMP PULLEY Spare Part 2088 7240 F6.424.21.0.00 WATER PUMP PULLEY Spare Part 2683 7241 F6.443.04.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 500/5A FOR FRAME-284 Spare Part 29258 7242 F6.443.05.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 1000/5A FRAME-354 Spare Part 36547 7243 F6.443.11.0.PR KOEL GREEN AG318262 ALTERNATOR 200KVA 3PH 415V 50HZ 0 8P F FRAME KG45 M1 SAE1 14 Spare Part 36547 7244 F6.465.33.0.00 ENGINE CONTROL DIGITAL DISPILAY 24VDC Spare Part 91186 7245 F6.465.50.0.00 INSTRUMENTATION CONTROL PANRL ASSEMBLY Spare Part 237781 7246 F6.474.02.0.00 STARTER SOLENOID(DUMORE, 535-0098)24V FOR F.FIGHTING Spare Part 486190 7247 F6.482.01.0.00 WATER HEATER(KIM HOTSTART, TPS202GT12-006, 2.0kW, 240V) Spare Part 48242 7248 F6.483.01.0.00 ACTUATOR(XADC225D15-24) FOR FIRE FIGHTING APPLN. Spare Part 154364 7249 F6.483.01.0.00 ACTUATOR(XADC225D15-24) FOR FIRE FIGHTING APPLN. Spare Part 132 </td <td></td> <td></td> <td></td> <td>•</td> <td></td> <td>15%</td>				•		15%
7240 F6.424.21.0.00 WATER PUMP PULLEY Spare Part 2683 7241 F6.443.04.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 500/5A FOR FRAME-284 Spare Part 29258 7242 F6.443.05.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 1000/5A FRAME-354 Spare Part 36547 7242 F6.443.05.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 1000/5A FRAME-354 Spare Part 36547 7243 F6.443.11.0.PR KOEL GREEN AG318262 ALTERNATOR 200KVA 3PH 415V 50HZ 0 8P F FRAME KG45 M1 SAE1 14 Spare Part 812798 7244 F6.465.30.0.00 ENGINE CONTROL DIGITAL DISPLAY 24VDC Spare Part 29186 7245 F6.465.50.0.00 INSTRUMENTATION CONTROL PANRI, ASSEMBLY Spare Part 2937781 7246 F6.474.02.0.00 STARTER SOLENDID(DUMORE, 535-0098)24V FOR F.FIGHTING Spare Part 86190 7247 F6.482.01.0.00 WATER HEATER(KIM HOTSTART, TPS202GT12-006, 2.0kW, 240V) Spare Part 48242 7248 F6.483.01.0.00 ACTUATOR(XADC225D115-24) FOR FIRE FIGHTING APPLN. Spare Part 154364 7249 F6.483.01.0.00 SPACER FOR LINK(M6 X1 LH - M6X1 RH) Spare Par						15%
7241 F6.443.04.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 500/5A FOR FRAME-284 Spare Part 29258 7242 F6.443.05.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 1000/5A FRAME -354 Spare Part 36547 7243 F6.443.11.0.PR KOEL GREEN AG318262 ALTERNATOR 200KVA 3PH 415V 50HZ 0 8P F FRAME KG45 M1 SAE1 14 Spare Part 812798 7244 F6.465.33.0.00 ENGINE CONTROL DIGITAL DISPLAY 24VDC Spare Part 91186 7245 F6.465.53.0.00 INSTRUMENTATION CONTROL PAINE ASSEMBLY Spare Part 237781 7246 F6.474.02.0.00 STARTER SOLENDIQUEMORE, 535-0098)24V FOR F.FIGHTING Spare Part 86190 7247 F6.482.01.0.00 WATER HEATER(KIM HOTSTART, TPS202GT12-006, 2.0kW, 240V) Spare Part 48242 7248 F6.483.01.0.00 ACTUATOR(XADC225D1S - 24) FOR FIRE FIGHTING APPLN. Spare Part 154364 7249 F6.483.01.0.00 SPACER FOR LINK(M6 X1 LH - M6X1 RH) Spare Part 132 7250 F6.483.06.0.00 LINK(M6X1 LH - M6X1 RH) Spare Part 142 7252 F6.483.01.0.PR WOODWARD MAKE TO PIN ENGINE CONTROL MODULE SECM70 Spare Par				•		15%
7242 F6.443.05.0.00 CURRENT TRANSFORMER (SET OF 4 CT) 1000/5A FRAME -354 Spare Part 36547 7243 F6.443.11.0.PR KOEL GREEN AG318262 ALTERNATOR 200KVA 3PH 415V 50HZ 0 8P F FRAME KG45 M1 SAE1 14 Spare Part 812798 7244 F6.465.33.0.00 ENGINE CONTROL DIGITAL DISPLAY 24VDC Spare Part 91186 7245 F6.465.50.00 INSTRUMENTATION CONTROL PANRL ASSEMBLY Spare Part 237781 7246 F6.474.02.0.00 STARTER SOLENOID(DUMORE, 535-0098)24V FOR F.FIGHTING Spare Part 86190 7247 F6.482.01.0.00 WATER HEATER(KIM HOTSTART, TPS202GT12-006, 2.0kW, 240V) Spare Part 48242 7248 F6.483.01.0.00 ACTUATOR(XADC225D1S - 24) FOR FIRE FIGHTING APPLN. Spare Part 15364 7249 F6.483.04.0.00 SPACER FOR LINK(M6 X1 LH - M6X1 RH) Spare Part 132 7250 F6.483.06.0.00 LINK(M6X1 LH - M6X1 RH) Spare Part 182 7251 F6.483.01.0.PR WOODWARD MAKE 70 PIN ENGINE CONTROL MODULE SECM70 Spare Part 114134 7252 F6.488.03.0.PR WOODWARD MAKE DELTA PRESSURE SENSOR SENSOR IN THE EFR Spare Part<						15%
7243 F6.443.11.0.PR KOEL GREEN AG318262 ALTERNATOR 200KVA 3PH 415V 50HZ 0 8P F FRAME KG45 M1 SAE1 14 Spare Part 812798 7244 F6.465.33.0.00 ENGINE CONTROL DIGITAL DISPLAY 24VDC Spare Part 91186 7245 F6.465.50.0.00 INSTRUMENTATION CONTROL PANRL ASSEMBLY Spare Part 237781 7246 F6.474.02.0.00 STARTER SOLENOID(DUMORE, 535-0098)24V FOR F.FIGHTING Spare Part 86190 7247 F6.482.01.0.00 WATER HEATER(KIM HOTSTART, TPS202GT12-006, 2.0kW, 240V) Spare Part 48242 7248 F6.483.01.0.00 ACTUATOR(XADC225D1S - 24) FOR FIRE FIGHTING APPLN. Spare Part 154364 7249 F6.483.04.0.00 SPACER FOR LINK(M6X1 LH - M6X1 RH) Spare Part 132 7250 F6.483.00.0.00 LINK(M6X1 LH - M6X1 RH) Spare Part 83 7251 F6.483.12.0.00 ADAPTOR (M6X1-M6X1) Spare Part 182 7252 F6.488.01.0.PR WOODWARD MAKE 70 PIN ENGINE CONTROL MODULE SECM70 Spare Part 14134 7253 F6.488.02.0.PR WOODWARD MAKE DELTA PRESSURE SENSOR SENSOR IN THE EFR Spare Part 55692 <td></td> <td></td> <td></td> <td></td> <td></td> <td>15%</td>						15%
7244 F6.465.33.0.00 ENGINE CONTROL DIGITAL DISPLAY 24VDC Spare Part 91186 7245 F6.465.50.0.00 INSTRUMENTATION CONTROL PANRL ASSEMBLY Spare Part 237781 7246 F6.474.02.0.00 STARTER SOLENOID(DUMORE, 535-0098)24V FOR F.FIGHTING Spare Part 86190 7247 F6.482.01.0.00 WATER HEATER(KIM HOTSTART, TPS202GT12-006, 2.0kW, 240V) Spare Part 48242 7248 F6.483.01.0.00 ACTUATOR(XADC225D1S - 24) FOR FIRE FIGHTING APPLN. Spare Part 154364 7249 F6.483.04.0.00 SPACER FOR LINK(MG X1 LH - M6X1 RH) Spare Part 132 7250 F6.483.12.0.00 ADAPTOR (M6X1-M6X1) Spare Part 83 7251 F6.483.01.0.PR WOODWARD MAKE 70 PIN ENGINE CONTROL MODULE SECM70 Spare Part 112 7252 F6.486.02.0.PR WOODWARD MAKE 70 PIN ENGINE CONTROL MODULE SECM70 Spare Part 15692 7254 F6.488.03.0.PR LAMBDA MAKE EUGO HEGO SENSOR Spare Part 17686 7255 F6.488.04.0.PR WOODWARD MAKE ELECTRONIC FLOW REGULATOR EFR Spare Part 276652 7256						15%
7245 F6.465.50.0.00 INSTRUMENTATION CONTROL PANRL ASSEMBLY Spare Part 237781 7246 F6.474.02.0.00 STARTER SOLENOID(DUMORE, 535-0098)24V FOR F.FIGHTING Spare Part 86190 7247 F6.482.01.0.00 WATER HEATER(KIM HOTSTART, TPS202GT12-006, 2.0kW, 240V) Spare Part 48242 7248 F6.483.01.0.00 ACTUATOR(XADC225D1S - 24) FOR FIRE FIGHTING APPLN. Spare Part 154364 7249 F6.483.04.0.00 SPACER FOR LINK(M6 X1 LH - M6X1 RH) Spare Part 132 7250 F6.483.06.0.00 LINK(M6X1 LH - M6X1 RH) Spare Part 83 7251 F6.483.12.0.00 ADAPTOR (M6X1-M6X1) Spare Part 182 7252 F6.488.01.0.PR WOODWARD MAKE 70 PIN ENGINE CONTROL MODULE SECM70 Spare Part 114134 7253 F6.488.02.0.PR WOODWARD MAKE DELTA PRESSURE SENSOR SENSOR IN THE EFR Spare Part 55692 7254 F6.488.03.0.PR LAMBDA MAKE EUGO HEGO SENSOR Spare Part 276652 7255 F6.488.04.0.PR WOODWARD MAKE F SERIES THROTTLE BODY Spare Part 269759 7256 F6.						15%
7246 F6.474.02.0.00 STARTER SOLENOID(DUMORE, 535-0098)24V FOR F.FIGHTING Spare Part 86190 7247 F6.482.01.0.00 WATER HEATER(KIM HOTSTART, TPS202GT12-006, 2.0kW, 240V) Spare Part 48242 7248 F6.483.01.0.00 ACTUATOR(XADC225D1S - 24) FOR FIRE FIGHTING APPLN. Spare Part 154364 7249 F6.483.04.0.00 SPACER FOR LINK(M6 X1 LH - M6X1 RH) Spare Part 132 7250 F6.483.06.0.00 LINK(M6X1 LH - M6X1 RH) Spare Part 83 7251 F6.483.12.0.00 ADAPTOR (M6X1-M6X1) Spare Part 182 7252 F6.488.01.0.PR WOODWARD MAKE 70 PIN ENGINE CONTROL MODULE SECM70 Spare Part 114134 7253 F6.488.02.0.PR WOODWARD MAKE DELTA PRESSURE SENSOR SENSOR IN THE EFR Spare Part 55692 7254 F6.488.03.0.PR LAMBDA MAKE EUGO HEGO SENSOR Spare Part 17686 7255 F6.488.04.0.PR WOODWARD MAKE ELECTRONIC FLOW REGULATOR EFR Spare Part 269759 7257 F6.488.05.0.PR WOODWARD MAKE F SERIES THROTTLE BODY Spare Part 18015 7258						15%
7247 F6.482.01.0.00 WATER HEATER(KIM HOTSTART, TPS202GT12-006, 2.0kW, 240V) Spare Part 48242 7248 F6.483.01.0.00 ACTUATOR(XADC225D1S - 24) FOR FIRE FIGHTING APPLN. Spare Part 154364 7249 F6.483.04.0.00 SPACER FOR LINK(M6 X1 LH - M6X1 RH) Spare Part 132 7250 F6.483.06.0.00 LINK(M6X1 LH - M6X1 RH) Spare Part 83 7251 F6.483.12.0.00 ADAPTOR (M6X1-M6X1) Spare Part 182 7252 F6.488.01.0.PR WOODWARD MAKE 70 PIN ENGINE CONTROL MODULE SECM70 Spare Part 114134 7253 F6.488.02.0.PR WOODWARD MAKE DELTA PRESSURE SENSOR SENSOR IN THE EFR Spare Part 55692 7254 F6.488.03.0.PR LAMBDA MAKE EUGO HEGO SENSOR Spare Part 17686 7255 F6.488.04.0.PR WOODWARD MAKE ELECTRONIC FLOW REGULATOR EFR Spare Part 276652 7256 F6.488.05.0.PR WOODWARD MAKE F SERIES THROTTLE BODY Spare Part 18015 7257 F6.488.06.0.PR IGNITION COIL Spare Part 21852 7259 F6.503.02.0.00 JOINT S						15%
7248 F6.483.01.0.00 ACTUATOR(XADC225D1S - 24) FOR FIRE FIGHTING APPLN. Spare Part 154364 7249 F6.483.04.0.00 SPACER FOR LINK(M6 X1 LH - M6X1 RH) Spare Part 132 7250 F6.483.06.0.00 LINK(M6X1 LH - M6X1 RH) Spare Part 83 7251 F6.483.12.0.00 ADAPTOR (M6X1-M6X1) Spare Part 182 7252 F6.488.01.0.PR WOODWARD MAKE 70 PIN ENGINE CONTROL MODULE SECM70 Spare Part 114134 7253 F6.488.02.0.PR WOODWARD MAKE DELTA PRESSURE SENSOR SENSOR IN THE EFR Spare Part 55692 7254 F6.488.03.0.PR LAMBDA MAKE EUGO HEGO SENSOR Spare Part 17686 7255 F6.488.04.0.PR WOODWARD MAKE ELECTRONIC FLOW REGULATOR EFR Spare Part 276652 7256 F6.488.05.0.PR WOODWARD MAKE F SERIES THROTTLE BODY Spare Part 18015 7257 F6.488.06.0.PR IGNITION COIL Spare Part 21852 7259 F6.503.01.0.00 EXHAUST SILENCER: 4" ID Spare Part 689						15%
7249 F6.483.04.0.00 SPACER FOR LINK(M6 X1 LH - M6X1 RH) Spare Part 132 7250 F6.483.06.0.00 LINK(M6X1 LH - M6X1 RH) Spare Part 83 7251 F6.483.12.0.00 ADAPTOR (M6X1-M6X1) Spare Part 182 7252 F6.488.01.0.PR WOODWARD MAKE 70 PIN ENGINE CONTROL MODULE SECM70 Spare Part 114134 7253 F6.488.02.0.PR WOODWARD MAKE DELTA PRESSURE SENSOR SENSOR IN THE EFR Spare Part 55692 7254 F6.488.03.0.PR LAMBDA MAKE EUGO HEGO SENSOR Spare Part 17686 7255 F6.488.04.0.PR WOODWARD MAKE ELECTRONIC FLOW REGULATOR EFR Spare Part 276652 7256 F6.488.05.0.PR WOODWARD MAKE F SERIES THROTTLE BODY Spare Part 269759 7257 F6.488.06.0.PR IGNITION COIL Spare Part 18015 7258 F6.503.01.0.00 EXHAUST SILENCER: 4" ID Spare Part 689 7259 F6.503.02.0.00 JOINT SS: 4" Spare Part 689				-		15%
7250 F6.483.06.0.00 LINK(M6X1 LH - M6X1 RH) Spare Part 83 7251 F6.483.12.0.00 ADAPTOR (M6X1-M6X1) Spare Part 182 7252 F6.488.01.0.PR WOODWARD MAKE 70 PIN ENGINE CONTROL MODULE SECM70 Spare Part 114134 7253 F6.488.02.0.PR WOODWARD MAKE DELTA PRESSURE SENSOR SENSOR IN THE EFR Spare Part 55692 7254 F6.488.03.0.PR LAMBDA MAKE EUGO HEGO SENSOR Spare Part 17686 7255 F6.488.04.0.PR WOODWARD MAKE ELECTRONIC FLOW REGULATOR EFR Spare Part 276652 7256 F6.488.05.0.PR WOODWARD MAKE F SERIES THROTTLE BODY Spare Part 269759 7257 F6.488.06.0.PR IGNITION COIL Spare Part 18015 7258 F6.503.01.0.00 EXHAUST SILENCER: 4" ID Spare Part 21852 7259 F6.503.02.0.00 JOINT SS: 4" Spare Part 689						15%
7251 F6.483.12.0.00 ADAPTOR (M6X1-M6X1) Spare Part 182 7252 F6.488.01.0.PR WOODWARD MAKE 70 PIN ENGINE CONTROL MODULE SECM70 Spare Part 114134 7253 F6.488.02.0.PR WOODWARD MAKE DELTA PRESSURE SENSOR SENSOR IN THE EFR Spare Part 55692 7254 F6.488.03.0.PR LAMBDA MAKE EUGO HEGO SENSOR Spare Part 17686 7255 F6.488.04.0.PR WOODWARD MAKE ELECTRONIC FLOW REGULATOR EFR Spare Part 276652 7256 F6.488.05.0.PR WOODWARD MAKE F SERIES THROTTLE BODY Spare Part 269759 7257 F6.488.06.0.PR IGNITION COIL Spare Part 18015 7258 F6.503.01.0.00 EXHAUST SILENCER: 4" ID Spare Part 21852 7259 F6.503.02.0.00 JOINT SS: 4" Spare Part 689						15%
7252 F6.488.01.0.PR WOODWARD MAKE 70 PIN ENGINE CONTROL MODULE SECM70 Spare Part 114134 7253 F6.488.02.0.PR WOODWARD MAKE DELTA PRESSURE SENSOR SENSOR IN THE EFR Spare Part 55692 7254 F6.488.03.0.PR LAMBDA MAKE EUGO HEGO SENSOR Spare Part 17686 7255 F6.488.04.0.PR WOODWARD MAKE ELECTRONIC FLOW REGULATOR EFR Spare Part 276652 7256 F6.488.05.0.PR WOODWARD MAKE F SERIES THROTTLE BODY Spare Part 269759 7257 F6.488.06.0.PR IGNITION COIL Spare Part 18015 7258 F6.503.01.0.00 EXHAUST SILENCER: 4" ID Spare Part 21852 7259 F6.503.02.0.00 JOINT SS: 4" Spare Part 689						15%
7253 F6.488.02.0.PR WOODWARD MAKE DELTA PRESSURE SENSOR SENSOR IN THE EFR Spare Part 55692 7254 F6.488.03.0.PR LAMBDA MAKE EUGO HEGO SENSOR Spare Part 17686 7255 F6.488.04.0.PR WOODWARD MAKE ELECTRONIC FLOW REGULATOR EFR Spare Part 276652 7256 F6.488.05.0.PR WOODWARD MAKE F SERIES THROTTLE BODY Spare Part 269759 7257 F6.488.06.0.PR IGNITION COIL Spare Part 18015 7258 F6.503.01.0.00 EXHAUST SILENCER: 4" ID Spare Part 21852 7259 F6.503.02.0.00 JOINT SS: 4" Spare Part 689						15%
7254 F6.488.03.0.PR LAMBDA MAKE EUGO HEGO SENSOR Spare Part 17686 7255 F6.488.04.0.PR WOODWARD MAKE ELECTRONIC FLOW REGULATOR EFR Spare Part 276652 7256 F6.488.05.0.PR WOODWARD MAKE F SERIES THROTTLE BODY Spare Part 269759 7257 F6.488.06.0.PR IGNITION COIL Spare Part 18015 7258 F6.503.01.0.00 EXHAUST SILENCER: 4" ID Spare Part 21852 7259 F6.503.02.0.00 JOINT SS: 4" Spare Part 689						15%
7255 F6.488.04.0.PR WOODWARD MAKE ELECTRONIC FLOW REGULATOR EFR Spare Part 276652 7256 F6.488.05.0.PR WOODWARD MAKE F SERIES THROTTLE BODY Spare Part 269759 7257 F6.488.06.0.PR IGNITION COIL Spare Part 18015 7258 F6.503.01.0.00 EXHAUST SILENCER: 4" ID Spare Part 21852 7259 F6.503.02.0.00 JOINT SS: 4" Spare Part 689						15%
7256 F6.488.05.0.PR WOODWARD MAKE F SERIES THROTTLE BODY Spare Part 269759 7257 F6.488.06.0.PR IGNITION COIL Spare Part 18015 7258 F6.503.01.0.00 EXHAUST SILENCER: 4" ID Spare Part 21852 7259 F6.503.02.0.00 JOINT SS: 4" Spare Part 689						15%
7257 F6.488.06.0.PR IGNITION COIL Spare Part 18015 7258 F6.503.01.0.00 EXHAUST SILENCER: 4" ID Spare Part 21852 7259 F6.503.02.0.00 JOINT SS: 4" Spare Part 689						15%
7258 F6.503.01.0.00 EXHAUST SILENCER: 4" ID Spare Part 21852 7259 F6.503.02.0.00 JOINT SS: 4" Spare Part 689						15%
7259 F6.503.02.0.00 JOINT SS: 4" Spare Part 689				-		15%
						15%
7260 F6.503.04.0.00 FLANGE-ID 4" Spare Part 1748						15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer without Vat in	Custom Charge%
				NPR	Charge/
7261	F6.504.01.0.00	AIR CLEANER: 14"+MTG STRAP CAP	Spare Part	37763	15%
7262	F6.504.02.0.00	RANGE RESTRICTION INDICATOR 1/8" 24"	Spare Part	1000	15%
7263	F6.504.08.0.00	AIR CLEANER ELEMENT-14"	Filter	4202	20%
7264	F6.504.32.0.00	AIR CLEANER ASSLY: DRY 11.5"	Filter	22717	20%
7265	F6.504.34.0.00	FILTER ELEMENT FOR 11.5"JJF DRYTYPE AIR CLEANER	Spare Part	4265	20%
7266	F6.504.35.0.00	HOOD FOR 11.5" FILTER	Spare Part	2092	15%
7267	F6.505.12.0.00	ADAPTOR: M24X1.5M-M10X1.5F	Spare Part	212	15%
7268	F6.508.01.0.00	ENGINE MTG FOOT	Spare Part	4769	15%
7269	F6.508.03.0.00	HARD WASHER(12 ID)	Spare Part	46	15%
7270	F6.508.18.0.SP	500 Hrs B Check Maintenance Kit	Spare Part	28784	20%
7271	F6.508.19.0.SP	1500 hrs C Check Maintenance Kit	Spare Part	53575	20%
7272	F6.508.22.0.SP	50 Hrs A check Maintenance Kit	Spare Part	20747	20%
7273	F6.509.03.0.00	WATER SUCTION CONNECTION	Spare Part	2600	15%
7274	F6.509.04.0.00	ANTI VIBRATION MOUNTS	Spare Part	575	15%
7275	F6.509.05.0.00	HOSE: RADIATOR INLET 50 ID	Spare Part	2314	15%
7276	F6.509.06.0.00	HOSE: RADIATOR OUTLET 60 ID	Spare Part	1957	15%
7277	F6.509.13.0.00	ADAPTOR(M14*15 TO M14*2)	Spare Part	105	15%
7278	F6.509.14.0.00	FLEXIBLE PIPE: M14XM14X600 L	Spare Part	1394	15%
7279	F6.510.02.0.00	RUBBER BLOCK(0.37 HOLSET COUPLING)	Spare Part	7631	15%
7280	F6.510.10.0.00	HOLSET COUPLING 0.37 RB 45 MM PILOT BORE	Spare Part	31477	15%
7281	F6.516.02.0.00	SSJOINT(FOR TURBO OUTLET)	Spare Part	231	15%
7282	F6.516.05.0.00	BRACKET GAS OUTLET MANIFOLD	Spare Part	1748	15%
7283	F6.531.01.0.00	CHARGING ALTERNATOR 28V 45A	Spare Part	19227	15%
7284	F6.534.01.0.00	PULLEY	Spare Part	9424	15%
7285	F6.534.02.0.00	PULLEY PCD 124	Spare Part	3083 12588	15% 15%
7286	F6.534.10.0.00	PULLEY ASSLY: FAN DRIVE STARTER RING	Spare Part	8277	15%
7287 7288	F6.537.02.0.00 F6.537.10.0.00	FLYWHEEL ASSEMBLY	Spare Part	45039	15%
7289	F6.544.01.0.00	CRANK PULLEY 3 GROOVES 210 PCD	Spare Part Spare Part	5960	15%
7299	F6.549.01.0.00	HEAT EXCHANGER	Spare Part	154084	15%
7291	F6.549.03.0.00	FRESH WATER INLET CONN.ON HEAT EXCHANGER	Spare Part	1938	15%
7292	F6.549.06.0.00	HOSE: THERMOSTAT HSG TO INT. PIPE	Spare Part	1071	15%
7293	F6.549.13.3.00	INTERMEDIATE PIPE FOR HE IN CONN AL CAST	Spare Part	6480	15%
7294	F6.550.01.0.00	EXPANSION BELLOW: 4" WITH 4MTG HOLE	Spare Part	12061	15%
7295	F6.554.04.0.00	NON RETURN VALVE	Spare Part	5228	15%
7296	F6.554.08.0.00	FLEXIBLE PIPE (M30 X M30 U 600 L)	Spare Part	3021	15%
7297	F6.557.01.0.00	MOUNTING BRACKET FOR MAKE UP WATER TANK	Spare Part	2369	15%
7298	F6.557.03.0.00	MOUNTING PLATE FOR MAKE UP WATER TANK.	Spare Part	2812	15%
7299	F6.557.04.0.00	MAKE UP WATER TANK.	Spare Part	8003	15%
7300	F6.557.05.0.00	CLAMPING STRAP FOR MAKEUP WATER TANK MTG	Spare Part	400	15%
7301	F6.557.06.0.00	SPECIAL STUD	Spare Part	126	15%
7302	F6.557.07.0.00	COVER WITH PRESS CAP	Spare Part	3086	15%
7303	F6.557.08.0.00	OUTLET PIPE CONN ON MAKEUP WATER TANK	Spare Part	465	15%
7304	F6.557.09.0.00	FLEXIBLE PIPE VENT FOR W.TANK	Spare Part	634	15%
7305	F6.560.01.0.00	COMPRESSION RING	Spare Part	225	15%
7306	F6.561.04.0.00	STOP SOLENOID: 24V ENERG-RUN	Spare Part	6163	15%
7307	F6.561.20.0.00	STOP SOLENOID ASSLY-24VDC SINGLE COIL	Spare Part	6720	15%
7308	F6.564.01.0.00	ADAPTOR FOR PRSWITCH	Spare Part	77	15%
7309	F6.566.10.0.00	SET OF O RINGS: 6SL9088T	Spare Part	477	15%
7310	F6.566.20.0.SP	SET OF JOINTS 6SL9088T ENGINE.	Spare Part	24003	15%
7311	F6.566.30.0.00	SET OF COPPER WASHER	Spare Part	1114	15%
7312	F6.566.40.0.SP	SET OF JOINTS FOR 6SL9088TA ENGINE/F6.3021/F6.3221/F6.3421/F6.3621/F6.3821(STANDRAD)/F6.	Spare Part	23772	15%
7313	F6.566.50.0.00	SET OF O RINGS	Spare Part	10597	15%
7314	F6.566.60.0.00	SET OF COPPER WASHER	Spare Part	1314	15%
7315	F6.566.70.0.SP	SET OF JOINTS	Spare Part	25661	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
7316	F6.566.80.0.00	SET OF O RINGS	Spare Part	11246	15%
7317	F6.569.10.0.00	SUB ASSLY OF HOSE TAIL M 12 BANJO	Spare Part	234	15%
7318	F6.570.06.0.00	STOP SOLENOID: 24V ENERG-RUN	Spare Part	8855	15%
7319	F6.579.01.0.00	WATER PUMP PULLEY	Spare Part	2628	15%
7320	F6.579.21.0.00	WATER PUMP PULLEY PCD 190	Spare Part	2403	15%
7321	F6.594.06.0.00	HOSE FOR AIR CLEANER	Spare Part	5825	15%
7322	F6.606.03.0.00	BUSH	Spare Part	86	15%
7323	F6.606.04.0.00	WASHER FOR AXUAL ALIGNMENT	Spare Part	25	15%
7324	F6.606.05.0.00	SPACER	Spare Part	58	15%
7325	F6.606.06.0.00	PULLEY FOR ALTERNATOR	Spare Part	655	15%
7326	F6.606.07.0.00	LEVER	Spare Part	388	15%
7327	F6.606.08.0.00	BRACKET: ALTERNATOR	Spare Part	742	15%
7328	F6.606.09.0.00	PULLEY FOR ALTERNATOR(2 GROOVE, 81 P.C.D.)	Spare Part	1655	15%
7329	F6.606.21.0.00	ALTERNATOR PULLEY	Spare Part	963	15%
7330	F6.610.02.0.00	PRESSURE SENDER	Spare Part	1914	15%
7331	F6.614.02.0.00	SPEED CONTROL	Spare Part	122112	15%
7332	F6.618.01.0.00	EXPANSION BELLOW: 4"	Spare Part	12628	15%
7333	F6.618.02.0.00	JOINT SS	Spare Part	332	15%
7334	F6.619.02.0.00	GAS OUTLET BEND	Spare Part	7997	15%
	F6.628.01.0.00	ENGINE MTG FOOT	Spare Part	3381	15%
	F6.639.01.0.00	BRACKET FOR ALTRNATOR	Spare Part	1135	15%
	F6.639.04.0.00	ALTERNATOR: 24V 45A WO BLOCKING DIODE	Spare Part	19911	15%
7338	F6.640.01.0.00	BRACKET FOR 11.5"AIR CLEANER	Spare Part	3452	15%
7339	F6.640.02.0.00	AIR CLEANER ELEMENT 11.5"	Filter	6532	20%
7340	F6.657.20.0.00	0.73RB COUPLING	Spare Part	47498	15%
7341	F6.669.01.0.00	RADIATOR ASSLY FOR URAL	Spare Part	216896	15%
7342	F6.669.09.0.00	FLEX.HOSE FOR VENT	Spare Part	1908	15%
	F6.670.34.0.00	LUBE OIL DRAIN PIPE ASSLY	Spare Part	5498	15%
7344	F6.670.98.0.PR	HOSE FOR AIR SUCTION PIPE	Spare Part	2535	15%
7345	F6.674.04.0.00	JOINT: AIR INLET MANIFOLD	Spare Part	68	15%
7346	F6.680.01.0.00	RADIATOR	Spare Part	275501	15%
7347	F6.680.04.0.00	PIPE FOR THERMOSTAT TO WATER TANK OF RADIATOR	Spare Part	1714	15%
7348	F6.680.06.0.00	RUBBER HOSE: MAIN PIPE 100X100X180L	Spare Part	3252	15%
7349	F6.680.08.0.00	SUCTION CONNECTION	Spare Part	2520	15%
	F6.680.11.0.00	LUG FOR STAY	Spare Part	279	20%
	F6.680.12.0.00	STAY FOR RADIATOR	Spare Part	508	15%
	F6.680.13.0.00	HOLDING BRACKET	Spare Part	880	15%
	F6.680.25.0.00	T BOLT CLAMP	Spare Part	154	15%
	F6.701.03.0.00	CIRCLIP: SEEGEV	Spare Part	95	15%
	F6.701.10.0.00	CON ROD ASSLY: 250 KVA W/0 BRG	Spare Part	15480	15%
	F6.701.100.0.PR	CONNECTING ROD ASSEMBLY	Spare Part	10326	15%
	F6.701.20.0.00	PISTON ASSEMBLY	Spare Part	13621	15%
	F6.701.40.0.00	CONNECTING ROD ASSLY	Spare Part	17560	15%
			·		
	F6.701.61.0.00	PISTON ASSEMBLY ELIEL DIDE INLET WATER SERBATER TO EIR	Spare Part	14803	15%
	F6.708.08.0.00	FUEL PIPE INLET WATER SEPRATER TO FIP	Spare Part	1566	15%
	F6.708.12.0.00	FUEL PIPE RETURN: M12X1.5 MALE PLUG X M14 X 1.5 BANJO 700MM	Spare Part	1295	15%
	F6.713.01.0.00	FIP: 250KVA	Spare Part	309873	15%
	F6.713.02.0.00	ADAPTOR REACY/ET FOR FIR MOUNTING	Spare Part	3625	15%
	F6.713.04.0.00	BRACKET FOR FIP MOUNTING	Spare Part	418	15%
	F6.713.05.0.00	JOINT: FLANGE	Spare Part	108	15%
	F6.713.08.0.00	O RING 15 I.D X1.78 DIA SECTION	Spare Part	25	15%
	F6.713.09.0.00	ADAPTOR FOR FUEL PIPE M14X1 5 X 14X1 5	Spare Part	172	15%
	F6.713.26.0.00	FEED PUMP	Spare Part	41267	15%
	F6.729.01.0.00	AIR CLEANER 16"	Filter	38945	20%
7370	F6.729.02.0.00	BRACKET FOR AIR CLEANER	Spare Part	6821	15%



				Price to	Custom
Sr.No.	Part Number	Part Description	Category	Customer without Vat in	Custom Charge%
				NPR	Charge/o
7371	F6.729.03.0.00	16"AIR CLEANER PRIMARY ELEMT	Filter	7909	20%
7372	F6.729.04.0.00	SAFETY AIR FILTER ELEMNT	Filter	3642	20%
7373	F6.729.05.0.00	16" AIR CLEANER HOOD WITH CLAMP ASSEMBLY	Spare Part	4736	20%
7374	F6.729.07.0.00	PRIMARY AIR CLEANER ELEMENT	Filter	10699	20%
7375	F6.729.08.0.00	AIR CLEANER SAFETY ELEMENT	Filter	2949	20%
7376	F6.729.13.0.00	HOSE: AIR INLET 250 KVA	Spare Part	8397	15%
7377	F6.729.19.0.00	HOSE: AIR CLEANER	Spare Part	6926	15%
7378	F6.734.10.0.00	PIPE COMPLETE ASSLY WITH CLAMPS	Spare Part	9708	15%
7379	F6.741.01.0.00	BRACKET FOR ADC 225 GS GOVERNOR	Spare Part	2538	15%
7380	F6.741.02.0.00	LINK: ADC C225 GS	Spare Part	68	15%
7381	F6.741.03.0.00	WIRING HARNESS	Spare Part	10357	15%
7382	F6.741.06.0.00	CONTROL UNIT	Spare Part	81670	15%
7383	F6.741.07.0.00	MAGNETIC P'UP THREAD 16X1.5	Spare Part	3477	15%
7384	F6.741.08.0.00	BRAKET FOR ADC225 GAC ACTUATOR	Spare Part	1849	15%
7385	F6.741.09.0.00	SPACER FOR THE FITMENT OF THE GOVERNOR LINKAGE FOR THE GAV G	Spare Part	151	15%
7386	F6.741.12.0.00	RELAY MOD 24V DC	Spare Part	1132	15%
7387	F6.741.14.0.00	MAGNETIC PICKUP: DUAL TWO CONNECTOR	Spare Part	7535	15%
7388	F6.741.16.0.00	MAGNETIC PICK UP 16X1.5 THREAD	Spare Part	3572	15%
7389	F6.741.19.0.00	MAGNETIC PICKUP: AMP CONNECTOR	Spare Part	4505	15%
7390	F6.741.26.0.PR	DUAL O P MPU MAKE UNITECH	Spare Part	6698	15%
7391	F6.742.06.0.00	CONTROL UNIT ESD 2210 S F SOLO	Spare Part	73553	15%
7392	F6.742.08.0.00	LEVER FOR ELEC ACTUATOR	Spare Part	938	15%
7393	F6.744.12.0.PR	O RING ID 69 6 5 mm	Spare Part	689	15%
7394	F6.746.01.0.00	WATER COOLED CAC-FOR FIRE FIGHTING (296HP/1500)	Spare Part	205305	15%
7395	F6.746.02.0.00	HEAT EXCHANGER FIRE FIGHTING	Spare Part	224606	15%
7396	F6.746.05.0.00	JOINT: WATERCOOLED CAC	Spare Part	46	15%
7397	F6.746.14.0.00	HOSE: SUCT CONN 60 IDX 700DX 60MM	Spare Part	566	15%
7398	F6.748.04.0.PR	RUBBER HOSE FOR DRAIN PIPE	Spare Part	920	15%
7399	F6.748.05.0.PR	JOINT BET TURBO ADAPTOR CRANKCASE	Spare Part	55	15%
7400	F6.748.13.0.PR	JOINT BETWEEN TURBO DRAIN PIPE	Spare Part	62	15%
7401	F6.749.11.0.PR	HOSE FOR CAC PIPE	Spare Part	3388	15%
7402	F6.755.06.0.PR	LUB OIL HEADER FOR SL90 320 KVA FINISH	Spare Part	18994	15%
7403	F6.755.12.0.PR	ORING BW HEADER CRANKCASE	Spare Part	634	15%
7404	F6.759.05.0.00	HX40 HOLSET TURBO 332 2100 40 L8294 H18E PROFILE 8	Spare Part	173558	15%
7405	F6.768.02.0.00	JOINT FOR EXHAUST SILENCER	Spare Part	2166	15%
7406	F6.768.04.0.00	U STRIP CLAMP FOR 160 125KVA	Spare Part	1569	15%
7407	F6.768.50.0.00	RAIN CAP	Spare Part	1474	15%
7408	F6.783.01.0.00	DAMPER	Spare Part	35670	15%
7409	F6.784.01.0.00	SPECIAL CRANK PULLEY	Spare Part	6280	15%
7410	F6.785.01.0.00	SPECIAL DRIVING HUB	Spare Part	4606	15%
7411	F6.786.01.0.00	EXPANSION BELLOW	Spare Part	4708	15%
7412	F6.795.03.0.00	FIP FOR SL90TA	Spare Part	314747	15%
7413	F6.795.13.0.00	FUEL INJECTION PUMP ASSMEBLY	Spare Part	301174	15%
7414	F6.795.18.0.PR	FUEL FEED PUMP 9 440 0 30 003	Spare Part	10637	15%
7415	F6.801.04.0.00	EXHAUST DIFFUSER	Spare Part	5689	15%
7416	F6.801.09.0.00	HOSE FOR AIR CLEANER	Spare Part	1806	15%
7417	F6.801.10.0.00	RADIATOR	Spare Part	288067	15%
7418	F6.801.11.0.00	HOSE (FROM RADIATOR TO WATER PUMP)	Spare Part	1889	15%
7419	F6.801.13.0.00	PIPE (THERMOSTAT TO RADIATOR)	Spare Part	1997	15%
7420	F6.801.15.0.00	FUEL RETURN PIPE	Spare Part	1095	15%
7421	F6.801.23.0.00	FUEL PIPE PRE-FILTER TO TANK	Spare Part	723	15%
7422	F6.801.25.0.00	BRACKET FOR ACTUATOR MOUNTING	Spare Part	5908	15%
7423	F6.801.26.0.00	VENT PIPE	Spare Part	1698	15%
7424	F6.801.27.0.00	VENT PIPE	Spare Part	1477	15%
7425	F6.801.28.0.00	FUEL RETURN PIPE	Spare Part	862	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
7426	F6.802.19.0.00	FUEL LEVEL SENSOR 145MM	Spare Part	2363	15%
7427	F6.811.02.0.00	HARD WASHER(FOR M20 BOLT).	Spare Part	274	15%
7428	F6.811.04.0.00	HARD WASHER (ID 17,OD 35,THK 5)	Spare Part	200	15%
7429	F6.814.11.0.00	AVR MODEL TAVR-3A S/F KG ALTERNATOR PART NO.AG4071810000, (140,160,180&200KVA)(FRAM	Spare Part	36015	15%
7430	F6.814.15.0.00	ROTATING RECTIFIER ASSLY: 6 DIODE	Spare Part	21732	15%
7431	F6.814.16.0.00	ROTATING REEFIFER ASSEMBLY WITH 6NOS. DIODE&HEATSINK S/F KG ALTERNATOR PARTNO.4	Spare Part	26258	15%
7432	F6.814.17.0.00	EXCITOR ROTOR ASSEMBLYTEX2.1 S/F KGALTERNATOR PARTNO.1ER210400100 (140 TO 320 KV/	Spare Part	54082	15%
7433	F6.814.25.0.00	TERMINAL BLOCK S/F KG ALTERNATOR PART NO.AG3040790000 (140 TO 320 KVA)	Spare Part	12578	15%
7434	F6.815.41.0.00	AVR	Spare Part	79128	15%
7435	F6.840.05.0.00	HOSE FOR AIR DELIVERY BEND	Spare Part	1997	15%
7436	F6.840.16.0.00	HOSE AT CAC IN (100 ID X 100 ID X 80 LENGTH)	Spare Part	2738	15%
7437	F6.857.01.0.00	RELAY BOARD: SINGLE CHANEL	Spare Part	1631	15%
7438	F6.858.20.0.00	CONTROL PANEL ASSEMBLY	Spare Part	52178	15%
7439	F6.860.11.0.00	RELAY 24VDC	Spare Part	1265	15%
7440	F6.863.17.0.00	RELAY BOARD 2.5 CH 70 AMP	Spare Part	6117	15%
7441	F6.865.05.0.00	RELAY BOARD	Spare Part	5557	15%
7442	F6.873.01.0.00	SELCTOR SWITCH 2 WAY WITH CENTER OFF 2POLE	Spare Part	2215	15%
7443	F6.889.02.0.00	TURBOCHARGER	Spare Part	87057	15%
7444	F6.889.03.0.00	TURBOCHARGER	Spare Part	87679	15%
7445	F6.889.04.0.00	AIR DELIVERY BEND: 200KVA	Spare Part	2723	15%
7446	F6.889.05.0.00	O RING (FOR TURBO OUTLET)	Spare Part	108	15%
7447	F6.889.08.0.00	AIR DELIVERY BEND (TURBOCHARGER)	Spare Part	3828	15%
7448	F6.889.16.0.PR	CAC HOSE HOT SIDE 4 PLIES LAKSHAYA PROJECT	Spare Part	3865	15%
7449	F6.900.23.0.00	SOLID STATE LAMP 183 mA: 8-30V	Spare Part	858	15%
7450	F6.906.70.0.00	LOW ENGINE COOLANT TEMPERATURE SWITCH	Spare Part	2105	15%
7451	F6.906.71.0.00	RAW WATER HIGH TEMPRATURE SWITCH	Spare Part	3200	15%
7452	F6.906.72.0.00	ENGINE COOLANT TEMPRATURE SWITCH.	Spare Part	2105	15%
7453	F6.908.01.0.00	MAGNETIC PICKUP M16X1.5	Spare Part	2225	15%
7454	F6.908.11.0.00	LOW LUB OIL PRESSURE SWITCH SETTING 2 BAR 1/8 NPT WITH TWO SCREW TERMINALS	Spare Part	705	15%
7455	F6.909.69.0.00	WATER TEMP SWITCH 98 DEG C	Spare Part	2363	15%
7456	F6.917.20.0.00	WIRING HARNESS FOR FIRE FIGHTING (250KVA)	Spare Part	9372	15%
7457	F6.920.10.0.00	PISTON ASSLY FOR 160 KVA GAS ENGINE	Spare Part	15975	15%
7458	F6.928.11.0.00	WIRING HARNESS ASSEMBLY SL90 FM UL NEW	Spare Part	35673	15%
7459	F6.928.20.0.00	WIRING HARNESS: FIRE FIGHTING	Spare Part	8117	15%
7460	F6.933.24.0.00	EARTHING CABLE (PVC ,GREEN COLOUR) FOR RADIATOR TO STARTER 2.5 SQ.MM.	Spare Part	335	15%
7461	F6.941.10.0.SP	RADIATOR WITH CAC	Spare Part	592740	15%
7462	F6.942.01.0.00	ENGINE CONTROL UNIT	Spare Part	17837	15%
7463	F6.942.02.0.00	ACTUATOR 24VDC SL90	Spare Part	28107	15%
7464	F6.942.03.0.00	ECU E-GOVERNER B12 24VDC SL90	Spare Part	17197	15%
7465	F6.942.12.0.00	ACTUATOR: 24VDC SL90	Spare Part	42698	15%
7466	F6.956.10.0.00	HT CABLE SET 6 HT CABLES FOR WOODWARD BIOGAS KIT FOR SL90 ENGINE	Spare Part	9486	15%
7467	F6.957.01.0.00	TURBOCHARGER HOLSET HX50 S F FIRE FIGHTING	Spare Part	270381	15%
7468	F6.959.10.0.00	ENGINE WIRING ASSLY: EMS907	Spare Part	9972	15%
7469	F6.962.10.0.00	WIRING HARNESS ASSLY: 250KVA	Spare Part	13055	15%
7470	F6.969.01.0.00	EXHAUST MANIFOLD (CENTRAL PIECE)	Spare Part	5757	15%
7470	F6.969.02.0.00	AIR DELIVERY BEND (FOR HOLSET HX50 TUBOCHARGER)	Spare Part	4874	15%
7471	F6.969.03.0.00	JOINT BETWEEN AIR BEND & CAC-IN PIPE	Spare Part	566	15%
7473	F6.969.04.0.00	AIR DELIVERY MAIN PIPE	Spare Part	7092	15%
7474	F6.969.07.0.00	ADAPTOR FOR OIL INLET TO TURBO	Spare Part	246	15%
					15%
7475	F6.969.08.0.00	JOINT AT TURBINE OUTLET OF HX-50 TURBOCHARGER	Spare Part	1538	
7476	F6.969.09.0.00	LUBE OIL DRAIN PIPE ASSEMBLY	Spare Part	1535	15%
7477	F6.969.11.0.00	HOSE: COMP OUT TO AIR DELIVERY BEND	Spare Part	2335	15%
7478	F6.969.20.0.00	LUB OIL SUPPLY PIPE TO TURBO CHARGER	Spare Part	1994	15%
7479	F6.969.24.0.00	HOSE: COMP. OUT TO AIR DELIVERY PIPE	Spare Part	1203	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
7481	F6.973.10.0.00	WIRING HARNESS ASSEMBLY FOR 140 KVA TO 200 KVA WITH EMS 907 WITH OUT WATER LEVEL	Spare Part	7821	15%
7482	F6.980.01.0.00	HOSE: AIR CLEANER	Spare Part	6101	15%
7483	F6.982.05.0.00	HOSE (FROM H.EXCHANGER PIPE TO SUCTION)	Spare Part	923	15%
7484	F6.982.06.0.00	HOSE (FROM THERMOSTAT TO H.E)	Spare Part	1446	15%
7485	F6.982.11.0.00	JOINT: HEAT EXCHANGER	Spare Part	62	15%
7486	F6.982.12.0.00	HOSE: CAC PIPE AND H.E.	Spare Part	846	15%
7487	F6.982.14.0.00	ADAPTOR FOR VENT PIPE(M14X15 TO 1/4")	Spare Part	132	15%
7488	F6.982.17.0.00	HEAT EXCHANGER(S/F FRESH WATER) FOR 6RTA AND SL90TA F.F. ENGINES	Spare Part	208182	15%
7489	F6.983.01.0.00	AIR CLEANER F.F. ENGINES	Filter	12352	20%
7490	F6.983.03.0.00	HOSE: AIR CLEANER	Spare Part	5425	15%
7491	F6.983.07.0.00	AIR CLEANER ASSEMBLY	Spare Part	14812	15%
7492	F6.984.01.0.00	WATER HEATER(KIM HOTSTART, TPS 152GT12-006, 1.5kW, 240V)	Spare Part	47236	15%
7493	F6.984.05.0.00	BRACKET FOR WATER HEATER MOUNTING	Spare Part	880	15%
7494	F6.984.10.0.00	TERMINAL BLOCK	Spare Part	5551	15%
7495	F6.986.02.0.00	HOSE CLAMP	Spare Part	433	20%
7496	F6.986.06.0.00	HOOD ASSEMBLY	Spare Part	14518	20%
7497	F6.986.08.0.00	HOSE CLAMP	Spare Part	388	15%
7498	F6.986.09.0.00	VACUUM INDICATOR(25")	Spare Part	2095	15%
7499	F6.986.11.0.00	AIR CLEANER PRIMARY ELEMENT	Filter	21043	20%
7500	F6.986.12.0.00	AIR CLEANER SAFETY ELEMENT	Filter	8478	20%
7501	F6.986.21.0.00	ADAPTOR (0.25 " BSP TO M16 X 1.5)	Spare Part	203	15%
7502	F6.986.30.0.00	AIR CLEANER ASSEMBLY KIT(FLEETGUARD)	Spare Part	111677	20%
7503	F6.992.08.0.00	MOUNTING BRACKET	Spare Part	2098	20%
7504	F6.992.09.0.00	MOUNTING BRACKET ASSEMBLY	Spare Part	2413	20%
7505	F6.993.01.0.00	WATER COOLED CAC FOR F F	Spare Part	203751	15%
7506	F6.993.08.0.00	PIPE FROM CAC TO HE	Spare Part	4378	15%
7507	F6.993.13.0.00	JOINT: RAW WATER INLET/OUTLET	Spare Part	34	15%
7508	F6.999.100.0.00	CENTRIFUGAL FILTER SERVICE KIT	Spare Part	674	15%
7509	F6.999.109.0.SP	CONTROL PANEL DOOR HINGE 40MM	Spare Part	532	15%
7510	F6.999.110.0.00	FUEL RETURN LINE NRV KIT	Spare Part	2969	15%
7511	F6.999.111.0.SP	CONTROL PANEL DOOR HINGE 50MM	Spare Part	778	15%
7512	F6.999.130.0.00	FUEL RETURN LINE NRV KIT	Spare Part	3520	15%
7513	F6.EGT4.12.0.PR	DOC CATALYST 12 DIA X 5 LENGTH 20 G CFT 5 1 PT PD FRESH	Spare Part	251892	15%
7514	F6.EGT4.15.0.PR	SCR CATALYST FIRST BRICK - FRESH (12" DIA X 7" LENGTH, WCL 2.75 G/IN3)	Spare Part	168358	15%
7515	F6.EGT4.16.0.PR	SCR CATALYST SECOND BRICK - FRESH (12" DIA X 7" LENGTH, 2.1 G/IN3 ON 5? LENGTH, ASC 2 G	Spare Part	167589	15%
7516	F6.EGT4.23.0.PR	12 Gasket 82602769	Spare Part	8834	15%
7517	F6.EGT4.24.0.PR	DOSING MODULE B444 606 555 DM2 2 6 HOLE 9 BAR	Spare Part	27332	15%
7518	F6.EGT4.25.0.PR	SUPPLY MODULE B444 606 941 SM 2 2 EVO BL 24 V 9 BAR	Spare Part	109340	15%
7519	F6.EGT4.28.0.PR	EXHAUST TEMP SENSOR FOR CPCB4	Spare Part	11997	15%
7520	F6.M019.12.0.00	PIPE FOR TURBO OIL SUPPLY	Spare Part	5557	15%
7521	F6.P008.05.0.PR	O RING ID 29 91 DIA 5 MM	Spare Part	298	15%
7522	F6.P008.07.0.PR	O RING ID 30 45 DIA 3 MM	Spare Part	243	15%
7523	FA1.031.02.0.00	FUEL FILTER ELEMENT 0 25 LIT	Spare Part	224	20%
7524	FA1.031.20.0.00	FUEL FILTER ASSEMBLY	Filter	764	20%
7525	G.038.5.01.703	BEARING BUSH NT KIR RA3	Spare Part	357	15%
7526	G.073.5.00.703	BEARING IG BUSH: HA394	Spare Part	388	15%
7527	G.584.5.00.703	MAIN BEARING IG BUSH R1040/4K1080	Spare Part	495	15%
7528	GP2.001.10.0.PR	CRANKCASE ASSEMBLY WITH M B CAP	Spare Part	80362	15%
7529	GP2.003.10.0.PR	CAMSHAFT ASSEMBLY	Spare Part	15363	15%
7530	GP2.005.13.0.PR	CYLINDER HEAD GASKET	Spare Part	5018	15%
7530	GP2.005.13.0.PR GP2.005.30.0.PR	CYLINDER HEAD ASSEMBLY WITH VALVE SPRING	Spare Part	25754	15%
7532	GP2.005.50.0.PR	ROCKER LEVER ASSEMBLY	Spare Part	5886	15%
		O RING FOR FIP SIDE COVER PLATE	Spare Part	283	15%
7533	GP2.011.21.0.PR	FUEL PUMP ASSEMBLY	Spare Part	66128	15%
7534	GP2.011.300.0.PR				



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
7536	GP2.015.40.0.PR	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	2360	15%
7537	GP2.021.03.0.PR	ADAPTOR FOR HOUSING SAE4	Spare Part	52704	15%
7538	GP2.021.04.0.PR	ADAPTOR FOR FLYWHEEL SAE 7 5	Spare Part	64273	15%
7539	GP2.021.10.0.PR	FLYWHEEL STARTER RING ASSEMBLY	Spare Part	19147	15%
7540	GP2.035.08.0.PR	GASKET FOR ROCKER COVER	Spare Part	1145	15%
7541	GP2.047.02.0.PR	FUEL PIPE FUEL FILTER TO F I P	Spare Part	723	15%
7542	GP2.047.06.0.SP	50 Hrs A check Maintenance Kit	Spare Part	4028	20%
7543	GP2.047.08.0.SP	1500 HRS C CHECK MAINTENANCE KIT	Spare Part	6634	20%
7544	GP2.047.09.0.SP	1500 Hrs C Check Maintenance Kit	Spare Part	6634	20%
7545		LEAK OFF PIPE POLY AMIDE	•	1738	15%
7546	GP2.048.01.0.PR GP2.100.01.0.PR	LOP SENSOR,5V, RATIOMETERIC,HONEYWELL	Spare Part	6683	15%
-	GP2.100.01.0.PR	TEMPERATURE SENSOR NTC TYPE HONEYWELL PROBE LENGTH 10MM Part No 32344949 002	Spare Part Spare Part	1228	15%
7547				618	
7548	GP2.107.06.0.PR	HOSE FROM THERMOSTAT TO RADIATOR	Spare Part		15%
7549	GP2.107.12.0.PR	SUCTION HOSE	Spare Part	1486	15%
7550	GP2.107.14.0.PR	RUBBER SLEEVE FOR HOSE	Spare Part	298	15%
7551	GP2.108.08.0.PR	FUEL TANK UNIT FOR 2R550 EXPORTS	Spare Part	4308	15%
7552	GP2.108.26.0.PR	FUEL HOSE FROM FUEL TANK TO PUMP	Spare Part	123	15%
7553	GP2.108.27.0.PR	FUEL PIPE FROM PUMP TO FEEDPUMP	Spare Part	969	15%
7554	GP2.110.07.0.PR	ANTI VIBRATION MOUNT CORI	Spare Part	1560	15%
7555	GP2.225.50.0.PR	ENGINE WIRING HARNESS FOR 2R550 10 12KVA ENGINE WITH AG48 AND KG645C	Spare Part	14058	15%
7556	GP3.001.06.0.PR	CAM SHAFT BUSH NA TC	Spare Part	326	15%
7557	GP3.001.10.0.PR	CRANKCASE ASSEMBLY WITH M B CAP	Spare Part	103559	15%
7558	GP3.001.26.0.PR	PIN FOR BANJO	Spare Part	31	15%
7559	GP3.001.27.0.PR	PLUG FOR BANJO	Spare Part	71	15%
7560	GP3.001.28.0.PR	BANJO BOLT FOR OIL SUPPLY	Spare Part	148	15%
7561	GP3.001.33.0.PR	BANJO BOLT FOR TURBO OIL SUPPLY PIPE	Spare Part	200	15%
7562	GP3.001.50.0.PR	CARNKCASE ASSEMBLY WITH M B CAP	Spare Part	93368	15%
7563	GP3.002.10.0.PR	CRANKSHAFT ASSEMBLY WITH CRANK GEAR	Spare Part	49433	15%
7564	GP3.003.10.0.PR	CAMSHAFT ASSEMBLY	Spare Part	17649	15%
7565	GP3.003.40.0.PR	CAMSHAFT ASSEMBLY	Spare Part	18120	15%
7566	GP3.004.07.0.PR	BOLT FOR CONNECTING ROD	Spare Part	138	15%
7567	GP3.004.10.0.PR	PISTON ASSEMBLY	Spare Part	4277	15%
7568	GP3.004.20.0.PR	CONNECTING ROD ASSLY WITH SMALL END BUSH	Spare Part	3151	15%
7569	GP3.004.22.0.PR	SMALL END BUSH BIMETAL BEARINGS LTD	Spare Part	692	15%
7570	GP3.004.23.0.PR	CONNECTING ROD BEARING UPPER BIMETAL BEARINGS LTD	Spare Part	335	15%
7571	GP3.004.24.0.PR	CONNECTING ROD BEARING LOWER BIMETAL BEARINGS LTD	Spare Part	182	15%
7572	GP3.005.08.0.PR	CYLINDER HEAD BOLT	Spare Part	212	15%
7573	GP3.005.19.0.PR	CYLINDER HEAD GASKET	Spare Part		15%
7574	GP3.005.30.0.PR	CYLINDER HEAD ASSEMBLY WITH VALVES AND SPRINGS	Spare Part	38326	15%
7575	GP3.005.80.0.PR	CYLINDER HEAD ASSEMBLY WITH VALVES AND SPRINGS	Spare Part	54741	15%
7576	GP3.007.60.0.PR	ROCKER LEVER ASSEMBLY COMPLETE	Spare Part		15%
7577	GP3.008.13.0.PR	O RING FOR LUB OIL PUMP	Spare Part	298	15%
7578	GP3.008.50.0.PR	LOP WITH RELIFE VALVE ASSEMBLY	Spare Part	8246	15%
7579	GP3.009.05.0.PR	FIP GEAR	Spare Part	2535	15%
7580	GP3.010.01.0.PR	GEAR COVER	Spare Part	5689	15%
7581	GP3.010.03.0.PR	FIP COVER PLATE	Spare Part	628	15%
7582	GP3.010.06.0.PR	O RING FOR FIP COVER PLATE	Spare Part	151	15%
7583	GP3.010.09.0.PR	OIL SEAL	Spare Part		15%
7584	GP3.011.06.0.PR	FUEL PUMP	Spare Part	42775	15%
7585	GP3.011.21.0.PR	O RING SIDE COVER FIP	Spare Part	308	15%
7586	GP3.011.25.0.PR	COVER (FEED PUMP)	Spare Part		15%
7587	GP3.011.26.0.PR	'O' RING (FEED PUMP COVER)	Spare Part	55	15%
7588	GP3.011.28.0.PR	O RING FOR DRAIN PLUG	Spare Part	22	15%
7589	GP3.011.410.0.PR	FUEL PUMP ASSEMBLY	Spare Part	140238	15%
7590	GP3.011.44.0.PR	OIL SUPPLY PIPE CRANKCASE TO F I P	Spare Part	800	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
			0 ,	without Vat in NPR	Charge%
7591	GP3.011.47.0.PR	LINEAR ACTUATOR WOODWARD MAKE APECS 0154	Spare Part	41827	15%
7592	GP3.011.530.0.PR	FUEL PUMP ASSEMBLY	Spare Part	107245	15%
7593	GP3.011.59.0.00	OIL SEAL HOUSING FOR FIP 20X52X10	Spare Part	1803	15%
7594	GP3.012.03.0.PR	O RING FOR HYDRAULIC PUMP ADAPTOR	Spare Part	240	15%
7595	GP3.012.07.0.PR	O RING FOR OIL FILLING CAP	Spare Part	262	15%
7596	GP3.012.13.0.PR	GEAR CASING FOR MECHANICAL FIP	Spare Part	7301	15%
7597	GP3.013.14.0.PR	BOSCH P TYPE INJECTOR FOR R550 ENGINE INJECTOR DRG NO E 080 3619 00 NOZZLE DRG	Spare Part	9640	15%
7598	GP3.013.32.0.PR	BOSCH P TYPE INJECTOR FOR R550 ENGINE INJECTOR DRG NO 0432 193 342 NOZZLE DRG N	Spare Part	10351	15%
7599	GP3.014.02.0.PR	GASKET FOR INTAKE MANIFOLD	Spare Part	114	15%
7600	GP3.014.07.0.PR	JOINT FOR INTAKE ADAPTOR	Spare Part	145	15%
7601	GP3.014.13.0.PR	GASKET FOR INTAKE MANIFOLD	Spare Part	142	15%
7602	GP3.015.100.0.PR	HIGH PRESSURE PIPE FOR CYL 3	Spare Part	2098	15%
7603	GP3.015.120.0.PR	HIGH PRESSURE PIPE FIP TO COMMON RAIL	Spare Part	1646	15%
7604	GP3.015.130.0.PR	HIGH PRESSURE PIPE FIP TO COMMON RAIL	Spare Part	1646	15%
7605	GP3.015.160.0.PR	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	4025	15%
7606	GP3.015.40.0.PR	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	3160	15%
7607	GP3.015.70.0.PR	HIGH PRESSURE PIPE FOR CYL 1	Spare Part	1997	15%
7608	GP3.015.90.0.PR	HP PIPE INTEGRAL SLEEVE ASSLY	Spare Part	1665	15%
7609	GP3.016.02.0.PR	OIL SEAL	Spare Part	1618	15%
7610	GP3.016.04.0.PR	O RING FOR OIL SEAL HOUSING	Spare Part	342	15%
7611	GP3.017.07.0.PR	O RING FOR SUCTION TUBE ADAPTOR	Spare Part	49	15%
7612	GP3.019.10.0.PR	LUB OIL SUMP SUB ASSEMBLY	Spare Part	8123	15%
7613	GP3.021.11.0.PR	STARTER RING	Spare Part	2126	15%
7614	GP3.022.01.0.PR	STARTOR	Spare Part	49590	15%
7615	GP3.022.01.0.PR	OIL FILTER ASSEMBLY	•	1243	20%
7616	GP3.025.10.0.PR	DIPSTICK ASSEMBLY WITH KNOB	Spare Part Spare Part	228	15%
7617	GP3.029.02.0.PR	GASKET FOR EXHAUST MANIFOLD	Spare Part	194	15%
7618	GP3.029.06.0.PR	GASKET FOR TURBO TO EXHAUST MANIFOLD	Spare Part	240	15%
7619	GP3.029.09.0.PR	GASKET EXHAUST MANIFOLD TO EGR COOLER	Spare Part	175	15%
7620	GP3.029.09.0.PR	GASKET FOR TURBO TO EXHAUST MANIFOLD	Spare Part	166	15%
7621	GP3.029.11.0.PR	SPACER FOR EXHAUST MANIFOLD	Spare Part	108	15%
7622	GP3.030.13.0.PR	TURBO CHARGER FOR TC VERSION CPCB II	Spare Part	51984	15%
7623	GP3.030.13.0.PR		•	1360	15%
7623	GP3.031.05.0.PR	ALTERNATOR PULLEY (P.C.D.68) O RING FOR WATER PUMP SLEEVE	Spare Part	52	15%
			Spare Part		
7625 7626	GP3.032.11.0.PR	WATER PUMP ASSEMBLY	Spare Part	135 18652	15% 15%
	GP3.032.50.0.PR	WATER PUMP ASSEMBLY	Spare Part		15%
7627	GP3.033.11.0.PR	POLY V BELT	Spare Part	812 34	
7628	GP3.034.02.0.PR	GASKET FOR THERMOSTAT COVER	Spare Part		15%
7629	GP3.034.03.0.PR	THERMOSTAT ELEMENT	Spare Part	1849	15%
7630	GP3.035.04.0.PR	GROMET FOR ROCKER COVER BOLT	Spare Part	138	15%
7631	GP3.035.05.0.PR	CAP FOR ROCKER COVER BOLT GROMET	Spare Part	209	15%
7632	GP3.035.08.0.PR	GASKET FOR ROCKER COVER	Spare Part	1132	15%
7633	GP3.035.09.0.PR	BOLT FOR ROCKER COVER	Spare Part	145	15%
7634	GP3.035.14.0.PR	GASKET FOR ROCKER COVER	Spare Part	1403	15%
7635	GP3.035.15.0.PR	O RING FOR ROCKER COVER	Spare Part	89	15%
7636	GP3.037.37.0.PR	AIR CLEANER HOSE	Spare Part	695	15%
7637	GP3.037.38.0.PR	HOSE FOR AIR CLEANER	Spare Part	1265	15%
7638	GP3.037.43.0.PR	AIR CLEANER HOSE	Spare Part	1431	15%
7639	GP3.037.78.0.PR	AIR CLEANER HOSE TO TURBO	Spare Part	2191	15%
7640	GP3.038.04.0.PR	JOINT FOR EXHAUST SYSTEM	Spare Part	114	15%
7641	GP3.038.08.0.PR	EXPANSION BELLOW WITH PIPE FROM MANIFOLD TO SILENCER GP3 15KVA	Spare Part	10631	15%
7642	GP3.038.10.0.PR	SILENCER FOR 3R550 2R550	Spare Part	16834	15%
7643	GP3.038.16.0.PR	JOINT EXHAUST BEND	Spare Part	138	15%
7644	GP3.038.66.0.PR	JOINT	Spare Part	625	15%
7645	GP3.039.04.0.PR	FAN FOR R550 RADIATOR DIA 380MM	Spare Part	4889	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer	Custom
		·		without Vat in NPR	Charge%
7646	GP3.041.07.0.PR	PIPE EGR MIXER HOSE TO TURBO	Spare Part	1077	15%
7647	GP3.041.08.0.PR	HOSE	Spare Part	720	15%
7648	GP3.042.02.0.PR	CAC HOSE COLD SIDE	Spare Part	898	15%
7649	GP3.042.05.0.PR	CAC HOSE COLD SIDE	Spare Part	2080	15%
7650	GP3.043.02.0.PR	CAC HOSE HOT SIDE	Spare Part	1320	15%
7651	GP3.043.08.0.PR	HOSE TURBO SIDE	Spare Part	960	15%
7652	GP3.043.14.0.PR	HOSE TURBO SIDE	Spare Part	2877	15%
7653	GP3.043.16.0.PR	CAC HOSE RADIATOR SIDE	Spare Part	1702	15%
7654	GP3.045.81.0.PR	ENGINE MOUNTING FOOT FOR R550	Spare Part	2465	15%
7655	GP3.045.82.0.PR	SPACER BETWEEN ENGINE FOOT CRANK CASE	Spare Part	1209	15%
7656	GP3.046.01.0.PR	GASKET FOR TURBO TO OIL DRAIN PIPE	Spare Part	15	15%
7657	GP3.046.13.0.PR	O RING FOR TURBO OIL SUPPY PIPE ADAPTOR	Spare Part	98	15%
7658	GP3.046.32.0.PR	TURBO OIL SUPPLY PIPE CRANKCASE SIDE	Spare Part	2938	15%
7659	GP3.047.01.0.PR	FUEL FILTER ASSEMBLY	Spare Part	3538	15%
7660	GP3.047.02.0.PR	FUEL PIPE FUEL FILTER TO F I P	Spare Part	495	15%
7661	GP3.047.09.0.PR	FUEL PIPE FTF	Spare Part	1308	15%
7662	GP3.047.11.0.SP	50 Hrs A check Maintenance Kit	Spare Part	7697	20%
7663	GP3.047.14.0.SP	1500 Hrs C Check Maintenance Kit	Spare Part	12062	20%
7664	GP3.047.16.0.PR	FUEL FILTER	Spare Part	6320	15%
7665	GP3.047.55.0.PR	SPINON FUEL FILTER	Spare Part	2710	20%
7666	GP3.048.01.0.PR	LEAK OFF PIPE POLYAMIDE	Spare Part	1726	15%
7667	GP3.048.04.0.PR	LEAK OFF PIPE ASSEMBLY FOR FIP SIDE	Spare Part	3234	15%
7668	GP3.048.05.0.PR	LEAK OFF PIPE ASSEMBLY FOR INJECTOR SIDE	Spare Part	5018	15%
7669	GP3.048.11.0.PR	LEAK OFF PIPE ASSEMBLY FOR FIP SIDE	Spare Part	4231	15%
7670	GP3.049.01.0.PR	COMMON RAIL	Spare Part	27757	15%
7671	GP3.050.02.0.PR	HOSE MIXER TO THROTTLE BODY	Spare Part	600	15%
7672	GP3.050.04.0.PR	GASKET BETWEEN EGR VALVE EGR PIPE	Spare Part	563	15%
7673	GP3.050.05.0.PR	GASKET BETWEEN EGR MIXER AND EGR VALVE	Spare Part	538	15%
7674	GP3.050.09.0.PR	HOSE EGR MIXER TO CAC PIPE	Spare Part	1465	15%
7675	GP3.050.11.0.PR	HOSE EGR VALVE TO CRANKCASE	Spare Part	274	15%
7676	GP3.050.12.0.PR	HOSE EGR VALVE TO CY HEAD	Spare Part	95	15%
7677	GP3.050.14.0.PR	GASKET	Spare Part	886	15%
7678	GP3.050.15.0.PR	HOSE EGR MIXER TO TURBO OUT	Spare Part	3489	15%
7679	GP3.050.22.0.PR	O RING	Spare Part	111	15%
7680	GP3.055.07.0.PR	HOSE EGR VALVE WATER INLET	Spare Part	212	15%
7681	GP3.055.08.0.PR	HOSE EGR VALVE WATER OUTLET	Spare Part	102	15%
7682	GP3.062.02.0.PR	HOSE FOR BREATHER SYSTEM	Spare Part	480	15%
7683	GP3.062.06.0.PR	HOSE FOR BREATHER	Spare Part	342	15%
7684	GP3.100.01.0.PR	CHARGING ALTERNETOR	Spare Part	22169	15%
7685	GP3.100.02.0.PR	3R550 ENGINE ECU AG48	Spare Part	36280	15%
7686	GP3.100.03.0.PR	ECU AG48 SEDEMAC FOR PG SPECIFIC APPLICATION	Spare Part	29224	15%
7687	GP3.107.04.0.PR	HOSE FOR RADIATOR	Spare Part	566	15%
7688	GP3.107.05.0.PR	HOSE FOR RADIATOR	Spare Part	329	15%
7689	GP3.107.06.0.PR	HOSE FROM THERMOSTAT TO RADIATOR	Spare Part	575	15%
7690	GP3.107.12.0.PR	SUCTION HOSE	Spare Part	1249	15%
7691	GP3.107.23.0.PR	RADIATOR FOR R550 GENSET	Spare Part	36316	15%
7692	GP3.107.36.0.PR	HOSE FROM THERMOSTAT TO RADIATOR	Spare Part	920	15%
7693	GP3.108.01.0.PR	FUEL PIPE FROM PRE FILTER TO FEED PUMP	Spare Part	714	15%
7694	GP3.108.05.0.PR	ELECTRIC FEED PUMP AND FUEL FILTER MOUNTING BRACKET	Spare Part	1938	15%
7695	GP3.108.06.0.PR	FUEL PIPE FROM TANK TO FILTER	Spare Part	446	15%
7696	GP3.108.07.0.PR	FUEL TANK UNIT S F 95 EFFECTIVE TANK HEIGHT	Spare Part	2997	15%
7697	GP3.108.14.0.PR	ADAPTOR M16 X 1 5 TO M22 X 1 5	Spare Part	298	15%
7698	GP3.108.141.0.PR	FUEL PIPE FROM TANK TO PRE FILTER	Spare Part	1342	15%
7699	GP3.108.142.0.PR	FUEL PIPE FROM PRE FILTER TO MAIN FILTER	Spare Part	1283	15%
7700	GP3.108.16.0.PR	TOP CLAMP FOR ELECTRIC PUMP	Spare Part	532	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
7701	GP3.108.56.0.PR	FUEL PIPE ELECTRIC PUMP TO TANK UNIT	Spare Part	742	15%
7702	GP3.110.07.0.PR	ANTI VIBRATION MOUNT CORI	Spare Part	2345	15%
7703	GP3.119.05.0.PR	CAN DISPLAY UNIT FOR R550	Spare Part	24738	15%
7704	GP3.210.11.0.PR	CONTROLLER UNIT KG645CR FOR R550	Spare Part	39495	15%
7705	GP3.210.17.0.PR	KG645 C CONTROLLER UNIT R550 SP 3 HARDWARE 12V	Spare Part	40633	15%
7706	GP3.211.10.0.PR	ENGINE WIRING HARNESS FOR 3R550TA CRDI CPCB4	Spare Part	57876	15%
7707	GP3.221.40.0.PR	ELECTRICAL SCHEAMATIC FOR 15KVA 3PH 3R550 WITH KG645C	Spare Part	40664	15%
7708	GP3.221.60.0.PR	ENGINE WIRING HARNESS 3R550 ENGINE WITH AG48 AND KG645C	Spare Part	26095	15%
7709	GP3.901.62.0.PR	KOEL ALTERNATOR 15 KVA 3PH 415V 0 8P F 50 HZ SAE 4 7 5 FRAME KG40 E	Spare Part	148804	15%
7710	GP3.999.02.0.SP	PISTON RING SET	Spare Part	1594	15%
7711	GP3.999.10.0.SP	MAIN BEARING PAIR R550	Spare Part	462	15%
7712	GP3.999.107.0.ESP	FIP TIMING TOOL FOR F SERIES	Spare Part	9117	15%
7713	GP3.999.109.0.SP	BOX TYPE FIP SPANNER 135MM FOR 3R550	Spare Part	3043	15%
7714	GP3.999.11.0.SP	THRUST WASHER SET R550	Spare Part	403	15%
7715	GP3.999.110.0.SP	S TYPE FIP SPANNER FOR 2R550 3R550	Spare Part	1123	15%
7716	GP3.999.111.0.SP	PULLER FOR FIP HUB REMOVAL 2R550 3R550	Spare Part	3741	15%
7717	GP3.999.12.0.SP	CONNECTING ROD BEARING R550	Spare Part	495	15%
7718	GP3.999.18.0.SP	PISTON ASSEMBLY FOR GP3 1009 ENGINE	Spare Part	5403	15%
7719	GP3.999.92.0.SP	BRACKET FOR R550 3 CYL ENGINE	Spare Part	76688	15%
7720	GP4.023.01.0.PR	OIL COOLER	Spare Part	8837	15%
7721	GP4.023.02.0.PR	O RING FOR OIL COOLER	Spare Part	68	15%
7722	GP4.035.11.0.PR	OIL SEPARATOR	Spare Part	3108	15%
7723	H.038.4.00.003	CON ROD BEARING: PAIR RA3	Spare Part	545	15%
7724	H.038.4.00.013	CON ROD BEARING PAIR: RA3	Spare Part	585	15%
7725	H.038.4.00.023	CON ROD BEARING PAIR: RA3	Spare Part	585	15%
7726	H.073.4.00.003	CON ROD BEARING: HA394	Spare Part	766	15%
7727	H.073.4.00.013	CON ROD BEARING: HA394	Spare Part	782	15%
7728	H.073.4.00.023	CON ROD BEARING: HA394	Spare Part	782	15%
7729	H.073.4.00.033	BEARING C/R	Spare Part	822	15%
7730	H.073.4.00.043	BEARING C/R	Spare Part	849	15%
7731	H.073.4.10.003	CON ROD BRG HA394 STD PAIR	Spare Part	782	15%
7732	H.073.4.10.013	CON ROD BEARING HA394 0.25 PAIR	Spare Part	843	15%
7733	H.073.4.10.023	CON ROD BEARING: HA394 020 U/S PAIR NICK	Spare Part	803	15%
7734	H.073.4.10.033	Connecting Rod bearing 030 U/S Pair	Spare Part	849	15%
7735	H.547.4.00.003	CONNECTING ROD BEARING PAIR	Spare Part	3649	15%
7736	H.553.4.00.003	CON ROD BEARING PAIR	Spare Part	6991	15%
7737	K12.001.18.0.PR	O RING FOR SIDE COVER PLATE	Spare Part	1335	15%
7738	K12.001.21.0.PR	O RING FOR SEALING PLUG	Spare Part	348	15%
7739	K12.001.25.0.PR	O RING FOR CAM COVER	Spare Part	335	15%
7740	K12.001.27.0.PR	GASKET FOR TOP COVER PLATE	Spare Part	7338	15%
7741	K12.001.31.0.PR	DOWEL PIN FOR CYLINDER HEAD	Spare Part	117	15%
7742	K12.001.33.0.PR	O RING FOR RELIEF VALVE COVER PLATE	Spare Part	298	15%
7743	K12.002.02.0.PR	O RING	Spare Part	1083	15%
		CYLINDER LINER ASSEMBLY			
7744	K12.002.10.0.PR	O RING FOR CRANK GEAR	Spare Part	26803 289	15%
7745	K12.003.05.0.PR K12.005.10.0.PR	PISTON ASSEMBLY	Spare Part Spare Part	413253	15%
7747	K12.005.10.0.PR	CONNECTING ROD ASSLY WITH SMALL END BUSH	Spare Part	34750	15%
	+	PUSH ROD ASSEMBLY	Spare Part		15%
7748	K12.006.40.0.PR	FULCRUM LEVER ASSEMBLY	Spare Part	1711	
7749	K12.006.50.0.PR			80451	15%
7750	K12.007.13.0.PR	BRIDGE FOR ROCKER ARM	Spare Part	1329	15%
7751	K12.007.15.0.PR	FIRE RING 3 THK FOR CYLINDER HEAD GASKET	Spare Part	2732	15%
7752	K12.007.16.0.PR	FIRE RING 3 25 THK FOR CYLINDER HEAD GASKET	Spare Part	4123	15%
7753	K12.007.18.0.PR	NOZZLE CLAMP	Spare Part	1138	15%
7754	K12.007.21.0.PR	CUP WASHER FOR NOZZLE CLAMP	Spare Part	243	15%



					Price to	
1756 112.007.28.0 PR	Sr.No.	Part Number	Part Description	Category	Customer	Custom
1775 12.007.40.0 PR			·		without Vat in NPR	Charge%
17758 KIZ2007.00.PR CVL HEAD SUB ASSEMBLY WITH SPRING VALVE Spare Part	7756	K12.007.28.0.PR	CYLINDER HEAD GASKET FOR 3 THK FIRE RING	Spare Part	10037	15%
17758 K12.008.00.PR GASKET FOR NOCKER COVER Spee Part	7757	K12.007.32.0.PR	NUT FOR FEED TUBE	Spare Part	2723	15%
17990 KI2.008.02.0 PR GASKET FOR ROCKER COVER Spare Part	7758	K12.007.40.0.PR	CYL HEAD SUB ASSEMBLY WITH SPRING VALVE	Spare Part	105817	15%
17761 K.12011.03.0.PR	7759	K12.008.70.0.PR	ROCKER LEVER ASSEMBLY COMPLETE	Spare Part	20212	15%
17722 1720	7760	K12.009.02.0.PR	GASKET FOR ROCKER COVER	Spare Part	5351	15%
7773 K12012170.0.PR LOP ASSEMBLY WITH GEAR GEAR RATIO 1.4 Spare Part 2 7768 K12013.0.DR O RING FOR LUB OIL PUMP COVER Spare Part 7768 K12013.0.DR O RING FOR SEA WATER PUMP COVER Spare Part Spare Part 7776 K12013.07.0.PR O RING FOR SEA WATER PUMP COVER Spare Part Spare Part 7777 K12013.10.0.PR O RING FOR PULP PUMP COVER PLATE Spare Part Spare Part 7776 K12013.10.0.PR O RING FOR PULP PUMP COVER PLATE Spare Part Spare Part 7778 K12013.10.0.PR O RING FOR PUMP COVER PLATE Spare Part 7778 K12014.00.0.PR O RING FOR PIP GEAR SUPPORT COVER Spare Part 7779 K12014.00.0.PR O RING FOR WATER PUMP SUCTION PIPE Spare Part 7777 K12014.00.0.PR WATER PUMP ASSEMBLY TAPER SHAPT Spare Part Spare Part 7777 K12016.00.0.PR WATER PUMP ASSEMBLY TAPER SHAPT Spare Part 7777 K12016.00.0.PR O RING FOR WATER PUMP SUCTION PIPE COVER PLATE Spare Part Spare Part 7777 K12017.00.0.PR O RING FOR PUMP SHEEM SHEEVE Spare Part Spare Part 7777 K12017.00.0.PR O RING FOR PLATE SH	7761	K12.010.03.0.PR	O RING FOR GEAR CASING	Spare Part	255	15%
1776	7762	K12.011.02.0.PR	O RING FOR INTERMEDIATE DOUBLE GEAR SUPPORT	Spare Part	252	15%
7765 K12.013.05.0 PR O RING FOR SEA WATER PUMP COVER Spare Part 7766 K12.013.07 O.PR O RING FOR FUEL PUMP COVER PLATE Spore Part 7767 K12.013.07 O.PR O RING GO. S. 2.X.11 D. FOR WATER PUMP SLEEVE ASSY Spare Part 7768 K12.013.19.0 PR O RING FOR FIP GEAR SUPPORT COVER Spare Part 7770 K12.014.09.0 PR O RING FOR FIP GEAR SUPPORT COVER Spare Part 7770 K12.014.09.0 PR O RING FOR FIP GEAR SUPPORT COVER Spare Part 7771 K12.014.09.0 PR O RING FOR SUCTION PIPE Spare Part 7777 K12.014.09.0 PR WATER PUMP ASSEMBLY TARPER SHAFT Spare Part 7777 K12.016.05.0 PR O RING FOR SUCTION PIPE COVER PLATE Spare Part 7777 K12.016.05.0 PR O RING FOR SUCTION PIPE COVER PLATE Spare Part 7776 K12.017.02.0 PR O RING FOR THERMOSTAT PUPE SLEEVE Spare Part 7777 K12.017.02.0 PR GASKET BETWEEN THERMOSTAT HOUSING AND GEAR CASING Spare Part 7778 K12.017.10.0 PR O RING FOR THERMOSTAT HOUSING AND GEAR CASING Spare Part <td< td=""><td>7763</td><td>K12.012.170.0.PR</td><td>LOP ASSEMBLY WITH GEAR GEAR RATIO 14</td><td>Spare Part</td><td>216649</td><td>15%</td></td<>	7763	K12.012.170.0.PR	LOP ASSEMBLY WITH GEAR GEAR RATIO 14	Spare Part	216649	15%
1776	7764	K12.012.19.0.PR	O RING FOR LUB OIL PUMP COVER	Spare Part	1249	15%
	7765	K12.013.05.0.PR	O RING FOR SEA WATER PUMP COVER	Spare Part	348	15%
7768 K12.013.19.0 PR O RING FOR FIP GEAR SUPPORT COVER Spare Part 7769 K12.014.08.0 PR O RING SW HOUSING AND FORNT COVER Spare Part 7777 K12.014.09.0 PR O RING FOR WATER PUMP SUCTION PIPE Spare Part 7771 K12.015.02.0 PR GASKET FOR WATER PUMP VOLUTE Spare Part 7773 K12.016.03.0 PR O RING FOR WATER PUMP VOLUTE Spare Part 7774 K12.016.03.0 PR O RING FOR WATER PUMP VOLUTE Spare Part 7774 K12.016.03.0 PR O RING FOR THERMOSTAT FURTH Spare Part 7775 K12.017.02.0 PR O RING FOR THERMOSTAT PIPE SLEEVE Spare Part 7776 K12.017.03.0 PR O RING FOR THERMOSTAT HOUSING AND GEAR CASING Spare Part 7777 K12.017.00.0 PR O RING FOR THERMOSTAT Spare Part 7778 K12.017.13.0 PR O RING FOR THERMOSTAT HOUSING Spare Part 7779 K12.018.02.0 PR FILTER HEADER O RING Spare Part 7778 K12.018.02.0 PR FILTER HEADER O RING Spare Part 7781 K12.018.03.0 PR GASKET FOR OIL AND COOLER HEA	7766	K12.013.07.0.PR	O RING FOR FUEL PUMP COVER PLATE	Spare Part	302	15%
1776	7767	K12.013.12.0.PR	O RING C S 2 X 11 ID FOR WATER PUMP SLEEVE ASSY	Spare Part	252	15%
7777 K12014.08.0.PR O RING FOR WATER PUMP ASSEMBLY Spare Part 7771 K12014.60.0.PR WATER PUMP ASSEMBLY Spare Part 7772 K12.016.00.PR WATER PUMP ASSEMBLY Spare Part 7773 K12.016.03.0.PR O RING FOR SUCTION PIPE COVER PLATE Spare Part 7774 K12.016.03.0.PR O RING FOR THERMOSTAT PIPE SLEEVE Spare Part 7775 K12.017.03.0.PR O RING FOR THERMOSTAT PIPE SLEEVE Spare Part 7776 K12.017.00.0.PR O RING FOR THERMOSTAT HOUSING AND GEAR CASING Spare Part 7777 K12.017.00.0.PR O RING FOR THERMOSTAT HOUSING Spare Part 7778 K12.017.13.0.PR O RING FOR THERMOSTAT HOUSING Spare Part 7779 K12.018.03.0.PR GASKET FOR THERMOSTAT HOUSING Spare Part 7780 K12.018.03.0.PR O RING FOR SLEEVE FOR OIL AND COOLER HEADER Spare Part 7781 K12.018.03.0.PR O RING FOR SLEEVE FOR OIL AND COOLER HEADER Spare Part 7782 K12.018.03.0.PR O RING FOR OIL COOLER Spare Part 7783 K12.018.03.0.PR O RI	7768	K12.013.19.0.PR	O RING FOR FIP GEAR SUPPORT COVER	Spare Part	1637	15%
7777 K12014.08.0.PR O RING FOR WATER PUMP ASSEMBLY Spare Part 7771 K12014.60.0.PR WATER PUMP ASSEMBLY Spare Part 7772 K12.016.00.PR WATER PUMP ASSEMBLY Spare Part 7773 K12.016.03.0.PR O RING FOR SUCTION PIPE COVER PLATE Spare Part 7774 K12.016.03.0.PR O RING FOR THERMOSTAT PIPE SLEEVE Spare Part 7775 K12.017.03.0.PR O RING FOR THERMOSTAT PIPE SLEEVE Spare Part 7776 K12.017.00.0.PR O RING FOR THERMOSTAT HOUSING AND GEAR CASING Spare Part 7777 K12.017.00.0.PR O RING FOR THERMOSTAT HOUSING Spare Part 7778 K12.017.13.0.PR O RING FOR THERMOSTAT HOUSING Spare Part 7779 K12.018.03.0.PR GASKET FOR THERMOSTAT HOUSING Spare Part 7780 K12.018.03.0.PR O RING FOR SLEEVE FOR OIL AND COOLER HEADER Spare Part 7781 K12.018.03.0.PR O RING FOR SLEEVE FOR OIL AND COOLER HEADER Spare Part 7782 K12.018.03.0.PR O RING FOR OIL COOLER Spare Part 7783 K12.018.03.0.PR O RI	7769	K12.014.08.0.PR	O RING BW HOUSING AND FORNT COVER	Spare Part	255	15%
7772 K12.015.02.0 PR GASKET FOR WATER PUMP VOLUTE Spare Part 7773 K12.016.03.0 PR O RING FOR SUCTION PIPE COVER PLATE Spare Part 7774 K12.016.05.0 PR O RING FOR THERMOSTAT PIPE SLEEVE Spare Part 7775 K12.017.02.0 PR THERMOSTAT PIPE SLEEVE Spare Part 7776 K12.017.03.0 PR O RING FOR THERMOSTAT HOUSING AND GEAR CASING Spare Part 7777 K12.017.12.0 PR O RING FOR THERMOSTAT HOUSING Spare Part 7778 K12.017.13.0 PR O RING FOR THERMOSTAT HOUSING Spare Part 7770 K12.018.02.0 PR GASKET FOR THERMOSTAT HOUSING Spare Part 7780 K12.018.02.0 PR FILTER HEADER O RING Spare Part 7781 K12.018.03.0 PR GASKET FOR LUB OIL HEADER Spare Part 7782 K12.018.00.0 PR GASKET FOR OIL COOLER Spare Part 7783 K12.018.00.0 PR GASKET FOR OIL COOLER Spare Part 7784 K12.018.13.0 PR O RING FOR OIL COOLER Spare Part 7785 K12.018.13.0 PR O RING FOR OIL COOLER Spare Part<	7770		O RING FOR WATER PUMP SUCTION PIPE	Spare Part	234	15%
7773 K12016.03.0 PR	7771	K12.014.60.0.PR	WATER PUMP ASSEMBLY TAPER SHAFT	Spare Part	79620	15%
7774 K12016.05.0.PR O RING FOR THERMOSTAT PIPE SLEEVE Spare Part 7775 K12017.02.0.PR THERMOSTAT Spare Part 7776 K12017.06.0.PR GASKET BETWEEN THERMOSTAT TOUSING AND GEAR CASING Spare Part 7777 K12017.07.0.PR O RING FOR THERMOSTAT OUT ADAPTOR Spare Part 7778 K12017.12.0.PR O RING FOR THERMOSTAT OUT ADAPTOR Spare Part 7779 K12018.02.0.PR GASKET FOR THERMOSTAT HOUSING Spare Part 7780 K12018.02.0.PR GASKET FOR THERMOSTAT HOUSING Spare Part 7781 K12018.05.0.PR GASKET FOR RING Spare Part 7782 K12018.05.0.PR GASKET FOR ULGOOLER Spare Part 7783 K12018.09.PR GASKET FOR OIL COOLER Spare Part 7784 K12018.09.PR GASKET FOR OIL COOLER Spare Part 7785 K12018.13.0.PR O IL COOLER Spare Part 7786 K12018.13.0.PR DOME NUT OR RING FOR OIL COOLER Spare Part 7788 K12018.13.0.PR DOME NUT OR RING FOR OIL COOLER Spare Part	7772	K12.015.02.0.PR	GASKET FOR WATER PUMP VOLUTE	Spare Part	7468	15%
7775 K12.017.02.0.PR THERMOSTAT Spare Part 7776 K12.017.06.0.PR GASKET BETWEEN THERMOSTAT Spare Part 7777 K12.017.07.0.PR O RING FOR THERMOSTAT Spare Part 7778 K12.017.12.0.PR O RING FOR THERMOSTAT OUT ADAPTOR Spare Part 7778 K12.017.13.0.PR GASKET FOR THERMOSTAT HOUSING Spare Part 7780 K12.018.02.0.PR FILTER HEADER O RING Spare Part 7781 K12.018.02.0.PR FILTER HEADER O RING Spare Part 7781 K12.018.05.0.PR O RING FOR SLEEVE FOR OIL AND COOLER HEADER Spare Part 7782 K12.018.09.0.PR GASKET FOR LUB OIL HEADER Spare Part 7783 K12.018.09.0.PR GASKET FOR OIL COOLER Spare Part 7784 K12.018.13.0.PR O RING FOR OIL COOLER Spare Part 7785 K12.018.13.0.PR O RING FOR OIL COOLER Spare Part 7786 K12.018.13.0.PR O RING FOR OIL COOLER Spare Part 7787 K12.018.13.0.PR O RING FOR OIL COOLER Spare Part 7788	7773	K12.016.03.0.PR	O RING FOR SUCTION PIPE COVER PLATE	Spare Part	243	15%
7775 K12.017.02.0.PR THERMOSTAT Spare Part 7776 K12.017.06.0.PR GASKET BETWEEN THERMOSTAT HOUSING AND GEAR CASING Spare Part 7777 K12.017.07.0.PR O RING FOR THERMOSTAT Spare Part 7778 K12.017.12.0.PR O RING FOR THERMOSTAT OUT ADAPTOR Spare Part 7779 K12.017.13.0.PR GASKET FOR THERMOSTAT HOUSING Spare Part 7780 K12.018.02.0.PR GLITER HEADER O RING Spare Part 7781 K12.018.05.0.PR O RING FOR SLEEVE FOR OIL AND COOLER HEADER Spare Part 7781 K12.018.06.0.PR GASKET FOR LUB OIL HEADER Spare Part 7782 K12.018.09.0.PR GASKET FOR OIL COOLER HEADER COVER Spare Part 7784 K12.018.13.0.PR O RING FOR OIL COOLER Spare Part 7785 K12.018.13.0.PR O RING FOR OIL COOLER Spare Part 7786 K12.018.13.0.PR O RING FOR OIL COOLER Spare Part 7787 K12.019.30.0.PR GASKET FOR SPASS FILTER Spare Part 7788 K12.0218.10.0.PR FUEL INJECTION PUMP LHS Spare Part	7774	K12.016.05.0.PR	O RING FOR THERMOSTAT PIPE SLEEVE	Spare Part	234	15%
7776 K12.017.06.0.PR GASKET BETWEEN THERMOSTAT HOUSING AND GEAR CASING Spare Part 7777 K12.017.07.0.PR O RING FOR THERMOSTAT Spare Part 7778 K12.017.12.0.PR O RING FOR THERMOSTAT OUT ADAPTOR Spare Part 7779 K12.017.13.0.PR GASKET FOR THERMOSTAT HOUSING Spare Part 7780 K12.018.02.0.PR FILTER HEADER O RING Spare Part 7781 K12.018.05.0.PR GING FOR SLEEVE FOR OIL AND COOLER HEADER Spare Part 7782 K12.018.06.0.PR GASKET FOR UB OIL HEADER Spare Part 7783 K12.018.09.PR GASKET FOR UB OIL COOLER HEADER COVER Spare Part 7784 K12.018.09.0.PR GASKET FOR OIL COOLER Spare Part 7785 K12.018.13.0.PR OIL COOLER Spare Part 7786 K12.018.15.0.PR DOME NUT O RING FOR OIL COOLER Spare Part 7787 K12.019.03.0.PR GASKET FOR BYPASS FILTER Spare Part 7788 K12.021.10.PR PILE LILIER SPIN ON Spare Part 7798 K12.022.00.0.PR FUEL ILIER ASSEMBLY Spare Part	7775	K12.017.02.0.PR		Spare Part	5449	15%
7777 K12.017.07.0.PR O RING FOR THERMOSTAT Spare Part 7778 K12.017.12.0.PR O RING FOR THERMOSTAT OUT ADAPTOR Spare Part 7779 K12.017.12.0.PR O RING FOR THERMOSTAT HOUSING Spare Part 7780 K12.018.02.0.PR FILTER HEADER O RING Spare Part 7781 K12.018.05.0.PR O RING FOR SLEEVE FOR OIL AND COOLER HEADER Spare Part 7782 K12.018.06.0.PR GASKET FOR ULB OIL HEADER Spare Part 7783 K12.018.09.0.PR OIL COOLER Spare Part 7784 K12.018.13.0.PR OIL COOLER Spare Part 7785 K12.018.13.0.PR OIL COOLER Spare Part 7786 K12.018.13.0.PR O RING FOR OIL COOLER Spare Part 7786 K12.018.13.0.PR O RING FOR OIL COOLER Spare Part 7787 K12.019.03.0.PR GASKET FOR BYEASS FLITER Spare Part 7788 K12.019.03.0.PR GASKET FOR RYEASS FLITER Spare Part 7789 K12.021.00.0.PR FUEL FILTER SEMBLY Spare Part 7788 K12.021.10.0					9098	15%
7778 K12.017.12.0.PR O RING FOR THERMOSTAT OUT ADAPTOR Spare Part 7779 K12.017.13.0.PR GASKET FOR THERMOSTAT HOUSING Spare Part 7780 K12.018.02.0.PR GENERAL FRENDER OR RING Spare Part 7781 K12.018.05.0.PR O RING FOR SLEEVE FOR OIL AND COOLER HEADER Spare Part 7782 K12.018.05.0.PR GASKET FOR LUB OIL HEADER Spare Part 7783 K12.018.09.0.PR GASKET FOR OIL COOLER Spare Part 7784 K12.018.13.0.PR GASKET FOR OIL COOLER Spare Part 7785 K12.018.13.0.PR O RING FOR OIL COOLER Spare Part 7786 K12.018.15.0.PR DOME NUT O RING FOR OIL COOLER Spare Part 7786 K12.018.15.0.PR DOME NUT O RING FOR OIL COOLER Spare Part 7787 K12.019.03.0.PR GASKET FOR BYPASS FILTER Spare Part 7788 K12.020.10.0.PR FUEL INJECTION PUMP LIHS Spare Part 7789 K12.021.10.0.PR FIP FOR K12 N16299M RHS FROM GEAR END Spare Part 7799 K12.021.10.0.PR FUEL FILTER SEMBLY Spare Part<	-		O RING FOR THERMOSTAT	•	271	15%
7779 K12.017.13.0.PR GASKET FOR THERMOSTAT HOUSING Spare Part					252	15%
7780 K12.018.02.0.PR FILTER HEADER O RING Spare Part 7781 K12.018.05.0.PR O RING FOR SLEEVE FOR OIL AND COOLER HEADER Spare Part 7782 K12.018.06.0.PR GASKET FOR LUB OIL HEADER Spare Part 7783 K12.018.09.0.PR GASKET FOR OIL COOLER Spare Part 7784 K12.018.19.0.PR OIL COOLER Spare Part 7785 K12.018.15.0.PR O RING FOR OIL COOLER Spare Part 7786 K12.018.15.0.PR DOME NUT O RING FOR OIL COOLER Spare Part 7787 K12.018.15.0.PR DOME NUT O RING FOR OIL COOLER Spare Part 7788 K12.019.03.0.PR GASKET FOR BYPASS FILTER Spare Part 7788 K12.020.10.0.PR FUEL INJECTION PUMP LHS Spare Part 25 7789 K12.022.10.0.PR FUEL RIJECT ASSEMBLY Spare Part 25 7789 K12.022.00.0.PR FUEL FILTER ASSEMBLY Spare Part 25 7790 K12.022.00.0.PR FUEL FILTER SPIN ON Spare Part 27 7791 K12.022.00.0.PR FUEL FILTER SPIN ON <td></td> <td>K12.017.13.0.PR</td> <td></td> <td></td> <td>7455</td> <td>15%</td>		K12.017.13.0.PR			7455	15%
7781 K12.018.05.0.PR O RING FOR SLEEVE FOR OIL AND COOLER HEADER Spare Part 7782 K12.018.06.0.PR GASKET FOR LUB OIL HEADER Spare Part 7783 K12.018.09.0.PR GASKET FOR OIL COOLER HEADER COVER Spare Part 7784 K12.018.15.0.PR OIL COOLER Spare Part 7785 K12.018.15.0.PR ORING FOR OIL COOLER Spare Part 7786 K12.018.15.0.PR DOME NUT O RING FOR OIL COOLER Spare Part 7787 K12.018.15.0.PR DOME NUT O RING FOR OIL COOLER Spare Part 7788 K12.021.10.3.0.PR GASKET FOR BYPASS FILTER Spare Part 7789 K12.020.10.0.PR FUEL INJECTION PUMP LHS Spare Part 25 7789 K12.022.10.0.PR FUEL FILTER SPIN ON Spare Part 25 7790 K12.022.00.0.PR FUEL FILTER SPIN ON Spare Part Spare Part 7791 K12.022.00.0.PR FUEL FILTER SPIN ON Spare Part Spare Part 7793 K12.023.03.0.PR GASKET FOR INLET MANIFOLD Spare Part 7794 K12.023.03.0.PR				•	517	15%
7782 K12.018.06.0.PR GASKET FOR LUB OIL HEADER Spare Part 7783 K12.018.09.0.PR GASKET FOR OIL COOLER Spare Part 7785 K12.018.12.0.PR OIL COOLER Spare Part 7786 K12.018.13.0.PR O RING FOR OIL COOLER Spare Part 7786 K12.018.13.0.PR DOME NUT O RING FOR OIL COOLER Spare Part 7787 K12.019.03.0.PR GASKET FOR BYPASS FILTER Spare Part 7788 K12.020.10.0.PR FUEL INJECTION PUMP LHS Spare Part 7789 K12.021.10.0.PR FUEL FILTER ASSEMBLY Spare Part 7790 K12.022.02.0.PR FUEL FILTER ASSEMBLY Spare Part 7791 K12.022.03.0.PR BRACKET FOR FLEETGUARD FUEL FILTER Spare Part 7792 K12.022.07.0.PR FUEL FILTER SPIN ON Spare Part 7793 K12.023.03.0.PR GASKET FOR COVER PLATE Spare Part 7794 K12.023.05.0.PR ORING S C 4 X 145 ID Spare Part 7795 K12.023.05.0.PR ORING S C A X 145 ID Spare Part 7794 K12.025.04.0					292	15%
7783 K12.018.09.0 PR GASKET FOR OIL COOLER HEADER COVER Spare Part 7784 K12.018.12.0 PR OIL COOLER Spare Part 7786 K12.018.13.0 PR O RING FOR OIL COOLER Spare Part 7786 K12.018.15.0 PR DOME NUT O RING FOR OIL COOLER Spare Part 7787 K12.019.03.0 PR GASKET FOR BYPASS FILTER Spare Part 7788 K12.020.10.0 PR FUEL INJECTION PUMP LHS Spare Part 7789 K12.021.10.0 PR FUEL FILTER ASSEMBLY Spare Part 7790 K12.022.00.0 PR FUEL FILTER ASSEMBLY Spare Part 7791 K12.022.07.0 PR FUEL FILTER SPIN ON Spare Part 7792 K12.022.07.0 PR FUEL FILTER SPIN ON Spare Part 7793 K12.023.03.0 PR GASKET FOR COVER PLATE Spare Part 7794 K12.023.13.0 PR GASKET FOR INLET MANIFOLD Spare Part 7795 K12.023.13.0 PR GASKET FOR INLET MANIFOLD Spare Part 7796 K12.023.10.0 PR HOSE FOR CAC PIPE ID 151 X ID 151 Spare Part 7797				•	9418	15%
7784 K12.018.12.0.PR OIL COOLER Spare Part 7785 K12.018.13.0.PR O RING FOR OIL COOLER Spare Part 7786 K12.018.15.0.PR DOME NUT O RING FOR OIL COOLER Spare Part 7787 K12.019.03.0.PR GASKET FOR BYPASS FILTER Spare Part 7788 K12.020.10.0.PR FUEL INJECTION PUMP LHS Spare Part 25 7789 K12.021.10.0.PR FUEL FILTER ASSEMBLY Spare Part 25 7790 K12.022.02.0.PR FUEL FILTER ASSEMBLY Spare Part 25 7791 K12.022.03.0.PR BRACKET FOR FLEETGUARD FUEL FILTER Spare Part 25 7791 K12.022.03.0.PR GASKET FOR COVER PLATE Spare Part 35 35 36 <t< td=""><td></td><td></td><td></td><td>•</td><td>11074</td><td>15%</td></t<>				•	11074	15%
7785 K12.018.13.0.PR O RING FOR OIL COOLER Spare Part 7786 K12.018.15.0.PR DOME NUT O RING FOR OIL COOLER Spare Part 7787 K12.019.03.0.PR GASKET FOR BYPASS FILTER Spare Part 7788 K12.020.10.0.PR FUEL INJECTION PUMP LHS Spare Part 7789 K12.022.10.0.PR FUEL INJECTION PUMP LHS Spare Part 7790 K12.022.02.0.PR FUEL FILTER ASSEMBLY Spare Part 7791 K12.022.02.0.PR FUEL FILTER ASSEMBLY Spare Part 7792 K12.022.07.0.PR FUEL FILTER SPIN ON Spare Part 7793 K12.023.03.0.PR GASKET FOR COVER PLATE Spare Part 7794 K12.023.03.0.PR GASKET FOR COVER PLATE Spare Part 7795 K12.023.13.0.PR GASKET FOR CAC PIPE ID 151 X ID 151 Spare Part 7796 K12.023.61.0.PR HOSE FOR CAC PIPE ID 151 X ID 151 Spare Part 7797 K12.025.04.0.PR EXPANSION BELLOW Spare Part 7798 K12.025.09.0.PR JOINT BET EXH MANIFOLD Spare Part 7800					58421	15%
7786 K12.018.15.0.PR DOME NUT O RING FOR OIL COOLER Spare Part 7787 K12.019.03.0.PR GASKET FOR BYPASS FILTER Spare Part 7788 K12.020.10.0.PR FUEL INJECTION PUMP LHS Spare Part 25 7789 K12.021.10.0.PR FUEL FILTER ASSEMBLY Spare Part 25 7790 K12.022.02.0.PR FUEL FILTER ASSEMBLY Spare Part Spare Part 7791 K12.022.07.0.PR FUEL FILTER SPIN ON Spare Part 7792 K12.022.07.0.PR FUEL FILTER SPIN ON Spare Part 7793 K12.023.03.0.PR GASKET FOR COVER PLATE Spare Part 7794 K12.023.31.0.PR GASKET FOR INLET MANIFOLD Spare Part 7795 K12.023.13.0.PR GASKET FOR INLET MANIFOLD Spare Part 7796 K12.023.61.0.PR HOSE FOR CAC PIPE ID 151 X ID 151 Spare Part 7797 K12.025.04.0.PR EXPANSION BELLOW Spare Part 7798 K12.025.09.0.PR JOINT BET EXH MANIFOLD Spare Part 7799 K12.025.09.0.PR JOINT BET WEEN TURBOCHARGER AND EXH MANIFO				•	283	15%
7787 K12.019.03.0.PR GASKET FOR BYPASS FILTER Spare Part 7788 K12.020.10.0.PR FUEL INJECTION PUMP LHS Spare Part 25 7789 K12.021.10.0.PR FIP FOR K12 N16299M RHS FROM GEAR END Spare Part 25 7790 K12.022.02.0.PR FUEL FILTER ASSEMBLY Spare Part 5pare Part 7791 K12.022.07.0.PR FUEL FILTER SPIN ON Spare Part 5pare Part 7792 K12.022.07.0.PR FUEL FILTER SPIN ON Spare Part 5pare Part 7793 K12.023.03.0.PR GASKET FOR COVER PLATE Spare Part 7794 K12.023.03.0.PR GASKET FOR INLET MANIFOLD Spare Part 7795 K12.023.03.0.PR GASKET FOR INLET MANIFOLD Spare Part 7796 K12.023.61.0.PR HOSE FOR CAC PIPE ID 151 X ID 151 Spare Part 7797 K12.025.04.0.PR EXPANSION BELLOW Spare Part 7798 K12.025.06.0.PR GASKET BETWEEN HEAD EXH MANIFOLD Spare Part 7799 K12.025.0.0.PR JOINT BET EXH MANIFOLD EXPA BELLOW Spare Part 7800 K12.025.5.0.PR JOINT BETWEEN					323	15%
7788 K12.020.10.0.PR FUEL INJECTION PUMP LHS Spare Part 25 7789 K12.021.10.0.PR FIP FOR K12 N16299M RHS FROM GEAR END Spare Part 25 7790 K12.022.02.0.PR FUEL FILTER ASSEMBLY Spare Part 7791 K12.022.06.0.PR BRACKET FOR FLEETGUARD FUEL FILTER Spare Part 7792 K12.022.07.0.PR FUEL FILTER SPIN ON Spare Part 7793 K12.023.03.0.PR GASKET FOR COVER PLATE Spare Part 7794 K12.023.05.0.PR O RING S C 4 X 145 ID Spare Part 7795 K12.023.013.0.PR GASKET FOR INLET MANIFOLD Spare Part 7796 K12.023.61.0.PR HOSE FOR CAC PIPE ID 151 X ID 151 Spare Part 7797 K12.025.04.0.PR EXPANSION BELLOW Spare Part 7798 K12.025.04.0.PR GASKET BETWEEN HEAD EXH MANIFOLD Spare Part 7799 K12.025.00.0.PR JOINT BET EXH MANIFOLD EXPA BELLOW Spare Part 7800 K12.025.01.0.PR JOINT BETWEEN TURBOCHARGER AND EXH MANIFOLD Spare Part 7801 K12.026.36.0.PR OIL SUPPLY PIPE FOR TEL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER LHS	-			•	5951	15%
7789 K12.021.10.0.PR FIP FOR K12 N16299M RHS FROM GEAR END Spare Part 25 7790 K12.022.02.0.PR FUEL FILTER ASSEMBLY Spare Part 7791 K12.022.06.0.PR BRACKET FOR FLEETGUARD FUEL FILTER Spare Part 7792 K12.022.07.0.PR FUEL FILTER SPIN ON Spare Part 7793 K12.023.03.0.PR GASKET FOR COVER PLATE Spare Part 7794 K12.023.05.0.PR O RING S C 4 X 145 ID Spare Part 7795 K12.023.13.0.PR GASKET FOR INLET MANIFOLD Spare Part 7796 K12.023.61.0.PR HOSE FOR CAC PIPE ID 151 X ID 151 Spare Part 7797 K12.025.04.0.PR EXPANSION BELLOW Spare Part 7798 K12.025.04.0.PR GASKET BETWEEN HEAD EXH MANIFOLD Spare Part 7799 K12.025.09.0.PR JOINT BET EXH MANIFOLD EXPA BELLOW Spare Part 7800 K12.025.11.0.PR JOINT BETWEEN TURBOCHARGER AND EXH MANIFOLD Spare Part 7801 K12.026.25.0.PR OIL SUPPLY PIPE FOR TELL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBO				•	2500059	15%
7790 K12.022.02.0.PR FUEL FILTER ASSEMBLY Spare Part 7791 K12.022.06.0.PR BRACKET FOR FLEETGUARD FUEL FILTER Spare Part 7792 K12.022.07.0.PR FUEL FILTER SPIN ON Spare Part 7793 K12.023.03.0.PR GASKET FOR COVER PLATE Spare Part 7794 K12.023.05.0.PR O RING S C 4 X 145 ID Spare Part 7795 K12.023.13.0.PR GASKET FOR INLET MANIFOLD Spare Part 7796 K12.023.61.0.PR HOSE FOR CAC PIPE ID 151 X ID 151 Spare Part 7797 K12.025.04.0.PR EXPANSION BELLOW Spare Part 7798 K12.025.04.0.PR GASKET BETWEEN HEAD EXH MANIFOLD Spare Part 7799 K12.025.09.0.PR JOINT BET EXH MANIFOLD EXPA BELLOW Spare Part 7800 K12.025.11.0.PR JOINT BETWEEN TURBOCHARGER AND EXH MANIFOLD Spare Part 7801 K12.026.25.0.PR OIL SUPPLY PIPE FOR TEL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER LHS FROM FWE Spare Part 7803 K12.026.38.0.PR O RING B W ADAPTOR TU					2500059	15%
7791 K12.022.06.0.PR BRACKET FOR FLEETGUARD FUEL FILTER Spare Part 7792 K12.022.07.0.PR FUEL FILTER SPIN ON Spare Part 7793 K12.023.03.0.PR GASKET FOR COVER PLATE Spare Part 7794 K12.023.05.0.PR O RING S C 4 X 145 ID Spare Part 7795 K12.023.13.0.PR GASKET FOR INLET MANIFOLD Spare Part 7796 K12.023.61.0.PR HOSE FOR CAC PIPE ID 151 X ID 151 Spare Part 7797 K12.025.04.0.PR EXPANSION BELLOW Spare Part 7798 K12.025.04.0.PR GASKET BETWEEN HEAD EXH MANIFOLD Spare Part 7799 K12.025.09.0.PR JOINT BET EXH MANIFOLD EXPA BELLOW Spare Part 7800 K12.025.11.0.PR JOINT BETWEEN TURBOCHARGER AND EXH MANIFOLD Spare Part 7801 K12.026.25.0.PR OIL SUPPLY PIPE FOR TEL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER Spare Part 7803 K12.026.38.0.PR O RING B W ADAPTOR TURBOCHARGER Spare Part 7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM </td <td></td> <td></td> <td></td> <td>•</td> <td>15874</td> <td>15%</td>				•	15874	15%
7792 K12.022.07.0.PR FUEL FILTER SPIN ON Spare Part 7793 K12.023.03.0.PR GASKET FOR COVER PLATE Spare Part 7794 K12.023.05.0.PR O RING S C 4 X 145 ID Spare Part 7795 K12.023.13.0.PR GASKET FOR INLET MANIFOLD Spare Part 7796 K12.023.61.0.PR HOSE FOR CAC PIPE ID 151 X ID 151 Spare Part 7797 K12.025.04.0.PR EXPANSION BELLOW Spare Part 7798 K12.025.06.0.PR GASKET BETWEEN HEAD EXH MANIFOLD Spare Part 7799 K12.025.09.0.PR JOINT BET EXH MANIFOLD EXPA BELLOW Spare Part 7800 K12.025.11.0.PR JOINT BETWEEN TURBOCHARGER AND EXH MANIFOLD Spare Part 7801 K12.026.25.0.PR OIL SUPPLY PIPE FOR TEL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER LHS FROM FWE Spare Part 7803 K12.026.38.0.PR O RING B W ADAPTOR TURBOCHARGER Spare Part 7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM Spare Part 7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DE					7674	15%
7793 K12.023.03.0.PR GASKET FOR COVER PLATE Spare Part 7794 K12.023.05.0.PR O RING S C 4 X 145 ID Spare Part 7795 K12.023.13.0.PR GASKET FOR INLET MANIFOLD Spare Part 7796 K12.023.61.0.PR HOSE FOR CAC PIPE ID 151 X ID 151 Spare Part 7797 K12.025.04.0.PR EXPANSION BELLOW Spare Part 7798 K12.025.06.0.PR GASKET BETWEEN HEAD EXH MANIFOLD Spare Part 7799 K12.025.09.0.PR JOINT BET EXH MANIFOLD EXPA BELLOW Spare Part 7800 K12.025.11.0.PR JOINT BETWEEN TURBOCHARGER AND EXH MANIFOLD Spare Part 7801 K12.026.25.0.PR OIL SUPPLY PIPE FOR TEL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER LHS FROM FWE Spare Part 7803 K12.026.38.0.PR O RING B W ADAPTOR TURBOCHARGER Spare Part 7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM Spare Part 7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DEG FOR 1500 RPM Spare Part 7806 K12.026.59.0.PR JOINT		K12.022.07.0.PR			5342	20%
7794 K12.023.05.0.PR O RING S C 4 X 145 ID Spare Part 7795 K12.023.13.0.PR GASKET FOR INLET MANIFOLD Spare Part 7796 K12.023.61.0.PR HOSE FOR CAC PIPE ID 151 X ID 151 Spare Part 7797 K12.025.04.0.PR EXPANSION BELLOW Spare Part 7798 K12.025.06.0.PR GASKET BETWEEN HEAD EXH MANIFOLD Spare Part 7799 K12.025.09.0.PR JOINT BET EXH MANIFOLD EXPA BELLOW Spare Part 7800 K12.025.11.0.PR JOINT BETWEEN TURBOCHARGER AND EXH MANIFOLD Spare Part 7801 K12.026.25.0.PR OIL SUPPLY PIPE FOR TEL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER LHS FROM FWE Spare Part 7803 K12.026.38.0.PR O RING B W ADAPTOR TURBOCHARGER Spare Part 7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM Spare Part 7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DEG FOR 1500 RPM Spare Part 7806 K12.026.59.0.PR JOINT BETWEEN T C AND DRAIN PIPE Spare Part					3800	15%
7795 K12.023.13.0.PR GASKET FOR INLET MANIFOLD Spare Part 7796 K12.023.61.0.PR HOSE FOR CAC PIPE ID 151 X ID 151 Spare Part 7797 K12.025.04.0.PR EXPANSION BELLOW Spare Part 7798 K12.025.06.0.PR GASKET BETWEEN HEAD EXH MANIFOLD Spare Part 7799 K12.025.09.0.PR JOINT BET EXH MANIFOLD EXPA BELLOW Spare Part 7800 K12.025.11.0.PR JOINT BETWEEN TURBOCHARGER AND EXH MANIFOLD Spare Part 7801 K12.026.25.0.PR OIL SUPPLY PIPE FOR TEL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER LHS FROM FWE Spare Part 7803 K12.026.38.0.PR O RING B W ADAPTOR TURBOCHARGER Spare Part 7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM Spare Part 7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DEG FOR 1500 RPM Spare Part 7806 K12.026.59.0.PR JOINT BETWEEN T C AND DRAIN PIPE Spare Part					468	15%
7796 K12.023.61.0.PR HOSE FOR CAC PIPE ID 151 X ID 151 Spare Part 7797 K12.025.04.0.PR EXPANSION BELLOW Spare Part 7798 K12.025.06.0.PR GASKET BETWEEN HEAD EXH MANIFOLD Spare Part 7799 K12.025.09.0.PR JOINT BET EXH MANIFOLD EXPA BELLOW Spare Part 7800 K12.025.11.0.PR JOINT BETWEEN TURBOCHARGER AND EXH MANIFOLD Spare Part 7801 K12.026.25.0.PR OIL SUPPLY PIPE FOR TEL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER LHS FROM FWE Spare Part 7803 K12.026.38.0.PR O RING B W ADAPTOR TURBOCHARGER Spare Part 7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM Spare Part 7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DEG FOR 1500 RPM Spare Part 7806 K12.026.59.0.PR JOINT BETWEEN T C AND DRAIN PIPE Spare Part				•	4261	15%
7797 K12.025.04.0.PR EXPANSION BELLOW Spare Part 7798 K12.025.06.0.PR GASKET BETWEEN HEAD EXH MANIFOLD Spare Part 7799 K12.025.09.0.PR JOINT BET EXH MANIFOLD EXPA BELLOW Spare Part 7800 K12.025.11.0.PR JOINT BETWEEN TURBOCHARGER AND EXH MANIFOLD Spare Part 7801 K12.026.25.0.PR OIL SUPPLY PIPE FOR TEL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER LHS FROM FWE Spare Part 7803 K12.026.38.0.PR O RING B W ADAPTOR TURBOCHARGER Spare Part 7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM Spare Part 7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DEG FOR 1500 RPM Spare Part 7806 K12.026.59.0.PR JOINT BETWEEN T C AND DRAIN PIPE Spare Part					8034	15%
7798 K12.025.06.0.PR GASKET BETWEEN HEAD EXH MANIFOLD Spare Part 7799 K12.025.09.0.PR JOINT BET EXH MANIFOLD EXPA BELLOW Spare Part 7800 K12.025.11.0.PR JOINT BETWEEN TURBOCHARGER AND EXH MANIFOLD Spare Part 7801 K12.026.25.0.PR OIL SUPPLY PIPE FOR TEL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER LHS FROM FWE Spare Part 7803 K12.026.38.0.PR O RING B W ADAPTOR TURBOCHARGER Spare Part 7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM Spare Part 7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DEG FOR 1500 RPM Spare Part 7806 K12.026.59.0.PR JOINT BETWEEN T C AND DRAIN PIPE Spare Part					29723	15%
7799 K12.025.09.0.PR JOINT BET EXH MANIFOLD EXPA BELLOW Spare Part 7800 K12.025.11.0.PR JOINT BETWEEN TURBOCHARGER AND EXH MANIFOLD Spare Part 7801 K12.026.25.0.PR OIL SUPPLY PIPE FOR TEL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER LHS FROM FWE Spare Part 7803 K12.026.38.0.PR O RING B W ADAPTOR TURBOCHARGER Spare Part 7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM Spare Part 7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DEG FOR 1500 RPM Spare Part 7806 K12.026.59.0.PR JOINT BETWEEN T C AND DRAIN PIPE Spare Part					4101	15%
7800 K12.025.11.0.PR JOINT BETWEEN TURBOCHARGER AND EXH MANIFOLD Spare Part 7801 K12.026.25.0.PR OIL SUPPLY PIPE FOR TEL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER LHS FROM FWE Spare Part 7803 K12.026.38.0.PR O RING B W ADAPTOR TURBOCHARGER Spare Part 7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM Spare Part 7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DEG FOR 1500 RPM Spare Part 7806 K12.026.59.0.PR JOINT BETWEEN T C AND DRAIN PIPE Spare Part					2963	15%
7801 K12.026.25.0.PR OIL SUPPLY PIPE FOR TEL TURBO Spare Part 7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER LHS FROM FWE Spare Part 7803 K12.026.38.0.PR O RING B W ADAPTOR TURBOCHARGER Spare Part 7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM Spare Part 7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DEG FOR 1500 RPM Spare Part 7806 K12.026.59.0.PR JOINT BETWEEN T C AND DRAIN PIPE Spare Part					4532	15%
7802 K12.026.36.0.PR ADAPTOR FOR B3NG TURBOCHARGER LHS FROM FWE Spare Part 7803 K12.026.38.0.PR O RING B W ADAPTOR TURBOCHARGER Spare Part 7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM Spare Part 4 7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DEG FOR 1500 RPM Spare Part 4 7806 K12.026.59.0.PR JOINT BETWEEN T C AND DRAIN PIPE Spare Part					1852	15%
7803 K12.026.38.0.PR O RING B W ADAPTOR TURBOCHARGER Spare Part 7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM Spare Part 4 7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DEG FOR 1500 RPM Spare Part 4 7806 K12.026.59.0.PR JOINT BETWEEN T C AND DRAIN PIPE Spare Part	-				22637	15%
7804 K12.026.49.0.PR TURBOCHARGER B3NS 180 DEG FOR 1500 RPM Spare Part 4 7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DEG FOR 1500 RPM Spare Part 4 7806 K12.026.59.0.PR JOINT BETWEEN T C AND DRAIN PIPE Spare Part					234	15%
7805 K12.026.51.0.PR TURBOCHARGER B3NS 23 DEG FOR 1500 RPM Spare Part 4 7806 K12.026.59.0.PR JOINT BETWEEN T C AND DRAIN PIPE Spare Part					436954	15%
7806 K12.026.59.0.PR JOINT BETWEEN T C AND DRAIN PIPE Spare Part				•	436954	15%
					1566	15%
pale rait	-			•	12468	15%
7808 K12.026.65.0.PR FLANGE FOR OIL DRAIN PIPE DOUBLE O RING Spare Part					1434	15%
7809 K12.026.67.0.PR O RING FOR TURBO DRAIN PIPE DOUBLE O RING Spare Part Spare Part					2591	15%
7809 K12.026.67.0.PR O RING FOR TORBO DRAIN PIPE FLANGE Spare Part 7810 K12.027.101.0.PR SLEEVE BETWEEN ADAPTOR AND CAC PIPE Spare Part				•	3009	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
			,	without Vat in NPR	Charge%
7811	K12.027.102.0.PR	O RING FOR CAC PIPE SLEEVE	Spare Part	4874	15%
7812	K12.027.11.0.PR	O RING DIA 4MM ID 88	Spare Part	345	15%
7813	K12.027.15.0.PR	O RING DIA 4MM ID 125	Spare Part	255	15%
7814	K12.027.23.0.PR	O RING DIA 6MM ID 82 5	Spare Part	517	15%
7815	K12.028.14.0.PR	OIL SEAL FOR FWE SAINT GOBAIN	Spare Part	184496	15%
7816	K12.028.40.0.PR	BARRING ASSEMBLY	Spare Part	20717	15%
7817	K12.031.03.0.PR	O RING FOR OIL FILLING	Spare Part	292	15%
7818	K12.031.14.0.PR	O RING BETWEEN SUMP AND CRANKCASE	Spare Part	274	15%
7819	K12.032.03.0.PR	O RING FOR CENTRIFUGE	Spare Part	560	15%
7820	K12.032.05.0.PR	O RING FOR OIL FLOW SLEEVE	Spare Part	323	15%
7821	K12.032.08.0.PR	O RING FOR CENTRIFUGE HOUSING	Spare Part	4812	15%
7822	K12.036.07.0.PR	UPPER CLAMP FOR OD 20 RUBBER SLEEVE	Spare Part	102	15%
7823	K12.036.08.0.PR	RUBBER SLEEVE ID 15 x OD 20	Spare Part	37	15%
7824	K12.036.09.0.PR	RUBBER SLEEVE ID 10 X OD 20	Spare Part	52	15%
7825	K12.036.12.0.PR	RUBBER SLEEVE ID 10 x OD 14	Spare Part	34	15%
7826	K12.036.13.0.PR	RUBBER SLEEVE ID 6 x OD 14	Spare Part	37	15%
7827	K12.036.130.0.PR	LEAK OFF PIPE RH BANK FROM FWE	Spare Part	11794	15%
7828	K12.036.220.0.PR	LUB OIL SUPPLY PIPE CRANKCASE TO FIP RH SIDE F G E	Spare Part	1440	15%
7829	K12.036.25.0.PR	RUBBER SLEEVE ID 8 X OD 20	Spare Part	52	15%
7830	K12.036.250.0.PR	FUEL PIPE FEED PUMP TO FUEL FILTER LH BANK FROM FWE	Spare Part	3581	15%
7831	K12.036.260.0.PR	FUEL PIPE FEED PUMP TO FUEL FILTER LH BANK FROM FWE	Spare Part	4249	15%
7832	K12.036.30.0.PR	FUEL DISCHARGE PIPE	Spare Part	2865	15%
7833	K12.036.35.0.PR	RUBBER SLEEVE OD 6 X O D 15	Spare Part	311	15%
7834	K12.036.36.0.PR	TWO PIPE CLAMP O D 6 X O D 15		138	15%
7835	K12.030.30.0.PR		Spare Part	48667	15%
7836	K12.103.01.0.PR	INJECTOR FOR K4300 ENGINE NOZZLE N16494A 2350 HTF 8 X 146 GOVERNOR DC 12 MASTER MAKE HENZMAN TYPE 620 00 195 01	Spare Part Spare Part	179810	15%
7837	K12.103.01.0.FIX	MAGNETIC PICK UP 16X1 5 THREADING HEINZMANN MAKE	Spare Part	59938	15%
7838	K12.103.02.0.FIX	STARTER FOR K4300	Spare Part	136229	15%
7839	K12.103.05.0.PR	STARTER FOR K4300 LH	Spare Part	136229	15%
7840	K12.103.05.0.PR	GOVERNOR DC 12 SLAVE MAKE HENZMAN TYPE 620 00 198 00	Spare Part	318999	15%
7841		ADAPTOR FOR OIL AND PRESSURE SENSOR	Spare Part	1505	15%
7842	K12.105.16.0.PR K12.107.08.0.PR	VENT PIPE FROM ENGINE TO RADIATOR	Spare Part	5726	15%
7843		VENT HOSE		348	15%
7844	K12.107.09.0.PR K12.107.12.0.PR	HOSE FOR CAC PIPE ID 126 X ID 126	Spare Part	6932	15%
			Spare Part		
7845 7846	K12.107.13.0.PR	FLEXIBLE VENT PIPE MALE PLUG M14X1 5 AND M14X1 5 UNION NUT FUEL PIPE FROM PRE FILTER TO FEED PUMP M18X1 5 BANJO BOTH SIDE	Spare Part	3932 4317	15% 15%
	K12.116.01.0.PR		Spare Part		15%
7847	K12.116.02.0.PR	FUEL INLET PIPE FROM PRE FILTER TO JUNCTION PLATE M22X1 5 BANJO AND M22X1 5 UNION N	Spare Part	4477	
7848	K12.116.03.0.PR	FUEL INLET PIPE FROM PRE FILTER TO JUNCTION PLATE M22X1 5 BANJO AND M22X1 5 UNION N	Spare Part	6658	15%
7849	K12.116.04.0.PR	FUEL RETURN PIPE M22X1 5 UNION BOTH SIDE RH SIDE FROM F W E	Spare Part	6095	15%
7850	K12.116.05.0.PR	FUEL RETURN PIPE M22X1 5 UNION BOTH SIDE LH SIDE FROM F W E	Spare Part	5086	15%
7851	K12.116.06.0.PR	FUEL PIPE M22X1 5 UNION BOTH SIDE FROM JUNCTION PLATE TO TANK	Spare Part	22587	15%
7852	K12.116.18.0.PR	FUEL PIPE FROM PRE FILTER TO FEED PUMP M18X1 5 BANJO BOTH SIDE	Spare Part	4141	15%
7853	K12.116.22.0.PR	FUEL INLET PIPE FROM PRE FILTER TO TANK	Spare Part	12723	15%
7854	K12.116.24.0.PR	FUEL RETURN PIPE M14X1 5 MALE PLUG	Spare Part	7701	15%
7855	K12.116.31.0.PR	FUEL PIPE FROM PRE FILTER TO FEED PUMP M18X1 5 BANJO BOTH SIDE RH SIDE FROM F W E	Spare Part	6148	15%
7856	K12.116.41.0.PR	BRACKET FOR FUEL PIPE	Spare Part	1006	15%
7857	K12.859.20.0.PR	CONTROL PANEL ASSEMBLY FOR K4300 ENGINE	Spare Part	176062	15%
7858	K12.910.20.0.PR	ENGINE WIRING HARNESS SF K4300 ENGINE KG745 UNIT	Spare Part	209942	15%
7859	K12.910.63.0.PR	COMMUNICATION CABLE HARNESS FOR DC12 GOVERNOR	Spare Part	3117	15%
7860	K12.911.30.0.PR	CANOPY WIRING HARNESS SF K4300 GENSET	Spare Part	6683	15%
7861	K12.999.050.0.SP	K4300 SPECIAL TOOLS KIT	Spare Part	713046	15%
7862	KCL.0006.400.0.00	CONTACTOR 25A, 4POLE, 240V AC	Spare Part	2178	15%
7863	KCL.0018.400.0.00	CONTACTOR 40A, 4POLE, 240V AC	Spare Part	3409	15%
7864	KCL.0032.400.0.00	CONTACTOR 50A, 4POLE, 240V AC	Spare Part	4917	15%
7865	KCL.0040.400.0.00	CONTACTOR 63A, 4POLE, 240V AC	Spare Part	8680	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
			,	without Vat in NPR	Charge%
7866	KCL.0050.400.0.00	CONTACTOR 80A, 4POLE, 240V AC	Spare Part	13938	15%
7867	KCL.0065.400.0.00	CONTACTOR 100A, 4POLE, 240V AC	Spare Part	17858	15%
7868	KCL.0085.400.0.00	CONTCACTOR 130A, 4 POLE, 240V AC (TYPE: KCL44 85)	Spare Part	17375	15%
7869	KCL.0150.400.0.00	CONTACTOR 250A, 4POLE, 240V AC	Spare Part	32950	15%
7870	KCL.0225.400.0.00	CONCTACTOR 320A 4 POLE 240V AC KOEL MAKE TYPE KCL64 225	Spare Part	69642	15%
7871	KCL.0330.400.0.00	CONCTACTOR 400A 4 POLE 240V AC KOEL MAKE TYPE KCL74 330	Spare Part	86307	15%
7872	KCL.0500.400.0.00	CONCTACTOR 630A 4 POLE 240V AC KOEL MAKE TYPE KCL84 500	Spare Part	144309	15%
7873	KL6.011.03.0.00	CAMSHAFT BUSH	Spare Part	7618	15%
7874	KL6.011.12.0.00	BEARING : MAIN (STD)	Spare Part	9661	15%
7875	KL6.011.13.0.00	MAIN BEARING: 0.25	Spare Part	12384	15%
7876	KL6.011.15.0.00	BEARING: MAIN 075	Spare Part	11640	15%
7877	KL6.011.17.0.00	THRUST WASHER	Spare Part	3215	15%
7878	KL6.011.18.0.00	THRUST WASHER	Spare Part	3215	15%
7879	KL6.011.21.0.00	RING: SEAL A16X22	Spare Part	268	15%
7880	KL6.011.23.0.00	RING SEAL	Spare Part	286	15%
7881	KL6.011.25.0.00	RING: SEAL A12X18	Spare Part	283	15%
7882	KL6.011.30.0.00	CYLINDER LINER	Spare Part	67218	15%
7883	KL6.011.31.0.00	NOZZLE: OIL SPRAY	Spare Part	4923	15%
7884	KL6.011.32.0.00	NOZZLE: OIL SPRAY	Spare Part	4923	15%
7885	KL6.011.33.0.00	BOLT : HEX	Spare Part	108	15%
7886	KL6.012.02.0.00	GASKET	Spare Part	11428	15%
7887	KL6.012.08.0.00	GASKET: TCG COVER	Spare Part	10157	15%
7888	KL6.012.16.0.00	OIL SEAL	Spare Part	11529	15%
7889	KL6.013.02.0.00	GASKET		17304	15%
7890		OIL SEAL	Spare Part	30012	15%
7891	KL6.013.08.0.00 KL6.013.09.0.00	SENSOR : TACHO 275/320 KVA	Spare Part Spare Part	40513	15%
7892	KL6.020.08.0.00	GEAR: RING STARTER	Spare Part	37664	15%
7893	KL6.020.12.0.00	CON ROD ASSLY	Spare Part	108380	15%
7894	KL6.020.14.0.00	BOLT: COLLARED HEX	Spare Part	1935	15%
7895	KL6.020.14.0.00	CON ROD BUSH		8129	15%
7896	KL6.020.17.0.00	CON ROD BEARING	Spare Part Spare Part	8323	15%
7897	KL6.020.17.0.00	CON ROD BEARING 0.25	Spare Part	6861	15%
7898	KL6.020.18.0.00	BEARING CON ROD 0.75		5154	15%
7899	KL6.020.20.0.00	BEARING CON ROD 1 00	Spare Part	5154	15%
			Spare Part	53793	
7900 7901	KL6.020.22.0.00	PISTON PIN	Spare Part	8994	15% 15%
	KL6.020.26.0.00		Spare Part		15%
7902	KL6.020.27.0.00	SNAP RING 45X1.75	Spare Part	342	
7903	KL6.020.30.0.00	BOLT SOCKET HEAD	Spare Part	3437	15%
7904	KL6.020.33.0.00	PISTON RING SET - 320 KVA	Spare Part	22923	15%
7905	KL6.030.03.0.00	BUSH: INJECTION NOZZLE	Spare Part	9418	15%
7906	KL6.030.04.0.00	O RING	Spare Part	840	15%
7907	KL6.030.09.0.00	VALVE SEAT	Spare Part	5246	15%
7908	KL6.030.10.0.00	VALVE SUIDE	Spare Part	5157	15%
7909	KL6.030.14.0.00	VALVE GUIDE	Spare Part	4049	15%
7910	KL6.030.15.0.00	CYLINDER HEAD ASSEMBLY REAR MODIFIED	Spare Part	558817	15%
7911	KL6.030.23.0.00	GASKET: CYLINDER HEAD-FRONT	Spare Part	40295	15%
7912	KL6.030.24.0.00	GASKET: CYLINDER HEAD- REAR	Spare Part	40295	15%
7913	KL6.030.27.0.00	BOLT : COLLARED HEX.	Spare Part	2145	15%
7914	KL6.030.35.0.00	GASKET: CYLINDER HEAD COVER	Spare Part	9283	15%
7915	KL6.030.37.0.00	WASHER	Spare Part	397	15%
7916	KL6.030.38.0.00	GASKET: CYLINDER HEAD COVER	Spare Part	575	15%
7917	KL6.030.39.0.00	HOUSING: BREATHER	Spare Part	16683	15%
7918	KL6.030.40.0.00	O-RING	Spare Part	483	15%
7919	KL6.031.01.0.00	VALVE: INLET ALTV	Spare Part	5948	15%
7920	KL6.031.04.0.00	VALVE: EXHAUST (ALTV)	Spare Part	8984	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
7921	KL6.031.07.0.00	SPRING : VALVE SPRING ASSLY	Spare Part	2652	15%
7922	KL6.031.08.0.00	VALVE SPRING (INNER)	Spare Part	1160	15%
7923	KL6.031.09.0.00	VALVE SPRING (OUTER)	Spare Part	1520	15%
7924	KL6.031.11.0.00	VALVE SPRING SEAT	Spare Part	662	15%
7925	KL6.031.12.0.00	RETAINER: VALVE SPRING	Spare Part	609	15%
7926	KL6.031.13.0.00	VALVE STEM SEAL	Spare Part	1052	15%
7927	KL6.031.14.0.00	COTTER: VALVE	Spare Part	212	15%
7928	KL6.031.16.0.00	ROCKER ARM ASSEMBLY	Spare Part	6151	15%
7929	KL6.031.31.0.00	TAPPET: VALVE	Spare Part	5388	15%
7930	KL6.031.32.0.00	ROD: PUSH	Spare Part	3243	15%
7931	KL6.031.33.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	270683	15%
7932	KL6.040.01.0.00	OIL PUMP ASSLY	Spare Part	131007	15%
7933	KL6.040.22.0.00	BALL BRG 6006C	Spare Part	4348	15%
7934	KL6.040.26.0.00	BOLT SOCKET HEAD	Spare Part	797	15%
7935	KL6.041.03.0.00	HEAD OIL FILTER	Spare Part	69870	15%
7936	KL6.041.19.0.00	O-RING	Spare Part	714	15%
7937	KL6.042.03.0.00	ELEMENT : OIL COOLER	Spare Part	125158	15%
7938	KL6.042.04.0.00	GASKET: OIL PIPE	Spare Part	502	15%
7939	KL6.042.09.0.00	GASKET	Spare Part	9474	15%
7940	KL6.042.16.0.00	GASKET: OIL PIPE	Spare Part	483	15%
7941	KL6.042.18.0.00	OIL PIPE	Spare Part	53458	15%
7942	KL6.043.02.0.00	GASKET: OIL PAN	Spare Part	35187	15%
7943	KL6.043.03.0.00	OIL LEVEL GAUGE	Spare Part	4948	15%
7944	KL6.043.05.0.00	WASHER: OIL SUMP	Spare Part	8575	15%
7945	KL6.043.12.0.00	PIPE OIL	Spare Part	21286	15%
7946	KL6.043.13.0.00	GASKET: OIL PIPE	Spare Part	1095	15%
7947	KL6.043.17.0.00	PIPE OIL	Spare Part	17544	15%
7948	KL6.055.03.0.00	HOUSING: THERMOSTAT	Spare Part	27981	15%
7949	KL6.055.04.0.00	GASKET: WATER PIPE	Spare Part	932	15%
7950	KL6.055.09.0.00	GASKET: WATER PIPE	Spare Part	640	15%
7951	KL6.055.10.0.00	GASKET FOR COOLING WATER PIPE (MODIFIED)	Spare Part	686	15%
7952	KL6.055.17.0.00	PIPE : COOLING WATER	Spare Part	10988	15%
7953	KL6.055.18.0.00	HOSE: RUBBER	Spare Part	4289	15%
7954	KL6.055.19.0.00	HOSE CLAMP: NW 28	Spare Part	800	15%
7955	KL6.055.20.0.00	HOSE: RUBBER	Spare Part	1935	15%
7956	KL6.055.23.0.00	PIPE : COOLING WATER	Spare Part	16317	15%
7957	KL6.055.24.0.00	GASKET: WATER PIPE	Spare Part	951	15%
7958	KL6.055.25.0.00	HOSE: RUBBER	Spare Part	2446	15%
7959	KL6.055.26.0.00	HOSE CLAMP: NW S40	Spare Part	942	15%
7960	KL6.055.33.0.00	THERMOSTAT ELEMENT	Spare Part	8055	15%
7961	KL6.055.34.0.00	THERMOSTAT ELEMENT	Spare Part	18480	15%
7962	KL6.056.15.0.00	O-RING	Spare Part	2705	15%
7963	KL6.081.02.0.00	MANIFOLD EXHAUST	Spare Part	24957	15%
7964	KL6.081.06.0.00	GASKET: EXHAUST M'FOLD	Spare Part	3637	15%
7965	KL6.081.07.0.00	BOLT: STUD M10	Spare Part	240	15%
7966	KL6.081.18.0.00	GASKET: INTAKE M'FOLD	Spare Part	10181	15%
7967	KL6.081.25.0.00	GASKET: COLD START	Spare Part	806	15%
7968	KL6.082.06.0.00	GASKET TURBOCHARGER	Spare Part	2185	15%
7969	KL6.082.07.0.00	JOINT ELBOW EXHAUST MANIFOLD	Spare Part	28877	15%
7970	KL6.082.36.0.00	HOSE	Spare Part	3720	15%
7971	KL6.082.37.0.00	CLAMP: HOSE BAND TYPE	Spare Part	1025	15%
7972	KL6.083.01.0.00	V BELT	Spare Part	25341	15%
7973	KL6.100.01.0.00	NOZZLE & HOLDER ASSLY	Spare Part	84903	15%
7974	KL6.100.04.0.00	GASKET: METAL	Spare Part	523	15%
7975	KL6.100.05.0.00	CAP: RUBBER	Spare Part	615	15%



				Price to		
Cu No	Dant Normalian	Don't Description	Catagony	Customer	Custom	
Sr.No.	Part Number	Part Description	Category	without Vat in	Charge%	
				NPR		
7976	KL6.100.06.0.00	BOLT : STUD	Spare Part	415	15%	
7977	KL6.101.02.0.00	GOVERNOT ASSLY	Spare Part	616416	15%	
7978	KL6.101.08.0.00	PIPE OIL	Spare Part	5261	15%	
7979	KL6.101.12.0.00	OIL PIPE	Spare Part	6529	15%	
7980	KL6.101.13.0.00	FIP COUPLING	Spare Part	160435	15%	
7981	KL6.101.31.0.00	GASKET INJECTION PUMP MOUNT	Spare Part	6529	15%	
7982	KL6.102.01.0.00	HOSE	Spare Part	9818	15%	
7983	KL6.102.02.0.00	HOSE: RUBBER RING JOINT	Spare Part	9818	15%	
7984	KL6.102.06.0.00	FUEL PIPE	Spare Part	14246	15%	
7985	KL6.102.09.0.00	HOSE	Spare Part	954	15%	
7986	KL6.102.10.0.00	CLAMP : HOSE RING TYPE	Spare Part	74	15%	
7987	KL6.140.03.0.00	BOLT ASSLY	Spare Part	332	15%	
7988	KL6.140.05.0.00	SPACER	Spare Part	520	15%	
7989	KL6.140.06.0.00	BOLT : HEX.	Spare Part	2178	15%	
7990	KL6.140.12.0.00	STARTER	Spare Part	291433	15%	
7991	KL6.175.02.0.00	HOSE, RUBBER C/W (INLET)	Spare Part	36363	15%	
7992	KL6.175.11.0.00	HOSE SIL D75 X 80	Spare Part	13157	15%	
7993	KL6.175.12.0.00	HOSE COOLING WATER	Spare Part	4763	15%	
7994	KL6.175.31.0.00	RUBBER HOSE: THERMOSTAT TO RADIATOR	Spare Part	3154	15%	
7995	KL6.175.46.0.00	T-BOLT HOSE CLAMP 75-68MM	Spare Part	142	15%	
7996	KL6.176.04.0.00	GASKET: WATER PUMP COVER	Spare Part	6280	15%	
7997	KL6.176.05.0.00	WATER PUMP ASSLY	Spare Part	183933	15%	
7998	KL6.188.10.0.00	SILENCER	Spare Part	90054	15%	
7999	KL6.190.01.0.00	PIPE CAC	Spare Part	68784	15%	
8000	KL6.190.02.0.00	PIPE CAC	Spare Part	42501	15%	
8001	KL6.194.04.0.00	HOSE FUEL (FEED PUMP TO FILTER)820MM	Spare Part	9991	15%	
8002	KL6.194.05.0.00	HOSE FUEL (FILTER TO FIP) 660MM	Spare Part	10754	15%	
8003	KL6.502.05.0.00	CLAMP	Spare Part	2542	15%	
8004	KL6.506.01.0.00	EXPANSION BELLOW ONE SIDE SQUARE FLANGE OTHER SIDE ROUND FLANGE	Spare Part	9889	15%	
8005	KL6.515.01.0.00	FAN: 32" PLASTIC	Spare Part	24640	20%	
8006	KL6.516.04.0.00	FUEL PIPE: 700MM LONG 7/8" UNF UNION BOTH SIDE	Spare Part	1834	15%	
8007	KL6.528.04.0.00	FUEL PIPE (LENGTH 800 MM) 7/8" UNF UNION (BOTH SIDE) FOR K-SERIES SILENT SET	Spare Part	1954	15%	
8008	KL6.801.12.0.PR	KOEL GREEN ALTERNATOR KG250 ST, FRAME:M, KG38 M4 A, SAE-1/14", 415V, 50HZ,0.8 PF.	Spare Part	961959	15%	
8009	KL6.802.14.0.00	ALTERNATOR	Spare Part	131297	15%	
8010			•	4154	15%	
8011	KLL 0075.310.0.00	MCCB 75A, 3 POLE, 10KA BREAKING CAPACITY, KOEL MAKE (TYPE: KLL13 75 WITH THERMAL-MAKE)	Spare Part	4465		
-	KLL.0075.410.0.00	MCCB 75A 4 POLE 10KA BREAKING CAPACITY KOEL MAKE TYPE KLL14 75 WITH THERMAL MA	Spare Part		15%	
8012	KLL.0100.310.0.00	MCCB 100A , 3 POLE, 10KA BREAKING CAPACITY	Spare Part	4421	15%	
8013	KLL.0100.410.0.00	MCCB 100A 4 POLE 10KA BREAKING CAPACITY KOEL MAKE TYPE KLL14 100 WITH THERMAL	Spare Part	6692	15%	
8014	KLL.0125.337.0.00	MCCB 125A, 3 POLE, 37KA BREAKING CAPACITY	Spare Part	10431	15%	
8015	KLL.0125.437.0.00	MCCB 125A 4 POLE 37KA BREAKING CAPACITY KOEL MAKE TYPE KLL24 125 WITH THERMAL	Spare Part	12477	15%	
8016	KLL.0200.326.0.00	MCCB 200A , 3 POLE, 26KA BREAKING CAPACITY	Spare Part	13163	15%	
8017	KLL.0200.426.0.00	MCCB 200A , 4 POLE, 26KA BREAKING CAPACITY, KOEL MAKE (TYPE: KLL34 200 WITH THERMAL-	Spare Part	17495	15%	
8018	KLL.0250.326.0.00	MCCB 250A , 3 POLE, 26KA BREAKING CAPACITY	Spare Part	17806	15%	
8019	KLL.0250.426.0.00	MCCB 250A , 4 POLE, 26KA BREAKING CAPACITY, KOEL MAKE (TYPE: KLL34 250 WITH THERMAL-	Spare Part	23246	15%	
8020	KLL.0350.337.0.00	MCCB 350A , 3 POLE, 37KA BREAKING CAPACITY, KOEL MAKE (TYPE: KLL43 350 WITH THERMAL-	Spare Part	40799	15%	
8021	KLL.0350.437.0.00	MCCB 350A 4 POLE 37KA BREAKING CAPACITY KOEL MAKE TYPE KLL44 350 WITH THERMAL	Spare Part	53624	15%	
8022	KLL.0400.337.0.00	MCCB 400A , 3 POLE, 37KA BREAKING CAPACITY	Spare Part	41267	15%	
8023	KLL.0400.437.0.00	MCCB 400A 4 POLE 37KA BREAKING CAPACITY KOEL MAKE TYPE KLL44 400 WITH THERMAL	Spare Part	50907	15%	
8024	KLL.0500.437.0.00	MCCB 500A 4 POLE 37KA BREAKING CAPACITY KOEL MAKE TYPE KLL54 500 WITH THERMAL	Spare Part	70682	15%	
8025	KLL.0630.337.0.00	MCCB 630A , 3 POLE, 37KA BREAKING CAPACITY	Spare Part	54584	15%	
8026	KLL.0630.437.0.00	MCCB 630A 4 POLE 37KA BREAKING CAPACITY KOEL MAKE TYPE KLL54 630 WITH THERMAL	Spare Part	73399	15%	
8027	KLL.0800.337.0.00	MCCB 800A , 3 POLE, 37KA BREAKING CAPACITY	Spare Part	67174	15%	
8028	KLL.0800.437.0.00	MCCB 800A 4 POLE 37KA BREAKING CAPACITY KOEL MAKE TYPE KLL54 800 WITH THERMAL	Spare Part	95642	15%	
8029	KML.0006.106.0.00	MCB 6A 1 POLE 06KA BREAKING CAPACITY CURVE C KOEL MAKE TYPE KML11 C6	Spare Part	363	15%	
8030	KML.0010.106.0.00	MCB 10A, 1POLE, 06KA BREAKING CAPACITY, CURVE C	Spare Part	388	15%	



Part Number					Price to	
Sp. Mo. Fair Number Fair Discription Category without Value Charge 0021 NAL DOTE 100.00 MCD 164 A. 1 POLE 09KA BREAKING CAPACITY CURVE C. KOEL MAKE (TYPE KRIL 13 CHS) Spere Part 1323 10.00 0023 NAL DOTE 300.00 MCD 164 A. 2 POLE 09KA BREAKING CAPACITY CURVE C. KOEL MAKE (TYPE KRIL 13 CHS) Spere Part 1330 10.00 0024 NAL DOZE 300.00 MCD 264 A. POLE 09KA BREAKING CAPACITY Spere Part 1500 10.00 0025 NAL DOZE 300.00 MCD 264 A. POLE 09KA BREAKING CAPACITY Spere Part 1500 10.00 0026 NAL DOZE 300.00 MCD 264 A. POLE 09KA BREAKING CAPACITY Spere Part 1500 10.00 0027 NAL DOZE 300.00 MCD 264 A. POLE 09KA BREAKING CAPACITY CURVE C. KOEL MAKE TYPE KRIL 1 CDD Spere Part 1440 10.00 0028 NAL DOZE 300.00 MCD 264 A. POLE 09KA BREAKING CAPACITY CURVE C. KOEL MAKE TYPE KRIL 1 CDD Spere Part 1241 10.00 0029 NAL DOZE 300.00 MCD 264 A. POLE 09KA BREAKING CAPACITY CURVE C. KOEL MAKE TYPE KRIL 1 CDD Spere Part 1242 10.00 0029 NAL						Custom
MIST MILL MIST	Sr.No.	Part Number	Part Description	Category		
1902 DR. D. O. 1983 00.00 DR. DE SA. POLE, DOAR REPENNIG CAPACITY, CURVEC, KOEL MARE (TYPE, KML 19 026) Suser Part 1930 1919 1939 1919 191					NPR	•
MAIL DOOS 100.000	8031	KML.0016.106.0.00	MCB 16A 1 POLE 06KA BREAKING CAPACITY CURVE C KOEL MAKE TYPE KML11 C16	Spare Part	397	15%
MAIL 0032 106 0.00 MCB 2874, 1 POLE GORD BERCHING CAPACITY Spen Part 1506 1506 1507 1506 1507 1506 1507 1506 1507 1506 1507 1506 1507 1506 1507 1506 1507 1506 1507 1506 1507 1506 1507 1506 1507 1507 1506 1507 15	8032	KML.0016.306.0.00	MCB 16A, 3 POLE, 06kA BREAKING CAPACITY, CURVE C, KOEL MAKE (TYPE: KML13 C16)	Spare Part	1323	15%
MILL 0002 08.0 0.00	8033	KML.0025.306.0.00	MCB 25A , 3 POLE, 06kA BREAKING CAPACITY, CURVE C, KOEL MAKE (TYPE: KML13 C25)	Spare Part	1363	15%
83838 MAIL 0002408.00.00 MCB 22A. 4 POLE 00A BEREANING CAPACITY, CURVE C, NCEL MARE (TYPE KML) 22 (4) Spen Pert 1486 1998 8393 MAIL 00000 00.00 MCB 20A. 5 POLE 00A BEREANING CAPACITY (CURVE C NCEL MARE TYPE KML) 22 (4) Spen Pert 244 1998 8393 MAIL 0000 000.00 MCB 20A. 5 POLE 00A BERCANING CAPACITY (CURVE C NCEL MARE TYPE KML) 12 (4) Spen Pert 2542 159 8404 KML 0000 000.00 MCB 20A. 5 POLE 00AA BREAKING CAPACITY (CURVE C NCEL MARE TYPE KML) 12 (3) Spen Pert 1566 159 8404 KML 0000 000.00 MCB 20A. 2 POLE 00AA BREAKING CAPACITY (CURVE C NCEL MARE TYPE KML 14 (3) Spen Pert 1506 159 8404 KML 0000 000 MCB 20A. 2 POLE 00AA BREAKING CAPACITY (CURVE C NCEL MARE TYPE KML 14 (3) Spen Pert 2525 159 8404 KML 0000 000 MCB 20A. 2 POLE 00A BREAKING CAPACITY MCD 20A MARE TYPE KML 14 (3) Spen Pert 2525 159 8404 KML 0000 000 MCB 20A BREAKING CAPACITY MCD 20A MARE TYPE KML 14 (3) Spen Pert 2525 159 8404 KML 0000 000 MCM 0000 000 MCD 20A MARE TYPE KML 14 (3) MCD	8034	KML.0032.106.0.00	MCB 32A , 1 POLE, 06KA BREAKING CAPACITY	Spare Part	388	15%
8937 ML.0002.08.00.00 MCAP 400.08.00.00 MCAP 400.08.00.00 Speen Part 1440 1998 8038 MLL.0004.08.00.00 MCAP 400.08.00.00 MCAP 400.00.00.00 MCAP 400.00.00.00 MCAP 400.00.00 MCAP 400.00.00.00 MCAP 400.00.00.00 MCAP 400.00.00.00 MCAP 400.00.00.00.00.00.00.00.00.00.00.00.00.	8035	KML.0032.306.0.00	MCB 32A , 3 POLE, 06KA BREAKING CAPACITY	Spare Part	1505	15%
MILLONG 00.00 00 MICHARD A POLE BORA BREANNO CAPACITY CURVEC KOEL MAKE TYPE KML 14 C40 Spare Part 234 199 190 19	8036	KML.0032.406.0.00	MCB 32A , 4 POLE, 06kA BREAKING CAPACITY, CURVE C, KOEL MAKE (TYPE: KML14 C32)	Spare Part	1582	15%
MICH. 0000 000 000 MICH. 000.4 A POLIC BOKA BERANNIC CAPACITY CURVE C, KOEL MAKE TYPE: KM.14 CAD Spare Part 2542 199	8037	KML.0040.206.0.00	MCB 40A 2 POLE 06kA BREAKING CAPACITY CURVE C KOEL MAKE TYPE KML12 C40	Spare Part	1440	15%
MILLORO 2006 0.00 MICL 500A, 2 POLIC 500A SREAVING CAPACITY, CURVE C, VOEL MAKE (TYPE KML 12 C50) Spare Part 1566 1998	8038	KML.0040.306.0.00	MCB 40A 3 POLE 06KA BREAKING CAPACITY CURVE C KOEL MAKE TYPE KML13 C40	Spare Part	2314	15%
	8039	KML.0040.406.0.00	MCB 40A 4 POLE 06KA BREAKING CAPACITY CURVE C KOEL MAKE TYPE: KML14 C40	Spare Part	2542	15%
MML.0053.065.0.00 MCB S0A - POILE GOKA BREAKING CAPACITY CURVE C. KOEL MAKE TYPE KML.12 CS3 Spare Part 1695 169	8040	KML.0050.206.0.00	MCB 50A, 2 POLE, 06kA BREAKING CAPACITY, CURVE C, KOEL MAKE (TYPE: KML12C50)	Spare Part	1566	15%
MML_0063_208_0.00 MGB SSA_ 2 POLE_00KA BREAKING CAPACITY Spare Part 2325 1579 2325 157	8041	KML.0050.306.0.00	MCB 50A, 3POLE, 06KA BREAKING CAPACITY, CURVE C	Spare Part	2252	15%
BOME MML.0083.300.000 MCGB 63A 3 POLE 09KA BREANING CAPACITY Spure Part 2230 159	8042	KML.0050.406.0.00	MCB 50A 4 POLE 06KA BREAKING CAPACITY CURVE C KOEL MAKE TYPE KML14 C50	Spare Part	2431	15%
	8043	KML.0063.206.0.00	MCB 63A , 2 POLE, 06kA BREAKING CAPACITY, CURVE C, KOEL MAKE (TYPE: KML12 C63)	Spare Part	1686	15%
MAIL 0083 AGR 0.00 MCS 63A POLE 06KA BREAKING CAPACITY	8044	KML.0063.306.0.00		Spare Part	2323	15%
8949 KY 1324 64 00 00						15%
804F KVO 0012 2.0.00 PISTON RING SET -400/800/800 KVA Spare Part 1980 155 8048 KVO 1012 19.00.00 RING: SEAL ZBX31 Spare Part 243 159 8059 KVO 1012 20.000 MAIN BEARING Spare Part 243 159 8059 KVO 1012 30.000 MAIN BEARING Spare Part 7801 191 8058 KVO 1012 30.000 FLAUST BEARING Spare Part 191 155 8058 KVO 1012 30.000 FLAUST BEARING Spare Part 191 155 8058 KVO 1012 30.000 CYLINDER LINER Spare Part 191 155 8058 KVO 1012 30.000 OR NG UPPER Spare Part 471 156 8058 KVO 1012 30.000 OR ING Spare Part 471 156 8058 KVO 1012 30.000 OR ING Spare Part 354 159 8058 KVO 1012 30.000 OR ING Spare Part 373 159 8058 KVO 1012 30.000 OR SAKET Spare Part <td></td> <td></td> <td></td> <td></td> <td></td> <td>20%</td>						20%
8048 KV0.012.19.0.00 RING. SEAL 28X31 Spare Part 6-69 159 8049 KV0.012.29.0.00 SEAL RING. A14/20 Spare Part 3021 159 8059 KV0.012.23.0.00 MIN BEARING Spare Part 3021 159 8051 KV0.012.23.0.00 THEUST EBEARING Spare Part 79014 119 8052 KV0.012.23.0.00 SPACER Spare Part 10005 151 8052 KV0.012.23.0.00 SPACER Spare Part 10005 150 8055 KV0.012.23.0.00 OR ING UPPER Spare Part 10005 150 8056 KV0.012.23.0.00 OR ING UPPER Spare Part 10005 150 8057 KV0.012.23.0.00 OR ING Spare Part 373 159 8058 KV0.012.23.0.00 OR ING Spare Part 373 159 8057 KV0.012.23.0.00 OR ING Spare Part 373 159 8058 KV0.012.24.0.00 OR SPACE Spare Part 372 <td>-</td> <td></td> <td></td> <td></td> <td></td> <td>15%</td>	-					15%
8049 KV0.012.290.00 SEAL RING A14X20 Spare Part 243 159 8056 KV0.012.300.00 MAN IN BEARING Spare Part 3901 159 8058 KV0.012.300.00 MENDER PART 39014 159 8058 KV0.012.330.00 SPACER Spare Part 1911 198 8058 KV0.012.330.00 CYLINDER LINER Spare Part 1901 193 8058 KV0.012.340.00 O RING UPPER Spare Part 100005 159 8056 KV0.012.350.00 O RING Spare Part 5240 159 8057 KV0.012.430.00 O RING Spare Part 5240 159 8057 KV0.012.430.00 O RING Spare Part 10560 159 8058 KV0.012.430.00 FLANGE ASSLY Spare Part 10560 159 8059 KV0.012.450.00 FLANGE ASSLY Spare Part 3446 159 8060 KV0.012.500.00 GASKET Spare Part 159 159						
8050 KW0.012.300.00 MAIN BEARING Spare Part 36021 159 8051 KW0.012.30.00 THRUST BEARING Spare Part 79014 159 8052 KW0.012.30.00 SPACER Spare Part 1911 159 8058 KW0.012.33.00 CVLINDER LINER Spare Part 100005 159 8058 KW0.012.33.00 O RING UPPER Spare Part 4471 159 8056 KW0.012.35.00 O RING Spare Part 4471 159 8056 KW0.012.36.00 O RING Spare Part 4471 159 8056 KW0.012.36.00 O RING Spare Part 3738 159 8057 KW0.012.43.00 O RING Spare Part 3738 159 8058 KW0.012.45.00 FLANGE ASSLY Spare Part 3446 159 8058 KW0.012.47.00 GASKET Spare Part 3612 159 8060 KW0.012.55.00 OI. SEAL FRONT Spare Part 3812 159						
8051 KW0.012.310.00 THRUST BEARING Spare Part 79014 159 8052 KW0.012.320.00 SPACER Spare Part 1016 159 8058 KW0.012.330.00 SVUINDER LINER Spare Part 1006 159 8055 KW0.012.330.00 O RING UPPER Spare Part 4241 159 8055 KW0.012.330.00 O RING LOWER Spare Part 524 159 8056 KW0.012.330.00 O RING Spare Part 524 159 8057 KW0.012.430.00 NORING Spare Part 1050 159 8058 KW0.012.430.00 NOZZLE. OIL SPRAY Spare Part 1050 159 8058 KW0.012.430.00 NOZZLE. OIL SPRAY Spare Part 329 159 8058 KW0.012.430.00 O RASKET Spare Part 329 159 8058 KW0.012.430.00 O Spare Part 348 159 8060 KW0.012.500.00 O Spare Part 329 159 8060						
8052 KV 0.012.32.0.00 SPACER Spare Part 911 159 8053 KV 0.012.33.0.00 CYLNDER LINER Spare Part 100005 158 8054 KV 0.012.34.0.00 O. RING UPPER Spare Part 4471 159 8056 KV 0.012.35.0.00 O. RING : LOWER Spare Part 5240 159 8056 KV 0.012.36.0.00 O. RING Spare Part 1050 159 8057 KV 0.012.36.0.00 O. RING Spare Part 1050 159 8058 KV 0.012.46.0.00 FLANGE ASSLY Spare Part 3446 159 8058 KV 0.012.47.0.00 GASKET Spare Part 320 159 8068 KV 0.012.50.00 GaskET Spare Part 320 159 8061 KV 0.012.50.00 Glas Escal HOLDER Spare Part 380 159 8062 KV 0.012.50.00 Glas SKET: Seal HOLDER Spare Part 320 159 8063 KV 0.012.50.00 Glas SKET Spare Part						
8053 KV 0.012.33.0.00 CYLINDER LINER Spare Part 1 00005 159 8054 KV 0.012.34.0.00 O RING LIPPER Spare Part 4471 159 8055 KV 0.012.35.0.00 O RING LIPPER Spare Part 5240 159 8056 KV 0.012.36.0.00 O RING LIPPER Spare Part 3738 159 8056 KV 0.012.36.0.00 O RING Spare Part 3738 159 8057 KV 0.012.45.0.00 NOZZLE: OIL SPRAY Spare Part 3446 159 8058 KV 0.012.45.0.00 GASKET Spare Part 324 159 8068 KV 0.012.50.00 Oil SEAL: FRONT Spare Part 329 159 8061 KV 0.012.50.00 Oil SEAL: FRONT Spare Part 13612 159 8062 KV 0.012.50.00 Oil SEAL: FRONT Spare Part 2986 159 8063 KV 0.012.50.00 Oil SEAL: FRONT Spare Part 2986 159 8064 KV 0.012.50.00 Oil SEAL: FRONT	-					
8054 KV0.012.34.0.00 O RING UPPER Spare Part 4471 159 8055 KV0.012.36.000 O RING: LOWER Spare Part 5240 159 8055 KV0.012.36.000 O RING: LOWER Spare Part 338 159 8057 KV0.012.36.000 O RING: LOWER Spare Part 3186 159 8058 KV0.012.36.000 O RING: LOWER Spare Part 10560 159 8058 KV0.012.40.000 FLANGE ASSLY Spare Part 3446 169 8069 KV0.012.50.000 GLASKET Spare Part 3261 159 8060 KV0.012.50.000 OLI SEAL: FRONT Spare Part 13612 159 8061 KV0.012.50.000 OLI SEAL: FRONT Spare Part 1362 159 8062 KV0.012.50.000 OLI SEAL: FRONT Spare Part 2582 159 8063 KV0.014.50.000 GASKET: FLYWHEEL HOUSING Spare Part 2584 159 8066 KV0.014.50.00 GASKET: FLYWHEEL HOUSING COVER <td></td> <td></td> <td></td> <td></td> <td>-</td> <td></td>					-	
8055 KV0.012.35.0.00 O RING LOWER Spare Part \$240 159 8056 KV0.012.35.0.00 O RING Spare Part 3738 159 8075 KV0.012.43.0.00 NOZZIE: OIL SPRAY Spare Part 3446 159 8058 KV0.012.46.0.00 FLANGE ASSLY Spare Part 3446 159 8059 KV0.012.47.0.00 GASKET Spare Part 329 159 8060 KV0.012.50.0.00 oil seal holder Spare Part 1582 159 8061 KV0.012.51.0.00 Oil SEAL: FRONT Spare Part 1582 159 8062 KV0.012.53.0.00 GASKET: SEAL HOLDER Spare Part 2089 159 8063 KV0.012.53.0.00 MAIN BEARING Spare Part 2089 159 8064 KV0.014.05.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3594 159 8065 KV0.014.05.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 152 8066 KV0.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER		1				
8656 KV0.012.36.0.00 O RING Spare Part 3738 159 8057 KV0.012.43.0.00 NOZZLE: Oll. SPRAY Spare Part 10560 159 8058 KV0.012.46.0.00 FLANGE ASSLY Spare Part 10560 159 8058 KV0.012.47.0.00 GASKET Spare Part 329 159 8060 KV0.012.50.0.00 GI. SEAL: FRONT Spare Part 13612 159 8061 KV0.012.50.0.00 GASKET: SEAL HOLDER Spare Part 2098 159 8062 KV0.012.50.0.00 GASKET: SEAL HOLDER Spare Part 2098 159 8063 KV0.012.50.0.00 GASKET: FLYWHEEL HOUSING Spare Part 26584 159 8065 KV0.014.0.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3594 159 8066 KV0.014.10.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 1123 159 8067 KV0.014.20.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 1520 159 8068 KV0						
8057 KV0.012.43.0.00 NOZZLE: OIL SPRAY Spare Part 10560 159 8058 KV0.012.40.00 FLANGE ASSLY Spare Part 346 159 8059 KV0.012.50.00 oil seal holder Spare Part 1361 159 8060 KV0.012.50.00 oil seal holder Spare Part 13612 159 8061 KV0.012.50.00 Oil SEAL: FRONT Spare Part 15892 159 8062 KV0.012.50.00 GISEAL: FRONT Spare Part 2802 159 8063 KV0.012.56.00 MAIN BEARING Spare Part 2808 159 8064 KV0.014.04.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3428 159 8066 KV0.014.05.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3594 159 8067 KV0.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 3504 159 8068 KV0.014.24.0.00 GLSEAL REAR Spare Part 3234 159 8069 KV0.014.25.0.00 <						
8658 KVO.012.46.0.00 FLANGE ASSLY Spare Part 3446 159 8099 KVO.012.47.0.00 GASKET Spare Part 329 159 8060 KVO.012.50.0.00 oil seal holder Spare Part 13612 159 8061 KVO.012.51.0.00 Oil SEAL: FRONT Spare Part 15892 159 8062 KVO.012.53.0.00 GASKET: SEAL HOLDER Spare Part 2088 159 8063 KVO.012.53.0.00 MAIN BEARING Spare Part 25654 159 8064 KVO.014.04.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3428 159 8066 KVO.014.05.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3594 159 8066 KVO.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 1123 159 8068 KVO.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 1529 159 8068 KVO.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 1529 159 8067	-					
8059 KVO.012.47.0.00 GASKET Spare Part 329 159 8060 KVO.012.50.0.00 oil seal holder Spare Part 13612 159 8061 KVO.012.53.0.00 oil seal holder Spare Part 15892 159 8062 KVO.012.53.0.00 GASKET: SEAL HOLDER Spare Part 2088 159 8063 KVO.012.56.0.00 MAIN BEARING Spare Part 26584 159 8064 KVO.014.04.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3428 159 8065 KVO.014.05.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3594 159 8066 KVO.014.20.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 1123 159 8067 KVO.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 3209 159 8068 KVO.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 3229 159 8069 KVO.014.22.0.00 GIL SEAL: REAR Spare Part 3229 159 8070 <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>						
8060 KV0.012.50.0.00 oil seal holder Spare Part 1.3612 1.59 8061 KV0.012.51.0.00 OIL SEAL: FRONT Spare Part 15892 1.59 8062 KV0.012.53.0.00 GASKET: SEAL HOLDER Spare Part 2098 1.59 8063 KV0.012.56.0.00 MAIN BEARING Spare Part 26584 1.59 8064 KV0.014.06.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3428 1.59 8065 KV0.014.06.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3594 1.59 8066 KV0.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 1123 1.59 8067 KV0.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 13209 1.59 8068 KV0.014.25.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 13209 1.59 8070 KV0.014.25.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 32747 1.59 8071 KV0.015.02.0.00 GRINGEY, FLYWHEEL HOUSING COVER Spare Part 362		1				
8061 KV0.012.51.0.00 OIL SEAL: FRONT Spare Part 15892 159 8062 KV0.012.53.0.00 GASKET: SEAL HOLDER Spare Part 2008 159 8063 KV0.012.56.0.00 MAIN BEARING Spare Part 26684 159 8064 KV0.014.04.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3594 159 8065 KV0.014.05.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3594 159 8066 KV0.014.05.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 1123 159 8067 KV0.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 5631 159 8068 KV0.014.24.0.00 GIL SEAL: REAR Spare Part 32747 159 8069 KV0.014.25.0.00 SENSOR: TACHO Spare Part 32747 159 8071 KV0.014.29.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 335 159 8071 KV0.014.29.0.00 GASKET: TACHO Spare Part 32747 159 80						
Spare Part 2098 159 15						
8083 KV0.012.56.0.00 MAIN BEARING Spare Part 26584 159 8064 KV0.014.04.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3428 159 8066 KV0.014.05.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3594 159 8066 KV0.014.16.0.00 GASKET Spare Part 1123 159 8067 KV0.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 1820 159 8068 KV0.014.22.0.00 OIL SEAL: REAR Spare Part 13209 159 8069 KV0.014.25.0.00 SENSOR: TACHO Spare Part 32747 159 8070 KV0.014.25.0.00 SENSOR: TACHO Spare Part 32747 159 8071 KV0.015.02.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 6628 159 8071 KV0.015.02.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 6628 159 8072 KV0.015.02.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 270 159 8	-					
8064 KV0.014.04.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3428 159 8065 KV0.014.05.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3594 159 8066 KV0.014.16.0.00 GASKET Spare Part 1123 159 8067 KV0.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 5631 159 8068 KV0.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 13209 159 8069 KV0.014.25.0.00 SENSOR: TACHO Spare Part 32747 159 8070 KV0.014.29.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 32747 159 8071 KV0.015.02.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 385 159 8071 KV0.015.02.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 385 159 8071 KV0.015.03.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 385 159 8071 KV0.015.03.0.00 O RING SPARE Part 385 159						15%
8065 KV0.014.05.0.00 GASKET: FLYWHEEL HOUSING Spare Part 3594 159 8066 KV0.014.16.0.00 GASKET Spare Part 1123 159 8067 KV0.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 5631 159 8068 KV0.014.24.0.00 OIL SEAL: REAR Spare Part 13209 159 8069 KV0.014.25.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 32747 159 8070 KV0.014.25.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 365 159 8071 KV0.014.29.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 385 159 8071 KV0.015.02.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 385 159 8071 KV0.015.03.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 385 159 8072 KV0.015.03.0.00 GRING Spare Part 2705 159 8072 KV0.015.03.0.00 HOSE RUBBER HOSE Spare Part 271 159						15%
8066 KV0.014.16.0.00 GASKET Spare Part 1123 159 8067 KV0.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 5631 159 8068 KV0.014.24.0.00 OIL SEAL: REAR Spare Part 13209 159 8069 KV0.014.25.0.00 SENSOR: TACHO Spare Part 32747 159 8070 KV0.014.29.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 6628 159 8071 KV0.015.02.0.00 O RING Spare Part 385 159 8072 KV0.015.03.0.00 HOSE Spare Part 2705 159 8073 KV0.015.03.0.00 HOSE Spare Part 2705 159 8074 KV0.015.03.0.00 HOSE CLAMP: NW S20 Spare Part 735 159 8075 KV0.015.06.0.00 CLAMP: HOSE NW 12 Spare Part 766 159 8076 KV0.015.07.0.00 PIPE BREATHER Spare Part 2677 159 8077 KV0.020.04.0.00 RING: WEAR, FRONT <td>8064</td> <td>KV0.014.04.0.00</td> <td>GASKET: FLYWHEEL HOUSING</td> <td>Spare Part</td> <td>3428</td> <td>15%</td>	8064	KV0.014.04.0.00	GASKET: FLYWHEEL HOUSING	Spare Part	3428	15%
8067 KV0.014.22.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 5631 159 8068 KV0.014.24.0.00 OIL SEAL: REAR Spare Part 13209 159 8069 KV0.014.25.0.00 SENSOR: TACHO Spare Part 32747 159 8070 KV0.014.29.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 6628 159 8071 KV0.015.02.0.00 O RING Spare Part 385 159 8072 KV0.015.03.0.00 HOSE Spare Part 2705 159 8073 KV0.015.03.0.00 RUBBER HOSE Spare Part 2705 159 8074 KV0.015.05.0.00 RUBBER HOSE Spare Part 735 159 8074 KV0.015.05.0.00 HOSE CLAMP: NW S20 Spare Part 735 159 8075 KV0.015.06.0.00 CLAMP: HOSE NW 12 Spare Part 766 159 8076 KV0.015.07.0.00 PIPE BREATHER Spare Part 2677 159 8077 KV0.020.04.0.00 RING: WEAR	8065	KV0.014.05.0.00	GASKET: FLYWHEEL HOUSING	Spare Part		15%
8088 KV0.014.24.0.00 OIL SEAL: REAR Spare Part 13209 159 8099 KV0.014.25.0.00 SENSOR: TACHO Spare Part 32747 159 8070 KV0.014.29.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 6628 159 8071 KV0.015.02.0.00 O RING Spare Part 385 159 8072 KV0.015.03.0.00 HOSE Spare Part 2705 159 8073 KV0.015.04.0.00 RUBBER HOSE Spare Part 2271 159 8074 KV0.015.05.0.00 HOSE CLAMP: NW S20 Spare Part 735 159 8074 KV0.015.06.0.00 CLAMP: HOSE NW 12 Spare Part 736 159 8075 KV0.015.07.0.00 PIPE BREATHER Spare Part 2677 159 8076 KV0.020.04.0.00 RING: WEAR, FRONT Spare Part 16797 159 8078 KV0.020.04.0.00 GEAR: RING STARTER Spare Part 16797 159 8079 KV0.020.160.00 GEAR: RING STA	8066	KV0.014.16.0.00	GASKET	Spare Part	1123	15%
8069 KV0.014.25.0.00 SENSOR: TACHO Spare Part 32747 159 8070 KV0.014.29.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 6628 159 8071 KV0.015.02.0.00 O RING Spare Part 385 159 8072 KV0.015.03.0.00 HOSE Spare Part 2705 159 8073 KV0.015.04.0.00 RUBBER HOSE Spare Part 2271 159 8074 KV0.015.05.0.00 HOSE CLAMP: NW S20 Spare Part 735 159 8075 KV0.015.06.0.00 CLAMP: HOSE NW 12 Spare Part 766 159 8076 KV0.015.07.0.00 PIPE BREATHER Spare Part 2677 159 8076 KV0.020.04.0.00 RING: WEAR, FRONT Spare Part 16797 159 8078 KV0.020.16.0.00 GEAR: RING STARTER Spare Part 46301 159 8079 KV0.020.18.0.00 BOLT: COLLARED HEX. Spare Part 1957 159 8080 KV0.021.04.0.00 BOLT: CON	8067	KV0.014.22.0.00	GASKET: FLYWHEEL HOUSING COVER	Spare Part	5631	15%
8070 KV0.014.29.0.00 GASKET: FLYWHEEL HOUSING COVER Spare Part 6628 159 8071 KV0.015.02.0.00 O RING Spare Part 385 159 8072 KV0.015.03.0.00 HOSE Spare Part 2705 159 8073 KV0.015.04.0.00 RUBBER HOSE Spare Part 2271 159 8074 KV0.015.05.0.00 HOSE CLAMP : NW S20 Spare Part 735 159 8075 KV0.015.06.0.00 CLAMP : HOSE NW 12 Spare Part 766 159 8076 KV0.015.07.0.00 PIPE BREATHER Spare Part 2677 159 8077 KV0.020.04.0.00 RING : WEAR, FRONT Spare Part 16797 159 8078 KV0.020.16.0.00 GEAR: RING STARTER Spare Part 46301 159 8079 KV0.020.18.0.00 BOLT : COLLARED HEX. Spare Part 1957 159 8080 KV0.021.01.0.00 CON ROD ASSLY Spare Part 1977 159 8081 KV0.021.05.0.00 UPPER	8068	KV0.014.24.0.00	OIL SEAL: REAR	Spare Part	13209	15%
8071 KV0.015.02.0.00 O RING Spare Part 385 159 8072 KV0.015.03.0.00 HOSE Spare Part 2705 159 8073 KV0.015.04.0.00 RUBBER HOSE Spare Part 2271 159 8074 KV0.015.05.0.00 HOSE CLAMP : NW S20 Spare Part 735 159 8075 KV0.015.06.0.00 CLAMP : HOSE NW 12 Spare Part 766 159 8076 KV0.015.07.0.00 PIPE BREATHER Spare Part 2677 159 8077 KV0.020.04.0.00 RING : WEAR, FRONT Spare Part 16797 159 8078 KV0.020.16.0.00 GEAR: RING STARTER Spare Part 46301 159 8079 KV0.020.18.0.00 BOLT : COLLARED HEX. Spare Part 1957 159 8080 KV0.021.01.0.00 CON ROD ASSLY Spare Part 107079 159 8081 KV0.021.05.0.00 UPPER CON ROD BEARING: STD Spare Part 9360 159 8083 KV0.021.11.0.00 PISTON P	8069	KV0.014.25.0.00	SENSOR : TACHO	Spare Part	32747	15%
8072 KV0.015.03.0.00 HOSE Spare Part 2705 159 8073 KV0.015.04.0.00 RUBBER HOSE Spare Part 2271 159 8074 KV0.015.05.0.00 HOSE CLAMP : NW S20 Spare Part 735 159 8075 KV0.015.06.0.00 CLAMP : HOSE NW 12 Spare Part 766 159 8076 KV0.015.07.0.00 PIPE BREATHER Spare Part 2677 159 8077 KV0.020.04.0.00 RING : WEAR, FRONT Spare Part 16797 159 8078 KV0.020.16.0.00 GEAR: RING STARTER Spare Part 46301 159 8079 KV0.020.18.0.00 BOLT : COLLARED HEX. Spare Part 1957 159 8080 KV0.021.01.0.00 CON ROD ASSLY Spare Part 107079 159 8081 KV0.021.04.0.00 BOLT: CON ROD Spare Part 1957 159 8082 KV0.021.05.0.00 UPPER CON ROD BEARING: STD Spare Part 61196 159 8084 KV0.021.12.0.00 <td< td=""><td>8070</td><td>KV0.014.29.0.00</td><td>GASKET: FLYWHEEL HOUSING COVER</td><td>Spare Part</td><td>6628</td><td>15%</td></td<>	8070	KV0.014.29.0.00	GASKET: FLYWHEEL HOUSING COVER	Spare Part	6628	15%
8073 KV0.015.04.0.00 RUBBER HOSE Spare Part 2271 159 8074 KV0.015.05.0.00 HOSE CLAMP : NW S20 Spare Part 735 159 8075 KV0.015.06.0.00 CLAMP : HOSE NW 12 Spare Part 766 159 8076 KV0.015.07.0.00 PIPE BREATHER Spare Part 2677 159 8077 KV0.020.04.0.00 RING : WEAR, FRONT Spare Part 16797 159 8078 KV0.020.16.0.00 GEAR: RING STARTER Spare Part 46301 159 8079 KV0.020.18.0.00 BOLT : COLLARED HEX. Spare Part 1957 159 8080 KV0.021.01.0.00 CON ROD ASSLY Spare Part 107079 159 8081 KV0.021.04.0.00 BOLT: CON ROD Spare Part 1957 159 8082 KV0.021.05.0.00 UPPER CON ROD BEARING: STD Spare Part 9360 159 8083 KV0.021.11.0.00 PISTON Spare Part 61196 159 8084 KV0.021.12.0.00 PISTON PIN Spare Part 9901 159	8071	KV0.015.02.0.00	O RING	Spare Part	385	15%
8074 KV0.015.05.0.00 HOSE CLAMP: NW S20 Spare Part 735 159 8075 KV0.015.06.0.00 CLAMP: HOSE NW 12 Spare Part 766 159 8076 KV0.015.07.0.00 PIPE BREATHER Spare Part 2677 159 8077 KV0.020.04.0.00 RING: WEAR, FRONT Spare Part 16797 159 8078 KV0.020.16.0.00 GEAR: RING STARTER Spare Part 46301 159 8079 KV0.020.18.0.00 BOLT: COLLARED HEX. Spare Part 1957 159 8080 KV0.021.01.0.00 CON ROD ASSLY Spare Part 107079 159 8081 KV0.021.04.0.00 BOLT: CON ROD Spare Part 1957 159 8082 KV0.021.05.0.00 UPPER CON ROD BEARING: STD Spare Part 9360 159 8083 KV0.021.11.0.00 PISTON Spare Part 61196 159 8084 KV0.021.12.0.00 PISTON PIN Spare Part 9901 159	8072	KV0.015.03.0.00	HOSE	Spare Part	2705	15%
8075 KV0.015.06.0.00 CLAMP : HOSE NW 12 Spare Part 766 159 8076 KV0.015.07.0.00 PIPE BREATHER Spare Part 2677 159 8077 KV0.020.04.0.00 RING : WEAR, FRONT Spare Part 16797 159 8078 KV0.020.16.0.00 GEAR: RING STARTER Spare Part 46301 159 8079 KV0.020.18.0.00 BOLT : COLLARED HEX. Spare Part 1957 159 8080 KV0.021.01.0.00 CON ROD ASSLY Spare Part 107079 159 8081 KV0.021.04.0.00 BOLT: CON ROD Spare Part 1957 159 8082 KV0.021.05.0.00 UPPER CON ROD BEARING: STD Spare Part 9360 159 8083 KV0.021.11.0.00 PISTON Spare Part 61196 159 8084 KV0.021.12.0.00 PISTON PIN Spare Part 9901 159	8073	KV0.015.04.0.00	RUBBER HOSE	Spare Part	2271	15%
8076 KV0.015.07.0.00 PIPE BREATHER Spare Part 2677 159 8077 KV0.020.04.0.00 RING : WEAR, FRONT Spare Part 16797 159 8078 KV0.020.16.0.00 GEAR: RING STARTER Spare Part 46301 159 8079 KV0.020.18.0.00 BOLT : COLLARED HEX. Spare Part 1957 159 8080 KV0.021.01.0.00 CON ROD ASSLY Spare Part 107079 159 8081 KV0.021.04.0.00 BOLT: CON ROD Spare Part 1957 159 8082 KV0.021.05.0.00 UPPER CON ROD BEARING: STD Spare Part 9360 159 8083 KV0.021.11.0.00 PISTON Spare Part 61196 159 8084 KV0.021.12.0.00 PISTON PIN Spare Part 9901 159	8074	KV0.015.05.0.00	HOSE CLAMP: NW S20	Spare Part	735	15%
8077 KV0.020.04.0.00 RING: WEAR, FRONT Spare Part 16797 159 8078 KV0.020.16.0.00 GEAR: RING STARTER Spare Part 46301 159 8079 KV0.020.18.0.00 BOLT: COLLARED HEX. Spare Part 1957 159 8080 KV0.021.01.0.00 CON ROD ASSLY Spare Part 107079 159 8081 KV0.021.04.0.00 BOLT: CON ROD Spare Part 1957 159 8082 KV0.021.05.0.00 UPPER CON ROD BEARING: STD Spare Part 9360 159 8083 KV0.021.11.0.00 PISTON Spare Part 61196 159 8084 KV0.021.12.0.00 PISTON PIN Spare Part 9901 159	8075	KV0.015.06.0.00	CLAMP : HOSE NW 12	Spare Part	766	15%
8078 KV0.020.16.0.00 GEAR: RING STARTER Spare Part 46301 159 8079 KV0.020.18.0.00 BOLT: COLLARED HEX. Spare Part 1957 159 8080 KV0.021.01.0.00 CON ROD ASSLY Spare Part 107079 159 8081 KV0.021.04.0.00 BOLT: CON ROD Spare Part 1957 159 8082 KV0.021.05.0.00 UPPER CON ROD BEARING: STD Spare Part 9360 159 8083 KV0.021.11.0.00 PISTON Spare Part 61196 159 8084 KV0.021.12.0.00 PISTON PIN Spare Part 9901 159	8076	KV0.015.07.0.00	PIPE BREATHER	Spare Part	2677	15%
8079 KV0.020.18.0.00 BOLT : COLLARED HEX. Spare Part 1957 159 8080 KV0.021.01.0.00 CON ROD ASSLY Spare Part 107079 159 8081 KV0.021.04.0.00 BOLT : CON ROD Spare Part 1957 159 8082 KV0.021.05.0.00 UPPER CON ROD BEARING: STD Spare Part 9360 159 8083 KV0.021.11.0.00 PISTON Spare Part 61196 159 8084 KV0.021.12.0.00 PISTON PIN Spare Part 9901 159	8077	KV0.020.04.0.00	RING : WEAR, FRONT	Spare Part	16797	15%
8080 KV0.021.01.0.00 CON ROD ASSLY Spare Part 107079 159 8081 KV0.021.04.0.00 BOLT: CON ROD Spare Part 1957 159 8082 KV0.021.05.0.00 UPPER CON ROD BEARING: STD Spare Part 9360 159 8083 KV0.021.11.0.00 PISTON Spare Part 61196 159 8084 KV0.021.12.0.00 PISTON PIN Spare Part 9901 159	8078	KV0.020.16.0.00	GEAR: RING STARTER	Spare Part	46301	15%
8081 KV0.021.04.0.00 BOLT: CON ROD Spare Part 1957 159 8082 KV0.021.05.0.00 UPPER CON ROD BEARING: STD Spare Part 9360 159 8083 KV0.021.11.0.00 PISTON Spare Part 61196 159 8084 KV0.021.12.0.00 PISTON PIN Spare Part 9901 159	8079	KV0.020.18.0.00	BOLT : COLLARED HEX.	Spare Part	1957	15%
8082 KV0.021.05.0.00 UPPER CON ROD BEARING: STD Spare Part 9360 15% 8083 KV0.021.11.0.00 PISTON Spare Part 61196 15% 8084 KV0.021.12.0.00 PISTON PIN Spare Part 9901 15%	8080	KV0.021.01.0.00	CON ROD ASSLY	Spare Part	107079	15%
8083 KV0.021.11.0.00 PISTON Spare Part 61196 159 8084 KV0.021.12.0.00 PISTON PIN Spare Part 9901 159	8081	KV0.021.04.0.00	BOLT: CON ROD	Spare Part	1957	15%
8084 KV0.021.12.0.00 PISTON PIN Spare Part 9901 159	8082	KV0.021.05.0.00	UPPER CON ROD BEARING: STD	Spare Part	9360	15%
	8083	KV0.021.11.0.00	PISTON	Spare Part	61196	15%
8085 KV0.021.13.0.00 SNAP RING Spare Part 532 159	8084	KV0.021.12.0.00	PISTON PIN	Spare Part	9901	15%
	8085	KV0.021.13.0.00	SNAP RING	Spare Part	532	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		·		without Vat in NPR	Charge%
8086	KV0.021.21.0.00	LOWER BEARING CONROD (STD)	Spare Part	8317	15%
8087	KV0.021.23.0.00	LOWER BEARING CONROD	Spare Part	26981	15%
8088	KV0.021.24.0.00	LOWER BEARING CONROD 0 50	Spare Part	24990	15%
8089	KV0.021.31.0.00	CON ROD BUSH	Spare Part	12628	15%
8090	KV0.030.04.0.00	VALVE GUIDE	Spare Part	3012	15%
8091	KV0.030.05.0.00	SEAT INTAKE VALVE	Spare Part	6295	15%
8092	KV0.030.06.0.00	SEAT EXHAUST VALVE	Spare Part	5655	15%
8093	KV0.030.11.0.00	CYLINDER HEAD BOLT	Spare Part	1991	15%
8094	KV0.030.12.0.00	CYLINDER HEAD BOLT	Spare Part	2351	15%
8095	KV0.030.13.0.00	BOLT : CYLINDER HEAD	Spare Part	1578	15%
8096	KV0.030.14.0.00	GASKET: CYLINDER HEAD	Spare Part	18391	15%
8097	KV0.030.18.0.00	BOLT ASSLY M8X45	Spare Part	348	15%
8098	KV0.030.19.0.00	CAP: FILLER	Spare Part	2375	15%
8099	KV0.030.20.0.00	CAP : FILLER	Spare Part	1345	15%
8100	KV0.030.22.0.00	GASKET: CYLINDER HEAD COVER	Spare Part	3163	15%
8101	KV0.030.23.0.00	VALVE GUIDE FINISH	Spare Part	4055	15%
8102	KV0.031.01.0.00	VALVE: INLET	Spare Part	7880	15%
8103	KV0.031.02.0.00	VALVE: EXHAUST	Spare Part	9058	15%
8104	KV0.031.04.0.00	WASHER	Spare Part	117	15%
8105	KV0.031.05.0.00	VALVE SPRING ASSLY	Spare Part	2745	15%
8106	KV0.031.06.0.00	VALVE SPRING (OUTER)	Spare Part	1385	15%
8107	KV0.031.07.0.00	VALVE SPRING (INNER)	Spare Part	1345	15%
8108	KV0.031.08.0.00	VALVE SPRING PLATE	Spare Part	803	15%
8109	KV0.031.09.0.00	COTTER: VALVE	Spare Part	298	15%
8110	KV0.031.10.0.00	VALVE STEM SEAL	Spare Part	1043	15%
8111	KV0.031.13.0.00	SCREW : ADJUST	Spare Part	852	15%
8112	KV0.031.14.0.00	NUT (HEX)	Spare Part	994	15%
8113	KV0.031.14.0.00	PUSH ROD	Spare Part	2375	15%
8114	KV0.041.01.0.00	LUB OIL PUMP ASSEMBLY	Spare Part	170096	15%
8115	KV0.041.03.0.00	WASHER SPRING A8	•	74	15%
8116	KV0.041.05.0.00	GASKET: OIL PIPE	Spare Part Spare Part	397	15%
8117	KV0.041.10.0.00	GASKET: FLANGE	Spare Part	502	15%
8118	KV0.041.10.0.00	LUBE OIL FILTER CARTRIGE	Filter	4864	20%
8119	KV0.043.04.0.00	GASKET: OIL FILTER	Spare Part	1289	15%
8120 8121	KV0.044.03.0.00	GASKET: OIL COOLER	Spare Part	5074 138	15% 15%
	KV0.044.07.0.00	WASHER: SPRING A10 BOLT : SOCKET HEAD	Spare Part	212	15%
8122	KV0.044.08.0.00		Spare Part		
	KV0.044.10.0.00	OIL COOLER ASSEMBLY	Spare Part	220923	15%
8124	KV0.044.12.0.00	GASKET: FLANGE	Spare Part	440	15%
8125	KV0.044.17.0.00	GASKET: COVER HOUSING	Spare Part	7052	15%
	KV0.045.10.0.00	GASKET : OIL COOLER (OLD)	Spare Part	7249	15%
8127	KV0.047.03.0.00	GASKET: FLANGE	Spare Part	388	15%
8128	KV0.047.14.0.00	RING: SEAL A26X32	Spare Part	560	15%
8129	KV0.047.16.0.00	SCREW: HOLLOW	Spare Part	2400	15%
8130	KV0.047.19.0.00	HOSE: TC DRAIN	Spare Part	10394	15%
8131	KV0.047.21.0.00	GASKET: T/C OIL RETURN	Spare Part	523	15%
8132	KV0.049.02.0.00	GASKET: OIL PAN	Spare Part	30766	15%
8133	KV0.049.09.0.00	DRAIN: JOINT ASSLY	Spare Part	18809	15%
8134	KV0.049.14.0.00	GASKET BY PASS FILTER	Spare Part	735	15%
8135	KV0.052.03.0.00	water pipe gasket	Spare Part	6135	15%
8136	KV0.052.06.0.00	HOSE: SIL D75 X 100	Spare Part	11664	15%
8137	KV0.052.07.0.00	CLAMP: HOSE NEW 64	Spare Part	994	15%
8138	KV0.052.12.0.00	GASKET : FLANGE	Spare Part	778	15%
8139	KV0.052.16.0.00	THERMOSTAT ELEMENT	Spare Part	7018	15%
8140	KV0.052.17.0.00	O RING: 60X4	Spare Part	286	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
8141	KV0.052.18.0.00	GASKET: THERMOSTAT	Spare Part	NPR 360	15%
8142	KV0.052.19.0.00	WATER PUMP ASSLY	Spare Part	408139	15%
8143	KV0.052.24.0.00	SEAL : WATER PUMP	Spare Part	12920	15%
8144	KV0.052.32.0.00	GASKET: WATER PUMP	Spare Part	1880	15%
8145	KV0.052.35.0.00	PULLEY V BELT	Spare Part	20378	15%
8146	KV0.052.37.0.00	HOSE SIL D75 X 100	Spare Part	10000	15%
8147	KV0.056.12.0.00	FAN : COOLING	Spare Part	76377	15%
8148	KV0.056.18.0.00	NUT : HEX. M10	Spare Part	132	15%
8149	KV0.056.28.0.00	V BELT: FAN PULLEY AX 52	Spare Part	3612	15%
8150	KV0.056.29.0.00	V BELT: FAN DRIVE 400/500/600 KVA	Spare Part	22707	15%
8151	KV0.056.30.0.00	V BELT: WATER PUMP 400/500/600 KVA	Spare Part	21498	15%
8152	KV0.082.04.0.00	GASKET: EXHAUST M'FOLD	Spare Part	1662	15%
8153	KV0.082.06.0.00	WASHER	Spare Part	431	15%
8154	KV0.082.07.0.00	BOLT : HEX	Spare Part	538	15%
8155	KV0.082.09.0.00	EXHAUST MANIFOLD	Spare Part	146546	15%
8156	KV0.082.16.0.00	EXHAUST MANIFOLD	Spare Part	81740	15%
8157	KV0.082.17.0.00	RING: LAMINATED	Spare Part	1843	15%
8158	KV0.082.18.0.00	GASKET: EXHAUST M'FOLD	Spare Part	1462	15%
8159	KV0.082.19.0.00	BOLT: HEX	Spare Part	643	15%
8160	KV0.082.20.0.00	Spacer : Exhaust Manifold	Spare Part	2588	15%
8161	KV0.085.02.0.00	GASKET: INTAKE M'FOLD 400/500/600 KVA	Spare Part	994	15%
8162	KV0.085.04.0.00	GASKET: INTAKE M'FOLD 400KVA	Spare Part	1911	15%
8163	KV0.085.10.0.00	HOSE, TC INLET	Spare Part	17667	15%
8164	KV0.085.21.0.00	RUBBER HOSE	Spare Part	12557	15%
8165	KV0.085.22.0.00	HOSE CLAMP	Spare Part	1160	15%
8166	KV0.085.33.0.00	GASKET: INTERCOOLER	Spare Part	2708	15%
8167	KV0.087.02.0.00	TURBOCHARGER ASSLY	Spare Part	549870	15%
8168	KV0.087.05.0.00	TURBOCHARGER ASSLY	Spare Part	463803	15%
8169	KV0.087.08.0.00	GASKET: TURBOCHARGER	Spare Part	2105	15%
8170	KV0.087.10.0.00	BOLT : STUD	Spare Part	769	15%
8171	KV0.087.12.0.00	NUT : HEX. M10	Spare Part	360	15%
8172	KV0.100.01.0.00	NOZZLE & HOLDER ASSLY	Spare Part	77710	15%
8173	KV0.100.02.0.00	NOZZLE	Spare Part	53242	15%
8174	KV0.100.03.0.00	SCREW: PRESSURE	Spare Part	2692	15%
8175	KV0.100.04.0.00	RING: SEAL	Spare Part	169	15%
8176	KV0.100.05.0.00	SEAL: NOZZLE HOLDER	Spare Part	172	15%
8177	KV0.105.06.0.00	SCREW: HOLLOW	Spare Part	917	15%
8178	KV0.105.09.0.00	PIECE CONNECTION	Spare Part	4988	15%
8179	KV0.105.12.0.00	FUEL FILTER ASSLY	Spare Part	20498	15%
8180	KV0.105.25.0.00	O RING	Spare Part	7446	15%
8181	KV0.105.26.0.00	O RING	Spare Part	16726	15%
8182	KV0.105.31.0.00	PRIMING PUMP	Spare Part	18864	15%
8183	KV0.105.32.0.00	FUEL STRAINER	Spare Part	38901	15%
8184	KV0.105.33.0.00	FUEL FILTER ELEMENT	Filter	8781	20%
8185	KV0.105.34.0.00	CONTROLLER ACTUATOR	Spare Part	422585	15%
8186	KV0.108.01.0.00	HOSE: RUBBER (FEED) PUMP TO FILTER	Spare Part	15806	15%
8187	KV0.108.03.0.00	RUBBER HOSE: FILTER TO PUMP	Spare Part	13809	15%
8188	KV0.108.08.0.00	GASKET	Spare Part	425	15%
8189	KV0.108.09.0.00	UNION : BANJO, DOUBLE	Spare Part	3763	15%
8190	KV0.108.10.0.00	VALVE : OVERFLOW	Spare Part	3628	15%
8191	KV0.108.11.0.00	TUBE	Spare Part	14427	15%
8192	KV0.108.12.0.00	RING: SEAL A8X14	Spare Part	111	15%
8193	KV0.108.13.0.00	SCREW: HOLLOW	Spare Part	1049	15%
8194	KV0.108.15.0.00	FUEL PIPE	Spare Part	13769	15%
8195	KV0.108.17.0.00	O RING	Spare Part	600	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
0			,	without Vat in	Charge%
8196	KV0.108.18.0.00	SCREW: HOLLOW	Spare Part	NPR 895	15%
8197	KV0.108.19.0.00	SCREW : HOLLOW	Spare Part	1945	15%
8198	KV0.108.20.0.00	TENSION BAND	Spare Part	25	15%
8199	KV0.108.22.0.00	PIPE FUEL 500 600KVA	Spare Part	3751	15%
8200	KV0.108.34.0.00	HOSE FUEL FOR 500 AND 600 KVA	Spare Part	12449	15%
8201	KV0.108.35.0.00	HOSE FUEL FOR 500 KVA	Spare Part	12741	15%
8202	KV0.109.05.0.00	RING : SEAL A10X16	Spare Part	169	15%
8203	KV0.110.01.0.00	FUEL FILTER ASSLY	Filter	5248	20%
8204	KV0.110.02.0.00	FUEL FILTER ASSEMBLY (GLASS TYPE 500/600 KVA)	Spare Part	15292	15%
8205	KV0.140.23.0.00	ALTERNATOR: BATTERY CHARGING	Spare Part	154503	15%
8206	KV0.175.08.0.00	PIPE : COOLING WATER	Spare Part	5861	15%
8207	KV0.260.01.0.00	STARTER	Spare Part	354091	15%
8208	KV0.505.02.0.00	AIR CLEANER PRIMARY ELEMENT	Filter	8976	20%
8209				4954	20%
	KV0.505.03.0.00	AIR CLEANER SAFETY ELEMENT	Filter		
8210	KV0.505.09.0.00	STRAP FOR AIR CLEANER FOR 10K18TA DIA 12	Spare Part	1625	15%
8211	KV0.505.10.0.00	AIR CLEANER ASSEMBLY FOR 10K18TA ENGINE	Spare Part	35178	15%
8212	KV0.505.13.0.00	HOSE T BOLT CLAMP: 130MM OD	Spare Part	258	15%
8213	KV0.505.14.0.00	HOSE BOLT CLAMP: 137MM OD	Spare Part	335	15%
8214	KV0.905.10.0.00	ENGINE WIRING HARNESS WITH EMS907	Spare Part	16052	15%
8215	KV2.045.10.0.00	GASKET : OIL COOLER (NEW)	Spare Part	10009	15%
8216	KV2.050.08.0.00	GASKET: OIL PAN	Spare Part	37713	15%
8217	KV2.086.11.0.00	CLAMP: HOSE	Spare Part	2323	15%
8218	KV2.086.21.0.00	HOSE SIL D100 X 90	Spare Part	17381	15%
8219	KV2.108.02.0.00	HOSE: RUBBER, FEED PUMP TO FILTER	Spare Part	19634	15%
8220	KV2.108.04.0.00	RUBBER HOSE: FILTER TO FEED PUMP	Spare Part	14360	15%
8221	KV2.505.02.0.00	AIR CLEANER PRIMARY ELEMENT	Filter	11006	20%
8222	KV2.505.03.0.00	AIR CLEANER SAFETY ELEMENT	Filter	5084	20%
8223	KV2.505.10.0.00	AIR CLEANER	Spare Part	51101	20%
8224	KV2.505.12.0.00	STRAP FOR AIR CLEANER FOR 12K22TA DIA 14"	Spare Part	1951	15%
8225	KV2.505.13.0.00	AIR INLET CAP	Spare Part	3865	15%
8226	KV2.505.14.0.00	HOSE T BOLT CLAMP: 150MM OD	Spare Part	360	15%
8227	KV2.505.20.0.00	AIR CLEANER	Spare Part	52072	20%
8228	KV2.506.20.0.00	FUEL PRE FILTER ASSLY	Filter	1757	20%
8229	KV2.508.01.0.00	WATER COOLED CAC FOR 12K22TA HEAT DOUBLE PASS	Spare Part	425810	15%
8230	KV2.508.14.0.00	STUD FOR BALANCE WATER TANK 370MM LENGTH	Spare Part	218	15%
8231	KV2.509.01.0.00	FUEL PIPE INLET HOSE: FEED PUMP TO PRE FILTER	Spare Part	6126	15%
8232	KV2.509.02.0.00	FUEL PIPE RETURN HOSE 2200MM	Spare Part	5751	15%
8233	KV2.509.03.0.00	FUEL PIPE- SUCTION: 12K22TA	Spare Part	2234	15%
8234	KV2.528.10.0.00	PRE CLEANER ASSLY	Filter	24796	20%
8235	KV2.801.13.0.00	AUTO VOL REGULATOR : AVR-R450	Spare Part	222265	15%
8236	KV2.901.04.0.00	EARTHING CABLE 25 3 850 MM LENGTH 50 SQMM FOR ALT TO PANEL	Spare Part	2754	15%
8237	KV8.040.01.0.00	LUB OIL PUMP ASSEMBLY	Spare Part	109371	15%
8238	KV8.040.10.0.00	GASKET OIL PIPE	Spare Part	385	15%
8239	KV8.046.02.0.00	OIL PIPE	Spare Part	5018	15%
8240	KV8.046.04.0.00	GASKET: FLANGE	Spare Part	425	15%
8241	KV8.048.02.0.00	GASKET : OIL PAN	Spare Part	33187	15%
8242	KV8.048.09.0.00	GASKET : OIL PAN	Spare Part	71	15%
8243	KV8.084.07.0.00	HOSE: TC INLET 400	Spare Part	3357	15%
8244	KV8.084.15.0.00	CLAMP HOSE	Spare Part	8231	15%
8245	KV8.084.22.0.00	CLAMP: HOSE, BAND TYPE	Spare Part	1200	15%
8246	KV8.087.01.0.00	TURBOCHARGER ASSLY	Spare Part	335528	15%
8247	KV8.087.07.0.00	GASKET: TURBOCHARGER	Spare Part	1071	15%
8248	KV8.087.09.0.00	BOLT: STUD	Spare Part	271	15%
8249	KV8.107.04.0.00	RUBBER HOSE: FEED PUMP TO FILTER	Spare Part	14609	15%
8250	KV8.107.05.0.00	RUBBER HOSE: FILTER TO FEED PUMP	Spare Part	14074	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
8251	KV8.107.12.0.00	TUBE	Spare Part	18221	15%
8252	KV8.107.15.0.00	FUEL PIPE	Spare Part	11566	15%
8253	KV8.175.02.0.00	HOSE: ENGINE WATER OUT CONNECT PIPE	Spare Part	1591	15%
8254	KV8.175.03.0.00	PIPE COOLING WATER	Spare Part	37833	15%
8255	KV8.175.04.0.00	HOSE: ENGINE WATER IN CONNECT PIPE	Spare Part	1409	15%
8256	KV8.175.06.0.00	HOSE FOR BALANCE WATER PIPE	Spare Part	323	15%
8257	KV8.175.12.0.00	RUBBER HOSE	Spare Part	67765	15%
8258	KV8.175.14.0.00	AIR VENT PIPE	Spare Part	6668	15%
8259	KV8.182.10.0.00	WATER PUMP ASSEMBLY	Spare Part	424450	15%
8260	KV8.185.01.0.00	HEAD OIL FILTER SINGLE SUITABLE FOR 400KVA	Spare Part	59233	15%
8261	KV8.500.03.0.00	ANTI VIBRATION MOUNTS	Spare Part	4012	15%
8262	KV8.500.04.0.00	ANTI VIBRATION MOUNT 80 SHORE RR 400 CRS 147 5MM CORI RUBBER MAKE	Spare Part	5994	15%
8263	KV8.505.02.0.00	AIR CLEANER PRIMARY ELEMENT	Filter	8057	20%
8264	KV8.505.03.0.00	AIR CLEANER SAFETY ELEMENT	Filter	3852	20%
8265	KV8.505.10.0.00	AIR CLEANER	Spare Part	37167	20%
8266	KV8.505.12.0.00	HOSE T BOLT CLAMP FOR OD 92MM	Spare Part	185	15%
8267	KV8.505.13.0.00	HOSE T BOLT CLAMP: 112MM OD	Spare Part	191	15%
8268	KV8.505.25.0.00	SUCTION HOSE: 8K15TA ENGINE	Spare Part	5668	15%
8269	KV8.505.28.0.00	HOSE T BOLT CLAMP 138 MM ID	Spare Part	424	20%
8270	KV8.507.01.0.00	FUEL PIPE INLET HOSE: 2000MM L	Spare Part	6034	15%
8271	KV8.801.11.0.00	AVR MODEL TAVR-18	Spare Part	44975	15%
8272	KV8.801.14.0.00	ROATATING RECTIFIER ASSEMBLY WITH 6 NOS. DIODES AND HEAT SINK ALTERNATOR FRAME T	Spare Part	25080	15%
8273	KV8.801.33.0.00	VARISTER (PART NO.AG4050820000) S/F TRIDENT ALTERNATOR FRAME TA 354S0/S1/S2/MO/M1/T	Spare Part	557	15%
8274	KV8.853.05.0.00	24 V DC RELAY BOARD 2CH. (70 AMP.) 1C/O. BATTERY -VE SIGNAL,DIN MOUNTED	Spare Part	5212	15%
8275	KV8.853.22.0.00	ADAPTOR 1 8 NPT x M10x1 5	Spare Part	111	15%
8276	L.019.5.10.013	BUSH	Spare Part	455	15%
8277	L.019.5.20.003	BRG.B	Spare Part	871	15%
8278	L.019.5.20.013	BRG.B	Spare Part	991	15%
8279	M.006.4.00.003	MAIN BEARING: 6R1080 STD	Spare Part	6649	15%
8280	M.006.4.00.013	MAIN BRG: 6R1080 0.25	Spare Part	6541	15%
8281	M.006.4.00.023	MAIN BEARING: 6R1080 020	Spare Part	6526	15%
8282	M.006.4.00.033	MAIN BEARING 030	Spare Part	7172	15%
8283	M.020.3.00.003	MAIN BRG	Spare Part	351	15%
8284	M.038.4.01.003	MAIN BEARING: RA3 T&B G	Spare Part	2249	15%
8285	M.038.4.01.013	MAIN BEARING: RA3 T&B G	Spare Part	2311	15%
8286	M.038.4.01.023	MAIN BEARING: RA2 T&B G	Spare Part	2203	15%
8287	M.038.4.01.033	MAIN BEARING 030	Spare Part	2305	15%
8288	M.040.4.01.003	MAIN BEARING	Spare Part	2803	15%
8289	M.040.4.01.023	MAIN BEARING 020		2883	15%
8290	M.055.4.00.003	MAIN BEARING: SL90	Spare Part Spare Part	12031	15%
8291	M.055.4.00.013	MAIN BEARING: SL90 010	Spare Part	12031	15%
8292	M.055.4.00.023	MAIN BEARING 020	Spare Part	11954	15%
8293	M.055.4.00.023	BEARING MAIN KIR SL90	Spare Part	8049	15%
			· · · · · · · · · · · · · · · · · · ·		
8294	M.070.4.00.003	TOP TWO HOLE BEARING MAIN KIR 4R810 STD	Spare Part	1332	15%
8295	M.073.4.00.003	MAIN BEARING: HA394	Spare Part	3046	15%
8296	M.073.4.00.013	MAIN BEARING: HA 394	Spare Part	3169	15%
8297	M.073.4.00.023	MAIN BEARING: HA394	Spare Part	3169	15%
8298	M.073.4.00.033	MAIN BEARING: HA394	Spare Part	3169	15%
8299	M.074.4.00.003	MAIN BEARING: HA494	Spare Part	3991	15%
8300	M.074.4.00.013	MAIN BEARING: HA 494	Spare Part	3960	15%
8301	M.074.4.00.023	MAIN BEARING: HA494	Spare Part	4157	15%
8302	M.074.4.00.033	MAIN BEARING: HA494	Spare Part	3960	15%
8303	M.074.4.00.043	MAIN BEARING 040	Spare Part	4280	15%
8304	M.075.4.00.003	MAIN BEARING: HA694	Spare Part	5326	15%
8305	M.075.4.00.013	MAIN BEARING: HA694	Spare Part	5818	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		, , 5.500 , pno		without Vat in	Charge%
8306	M.075.4.00.023	MAIN BEARING: HA694 020	Spare Part	NPR 5541	15%
8307	M.093.4.00.003	MAIN BEARING: HA294	Spare Part	2391	15%
8308	M.093.4.00.013	MAIN BEARING 010	Spare Part	2489	15%
8309	M.093.4.00.023	MAIN BEARING 020	Spare Part	2489	15%
8310	M.093.4.00.033	MAIN BEARING 030	Spare Part	2489	15%
8311	M.547.4.00.003	MAIN BEARING: DV10 STD	Spare Part	7911	15%
8312	M.552.4.00.003	MAIN BEARING: 4R810 STD	Spare Part	1800	15%
8313	M.553.4.00.003	MAIN BEARING: 6K1080TA STD	Spare Part	9412	15%
8314	M.553.4.10.003	MAIN BEARING: 4K1080 STD	Spare Part	7234	15%
8315	M.554.4.00.003	BEARING MAIN KIR 6K1080ETA CRDi, STD	Spare Part	5218	15%
8316	N11.051.01.0.00	FLANGED SCREW M6 X 1 0 X 10	Spare Part	12	15%
8317	N11.051.02.0.00	FLANGED NUT M6 X 1.0		9	15%
8318			Spare Part	31	
	N11.051.05.0.00	FLANGED NUT M8 X 1 25	Spare Part	15	15%
8319	N11.051.06.0.00	FLANGED SCREW - M6 X 1.0 X 12 MM	Spare Part		15%
8320	OWC.MMF.125.02.SP	HUMIDITY SENSOR BOLT M10X80 HEX BOLT SS HHB1080 SS	Spare Part	206	15%
8321	OWC.MMF.125.16.SP	GAS SPRING SIZE 12 CAPACITY 10 KG BGS1210	Spare Part	2914	15%
8322	OWC.MMF.125.26.SP	Bacteria Soil for 125 Kg i Land Machine 60kg	Spare Part	10834	15%
8323	OWC.MMF.25.05.SP	HUMIDITY SENSOR PLATE 100X50X12 SP 70	Spare Part	929	15%
8324	OWC.MMF.25.06.SP	HUMIDITY SENSOR BUSH x19X18 SP 70	Spare Part	255	15%
8325	OWC.MMF.25.07.SP	HUMIDITY SENSOR WASHER x19X4 5 SP 70	Spare Part	212	15%
8326	OWC.MMF.25.09.SP	PLAIN WASHER M10 PLAIN WASHER SS HPW10 SS	Spare Part	15	15%
8327	OWC.MMF.25.16.SP	HUMIDITY ELECTRONICS BOX EHB001	Spare Part	9652	15%
8328	OWC.MMF.25.18.SP	TEMPERATURE SENSOR PT 100 OUTSIDE TANK 6 MM RING TYPE PT100 3 MTR ETSO0603100	Spare Part	3323	15%
8329	OWC.MMF.25.19.SP	TEMPERATURE SENSOR PT 100 INSIDE TANK 6 MM X 25 MM PT100 BSP 3 MTR ETSI0603100	Spare Part	2914	15%
8330	OWC.MMF.25.21.SP	OIL SEAL 40X52X7 ADL RUBBER OD DOUBLE LIP WITH GARTER SPRING BOS04007	Spare Part	206	15%
8331	OWC.MMF.25.30.SP	GAS SPRING SIZE 9 CAPACITY 5 KG BGS0905	Spare Part	1449	15%
8332	OWC.MMF.25.44.SP	Bacteria Soil for 25 Kg i Land Machine 12kg	Spare Part	2169	15%
8333	OWC.MMF.250.04.SP	HOSE PIPE 4 PIPE HP400	Spare Part	3225	15%
8334	OWC.MMF.250.05.SP	HOSE PIPE CLIP 5 PIPE CLIP HC500	Spare Part	462	15%
8335	OWC.MMF.250.06.SP	OIL SEAL 80X100X8 ADL RUBBER OD DOUBLE LIP WITH GARTER SPRING BOS08008	Spare Part	449	15%
8336	OWC.MMF.250.15.SP	GAS SPRING 15 KG GS	Spare Part	2914	15%
8337	OWC.MMF.250.25.SP	CERAMIC HEATER 1500 W 35 X5 415 VAC ECH15003505	Spare Part	20200	15%
8338	OWC.MMF.250.27.SP	OIL SEAL 90X110X10 ADL RUBBER OD DOUBLE LIP WITH GARTER SPRING BOS09010	Spare Part	449	15%
8339	OWC.MMF.500.02.SP	HUMIDITY SENSOR BUSH x19X11 5 SP 70	Spare Part	255	15%
8340	OWC.MMF.500.03.SP	COMPOST DOOR HINGE FLAT HINGE DHIM 10080 BFH10080	Spare Part	3680	15%
8341	OWC.MMF.500.18.SP	Bacteria Soil for 500 Kg i Land Machine 350kg	Spare Part	63187	15%
8342	OWC.MMF.700.45.SP	MAIN MOTOR FOR GEAR DRIVE RATING 5 5 KW 7 HP 415 VAC KI 700 MOTOR GA	Spare Part	121165	15%
8343	OWC.MMF.75.04.SP	GAS SPRING 10KG BGS1210	Spare Part	2914	15%
8344	OWC.MMF.75.19.SP	BLOWER MOTOR 300 CFM 90 W 230 VAC EBM300090	Spare Part	26837	15%
8345	OWC.MMF.75.20.SP	CERAMIC HEATER 500 WATTS 415 VAC 24 X 3 ECH5002403	Spare Part	7554	15%
8346	OWC.MMF.75.23.SP	Bacteria Soil for 75 Kg i Land Machine 35kg	Spare Part	6320	15%
8347	OWC.MMF.75.45.SP	MAIN MOTOR FOR GEAR DRIVE RATING 0 37 KW 0 5HP 415 VAC KI 75	Spare Part	25320	15%
8348	OWC.MMF.75.46.SP	HELICAL GEARBOX FOR KI 75	Spare Part	123580	15%
8349	P08.0001.012.0.00	BUSH BEARING	Spare Part	243	15%
8350	P1.007.09.0.00	GASKET: CYLINDER HEAD 2CYL 1.22 THK	Spare Part	1249	15%
8351	P1.011.10.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	1560	15%
8352	P1.036.01.0.00	EXHAUST MANIFOLD	Spare Part	2754	15%
8353	P2.005.10.0.00	LUB OIL PUMP ASSLY	Spare Part	9600	15%
8354	P2.007.03.9.00	VALVE SEAT INSERT: EXHAUST	Spare Part	378	15%
8355	P2.007.06.0.00	EXHAUST VALVE (CHROME PLATED)	Spare Part	1262	15%
8356	P2.007.40.0.00	VALVE PAIR	Spare Part	2603	15%
8357	P2.015.04.0.00	BELT XPA 1232	Spare Part	997	15%
8358	P2.020.09.0.00	DEFLECTOR FOR OIL SEAL	Spare Part	446	15%
8359	P2.021.03.0.00	O RING	Spare Part	28	15%
			Spa.s. uit	0	.570



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in	Custom Charge%
				NPR	enange/s
8361	P2.036.01.0.00	EXHAUST MANIFOLD	Spare Part	4280	15%
8362	P2.038.17.0.00	COVER PLATE	Spare Part	517	15%
8363	P2.039.07.0.00	CAP ASSEMBLY	Spare Part	357	15%
8364	P2.049.20.0.00	DRIVE SHAFT ASSLY	Spare Part	1754	15%
8365	P2.051.10.0.00	WATER PUMP ASSLY	Spare Part	9951	15%
8366	P2.066.30.0.00	THERMOSTAT HOUSING	Spare Part	5997	15%
8367	P2.075.03.0.00	JOINT	Spare Part	65	15%
8368	P2.093.50.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	2462	15%
8369	P2.100.10.0.00	CRANKCASE W/O BEARINGS	Spare Part	144552	15%
8370	P2.100.40.0.00	MONOBLOCK CRANKCASE LINE BEARING OPERATION	Spare Part	197453	15%
8371	P2.101.02.0.00	JOINT: GEAR CASING 3R860 WR	Spare Part	560	15%
8372	P2.106.01.0.00	S.S. JOINT FOR EXHAUST MANIFOLD	Spare Part	108	15%
8373	P2.114.01.0.00	FUEL PIPE FEED TO FILTER	Spare Part	594	15%
8374	P2.114.02.0.00	FUEL PIPE FUEL FILTER TO FIP	Spare Part	483	15%
8375	P2.118.02.0.00	ADAPTOR (FOR SPIN-ON TYPE FILTER)	Spare Part	382	15%
8376	P2.121.03.0.00	JOINT: FUEL PUMP GEAR COVER	Spare Part	138	15%
8377	P2.124.01.0.00	CRANK SHAFT PULLEY	Spare Part	4643	15%
8378	P2.127.10.0.00	LEAK OFF PIPE	Spare Part	692	15%
8379	P3.010.10.0.00	VALVE ROCKER ASSEMBLY	Spare Part	6160	15%
8380	P4.041.01.0.00	LUBE OIL COOLER	Spare Part	5771	20%
8381	P4.041.02.0.00	WATER PIPE (FROM CRANKCASE TO OIL COOLER)	Spare Part	957	15%
8382	P4.041.03.0.00	WATER PIPE (FROM OIL COOLER TO CRANKCASE)	Spare Part	978	15%
8383	P5.005.20.0.00	CRANKSHAFT ASSLY.WITH CR.GEAR	Spare Part	68993	15%
8384	P5.013.02.0.00	LIFTING HOOK	Spare Part	911	15%
8385	P5.014.01.0.00	OIL FILLING BODY	Spare Part	705	15%
8386	P5.036.02.0.00	JONT FOR EXHAUST MANIFOLD (NON ASBESTOS)	Spare Part	194	15%
8387	P5.041.01.0.00	BREATHER PIPE	Spare Part	622	15%
8388	P5.046.01.0.00	TENSION ADJUSTING LEVER	Spare Part	462	15%
8389	P5.046.03.0.00	SPACER BOLT	Spare Part	148	15%
8390	P5.046.04.0.00	ALTERNETOR MTG BKT	Spare Part	2034	15%
8391	P5.075.02.0.00	FLYWHEEL HOUSING (S/F ACE TRACTOR)	Spare Part	25277	15%
8392	P5.076.01.0.00	LUB OIL SUMP	Spare Part	16351	15%
8393	P5.078.10.0.00	DIPSTICK ASSLY	Spare Part	185	15%
8394	P5.079.01.0.00	BELT SPAX 1220	Spare Part	871	15%
8395	S.006.5.00.703	BRG BUSH S/E: 6R1080 ENG SE	Spare Part	1486	15%
8396	S.034.5.00.703	BEARING BUSH	Spare Part	649	15%
8397	S.038.5.01.003	SMALL END BUSH	Spare Part	809	15%
8398	S.038.5.01.703	BEARING BUSH S/E: RA3	Spare Part	686	15%
8399	S.051.5.00.003	BEARING Small End bush	Spare Part	1058	15%
8400	S.051.5.00.703	BEARING BUSH S/E: RBV3	Spare Part	920	15%
8401	S.052.5.00.703	BEARING BUSH S/E: RBV4	Spare Part	1228	15%
8402	S.055.5.00.703	BEARING BUSH S/E: SL90	Spare Part	4421	15%
8403	S.055.5.20.703	SMALL END BUSH	Spare Part	4821	15%
8404	S.073.5.00.003	BUSH BEARING S/E: HA394	Spare Part	871	15%
8405	S.073.5.00.703	BUSH BEARING S/E: HA394	Spare Part	831	15%
8406	S.074.5.00.003	BEARING BUSH S/E: HA494	Spare Part	1160	15%
8407	S.074.5.00.703	BEARING BUSH S/E KIR HA 494	Spare Part	1160	15%
8408	S.075.5.00.003	BEARING BUSH S/E: HA694	Spare Part	1828	15%
8409	S.075.5.00.703	BEARING BUSH S/E KIR HA 694	Spare Part	1828	15%
8410	S.093.5.00.003	BEARING BUSH S/E: HA294	Spare Part	594	15%
8411	S.093.5.00.703	BUSH BEARING S/E: HA294	Spare Part	615	15%
8412	S.547.5.00.703	BEARING Small End bush	Spare Part	7261	15%
8413	S.552.5.00.703	BEARING BUSH S/E: 4R810 STD UB	Spare Part	855	15%
8414	S.553.5.00.703	BEARING BUSH S/E: 6K1080TA STD	Spare Part	2338	15%
8415	S.553.5.10.703	BEARING Small End bush	Spare Part	1628	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
				without Vat in NPR	Charge%
8416	SCL.0001.240.0.00	CONTACTOR SPARE COIL FOR 25 40 A 240 VAC FOR FRAME 1 KOEL MAKE	Spare Part	822	15%
	SCL.0002.240.0.00	CONTACTOR SPARE COIL FOR 50 63 A 240 VAC FOR FRAME 2 KOEL MAKE	Spare Part	966	15%
	SCL.0006.240.0.00	CONTACTOR SPARE COIL FOR 250 A 240 VAC FOR FRAME 6 KOEL MAKE	Spare Part	14483	15%
-	SCL.0034.240.0.00	CONTACTOR SPARE COIL FOR 80 - 130 A , 240 VAC	Spare Part	2757	15%
-	SCL.0072.240.0.00	CONTACTOR SPARE COIL FOR 400A 240 VAC FOR FRAME 7.2 KOEL MAKE	Spare Part	17591	15%
	T1.001.12.0.00	DOWEL DIA 18 (FWE)	Spare Part	34	15%
	T1.001.16.0.00	BUSH FOR CRANKCASE OIL METERING	Spare Part	25	15%
	T1.002.04.0.00	O RING: CYLINDER LINER- VITON	Spare Part	135	15%
	T1.003.03.0.00	CRANKSHAFT GEAR	Spare Part	3095	15%
	T1.006.02.0.00	CAMSHAFT GEAR	Spare Part	3443	15%
	T1.006.03.0.00	THRUST PLATE	Spare Part	385	15%
	T1.006.10.0.00	SUB ASSLY OF CAMSHAFT	Spare Part	31132	15%
	T1.007.10.0.00	LUB OIL PUMP ASSEMBLY	 	8089	15%
			Spare Part	225	
	T1.008.03.0.00	BRACKET FOR SUCTION TUBE	Spare Part		15%
	T1.008.05.0.00	JOINT: SUCTION TUBE	Spare Part	15	15%
-	T1.009.01.0.00	DELIVERY TUBE	Spare Part	234	15%
	T1.010.03.0.00	GEAR SUPPORT	Spare Part	1834	15%
	T1.010.04.0.00	RETAINING PLATE INTERMEDIATE GEAR	Spare Part	323	15%
	T1.010.10.0.00	ASSEMBLY OF INTERMEDIATE GEAR	Spare Part	2329	15%
	T1.011.01.0.00	FUEL PUMP GEAR	Spare Part	3637	15%
-	T1.011.03.0.00	HUB FOR FUEL PUMP FEAR	Spare Part	775	15%
	T1.013.01.0.00	GEAR CASING	Spare Part	7701	15%
8438	T1.013.02.0.00	JOINT: GEAR COVER	Spare Part	825	15%
8439	T1.016.02.0.00	VALVE GUIDE FINISH	Spare Part	280	15%
8440	T1.016.02.9.00	VALVE GUIDE (SEMI-FINISH)	Spare Part	218	15%
8441	T1.016.07.0.00	CYLINDER HEAD BOLT	Spare Part	182	15%
8442	T1.017.02.0.00	JOINT: WATER PUMP	Spare Part	126	15%
8443	T1.017.30.0.00	WATER PUMP ASSLY	Spare Part	9541	15%
8444	T1.017.50.0.00	WATER PUMP ASSEMBLY-FOR CRANE	Spare Part	9988	15%
8445	T1.019.03.0.00	STARTER RING	Spare Part	3212	15%
8446	T1.020.01.0.00	PUSH ROD	Spare Part	163	15%
8447	T1.023.28.0.00	INJECTOR	Spare Part	8815	15%
8448	T1.024.02.0.00	JOINT: ROCKER COVER	Spare Part	108	15%
8449	T1.025.02.0.00	JOINT: INLET M'FOLD	Spare Part	37	15%
8450	T1.026.02.0.00	GASKET: EXHAUST M'FOLD	Spare Part	222	15%
8451	T1.026.03.0.00	SPACER (ID 8.5 X OD 13 X 29 L)	Spare Part	25	15%
8452	T1.026.04.0.00	COPPER COATED ALLEN BOLT- 50.011.08.050	Spare Part	95	15%
8453	T1.035.01.0.00	COVER FOR FUEL PUMP BORE	Spare Part	1698	15%
8454	T1.036.01.0.00	HEADER FOR SPIN ON TYPE FILTER	Spare Part	1314	15%
8455	T1.036.02.0.00	JOINT: LUBE OIL HEADER	Spare Part	34	15%
8456	T1.037.02.0.00	JOINT: THERMOSTAT COVER	Spare Part	43	15%
8457	T1.039.10.0.00	DIPSTICK ASSLY	Spare Part	95	15%
8458	T1.039.20.0.00	DIPSTICK ASSEMBLY	Spare Part	132	15%
8459	T1.040.07.0.00	JOINT: BRAETHER HOUSING	Spare Part	31	15%
	T1.040.30.0.00	BRATHER BOX ASSEMBLY	Spare Part	2409	15%
	T1.047.30.0.00	LEAK OFF PIPE ASSEMBLY	Spare Part	920	15%
-	T1.050.02.0.00	PISTON PIN	Spare Part	462	15%
-	T1.050.10.0.00	PISTON RING SET	Spare Part	1446	15%
	T1.050.20.0.00	PISTON ASSEMBLY	Spare Part	6320	15%
	T1.050.90.0.SP	PISTON ASSEMBLY	Spare Part	5095	15%
	T1.057.02.9.00	VALVE SEAT INSERT: INLET	Spare Part	508	15%
-	T1.057.03.9.00	VALVE SEAT INSERT: EXHAUST	Spare Part	523	15%
-	T1.057.90.0.00	VALVE PAIR	Spare Part	1446	15%
			· · · · · · · · · · · · · · · · · · ·		
	T1.058.10.0.00	CYL LINER ASSEMBLY	Spare Part	3274	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
31.140.		18.125681.		without Vat in	Charge%
8471	T1.074.20.0.00	CRANKSAHFT ASSEMBLY	Spare Part	71959	15%
8472	T1.077.01.0.00	CRANK PULLEY (EICHER)	Spare Part	4498	15%
8473	T1.091.01.0.00	EXHAUST MANIFOLD	Spare Part	5437	15%
8474	T3.007.01.0.00	FUEL PIPES FUEL FILTER TO FIP FOR ACE TRACTOR	Spare Part	815	15%
8475	T3.007.02.0.00	FUEL PIPES FEED PUMP TO FUEL FILTER FOR ACE TRACTOR	Spare Part	960	15%
8476	T3.009.03.0.PR	CYLINDER HEAD GASKET 1 22 MM THICK	Spare Part	1972	15%
8477	T4.003.10.0.00	SUB ASM. OF CAM SHAFT	Spare Part	31252	15%
8478	T4.003.10.0.00	SUCTION TUBE	Spare Part	305	15%
8479	T4.004.10.0.00	INLET MANIFOLD (GE SIDE TOP OPENING)	Spare Part	8348	15%
				7658	15%
8480	T4.009.15.0.00	INLET MANIFOLD (COLD SIDE) ROCKER SHAFT ASSEMBLY WITH SPRING	Spare Part	9603	15%
8481	T4.012.60.0.00		Spare Part		15%
8482	T4.013.20.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	4021	
8483	T4.013.220.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	5418	15%
8484	T4.013.30.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	3095	15%
8485	T4.015.01.0.00	ROCKER COVER	Spare Part	5105	15%
8486	T4.015.02.0.00	JOINT: ROCKER COVER	Spare Part	323	15%
8487	T4.015.05.0.00	JOINT FOR ROCKER COVER	Spare Part	1843	15%
8488	T4.019.013.0.SP	500 Hrs B Check Maintenance Kit	Spare Part	7255	20%
8489	T4.019.03.0.00	FUEL FILTER BRACKET	Spare Part	652	15%
8490	T4.019.15.0.SP	1500 Hrs C Check Maintenance Kit	Spare Part	15292	20%
8491	T4.020.01.0.00	AIR INLET MANIFOLD, JCB	Spare Part	5960	15%
8492	T4.021.07.0.00	JOINT: COMPRESSOR HOUSING TO CRANKCASE	Spare Part	108	15%
8493	T4.021.08.0.00	JOINT: COMPRESSOR	Spare Part	157	15%
8494	T4.021.09.0.00	COVER PLATE FOR COMPRESSOR BORE ON CRANKCASE	Spare Part	760	15%
8495	T4.022.02.0.00	EXHAUST MANIFOLD GE TOP OPEN	Spare Part	5554	15%
8496	T4.022.04.0.00	BOLT COPPER COATED 50 002 08 110	Spare Part	406	15%
8497	T4.024.05.0.00	COMPRESSOR LUB OIL DRAIN PIPE, MODIFIED	Spare Part	345	15%
8498	T4.027.01.0.00	CRANK PULLEY PCD 1556	Spare Part	6412	15%
8499	T4.027.04.0.00	CRANK SHAFT PULLEY (137.5 PCD)	Spare Part	5711	15%
8500	T4.027.17.0.00	ALTERNATOR PULLEY (PCD 565 4PK)	Spare Part	1105	15%
8501	T4.027.21.0.PR	CRANKSHAFT PULEY PCD135 3 5PK POLY V GROOVE	Spare Part	3794	15%
8502	T4.028.01.0.00	ALTERNATOR TENSIONING LEVER	Spare Part	594	15%
8503	T4.029.01.0.00	V BELT: SPAX 1180 COGGED	Spare Part	1498	15%
8504	T4.029.03.0.00	V BELT: SPAX1160 COGGED	Spare Part	1203	15%
8505	T4.030.05.0.00	CYLINDER HEAD BOLT	Spare Part	194	15%
8506	T4.030.08.0.00	CYL HEAD GASKT WITH FIRE RING 1.37MM	Spare Part	2523	15%
8507	T4.030.09.0.00	GASKET: CYLINDER HEAD 1.32 THK	Spare Part	3920	15%
8508	T4.030.50.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	75953	15%
8509	T4.031.02.0.00	JOINT: THERMOSTAT COVER	Spare Part	28	15%
8510	T4.031.04.0.00	HOSE (THERMOSTAT COVERY HOSE (THERMOSTAT HOSE TO WATER PUMP)	Spare Part	172	15%
8511	T4.031.40.0.00	THERMOSTAT HOUSING ASSEMBLY	Spare Part	4535	15%
		THERMOSTAT HOUSING ASSEMBLT THERMOSTAT AND HOUSING	·	4846	15%
8512	T4.031.60.0.00		Spare Part		
8513	T4.031.90.0.00	THERMOSTAT HOUSING ASSEMBLY (M14 AND 0.5" NPTF) COVER TOWARD FAN	Spare Part	4594	15%
8514	T4.033.01.0.00	OIL SEAL HOUSING	Spare Part	1975	15%
8515	T4.033.02.0.00	OIL SEAL	Spare Part	3858	15%
8516	T4.035.80.0.00	CRANKCASE ASSEMBLY W O BEARINGS COMPLETE SUITABLE FOR COMPRESSOR MOUNTING	Spare Part	154595	15%
8517	T4.036.01.0.00	ROCKER COVER CAST-IRON (MACHINING)	Spare Part	6015	15%
8518	T4.043.01.0.00	INLET ADAPTOR ON INLET MANIFOLD S F ECEL	Spare Part	1957	15%
8519	T4.053.01.0.00	BREATHER HOSE	Spare Part	883	15%
8520	T4.053.07.0.00	HOSE FOR BREATHER: CONNECTING TO BASE PLATE	Spare Part	560	15%
8521	T4.053.08.0.00	HOSE FOR BREATHER; CONNECTING TO BEND PIPE	Spare Part	215	15%
8522	T4.053.10.0.00	LEAK OFF PIPE ASSLY	Spare Part	1563	15%
8523	T4.053.15.0.00	HOSE (RADIATOR TO PUMP INLET PIPE)	Spare Part	852	15%
8524	T4.053.16.0.00	HOSE (FOR RADIATOR TO WATER INLET PIPE)	Spare Part	1077	15%
8525	T4.053.17.0.00	PIPE (RADIATOR TO PUMP INLET)	Spare Part	520	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
8526	T4.053.18.0.00	HOSE: AIR CLEANER	Spare Part	1874	15%
8527	T4.053.21.0.00	LEAK OFF PIPE	Spare Part	1486	15%
8528	T4.053.24.0.00	FUEL PIPE MUD FILTER TO FIP	Spare Part	649	15%
8529	T4.053.38.0.00	LEAK OFF PIPE (INJECTOR) (POLYAMIDE)	Spare Part	2222	15%
8530	T4.053.49.0.PR	HOSE FOR RADIATOR TO WATER INLET PIPE	Spare Part	1505	15%
8531	T4.053.54.0.00	HOSE RADIATOR TO PUMP INLET	Spare Part	1569	15%
8532	T4.053.56.0.PR	HOSE IN BETWEEN AIR CLEANER AND TURBO	Spare Part	3477	15%
8533	T4.053.93.0.PR	HOSE RADIATOR TO PUMP INLET PIPE	Spare Part	1483	15%
8534	T4.054.01.0.00	LUB OIL SUMP CAST-IRON (REAR) MACHINING	Spare Part	13926	15%
8535	T4.054.02.0.00	LUBE OIL SUMP	Spare Part	12597	15%
8536	T4.054.10.0.00	LUBE OIL SUMP	Spare Part	7406	15%
8537	T4.058.01.0.00	HOSE FOR AIR CLEANER (DONALDSON)	Spare Part	1855	15%
8538	T4.067.105.0.PR	LUB OIL PUMP ASSEMBLY	Spare Part	14431	15%
8539	T4.067.55.0.00	LUBE OIL PUMP	Spare Part	15114	15%
8540	T4.067.75.0.PR	LUB OIL PUMP ASSLY	Spare Part	10486	15%
8541	T4.067.90.0.00	LUBE OIL PUMP	Spare Part	14237	15%
8542	T4.070.02.0.00	OIL SUPPLY PIPE	Spare Part	695	15%
8543	T4.075.10.0.00	FLYWHEEL ASSEMBLY SF BULL INDIA	Spare Part	13541	15%
8544	T4.075.50.0.00	FLYWHEEL ASSEMBLY	Spare Part	17492	15%
8545	T4.075.70.0.00	FLYWHEEL AND STARTER RING ASSEMBLY	Spare Part	17421	15%
8546	T4.076.01.0.00	FLYWHEEL HOUSING	Spare Part	20917	15%
8547	T4.076.02.0.00	FLYWHEEL HOUSING FOR PG SAE3	Spare Part	17683	15%
8548	T4.087.10.0.SP	SET OF JOINTS	Spare Part	4409	15%
8549	T4.087.20.0.00	SET OF 0 RINGS	Spare Part	234	15%
8550	T4.087.30.0.00	SET OF COPPER WASHER	Spare Part	529	15%
8551	T4.088.01.0.00	ENGINE MTG FOOT (GE LH)	Spare Part	2265	15%
8552	T4.088.02.0.00	ENGINE MTG FOOT (GE EH)	Spare Part	2265	15%
8553	T4.090.60.0.SP	CRANKCASE WITH BEARING CAPS	Spare Part	152423	15%
8554	T4.101.43.0.00	FAN (PUSHER TYPE-METALLIC 22" DIA MTG HOLE-55 PCD)	Spare Part	3283	15%
8555	T4.103.10.0.00	RADIATOR		107312	15%
8556	T4.103.26.0.SP	CAC CORE ASSEMBLY FOR T4.103.10.0.00 ALUMINIUM RADIATOR ASSEMBLY	Spare Part Spare Part	70211	15%
8557	T4.103.40.0.PR	ALUMINIUM RADIATOR ASSEMBLY	Spare Part	98802	15%
	T4.104.14.0.00				15%
8558		LEVER FOR CHARGING ALTERNATOR	Spare Part	809	
8559	T4.1043.10.0.PR	ENGINE WIRING HARNESS FOR 4RTA CRDI CPCB4	Spare Part	65633	15%
8560	T4.106.05.0.00	HOSE FOR AIR CLEANER HOSE FOR AIR CLEANER TO INLET MANIFOLD 70 ID 90 DEG	Spare Part	1668	15%
8561	T4.106.07.0.PR		Spare Part	1034 757	15% 15%
8562	T4.107.01.0.00	BRACKET FOR ALTERNATOR	Spare Part		
8563	T4.107.02.0.00	TENSIONING LEVER FOR BELT	Spare Part	569	15%
8564	T4.107.03.0.00	BRACKET FOR ALTERNATOR	Spare Part	1246	15%
8565	T4.107.06.0.00	BRACKET FOR ALTERNATOR MOUNTING	Spare Part	1363	15%
8566	T4.107.08.0.00	BRACKET FOR ALTERNATOR	Spare Part	920	15%
8567	T4.107.11.0.00	EYE BOLT FOR ALTERNATOR	Spare Part	1923	15%
8568	T4.107.18.0.PR	EYE BOLT FOR ALTERNATOR	Spare Part	375	15%
8569	T4.107.19.0.PR	BRACKET FOR STRETCH BELT ARRANGEMENT	Spare Part	1391	15%
8570	T4.107.21.0.00	BRACKET FOR ALTERNATOR	Spare Part	548	15%
8571	T4.108.07.0.00	BRACKET FOR FUEL FILTER & A/C MTG.	Spare Part	2603	15%
8572	T4.116.06.0.00	HEADER FOR LUBE OIL COOLER & FILTER	Spare Part	5945	15%
8573	T4.116.07.0.00	JOINT: LUBE OIL HEADER	Spare Part	283	15%
8574	T4.116.09.0.00	HEADER FOR LUB OIL COOLER & FILTER (FINISH) (SUITABLE FOR 8 PLATE COOLER)	Spare Part	5865	15%
8575	T4.116.12.0.00	JOINT FOR LUB OIL COOLER	Spare Part	77	15%
8576	T4.117.03.0.00	JOINT: AIR PIPE TC TO AIR INLET MANIFOLD	Spare Part	31	15%
8577	T4.117.16.0.00	AIR PIPE TC TO AIR INLET MANIFOLD	Spare Part	3465	15%
8578	T4.117.17.0.00	JOINT FOR CAC PIPE	Spare Part	86	15%
8579	T4.118.03.0.00	HOSE (215 ID X 32 OD, 50 LONG)	Spare Part	225	15%
8580	T4.118.38.0.00	LUBE OIL SUPPLY PIPE FOR TURBO	Spare Part	800	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		· ·		without Vat in NPR	Charge%
8581	T4.118.39.0.00	DRAIN PIPE ASSEMBLY FOR TURBOCHARGER	Spare Part	695	15%
8582	T4.118.40.0.00	LUBE OIL SUPPLY PIPE	Spare Part	880	15%
8583	T4.118.41.0.00	JOINT FOR TURBO DRAIN PIPE	Spare Part	114	15%
8584	T4.118.45.0.00	TURBO LUBE OIL SUPPLY PIPING ASSEMBLY	Spare Part	895	15%
8585	T4.118.46.0.PR	JOINT BET TURBO ADAPTOR CRANKCASE	Spare Part	132	15%
8586	T4.118.50.0.00	DRAIN PIPE ASSLY FOR AJAX DUMPER	Spare Part	1009	15%
8587	T4.119.02.0.00	PISTON COOLING NOZZLE	Spare Part	132	15%
8588	T4.119.11.0.00	ADAPTOR (M16 TO M12) FOR TURBO OIL INLET	Spare Part	166	15%
8589	T4.119.12.0.00	ADAPTOR (M12 X 175 TO M16 X 15)FOR TURBO OIL INLET	Spare Part	157	15%
8590	T4.119.30.0.SP	CRANK CASE WITH BRG CAPS	Spare Part	164687	15%
8591	T4.121.01.0.00	GEAR COVER	Spare Part	10972	15%
8592	T4.122.12.0.00	JOINT: TURBO & EXHAUST MANIFOLD	Spare Part	895	15%
8593	T4.122.13.0.00	JOINT: TURBO & DIFFUSER	Spare Part	163	15%
8594	T4.122.14.0.00	JOINT: TURBO & EXHAUST DIFFUSER	Spare Part	200	15%
8595	T4.122.18.0.00	JOINT: EXHAUST MANIFOLD & TURBO	Spare Part	686	15%
8596	T4.122.21.0.00	EXHAUST MANIFOLD	Spare Part	5209	15%
8597	T4.122.22.0.00	EXHAUST MANIFOLD	Spare Part	5471	15%
8598	T4.122.23.0.00	EXHAUST MANIFOLD	Spare Part	7489	15%
8599	T4.122.24.0.00	Socket Head Bolt (m8x50)	Spare Part	83	15%
8600	T4.122.25.0.00	STUD M8 X 35	Spare Part	68	15%
8601	T4.122.27.0.00	STUD (M10X60)	Spare Part	114	15%
8602	T4.122.29.0.00	STUD (M10 X 70)	Spare Part	123	15%
8603	T4.122.31.0.00	STUD (M8 X 25)	Spare Part	55	15%
8604	T4.122.32.0.00	STUD (M10 X 25)	Spare Part	77	15%
8605	T4.122.33.0.00	STUD (M10 X 30)	Spare Part	89	15%
8606	T4.122.34.0.00	SOCKET HEAD BOLT (M8X22)	Spare Part	52	15%
8607	T4.122.35.0.00	STUD (M8 X 20)	Spare Part	62	15%
8608	T4.122.36.0.00	SET SCREW (M8X25)	Spare Part	46	15%
8609	T4.122.39.0.00	NUT - M8X1.25 - GR.10	Spare Part	15	15%
8610	T4.122.41.0.00	NUT - M10X1.5 - GRADE 10	Spare Part	37	15%
8611	T4.122.42.0.00	NUT M12X1 75 GRADE 10	Spare Part	49	15%
8612	T4.122.48.0.00	STUD M10X40L FOR HIGH TEMP	Spare Part	68	15%
8613	T4.122.49.0.00	STUD M10X55	Spare Part	92	15%
8614	T4.122.51.0.00	STUD (M8 X 30) 10.9 GRADE	Spare Part	37	15%
8615	T4.122.52.0.00	SET SCREW M8X16 10 GRADE	Spare Part	31	15%
8616	T4.122.63.0.PR	EXHAUST MANIFOLD WITH HR PAINT 4R810T PROJECT BSIII BACKHOE	Spare Part	6126	15%
	T4.125.03.0.00	TURBOCHARGER	Spare Part	58928	15%
	T4.125.07.0.PR	TURBOCHARGER FOR 4R810 ENGINE TEL NO	Spare Part	53332	15%
8619	T4.126.07.0.00	GASKET LUBE OIL PUMP & SUCTION TUBE	Spare Part	55	15%
8620	T4.126.08.0.00	CLAMP STRAP RH SUCTION TUBE	Spare Part	86	15%
8621	T4.126.14.0.PR	GASKET FOR SUCTION TUBE	Spare Part	46	15%
8622	T4.126.30.0.00	SUCTION TUBE	Spare Part	862	15%
8623	T4.128.20.0.00	CAMSHAFT SUB ASSLY	Spare Part	32858	15%
8624	T4.128.40.0.00	CAM SHAFT & GEAR ASSEMBLY	Spare Part	30267	15%
8625	T4.130.01.0.00	SUCTION PIPE (WATER PUMP)	Spare Part	1034	15%
8626	T4.130.02.0.00	JOINT: SUCTION PIPE & GEAR COVER	Spare Part	62	15%
8627	T4.130.03.0.00	SUCTION PIPE FOR WATER PUMP	Spare Part	2369	15%
8628	T4.130.04.0.00	HOSE PIPE	Spare Part	658	15%
8629	T4.131.01.0.00	JOINT: WATER PUMP & GEAR COVER	Spare Part	148	15%
8630		WATER PUMP & GEAR COVER WATER PUMP PULLEY-110 PCD SPA SECTION	<u> </u>	1812	15%
8631	T4.131.02.0.00 T4.131.10.0.00	WATER PUMP POLLEY-110 PCD SPA SECTION WATER PUMP ASSLY	Spare Part Spare Part	6357	15%
8632	T4.131.11.0.00	FAN SPACER (70 MM)	Spare Part	1345	15%
0032	T4.131.11.0.00		Spare Part	1923	
8633		WATER PUMP PULLEY SPA SECTION 110 PCD 55 MTG PCD	i Spare Parti	1923	15%
8633 8634	T4.131.27.0.PR	WATER PUMP PULLEY 4PK SECTION 94 6 PCD 55 MTG PCD	Spare Part	2326	15%



Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
8636	T4.131.43.0.00	FAN SPACER- 70MM	Spare Part	1631	15%
8637	T4.131.75.0.PR	WATER PUMP ASSEMBLY WITH IMPELLER AND SEAL	Spare Part	10732	15%
8638	T4.132.50.0.00	THERMOSTAT & HOUSING	Spare Part	5683	15%
8639	T4.132.80.0.00	THERMOSTAT HOUSING ASSEMBLY M14 TAPPING BOTH SIDES WITH CORE PLUG on LHS	Spare Part	8477	15%
8640	T4.134.05.0.PR	4PK EPDM POLY- V BELT	Spare Part	1542	15%
8641	T4.136.01.0.00	DELIVERY TUBE	Spare Part	1058	15%
8642	T4.138.20.0.00	FLYWHEEL ASSEMBLY	Spare Part	18323	15%
8643	T4.140.15.0.00	NOZZLE LEAK OFF PIPE ASSLY	Spare Part	1378	15%
8644	T4.140.25.0.PR	NOZZLE LEAK OFF PIPE ASSLY	Spare Part	2255	15%
8645	T4.143.05.0.00	ROTARY FIP: 4R810T 60HP @ 2400 RPM	Spare Part	88537	15%
8646	T4.143.07.0.00	FIP: 4R810 TA 83 HP@1500RPM CPCBII	Spare Part	61775	15%
8647	T4.152.40.0.00	HIGH PRESSURE PIPE ASSEMBLY	Spare Part	5163	15%
8648	T4.153.10.0.00	ASSEMBLY OF INTERMEDIATE GEAR	Spare Part	3637	15%
8649	T4.155.20.0.00	FLYWHEEL	Spare Part	33252	15%
8650	T4.158.02.0.00	GEAR (FOR HYDRAULIC PUMP)	Spare Part	2901	15%
8651	T4.159.30.0.00	CRANKSHAFT ASSEMBLY	Spare Part	80464	15%
8652	T4.159.50.0.00	CRANKSHAFT ASSEMBLY	Spare Part	83039	15%
8653	T4.160.30.0.00	CON ROD ASSLY	Spare Part	7729	15%
8654	T4.160.40.0.PR	CONNECTING ROD ASSEMBLY FRACTURED	Spare Part	6366	15%
8655	T4.161.01.0.00	FAN: 17/5-5/40/PAG/1ZL	Spare Part	12028	15%
8656	T4.161.03.0.00	SPACER 68 MM WIDTH FOR MOUNTING FAN 17/5-5/40?/PAG/1ZL	Spare Part	2603	15%
8657	T4.161.20.0.00	FAN ASSEMBLY 17 5 5 40 PAG 1ZL	Spare Part	15732	15%
8658	T4.165.01.0.00	ALTERNATOR BRACKET	Spare Part	1191	15%
8659	T4.166.03.0.00	BELT GUARD	Spare Part	2234	15%
8660	T4.166.21.0.00	BELT GUARD	Spare Part	2622	15%
8661	T4.166.27.0.PR	BELT GUARD FOR STRETCH BELT	Spare Part	3941	15%
8662	T4.170.10.0.00	PISTON ASSEMBLY: R810T/TA BSIII	Spare Part	5954	15%
8663	T4.170.20.0.00	PISTON RING SET	Spare Part	1529	15%
8664	T4.171.02.0.00	HOSE AIR CLEANER BS III	Spare Part	775	15%
8665	T4.174.01.0.00	BRACKET FOR SPINON FILTER MOUNTING	Spare Part	892	15%
8666	T4.181.03.0.00	HUB WITH FACIAL CAM	Spare Part	8218	15%
8667	T4.181.04.0.00	FUEL PUMP GEAR	Spare Part	2957	15%
8668	T4.182.01.0.00	COVER FOR FUEL PUMP GEAR	Spare Part	2455	15%
8669	T4.182.03.0.00	COVER PLATE ALUMINIUM FOR FUEL PUMP GEAR FINISH 4R810T WITH INLINE FUEL PUMP	Spare Part	2268	15%
8670	T4.183.05.0.00	GEAR CASING	Spare Part	10098	15%
8671	T4.185.02.0.00	FUEL INJECTION PUMP FOR 4R810NA ENGINE	Spare Part	69928	15%
8672	T4.185.03.0.00	FIP: 4R810NA 49.5HP @ 2200RPM HD GOVERNOR	Spare Part	90048	15%
8673	T4.187.02.0.00	TURBOCHARGER	Spare Part	48184	15%
8674	T4.191.05.0.00	HOSE: AIR CLEANER	Spare Part	446	15%
8675	T4.191.16.0.00	HOSE FOR PVC PIPE	Spare Part	775	15%
8676	T4.191.19.0.PR	BRACKET FOR AIR CLEANER MOUNTING	Spare Part	4215	15%
8677	T4.193.01.0.00	FUEL PIPE 200 L	Spare Part	532	15%
8678	T4.196.01.0.00	EXHAUST SILENCER ASSEMBLY FOR 60 HP @ 2400 RPM BS III ENGINE	Spare Part	12621	15%
8679	T4.197.01.0.00	EXHAUST DIFFUSER BULL	Spare Part	1772	15%
8680	T4.198.02.0.00	HOSE FOR AIRCLEANER	Spare Part	3397	15%
8681	T4.201.01.0.00	FUEL PIPE FUEL FILTER TO FIP	Spare Part	622	15%
8682	T4.201.02.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	662	15%
8683	T4.201.05.0.00	FUEL PIPE FUEL FILTER TO PUMP	Spare Part	563	15%
8684	T4.201.05.0.00	FUEL PIPE FEED PUMP TO FUEL FILTER	Spare Part	532	15%
8685	T4.201.16.0.00	FUEL PIPE (FUEL FILTER TO PUMP) (POLYAMIDE)	Spare Part	446	15%
8686	T4.201.16.0.00	FUEL PIPE (FUEL FILTER TO PUMP) (POLYAMIDE) FUEL PIPE (FEED PUMP TO FUEL FILTER) (POLYAMIDE)	Spare Part	446	15%
			· · · · · · · · · · · · · · · · · · ·		15%
8687	T4.202.20.0.PR	PISTON RING SET FOR 4R810TA	Spare Part	1388	
8688	T4.203.100.0.00 T4.206.11.0.00	CRANKCASE ASSLY EXHAUST DIFFUSER	Spare Part Spare Part	164887 2800	15%
8689		IEAEALIST THEELISEK	Spare Part	28001	15%



				Price to	
Sr.No.	Part Number	Part Description	Category	Customer	Custom
		·		without Vat in NPR	Charge%
8691	T4.206.18.0.00	BRACKET FOR FUEL PIPES	Spare Part	274	15%
8692	T4.206.23.0.PR	JOINT	Spare Part	215	15%
8693	T4.207.07.0.00	CAC PIPE	Spare Part	5151	15%
8694	T4.207.08.0.00	CAC HOSE	Spare Part	714	15%
8695	T4.207.09.0.00	AIR PIPE (TURBO TO RADIATOR)	Spare Part	6298	15%
8696	T4.207.12.0.00	CAC HOSE (HOT SIDE 4 PLIES)	Spare Part	1486	15%
8697	T4.207.13.0.00	CAC HOSE COLD SIDE	Spare Part	1028	15%
8698	T4.207.23.0.00	CAC PIPE COLD SIDE (COLD START)	Spare Part	3098	15%
8699	T4.207.31.0.PR	CAC PIPE RADIATOR TO INLET MANIFOLD	Spare Part	2794	15%
8700	T4.207.32.0.00	CAC HOT PIPE TURBO SIDE	Spare Part	4618	15%
8701	T4.207.33.0.PR	JOINT BETWEEN CAC HOT PIPES	Spare Part	172	15%
8702	T4.207.34.0.00	CAC HOT PIPE RADIATOR SIDE	Spare Part	4409	15%
8703	T4.208.01.0.00	HOSE FOR THERMOSTAT TO RADIATOR INLET	Spare Part	1388	15%
8704	T4.208.07.0.PR	HOSE FOR THERMOSTAT TO RADIATOR INLET	Spare Part	1363	15%
8705	T4.209.10.0.00	DIPSTICK ASSEMBLY	Spare Part	117	15%
8706	T4.215.30.0.00	CYLINDER HEAD ASSEMBLY	Spare Part	74716	15%
8707	T4.216.20.0.PR	PISTON ASSEMBLY FOR 4R810TA	Spare Part	6566	15%
8708	T4.217.10.0.00	FLYWHEEL	Spare Part	12437	15%
8709	T4.241.02.0.00	FUEL PIPE PRE-FILETR TO FEED PUMP	Spare Part	674	15%
8710	T4.241.05.0.00	FUEL PIPE FUEL TANK TO FUEL PUMP	Spare Part	1172	15%
8711	T4.241.24.0.00	DRAIN PIPE	Spare Part	409	15%
8712	T4.241.26.0.PR	STARTER	Spare Part	70962	15%
8713	T4.241.90.0.00	FUEL PIPE KIT	Spare Part	2637	15%
8714	T4.246.10.0.PR	AIR CLEANER ASSEMBLY 350 KGHR 90 DEG BEND OUTLET I 0 O 23 G080755	Spare Part	9784	15%
8715	T4.247.02.0.PR	HOSE AIR SUCTION ID70XID89 BEND EPDM	Spare Part	3126	15%
8716	T4.326.20.0.PR	FAN ASSEMBLY 17 5 5 40DEG PAG 1ZL WITH SPACER S F MODIFIED WP	Spare Part	15351	15%
8717	T4.400.80.0.PR	CRANKCASE WITH BRG CAP	Spare Part	152336	15%
8718	T4.401.20.0.PR	CAMSHAFT SUB ASSEMBLY	Spare Part	28009	15%
8719	T4.402.20.0.PR	CYLINDER HEAD ASSEMBLY WITH VALVE SEAT INSERT AND VALVE GUIDE	Spare Part	51356	15%
8720	T4.407.30.0.PR	H P PIPE FOR CYL 1	Spare Part	2215	15%
8721	T4.407.40.0.PR	H P PIPE FOR CYL 2	Spare Part	2215	15%
8722	T4.407.50.0.PR	H P PIPE FOR CYL 3	Spare Part	2215	15%
8723	T4.407.60.0.PR	H P PIPE FOR CYL 4	Spare Part	2215	15%
8724	T4.407.70.0.PR	H P PIPE FIP TO COMMON RAIL 1	Spare Part	1923	15%
8725	T4.407.80.0.PR	H P PIPE FIP TO COMMON RAIL 2	Spare Part	1923	15%
8726	T4.411.01.0.PR	AITERNATOR PULLEY PCD 71 5 PK POLY V GROOVE	Spare Part	1037	15%
	T4.418.02.0.PR	FUEL PIPE FUEL FILTER TO FIP	Spare Part	643	15%
8728	T4.419.01.0.PR	HOSE EGR VALVE WATER INLET	Spare Part	191	15%
8729	T4.419.02.0.PR	HOSE EGR VALVE WATER OUT	Spare Part	206	15%
8730	T4.424.01.0.PR	LEAK OFF PIPE INJECTOR	Spare Part	5874	15%
	T4.424.02.0.PR	LEAK OFF PIPE	Spare Part	2354	15%
	T4.433.01.0.PR	TURBOCHARGER FOR 4R810TA CPCB4 PLUSE 54 4KW 1500 RPM	Spare Part	57845	15%
8733	T4.434.06.0.PR	T4 434 06 0 PR CRI2 16 INJECTOR ASSEMBLY 4R810TA CPCB4 PLUS 6X144 X300HTF	Spare Part	27110	15%
8734	T4.435.01.0.PR	ECU MD1CS162 CANOPY MOUNTED FOR CPCB 4 PLUS PROJECT	Spare Part	32867	15%
8735	T4.438.01.0.PR	PK SEC BELT 5PK 1168 EPDM	Spare Part	1778	15%
8736	T4.438.02.0.PR	STRETCH FIT BELT 5PK1148	Spare Part	3052	15%
8737	T4.466.30.0.PR	Control Panel for 62.5 IP+A - KG640	Spare Part	68285	15%
8738	T4.467.40.0.PR	CONTROL PANEL SCHEMATIC FOR 62 5KVA 3PH T4 IP B	Spare Part	155958	15%
8739	T4.472.01.0.00	BRACKET FOR ACTUATOR ECU MTG	Spare Part	2671	15%
8740	T4.472.02.0.00	LEVER FOR ELE ACTUATOR	Spare Part	505	15%
8741	T4.472.03.0.00	STUD COUPLER 55 MM LONG	Spare Part	55	15%
8742	T4.472.04.0.00	ENGINE CONTROL UNIT	Spare Part	16452	15%
8743	T4.473.01.0.00	BRACKET FOR RELAY BOX MOUNTING	Spare Part	886	15%
8744	T4.486.27.0.PR	SILENCER ASSEMBLY	Spare Part	36732	15%
8745	T4.486.28.0.PR	SILENCER ASSEMBLY	Spare Part	36732	15%



1977 174 480 19.0 PR PURE PIEP FROM FUEL TANK UNIT TO PRE FILTER IN Spare Part 2037 15% 15% 154 154 156 15% 15	Sr.No.	Part Number	Part Description	Category	Price to Customer without Vat in NPR	Custom Charge%
1974 T.4-88-92.0.PR	8746	T4.486.37.0.PR	RETURN FUEL PIPE	Spare Part	1065	15%
14-889 SS D.PR						
1500 1500						
1575 1.4.524.01.0.PR				·		
8752 T4.810.70.0.00 ENGINE WIRING HARNESS ASSEMBLY WITH KG934 UNIT Spare Part 10388 15%						
8753 14.820.30.0.00 ENGINE WIRING HARNESS SF 4R810TA ENGINE Spare Part 6845 15% 15				· ·		
8754 T4.821.20.0 PR 4R810 FLANGE HEATER WIRING HARNESS Spare Patt 9840 15% 8756 T4.822.10.0 PR ENIONIE WIRING HARNESS FOR 62 SKVA THE EMERALD Spare Patt 10344 15% 8757 T4.822.20.0.0 ENIONIE WIRING HARNESS FOR 62 SKVA EMRALD COLDSTART Spare Patt 11044 15% 8757 T4.820.20.0.00 ENIONIE WIRING HARNESS FOR 62 SKVA EMRALD COLDSTART Spare Patt 11106 15% 8758 T4.890.40.0 PR POWER CABLE PVC FOR 62 SKVA 3PH 74 EMERALD Spare Patt 11116 15% 8760 T4.990.0 JS.P SET OF JOINT Spare Patt 5181 15% 8761 T4.999.0 JO.S.P SET OF JOINT Spare Patt 5181 15% 8761 T4.999.1 JO.S.P CONNECTING ROD BEARING PAIR Spare Patt 6670 15% 8762 T4.999.1 JO.S.P MAJOR OVERHAULING FOR AJAX DUMPER, SCHWING, BACKHOE LOADER BULL Spare Patt 66670 15% 8763 T4.999.1 JO.S.P MAJOR OVERHAULING FOR JGB Spare Patt 6748 15% 8764 T4.999.1 JS				·		
8755 T4 822-10.0 PR ENGINE WIRING HARNESS FOR 62 8KVA T4 EMERALD Spare Part 6474 15% 3756 T4 822-20.0.00 ENGINE WIRING HARNESS FOR 62 8KVA EMRALD COLDSTART Spare Part 10344 105% 3757 T4.830-20.0.00 ENGINE WIRING HARNESS FOR 62 8KVA EMRALD COLDSTART Spare Part 1034 115% 3758 T4.990-20.0.00 ENGINE WIRING HARNESS FOR 62 8KVA 3PH T4 EMERALD Spare Part 12114 15% 3769 T4.999-10.0.P POWER CABLE PVC FOR 62 8KVA 3PH T4 EMERALD Spare Part 6669 15% 3761 T4.999-30.0.SP SET OF JOINT Spare Part 6589 15% 3761 T4.999-30.0.SP SET OF JOINTS Spare Part 789 15% 3762 T4.999-10.0.SP SET OF JOINTS Spare Part 789 15% 3763 T4.999-11.0.SP SET OF JOINTS Spare Part 789 15% 3764 T4.999-10.0.SP SET OF JOINTS Spare Part 789 15% 3764 T4.999-10.0.SP SET OF JOINTS Spare Part				·		
8766 T4 822 20 0.00 ENGINE WIRING HARNESS FOR 62.5KVA EMRALD COLDSTART Spare Part 10344 15% 3767 T4 390 20 0.00 ENGINE WIRING HARNESS SP KG 645 UNIT GOVERNOR Spare Part 11106 15% 3787 T4 390 40.00 PR OWER CABLE PVC FOR 62 5KVA 3PH 14 EMERALD Spare Part 15% 3760 T4 399 01.0 SP SET OF JOINT Spare Part 6660 15% 3761 T4 399 05.0 SP CONNECTING ROD BEARING PAIR Spare Part 769 15% 3762 T4 399 10.0 SP SET OF JOINTS Spare Part 903 15% 3763 T4 599 11.0 SP MAJOR OVERHAULING FOR AJAX DUMPER, SCHWING, BACKHOE LOADER BULL Spare Part 903 15% 3765 T4 599 12.0 SP TOP OVERHAULING FOR JCB Spare Part 70448 15% 3765 T4 599 13.0 SP MAJOR OVERHAULING FOR JCB Spare Part 70448 15% 3767 T4 599 13.0 SP MAJOR OVERHAULING FOR PG Spare Part 67030 15% 3768 T4 599 14.0 SP TOP OVERHAULING FOR PG Spare						
8757 74.830.20.0.00 ENGINE WIRING HARNESS SF KG 645 UNIT GOVERNOR Spare Part 11108 15% 8758 74.990.40.0.PR POWER CABLE PVC FOR 62 SKVA 3PH 74 EMERALD Spare Part 1214 15% 8759 74.999.01.0.SP SET OF JOINT Spare Part 568 15% 8760 74.999.03.0.SP SET OF JOINT Spare Part 769 15% 8761 74.999.05.0.SP OCNNECTING ROD BEARING PAIR Spare Part 769 15% 8762 74.999.10.SP SET OF JOINTS Spare Part 966 15% 8763 74.999.10.SP MAJOR OVERHAULING FOR AJAX DUMPER, SCHWING, BACKHOE LOADER BULL Spare Part 40483 15% 8765 74.999.12.0.SP TOP OVERHAULING FOR JOEB Spare Part 40483 15% 8766 74.999.14.0.SP TOP OVERHAULING FOR JOEB Spare Part 40482 15% 8767 74.999.15.0.SP TOP OVERHAULING FOR JOE Spare Part 40452 15% 8768 74.999.15.0.SP MAJOR OVERHAULING FOR JOE Spare Part						
8758 T 4,910,40,0 PR POWER CABLE PVC FOR 62 SKVA 3PH T4 EMERALD Spare Part 15% 8759 T 4,999,01,0 SP SET OF JOINT Spare Part 6569 15% 8760 T 4,999,01,0 SP SET OF JOINT Spare Part 769 15% 8761 T 4,999,10,0 SP SET OF JOINTS Spare Part 709 15% 8762 T 4,999,10,0 SP SET OF JOINTS Spare Part 709 15% 8763 T 4,999,10,0 SP SET OF JOINTS Spare Part 9037 15% 8763 T 4,999,10,0 SP MAJOR OVERHAULING FOR AJAX DUMPER, SCHWING, BACKHOE LOADER BULL Spare Part 4043 15% 8765 T 4,999,13,0 SP TOP OVERHAULING FOR JCB Spare Part 40443 15% 8766 T 4,999,14,0 SP TOP OVERHAULING FOR JCB Spare Part 40443 15% 8767 T 4,999,16,0 SP TOP OVERHAULING FOR JCB Spare Part 40452 15% 8768 T 4,999,16,0 SP TOP OVERHAULING FOR JCB Spare Part 40452 15%						
8759 T4.999.01.0.SP SET OF JOINT Spare Part 6569 15% 8760 T4.999.03.0.SP SET OF JOINT Spare Part 759 15% 8761 T4.999.10.SP SET OF JOINTS Spare Part 903 15% 8762 T4.999.10.SP SET OF JOINTS Spare Part 9037 15% 8763 T4.999.10.SP MAJOR OVERHAULING FOR AJAX DUMPER, SCHWING, BACKHOE LOADER BULL Spare Part 66670 15% 8764 T4.999.13.0.SP MAJOR OVERHAULING FOR AJAX DUMPER, SCHWING, BACKHOE LOADER BULL Spare Part 40483 15% 8765 T4.999.13.0.SP MAJOR OVERHAULING FOR AJAX Spare Part 40483 15% 8766 T4.999.13.0.SP MAJOR OVERHAULING FOR CICB Spare Part 40482 15% 8767 T4.999.13.0.SP MAJOR OVERHAULING FOR PG Spare Part 40462 15% 8767 T4.999.30.0.0.D ELECTRONIC GOVERNOR KIT FOR GR Spare Part 41916 15% 8768 T4.9999.30.0.D ELECTRONIC GOVERNOR KIT FOR 4R810 Spare Part						
8760 T4.999.03.0.SP SET OF JOINT Spare Part 5181 15% 8761 T4.999.05.0.SP CONNECTING ROD BEARING PAIR Spare Part 769 15% 8762 T4.999.10.SP SET OF JOINTS Spare Part 9037 15% 8763 T4.999.11.0.SP MAJOR OVERHAULING FOR AJAX DUMPER, SCHWING, BACKHOE LOADER BULL Spare Part 66670 15% 8765 T4.999.12.0.SP TOP OVERHAULING FOR AJAX DUMPER, SCHWING, BACKHOE LOADER BULL Spare Part 40483 15% 8766 T4.999.14.0.SP TOP OVERHAULING FOR JCB Spare Part 40483 15% 8767 T4.999.14.0.SP TOP OVERHAULING FOR JCB Spare Part 40462 15% 8767 T4.999.16.0.SP TOP OVERHAULING FOR PG Spare Part 40452 15% 8768 T4.999.16.0.SP TOP OVERHAULING FOR PG Spare Part 41916 15% 8769 T4.999.30.0.OD ELECTRONIC GOVERNOR KIT-4R810 Spare Part 41916 15% 8770 T4.999.31.0.SP BELL INSTALLATION TOOL Spare Part						
8761 T4.999.05.0.SP CONNECTING ROD BEARING PAIR Spaire Part 769 15% 8762 T4.999.10.0.SP SET OF JOINTS Spaire Part 9037 15% 8763 T4.999.11.0.SP MAJOR OVERHAULING FOR AJAX DUMPER, SCHWING, BACKHOE LOADER BULL Spaire Part 66670 15% 8764 T4.999.12.0.SP TOP OVERHAULING FOR AJAX DUMPER, SCHWING, BACKHOE LOADER BULL Spaire Part 40463 15% 8765 T4.999.13.0.SP MAJOR OVERHAULING FOR JCB Spaire Part 40462 15% 8766 T4.999.14.0.SP TOP OVERHAULING FOR JCB Spaire Part 40452 15% 8767 T4.999.16.0.SP MAJOR OVERHAULING FOR PG Spaire Part 41916 15% 8768 T4.999.30.0.0.D ELECTRONIC GOVERNOR KIT: 4R810 Spaire Part 55128 15% 8770 T4.999.31.0.SP BELT INSTALLATION TOOL Spaire Part 37664 15% 8771 T4.999.37.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 (EMERALD) Spaire Part 126 15% 8773 V.0015.0.1003 AV1				·		
8762 T4.999.10.SP						15%
8764 T4.999.12.0.SP TOP OVERHAULING FOR AJAX DUMPER, SCHWING, BACKHOE LOADER BULL Spare Part 40483 15% 8765 T4.999.13.0.SP MAJOR OVERHAULING FOR JCB Spare Part 70448 15% 8766 T4.999.14.0.SP TOP OVERHAULING FOR JCB Spare Part 40452 15% 8767 T4.999.15.0.SP MAJOR OVERHAULING FOR PG Spare Part 67030 15% 8768 T4.999.16.0.SP TOP OVERHAULING FOR PG Spare Part 41916 15% 8769 T4.999.30.0.0 ELECTRONIC GOVERNOR KIT: 4R810 Spare Part 55128 15% 8770 T4.999.31.0.SP BELT INSTALLATION TOOL Spare Part 37664 15% 8772 T4.999.37.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 Spare Part 56861 15% 8773 V.001.5.01.003 AV1 VR BUSH Spare Part 126 15% 8774 V.033.5.01.703 BEARING VIR Spare Part 926 15% 8775 V.073.5.00.003 BEARING VIR Spare Part 120 15%<	8762	T4.999.10.0.SP	SET OF JOINTS	· ·	9037	15%
8765 T4.999.13.0.SP MAJOR OVERHAULING FOR JCB Spare Part 70448 15% 8766 T4.999.14.0.SP TOP OVERHAULING FOR JCB Spare Part 40452 15% 8767 T4.999.15.0.SP MAJOR OVERHAULING FOR PG Spare Part 67030 15% 8768 T4.999.16.0.SP TOP OVERHAULING FOR PG Spare Part 41916 15% 8769 T4.999.30.0.00 ELECTRONIC GOVERNOR KIT. 4R810 Spare Part 55128 15% 8770 T4.999.31.0.SP BELT INSTALLATION TOOL Spare Part 62359 15% 8771 T4.999.37.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 Spare Part 62359 15% 8772 T4.999.37.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 (EMERALD) Spare Part 5681 15% 8773 Y.001.5.01.003 AV1 VR BUSH Spare Part 126 15% 8774 V.038.5.01.703 BEARING VIR Spare Part 914 15% 8775 V.073.5.00.003 BEARING VIR Spare Part 926 15%	8763	T4.999.11.0.SP	MAJOR OVERHAULING FOR AJAX DUMPER, SCHWING, BACKHOE LOADER BULL	·		15%
8766 T4.999.14.0.SP TOP OVERHAULING FOR JCB Spare Part 40452 15% 8767 T4.999.15.0.SP MAJOR OVERHAULING FOR PG Spare Part 67030 15% 8768 T4.999.16.0.SP TOP OVERHAULING FOR PG Spare Part 41916 15% 8769 T4.999.30.0.00 ELECTRONIC GOVERNOR KIT: 4R810 Spare Part 55128 15% 8770 T4.999.31.0.SP BELT INSTALLATION TOOL Spare Part 62359 15% 8771 T4.999.37.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 Spare Part 62359 15% 8772 T4.999.37.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 (EMERALD) Spare Part 56581 15% 8773 V.001.5.01.003 AV1 VR BUSH Spare Part 126 15% 8774 V.038.5.01.703 BEARING V/R Spare Part 926 15% 8776 V.073.5.00.003 BEARING V/R Spare Part 926 15% 8777 V.074.5.00.003 BEARING V/R Spare Part 120 15% <	8764	T4.999.12.0.SP	TOP OVERHAULING FOR AJAX DUMPER, SCHWING, BACKHOE LOADER BULL	Spare Part	40483	15%
8767 T4.999.15.0.SP MAJOR OVERHAULING FOR PG Spare Part 67030 15% 8768 T4.999.16.0.SP TOP OVERHAULING FOR PG Spare Part 41916 15% 8769 T4.999.30.0.00 ELECTRONIC GOVERNOR KIT: 4R810 Spare Part 55128 15% 8770 T4.999.31.0.SP BELT INSTALLATION TOOL Spare Part 37664 15% 8771 T4.999.37.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 Spare Part 6239 15% 8772 T4.999.37.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 (EMERALD) Spare Part 56681 15% 8773 V.001.5.01.003 AV1 VR BUSH Spare Part 126 15% 8774 V.038.5.01.003 BEARING VIR Spare Part 91 15% 8775 V.073.5.00.003 BEARING VIR Spare Part 926 15% 8776 V.073.5.00.003 BEARING VIR Spare Part 120 15% 8779 V.074.5.00.003 BEARING VIR Spare Part 120 15% 8779	8765	T4.999.13.0.SP	MAJOR OVERHAULING FOR JCB	Spare Part	70448	15%
8768 T4.999.16.0.SP TOP OVERHAULING FOR PG Spare Part 41916 15% 8769 T4.999.30.0.00 ELECTRONIC GOVERNOR KIT: 4R810 Spare Part 55128 15% 8770 T4.999.31.0.SP BELT INSTALLATION TOOL Spare Part 37664 15% 8771 T4.999.30.SP ELECTRONIC GOVERNOR KIT FOR 4R810 Spare Part 62359 15% 8772 T4.999.37.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 (EMERALD) Spare Part 56581 15% 8773 V.001.5.01.003 AV1 VR BUSH Spare Part 126 15% 8774 V.038.5.01.703 BEARING VIR Spare Part 914 15% 8775 V.073.5.00.003 BEARING VIR Spare Part 926 15% 8776 V.073.5.00.003 BEARING VIR Spare Part 120 15% 8777 V.074.5.00.003 BEARING VIR Spare Part 120 15% 8779 V.075.5.00.703 BEARING VIR Spare Part 1182 15% 8780 V.093	8766	T4.999.14.0.SP	TOP OVERHAULING FOR JCB	Spare Part	40452	15%
8769 T4.999.30.0.00 ELECTRONIC GOVERNOR KIT: 4R810 Spare Part 55128 15% 8770 T4.999.31.0.SP BELT INSTALLATION TOOL Spare Part 37664 15% 8771 T4.999.31.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 Spare Part 62359 15% 8772 T4.999.37.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 (EMERALD) Spare Part 56581 15% 8773 V.001.5.01.003 AV1 VR BUSH Spare Part 126 15% 8774 V.038.5.01.703 BEARING VIR Spare Part 126 15% 8775 V.073.5.00.003 BEARING VIR Spare Part 226 15% 8776 V.073.5.00.003 BEARING VIR Spare Part 1209 15% 8777 V.074.5.00.003 BEARING VIR Spare Part 1209 15% 8778 V.075.5.00.703 BEARING VIR Spare Part 1209 15% 8778 V.075.5.00.703 BEARING VIR Spare Part 1182 15% 8780 V.093.5.00.00	8767	T4.999.15.0.SP	MAJOR OVERHAULING FOR PG	Spare Part	67030	15%
8770 T4.999.31.0.SP BELT INSTALLATION TOOL Spare Part 37664 15% 8771 T4.999.36.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 Spare Part 62359 15% 8772 T4.999.37.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 (EMERALD) Spare Part 56581 15% 8773 V.001.5.01.003 AV1 VR BUSH Spare Part 126 15% 8774 V.038.5.01.703 BEARING V/R Spare Part 914 15% 8775 V.073.5.00.003 BEARING V/R Spare Part 926 15% 8776 V.073.5.00.073 BEARING V/R Spare Part 1209 15% 8777 V.074.5.00.003 BEARING V/R Spare Part 1209 15% 8778 V.074.5.00.003 BEARING V/R Spare Part 1209 15% 8778 V.074.5.00.003 BEARING V/R Spare Part 1209 15% 8779 V.075.5.00.703 BEARING V/R Spare Part 2018 15% 8781 W.009.3.5.00.003 <td< td=""><td>8768</td><td>T4.999.16.0.SP</td><td>TOP OVERHAULING FOR PG</td><td>Spare Part</td><td>41916</td><td>15%</td></td<>	8768	T4.999.16.0.SP	TOP OVERHAULING FOR PG	Spare Part	41916	15%
8771 T4.999.36.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 Spare Part 62359 15% 8772 T4.999.37.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 (EMERALD) Spare Part 56581 15% 8773 V.001.5.01.003 AV1 VR BUSH Spare Part 126 15% 8774 V.038.5.01.703 BEARING V/R Spare Part 914 15% 8775 V.073.5.00.003 BEARING V/R Spare Part 926 15% 8776 V.073.5.00.0703 BEARING V/R: HA394 Spare Part 868 15% 8777 V.074.5.00.003 BEARING V/R Spare Part 1209 15% 8778 V.074.5.00.073 BEARING V/R Spare Part 1182 15% 8779 V.075.5.00.703 BEARING V/R Spare Part 2018 15% 8780 V.093.5.00.003 BEARING V/R Spare Part 2018 15% 8781 W.006.3.20.003 BEARING TW 6R1080 (U.& L.) Spare Part 126 15% 8782 W.019.9.00.003	8769	T4.999.30.0.00	ELECTRONIC GOVERNOR KIT: 4R810	Spare Part	55128	15%
8772 T4.999.37.0.SP ELECTRONIC GOVERNOR KIT FOR 4R810 (EMERALD) Spare Part 56581 15% 8773 V.001.5.01.003 AV1 VR BUSH Spare Part 126 15% 8774 V.038.5.01.703 BEARING V/R Spare Part 914 15% 8775 V.073.5.00.003 BEARING V/R Spare Part 926 15% 8776 V.073.5.00.703 BEARING V/R: HA394 Spare Part 868 15% 8777 V.074.5.00.003 BEARING V/R: HA494 STD UB Spare Part 1182 15% 8778 V.075.5.00.703 BEARING V/R: HA494 STD UB Spare Part 2018 15% 8780 V.093.5.00.003 BEARING V/R Spare Part 2018 15% 8780 V.093.5.00.003 BEARING V/R Spare Part 182 15% 8781 W.006.3.20.003 BEARING T/W 6R1080 (U & L) Spare Part 815 15% 8782 W.019.9.00.003 SET OF BEARING T/W: TV1 Spare Part 126 15% 8784 W.038.9.10	8770	T4.999.31.0.SP	BELT INSTALLATION TOOL	Spare Part	37664	15%
8773 V.001.5.01.003 AV1 VR BUSH Spare Part 126 15% 8774 V.038.5.01.703 BEARING V/R Spare Part 914 15% 8775 V.073.5.00.003 BEARING V/R Spare Part 926 15% 8776 V.073.5.00.703 BEARING V/R: HA394 Spare Part 868 15% 8777 V.074.5.00.003 BEARING V/R Spare Part 1209 15% 8778 V.074.5.00.703 BEARING V/R: HA494 STD UB Spare Part 1182 15% 8779 V.075.5.00.703 BEARING V/R Spare Part 2018 15% 8780 V.093.5.00.003 BEARING V/R Spare Part 2018 15% 8781 W.006.3.20.003 BEARING T/W 6R1080 (U & L) Spare Part 815 15% 8782 W.019.9.00.003 SET OF BEARING T/W: TV1 Spare Part 126 15% 8783 W.038.9.10.003 THRUST WASHER: IG RA3 Spare Part 108 15% 8784 W.038.9.10.003 BEARING T/W: SL90 Spare Part 938 15% 8785 W.055.5	8771	T4.999.36.0.SP	ELECTRONIC GOVERNOR KIT FOR 4R810	Spare Part	62359	15%
8774 V.038.5.01.703 BEARING V/R Spare Part 914 15% 8775 V.073.5.00.003 BEARING V/R Spare Part 926 15% 8776 V.073.5.00.703 BEARING V/R: HA394 Spare Part 868 15% 8777 V.074.5.00.003 BEARING V/R Spare Part 1209 15% 8778 V.074.5.00.703 BEARING V/R: HA494 STD UB Spare Part 1182 15% 8779 V.075.5.00.703 BEARING V/R Spare Part 2018 15% 8780 V.093.5.00.003 BEARING V/R Spare Part 2018 15% 8781 W.006.3.20.003 BEARING TW 6R1080 (U & L) Spare Part 815 15% 8782 W.019.9.00.003 SET OF BEARING TW: TV1 Spare Part 126 15% 8783 W.038.9.00.003 BEARING TW: RA3 Spare Part 108 15% 8784 W.038.9.10.003 THRUST WASHER: IG RA3 Spare Part 108 15% 8785 W.055.5.00.003 BEARING TW: S	8772	T4.999.37.0.SP	ELECTRONIC GOVERNOR KIT FOR 4R810 (EMERALD)	Spare Part	56581	15%
8775 V.073.5.00.003 BEARING V/R Spare Part 926 15% 8776 V.073.5.00.703 BEARING V/R: HA394 Spare Part 868 15% 8777 V.074.5.00.003 BEARING V/R Spare Part 1209 15% 8778 V.074.5.00.703 BEARING V/R: HA494 STD UB Spare Part 1182 15% 8779 V.075.5.00.703 BEARING V/R Spare Part 2018 15% 8780 V.093.5.00.003 BEARING V/R Spare Part 782 15% 8781 W.006.3.20.003 BEARING TW 6R1080 (U & L) Spare Part 815 15% 8782 W.019.9.00.003 SET OF BEARING TW: TV1 Spare Part 126 15% 8783 W.038.9.00.003 BEARING TW: RA3 Spare Part 375 15% 8784 W.038.9.10.003 THRUST WASHER: IG RA3 Spare Part 108 15% 8785 W.055.5.00.003 BEARING TW: SL90 Spare Part 849 15% 8786 W.073.5.00.003 BEARING TW: KIR HA 394 Spare Part 840 15%	8773	V.001.5.01.003	AV1 VR BUSH	Spare Part	126	15%
8776 V.073.5.00.703 BEARING V/R: HA394 Spare Part 868 15% 8777 V.074.5.00.003 BEARING V/R Spare Part 1209 15% 8778 V.074.5.00.703 BEARING V/R: HA494 STD UB Spare Part 1182 15% 8779 V.075.5.00.703 BEARING V/R Spare Part 2018 15% 8780 V.093.5.00.003 BEARING V/R Spare Part 782 15% 8781 W.006.3.20.003 BEARING TW 6R1080 (U & L) Spare Part 815 15% 8782 W.019.9.00.003 SET OF BEARING TW: TV1 Spare Part 126 15% 8783 W.038.9.00.003 BEARING TW: RA3 Spare Part 108 15% 8784 W.038.9.10.003 THRUST WASHER: IG RA3 Spare Part 108 15% 8785 W.055.5.00.003 BEARING TW: SL90 Spare Part 849 15% 8786 W.073.5.00.003 BEARING TW KIR HA 394 Spare Part 840 15%	8774	V.038.5.01.703	BEARING V/R	Spare Part	914	15%
8777 V.074.5.00.003 BEARING V/R Spare Part 1209 15% 8778 V.074.5.00.703 BEARING V/R: HA494 STD UB Spare Part 1182 15% 8779 V.075.5.00.703 BEARING V/R Spare Part 2018 15% 8780 V.093.5.00.003 BEARING V/R Spare Part 782 15% 8781 W.006.3.20.003 BEARING TW 6R1080 (U & L) Spare Part 815 15% 8782 W.019.9.00.003 SET OF BEARING TW: TV1 Spare Part 126 15% 8783 W.038.9.00.003 BEARING TW: RA3 Spare Part 108 15% 8784 W.038.9.10.003 THRUST WASHER: IG RA3 Spare Part 108 15% 8785 W.055.5.00.003 BEARING TW: SL90 Spare Part 938 15% 8786 W.073.5.00.003 BEARING TW KIR HA 394 Spare Part 840 15%						
8778 V.074.5.00.703 BEARING V/R: HA494 STD UB Spare Part 1182 15% 8779 V.075.5.00.703 BEARING V/R Spare Part 2018 15% 8780 V.093.5.00.003 BEARING V/R Spare Part 782 15% 8781 W.006.3.20.003 BEARING TW 6R1080 (U & L) Spare Part 815 15% 8782 W.019.9.00.003 SET OF BEARING TW: TV1 Spare Part 126 15% 8783 W.038.9.00.003 BEARING TW: RA3 Spare Part 375 15% 8784 W.038.9.10.003 THRUST WASHER: IG RA3 Spare Part 108 15% 8785 W.055.5.00.003 BEARING TW: SL90 Spare Part 938 15% 8786 W.073.5.00.003 BEARING Spare Part 849 15% 8787 W.073.7.00.003 BEARING TW KIR HA 394 Spare Part 840 15%				· ·		
8779 V.075.5.00.703 BEARING V/R Spare Part 2018 15% 8780 V.093.5.00.003 BEARING T/W 6R1080 (U & L) Spare Part 782 15% 8781 W.006.3.20.003 BEARING T/W 6R1080 (U & L) Spare Part 815 15% 8782 W.019.9.00.003 SET OF BEARING T/W: TV1 Spare Part 126 15% 8783 W.038.9.00.003 BEARING T/W: RA3 Spare Part 375 15% 8784 W.038.9.10.003 THRUST WASHER: IG RA3 Spare Part 108 15% 8785 W.055.5.00.003 BEARING T/W: SL90 Spare Part 938 15% 8786 W.073.5.00.003 BEARING Spare Part 849 15% 8787 W.073.7.00.003 BEARING T/W KIR HA 394 Spare Part 840 15%				·		
8780 V.093.5.00.003 BEARING V/R Spare Part 782 15% 8781 W.006.3.20.003 BEARING TW 6R1080 (U & L) Spare Part 815 15% 8782 W.019.9.00.003 SET OF BEARING TW: TV1 Spare Part 126 15% 8783 W.038.9.00.003 BEARING TW: RA3 Spare Part 375 15% 8784 W.038.9.10.003 THRUST WASHER: IG RA3 Spare Part 108 15% 8785 W.055.5.00.003 BEARING TW: SL90 Spare Part 938 15% 8786 W.073.5.00.003 BEARING Spare Part 849 15% 8787 W.073.7.00.003 BEARING TW KIR HA 394 Spare Part 840 15%						
8781 W.006.3.20.003 BEARING TW 6R1080 (U & L) Spare Part 815 15% 8782 W.019.9.00.003 SET OF BEARING TW: TV1 Spare Part 126 15% 8783 W.038.9.00.003 BEARING TW: RA3 Spare Part 375 15% 8784 W.038.9.10.003 THRUST WASHER: IG RA3 Spare Part 108 15% 8785 W.055.5.00.003 BEARING TW: SL90 Spare Part 938 15% 8786 W.073.5.00.003 BEARING Spare Part 849 15% 8787 W.073.7.00.003 BEARING TW KIR HA 394 Spare Part 840 15%				·		
8782 W.019.9.00.003 SET OF BEARING T/W: TV1 Spare Part 126 15% 8783 W.038.9.00.003 BEARING T/W: RA3 Spare Part 375 15% 8784 W.038.9.10.003 THRUST WASHER: IG RA3 Spare Part 108 15% 8785 W.055.5.00.003 BEARING T/W: SL90 Spare Part 938 15% 8786 W.073.5.00.003 BEARING Spare Part 849 15% 8787 W.073.7.00.003 BEARING T/W KIR HA 394 Spare Part 840 15%				·		
8783 W.038.9.00.003 BEARING TW: RA3 Spare Part 375 15% 8784 W.038.9.10.003 THRUST WASHER: IG RA3 Spare Part 108 15% 8785 W.055.5.00.003 BEARING TW: SL90 Spare Part 938 15% 8786 W.073.5.00.003 BEARING Spare Part 849 15% 8787 W.073.7.00.003 BEARING TW KIR HA 394 Spare Part 840 15%						
8784 W.038.9.10.003 THRUST WASHER: IG RA3 Spare Part 108 15% 8785 W.055.5.00.003 BEARING TW: SL90 Spare Part 938 15% 8786 W.073.5.00.003 BEARING Spare Part 849 15% 8787 W.073.7.00.003 BEARING TW KIR HA 394 Spare Part 840 15%				·		
8785 W.055.5.00.003 BEARING TW: SL90 Spare Part 938 15% 8786 W.073.5.00.003 BEARING Spare Part 849 15% 8787 W.073.7.00.003 BEARING TW KIR HA 394 Spare Part 840 15%						
8786 W.073.5.00.003 BEARING Spare Part 849 15% 8787 W.073.7.00.003 BEARING TW KIR HA 394 Spare Part 840 15%				· ·		
8787 W.073.7.00.003 BEARING T/W KIR HA 394 Spare Part 840 15%						
1 8788 IW 647 6 00 003 THDLIST WASHED Soore Bort 2001 460/	8788	W.547.5.00.003	THRUST WASHER	Spare Part	2391	15%
						15%