#Write an assembly language program to convert a BCD number into Binary. **LDA 2000** ANI OF; MOV B,A; LDA 2000H; ANI FO **RLC RLC RLC RLC** MOV D,A; **MVI A,00H**; MVI C,OAH; **BACK: ADD D** DCR C JNZ BACK ADD B **STA 2001H**

HLT