#Write an assembly language program to generate time delay.

```
MVI A,FFH
LOOP: NOP;
NOP;
NOP;
DCR A;
JNZ LOOP;
HLT
```