12/8/24 EX-No:26 Make your own Ethornet come-overcety

Tads/parts orequired

entified for gigabit support, but CATS cabling works as well, just over works distance.

* Two Ri45 plugs
* optional two plugs shields

Steps:

Steps: To start construction of Ma davice, begin by threating shield onto the calle.

Stop = = Nort Staip approximately 1.500 of cable shelding from both ords. The orimping toll has a round area to complete the task.

Steps: After, you will need to utargle the wire, three should be four "kwinked grivis."
Referencing back to the sheet, arrange then from top to Rotton. one and should be in avangement A and and other in I

Step 4:

once the order is correct, bunch then together is a line, and If there are that stick out of without then other, imp them back to create and even level. The different expect is planning there into RI45 plug without mossessing up the order to do so hold the plug with the side facing away from you and have the goi pins forwards you as shown.

Stop 5:

Next, push the cable sight in. The nutch at the end of the play need to be just over the able shedding and inm. I the means that you strapped off too much shedding, simply ship the cables buch a little more

Stop 6:

After the wive we securely riting invite the plug invoit into the crownping tool a push down.

Step 7:

Lostly, repeat for the other and wing diagrams (to make a orange cables) wing diagram A.