


---

```
clc;
clear;
close all;
snr = 0:5:30;
snr_linear = 10.^(snr/10);
capacity = log2(1 + snr_linear);
figure;
plot(snr,capacity, '-o', 'LineWidth',2, 'MarkerSize',6);
grid on;
xlabel('SNR (dB)');
ylabel('Channel Capacity (bps/Hz)');
title('Channel Capacity vs SNR');
```



*Published with MATLAB® R2026a*